




# HEIDENHAIN

## Technical Manual

# MANUALplus 620

NC Software  
548 328-04



January 2012



# Contents

<b>1</b>	<b>Update Information No. 1</b>	<b>19</b>
1.1	Overview	19
1.2	NC Software 548 328-02	19
1.2.1	Important notes on updating software	19
1.2.2	Description of the new functions	26
<b>1</b>	<b>Update Information No. 2</b>	<b>37</b>
1.1	Overview	37
1.2	NC Software 548 328-03	37
1.2.1	Important notes on updating software	37
1.2.2	Description of the new functions	39
<b>1</b>	<b>Update Information No. 3</b>	<b>47</b>
1.1	Hardware	47
1.1.1	UEC 11x controller unit with inverter and PLC I/O	47
<b>1</b>	<b>Update Information No. 4</b>	<b>51</b>
1.1	Overview	51
1.1.1	Released service packs	51
1.1.2	Released NC software	51
1.2	NC Software 548 328-03	51
1.3	NC Software 548 328-04	52
1.3.1	Important change made in the technical manual	52
1.3.2	Important notes on updating software	53
1.3.3	Description of the new functions	57
1.4	Hardware	78
1.4.1	CMA-H SPI module for analog axes	78

<b>2</b>	<b>Introduction.....</b>	<b>79</b>
<b>2.1</b>	<b>Meaning of the Symbols Used in this Manual .....</b>	<b>79</b>
<b>2.2</b>	<b>Proper and Intended Operation .....</b>	<b>79</b>
<b>2.3</b>	<b>Trained Personnel .....</b>	<b>79</b>
<b>2.4</b>	<b>General Information.....</b>	<b>80</b>
2.4.1	HSCI interface.....	83
<b>2.5</b>	<b>Component Overview of MANUALplus 620.....</b>	<b>84</b>
2.5.1	MC main computer, CFR memory card and SIK.....	84
2.5.2	SIK (System Identification Key).....	86
2.5.3	CC 61xx controller units.....	86
2.5.4	UEC 11x controller unit with integrated inverter and PLC ....	87
2.5.5	PLC input/output systems with HSCI interface .....	89
2.5.6	SPI expansion modules.....	93
2.5.7	PSL 13x low-voltage power supply unit.....	94
2.5.8	MB 620T machine operating panel .....	96
2.5.9	HSCI adapter for PLB 6001 OEM-specific machine operating panel .....	97
2.5.10	Handwheels.....	98
2.5.11	Key symbols.....	101
2.5.12	Touch probes .....	106
2.5.13	Other accessories .....	109
2.5.14	Documentation .....	110
<b>2.6</b>	<b>Brief Description.....</b>	<b>111</b>
2.6.1	Specifications for MANUALplus 620 .....	111
2.6.2	User functions.....	117
2.6.3	Software options.....	122
2.6.4	Accessories.....	123
<b>2.7</b>	<b>Software .....</b>	<b>125</b>
2.7.1	Designation of the software .....	125
2.7.2	PLC software .....	125
2.7.3	Additional control loops or software options .....	126
2.7.4	Configurations.....	136
2.7.5	Coordinate system of the lathe.....	137
2.7.6	NC software exchange on the MANUALplus 620 .....	137
2.7.7	Installing a service pack .....	143
2.7.8	Reversing a software update .....	144
2.7.9	Special features of the software.....	146
2.7.10	Firmware update on HSCI devices .....	147
2.7.11	Monitoring hardware changes .....	149
2.7.12	Data backup .....	149
<b>2.8</b>	<b>Software Releases .....</b>	<b>150</b>
2.8.1	NC software 548 328-xx .....	150



<b>3</b>	<b>Mounting and Electrical Installation.....</b>	<b>151</b>
<b>3.1</b>	<b>General Information.....</b>	<b>151</b>
3.1.1	Safety precautions .....	151
3.1.2	Degrees of protection .....	152
3.1.3	Electromagnetic compatibility .....	152
3.1.4	ESD protection.....	153
<b>3.2</b>	<b>Environmental Conditions .....</b>	<b>155</b>
3.2.1	Storage and operating temperatures .....	155
3.2.2	Heat generation and cooling .....	157
3.2.3	Limit values for ambient conditions .....	158
3.2.4	Installation elevation .....	158
3.2.5	UEC 11x (FS) mounting position .....	159
3.2.6	MC 6110T mounting position .....	160
3.2.7	CC 61xx, UV xxx, UM xxx, UE 2xx B(D) mounting position .....	161
3.2.8	PLB 6xxx mounting position .....	162
<b>3.3</b>	<b>Overview of Components .....</b>	<b>163</b>
<b>3.4</b>	<b>HSCI.....</b>	<b>168</b>
3.4.1	Introduction.....	168
3.4.2	Topology .....	170
3.4.3	HSCI interface.....	171
<b>3.5</b>	<b>MANUALplus 620 Connection Overview .....</b>	<b>172</b>
3.5.1	MC 6110T main computer .....	172
3.5.2	CC 6106 .....	173
3.5.3	CC 6108 .....	174
3.5.4	CC 6110 .....	175
3.5.5	UEC 11x.....	176
3.5.6	PLB 62xx.....	177
3.5.7	PLB 61xx.....	177
3.5.8	PLD-H and PLA-H I/O modules.....	178
<b>3.6</b>	<b>Supply Voltages in the HSCI System.....</b>	<b>180</b>
3.6.1	Current consumption of the HSCI components.....	182
3.6.2	X90: +24 V NC output of the UxC 11x (FS).....	183
3.6.3	X101: NC power supply .....	184
3.6.4	Power supply of the CC 61xx .....	185
3.6.5	PSL 13x low-voltage power supply unit.....	189
<b>3.7</b>	<b>MS 110 / MS 111 Installation Kit for Double-Row Configuration ....</b>	<b>199</b>
3.7.1	General information .....	199
3.7.2	Double-row configuration.....	200
3.7.3	Connection overview .....	202
<b>3.8</b>	<b>UxC 11x (FS): Power Supply and Motor Connection.....</b>	<b>206</b>
3.8.1	UEC 11x (FS).....	206
<b>3.9</b>	<b>UxC 11x (FS): Meaning of the LEDs.....</b>	<b>212</b>
<b>3.10</b>	<b>Power Supply for PLC Outputs.....</b>	<b>214</b>
<b>3.11</b>	<b>Power Supply for PLB 6xxx (FS) .....</b>	<b>216</b>
<b>3.12</b>	<b>Meaning of the LED on PLB 6xxx .....</b>	<b>217</b>
<b>3.13</b>	<b>Power Supply for Control-Is-Ready Signal .....</b>	<b>217</b>
<b>3.14</b>	<b>Drive Controller Enable .....</b>	<b>218</b>

<b>3.15</b>	<b>Digital PLC Inputs/Outputs</b> .....	<b>219</b>
3.15.1	UxC 11x (FS): Digital PLC inputs/outputs.....	228
<b>3.16</b>	<b>Analog PLC Inputs/Outputs</b> .....	<b>235</b>
<b>3.17</b>	<b>PROFIBUS Connection</b> .....	<b>237</b>
<b>3.18</b>	<b>Configuring the PLC Inputs/Outputs with IOconfig</b> .....	<b>238</b>
<b>3.19</b>	<b>Buffer Battery</b> .....	<b>241</b>
<b>3.20</b>	<b>Encoder Connections</b> .....	<b>242</b>
3.20.1	General information .....	242
3.20.2	Position encoder input .....	243
3.20.3	Speed encoder input .....	246
<b>3.21</b>	<b>Adapters for Encoder Signals</b> .....	<b>250</b>
<b>3.22</b>	<b>Connecting the Motor Power Modules (Only CC 61xx)</b> .....	<b>254</b>
<b>3.23</b>	<b>Analog Nominal Value Output</b> .....	<b>255</b>
3.23.1	CMA-H 04-04-00 – Pin layout.....	257
<b>3.24</b>	<b>Touch Probe Systems</b> .....	<b>260</b>
<b>3.25</b>	<b>Data Interfaces</b> .....	<b>265</b>
3.25.1	USB interface (USB 2.0).....	268
<b>3.26</b>	<b>MB 620T Machine Operating Panel</b> .....	<b>269</b>
<b>3.27</b>	<b>HSCI Adapter for PLB 6001 OEM-Specific Machine Operating Panel</b> .....	<b>278</b>
<b>3.28</b>	<b>Handwheel Input</b> .....	<b>287</b>
3.28.1	HR 410 portable handwheel .....	287
3.28.2	HR 130 panel-mounted handwheel .....	289
3.28.3	HRA 110 handwheel adapter .....	290
<b>3.29</b>	<b>CML 110 Capacitor Module</b> .....	<b>292</b>
<b>3.30</b>	<b>Connecting Cables: Specifications</b> .....	<b>294</b>
<b>3.31</b>	<b>Dimensions</b> .....	<b>295</b>
3.31.1	MC 6110T .....	296
3.31.2	MB 620T .....	297
3.31.3	CC 6106 .....	298
3.31.4	CC 6108 / CC 6110 .....	299
3.31.5	UEC 11x (FS).....	300
3.31.6	PL 6xxx (FS) .....	301
3.31.7	PLB 6001(FS) .....	302
3.31.8	PSL 130.....	303
3.31.9	PSL 135.....	304
3.31.10	MS 11x.....	305
3.31.11	Adapter block for the data interface.....	306
3.31.12	USB hub.....	307
3.31.13	Line-drop compensator.....	308
3.31.14	Handwheels .....	308
3.31.15	Touch probes .....	311
3.31.16	CML 110 .....	318
3.31.17	USB hub for operating panel.....	318
<b>3.32</b>	<b>HSCI Connection Overview of the MANUALplus 620 with CC 61xx</b> .....	<b>319</b>
<b>3.33</b>	<b>HSCI Connection Overview of the MANUALplus 620 with UEC 11x</b> .....	<b>320</b>

<b>3.34</b>	<b>Grounding Diagram for MANUALplus 620 with Modular HEIDENHAIN Inverter System .....</b>	<b>321</b>
<b>3.35</b>	<b>Basic Circuit Diagram for MANUALplus 620 .....</b>	<b>322</b>
<b>3.36</b>	<b>Cable Overview for MANUALplus 620 with UEC 11x – Basic Configuration.....</b>	<b>323</b>
<b>3.37</b>	<b>Cable Overview for MANUALplus 620 with CC 610x – Basic Configuration.....</b>	<b>324</b>
<b>3.38</b>	<b>Cable Overview for HEIDENHAIN Inverter System.....</b>	<b>325</b>
<b>3.39</b>	<b>Cable Overview for MANUALplus 620 – Accessories .....</b>	<b>326</b>
<b>4</b>	<b>Machine Parameters.....</b>	<b>327</b>
<b>4.1</b>	<b>General Information.....</b>	<b>327</b>
<b>4.2</b>	<b>The "Machine Parameters" Mode of Operation.....</b>	<b>329</b>
4.2.1	Calling the configuration editor .....	329
4.2.2	Entering and changing machine parameters.....	331
4.2.3	Accessing machine parameters via MP numbers.....	342
4.2.4	Managing configuration files.....	345
4.2.5	Sorting file content.....	346
4.2.6	Attribute information .....	347
4.2.7	Access protection / Options.....	350
4.2.8	Update rules.....	351
4.2.9	Removing syntax errors .....	362
4.2.10	Resetting the update version .....	362
4.2.11	Backup of parameters .....	363
4.2.12	Resetting system settings .....	364
<b>4.3</b>	<b>User Parameters.....</b>	<b>365</b>
4.3.1	Configuration of the user parameters .....	366
4.3.2	Example: .....	372
4.3.3	XML commands for creating the layout files .....	374
<b>4.4</b>	<b>The KeySynonym Function .....</b>	<b>377</b>
<b>4.5</b>	<b>Allocation of Configuration Data .....</b>	<b>379</b>
<b>4.6</b>	<b>Structure of a Parameter File .....</b>	<b>380</b>
<b>4.7</b>	<b>Machine-Parameter Subfiles .....</b>	<b>383</b>
4.7.1	Syntax of machine-parameter subfile .....	383
4.7.2	Activating the machine-parameter subfile .....	384
4.7.3	Displaying/editing data records in the configuration editor .....	387
<b>4.8</b>	<b>Reading or Changing Machine Parameters via PLC Modules.....</b>	<b>389</b>
<b>4.9</b>	<b>Switching Parameter Sets .....</b>	<b>398</b>
<b>4.10</b>	<b>List of Machine Parameters .....</b>	<b>408</b>
4.10.1	"System" group.....	408
4.10.2	"Channels" group .....	490
4.10.3	"Axes" group.....	510
4.10.4	KeySynonym .....	582
4.10.5	Aggregates.....	583
4.10.6	ProcessingData .....	595

<b>5</b>	<b>Modules and PLC Operands .....</b>	<b>599</b>
<b>5.1</b>	<b>Overview of Modules.....</b>	<b>599</b>
<b>5.2</b>	<b>Overview of the PLC Operands.....</b>	<b>604</b>
5.2.1	PLC operands of the General Data group .....	604
5.2.2	PLC operands of the Operating Mode Group group .....	606
5.2.3	PLC operands of the Machining Channels group.....	607
5.2.4	PLC operands of the Axis group .....	609
5.2.5	PLC operands of the Spindle group .....	611
<b>6</b>	<b>Configuring the Axes and Spindle .....</b>	<b>613</b>
<b>6.1</b>	<b>Machine Structure .....</b>	<b>613</b>
6.1.1	Adapting the MANUALplus 620 to the machine.....	613
6.1.2	Definition of axes .....	614
<b>6.2</b>	<b>Configuration of Machining Channels .....</b>	<b>617</b>
6.2.1	Configuring a machining channel.....	617
6.2.2	Traversing the reference marks .....	621
6.2.3	Returning to the contour/block scan .....	622
<b>6.3</b>	<b>Configuration of Axes.....</b>	<b>624</b>
6.3.1	Axis designations and coordinates.....	626
6.3.2	Programmable axes .....	628
6.3.3	Physical axes.....	631
6.3.4	Kinematic properties of axes .....	641
6.3.5	Manually operated axis (counter axis).....	643
<b>6.4</b>	<b>Encoders .....</b>	<b>645</b>
6.4.1	Type of position encoder .....	645
6.4.2	Signal period of encoders .....	648
6.4.3	Distance-coded reference marks .....	654
6.4.4	Connecting the encoders, PWM output on the CC 61xx....	656
6.4.5	Connecting the encoders to the UEC 11x .....	661
6.4.6	Defining the traverse direction.....	663
6.4.7	Encoder monitoring.....	665
<b>6.5</b>	<b>Analog Axes.....</b>	<b>669</b>
6.5.1	Central drive.....	670
<b>6.6</b>	<b>Reading and Writing Axis Information .....</b>	<b>671</b>
6.6.1	Reading axis information.....	671
6.6.2	Writing axis information—activating and deactivating axes....	678
<b>6.7</b>	<b>Traverse Ranges.....</b>	<b>688</b>
<b>6.8</b>	<b>Lubrication Pulse.....</b>	<b>690</b>
<b>6.9</b>	<b>PLC Axes .....</b>	<b>692</b>
6.9.1	Hirth coupling.....	702
<b>6.10</b>	<b>Axis Error Compensation .....</b>	<b>705</b>
6.10.1	Backlash compensation .....	707
6.10.2	Linear axis error compensation.....	711
6.10.3	Nonlinear axis error compensation .....	713
6.10.4	Compensation of thermal expansion .....	721
6.10.5	Compensation of static friction .....	723
6.10.6	Compensation of sliding friction .....	724

<b>6.11</b>	<b>Machine Kinematics (As of NC Software 548328-03)</b>	<b>727</b>
6.11.1	Configuring the machine kinematics	730
6.11.2	Preconfigured subkinematics	739
6.11.3	Standard kinematic models	742
6.11.4	Finding/activating kinematics through the PLC	744
6.11.5	Axis mirroring on lathes (as of NC software 548328-03)	746
<b>6.12</b>	<b>Machine Kinematics (Up to NC Software 548 328-02)</b>	<b>747</b>
6.12.1	Configuration of the machine kinematics	748
6.12.2	Definition of the transformation with vectors	758
6.12.3	Axis mirroring for lathes	761
<b>6.13</b>	<b>Parallel Axes</b>	<b>762</b>
<b>6.14</b>	<b>Synchronized Axes (Option 24)</b>	<b>764</b>
6.14.1	Gantry axes	765
6.14.2	Master-slave torque control	775
6.14.3	Brake test for synchronized axes	784
<b>6.15</b>	<b>Reference Marks</b>	<b>789</b>
6.15.1	Definition	789
6.15.2	Traversing the reference marks	790
6.15.3	Traversing the reference marks	794
6.15.4	Defining the process of traversing the reference marks	797
6.15.5	"Traverse Reference Points" operating mode	804
<b>6.16</b>	<b>The Control Loop</b>	<b>808</b>
6.16.1	Block diagram of control loop	808
6.16.2	Relation between jerk, acceleration, velocity and distance	809
6.16.3	Nominal position value filter	811
6.16.4	Look-ahead	825
6.16.5	Interpolator	838
6.16.6	Position controller	839
6.16.7	Activating and deactivating position control loops	848
6.16.8	Feed-rate enable	852
6.16.9	Speed controller	853
6.16.10	Filters in the speed controller and position controller when using the CC 61xx and CC 424	857
6.16.11	Filter order for separate low-pass filter in the speed controller on the CC 61xx and CC 424:	861
6.16.12	Peculiarities in weakened-field operation with CC 61xx and CC 424	862
6.16.13	Active damping of low-frequency oscillations	864
6.16.14	Acceleration feedforward control	866
6.16.15	IPC, holding torque, following error in the jerk phase	869
6.16.16	HSCI: switching drives on and off, enabling the drive controller	874
6.16.17	Current controller	885
6.16.18	Braking the drives for an emergency stop and a power failure	890
6.16.19	Power and torque limiting	894
6.16.20	Controller parameters for manual traverse	901
6.16.21	Controller parameters for analog axes	902
6.16.22	Controller parameters for analog axes	913
6.16.23	Weakened field operation	924
6.16.24	Motor with wye/delta switchover	936
6.16.25	Speed-dependent switching of the PWM frequency	938
6.16.26	TRC – Torque Ripple Compensation	941
6.16.27	Torsion compensation	944

<b>6.17</b>	<b>Monitoring Functions .....</b>	<b>946</b>
6.17.1	Monitoring the drives.....	946
6.17.2	Position monitoring.....	948
6.17.3	Movement monitoring .....	953
6.17.4	Standstill monitoring .....	955
6.17.5	Positioning window.....	956
6.17.6	Monitoring of the power supply unit .....	959
6.17.7	Temperature monitoring .....	962
6.17.8	I <sup>2</sup> t monitoring .....	965
6.17.9	Momentary utilization of drive motors .....	977
6.17.10	Status of HEIDENHAIN hardware and software.....	979
6.17.11	Motor brake .....	983
6.17.12	Emergency stop monitoring.....	989
6.17.13	Monitoring functions when using the CC 61xx and CC 424 .....	996
<b>6.18</b>	<b>Spindles .....</b>	<b>998</b>
6.18.1	Configuring spindles .....	998
6.18.2	Spindle in position feedback control .....	1000
6.18.3	Spindle in speed control.....	1009
6.18.4	Filtering the acceleration values.....	1014
6.18.5	Controlling the spindle .....	1015
6.18.6	Switching the operating modes .....	1029
6.18.7	Analog spindle with unipolar motor .....	1032
6.18.8	Spindle synchronism.....	1033
6.18.9	Spindle of the kinematics model (as of NC software 548 328-03) .....	1036
6.18.10	Spindle of the kinematics model (until NC software 548 328-02) .....	1037
6.18.11	Gear shifting.....	1038
6.18.12	Tapping .....	1039
6.18.13	C-axis operation .....	1040
6.18.14	Volts-per-hertz control mode.....	1042
<b>6.19</b>	<b>Configuring the Controller Unit and Drive Motors .....</b>	<b>1044</b>
6.19.1	Specifications of CC 61xx / UEC 1xx .....	1044
6.19.2	Structure of the CC 61xx and UEC 11x controller units....	1046
6.19.3	PWM frequencies with the CC 61xx .....	1048
6.19.4	PWM frequency with INDRAMAT "POWER DRIVE" inverters ...	1050
6.19.5	PWM frequency with SIEMENS "SIMODRIVE" inverters ..	1050
6.19.6	Comparison of the CC 61xx and CC 424 controller units..	1053
6.19.7	Configuring the drive motor .....	1055
6.19.8	Field orientation .....	1058
6.19.9	Determining the field angle with the CC 61xx und CC 424 .....	1061
<b>6.20</b>	<b>Commissioning .....</b>	<b>1072</b>
6.20.1	Tables for power modules, supply modules and motors..	1072
6.20.2	Field orientation .....	1084
6.20.3	Preparation.....	1084
6.20.4	Commissioning of digital axes .....	1089
6.20.5	Commissioning of analog axes .....	1104
6.20.6	Configuring the nominal position value filter and look-ahead parameters.....	1124
6.20.7	Commissioning the digital spindle .....	1140

<b>6.21</b>	<b>Integrated Oscilloscope</b> .....	<b>1145</b>
6.21.1	Fundamentals .....	1145
6.21.2	Preparing a recording .....	1147
6.21.3	Recording signals .....	1151
6.21.4	Analyzing the recording .....	1154
6.21.5	Saving and loading recordings .....	1157
6.21.6	Circular interpolation test with the integrated oscilloscope ...	1158
6.21.7	Configuring the colors of the oscilloscope display .....	1159
<b>6.22</b>	<b>Diagnosis with the Online Monitor (OLM)</b> .....	<b>1162</b>
6.22.1	Introduction .....	1162
6.22.2	Using the OLM .....	1163
6.22.3	Screen layout .....	1165
6.22.4	Group of NC axes .....	1168
6.22.5	Group of spindle commands .....	1188
6.22.6	Group of NC channels .....	1190
6.22.7	Hardware group .....	1196
6.22.8	Group of drive commands .....	1209
6.22.9	Auxiliary group .....	1210
6.22.10	PLC group .....	1216
6.22.11	Queue trace .....	1219
6.22.12	Frequent causes of error .....	1221
<b>7</b>	<b>Machine Interfacing</b> .....	<b>1223</b>
<b>7.1</b>	<b>Display and Operation</b> .....	<b>1223</b>
7.1.1	Unit of measurement for display and operation .....	1223
7.1.2	Conversational language .....	1225
7.1.3	Expanded menu structure .....	1228
7.1.4	Access rights to NC files .....	1230
7.1.5	Code numbers .....	1230
7.1.6	Programming station mode .....	1233
7.1.7	Operating modes / control operation in the operating mode group .....	1236
7.1.8	Control operation in the machining channel .....	1241
7.1.9	Error messages and log files .....	1254
7.1.10	TURNguide – context-sensitive help system (user documentation) .....	1278
<b>7.2</b>	<b>Machine Display in the Dashboard</b> .....	<b>1287</b>
7.2.1	Assigning dashboards to the operating modes .....	1289
7.2.2	Configuring dashboards .....	1292
<b>7.3</b>	<b>PLC Soft Keys</b> .....	<b>1307</b>
7.3.1	Soft-key resource file .....	1308
<b>7.4</b>	<b>Switching the Control On/Off</b> .....	<b>1313</b>
7.4.1	Powering up the control .....	1313
7.4.2	Shutting down the control .....	1317
<b>7.5</b>	<b>Keystroke Simulation</b> .....	<b>1325</b>
7.5.1	Control keyboard .....	1325
7.5.2	Machine operating panel .....	1331

<b>7.6</b>	<b>Electronic Handwheel</b> .....	<b>1333</b>
7.6.1	Serial handwheel.....	1333
7.6.2	Handwheel at position encoder input.....	1339
7.6.3	Traverse per handwheel revolution.....	1344
7.6.4	Assigning a handwheel to an axis.....	1345
7.6.5	HR 410 portable handwheel.....	1348
7.6.6	HR 150 panel-mounted handwheels with HRA 110 handwheel adapter.....	1350
<b>7.7</b>	<b>Override</b> .....	<b>1352</b>
7.7.1	Override devices.....	1352
7.7.2	Override functions.....	1354
7.7.3	Compensation for potentiometers.....	1360
<b>7.8</b>	<b>PLC Inputs/Outputs</b> .....	<b>1361</b>
7.8.1	Diagnosis of the external PL.....	1361
7.8.2	24 V– switching input/outputs.....	1365
7.8.3	Analog inputs.....	1368
7.8.4	Analog outputs.....	1371
<b>7.9</b>	<b>Operating Times and System Times</b> .....	<b>1373</b>
7.9.1	Measuring operating times.....	1373
7.9.2	System time.....	1379
<b>7.10</b>	<b>Touch Probe</b> .....	<b>1381</b>
7.10.1	Tool measurement.....	1384
<b>7.11</b>	<b>Additional Parameters for Lathes</b> .....	<b>1388</b>
7.11.1	Coordinate system of the lathe.....	1388
7.11.2	Linear axes.....	1389
7.11.3	Spindles.....	1391
7.11.4	C axis.....	1393
7.11.5	Tailstock and steady rest.....	1395
7.11.6	Tool carriers.....	1396
7.11.7	Tool holders (mounts).....	1400
7.11.8	Transfer of data to the PLC.....	1404
7.11.9	Conversions.....	1408
7.11.10	Global settings.....	1408
7.11.11	Settings for cycles.....	1418
7.11.12	Settings for smart.Turn operating mode.....	1419
7.11.13	Settings for the simulation.....	1422
7.11.14	User parameters.....	1427
<b>7.12</b>	<b>Configuration of the Lathe</b> .....	<b>1428</b>
7.12.1	Coordinate system.....	1428
7.12.2	Settings for linear axes.....	1429
7.12.3	Settings for spindles.....	1430
7.12.4	Driven tool.....	1432
7.12.5	Settings for the C axis.....	1434
7.12.6	Configuring the Y axis.....	1439
7.12.7	Configuring parallel axes.....	1446
7.12.8	Activating gantry axes.....	1452
7.12.9	Configuring rear-side machining.....	1455
7.12.10	Traversing to a fixed stop (G916) and sleeve monitoring (G930).....	1464
7.12.11	Configuring the tool carrier.....	1470
7.12.12	Expert programs.....	1476
7.12.13	Manual programs.....	1478



<b>8</b>	<b>PLC Programming</b>	<b>1481</b>
<b>8.1</b>	<b>PLC Functions</b>	<b>1481</b>
8.1.1	The API 3.0 symbolic memory interface	1482
8.1.2	HEIDENHAIN PLC basic program	1486
8.1.3	Selecting the PLC programming mode of operation	1487
8.1.4	PLC main menu	1487
8.1.5	File management	1489
8.1.6	The API DATA function	1490
8.1.7	The WATCH LIST function	1491
8.1.8	The TABLE function	1493
8.1.9	The TRACE function	1495
8.1.10	The COMPILE function	1497
8.1.11	The EDIT function	1498
8.1.12	Diagnostic functions	1501
8.1.13	Bus diagnosis	1502
<b>8.2</b>	<b>PLC Compiler</b>	<b>1509</b>
8.2.1	Configuration file for the PLC compiler	1509
8.2.2	Conditional compilation	1514
<b>8.3</b>	<b>Configuring PLC Input/Output Systems</b>	<b>1516</b>
<b>8.4</b>	<b>Operands</b>	<b>1518</b>
8.4.1	Overview of operands	1518
8.4.2	Operand addressing (byte, word, double word)	1521
8.4.3	Timers and counters	1522
8.4.4	Fast PLC inputs	1532
<b>8.5</b>	<b>Data Organization</b>	<b>1534</b>
8.5.1	Data organization on the CFR memory card	1534
8.5.2	Data organization on the hard disk	1536
8.5.3	Compressing graphic files	1537
8.5.4	Configuring the displayed drives and directories in the file manager	1538
8.5.5	PLC system files	1540
<b>8.6</b>	<b>M Functions (M Strobe)</b>	<b>1548</b>
8.6.1	Assigning M functions to the machining channels	1548
8.6.2	Configuration of M functions	1549
8.6.3	Overview of M functions of the MANUALplus 620	1558
<b>8.7</b>	<b>S Function (S Strobe)</b>	<b>1560</b>
8.7.1	Assigning S functions to the machining channels	1560
8.7.2	Configuration of S function	1561
<b>8.8</b>	<b>T Functions (T Strobe)</b>	<b>1574</b>
8.8.1	Assigning T functions to the machining channels	1574
8.8.2	Configuration of T functions	1575
<b>8.9</b>	<b>Alias Functions (Alias Strobe)</b>	<b>1582</b>
8.9.1	Assigning alias functions to the machining channels	1582
8.9.2	Configuration of alias functions	1583
<b>8.10</b>	<b>Python Settings (Option 46)</b>	<b>1585</b>
<b>8.11</b>	<b>User-Defined Cycles</b>	<b>1588</b>

<b>8.12 Tables</b>	<b>1589</b>
8.12.1 Table types of the MANUALplus 620	1590
8.12.2 Creating a new table type	1593
8.12.3 Defining the path for OEM tables	1605
8.12.4 Symbolic names for tables	1605
8.12.5 Editing tables via the PLC	1606
8.12.6 Access to tables via SQL commands	1621
8.12.7 PLC modules for the SQL statements	1635
<b>8.13 Data Transfer NC =&gt; PLC, PLC =&gt; NC</b>	<b>1654</b>
8.13.1 Introduction	1654
8.13.2 Data transfer NC program => PLC	1654
8.13.3 Data transfer machine parameters => PLC	1657
<b>8.14 Program Creation</b>	<b>1659</b>
8.14.1 ASCII editor	1659
8.14.2 Program format	1659
8.14.3 Program structure	1660
<b>8.15 Command Set</b>	<b>1661</b>
8.15.1 Overview	1661
8.15.2 LOAD (L)	1664
8.15.3 LOAD NOT (LN)	1666
8.15.4 LOAD TWO'S COMPLEMENT (L-)	1668
8.15.5 LOAD BYTE (LB)	1669
8.15.6 LOAD WORD (LW)	1669
8.15.7 LOAD DOUBLE WORD (LD)	1670
8.15.8 ASSIGN (=)	1670
8.15.9 ASSIGN BYTE (B=)	1671
8.15.10 ASSIGN WORD (W=)	1672
8.15.11 ASSIGN DOUBLE WORD (D=)	1672
8.15.12 ASSIGN NOT (=N)	1673
8.15.13 ASSIGN TWO'S COMPLEMENT (=-)	1673
8.15.14 SET (S)	1674
8.15.15 RESET (R)	1675
8.15.16 SET NOT (SN)	1676
8.15.17 RESET NOT (RN)	1677
8.15.18 AND (A)	1678
8.15.19 AND NOT (AN)	1680
8.15.20 OR (O)	1682
8.15.21 OR NOT (ON)	1684
8.15.22 EXCLUSIVE OR (XO)	1686
8.15.23 EXCLUSIVE OR NOT (XON)	1688
8.15.24 ADDITION (+)	1690
8.15.25 SUBTRACTION (-)	1691
8.15.26 MULTIPLICATION (X)	1692
8.15.27 DIVISION (/)	1693
8.15.28 REMAINDER (MOD)	1694
8.15.29 INCREMENT (INC)	1695
8.15.30 DECREMENT (DEC)	1695
8.15.31 EQUAL TO (==)	1696
8.15.32 LESS THAN (<)	1697
8.15.33 GREATER THAN (>)	1698
8.15.34 LESS THAN OR EQUAL TO (<=)	1699
8.15.35 GREATER THAN OR EQUAL TO (>=)	1700
8.15.36 NOT EQUAL (<>)	1701

8.15.37	AND [ ] (A[ ])	1702
8.15.38	AND NOT [ ] (AN[ ])	1704
8.15.39	OR [ ] (O[ ])	1704
8.15.40	OR NOT [ ] (ON[ ])	1704
8.15.41	EXCLUSIVE OR [ ] (XO[ ])	1704
8.15.42	EXCLUSIVE OR NOT [ ] (XON[ ])	1704
8.15.43	ADDITION [ ] (+[ ])	1705
8.15.44	SUBTRACT [ ] (-[ ])	1706
8.15.45	MULTIPLY [ ] (x[ ])	1706
8.15.46	DIVIDE [ ] (/ [ ])	1706
8.15.47	REMAINDER [ ] (MOD[ ])	1706
8.15.48	EQUAL TO [ ] (=[ ])	1707
8.15.49	LESS THAN [ ] (<[ ])	1708
8.15.50	GREATER THAN [ ] (>[ ])	1708
8.15.51	LESS THAN OR EQUAL TO [ ] (<=[ ])	1708
8.15.52	GREATER THAN OR EQUAL TO [ ] (>=[ ])	1708
8.15.53	NOT EQUAL [ ] (<>[ ])	1708
8.15.54	SHIFT LEFT (<<)	1709
8.15.55	SHIFT RIGHT (>>)	1710
8.15.56	BIT SET (BS)	1710
8.15.57	BIT CLEAR (BC)	1711
8.15.58	BIT TEST (BT)	1712
8.15.59	PUSH DATA ONTO THE DATA STACK (PS)	1713
8.15.60	PULL DATA FROM THE DATA STACK (PL)	1714
8.15.61	PUSH LOGIC ACCUMULATOR ONTO THE DATA STACK (PSL)	1714
8.15.62	PUSH WORD ACCUMULATOR ONTO THE DATA STACK (PSW)	1715
8.15.63	PULL LOGIC ACCUMULATOR FROM THE DATA STACK (PLL)	1715
8.15.64	PULL WORD ACCUMULATOR FROM THE DATA STACK (PLW)	1716
8.15.65	UNCONDITIONAL JUMP (JP)	1716
8.15.66	JUMP IF LOGIC ACCUMULATOR = 1 (JPT)	1717
8.15.67	JUMP IF LOGIC ACCUMULATOR = 0 (JPF)	1718
8.15.68	CALL MODULE (CM)	1718
8.15.69	CALL MODULE IF LOGIC ACCUMULATOR = 1 (CMT)	1718
8.15.70	CALL MODULE IF LOGIC ACCUMULATOR = 0 (CMF)	1719
8.15.71	END OF MODULE, END OF PROGRAM (EM)	1720
8.15.72	END OF MODULE IF LOGIC ACCUMULATOR = 1 (EMT)	1720
8.15.73	END OF MODULE IF LOGIC ACCUMULATOR = 0 (EMF)	1720
8.15.74	LABEL (LBL)	1720
<b>8.16</b>	<b>INDEX Register (X Register)</b>	<b>1721</b>
<b>8.17</b>	<b>Commands for String Processing</b>	<b>1723</b>
<b>8.18</b>	<b>LOAD String (L)</b>	<b>1725</b>
<b>8.19</b>	<b>ADD String (+)</b>	<b>1725</b>
<b>8.20</b>	<b>STORE String (=)</b>	<b>1725</b>
<b>8.21</b>	<b>OVERWRITE String (OVWR)</b>	<b>1726</b>
<b>8.22</b>	<b>EQUAL TO Command for String Processing (==)</b>	<b>1727</b>
<b>8.23</b>	<b>LESS THAN Command for String Processing (&lt;)</b>	<b>1727</b>
<b>8.24</b>	<b>GREATER THAN Command for String Processing (&gt;)</b>	<b>1727</b>

<b>8.25</b>	<b>LESS THAN OR EQUAL TO Command for String Processing (&lt;=)</b> .....	<b>1728</b>
<b>8.26</b>	<b>GREATER THAN OR EQUAL TO Command for String Processing (&gt;=)</b> .....	<b>1728</b>
<b>8.27</b>	<b>NOT EQUAL Command for String Processing (&lt;&gt;)</b> .....	<b>1729</b>
<b>8.28</b>	<b>Modules for string processing</b> .....	<b>1730</b>
<b>8.29</b>	<b>Submit Programs</b> .....	<b>1733</b>
<b>8.30</b>	<b>Calling the Submit Program (SUBM)</b> .....	<b>1734</b>
<b>8.31</b>	<b>Interrogating the Status of a Submit Program (RPLY)</b> .....	<b>1734</b>
<b>8.32</b>	<b>Canceling a Submit Program (CAN)</b> .....	<b>1735</b>
<b>8.33</b>	<b>Cooperative Multitasking</b> .....	<b>1737</b>
	8.33.1 Starting a parallel process (SPAWN) .....	1737
	8.33.2 Control of events .....	1737
<b>8.34</b>	<b>Constants Field (KF)</b> .....	<b>1744</b>
<b>8.35</b>	<b>Program Structures</b> .....	<b>1745</b>
	8.35.1 IF ... ELSE ... ENDI structure.....	1746
	8.35.2 REPEAT ... UNTIL structure.....	1746
	8.35.3 WHILE ... ENDW structure .....	1747
<b>8.36</b>	<b>CASE Branch</b> .....	<b>1748</b>
<b>8.37</b>	<b>Linking Files</b> .....	<b>1749</b>
<b>8.38</b>	<b>USES Statement (USES)</b> .....	<b>1750</b>
<b>8.39</b>	<b>GLOBAL Statement (GLOBAL)</b> .....	<b>1751</b>
<b>8.40</b>	<b>EXTERN Statement (EXTERN)</b> .....	<b>1751</b>
<b>8.41</b>	<b>PLC Modules</b> .....	<b>1752</b>
	8.41.1 Markers, bytes, words, and double words .....	1752
	8.41.2 Number conversion.....	1755

<b>9</b>	<b>Data Interfaces .....</b>	<b>1759</b>
9.1	Introduction .....	1759
9.2	The Ethernet Interface .....	1760
9.3	HSCI interface .....	1761
9.4	The USB Interface of the Control (USB 2.0) .....	1763
9.5	The Serial Interface of the Control .....	1766
9.5.1	RS-232-C/V.24 interface .....	1766
9.5.2	RS-422/V.11 interface .....	1769
9.6	Configuring the Serial Interface .....	1771
9.6.1	Control characters .....	1771
9.6.2	Configuration of interfaces .....	1772
9.7	Data Transmission Protocols .....	1783
9.7.1	Standard communications protocol .....	1783
9.7.2	Communications protocol with block check character .....	1785
9.7.3	LSV2 transmission protocol .....	1788
9.8	Saving and Loading Files .....	1789
9.9	Configuring the Control for TeleService 2.0 .....	1790
9.10	The Transfer Mode of Operation .....	1793
9.10.1	Selective parameter backup .....	1794
9.11	Data Transfer by PLC .....	1795
9.11.1	PLC modules .....	1795
<b>10</b>	<b>Index .....</b>	<b>1807</b>



# 1 Update Information No. 1

## 1.1 Overview

## 1.2 NC Software 548 328-02

### 1.2.1 Important notes on updating software

Please remember the following important information when updating the software versions listed below:

■ **MANUALplus 620: 548 328-01 to 548 328-02**



Note

If you are using linear encoders with EnDat interface or motor encoders with EnDat interface for position measurement on your machine, you must carry out the following step.

■ **Moving the EnDat axes to known positions before the update:**

A function for monitoring the SRAM contents for consistency is introduced with the new NC software. After the software update, all EnDat axes will therefore display the error message **S-RAM contents of axis are invalid**. At the same time, the control will display a dialog box for confirmation, in which the current (the displayed) position of the axis is compared with the physical (switch-off) position.

- ▶ Move the axes to known positions before the update.
- ▶ Write down the switch-off positions.
- ▶ After the control has booted with the new software for the first time, confirm the positions of the EnDat axes.



Note

HEIDENHAIN recommends:

Making a backup of the control (e.g. with TNCbackup) before updating the NC software.

Saving your current machine configuration. The configuration editor (DATA BACKUP soft key) can be used for this purpose.

If you later want to undo the software update and return to the previous software version, you need the saved configuration data of the old version!



Note

Please perform the update of the NC software as described in the Technical Manual in Chapter 2 "NC Software Exchange".



Note

Be sure to remember the important information about the software update, which is provided on the following pages.

### ■ **Checking and saving new machine parameters:**

After having installed the new NC software and rebooted the control, you must check and confirm the new machine parameters. The code number dialog box appears on the screen:

- ▶ Enter the MP code number **95148** and confirm your entry with the ENT key.
- ▶ Press the **UPDATE RULES** soft key.  
Check the listed update rules. Each entry in the list stands for a new parameter that was added to the system by the update.
- ▶ Exit the **UPDATE RULES** with the **END** soft key.
- ▶ Press the **CONFIG DATA** soft key.  
Before the configuration editor opens, an informational window is displayed, reporting the removal of the CfgRestorePosition machine parameter. Press the **NEXT** soft key.
- ▶ All new machine parameters are marked with a red exclamation point in the configuration editor. The control indicates if certain machine parameters are faulty. Please ignore these messages for the time being.
- ▶ **Important step:** Press the **SAVE** soft key
- ▶ The **Configuration data changed** dialog box opens. Press the **SAVE** soft key again. The new machine parameters are now automatically saved in the \*.cfg files.
- ▶ Press the **END** soft key and exit the **Machine Parameter** operating mode by pressing the **END** soft key again.

The control then continues booting.



#### Note


The definition file of the symbolic programming interface API 3.0 has been expanded. The step described below must be taken for the PLC program to be compiled successfully after the update.



### ■ Replacing the **apimarker.def** file:

During the update of the NC software, a new version of the **apimarker.def** file was automatically copied to the PLC partition of the control. Proceed as follows:

- ▶ Switch to the **Organization** mode of operation.
- ▶ Enter the code number 95148 to call the **Machine Parameter** mode of operation.
- ▶ Press the **END** soft key and switch the soft-key row.
- ▶ Press the **PGMMGT** PGMMGT soft key to open the file manager.
- ▶ Switch to the PLC:\proto\plc directory.
- ▶ Copy the **apimarker.def** file to the program directory of your PLC program. Overwrite the existing **apimarker.def** file:



#### Note

You also need to copy the **apimarker.def** file to your PC, and add it to the PLCdesignNT project. Otherwise, during the next transfer of PLC project files to the control, the file might be overwritten by the old version.



#### Note

After an update, please modify the previous file **oem\_turning.mcg** as described below, and add it to the PLCdesignNT project. Otherwise, during the next transfer of PLC project files to the control, the file **oem\_turning.mcg** might be overwritten by the old version, which leads to an error.

■ **Modifying the max. number of spindles in the file `oem.mcg` or `oem_turning.mcg`:**

To modify the max. number of spindles in the PLC file `oem.mcg` or `oem_turning.mcg`, proceed as follows:

...

```
DEFINE SPINDLE_COUNT      = 6          ; (old: =4)
```

...



Note

After an update, please modify the previous file `plc.cfg` as described below, and add it to the PLCdesignNT project. Otherwise, during the next transfer of PLC project files to the control, the file `plc.cfg` might be overwritten by the old version, which leads to an error (Fatal Error Syntax).



### ■ Modifying the plc.cfg file:

The current plc.cfg file is located in the control in the directory PLC:\config\lathe\manplus\plc.cfg. You can use TNCremoNT to copy the file from the control to the PLC project, or you can use PLCdesignNT to modify the previous file in the PLC project.

- ▶ Make the following changes to the plc.cfg file:

```
CfgPlcOverrideDev (
```

```
  key:="PotentiometerF",
  source:=OVR1,
  mop:="MB",                ; This line must be added.
  mode:=LINEAR,
  values:=[]
)
```

```
CfgPlcOverrideDev (
```

```
  key:="PotentiometerS",
  source:=OVR2,
  mop:="MB",                ; This line must be added.
  mode:=LINEAR,
  values:=[]
)
```

```
CfgPlcStrobes (
```

```
  ...
  sStrobe:=[                ; Add an opening bracket
  "S1"
  ],                          ; Add a closing bracket
  ...
)
```

```
CfgPlcOverrideS (
```

```
  key:="S1",
  minimal:=0.5,
  maximal:=1.5,
  source:= [                ; Add an opening bracket
  "PotentiometerS"
  ]                          ; Add a closing bracket
```

```

)
CfgPlcOverrideS (
  key:="S2",
  minimal:=1,
  maximal:=1,
  source:= [           ; Add an opening bracket
    "PotentiometerS"
  ]           ; Add a closing bracket
)
CfgPlcOverrideF (
  key:="CH_NC1",
  minimal:=0,
  maximal:=1.5,
  source:= [           ; Add an opening bracket
    "PotentiometerF"
  ]           ; Add a closing bracket
)

CfgPlcMop (           ; Add this and all the following data
  key:="MB",
  type:=MB,
  primary:=FALSE,
  omg:=0,
  spindle:=0
)
CfgPlcMop (
  key:="HR",
  type:=HR,
  primary:=FALSE,
  omg:=0,
  spindle:=0
)

```





## Note

Please observe the following note if you are using the HEIDENHAIN PLC Basic Program!

### ■ Checking and modifying the PLC program is essential:

The behavior of the symbolic API marker **NN\_ChnProgCancel** (NC program cancelation) has been changed: **NN\_ChnProgCancel** will now be set every time the NC program is canceled. For a normal end of program, **NN\_ChnProgEnd** will be set. The **NN\_ChnProgCancel** marker remains set during the complete Cancel cycle and beyond the program end until the next NC program is started.

When a program is canceled, the **NN\_ChnProgEnd** marker will not be set. The end of program run, including the execution of a Cancel cycle, has been reached when **NN\_ChnControllnOperation** is reset. **NN\_ChnProgCancel** and **NN\_ChnProgEnd** will be reset when **NN\_ChnControllnOperation** is set again.

If both **NN\_ChnProgCancel** and **NN\_ChnControllnOperation** are set, this indicates that the Cancel cycle is being executed.

Module 9429 or 9320 can be used to inquire the reason for the program cancelation.

Please check the following lines in the PLC basic program and modify them if required:

German: Biblioth.src

```
;External/Internal STOP
L      ApiChn.NN_ChnProgCancel
AN     ML_Internal_STOP
=      MG_Impuls_Internal_STOP

L      ApiChn.NN_ChnProgCancel
=      ML_Internal_STOP
```

English: Library.src

```
;External/Internal STOP
L      ApiChn.NN_ChnProgCancel
AN     ML_Internal_STOP
=      MG_pulse_internal_stop

L      ApiChn.NN_ChnProgCancel
=      ML_Internal_STOP
```

## 1.2.2 Description of the new functions

### New software options

You can enable the following new software options by entering a code number. HEIDENHAIN can give you the code number after having been informed of the SIK number:

Option	Description	ID
#10	<b>Tools and technology</b> <ul style="list-style-type: none"> <li>■ Tool database expanded to 999 entries</li> <li>■ Technology database expanded to 62 workpiece-material/tool-material combinations</li> <li>■ Support of multipoint tools</li> <li>■ Tool life monitoring with exchange tools</li> </ul>	632 228-01
#17	<b>Tool measurement</b> <ul style="list-style-type: none"> <li>■ Determining tool-setting dimensions with a touch probe</li> <li>■ Determining tool-setting dimensions with an optical gauge</li> </ul>	632 230-01
#41	<b>Additional Language</b> Enabling of additional conversational languages. The languages listed below can be ordered. Please contact HEIDENHAIN if you require additional conversational languages.	
	Slovenian	530 184-01
	Slovak	530 184-02
	Latvian	530 184-03
	Norwegian	530 184-04
	Korean	530 184-06
	Estonian	530 184-07
	Turkish	530 184-08
	Romanian	530 184-09
	Lithuanian	530 184-10
#42	<b>DXF import</b> <ul style="list-style-type: none"> <li>■ Loading of DXF contours</li> </ul>	632 231-01
#70	<b>Y-axis machining</b> <ul style="list-style-type: none"> <li>■ Y-axis machining</li> </ul>	661 881-01
#94	<b>W-axis machining</b> <ul style="list-style-type: none"> <li>■ W-axis support</li> </ul>	679 676-01



## Overview of the improvements

A summary of the improvements in NC software 548 328-02 is given below. For more detailed information, please refer to the Technical Manual sections indicated in the brief descriptions given below.

### Machine configuration

#### ■ **New: Search for the iTNC MP number in the configuration editor**

For numerous machine parameters, the compatible iTNC MP number is stored in the help text in the configuration editor. Up to now, it has not been possible to search the configuration for these numbers. The search function of the configuration editor now enables you to search for the iTNC MP number (selection: MP number). See "Finding/Replacing" on page 339.

#### ■ **New: Separate parameter numbers for OEM parameters**

In order for the OEM to group the parameters in the configuration editor according to his own needs, or to make them easier to find, there is now a separate number range for the OEM. Numbers 900000 to 999999 are reserved for the OEM. For those parameters for which an OEM number is defined, this number is shown instead of the HEIDENHAIN number. The numbers are to be defined in the `%OEM%\config\layout\PlcUniqueNumbers.xml` file. If the file is missing or empty, no OEM numbers will be displayed. For more information, please refer to "User Parameters" on page 365.

#### ■ **Enhanced: OEM motor table (only digital control)**

Until now, if the OEM-specific motor table (path:

`PLC:\table\motor_oem.mot`) was missing, a warning was issued and the user had to create the table himself. Now no warning will be issued. The control itself creates a new blank table as soon as the `MP_motName` (401301) parameter is edited. If the OEM motor table exists but columns are missing, then the columns that exist in the SYS motor table will be transferred to the OEM motor table during copying. The control indicates which columns were not copied.

#### ■ **Enhanced: Saving update rules**

If the user tries to exit the configuration editor without saving the changes made by the update rules, a dialog window appears prompting the user to save the data. The configuration editor cannot be exited until the data are saved. See "Update rules" on page 351.



#### Note

The first restart of the control after the update cannot be continued without saving the configuration changes made by the update rules.

Enhanced/Modified machine parameters:

MP number	Config object	Parameter	Description of change
100201	CfgMachineSimul	MP_simMode	<ul style="list-style-type: none"> <li>■ When the new value <b>Delivery</b> is set, during startup of the control all axes are set to the test mode, and a switch-on of the axes is prevented. The user should then be able to start the control, even with an incomplete or faulty axis configuration in order to put the axes into operation. After the configuration of all axes has been completed, the control can be switched to full operation (FullOperation).</li> <li>■ If <b>Delivery</b>, <b>CcAndExt</b> or <b>CcOnly</b> is set, the control now no longer outputs any analog nominal values.</li> </ul>
102902	CfgFileType	MP_standardEditor	"TEXT-EDITOR" can now be selected in order to assign the ASCII editor of the control to a file type.
103502	CfgPlcTimer	MP_value	The input range of the parameter was expanded from 1 000 to 1 000 000 seconds (corresponds to approx. 11.5 days).
104300 104400	CfgPlcOverrideDev CfgPlcOverrideS	–	The reaction of the parameters under CfgPlcOverrideDev, CfgPlcOverrideS, CfgPlcOverrideF and CfgPlcOverrideR was changed from NOTHING to RESET. The control must now be rebooted after a parameter change.
105201	CfgSystemTime	MP_offsetToUTC	Values with decimal places can now be entered for time differences to universal time (GMT). This is necessary for parts of Australia (+8.5 and +9.5 hours) and Kazakhstan (+3.5 hours), for example. Also, the maximum value was extended from +13 to +14 [hours].
400011	CfgAxisHardware	MP_posEncoder Resistor	The default value of the parameter was changed from <b>without</b> to <b>120 ohm</b> .





**New machine parameters:**

<b>MP number</b>	<b>Config object</b>	<b>Parameter</b>	<b>Description</b>
102907	CfgFileType	MP_protect	Disables filtering or editing of a file type, see page 1597.
104018	CfgPlcSStrobe	MP_cuttingSpeed	Optional parameter – If parts of the configuration indicate the symbolic name or number of a word marker to which the cutting speed is copied.
104304	CfgPlcOverrideDev	MP_mop	In <b>MP_mop</b> , enter the key name of the machine operating panel on which the override source is located, see page 1353.
106501	CfgConfigSettings	MP_undoListSize	Defines the number of entries in the parameter change list, see page 339.
106502		MP_suppressUsrMsg	This parameter is used to suppress the warning <b>Key non-functional</b> , see page 1277.
106503		MP_dispParam Numbers	Specifies whether MP numbers or symbolic names are displayed in the parameter change list, see page 339.
106504		MP_hideWrite Protected	If the parameter is set to TRUE, write-protected parameters are hidden in the configuration editor, see page 350.
116103	CfgPlcSymName	MP_dbLoadDisplay	The parameter defines the variable name for the dashboard load display, see page 1405.
203804	CfgChannelProperties	MP_kinManualMode	Y axis as oblique axis: Activate the compensating motion in Manual mode as well, see page 1444.
300110	CfgAxis	MP_deactivatedAtStart	Deactivate the axis or spindle during start-up, see page 682.
300111		MP_restoreModuloCntr	Save modulo counter of the axis in SRAM, see page 632.
300205	CfgAxisPropKin	MP_parAxComp	Define the compensation for parallel secondary axes, see page 762.
401509	CfgSpindle	MP_changeTurnDir	Rotational direction reversal with M3 and M4, see page 663.
601801	CfgGlobalProperties	MP_lifeTime	Activate tool life monitoring for tool service age or workpiece quantity, see page 1408.
601806	CfgGlobalProperties	MP_doProgAfterTCall	Run subprogram after the tool change, see page 1445.



<b>MP number</b>	<b>Config object</b>	<b>Parameter</b>	<b>Description</b>
<b>604601</b>	<b>CfgToolMeasuring</b>	<b>MP_measuringType</b>	Type of tool measurement, see page 1386.
<b>604602</b>		<b>MP_feed</b>	Tool measurement: Measuring feed rate, see page 1386.
<b>604603</b>		<b>MP_distance</b>	Tool measurement: Measuring range, see page 1386.
<b>604701</b>	<b>CfgProbePosition</b>	<b>MP_positionProbePos</b>	Tool measurement: Position of the touch probe in positive axis direction, see page 1384.
<b>604702</b>		<b>MP_positionProbeNeg</b>	Tool measurement: Position of the touch probe in negative axis direction, see page 1384.
<b>604703</b>		<b>MP_maxMeasuringFeed</b>	Tool measurement: Maximum permissible measuring feed rate, see page 1384.
<b>604801</b>	<b>CfgGlbDispSettings</b>	<b>MP_plcSpindleSelect</b>	Selection of spindle number by PLC, see page 1411.



## Operation and technology

- **Enhanced: Dashboard display of PLC signals**

The attribute evaluation of the dashboard element "LoadDisplay" was enhanced so that PLC data can now optionally also be transferred to this element. Therefore, it is now also possible during analog control to realize a load display for axis and spindle drives directly in the dashboard. See "Load display for analog drives" on page 1405.
- **Enhanced: Update of NC software**

The NC software can now also be updated while it is running. The new code number 231019 was therefore introduced. See "Start update while software is running on the control" on page 141.
- **Enhanced: Log**

The display of the control's log was improved. The accumulated keystrokes are now stored simultaneously with the control events in the log and are displayed in table view.  
In order to be able to track machine operation or machine conditions systematically, detailed additional information is entered and stored simultaneously with all important log entries, such as keystrokes, errors, system errors or warnings. See "Error messages and log files" on page 1254.
- **Enhanced: Display of configuration errors during start-up**

If configuration errors occur during control start-up, the **Error during start-up** message appears instead of **Power interrupted**. Also, the error messages for the incorrect configuration data, which are triggered by the applications, are displayed individually.

## Machine interfacing

- **New: Additional data types for table columns**

The control supports additional data types for columns in NC tables. The FEED\_CUT column data type applies to the cutting speed in units of m/min or feet/min. The FEED\_ROT column data type applies to the feed rate per revolution in units of mm/rev or inch/rev. As usual, the new column data types are listed as enumeration values of parameter **MP\_unit** (105602) of the configuration object **CfgColumnDescription**.
- **Enhanced: Integrated oscilloscope – Selection of symbolic operands**

In the MIOTC dialog (dialog box for selecting markers, inputs, outputs, timers and counters) in the integrated oscilloscope, symbolic API operands can now also be selected and displayed conveniently in a list. See "Setup for digital signals" on page 1150.
- **New: Integrated oscilloscope – Circular interpolation test**

A circular interpolation test can now be performed with the integrated oscilloscope. See "Circular interpolation test with the integrated oscilloscope" on page 1158.
- **New: Test of internal EMERGENCY STOP by code number**

For test purposes, the behavior during an internal EMERGENCY STOP can now be simulated in order to inspect the correct wiring of the machine. The control-is-ready output is reset, and the NC and PLC are no longer operable. It is essential that you support hanging axes before the test in order to prevent damage to the machine in case of error. To start the test, press the **CODE NUMBER** soft key and enter the code number **6871232**. Enter the code number again to reset the control status to "ready for operation."

■ **New: Software option #70 – Y-axis machining**

With a Y axis you can drill and mill a workpiece on its front, back and lateral surfaces.

During use of the Y-axis, two axes interpolate linearly or circularly in the given working plane, while the third axis interpolates linearly. This enables you to machine slots or pockets, for example, with plane floors and perpendicular edges. By defining the spindle angle, you can determine the position of the milling contour on the workpiece.

If the Y axis is to be positioned at an angle not equal to 90° to the X or Z axis, the Y axis can also be configured as an oblique axis.

For configuring the Y axis, please refer to "Configuring the Y axis" on page 1439. For information on programming the Y axis, please refer to the User's Manual for the control.

■ **New: Software option #94 – W-axis support**

The control can now offset the display of movements in the Z axis with those of its parallel secondary axis W. The W axis is already configured in the control kinematics and can be moved via the PLC.

For more information on the configuration of the W axis, please refer to "Configuring parallel axes" on page 1446.

■ **New: Spindle change key**

Starting immediately, a spindle change key can be supported by the PLC. It assigns the input (TSF dialog) to the selected spindle. The selected spindle is identified in the corresponding display element of the dashboard, see page 1410.

■ **Enhanced: Backlash compensation**

If nonlinear axis-error compensation is active, **MP\_backLash** can now be used to activate backlash compensation in addition to the compensation-value tables, See "Axis Error Compensation" on page 705.

**PLC programming**

■ **Enhanced: Symbolic memory interface (API 3.0) – New operands introduced:**

PLC operand / Description	Type
NP_ChnProgSelected NC program selected This marker can be used to interrogate whether an NC program is selected in the Program Run modes of operation. The marker is not set if an NC program is selected from a pallet table.	M
NN_ChnFeedRapidTraverseActive 0: Rapid traverse active (FMAX) 1: Rapid traverse not active	M

■ **Changed: Behavior of NN\_ChnToolLifeExpired (tool life 1 expired)**

The status of **NN\_ChnToolLifeExpired** is now reset by the PLC runtime system after the end of an NC program.

■ **New: PLC process monitor**

In the PLC programming mode you can use the MONITOR and PROCESS MONITOR soft keys to open a status screen in which the control displays all parallel processes, as well as the process for the submit queue. See "Control of events" on page 1737.



### ■ **Enhanced: Compilation of PLC program**

- If the PLC program has already been compiled in the **PLC Programming** mode of operation before the **Power interrupted** message has been acknowledged, the PLC program will not be compiled again when the message is acknowledged. This change makes it possible to observe the PLC operands with the integrated oscilloscope during start-up of the PLC program:
  - Start the control, do not acknowledge the **Power interrupted** message.
  - Compile the PLC program in the PLC Programming mode of operation.
  - Activate the integrated oscilloscope in order to observe the desired PLC operands and start the measurement.
  - Acknowledge the Power interrupted message now for the control to start the PLC program.
- Now a PLC program is compiled even if the machine parameters refer to symbolic names of PLC operands that are not defined in the PLC program. The control issues an error message for every undefined symbolic name and then compiles the PLC program.



#### Warning

A PLC program with undefined symbolic PLC operands can lead to hazardous behavior of the machine! It is essential that you check whether the parameters for configuring the M functions (CfgPlcMStroke) contain meaningful strobe definitions. The data of strobe definitions must be mapped onto defined PLC operands.

### ■ **Enhanced: Commands for string processing**

Symbolic operands (B/W/D operands) can now be used for indexed access to the string operands "S" or the PLC error and dialog files, See "Commands for String Processing" on page 1723.

### ■ **Enhanced: WATCH LIST and TRACE function**

New TYPE column: Type (M for marker, B for byte, W for word, etc.) of the PLC operand, See "The WATCH LIST function" on page 1491.

The **ADD TO WATCH LIST** soft key can be used to transfer the PLC operands of the currently highlighted line to the WATCH LIST, See "The TRACE function" on page 1495.

### ■ **Enhanced: EDIT function**

The features and the operation of the editor were changed. The editor is now a full-fledged ASCII editor. The cursor can be positioned in all directions and line breaks can be inserted, See "The EDIT function" on page 1498.

### ■ **New: Moving PLC axes with the handwheel**

It is now possible to assign a PLC axis to a handwheel via Module 9036. In the **E1. Handwheel** mode of operation, the machine operator can use the axis keys to select a PLC axis and move it with the handwheel.

■ **Changed: Module 9145 (Actual-to-Nominal Value Transfer)**

A call of PLC API Module 9145 for actual-to-nominal value transfer is now synchronized with other positioning commands. The transfer cannot be started while another positioning command is pending.  
A PLC positioning movement cannot be started while the transfer is running. During the transfer, NC program execution is not continued after a strobe.

■ **Enhanced: Modules 9226 and 9418 (Define the Status of an Axis or Spindle):**

Comprehensive possibilities for deactivating/activating an axis without rebooting have been created. The improvements are described in detail in "Writing axis information—activating and deactivating axes" on page 678.

■ **Enhanced: Modules 9040, 9041 and 9049**

The following additional axis information can be read:

- 7: Actual values in the reference system with backlash
- 8: Distance traversed in [mm] since the last lubricating pulse
- 9: Temperature compensation.

For the complete module documentation, see:

- "Module 9040 Reading of axis coordinates by the PLC in the format 1/1000 (0.001) mm" on page 674
- "Module 9041 Reading of axis coordinates by the PLC in the format 1/10000 (0.0001) mm" on page 675
- "Module 9049 Read position value and speed value of an axis" on page 673

■ **Enhanced: Modules 9240, 9248, 9250, 9277, 9290, 9291, 9295 and 9343**  
(Modules for accessing files)

The name of an OEM machine parameter from the CfgOemString configuration object can now be transferred instead of the path name. The transferred character string must begin with ">OEM." and end with the key name from CfgOemString. The parameter value must contain the path name to the file. If no key name with the transferred path name is found, the Modules 9248, 9277 and 9295 return the error code 62. The other modules set the error marker to the value provided for an invalid path name.

■ **Enhanced: Module 9247 (Searching for a Condition in a Table)**

Module 9247 now accepts the SQL keyword "WHERE" in a string in order to transfer a search condition to the module, see page 1613.

■ **Enhanced: Module 9434 (Select Parameter Set)**

The PLC program can now activate another parameter set even while a PLC positioning movement is being executed. A PLC positioning movement can also be started while a new parameter set is being selected via Module 9434. In this case, the PLC program must ensure the safety of the machine. The PLC programmer must ensure that parameter blocks containing machine parameters that are not suitable for this drive are not selected. Unsuitable parameter blocks can cause incorrect positioning movements and damage to the machine!

New error code 5 added:

The module was not executed, because the axis is deactivated.

For a detailed description of the module, see page 406.



## New PLC modules

- **Module 9066: Status of HEIDENHAIN Hardware**, see page 979.
- **Module 9067: Status of HEIDENHAIN Software**, see page 980.
- **Module 9128: Torque Limiting by the PLC**, see page 897.
- **Module 9129: Status of Torque Limiting by the PLC**, see page 898.
- **Module 9158: Maximum Torque**, see page 899.
- **Module 9146: Storing/Restoring Actual Position Values**, see page 1041.
- **Module 9155: Axis Switchover from Closed Loop to Open Loop**, see page 685.
- **Module 9156: Axis Switchover from Open Loop to Closed Loop**, see page 686.



### Note

Modules 9155 and 9156 were introduced to ensure compatibility with earlier HEIDENHAIN contouring controls. HEIDENHAIN recommends:  
Using Modules 9226 and 9418 for activating and deactivating axes and spindle, if possible.

- **Module 9193: Setting the Operating Hours Counter**, see page 1377.
- **Module 9227: Positioning of auxiliary axes and NC axes**, see page 700





# 1 Update Information No. 2

## 1.1 Overview

## 1.2 NC Software 548 328-03

### 1.2.1 Important notes on updating software

Please remember the following important information when updating the software versions listed below:

■ **MANUALplus 620: 548 328-02 to 548 328-03**

■ **MANUALplus 620: 548 328-01 to 548 328-03**

For an update from NC SW 548 328-01 to NC SW 548 328-03 it is absolutely necessary to comply with the information in the Update Information No.1 on the software update from NC SW 548 328-01 to NC SW 548 328-02, See "Important notes on updating software" on page 19.



#### Note

HEIDENHAIN recommends:

Making a backup of the control (e.g. with TNCbackup) before updating the NC software.

Saving your current machine configuration. The configuration editor (DATA BACKUP soft key) can be used for this purpose.

If you later want to undo the software update and return to the previous software version, you need the saved configuration data of the old version!



#### Note

Please perform the update of the NC software as described in the Technical Manual in Chapter 2 "NC Software Exchange."



#### Note

Be sure to remember the important information about the software update, which is provided on the following pages.

### ■ **Checking and saving new machine parameters:**

After having installed the new NC software and rebooted the control, you must check and confirm the new machine parameters. The code number dialog box appears on the screen:

- ▶ Enter the MP code number **95148** and confirm your entry with the ENT key.
- ▶ Press the **UPDATE RULES** soft key.  
Check the listed update rules. Each entry in the list stands for a new parameter that was added to the system by the update.
- ▶ Exit the **UPDATE RULES** with the **END** soft key.
- ▶ Press the **CONFIG DATA** soft key.  
Before the configuration editor opens, an informational window is displayed, reporting the removal of the CfgRestorePosition machine parameter. Press the **NEXT** soft key.
- ▶ All new machine parameters are marked with a red exclamation point in the configuration editor. The control indicates if certain machine parameters are faulty. Please ignore these messages for the time being.
- ▶ **Important step:** Press the **SAVE** soft key.
- ▶ The **Configuration data changed** dialog box opens. Press the **SAVE** soft key again. The new machine parameters are now automatically saved in the \*.cfg files.
- ▶ Press the **END** soft key and exit the **Machine Parameter** operating mode by pressing the **END** soft key again.

The control then continues booting.



## 1.2.2 Description of the new functions

### Software options

The features of the following MANUALplus 620 options will change as of NC software version 548 328-03:

#### ■ **Software option 3—tools and technology (option 10)**

This option is no longer required for the support of multi-edge tools (tools with multiple cutting edges or multiple reference points) in smart.Turn and DIN programs. The support is now included in the standard features of the NC software.

#### ■ **Touch probe functions (option 17)**

This option has been expanded by automatic workpiece measurement with touch probes.

A summary of the improvements in NC software 548 328-03 is given below. For more detailed information, please refer to the Technical Manual sections indicated in the brief descriptions given below.

### Machine configuration

#### ■ **New: HSCI/PROFIBUS diagnostics**

After the OEM code word has been entered, the BUS DIAGNOSIS soft key will now be available in the Organization mode of operation after pressing the DIAGNOSIS soft key. The arrangement of all bus participants as well as the properties and conditions of each individual device are displayed graphically and separately for HSCI and Profibus, See "Bus diagnosis" on page 1502.

#### ■ **Implementation of new kinematic model**

The new kinematic model developed for NCK-based controls is now also available for the MANUALplus 620. The new kinematic model makes it possible to use the PC software **KinematicsDesign** to create and modify kinematic configurations, See "Machine Kinematics (As of NC Software 548328-03)" on page 727.

#### ■ **Enhanced: OEM cycles with dialog texts and help graphics**

The OEM can define his own cycles (G500 to G590) with dialog texts and help graphics. A prepared file in XML format is available as a template in the control under **PLC:\resource\formdlg\g\_oem.fdxml** See "OEM cycles (G5xx)" on page 1588.

#### ■ **Enhanced: PLC G functions with dialog texts and help graphics**

Dialog texts with help graphics can now be saved in the control for G functions (G602 to G699) that are not executed in a subprogram, but by the PLC, See "PLC-G functions (G6xx)" on page 1588.

#### ■ **Enhanced: Creating subprograms**

When subprograms are written, a separate help graphic can now be defined and displayed for every input field in the dialog.

#### ■ **Enhanced: Update rules for OEM parameters**

In the directory **PLC:\config\athe\manplus**, release-specific files were provided for the update rules of the machine tool builder. In the control's shipping condition, the **UpdateOemRe100x.cfg** files (update rules for release x) are empty.

Enhanced/Modified machine parameters:

MP number	Config object	Parameter	Description of change
100402	CfgFilter	MP_typeFilter1	The input range for the maximum value of the filter order was increased from 31 to 63.
100404		MP_typeFilter2	
113102	CfgDashboardElement /DB_LD_S1 /DB_LD_S2	MP_attribut	For spindles, the utilization of the rotational speed limit can be displayed by setting bit 1 = 1 in <b>MP_attribut</b> ; See "Configuring dashboards" on page 1292.
113102	CfgDashboardElement /DB_OVERRIDE	MP_attribut	In the override display of the dashboard, the current rapid traverse reduction can be displayed by setting bit 1 = 1 in <b>MP_attribut</b> ; See "Configuring dashboards" on page 1292.

New machine parameters:

MP number	Config object	Parameter	Description
116104	CfgPlcSymName	MP_readTsfData	The data for feed rate and spindle speed can now be read out by the PLC from the "Set T, S, F" dialog; See "Transferring the spindle speed and feed rate data to the PLC" on page 1406.
116105		MP_displayMode	The active display mode (e.g. "manual control," and "automatic") can now be passed on to the PLC; See "Transfer display mode to PLC" on page 1406.
116106		MP_setToolPlace	By entering a PLC operand, the PLC can command the turret position, which you would otherwise have to set manually; See "MP_setToolPlace" on page 1407.

MP number	Config object	Parameter	Description
202601	CfgKinSimpleTrans	MP_dir	As of NC software 548 328-03, a new kinematic model is available for the MANUALplus 620 as an alternative to the previous kinematic model. The new kinematic model, which is provided as a standard feature, makes it possible to use the PC software KinematicsDesign to create and modify kinematics for the control. For configuration of the new kinematic model, See "Machine Kinematics (As of NC Software 548328-03)" on page 727.
202602		MP_val	
202603		MP_realtimeComp	
202701	CfgKinSimpleAxis	MP_dir	
202702		MP_axisRef	
202801	CfgKinSimple Model	MP_kinObjects	
202901	CfgKinCompos Model	MP_subKinList	
202902		MP_activeSpindle	
202904		MP_tiltingAllowed	
203001	CfgKinList	MP_kinCompositeMode Is	
203701	CfgKinAnchor	MP_kindOfAnchor	
300112	CfgAxis	MP_advancedSettings	This machine parameter makes it possible to configure that the PLC movement of an individual axis is not canceled if the touch probe is deflected; See "Advanced settings for individual axes" on page 638.
400413	CfgReferencing	MP_externRefPulse	For referencing a single axis with an external reference signal, See "Referencing with external reference signal" on page 1006.
600418	CfgToolMount	MP_kinModelToModify	Assign axis mirroring to a tool holder: See "Axis mirroring on lathes (as of NC software 548328-03)" on page 746.
600419		MP_kinModel	
601807	CfgGlobalProperties	MP_threadHandWheelOn	Activation of the "handwheel in thread" function: See "Activate handwheel in the thread" on page 1416.
601808		MP_freezeVconst	Activate constant spindle speed for rapid traverse movements and active constant surface speed: See "Freeze spindle speed for rapid traverse" on page 1392.
604803	CfgGlbDispSettings	MP_axesDisplayMode	This machine parameter makes it possible to configure the type of axis display in the dashboard. You can choose between actual value, nominal value, following error or distance to go; See "Configuring the OEM window" on page 1293
604901	CfgMMISettings	MP_extManualMode	Activation of an extended menu structure in the <b>Machine</b> and <b>Program Run</b> operating modes: See "Expanded menu structure" on page 1228.
604902		MP_extProgramMode	

- **New: Dashboard display of unit quantities and time per unit**  
The dashboard element **QuantityInformationAndTimePerUnit** is now available in the machine display to show the defined quantity, current quantity, time per unit and total time of finished workpieces; See "Configuring dashboards" on page 1292.
- **New: Configuring the axis display in the dashboard**  
Effective immediately, it is possible to use **MP\_axesDisplayMode** to set whether the axis display in the dashboard should show the actual value, nominal value, following error or distance to go; See "Configuring dashboards" on page 1292.
- **New: Expanded menu structure**  
In the **Machine** and **Program Run** operating mode it is now possible to use **MP\_axesDisplayMode** to activate an expanded menu structure; See "Expanded menu structure" on page 1228.
- **New: Workpiece measurement with TS touch probe**  
The control now also supports tool measurement with a touch probe; See "Touch Probe" on page 1381.
- **New: Activate handwheel in the thread**  
Effective immediately, the "handwheel in thread" function can be activated through a machine parameter. This function makes it possible to compensate position and angular error of the linear and spindle axes; See "Activate handwheel in the thread" on page 1416.
- **Enhanced: Dashboard display for feed rate reduction**  
The attribute evaluation of the dashboard element "ChannelDisplay" was expanded so that now you can display the feed rate reduction in the dashboard in addition to the spindle and feed rate override; See "Configuring dashboards" on page 1292.
- **Enhanced: Speed display for spindles**  
For a C axis with external spindle drive (e.g. S4 drives the main spindle S1 through a transmission), the spindle speed of S4 is now displayed in the S1 dashboard element in the C-axis mode; See "Configuring dashboards" on page 1292.
- **Enhanced: Utilization display for spindles**  
The attribute evaluation of the dashboard element "LoadDisplay" was expanded for spindles so that you can now display the speed limitation in the dashboard in addition to the utilization display for spindle drives; See "Configuring dashboards" on page 1292.

## Configuring the axes and spindle

- **New: Advanced settings for individual axes**  
**MP\_advancedSettings** makes it possible to configure that the PLC movement of an individual axis is not canceled if the touch probe is deflected by another axis.  
A faster acceleration and filter calculation for PLC movements can be activated in addition to the configuration of a fast axis; See "Advanced settings for individual axes" on page 638.
- **New: Referencing with external reference signal**  
Effective immediately, an external reference signal can be used instead of the reference signal of the connected motor encoder to reference an individual axis of the entire system (e.g. spindle); See "Referencing with external reference signal" on page 1006.
- **New: Axis mirroring with new kinematic model**  
In the new kinematic model, an axis can also be mirrored within a kinematic group without switching the kinematics; See "Axis mirroring on lathes (as of NC software 548328-03)" on page 746.
- **New: Keeping spindle speed for rapid traverse constant**  
With the new machine parameter **MP\_freezeVconst** you can prevent the spindle from changing its speed during constant surface speed Vconst according to the current diameter if there are several rapid traverse movements. This can prevent unnecessary deceleration and acceleration of the spindle during several successive rapid traverse movements; See "Freeze spindle speed for rapid traverse" on page 1392.
- **Enhanced: Configuration of the nominal position value filters**  
The possible maximum value for the filter order was increased from 31 to 63 in the machine parameters **MP\_orderFilter1** and **MP\_orderFilter2**, which are effective for all axes; See "Nominal position value filter" on page 811.

## Analog hardware

- **MANUALplus 620 for retrofitting**  
The new MC 320T main computer supports purely analog drive control. The axes are controlled exclusively through the analog nominal speed command interface. The compact MC 320T main computer is integrated behind the screen of the operating panel to save space.

## PLC programming

- **New: Transferring the spindle speed and feed rate data to the PLC**  
With **MP\_readTsfData** you can now configure whether the PLC will read the data for feed rate and spindle speed shown in the dialog "**Set T, S, F**" from the tables **ch\_tsf.mch** and **sp\_tsf.msp**; See "Transferring the spindle speed and feed rate data to the PLC" on page 1406.
- **New: Transferring the display mode of the machine display to the PLC**  
The active display mode (e.g. "manual control," and "automatic") of the dashboard can now be passed on to the PLC. This makes it possible to switch the view of the machine display; See "Transfer display mode to PLC" on page 1406.
- **New: Tool pocket preset by the PLC**  
In the machine parameter **MP\_setToolPlace** you can now define a symbol variable name under which the PLC can name the NC a tool pocket that is then used and displayed by the user interface; See "Tool pocket preset by the PLC" on page 1407.





## New PLC modules

- **Module 9142: Reference value for a programmed axis**, see page 630.
- **Module 9250: Starting the editor for sections of a table**, see page 1615.
- **Module 9251: End the PLC table editor**, see page 1617.
- **Module 9252: Position the cursor in the PLC table editor**, see page 1618.
- **Module 9285: Disable operating modes**, see page 1238.
- **Module 9480: Selection of channel display**, see page 1412.
- **Module 9481: Finding the channel display**, see page 1413.
- **Module 9482: Selection of spindle display**, see page 1413.
- **Module 9483: Finding the spindle display**, see page 1414.



# 1 Update Information No. 3



## 1.1 Hardware

### 1.1.1 UEC 11x controller unit with inverter and PLC I/O

A new variant was released for the UEC 11x compact controller units.

Previously, the UEC 11x was shipped both with variant 01 and variant 02. The new variant 03 replaces both of the previous variants. The changed ID numbers are listed in the table below:

Device	Previous IDs	New ID
<b>UEC 111</b> Without functional safety (FS) Max. 4 control loops 4 x speed and 4 x position inputs DC-link power rating: 14 kW 38 x PLC inputs, 23 x PLC outputs	625 777-01 625 777-02	625 777-03
<b>UEC 112</b> Without functional safety (FS) Max. 5 control loops 5 x speed and 5 x position inputs DC-link power rating: 14 kW 38 x PLC inputs, 23 x PLC outputs	625 779-01 625 779-02	625 779-03

UEC 111, UEC 112	
ID number	Changes
625 777-01 625 779-01	<b>Initial introduction</b>
625 777-02 625 779-02	<p><b>1st improvement</b></p> <ul style="list-style-type: none"> <li> <b>Support of motor holding brakes</b>                      New connections X344 and X394 for controlling the motor holding brakes of axes 1 to 4. For variant 01, PLC outputs were required for controlling the motor holding brakes.                 </li> <li> <b>New terminals for the axis motors</b>                      Pluggable screw terminals for the axis motors connected to X81 to X84. In variant 01, the terminals for the motors are permanently integrated in the unit and are not pluggable.                 </li> </ul>
625 777-03 625 779-03	<p><b>2nd improvement</b></p> <ul style="list-style-type: none"> <li> <b>Optimized active cooling</b>                      A new arrangement of fans in the UEC 11x has improved the distribution of cooling air in the unit.                 </li> <li> <b>Changed arrangement of connection X19</b>                      Connection X19 (speed encoder of the 4th axis, only UEC 112) was shifted slightly. See drawing below.                 </li> </ul> <div style="display: flex; justify-content: space-around; text-align: center;"> <div> <p><b>UEC 11x, old:</b></p>  </div> <div> <p><b>UEC 11x, new:</b></p>  </div> </div>

## Service


Operation of the new UEC 11x on the MANUALplus 620 with HSCI may require the installation of a service pack or upgrading the NC software to a newer software version.



### Note

NC software 548 328-03 or higher is required for operating the new UEC 11x (variant 03) with the MANUALplus 620!

## Dimensions





# 1 Update Information No. 4

## 1.1 Overview

### 1.1.1 Released service packs

The following service packs were released for NC software **548 328-03**:

- Service pack 3: 548 328-03 SP3                      July 2011

### 1.1.2 Released NC software

The following NC software has been released:

- NC software 548 328-04                      (NCK software version: 597 110-05)

## 1.2 NC Software 548 328-03

### Service packs



#### Warning

When needed, HEIDENHAIN prepares service packs for the various versions of the NC software. Registered customers can download these service packs from the HEIDENHAIN FileBase on the Internet. Installation of a service pack in addition to the already installed NC software implements important error fixes. Please ensure that the NC software always contains the latest service pack before you ship the machine. Perform all tests required of the machine or the NC software again after having installed the service pack.

The following service packs were released for NC software 548 328-03:

Service pack	NC Software	Release
548 328-03 SP3	548 328-03	July 2011

## 1.3 NC Software 548 328-04

### 1.3.1 Important change made in the technical manual

In older editions of the present documentation, an incorrect assignment for the X394 terminal (connection of the motor holding brakes) was printed for the UEC 11x connection description (See "X394: Motor holding brakes" on page 210):

#### Incorrect assignment for X394:

Connecting terminals	Assignment
1	Holding brake 1 (X81)
2	0 V PLC
3	Holding brake 2 (X82)
4	0 V PLC
5	Holding brake 3 (X83)
6	0 V PLC
7	Holding brake 4 (X84)
8	0 V PLC

#### Corrected assignment for X394:

Connecting terminals	Assignment
1	Holding brake X80
2	0 V PLC
3	Holding brake X81
4	0 V PLC
5	Holding brake X82
6	0 V PLC
7	Holding brake X83
8	0 V PLC
9	Holding brake X84
10	0 V PLC

If the motor holding brakes are wired as per the incorrect connection layout, this could lead, for example, to the brake for the Z axis incorrectly being wired to the brake output of the Y axis. Since the motor brakes are generally commanded as a group via the PLC (see the basic circuit diagram), incorrect wiring of X394 should have no negative effect on the behavior of the machine.



#### Warning

**Please check the wiring of the motor holding brakes of your machine if you use output X394 of the UEC11x.**

**If necessary, change the assignments of the terminal as per the corrected layout.**





### 1.3.2 Important notes on updating software

Please remember the following important information when updating the software versions listed below:

■ **MANUALplus 620: 548 328-03 to 548 328-04**



Note

HEIDENHAIN recommends:

Making a backup of the control (e.g. with TNCbackup), before updating the NC software.

Saving your current machine configuration. The configuration editor (DATA BACKUP soft key) can be used for this purpose.

If you later want to undo the software update and return to the previous software version, you need the saved configuration data of the old version!



Note

Please perform the update of the NC software as described in the Technical Manual in Chapter 2 "NC Software Exchange".



Note

Be sure to remember the important information about the software update, which is provided on the following pages.

### ■ **Checking and saving new machine parameters:**

After having installed the new NC software and rebooted the control, you must check and confirm the new machine parameters. The code number dialog box appears on the screen:

- ▶ Enter the MP code number **95148** and confirm your entry with the ENT key.
- ▶ Press the **UPDATE RULES** soft key.  
Check the listed update rules. Each entry in the list stands for a new parameter that was added to the system by the update.
- ▶ Exit the **UPDATE RULES** with the **END** soft key.
- ▶ Press the **CONFIG DATA** soft key.  
Before the configuration editor opens, an informational window is displayed, reporting the removal of the CfgRestorePosition machine parameter. Press the **NEXT** soft key.
- ▶ All new machine parameters are marked with a red exclamation point in the configuration editor. The control indicates if certain machine parameters are faulty. Please ignore these messages for the time being.
- ▶ **Important step:** Press the **SAVE** soft key
- ▶ The **Configuration data changed** dialog box opens. Press the **SAVE** soft key again. The new machine parameters are now automatically saved in the \*.cfg files.
- ▶ Press the **END** soft key and exit the **Machine Parameter** operating mode by pressing the **END** soft key again.

The control then continues booting.




#### Note


The definition file of the symbolic programming interface API 3.0 has been expanded. The step described below must be taken for the PLC program to be compiled successfully after the update.

### ■ **Replace the apimarker.def file:**

During the update of the NC software, a new version of the **apimarker.def** file was automatically copied to the PLC partition of the control. Proceed as follows:

- ▶ Switch to the **Organization** mode of operation.
- ▶ Enter the code number 95148 to call the **Machine Parameter** mode of operation.
- ▶ Press the **END** soft key and switch the soft-key row.
- ▶ Press the **PGMMGT**  soft key to open the file manager.
- ▶ Switch to the PLC:\proto\plc directory.
- ▶ Copy the **apimarker.def** file to the program directory of your PLC program. Overwrite the existing **apimarker.def** file:





#### Note

You also need to copy the **apimarker.def** file to your PC, and add it to the PLCdesignNT project. Otherwise, during the next transfer of PLC project files to the control, the file might be overwritten by the old version.

### Checking machine parameters

If you use a coded spindle on your MANUALplus 620, you must check the setting of **MP\_axisMode** (300105) and change it, if necessary.

Until now, it was allowed to set **MP\_axisMode = active** for a spindle with encoded output of the spindle speed. Now this setting is not allowed anymore. Check the setting of the encoded spindle and change the value to **MP\_axisMode = PlcControlled**, if necessary.



#### Note

Please note the following important information if you are using the NCK-Turn-V04-04 HEIDENHAIN PLC basic program in conjunction with the NC software 548 328-04.



#### Note

After an update, please modify the previous file **plc\_attr.cfg** as described below, and add it to the PLCdesignNT project. Otherwise, during the next transfer of PLC project files to the control, the file **plc\_attr.cfg** might be overwritten by the old version, which leads to the multiple error 140-0033 "Job cannot run."

### ■ Modify the `plc_attr.cfg` file:

The current `plc_attr.cfg` file is located in the control in the directory `PLC:\config\lath\manplus\plc_attr.cfg`. You can use `TNCremoNT` to copy the file from the control to the PLC project, or you can use `PLCdesignNT` to modify the previous file in the PLC project.

- ▶ For all 43 timers, in the `plc_attr.cfg` file delete the line **`event:=NOTHING`**, in every `CfgAttrEntity` with **`name:="CfgPlcTimer-..."`**:

```
CfgAttrEntity (
```

```
  name:="CfgPlcTimer-TR_Cax_Aus_Entprellen",
```

```
  event:=NOTHING,           ; This line must be deleted
```

```
  protection:=LEVEL1
```

```
)
```

```
...
```

### Checking the direction of spindle rotation

The evaluation of the **`MP_signCorrNominalVal`** parameter was revised for spindles. The `MANUALplus 620` therefore adjusts the value of the **`MP_signCorrActualVal`** parameter automatically when the NC software is updated. After the value has been adjusted, the `MANUALplus 620` displays the message **Check the parameter for the direction of spindle rotation!**.

Check the direction of spindle rotation. Proceed as follows:

- ▶ Check whether the spindle turns with `M3` and `M19` in the correct direction.
- ▶ If required, use the parameters **`MP_signCorrNominalVal`** (400002) and **`MP_signCorrActualVal`** (400001) to define the direction of rotation correctly. See "Defining the traverse direction" on page 663.

### Operation of a C axis with separate drive



#### Note

Please note that, if the same position encoder is used for the main spindle and the C axis, the operation of a separately driven C axis along with the use of a `CC 61xx` is not possible until the beginning of 2012. Contact `HEIDENHAIN` if you need this feature before the above mentioned date.

### 1.3.3 Description of the new functions

#### New software options

You can enable the following new software options by entering a code number. HEIDENHAIN can give you the code number after having been informed of the SIK number:

Option	Description	ID
#24	<b>Gantry axes</b> Gantry axes in master-slave torque control	634 621-01
#46	<b>Python OEM process</b> Python application on the MANUALplus 620 (available only for HSCI hardware)	579 650-01
#131	<b>Spindle synchronism</b> Spindle synchronization	806 270-01
#132	<b>Opposing spindle</b> Opposing spindle	806 275-01

#### Enhanced software options

The features of the following MANUALplus 620 options changed with the introduction of the new NC software version:

■ **Additional control loops 5, 6 and 7 (options 4, 5 and 6):**

It is now possible to operate up to 10 control loops (spindle and opposing spindle, X, Z, C, Y, U, V, W axes and driven tool) in connection with a CC 6110.

■ **Support of parallel axes U, V, W (option 94):**

The auxiliary axes U and V are now supported in addition to the existing W axis. The axes can be used for the programmable control of a traversable opposing spindle, a mechatronic tailstock or a steady rest.

#### Overview of the improvements

A summary of the improvements in NC software 548 328-04 is given below. For more detailed information about the function in this Technical Manual, please refer to the links indicated in the brief descriptions given below.

■ **New: TURNguide – The context-sensitive help system of the MANUALplus 620**

The browser-based, context-sensitive help system TURNguide is now available on the control. TURNguide is based on the Mozilla browser and displays CHM help files. You can download the control's respective User's Manual in CHM format from the HEIDENHAIN home page and transfer it to the control. For more information on TURNguide, please refer to "TURNguide – context-sensitive help system (user documentation)" on page 1278.

■ **New: Software option #46 (Python OEM Process)**

With the "Python OEM Process" option, the OEM can use a powerful, object-oriented programming language within the control (PLC). Python is an easy-to-learn script language that supports the use of all necessary high-level language elements. Python is widely known among programming experts.

"Python OEM Process" can be used for machine functions and complex calculations, as well as to display special information. It provides comprehensive possibilities for realizing user-specific and machine-specific software solutions, e.g. special algorithms for tool calculation or custom user interfaces for special functions. Freely definable windows up to the size of the control screen can be displayed for visualization.

A separate documentation, additional PC tools for debugging and for the development of user interfaces as well as example programs are available for Python OEM Process. In the HEIDENHAIN HESIS Web Including Filebase you can download the "Python in HEIDENHAIN controls" Technical Manual under "PC Software > Python."

■ **New: Dashboard with integrated Python window**

The OEM can define four OEM-specific areas of different sizes in the dashboard. These can be used to display Python applications. For more information, See "Configuring the OEM window" on page 1293.

■ **Enhanced: Dashboard position display**

The display of axis positions can now also show the C-axis and slide number if more than one C axis or slide is configured. The control currently supports only one slide. See "Overview of the available dashboard elements" on page 1296.

■ **Enhanced: Dashboard feed-rate display**

The feed-rate display for the slides can now also show the spindle number of the feed spindle that is definitive for calculation of the feed per revolution. See "Overview of the available dashboard elements" on page 1296.

■ **Enhanced: Dashboard spindle display**

The spindle display can now show the spindle selected using the spindle change key.

If a spindle is running in slave mode, its programmed value is only displayed on the master spindle. The display for the slave spindle only shows the actual value, which depends on the master spindle. See "Overview of the available dashboard elements" on page 1296.

■ **New: File management with project directories**

The control now offers the possibility of managing NC programs, DXF contours, ICP contours and cycle programs in separate directories (projects). Also, the Cut/Paste function was added to the file dialogs, and the Copy and Delete functions were revised so that the file manager now provides the usual functions. OEM programs (M functions, expert programs, etc.) can be stored in a protected folder on the PLC partition (See "Expert programs" on page 1476).



■ **New: Rear-face machining with opposing spindle**

The following functions have been added to the control so that it can support rear-face machining with opposing spindle:

• **Dashboard display for rear-face machining**

The new dashboard element can be used to show the status of rear-face machining and the current zero-point shift (See "Overview of the available dashboard elements" on page 1296).

• **New: MMI supports rear-face machining with opposing spindle**

The parameter WP (active workpiece spindle) was added to the input cycles for teach-in and manual operation, in order to support rear-face machining with opposing spindle. The current workpiece spindle is entered in the cycles as a proposed value when making a new entry. The setup functions also include the active workpiece spindle and can thus also be used on the main or opposing spindle. Refer to the User's Manual for your control for more information about this.

• **New: Simulation supports rear-face contours**

The simulation now also supports the display of rear-face contours. In addition, in the smart.Turn editor the current contour of the workpiece blank and the finished part can be saved and reloaded for rear-face machining. Refer to the User's Manual for your control for more information about this.

• **New: ICP editor supports rear-face contours**

The ICP editor now also supports the editing of rear-face contours. Refer to the User's Manual for your control for more information about this.

• **New: Activating kinematics for rear-face machining (G30)**

The G function G30 is now available for activation of the kinematics for rear-face machining (See "Kinematic models for rear-side machining" on page 1458).

■ **New: Spindle synchronization (G720)**

The spindle synchronization option synchronizes the shaft speeds of two or more spindles so that they rotate synchronously, with a gear ratio or a defined offset. The synchronism can be used to transfer the workpiece between the main spindle and the opposing spindle, or for special machining tasks such as polygonal turning (manufacture of key flats without time-consuming milling) or hobbing. Refer to the User's Manual for your control for more information about this.

■ **New: Saving the offset angle for spindle synchronization (G905)**

The G905 function can be used to store the offset angle of main and opposing spindles during spindle synchronization, and take it into account for a zero-point shift in the C axis (G152). Refer to the User's Manual for your control for more information about this.

■ **New: Traversing to a dead stop (G916)**

The "traverse to a fixed stop" function (G916) is now available for transferring the workpiece to the second traversable spindle or for pressing the tailstock against the workpiece. To do this, the control moves up to the fixed stop and stops as soon as the servo lag has been reached. Then the position of the fixed stop is saved and the remaining path of traverse is deleted. The contact force at the stop position can be programmed (See "Traversing to a fixed stop (G916) and sleeve monitoring (G930)" on page 1464).

■ **New: Controlled parting (G917)**

Controlled parting using servo-lag monitoring (G917) can now be activated to prevent collisions caused by incomplete parting processes. The control checks whether a servo lag occurs when the workpiece is moved along a defined path after it has been cut off. The tensile force for moving the two cut-off parts of the workpiece away from each other can be programmed. Refer to the User's Manual for your control for more information about this.

■ **New: Sleeve monitoring (G930)**

The G930 function makes it possible to define and monitor the maximum contact force for an axis. This function can be applied to use the opposing spindle as a mechatronic tailstock, for example (See "Traversing to a fixed stop (G916) and sleeve monitoring (G930)" on page 1464).

■ **New: Program list with file preview**

A file preview is now displayed below the file list during program selection of cycle programs. A machine parameter is used to toggle between hiding/showing the file preview (See "File preview during program selection" on page 1410).

■ **New: Starting block of cycle programs in program run**

When selecting the program run mode, until now the first cycle in a cycle program was selected, regardless of the cycle selected in teach-in. This behavior can now be changed via machine parameter insofar as the selected cycle is confirmed when changing from teach-in to program run (See "Cycle selection in Program Run" on page 1409).

■ **New: Expanded SIK dialog with additional functions**

The dialog for enabling software options (MOD code number **SIK**) was revised and expanded. In addition to improved transparency, new functions are available. For example, the HEIDENHAIN "TNCOEMOption Key Generator" software for PCs can now be used to enable any option for a limited time. If one of your customers wants to test an option before buying it, you can use this software to generate a code number for this option and choose any test period from 1 to 90 days. See "Enabling software options" on page 130.

■ **New: Selective parameter backup**

The machine parameters now make it possible to configure any file lists that are saved under unique key names on the control. These are used for parameter backups. When starting the parameter backup, in a dialog box you can individually select all defined file lists via their key names. Parameter backups can now be carried out separately for machine parameters and PLC parameters, for example. For more details on parameter backups, please see "Selective parameter backup" on page 1794.

■ **Enhanced function: SAVE SERVICE FILES**

When saving service files (See "Saving log files (service files)" on page 1267), you can now choose any file name for the service \*.ZIP file.

■ **New: Input of relative and absolute paths**

The "Save as" and the "Open" dialog (e.g. in the machine configuration) now also supports the input of absolute or relative paths in addition to the input of file names.



■ **New: Manual change systems for the tool turret**

The control now supports the management of manual change systems for the tool turret. These systems are special tool holders with a fixture for tool inserts so that the tools can be exchanged during NC machining with just a few simple steps. This makes it possible to increase the number of available tools for the same number of pockets. Refer to the User's Manual for your control for more information about this.

■ **New: Integrated calculator supports the input of HEX numbers**

The MANUALplus 620 features a very powerful integrated calculator (CALC key). This calculator has for some time now already provided the possibility of activating a scientific view with expanded calculator operations, for example. Now the calculator also supports the input of hexadecimal numbers via soft keys. Until now, an external USB keyboard was required for entering the HEX numbers A to F.

■ **New: Behavior of nominal position value filters during measurement with the TT has been changed**

When tools are measured with the TT tool touch probe, the nominal position value filters are now only deactivated during the probing movement and the retraction movement. If, for example, the TT cycle is interrupted by the user and the axes are moved manually, the filters are reactivated automatically. This ensures jerk-free movement of the axes.

■ **New: sik.info file with information about the SIK of the MANUALplus 620:**

Now the MANUALplus 620 automatically saves information about the current SIK in the `PLC:\service\sik.info` file each time the control is started. The active software options, option designations, the current FCL and the SIK ID and SIK serial number are saved, along with other data. The `sik.info` file is also saved with the service files.

■ **New: System check in the event of incorrect shutdown**

If the supply voltage of the MANUALplus 620 was switched off although the NC software had not been shut down properly, a system check will now be performed during the next startup. During the check the message **System Secured Startup** is displayed instead of **System Startup**. If the system check detects an inconsistent file system, the MANUALplus 620 displays an error message and the startup of the control is interrupted.



Warning

Inappropriate switch-off of the MANUALplus 620 can lead to data loss!

To prevent data from being lost at switch-off, you need to shut down the NC software of the MANUALplus 620 as follows before turning off the main switch of the machine:

Press the soft key for shutting down the control. When the MANUALplus 620 displays the message **NOW IT IS SAFE TO TURN POWER OFF** in a superimposed window, you may cut off the power supply to the MANUALplus 620.

- **New: Kinematic configurations for rear-face machining**  
 Additional kinematic configurations with a second workpiece spindle (S4) and a second C axis (C2) were introduced for rear-face machining with opposing spindle (See "Preconfigured subkinematics" on page 739).
- **New: Help graphics for "vertical, to the left of the workpiece"**  
 The entire range of help graphics is now also available for vertical lathes if the tool carrier is located to the left of the workpiece (See "Coordinate system of the lathe" on page 137).
- **New: Dialog window for selecting files and directories**  
 In the configuration editor (**Machine parameter** mode of operation) the paths no longer need to be entered through the keyboard. For machine parameters that require the entry of a path to a directory or a file, the MANUALplus 620 displays a dialog window for selecting the directory or the file.
- **New: Progress bar in the configuration editor**  
 The configuration editor (**Machine parameter** mode of operation) now displays a progress bar for the functions listed below if they take a long time. The progress bar has a CANCEL soft key that can be used to terminate the function ahead of time. However, this may sometimes lead to incomplete files or an unsuccessful search.

  - **Saving help information to a file** function (DATA BACKUP soft key)
  - **Saving a data tree to a file** function (DATA BACKUP soft key)
  - Search function in the configuration editor (FIND soft key)
  - GOTO function
- **Enhanced: Number system can be selected for numerical parameters**  
 When editing a numerical value in the configuration editor (**Machine parameter** mode of operation), you can now switch the number system. You can choose between decimal (DEC), hexadecimal (HEX) and binary (BIN). The current value entered is converted when the number system is switched.
- **Enhanced: Editing of machine parameter subfiles**  
 The function for loading machine parameter subfiles (LOAD MP SUBFILE soft key) in the **Machine parameter** mode of operation was enhanced (See "Machine-Parameter Subfiles" on page 383):

Soft key	Function
LOAD MP SUBFILE	Calls the function for activating/editing MP subfiles
LOAD AND SELECT	The selected MP subfile is loaded and activated. The parameters are effective immediately and can be edited in the configuration editor.
ONLY EDIT	The selected MP subfile is opened only for editing and is not effective. For example, this function can also be used to edit reset parameters in MP subfiles without having to restart the MANUALplus 620.

■ **Enhanced: Search function in the configuration editor**

The search function in the configuration editor (**Machine parameter programming** mode of operation) was enhanced. See "Finding/Replacing" on page 339:

- Simultaneous selection of multiple search criteria possible
- If the machine configuration has been searched down to the end or up to the beginning (depending on the selected search direction) and the search term has not been found, a new query is displayed. Upon request the control continues searching in the opposite direction.

■ **New: New behavior when parameters are changed while NN\_GenCycleAfterReConfig (M4174) is set**

Changing a machine parameter while the **NN\_GenCycleAfterReConfig** marker is set leads to a recompilation of the PLC program. Now changes to such parameters are prevented in any case while the NC program is running. Therefore, for parameters with the behavior **Change at any time** (NOTHING), the behavior **PLC/Pgm. run is locked** is now displayed to indicate the changed behavior.

■ **New: Reset system settings**

In the configuration editor (**Machine parameter** mode of operation), the new **RESET SETTINGS** soft key in the **MORE FUNCTIONS** menu can be used to reset all nonvolatile (= permanent) system settings (See "Resetting system settings" on page 364).

MP number	Config object	Parameter	Description of change
100103	CfgHardware	MP_currentControlAdjust	The parameter was removed from the machine configuration.
100401	CfgFilter	MP_typeFilter1	The parameter was removed since as of NCK-SW 597 110-05 there are new MPs for configuration of the nominal position value filters, see page 814.
100402		MP_orderFilter1	
100403		MP_typeFilter2	
100404		MP_orderFilter2	
102307	CfgPlcPath	MP_compErrorTable	The machine parameter was removed from the configuration. The path for the error table of the PLC compiler has now been permanently set to <b>SYS:\config\plccomp.ert</b> by HEIDENHAIN and cannot be configured anymore.
104701	CfgOemPosition	MP_value	The new ACTUAL POSITION CAPTURE soft key is available for the parameters for configuring OEM position values. The soft key displays a soft-key row showing the available axes. If you press an axis soft key, the MANUALplus 620 adopts the position of the axis from the REFNOML system, see page 1657.
400013	CfgAxisHardware	MP_inverterInterface	The <b>MP_pwmSignalOutput</b> parameter was renamed to <b>MP_inverterInterface</b> , see page 657.
400016	CfgAxisHardware	MP_checkPhiFieldRef	The parameter <b>MP_checkPhiFieldRef</b> was removed.
400305	CfgFeedLimits	MP_maxAcceleration	The configurable minimum value was set to 0.000000001 m/s <sup>2</sup> .
400501	CfgPositionLimits	MP_swLimitSwitchPos	The new ACTUAL POSITION CAPTURE soft key is available for the parameters for configuring the software limit switches. The soft key displays a soft-key row showing the available axes. If you press an axis soft key, the MANUALplus 620 adopts the position of the axis from the REFNOML system, see page 688.
400502		MP_swLimitSwitchNeg	

<b>MP number</b>	<b>Config object</b>	<b>Parameter</b>	<b>Description of change</b>
401001	<b>CfgCurrentControl</b>	<b>MP_iCtrlPropGain</b>	Automatic calculation of the P and I factor of the current controller is now possible for synchronous and asynchronous motors. However, automatic calculation is not to be used for linear synchronous and torque motors. The calculated value is entered in the configuration. An asterisk (*) is prefixed to the parameters to identify the automatically calculated value, see page 885.
401002		<b>MP_iCtrlIntGain</b>	
401202	<b>CfgPowerStage</b>	<b>MP_ampPowerSupplyType</b>	The parameter was removed from the machine configuration. It is no longer necessary, because the value is now read from the power supply module table <b>SUPPLY.SPY</b> .
401205		<b>MP_ampVoltProtection</b>	Defines the setting for field weakening for synchronous motors. The parameter was revised to provide new modes for field weakening. For the chapter dealing with information on weakened-field operation, please refer to "Weakened field operation" on page 924.

**New machine parameters:**

<b>MP number</b>	<b>Config object</b>	<b>Parameter</b>	<b>Description</b>
100204	<b>CfgMachineSimul</b>	<b>MP_simHardwareType</b>	Defines the simulated CC in the programming station mode, see page 1235.
100405 100406	<b>CfgFilter</b>	<b>MP_shape</b>	The nominal position value filters were thoroughly revised and optimized (See "Configuration of the nominal position value filters as of NCK software version 597 110-05" on page 814).
100405 100406		<b>MP_frequency</b>	
100405 100406		<b>MP_hscMode</b>	
100407		<b>MP_defaultManualOrder</b>	
100610	<b>CfgHandwheel</b>	<b>MP_selectAxes</b>	Selection of the axis/axes that are to be moved by the handwheel configured in <b>MP_type</b> , see page 1338.
102315	<b>CfgPlcPath</b>	<b>MP_pythonScripts</b>	Specifies which Python scripts are automatically started after compilation of the PLC program, see page 1545.
102502	<b>CfgTablePath</b>	<b>MP_readOnlyMode</b>	Activates write-protection for the respective table in the table editor.
118301	<b>CfgPythonScript</b>	<b>MP_parameter</b>	Specifies expanded calling parameters for the Python script, see page 1585.
118302		<b>MP_memLimit</b>	Specifies the maximum memory available for the Python application to be started, see page 1585.
118303		<b>MP_path</b>	When the soft key entered in the key name is pressed, the selected Python script is started, see page 1585.
118304		<b>MP_jobName</b>	Specifies the name of the Python application, see page 1585.
120501	<b>CfgChangePassword</b>	<b>MP_replaceWith</b>	Replaces existing HEIDENHAIN code numbers with the OEM's own code numbers, see page 1231.
120502		<b>MP_hideOriginal</b>	
201516	<b>CfgLaPath</b>	<b>MP_reduceCornerFeed</b>	Reduction of the contouring feed rate at the beginning of a contour element, see page 836.
300112	<b>CfgAxis</b>	<b>MP_advancedSettings</b>	Specifies advanced settings for individual axes, see page 638.



MP number	Config object	Parameter	Description
400313	<b>CfgFeedLimits</b>	<b>MP_limitSpeedAcc</b>	For spindle in speed control loop (M3/M4/M5): Limit speed for reduction of the acceleration, see page 1011.
400314		<b>MP_limitSpeedDec</b>	For spindle in speed control loop (M3/M4/M5): Limit speed for reduction of the braking deceleration, see page 1011.
400315		<b>MP_limitAccSpeedCtrl</b>	For spindle in speed control loop (M3/M4/M5): Absolute acceleration. Effective above <b>MP_limitSpeedAcc</b> , see page 1011.
400316		<b>MP_limitDecSpeedCtrl</b>	For spindle in speed control loop (M3/M4/M5): Absolute deceleration during braking. Effective above <b>MP_limitSpeedDec</b> , see page 1011.
400413	<b>CfgReferencing</b>	<b>MP_externRefPulse</b>	Referencing with external reference signal (X30 or –SP.REF for HSC), see page 1005.
400928	<b>CfgSpeedControl</b>	<b>MP_vCtrlTimeSwitchOff</b>	Pulse switch-off of the power modules. Monitoring time for the braking process. If after the time has expired the axes are still in motion, the pulses of the power modules are switched off, see page 991.
400930		<b>MP_vCtrlSpinSpeedTol</b>	Monitoring of the spindle speed; useful during power milling, for example. Specify the permissible lower spindle speed limit, see page 1026.
400931		<b>MP_vCtrlSpinMinSpeed</b>	Minimum spindle speed as of which the monitoring in MP_vCtrlSpinSpeedTol becomes active, see page 1026.
400932		<b>MP_vCtrlEnclInputFunc</b>	Only in effect with CC 61xx: Specify the maximum input frequency of the motor encoder, see page 1044.
400933		<b>MP_delayEmStopSpin</b>	Delay of emergency-stop reaction of spindles, see page 1026.
401323	<b>CfgServoMotor</b>	<b>MP_testBrakeCurrent</b>	Test of motor brake: Factor for motor stall current, see page 987.
401324		<b>MP_testBrakeTolerance</b>	Test of motor brake: Maximum permissible path, see page 987.

MP number	Config object	Parameter	Description
401510	<b>CfgSpindle</b>	<b>MP_kvFactorM19</b>	kv factor for spindle orientation, see page 1004.
401511		<b>MP_kvFactorTapping</b>	kv factor for tapping, see page 1039.
401512		<b>MP_kvFactorSync</b>	kv factor for spindle synchronism, see page 1033.
401606 401607	<b>CfgPositionFilter</b>	<b>MP_shape</b>	Shape of the nominal position value filter, see page 814.
401606 401607		<b>MP_frequency</b>	Limit frequency of the nominal position value filter, see page 814.
401606 401607		<b>MP_hscMode</b>	Operating mode of the nominal position value filter, see page 814.
401608	<b>CfgPositionFilter</b>	<b>MP_handwheelFilterOrder</b>	Order of the mean-filter value in the Electronic Handwheel mode, see page 814.
402301	<b>CfgAxisCoupling</b>	<b>MP_masterAxis</b>	Synchronized axes: Assign a master axis to the slave axis, see page 764.
402302		<b>MP_mode</b>	Synchronized axes: Mode of the coupling, see page 764.
402303		<b>MP_type</b>	Synchronized axes: Type of coupling, see page 764.
402304		<b>MP_typeOfOffset</b>	Synchronized axes: The parameter specifies how the position offset between master and slave axis is treated, see page 764.
402305		<b>MP_posOffset</b>	Synchronized axes: Value of the position offset with closed coupling, see page 764.
402306		<b>MP_offsetFeed</b>	Synchronized axes: The velocity with which an offset between the master axis and the slave axis is compensated for, see page 764.
402307		<b>MP_maxPosDiff</b>	Synchronized axes: Synchronization monitoring – deletable emergency stop message, see page 764.
402308		<b>MP_ultimatePosDiff</b>	Synchronized axes: Synchronization monitoring – non-deletable emergency stop message, see page 764.
402309		<b>MP_scalingFactor</b>	Synchronized axes: Scaling factor for calculating the slave position, see page 764.



<b>MP number</b>	<b>Config object</b>	<b>Parameter</b>	<b>Description</b>
402310		<b>MP_torqueBias</b>	Synchronized axes: Tensioning torque between master and slave for master-slave torque control (entry for the slave axis), see page 764.
402311		<b>MP_propGain</b>	Synchronized axes: P factor of the torque controller for master-slave torque control (entry for the slave axis), see page 764.
402314		<b>MP_inverseVelocity</b>	Synchronized axes: Reversal of the algebraic sign of the nominal speed value, see page 764.
402315		<b>MP_accFilterTime</b>	Synchronized axes: Time constant for filtering the acceleration curve, see page 764.
402316		<b>MP_autoBrakeTest</b>	Run a brake test automatically with the master axis, see page 764.
403001	<b>CfgDeadStop</b>	<b>MP_deadStopLag</b>	Max. permissible following error, see page 1464.
403003		<b>MP_forthTorqueFactor</b>	Factor for converting the programmed force to a torque, see page 1464.
403004		<b>MP_minTorque</b>	Min. limit of current with quill function, see page 1464.
403005		<b>MP_maxTorque</b>	Max. limit of current with quill function, see page 1464.
403006		<b>MP_torqueTolerance</b>	Tolerance window for status message, see page 1464.
600213	<b>CfgTHDescription</b>	<b>MP_coolantCirc</b>	List with the numbers of the allocated coolant circuits, see page 1399.
601809	<b>CfgGlobalProperties</b>	<b>MP_ncStartWithActCyc</b>	Program run with the most recently selected cycle, see page 1417.
602017	<b>CfgGlobalTechPara</b>	<b>MP_DefaultM3M4</b>	Rotational direction for new units, see page 1421.
604804	<b>CfgGlbDispSettings</b>	<b>MP_mmiFilePreview</b>	Activates file preview during program selection, see page 1410.
605501	<b>CfgBackup</b>	<b>MP_groupList</b>	List with the key names of all backup lists, see page 1794.
605601	<b>CfgBackupGroup</b>	<b>MP_backupFiles</b>	List with the paths of all configuration files, see page 1794.

<b>MP number</b>	<b>Config object</b>	<b>Parameter</b>	<b>Description</b>
605701	<b>CfgRearSideKinem</b>	<b>MP_kinList</b>	Kinematic-configuration key names for rear-face machining, see page 1458.
605702		<b>MP_specWpSpindleList</b>	Workpiece-spindle key names for rear-face machining, see page 1458.
605801	<b>CfgRearSideTrafo</b>	<b>MP_trafoMirAxis</b>	Transformations for mirroring the axes, see page 1458.
605802		<b>MP_trafoMirToolLength</b>	Transformations for mirroring the tool lengths, see page 1458.
605803		<b>MP_zeroPointOffset</b>	Transformations for the offset of the zero point, see page 1458.
605804		<b>MP_mirAxis</b>	List with the key names of the mirrored axes, see page 1458.
605805		<b>MP_toolLengthDir</b>	List with the axis directions of the mirrored tool lengths, see page 1458.
605806		<b>MP_zeroPointOffsAxis</b>	List with the key names of the axes with zero-point shift, see page 1458.

## Machine interfacing

## Configuring the axes and spindle

### ■ **New: Automatic test of motor brakes**

The control now supports the automatic motor brake test. You can carry out an automated functional test of the motor brake after switching on the drive, either before traversing the reference mark or through activation by PLC Module 9143 (See "Automatic test of the motor brake" on page 985).

### ■ **New: Support for synchronized axes (gantry axes and master-slave torque control)**

In gantry axes, two or more closed-loop axes are coupled so that they can only move simultaneously. The main axis is referred to as the master, and the tracking axes as the slaves.

In master-slave torque control, two or more motors (master and slave) are mechanically coupled. Because of the coupling, only one position encoder is required. The motor to which the position encoder is assigned is the master.

The number of slave axes in master-slave torque control and gantry combinations is restricted by the controller unit on which the master axis is configured. The slave axes and the master axis must be configured on the same drive-control motherboard (DSPs). Thus, up to five slave axes are possible per CC 61xx.

Software option 24 is required for both coupling types for synchronized axes. For more information, see "Gantry axes" on page 765, "Activating gantry axes" on page 1452 and "Master-slave torque control" on page 775.

### ■ **New: Additional secondary axes U and V**

In addition to the W axis, the control now also supports the secondary axes U and V. These axes can be used, for example, for the programmable control of a traversable opposing spindle, a mechatronic tailstock or a steady rest. As an alternative, the control can display the compensated position value of the movements of the parallel secondary axes U, V, W, and compensate them with the principal axis. You can use the parameter **MP\_parAxComp** (300205) to define the default setting for the compensation of secondary axes. For more information about the parameter, see "Configuring parallel axes" on page 1446.

### ■ **New: Current Controller and Field Angle Adjustment special operating mode**

A new special operating mode is available for adjusting the integrated current controller and the field angle. The MOD code number **94655** is used to open the new special operating mode. You can find a guideline for commissioning the current controller under "Commissioning of digital axes" on page 1089.

### ■ **New: Support of analog axes/spindle**

In the HSCI system, analog nominal-value outputs are now available via the new CMA-H 04-04-00 SPI expansion module, e.g. for controlling spindles and auxiliary axes. See also "CMA-H SPI module for analog axes" on page 78 of this Update Information. For more information about the installation, electrical connection and configuration of the CMA-H, please see "Analog Nominal Value Output" on page 255.

### ■ **New: Oscilloscope signals for I<sup>2</sup>-T monitoring**

Two new signals are available in the integrated oscilloscope, see also "Integrated Oscilloscope" on page 1145:

- **I2-t (mot.)**: Current value of I<sup>2</sup>-t monitoring of the motor [%]
- **I2-t (p.m.)**: Current value of I<sup>2</sup>-t monitoring of the power module [%]

### ■ Enhanced: Nominal position value filters

The nominal position value filters were thoroughly revised and optimized. Overview of the most important improvements:

- For each axis the filter parameters are now only for the filter shape (**MP\_shape**) and the frequency (**MP\_frequency**).
- New machine parameter: **MP\_hscMode**. The HSC modes "smoothing" (optimum filter for finishing) and "roughing" (optimum filter for roughing) can be set for the HSC filter.
- Now default filters are defined in the configuration object **CfgFilter**. These filters apply for those axes that have no individual setting in the **CfgPositionFilter** configuration object.
- All machine parameters in **CfgPositionFilter** are optional now. The settings of **CfgFilter** are automatically adopted if no values are defined in **CfgPositionFilter**.
- Now explicit parameter designations distinguish between position filters and cutter location filters (for rotary axes).
- The optional machine parameters **maxTransAcc** and **MP\_maxTransAccHi** (CfgLaPath) are now available in order to limit radial accelerations. The new parameters are generally in effect for curved paths such as free-form surface and circle machining. The axis acceleration in **MP\_maxAcceleration** (CfgFeedLimits) is not exceeded, regardless of the setting in the two parameters.
- If **MP\_maxG1Feed** (CfgLaPath) is set to the value 0, the dynamically lower settings (i.e. no HIGH parameters) are now in effect for all feed rates (even FMAX). Example: **MP\_pathTolerance** is also effective during rapid traverse, and not **MP\_pathToleranceHi**.



#### Note

During a software update, the configuration of the nominal position value filters is automatically adapted to the new parameters. This can result in slight changes in the filter frequency due to the optimization of the HSC filters. However, the behavior of the machine remains unchanged. The old HSC filters can also be replaced by the new advanced HSC filters.

#### Important note:

The automatic adaptation of the filter configuration can only take place if all filter settings correspond to NC software version 548 328-03. If many axes have the same filter settings, the values will automatically be saved as default setting in **CfgFilter**.



#### Note

Please also note other information on the new nominal position value filters given in this Technical Manual:

- For a comprehensive description of the new nominal position value filters, see "Nominal position value filter" on page 811.
- A guideline for setting the new nominal position value filters and the look-ahead parameters is provided in "Configuring the nominal position value filter and look-ahead parameters" on page 1124.



■ **Enhanced: Symbolic memory interface (API 3.0) – New operands introduced:**

PLC operand / Description	Type
NN_GenSafetySelftest Safety self-test of the control (emergency stop test) 0: Self-test is not active 1: The control is currently performing the self-test	M

■ **Modified: Behavior of markers for feed-rate enable**

Up to now, the marker **PP\_ChnWorkFeedEnable** was available on the memory interface, but it was not evaluated by the run-time system. Now the marker is supported.

Up to now, the run-time system used **PP\_ChnFeedEnable** to enable the feed rate for all axes of an NC channel. Now it is possible to enable the feed rate for individual axes via **PP\_AxFeedEnable**, even if **PP\_ChnFeedEnable** is not set (See "Feed-rate enable" on page 852).

■ **Modified: Effect of PP\_AxManualFeedMax marker**

Up to now, **PP\_AxManualFeedMax** could only be used to limit the feed rate in the manual operating modes. Now **PP\_AxManualFeedMax** is effective in all operating modes (See "Feed rate values in PLC operands" on page 846).



Note

Check the PLC program; an adaptation to the new behavior might be necessary!

■ **Modified: Behavior of NN\_AxLogNumber for deactivated axes**

**NN\_AxLogNumber** now changes its value if you deactivate an axis with Modules 9226 or 9418. **NN\_AxLogNumber** is set to the value -1 for deactivated axes. **NN\_AxLogNumber** shows the current operating status of the axis and therefore does not change immediately when the module is called, but a little later.



Note

Please note that activating a deactivated axis can take up to half a second.

■ **Modified: Behavior of structure definitions for the API 3.0**



The behavior of the structure definitions for the symbolic memory interface API 3.0 was modified. In the configuration file of the PLC compiler (\*.MCG), for the constants **OMG\_COUNT**, **CHANNEL\_COUNT**, **AXIS\_COUNT** and **SPINDLE\_COUNT** you can now define values that differ from the internal constants **MAX\_OMG\_PRODUCT**, **MAX\_CHANNEL\_PRODUCT**, **MAX\_SPINDLE\_PRODUCT** and **MAX\_AXIS\_PRODUCT**. If your definition exceeds the internal maximum values, the control automatically limits the value. If HEIDENHAIN increases the internal product-specific constants (e.g. as a part of an update), the configuration file of the PLC compiler does not need to be adapted. If the constants **OMG\_COUNT**, **CHANNEL\_COUNT**, **AXIS\_COUNT** and **SPINDLE\_COUNT** are not defined by the machine manufacturer, the NC software automatically uses the internal constants, see page 1509.



■ **New: Saving the states of PLC operands in an ASCII file / Loading the states of PLC operands from an ASCII file**

Within the TABLE function (PLC programming operating mode) you can now use the SAVE M/B/W/D soft key to save the states of selectable operands or operand ranges in an ASCII file \*.A. The RESTORE M/B/W/D soft key is used to load the saved states from an ASCII file. Multiple operands must be separated by a comma, ranges are indicated by two periods (.). Example: **M0..M127,B0..B799,B800..B999,M1250**

This function is especially useful if servicing becomes necessary, and the states of non-volatile operands are to be transferred to a new computer unit, for example.

Soft key	Function
	Save states of selectable operand ranges in an ASCII file. Ranges of more than one operand can be saved, e.g. <b>M0..M100,W100..W118</b>
	Load the states of saved operands from an ASCII file

■ **New: Enhanced diagnostic information for Python scripts (option 46)**

The MANUALplus 620 now writes additional diagnostic information about the starting and stopping of a Python script in an additional log file. The path of the log file is **PLC:\service\[script name].a**. If a serious error occurs in the script, the complete sequence of all function calls (traceback) is written to the log file. The information is also displayed in the error message and copied to the general error log.

■ **New: Support of pop-up menus**

The MANUALplus 620 now supports the display of pop-up menus. You can make pop-up menus with the program MenuDesign (provided in the PLCdesignNT package). A pop-up menu is called through an OEM soft key in the vertical soft-key row and covers the horizontal soft-key row with OEM soft-keys. This function is interesting, for example, when you need additional space for soft keys for more comprehensive tasks in the PLC. See "Pop-up menu" on page 1310.

- **Enhanced: Module 9034  
(Load machine parameter subfile)**  
New error codes have been added:  
6: Change not possible with a running NC program  
7: Access rights insufficient, or access already reserved  
8: Internal system error  
See page 386.
- **Enhanced: Module 9035  
(Read NC status information)**  
New NC status information has been added:  
#8: Selected axis in machine mode (for actual-position capture)  
#20: Speed for HR 410
- **Enhanced: Module 9038  
(Read the status information of the axes)**  
Constraints for the MANUALplus 620 and new transfer value #9 (axis is slave axis) have been added, see page 671.
- **Modified: Modules 9040 and 9041  
(Read axis coordinates)**  
To read the data for an array of axes, Modules 9040 and 9041 now use the constant AXIS\_COUNT that can be defined by the OEM, instead of the array width from the internal constant MAX\_AXIS\_PRODUCT.
- **Enhanced: Module 9125  
Stop PLC axis at next Hirth grid position**  
New constraints have been added, see page 704.
- **Enhanced: Module 9129  
Status of torque limiting by the PLC**  
New mode 3 has been added: Limitation reached / not reached, see page 898.
- **Enhanced: Module 9144  
Configuration of the EMERGENCY STOP test**  
New modes have been added—mainly for decentral automation solutions (PNC 610):  
Mode 10: Define the operating mode for functional safety  
Mode 11: Request for testing the axis position  
See page 994.
- **Enhanced: Module 9163  
Switch the drive parameters for delta and wye connection**  
New error reactions and constraints have been added, module description has been expanded, see page 1031.
- **Enhanced: Module 9164  
Read the actual speed value of drive motors**  
New constraints have been added, module description has been expanded.  
See page 855.
- **Enhanced: Module 9165  
Read the temperature of the drive motors**  
New constraints have been added, module description has been expanded.  
See page 963.
- **Enhanced: Module 9166  
Read the actual utilization of the drive motors**  
New constraints have been added, module description has been expanded.  
See page 978.
- **Enhanced: Module 9227  
Position auxiliary axes and NC axes**  
New mode for NC and auxiliary axes has been added:  
Bit 1 = 1: Software limit switch active. See page 700.

- **Enhanced: Module 9411**  
**Read actual spindle values**  
 New spindle information has been added:  
 #5 (accumulated traverse path), #12 (nominal speed at the end of acceleration), #21 (information about path-dependent lubrication).  
 Return codes for spindle information #20 have been enhanced (information on wye/delta operation). See page 676.

- **Enhanced: Module 9418**  
**Set status for spindle**  
 New modes for spindle have been added:  
 #4 (reset accumulated traverse path), #5 (reset accumulated traverse path for path-dependent lubrication). See page 684.

## New PLC modules

- **Module 9048:**  
**Interrogate the operating states of axes**  
 Module 9048 is used to interrogate the operating status/activation status of a certain axis or for all axes together. See page 687.
- **Module 9065:**  
**Status of the commissioning function**  
 Module 9065 is used to interrogate status information of commissioning functions dealing with the determination of the field angle, and with the commissioning of the current controller of an axis. See page 1069.
- **Module 9126:**  
**Configure axis coupling**  
 With Module 9126 you can close or open the coupling of a PLC axis as slave to another axis. See page 773.
- **Module 9127:**  
**Interrogate the status of the axis coupling**  
 Module 9127 is used to interrogate the status of the coupling of an axis with another axis. See page 774.
- **Module 9143:**  
**Activate motor brake test**  
 This module can start an axis-specific brake test with the configuration from the machine parameters or with other values for the **MP\_testBrakeCurrent** and **MP\_testBrakeTolerance** machine parameters. See page 987.
- **Module 9250:**  
**Start the PLC table editor**  
 Module 9250 starts a table editor in the Machine operating modes. See page 1615.
- **Module 9251:**  
**Exit the PLC table editor**  
 Module 9251 ends the PLC's table editor that was started with Module 9250. See page 1617.
- **Module 9252:**  
**Position the cursor in the PLC table editor**  
 Module 9252 moves the cursor in the PLC's table editor to a certain row and column. See page 1618.
- **Module 9295:**  
**Start a Python instance**  
 A Python instance can be started with Module 9295. Refer to the Python documentation.
- **Module 9296:**  
**Send a signal to a Python instance**  
 With Module 9296 you can send a "cancel" signal to a Python instance that was started with Module 9295. The actual end of the process is not awaited. Refer to the Python documentation.





- **Module 9297:**  
**Interrogate the status of a Python instance**  
The status of a Python instance that was started with Module 9295 can be interrogated with Module 9297. Refer to the Python documentation.
- **Module 9311:**  
**Dynamically change values for friction compensation**  
Module 9311 is used at run-time to prescribe other values for the friction compensation. The original values from **MP\_compFriction0**, **MP\_compFrictionT1** and **MP\_compFrictionT2** are temporarily overwritten in the DSP. The values in the machine configuration remain unchanged. See page 726.
- **Module 9355:**  
**Interrogate tool life**  
Module 9355 is used to request information about the tool life of the tool used in an NC channel.
- **Module 9436:**  
**Change the numeric value of a machine parameter persistently**  
Module 9436 is used to enter a numeric value in the indicated machine parameter. The value of the machine parameter is overwritten in the run-time memory, and the new value is stored persistently in the **\*.cfg** file, overwriting the previous value.  
See page 395.
- **Module 9470:**  
**Special operating modes and functions for commissioning**  
Module 9470 is used to interrogate the status and parameters of various special operating modes and functions of an axis.

## 1.4 Hardware

### 1.4.1 CMA-H SPI module for analog axes

Expansion module for analog axes/spindles in the HSCI system

Expansion module for analog axes/spindles in the HSCI system:

■ **CMA-H 04-04-00:**

Module for controlling analog axes or spindles. The CMA-H is inserted in one of the SPI slots on the bottom of the controller units. The analog control loop outputs are accessed only via the NC. Interpolated movements of analog axes with other axes are not possible.

**The CMA-H 04-04-00 is supported by the following CC 61xx and UEC 11x:**

- CC 6106 as of ID 662636-01
- CC 6108 as of ID 662637-01
- CC 6110 as of ID 662638-01
- UEC 111 as of ID 625777-02
- UEC 112 as of ID 625779-02

**CMA-H 04-04-00**

**ID 688 721-xx**



## 2 Introduction

### 2.1 Meaning of the Symbols Used in this Manual



#### Danger

Failure to comply with this information could result in most serious or fatal injuries, and/or in substantial material damage.



#### Warning

Failure to comply with this information could result in injuries and interruptions of operation, including material damage.



#### Note

Tips and tricks for operation as well as important information, for example about standards and regulations, as well as for better understanding of the document.

### 2.2 Proper and Intended Operation

The described components may only be installed and operated as described in this manual. Commissioning, maintenance, inspection and operation are only to be performed by trained personnel.

### 2.3 Trained Personnel

Trained personnel in the sense of this manual means persons who are familiar with the installation, mounting, commissioning, and operation of the HEIDENHAIN components. Furthermore, electrical engineering work on the system may be carried out only by trained electrical engineering technicians or persons trained specifically for the respective application.

Basically, persons who perform work on HEIDENHAIN components must meet the following requirements:

- They must have been trained or instructed in the standards of safety engineering.
- They must have appropriate safety equipment (clothing, measuring systems).
- They should be skilled in first-aid practice.

## 2.4 General Information

The HEIDENHAIN **MANUALplus 620** contouring control was conceived for standard CNC lathes. The control has an integrated digital drive control and drives the power modules through PWM signals.


Integrating the drive controllers in the MANUALplus 620 provides the following benefits:

- All the software is contained centrally in the NC; this means that the individual components of the NC, such as feed axes, spindle, NC and PLC, are optimally matched.
- High control quality, because the position controller, speed controller and current controller are combined into one unit.
- The same functions are available for commissioning, optimizing and diagnosing feed drives as well as spindles.

The **MANUALplus 620** supports lathes up to the following level:

- 1 slide (NC channel)
- 6 axes (X/Z/Y/U/V/W axis)
- 3 spindles (main spindle and opposing spindle, driven tool)
- 2 C axes (via main spindle drive or with separate drive)

The following diagram illustrates drive control with the use of a rotary encoder for measuring the actual speed values and a linear encoder or angle encoder for measuring the actual position values.




The **MANUALplus 620** is based on **HEIDENHAIN NCK**, the software platform for the HEIDENHAIN control family. Other controls with NCK are, for example, the TNC 620, TNC 320 or the CNC PILOT 620.

The **MC 6110T**, the compact main computer of the MANUALplus 620, takes up very little space, as it is housed in the operating console, directly behind the integrated 12.1-inch TFT display.


The MC is connected to the CC controller unit, the MB machine operating panel and the PL 6xxx PLC input/output systems via **HSCI** (HEIDENHAIN Serial Controller Interface). The connection of the various control components via HSCI offers numerous benefits, including:

- Simple and uncomplicated wiring
- High noise immunity
- Simple commissioning
- Comprehensive yet straightforward possibilities for diagnostics

The TNC 620 is prepared for the connection of incremental and absolute position and shaft-speed encoders. EnDat 2.2, which is purely digital and compatible to version 2.1, makes it possible to very rapidly transmit highly resolved position values over long cable lengths. An overview of EnDat 2.2:



Overview of the purely digital control architecture with HSCI and EnDat 2.2:



The **TNC 620** is designed for connection of a compact inverter or modular inverter system. A complete control package, including drives and HEIDENHAIN motors, can be delivered (see the "Inverter Systems and Motors" Technical Manual).

## 2.4.1 HSCI interface

The individual control components communicate with each other via the HSCI connection (HEIDENHAIN Serial Controller Interface). A connection via HSCI is only permitted for HEIDENHAIN components that are part of the machine tool's control system. In addition, the HSCI connecting cable may only be installed in a protected manner (e.g. within the electrical cabinet, cable ducts).

The following features characterize the HSCI connection:

- Based on standard 100BaseT Ethernet hardware
- Telegrams of the HSCI connection are not compatible with the Ethernet
- Line structure
- Only one master in the system (MC), all other devices are HSCI slaves

Different addresses are assigned to the individual participants in the HSCI network. The addresses are assigned dynamically during booting of the MC. The HSCI addresses of the participants are formed from an HSCI address (8 bits) and a device type address (6 bits).

After the machine has undergone acceptance testing, the nominal configuration of the control is saved in the IOC file on the control's memory card. This nominal configuration contains the assignment of the device-type address and serial number of the device to the individual HSCI addresses. The momentary configuration is ascertained during startup of the system by requesting the serial numbers. The momentary configuration is compared with the nominal configuration. If there is a deviation, the machine operator is prompted to check the configuration.

The following applies to the assignment of the HSCI address:

- The HSCI address (bus address) is the result of the device's position in the bus
- The master (MC) always has the HSCI address 0.
- The HSCI addresses of the slaves result from their position in the bus:
  - First device after the master (MC): Bus address 1
  - Second device after the master (MC): Bus address 2
  - etc.

The device-type address is for internally distinguishing between connected HSCI participants. Each device type (MC, CC, PL, MB, etc.) is assigned a type specification that is used to address all HSCI participants of this type.

More information on the connection of the HSCI components is provided under "HSCI" on page 168.

## 2.5 Component Overview of MANUALplus 620

### 2.5.1 MC main computer, CFR memory card and SIK

The MANUALplus 620 always includes at least the following components:

- MC 6110T main computer  
(MC = Main Computer)

and either:

- CC 61xx controller unit  
(CC = Controller Computer)
- PL 620x system PL
- Modular or compact HEIDENHAIN inverter system

or


- UEC 11x controller unit with integrated inverter and PLC

#### MC 6110T main computer

Compact main computer for incorporation in the operating console, with integrated TFT flat-panel display and operating keys. Machine operating panel is optional.

- Processor:  
Intel Celeron M 1.0 GHz
- 1 GB RAM
- HSCI interface
- Ethernet interface 100BaseT
- 3 x USB 2.0  
(1 in the operating panel, 2 on the rear)
- 1 x RS-232C

MC 6110T **ID 731 604-xx**



Additionally required:


- **CFR** CompactFlash memory card
  - CompactFlash memory card, Type 1
  - Contains the NC software
  - 1 GB memory capacity, of which 250 MB are for V:\ partition and 50 MB for O:\ partition. Remaining memory is used for system data.





■ **SIK** System Identification Key

- Contains the NC software license for enabling control loops and software options.
- The SIK number provides the control with a unique identification.



Main computer components	ID
MC 6110T compact main computer	731 604-xx
CompactFlash memory card (CFR) with MANUALplus 620 software	733 606-51
SIK component, 3 control loops and the "Teach-in," "smart.Turn," "Thread recutting" and "C-axis machining" software options are enabled, see "Software options" on page 122.	733 604-53
SIK component, 3 control loops and the "Teach-in" software option are enabled, see "Software options" on page 122.	733 604-55
SIK component, 4 control loops and the "Teach-in" and "C-axis machining" software options are enabled, see "Software options" on page 122.	733 604-56
Control loop expansions:	ID
Enabling for:	
Addition of a 4th control loop	354 540-01
Addition of a 5th control loop	353 904-01
Addition of a 6th control loop	353 905-01
Addition of a 7th control loop	367 867-01
Addition of an 8th control loop	367 868-01
Addition of a 9th control loop	370 291-01
Addition of a 10th control loop	370 292-01

Further control loops can be enabled in addition to the control loops of the respective SIK version. The maximum number is:

- UEC 111: 4 control loops
- UEC 112: 5 control loops
- CC 6106: 6 control loops
- CC 6108: 8 control loops
- CC 6110: 10 control loops



Note

**Control loop for C1/C2 axis:** If the drive of the main/opposing spindle is used for the C1/C2 axis, one control loop is sufficient for the main/opposing spindle and the C1/C2 axis. If there is a separate drive for the C1/C2 axis, then the main/opposing spindle and C1/C2 axis each require their own control loop.

### 2.5.2 SIK (System Identification Key)

Each control is clearly identified by the SIK (System Identification Key).



Note

If you replace the MANUALplus 620, you must also replace the SIK in order to ensure that the enabled options will also be enabled on the new hardware.

### 2.5.3 CC 61xx controller units

CC 61xx	
Controller unit with HSCI interface for up to 6, 8 or 10 control loops	
It is equipped with:	
<ul style="list-style-type: none"> <li>■ 6, 8 or 10 PWM outputs</li> <li>■ 6, 8 or 10 speed encoder inputs</li> <li>■ 6, 8 or 10 position encoder inputs</li> <li>■ 2 SPI expansion slots</li> <li>■ Power supply through UV(R) power supply unit</li> </ul>	
CC 6106	ID 662 636-xx
CC 6108	ID 662 637-xx
CC 6110	ID 662 638-xx



## 2.5.4 UEC 11x controller unit with integrated inverter and PLC

### UEC 11x

Controller unit with integrated inverter and PLC for up to 5 control loops. Compact unit for machines with limited number of axes and low power demands.

It is equipped with:


- HSCI interface
- 4 (UEC 111) or 5 (UEC 112) speed encoder inputs
- 4 (UEC 111) or 5 (UEC 112) position encoder inputs
- Connection for 3 axes plus spindle (UEC 111) or  
Connection for 4 axes plus spindle (UEC 112)
- Braking resistor
- 38 PLC inputs, 23 PLC outputs (expandable via PL 61xx)
- Integrated power supply unit 24 V NC / 3.5 A for supplying the HSCI components

#### UEC 111 with 4 control loops

ID 625 777-xx


#### UEC 112 with 5 control loops

ID 625 779-xx



**Designation of the  
MC 6110T, CC 61xx  
and UEC 11x**

ID of MC 6110T:



The basic ID number indicates hardware differences.  
This first digit of the variant number indicates hardware changes.

Variant	Changes to MC 6110T
xxx xxx-y1	Initial version

Variant	Changes to CC 6106
xxx xxx-y1	Prototype
xxx xxx-y2	Prototype
xxx xxx-y3	Initial version

Variant	Changes to CC 6108
xxx xxx-y1	Initial version

Variant	Changes to CC 6110
xxx xxx-y1	Initial version

Variant	Changes to UEC 111
xxx xxx-y1	Prototype
xxx xxx-y2	Initial version

Variant	Changes to UEC 112
xxx xxx-y1	Prototype
xxx xxx-y2	Initial version



## 2.5.5 PLC input/output systems with HSCI interface

The PLC inputs and outputs of the MANUALplus 620 are available via the external modular PL 6xxx PLC input/output systems.

The PL 6xxx consists of the PLB 6xxx basic module and one or more I/O modules. The basic modules are connected to the MC main computer via the HSCI interface.



### Note

The MC 6110T main computer of the MANUALplus 620 does **not** have integrated PLC inputs/outputs, and has **no** connections for TS or TT touch probes. In order to operate the control, at least the PL 62xx system PL (when using a CC 610x) or the UEC 11x controller unit with integrated inverter and PLC is necessary. (The system PL is integrated in the UEC.)

The PLC inputs/outputs are configured with the PC software IOconfig.

## System PL

### PL 62xx

System PL, consisting of PLB 620x basic module and I/O modules.

- One module must be in the HSCI system if no UEC 11x is used
- Available with 4, 6 or 8 slots
- HSCI interface
- Connections for TS and TT touch probes
- Safety-relevant PLC inputs/outputs

For an overview of the available I/O modules, see "I/O modules" on page 91.

They are mounted on standard NS 35 rails (DIN 46 227 or EN 50 022)

**PLB 6204**    **ID 591 832-xx**

**PLB 6206**    **ID 630 054-xx**

**PLB 6208**    **ID 630 055-xx**



## Expansion PL

### PL 61xx

Expansion PL, consisting of PLB 620x basic module and I/O modules.

- Available with 4, 6 or 8 slots
- HSCI interface
- Up to 7 PL 61xx can be present in the HSCI system

For an overview of the available I/O modules, see "I/O modules" on page 91.

They are mounted on standard NS 35 rails (DIN 46 227 or EN 50 022)

**PLB 6104**    **ID 591 828-xx**

**PLB 6106**    **ID 630 058-xx**

**PLB 6108**    **ID 630 059-xx**



## I/O modules

I/O modules are available with digital and analog inputs and outputs. For partially occupied PLB basic modules, the unused slots must be occupied by an empty housing.

PLD-H xx-xx-xx

Digital I/O module:

- **PLD-H 16-08-00:**  
I/O module with 16 digital inputs and 8 digital outputs
- **PLD-H 08-16-00:**  
I/O module with 8 digital inputs and 16 digital outputs
- **PLD-H 08-04-00:**  
I/O module with 8 digital inputs and 4 digital outputs
- **PLD-H 04-08-00:**  
I/O module with 4 digital inputs and 8 digital outputs

**PLD-H 16-08-00**      **ID 594 243-xx**

**PLD-H 08-16-00**      **ID 650 891-xx**

**PLD-H 08-04-00**      **ID 598 905-xx**

**PLD-H 04-08-00**      **ID 727 219-xx**



**PLA-H xx-xx-xx**

Analog I/O module:

**■ PLA-H 04-00-04:**

Analog module with 4 analog inputs  $\pm 10$  V, 0 analog outputs and 4 inputs for Pt 100 thermistors.

**■ PLA-H 08-04-04:**

Analog module with 8 analog inputs  $\pm 10$  V, 4 analog outputs  $\pm 10$  V and 4 inputs for Pt 100 thermistors.

**PLA-H 04-00-04      ID 599 070-xx**

**PLA-H 08-04-04      ID 675 572-xx**

**Empty housing**

...for partial assembly

**ID 383 022-11**



## 2.5.6 SPI expansion modules

Expansion module for analog axes/spindles in the HSCI system

Expansion module for analog axes/spindles in the HSCI system:

■ **CMA-H 04-04-00:**

Module for controlling analog axes or spindles. The CMA-H is inserted in one of the SPI slots on the bottom of the controller units. The analog control loop outputs are accessed only via the NC. Interpolated movements of analog axes with other axes are not possible.

**CMA-H 04-04-00**

**ID 688 721-xx**



## 2.5.7 PSL 13x low-voltage power supply unit

### PSL 130

Power supply unit to supply HSCI components with +24 V.

- The power is supplied via line voltage (L1, L2) and the DC-link voltage  $U_z$ . This is used to produce the +24 V NC and +24 V PLC output voltages.
- Both output voltages are produced by two internally separated power supplies. The NC and PLC power supplies are galvanically isolated and fulfill the requirements of EN 61800-5-1 for "low voltage electrical separation."
- Output voltages must be grounded according to EN 60204-1:2006 "protective extra-low voltage (PELV)" (see Grounding Diagram).
- The two output voltages can be connected in parallel. This way the PSL 130 provides an output voltage of +24 V at a maximum output power of 750 W.

Please observe the information and regulations for the power connection cited under "PSL 13x low-voltage power supply unit" on page 189 and in the "Inverter Systems and Motors" Technical Manual.

**ID 575 047-xx**



## PSL 135

Power supply unit for supplying the HSCI components for use of a non-HEIDENHAIN inverter system.

- The power is supplied via line voltage (L1, L2) and the DC-link voltage  $U_2$ . This is used to produce the +24 V NC, +24 V PLC and +5 V output voltages.
- +24 V NC and +24 V PLC are produced by two internally separated power supplies. The NC and PLC power supplies are galvanically isolated and fulfill the requirements of EN 61800-5-1 for "low voltage electrical separation."
- Output voltages must be grounded according to EN 60204-1:2006 "protective extra-low voltage (PELV)" (see Grounding Diagram).
- +24 V NC and +24 V PLC can be connected in parallel. This way the PSL 135 provides an output voltage of +24 V at a maximum output power of 750 W.

Please observe the information and regulations for the power connection cited under "PSL 13x low-voltage power supply unit" on page 189 and in the "Inverter Systems and Motors" Technical Manual.

**ID 627 032-xx**



## 2.5.8 MB 620T machine operating panel

### MB 620T

The MB 620T is equipped with:

- HSCI interface
- Handwheel connection, X23
- Spindle-speed and feed-rate override potentiometer
- Snap-on (exchangeable) keys, see "Key symbols" on page 101. The key functions are freely definable via the PLC
- 8 PLC inputs and 8 PLC outputs
- Two bore holes for additional keys or keylock switches

Controls and displays:

- 9 axis keys
- 17 function keys
- NC start
- NC stop
- Feed rate stop
- Spindle stop
- EMERGENCY STOP button
- Control voltage On<sup>1</sup>

<sup>1)</sup> Key is illuminated



**ID 737 610-xx**


## 2.5.9 HSCI adapter for PLB 6001 OEM-specific machine operating panel

### PLB 6001

The PLB 6001 is equipped with:

- HSCI interface
- Handwheel connection, X23
- 64 PLC inputs, 32 PLC outputs for keys / key illumination
- Connection for spindle-speed and feed-rate override potentiometer
- Screw fastening or top-hat-rail mounting
- Weight: 1.2 kg

**ID 668 792-xx**



## 2.5.10 Handwheels

All handwheels are available with and without detent. For handwheels with detent, the cogging torque prevents movements of the handwheel due to motions or vibrations of the machine. On handwheels without detent, this is prevented by a defined holding torque.

Handwheels with detent feature 100 detent positions per revolution, i.e. every 3.6°. The machine manufacturer defines the increment via the machine configuration.

### HR 410 handwheel

Portable electronic handwheel with snap-on (exchangeable) keys, (see "Key symbols" on page 101).

- Five axis selection keys
- Keys for traverse direction
- Keys for preset feeds
- Actual-position-capture key
- Three keys for machine functions (definable via PLC)
  - Spindle right/left/stop
  - NC start/stop, spindle start; (for HEIDENHAIN PLC basic program)
- Two permissive buttons (24 V)
- Emergency stop button (24 V)
- Magnetic holding pads

The handwheel is available with or without detent.

See the following table for the possible handwheel assignments.

- ID 312 879-01 Connecting cable to cable adapter (spiral cable 3 m)
- ID 296 467-xx Connecting cable to cable adapter (normal cable)
- ID 296 687-xx Connecting cable to cable adapter (with metal armor)
- ID 296 466-xx Adapter cable to control
- ID 281 429-xx Extension to adapter cable
- ID 271 958-03 Dummy plug for emergency stop circuit



Key assignments **HR 410** handwheel \*):

Without detent:  
**ID 296 469-55**

Without detent:  
**ID 296 469-54**

Without detent:  
**ID 296 469-53**




With detent:  
**ID 535 220-05**

With detent:  
**ID 535 220-03**

(for PLC basic program)

(special assignment)

(standard)



\*) For a list of the keys available for exchanging, see "Key symbols" on page 101.

### HR 130 handwheel

Panel-mounted handwheel

ID 540 940-01HR 130 handwheel **with** detent, with ergonomic control knob, radial cable outlet

ID 540 940-03HR 130 handwheel **without** detent, with ergonomic control knob, radial cable outlet



**HR 180 panel-mounted handwheel** for connection to a position input.

ID 540 940-08 Handwheel with mechanical detent (100 stops per handwheel revolution), with ergonomic knob.

Output signal: 1 V<sub>PP</sub>



### HRA 110 handwheel adapter

For connecting up to three **HR 150** handwheels to the control.  
The axes and the subdivision factor are selected via selection switch.

ID 261 097-03

HRA 110

ID 540 940-06

HR 150 handwheel  
**without** detent, with  
ergonomic knob, radial  
cable outlet

ID 540 940-07

HR 150 handwheel  
**with** detent, with  
ergonomic knob, radial  
cable outlet

ID 270 908-xx








Handwheel selection  
switch















## 2.5.11 Key symbols























### Key symbols for the spindle

Key	Description Print/Background ID	Key	Description Print/Background ID
	Spindle stop White/Red 330 816-08		Spindle start White/Green 330 816-09
	Spindle direction left Black/Gray 330 816-40		Spindle direction right Black/Gray 330 816-41
	Spindle stop White/Red 330 816-47		Spindle start White/Green 330 816-46
	Clamp the spindle Black/Gray 330 816-48		

### Key symbols with axis designations

Key	Description Print/Background ID	Key	Description Print/Background ID
	X Black/Orange 330 816-24		Y Black/Orange 330 816-36
	Z Black/Orange 330 816-25		A Black/Orange 330 816-42
	B Black/Orange 330 816-26		C Black/Orange 330 816-23
	U Black/Orange 330 816-43		V Black/Orange 330 816-38
	W Black/Orange 330 816-45		IV Black/Orange 330 816-37

**Axis direction keys  
for the  
principal axes**



























Key	Description Print/Background ID	Key	Description Print/Background ID
	X- Black/Gray 330 816-63		X+ Black/Gray 330 816-64
	X- <- Black/Gray 330 816-18		X+ -> Black/Gray 330 816-17
	X' -> Black/Gray 330 816-0W		X' + <- Black/Gray 330 816-0V
	X- <-> Black/Gray 330 816-0N		X+ <-> Black/Gray 330 816-0M
	Y- Black/Gray 330 816-67		Y+ Black/Gray 330 816-68
	Y' -> Black/Gray 330 816-21		Y' + <- Black/Gray 330 816-20
	Y- <-> Black/Gray 330 816-0P		Y+ <-> Black/Gray 330 816-0R
	Y- -> Black/Gray 330 816-0D		Y+ <- Black/Gray 330 816-0E
	Z- Black/Gray 330 816-65		Z+ Black/Gray 330 816-66
	Z- <- Black/Gray 330 816-19		Z+ -> Black/Gray 330 816-16
	Z' -> Black/Gray 330 816-0L		Z' + <- Black/Gray 330 816-0K

**Key symbols for axis direction keys for rotary and additional linear axes**


















Key	Description Print/Background ID	Key	Description Print/Background ID
<b>A-</b>	A- Black/Gray 330 816-95	<b>A+</b>	A+ Black/Gray 330 816-96
<b>B-</b>	B- Black/Gray 330 816-97	<b>B+</b>	B+ Black/Gray 330 816-98
<b>C-</b>	C- Black/Gray 330 816-99	<b>C+</b>	C+ Black/Gray 330 816-0A
<b>U-</b>	U- Black/Gray 330 816-0B	<b>U+</b>	U+ Black/Gray 330 816-0C
<b>V-</b>	V- Black/Gray 330 816-70	<b>V+</b>	V+ Black/Gray 330 816-69
<b>W-</b>	W- Black/Gray 330 816-0G	<b>W+</b>	W+ Black/Gray 330 816-0H
<b>IV-</b>	IV- Black/Gray 330 816-71	<b>IV+</b>	IV+ Black/Gray 330 816-72



## Key symbols for machine functions

Key	Description Print/Background ID	Key	Description Print/Background ID
	Special function Black/Gray 330 816-0X		Function A White/Black 330 816-30
	Function B White/Black 330 816-31		Function C White/Black 330 816-32
	Function 1 Black/Gray 330 816-73		Function 2 Black/Gray 330 816-74
	Function 3 Black/Gray 330 816-75		Function 4 Black/Gray 330 816-76
	Function 5 Black/Gray 330 816-77		Unlock door Black/Gray 330 816-78
	Unlock door Black/Gray 330 816-79		Coolant Black/Gray 330 816-80
	Coolant (internal) Black/Gray 330 816-0S		Coolant (external) Black/Gray 330 816-0T
	Rinse water jet Black/Gray 330 816-81		Spotlight Black/Gray 330 816-82
	Chip removal Black/Gray 330 816-83		Chip conveyor Black/Gray 330 816-84
	Tool change Black/Gray 330 816-89		Tool changer left Black/Gray 330 816-85
	Tool changer right Black/Gray 330 816-86		Unclamp tool Black/Gray 330 816-87
	Unclamp tool Black/Gray 330 816-88		Clamp tool Black/Gray 330 816-94
	Clamp tool Black/Gray 330 816-0U		Retract axis Black/Gray 330 816-91

## Other key symbols

Key	Description Print/Background ID	Key	Description Print/Background ID
	No symbol -/Black 330 816-01		No symbol -/Gray 330 816-61
	NC start White/Green 330 816-11		NC stop White/Red 330 816-12
	NC start White/Green 330 816-49		NC stop White/Red 330 816-50
	Feed rate 1 Black/Gray 330 816-33		Feed rate 2 Black/Gray 330 816-34
	Rapid traverse Black/Gray 330 816-35		Permissive button White/Green 330 816-22
	Permissive button Black/Gray 330 816-90		Actual position capture White/Black 330 816-27
	- White/Black 330 816-28		+ White/Black 330 816-29
	Menu selection -> Black/Gray 330 816-92		Menu selection <- Black/Gray 330 816-93
	0 Black/Gray 330 816-0Y		

## 2.5.12 Touch probes

Touch probes for workpiece measurement are connected via the system PL 62xx or the UEC 11x. The touch probes generate a trigger signal that captures the current position value. For more information about touch probes, please request the "Touch Probes" brochure or CD-ROM from HEIDENHAIN.

### Workpiece measurement

The TS touch trigger probe has a stylus with which it probes workpieces. The MANUALplus 620 provides standard routines for workpiece measurement (software option 17 required). The touch probes are available with various taper shanks. Assorted styli are available as accessories.

#### TS 220 touch probe

Triggering touch probe with signal transmission over cable connection for machines with manual tool change. For workpiece setup and measurement during machining.

ID 293 488-xx

TS 220

ID 633 613-xx

Adapter cable for connection to the system PL or the UEC



**TS 740, TS 640, TS 444, TS 440** touch probes

Triggering touch probe with infrared transmission, for workpiece setup and measurement during machining. For machines with automatic tool changer.

- TS 440 with compact dimensions
- TS 444 with alternative battery-free power supply via compressed air through the spindle head
- TS 640 with wide-range infrared transmission and long operating time
- TS 740 with high probing accuracy and repeatability, and low probing forces

The infrared transmission is established between the TS touch probe and the SE transceiver unit. The following SE units can be combined with the TS touch probes:

- SE 640 for integration in the machine workspace
- SE 540 for integration in the spindle head

ID 573 757-xx	TS 740
ID 620 189-xx	TS 640
ID 620 046-xx	TS 440
ID 588 008-xx	TS 444

ID 631 225-xx SE 640 transmitter-receiver unit

ID 626 001-xx SE 540 transmitter-receiver unit



TS 640, TS 740



TS 440, TS 444



SE 640



SE 540

## Tool measurement

### TT 140 tool touch probe

Touch trigger probe with rated break point of the connection pin for the probe head and optical deflection display. An additional connection pin is delivered with the touch probe.

ID 527 797-03

TT 140

ID 676 497-01

Cuboid probe contact

Connection pin

ID 559 758-01

ID 633 616-xx

Adapter cable for  
connection to the  
system PL or the UEC





## 2.5.13 Other accessories

Further components	ID
<b>Adapters for encoder signals</b>	
TTL (HEIDENHAIN layout)/1 V <sub>PP</sub>	317 505-01
TTL (SIEMENS layout)/1 V <sub>PP</sub>	317 505-02

### CML 110 capacitor module for 24 V power supply

#### Specifications

- Supply voltage: 24 V
- Capacitance: 8.3 F
- Max. charging current: 2.4 A
- Internal resistance (discharge)
  - Maximum: 156 milliohm
  - Typically: 65 milliohm
- Discharge current: 30 A

**ID 574 087-02**

**CML 110**



## 2.5.14 Documentation

You will receive a set of supplementary pages every time changes are made to this manual.

The features of the control are described in the following manuals:

- **MANUALplus 620 User's Manual** (ID 634 864-xx)
- **MANUALplus 620 / CNC PILOT 620 smart.Turn and DIN Programming User's Manual** (ID 685 556-xx)

The HEIDENHAIN inverters and motors are described in the

- **Technical Manual for Inverters and Motors** (ID 208 962-xx)

The **DataPilot MP/CP 620** is the new programming station for the MANUALplus 620 and CNC PILOT 620 lathe controls.

- **DataPilot MP/CP 620** CD-ROM
  - Demo software (ID 737 139-xx)
  - Single-station license (ID 737 157-xx)
  - Network license for 14 training stations (ID 737 158-xx)
  - Network license for 20 training stations (ID 737 159-xx)

### Other Documentation

Available in the form of brochures:

- **MANUALplus 620** brochure (ID 634 865-xx)
- **MANUALplus 620 OEM** brochure (ID 634 867-xx)
- **Touch Probes** brochure (ID 208 951-xx)
- **Inverter Systems** brochure (ID 622 420-xx)
- **Motors** brochure (ID 208 893-xx)
- **Remote Diagnosis with TeleService** product overview (ID 348 236-xx)
- **Touch Probes** CD-ROM (ID 344 353-xx)



## 2.6 Brief Description

### 2.6.1 Specifications for MANUALplus 620

Specifications	MANUALplus 620
<b>MC 6110T</b>	<p>Compact contouring control with integrated main computer, TFT color flat-panel display and operating keys</p> <ul style="list-style-type: none"> <li>■ Intel Celeron M 1.0 GHz processor</li> <li>■ 1 GB SDRAM main memory</li> <li>■ Bus frequency 400 MHz</li> <li>■ HSCI interface</li> <li>■ Three USB interfaces</li> <li>■ Unique identification of MC 6110T through SIK (System Identification Key)</li> </ul>
<b>CC 61xx</b>	<p>All position and speed encoder inputs 1 V<sub>PP</sub> or EnDat</p> <ul style="list-style-type: none"> <li>■ HSCI interface</li> <li>■ Max. 6, 8 or 10 digital control loops</li> <li>■ 6, 8 or 10 position and 6, 8 or 10 speed encoder inputs with 1 V<sub>PP</sub> or EnDat 2.2 for axes and spindle (EnDat 2.2 is backward-compatible to EnDat 2.1)</li> <li>■ 6, 8 or 10 PWM outputs</li> <li>■ Power supply via UV(R), UE or UR power supply unit</li> </ul>
<b>UEC 11x</b>	<p>Controller unit with integrated inverter and PLC, for machines with low power demands</p> <ul style="list-style-type: none"> <li>■ HSCI interface</li> <li>■ Controller unit with position, speed and current controller</li> <li>■ UEC 111: Up to 4 digital control loops, connection for 3 axes plus spindle</li> <li>■ UEC 112: Up to 5 digital control loops, connection for 4 axes plus spindle</li> <li>■ Integrated braking resistor</li> <li>■ 38 PLC inputs, 23 PLC outputs (expandable via PL 61xx)</li> <li>■ Interfaces to the speed encoders</li> <li>■ Interfaces to the position encoders</li> <li>■ Interfaces for one TS and TT touch probe each</li> <li>■ +24 V NC power supply with 2.5 A for MC and other control components</li> </ul>
<b>Axis feedback control</b>	<p>Velocity feedforward control / Operation with following error / Jerk limiting</p> <p>Connection of the CC controller unit via HSCI</p> <p>Cycle time for path interpolation</p> <p>3 ms</p>

<b>Specifications</b>		<b>MANUALplus 620</b>
Options		Software options can be enabled by entering a code number.
Display		12.1-inch TFT color flat-panel display (integrated)
Program memory		250 MB on CFR memory card
<b>Input resolution and display step</b>		
Linear axes	X axis: 0.5 $\mu\text{m}$ (diameter: 1 $\mu\text{m}$ ) Z, Y, U, V, W axis: 1 $\mu\text{m}$	
C axis	0.001°	
<b>Block processing time</b>		
		3 ms
<b>Interpolation</b>		
Linear	In 2 axes (max. $\pm 100$ m), optional in 3 principal axes	
Circle	In 2 axes (radius max. 999 m), optional additional linear interpolation in the third axis	
C1/C2 axis	Interpolation of X and Z linear axes with the C1/C2 axis (option)	
Helix	Superimpositioning of circular and straight paths	
Look-ahead	Precalculation of up to 5000 blocks for determining the contouring velocity profile	

Specifications	MANUALplus 620
<b>Feedback control with CC 6xxx / UEC 1xx</b>	
Position loop resolution	$\frac{\text{Signal period of position encoder}}{4096}$ or encoder resolution (EnDat 2.2 interpol.)
Path interpolation	3 ms
Cycle time of current controller	PWM frequency      Cycle time: 3333 Hz                  150 $\mu$ s 4000 Hz                  125 $\mu$ s 5000 Hz                  100 $\mu$ s
Cycle time of speed controller	Speed controller cycle time = 2 · current controller cycle time
Cycle time of position controller	= Cycle time of speed controller
Feed rate	Maximum feed rate: $\frac{60000 \text{ 1/min}}{\text{No. of pole pairs}} \cdot \text{Screw pitch in mm}$ at $f_{\text{PWM}} = 5000 \text{ Hz}$ <ul style="list-style-type: none"> <li>■ Up to approx. 32.4 m/min (27 kHz) or approx. 480 m/min (400 kHz) for encoders with 20 <math>\mu</math>m grating period</li> <li>■ Up to approx. 162 m/min (27 kHz) or approx. 2400 m/min (400 kHz) for encoders with 100 <math>\mu</math>m grating period</li> <li>■ mm/min or mm/revolution</li> <li>■ Constant surface speed</li> <li>■ Feed rate with chip breaking</li> </ul>
Shaft speed (spindle)	Maximum revolutions per minute: $n_{\text{max}} = \frac{f_{\text{PWM}} \cdot 60000 \text{ min}^{-1}}{p \cdot 5000 \text{ Hz}}$ <p> <math>n_{\text{max}}</math>: Maximum spindle speed [<math>\text{min}^{-1}</math>]  <math>f_{\text{PWM}}</math>: PWM frequency [Hz]  <math>p</math>: Number of pole pairs           </p> The following PWM frequencies are available: 3333 Hz, 4000 Hz, 5000 Hz

Specifications	MANUALplus 620
<b>Threads</b>	<ul style="list-style-type: none"> <li>■ Longitudinal thread</li> <li>■ Transversal thread (as DIN cycle)</li> <li>■ Tapered thread</li> <li>■ API thread</li> <li>■ Multiple thread</li> <li>■ Discontinuous threads with slanted entry and exit</li> <li>■ Variable pitch</li> <li>■ Tapping</li> <li>■ Thread milling (possible only with C axis)</li> <li>■ Thread with variable pitch</li> </ul>
<b>Error compensation</b>	<ul style="list-style-type: none"> <li>■ Linear and nonlinear axis error</li> <li>■ Backlash</li> <li>■ Hysteresis</li> <li>■ Reversal error during circular movements</li> <li>■ Thermal expansion</li> <li>■ Friction, stick-slip</li> <li>■ Friction, sliding</li> <li>■ Tool nose (cutting) radius</li> <li>■ Milling tool radius</li> </ul>
<b>Monitoring functions</b>	<ul style="list-style-type: none"> <li>■ Amplitude of encoder signals</li> <li>■ Edge separation of encoder signals</li> <li>■ Absolute position for encoders with distance-coded reference marks</li> <li>■ Following error</li> <li>■ Movement monitoring</li> <li>■ Standstill monitoring</li> <li>■ Nominal speed value</li> <li>■ Checksum of safety-related functions</li> <li>■ Power supply</li> <li>■ Buffer battery</li> <li>■ Operating temperature</li> <li>■ Running time of the PLC program</li> <li>■ Motor current</li> <li>■ Motor temperature</li> <li>■ Temperature of power stage</li> <li>■ DC-link voltage</li> </ul>



<b>Specifications</b>	<b>MANUALplus 620</b>
<b>Integrated PLC</b>	
PLC memory	50 MB on CFR memory card
Program format	Statement list (STL)
PLC main memory RAM	Dynamic, determined by the free main memory of the control
PLC cycle time	9 ms to 30 ms (adjustable)
PLC inputs, 24 V–	Via PL
PLC outputs, 24 V–	Via PL
Analog inputs, ± 10 V	Via PL
Analog outputs, ± 10 V	Via PL
Inputs for thermistors	Via PL

<b>Machine interfacing</b>	<b>MANUALplus 620</b>
<b>Commissioning aids</b>	<ul style="list-style-type: none"> <li>■ Oscilloscope</li> <li>■ Trace function</li> <li>■ Table function</li> <li>■ API DATA function</li> <li>■ Watchlist function</li> <li>■ Logic diagram (integrated in oscilloscope)</li> <li>■ Log</li> <li>■ OnLine monitor (OLM)</li> <li>■ TNCopt PC software</li> <li>■ TNCscoptNT recording software</li> <li>■ TeleService</li> </ul>
<b>Interfaces</b>	<ul style="list-style-type: none"> <li>■ 100BaseT Fast Ethernet interface</li> <li>■ 2 x HSCI</li> <li>■ 3 x USB 2.0</li> <li>■ RS-232-C/V.24 with max. 115 Kbps</li> <li>■ Expanded data interface with LSV-2 protocol for data exchange and external operation of the control with HEIDENHAIN software TNCremoNT</li> </ul>
<b>Permissible temperature range</b>	<p>Incoming air in panel or electrical cabinet  0 °C to 50 °C</p> <p>Temperature range outside the panel:  0 °C to 45 °C</p> <p>Storage: -20 °C to +60 °C</p>





## 2.6.2 User functions

User functions	MANUALplus 620
<b>Operating modes</b>	
Manual operation	<ul style="list-style-type: none"> <li>■ Manual slide movement through axis-direction keys, intermediate switch or electronic handwheels</li> <li>■ Graphic support for entering and running cycles without saving the machining steps in alternation with manual machine operation</li> <li>■ Thread repair (thread reworking in a second workpiece setup)</li> </ul>
Teach-in mode	<ul style="list-style-type: none"> <li>■ Sequential linking of fixed cycles, where each cycle is run immediately after input or is graphically simulated and subsequently saved.</li> </ul>
Program run	<ul style="list-style-type: none"> <li>■ Cycle programs, DIN PLUS or smart.Turn programs in single block or full sequence</li> </ul>
Setup functions	<ul style="list-style-type: none"> <li>■ Workpiece datum setting</li> <li>■ Definition of tool-change position</li> <li>■ Definition of protection zone</li> <li>■ Definition of machine dimensions</li> <li>■ Manual programs</li> <li>■ Tool measurement—alternatively:               <ul style="list-style-type: none"> <li>• By touch-off</li> <li>• With a touch probe (<b>Option 17</b>)</li> <li>• With measuring optics (<b>Option 17</b>)</li> </ul> </li> <li>■ Automatic workpiece measurement with the TS workpiece touch probe (<b>Option 17</b>)</li> </ul>

User functions	MANUALplus 620
<b>Programming</b>	
Cycle programming	<ul style="list-style-type: none"> <li>■ Turning cycles for simple and complex contours, as well as contours described with Interactive Contour Programming (ICP)</li> <li>■ Contour-parallel turning cycles</li> <li>■ Recessing cycles for simple and complex contours, as well as contours described with ICP</li> <li>■ Repetitions with recessing cycles</li> <li>■ Recess turning cycles for simple and complex contours, as well as contours described with ICP</li> <li>■ Undercut and parting cycles</li> <li>■ Threading cycles for single or multi-start longitudinal, taper or API threads, threads with variable pitch</li> <li>■ Cycles for axial and radial drilling, pecking and tapping operations with the C axis</li> <li>■ Thread milling with the C axis</li> <li>■ Axial and radial milling cycles for slots, figures, single surfaces and polygons as well as for complex contours defined with ICP for machining with the C axis</li> <li>■ Helical slot milling (multi-start) with the C axis</li> <li>■ Linear and circular patterns for drilling and milling operations with the C axis</li> <li>■ Use of DIN macros in cycle programs</li> <li>■ Transfer of cutting values from technology database</li> <li>■ Context-sensitive help graphics</li> <li>■ Conversion of cycle programs to smart.Turn programs</li> </ul>
Interactive contour programming(ICP)	<ul style="list-style-type: none"> <li>■ Contour definition with linear and circular contour elements</li> <li>■ Immediate display of entered contour elements</li> <li>■ Calculation of missing coordinates, intersections, etc.</li> <li>■ Graphic display of all solutions for selection by the user if more than one solution is possible</li> <li>■ Chamfers, rounding arcs and undercuts available as form elements</li> <li>■ Input of form elements immediately during contour creation or by superimposition later</li> <li>■ Changes to existing contours can be programmed</li> <li>■ Machining attributes available for individual contour elements</li> </ul>

User functions	MANUALplus 620
Subfunction of the ICP	<p>C-axis machining on face and lateral surface:</p> <ul style="list-style-type: none"> <li>■ Description of individual holes and hole patterns (only with smart.Turn)</li> <li>■ Description of figures and figure patterns for milling operations (only with smart.Turn)</li> <li>■ Creation of freely definable milling contours</li> </ul> <p>Y-axis machining (option 70) in the XY and ZY planes (only with smart.Turn):</p> <ul style="list-style-type: none"> <li>■ Description of individual holes and hole patterns</li> <li>■ Description of figures and figure patterns for milling operations</li> <li>■ Creation of freely definable milling contours</li> </ul> <p>Programming of the rear face for full-surface machining with the C and Y axes</p> <p>DXF import (Option 42): Import of contours for lathe and milling operations</p>
smart.Turn programming	<ul style="list-style-type: none"> <li>■ Program blocks (UNITS) for the complete description of a machining block (geometry, technology and cycle data)</li> <li>■ Dialog boxes divided into overview and detail forms</li> <li>■ Fast navigation between the fillable forms and input groups via the "smart" keys</li> <li>■ Context-sensitive help graphics</li> <li>■ Start unit with global settings</li> <li>■ Transfer of global values from the start unit</li> <li>■ Transfer of cutting values from technology database</li> <li>■ Units for all turning and recessing operations for simple contours and ICP contours</li> <li>■ Units for boring, drilling and milling operations with the C and Y axes for simple holes, milling contours and drilling and milling patterns or those programmed with ICP</li> <li>■ Special units for subroutines, section repeats and activating/deactivating the C axis</li> <li>■ Verification graphics for blank and finished part and for C and Y axis contours</li> <li>■ Turret assignment and other setup information in the smart.Turn program</li> <li>■ Parallel programming</li> <li>■ Parallel simulation</li> </ul>

User functions	MANUALplus 620
DIN PLUS programming	<ul style="list-style-type: none"> <li>■ NC programming as per DIN 66025 (ISO 6983)</li> <li>■ Extended command format (IF...THEN...ELSE...)</li> <li>■ Simple geometry programming (calculation of missing data)</li> <li>■ Powerful fixed cycles for turning, recessing, recess turning and thread machining</li> <li>■ Powerful fixed cycles for boring, drilling and milling with the C axis</li> <li>■ Powerful fixed cycles for drilling and milling with the Y axis (option 70)</li> <li>■ Subroutines</li> <li>■ Technology functions for full-surface machining: <ul style="list-style-type: none"> <li>- Traversing to a fixed stop</li> <li>- Parting control</li> <li>- Spindle synchronization</li> <li>- Mirroring and converting</li> <li>- Mechatronic tailstock</li> </ul> </li> <li>■ Programming with variables</li> <li>■ Contour description with ICP</li> <li>■ Program verification graphics for workpiece blank and finished part</li> <li>■ Turret assignment and other setup information in the DIN PLUS program</li> <li>■ Conversion of smart.Turn units into DIN PLUS command sequences</li> <li>■ Parallel programming</li> <li>■ Parallel simulation</li> </ul>
<b>Program verification graphics</b>	<p>Graphic simulation of cycle execution for cycle programs, smart.Turn or DIN PLUS programs:</p> <ul style="list-style-type: none"> <li>■ Display of the tool paths as wire-frame or cutting-path graphics, special identification of the rapid-traverse paths</li> <li>■ Machining simulation (2-D material-removal graphic)</li> <li>■ Side or face view, or 2-D view of cylindrical surface for verification of Caxis machining</li> <li>■ Display of programmed contours</li> <li>■ View of face and YZ plane for verification of Y-axis machining</li> <li>■ Workpiece blank definition</li> <li>■ Three-dimensional graphic display of the workpiece blank and finished part</li> <li>■ Shifting and magnifying functions</li> </ul>
<b>Machining time analysis</b>	<ul style="list-style-type: none"> <li>■ Calculation of machining time and idle machine time</li> <li>■ Consideration of switching commands triggered by the CNC</li> <li>■ Individual times per cycle or tool change</li> </ul>

User functions	MANUALplus 620
<b>Tool database</b>	<ul style="list-style-type: none"> <li>■ Database for 250 tools with tool description</li> <li>■ <b>Option 10:</b> 999 tools</li> <li>■ Tool description can be entered for every tool</li> <li>■ Automatic checking of tool-tip position with respect to the contour</li> <li>■ Compensation of tool-tip position in the X/Y/Z plane</li> <li>■ High-precision correction via handwheel, capturing compensation values in the tool table</li> <li>■ Automatic tool-tip and cutter radius compensation</li> <li>■ Management of multipoint tools (multiple inserts on one tool holder)</li> <li>■ Tool monitoring after rated life of insert or number of workpieces</li> <li>■ <b>Option 10:</b> Tool monitoring with automatic tool change after tool insert wear</li> </ul>
<b>Tool compensation</b>	<ul style="list-style-type: none"> <li>■ Compensation of tool-tip position in the X/Y/Z plane</li> <li>■ Automatic tool point position detection (left, right, inward, outward)</li> <li>■ High-precision adjustment via handwheel, capturing compensation values in the tool table</li> <li>■ Automatic tool-tip and cutter radius compensation</li> </ul>
<b>Technology database</b>	<ul style="list-style-type: none"> <li>■ Access to cutting data after definition of workpiece material, cutting material and machining mode (reduced number of database entries). The MANUALplus 620 distinguishes between 16 machining modes. Each workpiece-material/tool-material combination includes the cutting speed, the main and secondary feed rates, and the infeed for 16 machining modes.</li> <li>■ Automatic determination of the machining modes from the cycle or the machining unit</li> <li>■ Cutting data is entered in the cycle or in the unit as default values</li> <li>■ 9 workpiece-material/tool-material combinations (144 entries)</li> <li>■ <b>Option 10:</b> 62 workpiece-material/tool-material combinations (992 entries)</li> </ul>
Conversational languages	<p>Chinese (simplified), Chinese (traditional), Czech, Danish, Dutch, English, Finnish, French, German, Hungarian, Italian, Polish, Portuguese, Russian, Spanish, Swedish</p> <p><b>Only with Option 41</b> (ID 530 184-xx): Estonian, Korean, Latvian, Lithuanian, Norwegian, Romanian, Slovak, Slovenian, Turkish</p>

### 2.6.3 Software options

Option number	Option	ID	Comment
<b>0</b>	Additional axis	354 540-01	<b>Additional control loops 1 to 7</b>
<b>1</b>		353 904-01	
<b>2</b>		353 905-01	
<b>3</b>		367 867-01	
<b>4</b>		367 868-01	
<b>5</b>		370 291-01	
<b>6</b>		370 292-01	
<b>8</b>	Software option 1 Teach-in	632 226-01	<b>Cycle programming</b> <ul style="list-style-type: none"> <li>■ Contour description with ICP</li> <li>■ Cycle programming</li> <li>■ Technology database with 9 workpiece-material/ tool-material combinations</li> </ul>
<b>9</b>	Software option 2 smart.Turn	632 227-01	<b>smart.Turn</b> <ul style="list-style-type: none"> <li>■ Contour description with ICP</li> <li>■ Programming with smart.Turn</li> <li>■ Technology database with 9 workpiece-material/ tool-material combinations</li> </ul>
<b>10</b>	Software option 3 Tools and technology	632 228-01	<b>Tools and technology</b> <ul style="list-style-type: none"> <li>■ Tool database expanded to 999 entries</li> <li>■ Technology database expanded to 62 workpiece- material/tool-material combinations</li> <li>■ Tool life monitoring with exchange tools</li> </ul>
<b>11</b>	Software option 4 Thread recutting	632 229-01	<b>Threads</b> <ul style="list-style-type: none"> <li>■ Thread recutting</li> <li>■ Handwheel superimposition during thread cutting</li> </ul>
<b>17</b>	Touch probe functions	632 230-01	<b>Tool and workpiece measurement</b> <ul style="list-style-type: none"> <li>■ Determining tool-setting dimensions with a TT tool touch probe</li> <li>■ Determining tool-setting dimensions with an optical gauge</li> <li>■ Measuring workpieces automatically with a TS workpiece touch probe</li> </ul>
<b>24</b>	Gantry axes	634 621-xx	<b>Gantry axes in master-slave torque control</b>



Option number	Option	ID	Comment
41	Additional Language	530 184-xx	<b>Additional conversational language</b> <ul style="list-style-type: none"> <li>■ Estonian, Korean, Latvian, Norwegian, Romanian, Slovak, Slovenian, Turkish, Lithuanian</li> </ul>
42	DXF import	632 231-01	<b>DXF import</b> <ul style="list-style-type: none"> <li>■ Loading of DXF contours</li> </ul>
55	C-axis machining	633 944-01	<b>C-axis machining</b>
70	Y-axis machining	661 881-01	<b>Y-axis machining</b>
94	Parallel axes	679 676-01	<b>Support of parallel axes (U, V, W)</b> Combined display of principal axes and secondary axes
131	Spindle synchronism	806 270-01	<b>Spindle synchronization</b> (of two or more spindles)
132	Opposing spindle	806 275-01	<b>Opposing spindle</b> (spindle synchronization, rear-face machining)

## 2.6.4 Accessories

Accessories	MANUALplus 620
<b>PL 6xxx PLC input/output systems with HSCI</b>	Up to eight PL 6xxx can be connected
	<ul style="list-style-type: none"> <li>■ PL 620x (system PL)               <ul style="list-style-type: none"> <li>• Necessary once for each control system (except with UEC)</li> <li>• Has connections for TS and TT touch probes</li> <li>• Safety-relevant inputs/outputs</li> <li>• Available for 4, 6 or 8 I/O modules</li> </ul> </li> <li>■ PL 610x (expansion PL)               <ul style="list-style-type: none"> <li>• As addition to the system PL for increasing the number of PLC inputs/outputs</li> <li>• Available for 4, 6 or 8 I/O modules</li> </ul> </li> <li>■ I/O modules               <ul style="list-style-type: none"> <li>• PLD-H 16-08-00 I/O module with 16 digital inputs and 8 digital outputs</li> <li>• PLD-H 04-00-04 I/O module with 4 analog inputs for PT 100 thermistors and 4 analog inputs for <math>\pm 10</math> V</li> <li>• PLD-H 00-12-00 I/O module with 12 analog outputs for <math>\pm 10</math> V</li> </ul> </li> </ul>

Accessories	MANUALplus 620
<b>Power supply for HSCI components</b>	<ul style="list-style-type: none"> <li>■ PSL 13x 24 V power supply unit for supplying the HSCI components. <ul style="list-style-type: none"> <li>• Outputs: <ul style="list-style-type: none"> <li>NC: 24 V– (double insulation)</li> <li>PLC: 24 V– (basic insulation)</li> <li>Per output: max. 21 A/ 500 W</li> <li>Total: Max. 32 A / 750 W</li> </ul> </li> <li>• Outputs can be connected in parallel</li> </ul> </li> </ul>
<b>Electronic handwheels</b>	<ul style="list-style-type: none"> <li>■ One <b>HR 130</b> panel-mounted handwheel or an <b>HR 410</b> portable handwheel at the X23 serial input.</li> <li>■ Up to three <b>HR 150</b> at the X23 serial input via <b>HRA 110</b>.</li> <li>■ <b>HR 180</b> panel-mounted handwheels at position inputs. The number is limited by the number of vacant position inputs. You can additionally connect an HR 410 serial handwheel, an HR 130 or up to three HR150 (via HRA 110) to X23.</li> </ul>
<b>Workpiece touch probe</b>	<ul style="list-style-type: none"> <li>■ <b>TS 220</b> 3-D touch trigger probe with cable connection or</li> <li>■ <b>TS 440, TS 444, TS 640 and TS 740</b> triggering 3-D touch probe with infrared transmission</li> </ul>
<b>Tool touch probe</b>	<ul style="list-style-type: none"> <li>■ <b>TT 140</b> with a cuboid probe contact</li> </ul>
<b>Software</b>	<ul style="list-style-type: none"> <li>■ <b>PLCdesignNT<sup>a</sup></b> PLC software developing environment</li> <li>■ <b>IOconfig<sup>a</sup></b> Software for configuring PLC I/O and PROFIBUS-DP components</li> <li>■ <b>TNCremoNT</b> Data transfer software</li> <li>■ <b>TNCremoPlus</b> Data transfer software with "live" screen</li> <li>■ <b>TNCscopeNT<sup>a</sup></b> Software for recording data online or evaluating oscilloscope measurement series</li> <li>■ <b>DriveDiag<sup>a</sup></b> Software for diagnosis of digital control loops</li> <li>■ <b>TNCopt<sup>a</sup></b> Software for putting digital control loops into service</li> <li>■ <b>KinematicsDesign<sup>a</sup></b> Software for configuring the machine kinematics</li> <li>■ <b>TeleService</b> Software for remote diagnostics, monitoring, and operation</li> </ul>

a. Registered customers can download these software products from the Internet.






## 2.7 Software

### 2.7.1 Designation of the software


The control features a separate software for the NC and the PLC. The NC software is identified with an eight-digit number.

To show the software version:

- ▶ Switch to the **Organization** mode of operation.



- ▶ Press the soft key. The MANUALplus 620 shows the control model and the versions of the NC and PLC software. An installed service pack is shown by **SPx** after the ID number of the NC software.



#### Type

The MANUALplus 620 is approved for export to all countries. No export license is required for the NC software of the control.

HEIDENHAIN may release a new NC software type when it introduces extensive new functions.

### 2.7.2 PLC software

The PLC software is on the hard disk of the MANUALplus 620. HEIDENHAIN offers a PLC basic program you can order directly from HEIDENHAIN or, as a registered HEIDENHAIN customer, download from the FileBase on the Internet. With the **PLCdesignNT** PLC software development environment, the PLC basic program can very easily be adapted to the requirements of the machine.

### 2.7.3 Additional control loops or software options

For each MC 6110T, only the minimum number of control loops is enabled. The MANUALplus 620 is offered as a basic version with two controlled axes and a controlled spindle. Seven more control loops can be added as an option. Software options can be used to adapt the scope of functions of the NC software to the respective needs and applications, see "Software options" on page 122.

If you need additional control loops, you must enable them by entering a code number in the SIK.

If you wish to enable an additional axis or software options, please contact HEIDENHAIN for the code number. HEIDENHAIN can give you the code number after you state your SIK number. The following additional control loops can be enabled:

Control loop	On the basic version with 3 control loops, this corresponds to	ID
1st additional axis	4th control loop	354 540-01
2nd additional axis	5th control loop	353 904-01
3rd additional axis	6th control loop	353 905-01
4th additional axis	7th control loop	367 867-01
5th additional axis	8th control loop	367 868-01
6th additional axis	9th control loop	370 291-01
7th additional axis	10th control loop	370 292-01

The definition as to whether a control loop is used and counted in the SIK is made in the machine parameters **MP\_axisMode** and **MP\_axisHw**.



Note

#### Rule of thumb:

If an axis or spindle is moved by the control by setting a nominal value, the respective axis or spindle must be enabled in the SIK.

If an axis is only moved manually (e.g. through mechanical handwheels) and is only displayed, a control loop does not need to be enabled for the respective axis in the SIK.

If an axis or spindle is only controlled in encoded form via PLC outputs (**MP\_axisMode = PlcControlled**), a control loop does not need to be enabled for the respective axis or spindle.



### Note

- A control loop may also be necessary for axes in test mode (**MP\_testMode = TRUE**), depending on the configuration of **MP\_axisMode** and **MP\_axisHw** (see table below).
- A control loop must be enabled for every axis of a central drive group if **MP\_axisMode = Active** is set for the axes. In this context, please note the following information on the "alternating" use of axis options with the PLC modules 9226 and 9418.
- For gantry axes and master-slave-torque control, all axes involved must be enabled in the SIK.

Setting in MP_axisHw (300104)	Setting in MP_axisMode (300105)	Control loop enabling in SIK required?	
		Yes	No
InOutCC AnalogMC AnalogCC Profinet	Active	X	
DisplayMC DisplayCC ManualMC ManualCC	Active		X
InOutCC AnalogMC AnalogCC DisplayMC DisplayCC ManualMC ManualCC Profinet	NotActive PlcControlled		X



If an axis is deactivated with Module 9226 or 9418 (see "Writing axis information—activating and deactivating axes" on page 678), the deactivated axis does not need to be enabled in the SIK. If the axes are reactivated, they must be enabled in the SIK. This makes "alternating" use of axis options possible. Example:

- Ten axes are defined in the machine configuration.
  - The standard version of the MANUALplus 620 has three control loops.
  - Three axis options were bought in addition to the standard configuration.
- = Six control loops may be active at the same time

Use Modules 9226 (for axes) and 9418 (for the spindle) to define which control loops are to be active at the current point in time.

If more axes are activated than enabled in the SIK, the control issues an error message.

An NCK-based control currently supports up to 20 axes ( $MAX\_AXIS = 20$ ). This value cannot be changed, and represents the upper limit for all configurable axes (including the manually operated axes as well as those that are only displayed).

Every end product with NCK software also has the internal constant  $MAX\_AXIS\_PRODUCT$ , which defines the maximum number of axes of the respective product:


End product	Value of $MAX\_AXIS\_PRODUCT$
MANUALplus 620	10
Programming station	20

In the configuration file of the PLC compiler, you define the number of axes to be considered in the structure of the memory interface, see "Configuration file for the PLC compiler" on page 1509.



**SIK**  
**(system**  
**identification key)**

Every MC 6110T can be identified unambiguously by the SIK (System Identification Key). You will find the SIK number on the ID label of the SIK.




**Note**

If you replace the MC 6110T, you must also replace the SIK in order to ensure that the enabled software options will also be enabled on the new hardware.

## Enabling software options


To enable options, proceed as follows:

- ▶ Switch to the **Organization** mode of operation.



- ▶ Press the soft key.
- ▶ Enter the code number SIK and confirm your entry with the ENT key.

The following display will appear:



The display gives you the following information and possibilities for settings:

### NC Information:

Display	Meaning
<b>ID Number:</b>	Software
<b>Rev:</b>	Software version
<b>Control Type</b>	Control model
<b>Performance Class:</b>	Type of main computer
<b>Features:</b>	Characteristics of the control



### SIK Information:

Display	Meaning
Serial No. (SN):	SIK number
Control Type	Control model
Performance Class:	Type of main computer
Features	Characteristics of the SIK
SIK ok, wrong SIK (Control Type mismatch), wrong SIK (Features mismatch), wrong SIK (Performance Class mismatch), no SIK (Programming Station) or no SIK	Status of the SIK

### General Key:

The general key permits you to enable and test all new feature content level functions and software options. The general key is valid for 90 days after the first enabling. After these 90 days have expired, the general key can only be used again after the software version on your control has been updated.

Display	Meaning	
State:	NONE	General key was not used yet for this software version.
	dd.mm.yyyy	Date up to which all options will be available. It is not possible to enable them again after this date.
	EXPIRED	General key has expired for this software version. Enabling is not possible.

Press the **SET GENERAL KEY** soft key to open a window in which you press the OK soft key to enable all options for a period of **90 days**.

If this is done successfully, the **General key has been set** message appears and the expiration date of the general key is shown in the **Status** field.

Pressing the **EXPIRE GENERAL KEY** soft key opens a window in which you press the OK soft key to expire the general key immediately.

Be aware that it is then no longer possible to enable the general key for this software version!

## Feature Content Level (FCL):



### Danger

If you reduce the feature content level, then all new FCL functions and enhanced functions will be set to the desired lower version. Only error fixes remain active. This action can only be reversed by entering a valid code number again.

Display	Meaning
<b>Actual Value:</b>	Current version of the feature content level
<b>Installed Software Supports</b>	Highest possible FCL with the current software

Pressing the **SET FCL** soft key opens a window in which you can enter the code number for the desired feature content level under **Enter Key Code**. HEIDENHAIN can give you the code number after having been informed of the SIK number.

Then press the **OK** soft key to confirm your entry. If this is done successfully, the message **Feature Content Level has been set** appears.

Pressing the **REDUCE FCL** soft key opens a window in which you can enter the desired **lower** feature content level under **New (lower) FCL**.

Please note that this action can only be reversed by entering a valid code number again.

If you really want to reduce the feature content level, then press the **OK** soft key to confirm the entry. If this is done successfully, the message

**Feature Content Level has been set** appears.

### SIK Options:

All available software options and their corresponding numbers are listed in a table. The check marks in the first column indicate which software options have been enabled on your control.

To enable additional software options, proceed as follows:

- ▶ In the table on the right side of the screen, use the arrow keys or the mouse to select the software option you want to enable.
- ▶ Pressing the **SET OPTION** soft key opens a window in which you can enter the code number for the desired software option under **Enter Key Code**. HEIDENHAIN can give you the code number after having been informed of the SIK number.
- ▶ Enter the code number and confirm your entry by pressing the **OK** soft key.
- ▶ If this is done successfully, the message **Option <number> has been set** appears, and the option is checked in the table.

When you leave this table of SIK functions by pressing the **END** soft key or the **END** key, you are requested to reboot the control if you have made any changes. Press the emergency stop button and press the **Reboot Now!** button or the **REBOOT NOW** soft key to reboot the control and activate the changes.





## Temporary enabling of an option

You have the possibility of enabling software options with a temporary code number for a limited time. You can define a time between 10 to 90 days for enabling the software options. However, each option can only be enabled once with a temporary code number.

If you want to enable a software option temporarily on the control via the temporary key, proceed in the same way as for the standard enabling of software options. Press the **Set Option** button or the SET OPTION soft key. This opens a window in which you can enter the code number for the desired software option in **Enter Key Code**.

If the software option was enabled successfully, the expiration date of the temporary enabling is shown in the **Expires** column under **SIK Options**. After the defined period has expired, the entry in the **Expires** column will change to **EXP**, meaning "expired." The software option is then no longer available.

A software option can be enabled for an unlimited period at any time by means of the code number, which you will receive from HEIDENHAIN after stating the SIK number.

HEIDENHAIN would like to point out that it is not possible to use the OEM-specific options with the SIKs of the first generation. If you encounter any problems in this respect, please contact your HEIDENHAIN service agency.

You can generate the temporary code number with the TNCOEMOption tool for PCs. The tool is available for cost-free download from our HEIDENHAIN FileBase.

When you generate the code number, you must specify the number of the respective software option, the number of days you want to enable the option, and an optional OEM Key. The OEM Key provides protection against unauthorized persons generating code numbers for your machines with the help of the PC tool in order to enable software options without your approval. However, it is not essential to specify an OEM Key.

The OEM Key for generating the code number must be identical to the OEM Key on your control.

The OEM key was added to the display and management of the SIK options, feature content level and general key on the control. Press the code number key and enter the code number **SIK** to display the input form for SIK functions:

■ **OEM Key**

The OEM Key on the control can only be used for enabling software options with a temporary code number if the same OEM Key was specified for the generation of the temporary code number.

If the OEM Key on the control is not identical to the one used for generating the code number, the software option will not be enabled. Once the OEM Key has been set, it cannot be reset.

<b>Display</b>	<b>Meaning</b>	
<b>OEM Key for temp. options</b>	<b>Not Set</b>	OEM Key was not set
	<b>Set</b>	OEM Key was set

Pressing the **SET OEM KEY TEMP. OPT.** soft key opens a window in which you can enter an OEM key.

Keep in mind that this process cannot be undone.

The OEM Key must consist only of numbers. The maximum permissible input value for the OEM key is 65535. Conclude your entry by pressing the **OK** soft key.

If the OEM Key was set successfully, the message **OEM Key has been set** appears, and the status in **OEM Key for temp. options** changes to **SET**.



## Options for the OEM

The SIK options #101 to #130 are available as OEM-specific options for you, the machine tool builder. You can assign your own OEM-specific software options to these options.

This makes it possible for you to enable your own applications (e.g. cycles) for the end user via the SIK from HEIDENHAIN.

The options can be enabled by entering a code number. HEIDENHAIN can give you the code number after having been informed of the SIK number. You also have the possibility of creating a temporary key for these OEM-specific options in order to enable the options for a period of max. 90 days.

The PLC module 9067 enables you to request the status of the SIK options. Use this module to request information from the SIK about whether certain software options are enabled via the SIK. Depending on the response, you can activate the software option via the PLC program.

## Status of options that have been set

### Module 9067 Status of software settings

PLC Module 9067 enables you to request status information about software settings. Module 9067 can currently be used to interrogate the software options set in the SIK.

Call:

PS B/W/D/K <Mode>  
0: Interrogate whether SW option is set in the SIK

PS B/W/D/K <Number>  
If mode is 0: Number of SIK option

CM 9067

PL B/W/D <Status>  
Status of SIK option (if mode is 0):  
0: Not set  
1: Set

### Error recognition:

Marker	Value	Meaning
M4203	0	Function was performed correctly
	1	Error code in W1022
W1022	1	Invalid value for number
	2	Invalid value for mode




## Overview of the options

See "Software options" on page 122.

## 2.7.4 Configurations

The maximum configuration of the MANUALplus 620 is designed for one slide (with X, Z, Y, U, V and W axis), main spindle, opposing spindle, C1/C2 axis and driven tool. Use parameters to hide components not present on the machine. You also set the type of C-axis drive (separate C-axis drive or driven with spindle motor) via parameter. If there is a separate drive for the C axis, an additional control loop is required.

Please contact HEIDENHAIN if you require a different configuration.

Configuration of MANUALplus 620	
Machine setup	Axes and spindles
	<p>Example 1:</p> <ul style="list-style-type: none"> <li>■ 2 spindles (spindle and driven tool)</li> <li>■ 1 slide</li> <li>■ 2 linear axes (X1 and Z1 axes)</li> <li>■ C1 axis (drive with spindle motor)</li> </ul>
	<p>Example 2:</p> <ul style="list-style-type: none"> <li>■ 2 spindles (spindle and driven tool)</li> <li>■ 1 slide</li> <li>■ 4 linear axes (X1, Z1, Y1 and W1 axes)</li> <li>■ C1 axis</li> </ul>
	<p>Example 3:</p> <ul style="list-style-type: none"> <li>■ 3 spindles (spindle and opposing spindle, driven tool)</li> <li>■ 1 slide</li> <li>■ 3 linear axes (X1, Z1 and W axes)</li> <li>■ C1/C2 axis</li> </ul>



### Note

Please note that, if the same position encoder is used for the main spindle and the C axis, the operation of a separately driven C axis along with the use of a CC 61xx is not possible until the beginning of 2012. Contact HEIDENHAIN if you need this feature before the above mentioned date.

## 2.7.5 Coordinate system of the lathe

You specify the coordinate system of the lathe in the kinematics description.

The parameter MP\_CoordSystem (in System/DisplaySettings/CfgCoordSystem) is relevant for the simulation, graphic representation in ICP and for the help graphics. The following settings are possible:

- +X / +Z: Horizontal lathe—turning behind the center
- -X / +Z: Horizontal lathe—turning in front of center
- +Z / +X: Vertical lathe—turning to the right of center
- +Z / -X: Vertical lathe—turning to the left of center

## 2.7.6 NC software exchange on the MANUALplus 620



### Note

- The NC software must be exchanged only by trained personnel.
- For exchanging the NC software, HEIDENHAIN provides a packed file with the NC software. For intermediate storage, the packed file is stored on a USB memory stick or a USB hard disk. Then it is installed on the control from the intermediate storage medium.
- HEIDENHAIN recommends making a backup of the control, for example with TNCbackup (included in TNCremoNT), before updating the NC software, see "Data backup" on page 149.

## General information

- The **setup.zip** file is required for the software exchange. The installation program of the control automatically detects the file which must be stored in root directory of the data medium from which the update is run.



### Note

HEIDENHAIN recommends:

Use a USB memory stick (1 GB or larger) to exchange the software. Do not use any memory stick with a smaller storage capacity.

- A backup of the control's previous NC software is automatically created, while the software is being updated. The backup file is packed and stored on the memory stick. If the update is not completed successfully, your previous NC software version will automatically be restored. In addition, the complete update archive is automatically unpacked to the memory stick before installation. The memory stick must have enough free space for the backup and for unpacking the setup files. This is ensured by using a USB memory stick with a storage capacity of 1 GB.



### Note

As a registered customer, you will receive the **setup.zip** file necessary for the update directly from HEIDENHAIN.

To do so, please write by e-mail to [filebaseteam@heidenhain.de](mailto:filebaseteam@heidenhain.de).

- Software updates and service packs are installed in the same manner.
- The NC software has been prepared in such a manner that when an update is performed or a service pack loaded, the PLC program, the machine configuration or data on the PLC partition can be updated as well, according to the OEM's specific requirements. The OEM uses the HEIDENHAIN PC software **PLCdesignNT** to add all necessary files to the **setup.zip** archive. These files are copied to the appropriate locations on the control during an update.



#### Note

For detailed information on how to add OEM specific files to the setup packet, refer to the online help for PLCdesignNT under "Generate Machine Setup." The support necessary for this from PLCdesignNT will be available starting from version 2.5.

### Procedure for exchanging the NC software

To install an NC software update, proceed as follows:


- ▶ If the machine is running, shut down the control by pressing the **OFF** soft key.
- ▶ Switch off the machine.
- ▶ If the new NC software is stored on a USB memory stick or a USB hard disk, connect the storage medium to a free USB socket.
- ▶ Switch the machine back on again.
- ▶ When the screen turns blue while the control is starting up, press the **DEL** key on the operating panel repeatedly. You must not hold down the DEL key. The control interrupts the boot process and a login message of the HEIDENHAIN operating system will be displayed:




- ▶ Enter **049866931** or **1** for "User name." If a USB keyboard is connected to the control, you can also enter **update** as an alternative.
- ▶ Press the **ENT** key or the RETURN key on the external USB keyboard.




- ▶ The control starts the HE menu. The following window appears on the screen:



- ▶ Select the **Update** menu item and confirm your entry with the **ENT** key.



- ▶ Select the source on which the packed files for the software update are stored. If the setup files are stored on a USB stick, select **Source: USB stick**. Press the **ENT** key to confirm your selection.



- ▶ The control then starts the boot updater. A new window opens, which displays the contents of the update packet:

```

Bootupdater Version: 0.99   03.05.2005
Version: 340551_00B_____

Version created 02.Aug.2005 16:02:44

Complete content of this update:

McKern_SYS.zip           NC_Kern Software (Filelist based produced)
sv_updater.zip           The Software Updater

0: Cancel
1: Do complete update

Select: _

```

- ▶ Select **1** and confirm your selection with the ENT key.
- ▶ The control automatically performs the NC software update (approx. 20 to 30 minutes).
- ▶ After the update has been completed, the control requests you to remove the USB memory stick and then press **ENT**:

**Remove the USB stick and then press ENT or Return!**

- ▶ Remove the USB device (memory stick or hard disk) from the control.
- ▶ Press the **ENT** key or the RETURN key on the optional USB keyboard.
- ▶ The control is shut down and then restarts automatically.
- ▶ The NC software update is complete.

## Automated updating of machine parameters

If new machine parameters are introduced as a part of a software update, HEIDENHAIN creates "update rules" for the changes to the machine configuration. These update rules are executed during the first restart after the update and automatically make the changes to the configuration. During the first booting after the update, the control therefore request you to check and save the update rules and the changes made automatically to the machine configuration.

You also have the possibility of using the OEM update rules to define changes (e.g. inserting new PLC machine parameters or changing existing parameter values) to the machine configuration and to perform the changes automatically after the update.

Update rules are files of the \*.cfg type, which contain instructions for automated changes to the machine configuration.

For a description of how to create update rules, see „Update rules" on page 351.





## Start update while software is running on the control

As of SW version 548 328-02 you can start an NC software update even while the software is running on the control.



### Note

Please note that the space on the CFR memory card is not sufficient for the MANUALplus 620 to open the setup.zip file from the "TNC:" or "PLC:" drive. Always save the file on a USB memory stick with at least 512 MB free memory.

Plug the memory stick in a free USB socket of the control and start the update as described below.



### Note

HEIDENHAIN recommends:

After you have updated your software, keep the data on the USB stick used in a safe place. Then you can return to a previous software version if needed, see "Reversing a software update" on page 144.

▶ Switch to the **Organization** operating mode.


▶ Press the  soft key.

▶ Enter the code number 231019.


▶ Press the **UPDATE DATA**  soft key.

▶ Then press the **LOAD ZIP**  soft key.

▶ Press the **PATH** soft key to select the directory, in which the setup file is located, in the left window.



- ▶ Then press the **FILES** soft key to place the cursor in the right window on file level. Use the **SELECT** soft key to select the setup.zip file. The control checks whether the selected setup file can be used for the current software version of the control.



- ▶ Confirm the confirmation request "Do you really want to switch off?". The NC software is now automatically shut down and then the actual update program is started.
- ▶ Select a dialog language.
- ▶ The next dialog field shows the old and new software. Confirm the confirmation request "Do you really want to install the software now?". Now the software update is started. The bar diagram displays the current progress of installation.
- ▶ After the software update is complete you will be prompted to restart the control. If you have used a USB stick, remove it before restarting the control.
- ▶ While the control is running up, the dialog window for entering the code number appears. Enter here 95148.
- ▶ In the next step you are prompted to check the update rules. Press the **UPDATE RULES** soft key.
- ▶ To leave the update rules, press the **END** soft key.
- ▶ In the next step, check the configuration data by pressing the **CONFIG DATA** soft key.

- ▶ If parameters were changed, added or removed in the configuration data by the software update, this is marked by a red exclamation mark. Check all changed passages of the configuration data and press the **SAVE** soft key.
- ▶ Exit the software update by twice pressing the **END** soft key, and after booting the control, conduct a restart.
- ▶ To finally conclude the software update, you have to confirm in a dialog window any changes of the firmware/hardware of the control; see "Monitoring hardware changes" on page 149.

### 2.7.7 Installing a service pack



#### Warning

When needed, HEIDENHAIN prepares service packs for the various versions of the NC software. Registered customers can download these service packs from the HEIDENHAIN FileBase on the Internet. Installation of a service pack in addition to the already installed NC software implements important error fixes. Please ensure that the NC software always contains the latest service pack before you ship the machine. Perform all tests required of the machine or the NC software again after having installed the service pack.

The latest service pack always includes all changes from earlier service packs. HEIDENHAIN recommends always installing the latest released service pack!



#### Warning

If a service pack has already been installed, it will not be possible to install a service pack with a lower index. This will be checked during the installation of a service pack and a message will be displayed if an error is found.



#### Note

- If a service pack is available for the current NC software, you can download it from the HEIDENHAIN FileBase on the Internet (<http://filebase.heidenhain.de>). The file name consists of the NC software number and the number of the service pack, e.g. **54832801sp1.zip**.
- A service pack must be installed only by trained personnel.

The service pack consists of a packed file (**setup.zip**). For intermediate storage, the packed file is stored on a USB memory stick, for example. Then it is installed on the control from the intermediate storage medium.

### Installing a service pack

A service pack is installed in the same manner as the NC software update. For instructions, please refer to "Procedure for exchanging the NC software" on page 138.

## 2.7.8 Reversing a software update

Under certain circumstances it may be necessary to reverse an NC software update. The prerequisite is that you still have the USB stick or the USB block device from which the update was carried out.

In addition to the **setup.zip** update file the control automatically saves several backup ZIP files of the last NC software on the USB drive during the software update. Together with the **setup.zip** file you can thus return to the previous software version.

Proceed as follows:

- ▶ Connect the USB stick or the USB drive with a vacant USB port on the control.
- ▶ Switch on the control.
- ▶ Interrupt the boot process by pressing the DEL key several times while the blue boot screen is shown; see "Procedure for exchanging the NC software" on page 138.
- ▶ The login message for the HEIDENHAIN operating system appears. Enter the code number **049866931** or **1**, or the keyword **update**. The control opens the HE menu.
- ▶ Open the **Update > Special features > Restore > RESTORE of setup.zip on USB stick** menu items, concluding each selection with the ENT key.
- ▶ If the control detects that the backup files for reversing the update exist, then an overview of the setup files stored on the USB stick appears. Otherwise an error message is displayed.
- ▶ Press the "1" key on the operating panel to start the reversal of the update.



### Note

HEIDENHAIN recommends:

After you have updated your software, keep the USB stick used for this in a safe place. Then you can return to a previous software version if needed.



### Note




Back up the NC programs or parameters you have created or changed after the installation of the last software update, before returning to the previous software version!

During this return to the previous software version, the data on the hard disk is replaced without a confirmation prompt! The exact state of the previous software is restored. Any changes or data added after the update was performed are lost.



## Reversing a software update while the NC software is running

As of SW version 548 328-02 you can undo an NC software update even while the software is running on the control.

- ▶ Switch to the **Organization** operating mode.
- ▶ Press the  soft key.
- ▶ Enter the code number 231019.
- ▶ Press the **UPDATE DATA**  soft key.
  
- ▶ Then press the **LOAD ZIP**  soft key.
- ▶ Press the **PATH** soft key to select the directory, in which the setup file is located, in the left window, e.g. USB0:
- ▶ Then press the **FILES** soft key to place the cursor in the right window on file level.
- ▶ Press the **UNDO UPDATE** soft key.
- ▶ Use the **SELECT** soft key to select the setup.zip file. The control checks whether it can use the selected setup file together with the REDO files saved in the same directory for restoring the previous software level.
- ▶ Confirm the confirmation request "Do you really want to switch off?". The NC software is now automatically shut down and then the actual update program is started.
- ▶ A dialog field prompts you to select a language.
- ▶ Confirm the confirmation request "Do you want to continue?".
- ▶ The next dialog box shows the previous and the currently installed software version and once again requests a confirmation for uninstalling the software. After your confirmation, a progress bar appears for the restoration of the previous software version.
- ▶ Then confirm the status message announcing the successful restoration of the software level and remove the USB stick. The control now automatically reboots.

## 2.7.9 Special features of the software

### Firmware

HSCI components have their own firmware, which must match the currently installed NC software version. Every time the control is started, the NC software checks the firmware versions of the individual HSCI components. After a software update, during initial operation or after replacing a hardware component, a firmware update may be required.



#### Note

The control must not be switched off during a firmware update!

If the NC software detects that a firmware update is necessary, you will be prompted by a dialog box to start the firmware update. The firmware updates are included in the NC software update package. Please read the notes on firmware updates under "Firmware update on HSCI devices" on page 147. When the firmware versions of all HSCI participants have been updated, the control boots until the "Power interrupted" message appears.

### Configuration

During startup, a control in an HSCI system expects the complete configuration of the HSCI system in the form of an IOC file. The IOconfig software for PCs is used to configure the system, the PLC input/output systems (PL 6xxx, UEC 11x, MB machine operating panel with a connected HR handwheel ) and the PROFIBUS components.

With IOconfig, the components of an HSCI/PROFIBUS system are specified in a project and their arrangement is described. On the basis of this data, IOconfig generates the IOC file (\*.IOC) that contains all relevant configuration data for the HSCI system. Then you transfer the IOC file to the control. With the **MP\_iocProject** machine parameter (103402) you enter the path and name of the project file (e.g. %OEM%\IOC\Structur.ioc). When the control is next booted, the file is read in and evaluated by the control.



#### Note

All information required for using the IOconfig PC software and configuring HSCI and PROFIBUS components is contained in the IOconfig Technical Information, which is available for registered customers from the HEIDENHAIN FileBase on the Internet.

During start-up of the control, the nominal configuration of the IOC file is compared with the actual configuration. If there is a difference, you will be informed of it in a dialog box. Press the **Accept** button to confirm the new configuration and continue start-up of the control.


In addition to the configuration, the serial numbers of the individual HSCI components are also saved. During start-up they are compared with those of the detected hardware. Any difference must be checked and accepted by the user. (See "Monitoring hardware changes" on page 149.)

The control also starts up without the IOC file or entry in the **MP\_iocProject** (103402) parameter. The control then automatically detects all components connected to the HSCI chain and the current configuration—without the PLC input/output systems, however. Press the **Accept** button in the dialog box to confirm the detected configuration and continue start-up of the control. However, further configuration of the control is not possible. In the **Programming** mode you can start the BUS DIAGNOSIS by pressing the MOD key and the DIAGNOSIS soft keys. The control will display the structure of the detected HSCI system. If required, you can use this information for the configuration with IOconfig.

### 2.7.10 Firmware update on HSCI devices


During a software update or after installing a service pack, an update of the internal firmware of HSCI components may be required.

In this case, the control displays the following error message after start-up:



- Acknowledge the error message by pressing the **DELETE ALL** soft key.

The control now starts to install the new firmware on the HSCI devices. This procedure is displayed with the following dialog box:



#### Warning

Never shut down the control while a firmware update is running—otherwise the control will require servicing!

After the update is finished, the control displays another message on the screen. After you have acknowledged the message, the control will shut down automatically. Switch off the machines and restart the control.





## 2.7.11 Monitoring hardware changes

The MANUALplus 620 automatically monitors and checks whether hardware changes to control components took place. If the control detects a hardware change, it displays a dialog window after start-up. The operator must confirm the hardware change(s).

To accept a control hardware change:

- ▶ Press the right arrow key to navigate to the **Accept** button. Then press the ENT key:

To reject a control hardware change:

- ▶ Press the **Reject** button. The control will continue booting and start in the Programming Station mode. When the control is next booted, the dialog box will be displayed again.



## 2.7.12 Data backup

For data backup, HEIDENHAIN offers the PC software **TNCbackup** free of charge. TNCbackup provides convenient functions for backing up and restoring data. TNCbackup is part of the TNCremoNT software package and can be downloaded from the HEIDENHAIN file base on the Internet. (<http://filebase.heidenhain.de>)

HEIDENHAIN recommends that the machine manufacturer use the TNCbackup software to save all his **machine-specific data** and to supply them with the machine (e.g. on CD-ROM). To do so, use the PC software TNCremoNT to set up a connection with the PLC partition (drive O:) of the control and, in the Extras/Backup menu, start the TNCbackup software. In TNCbackup, under "File/Scan file list," select the "Scan directory tree" function to display and mark all directories and subdirectories of the PLC partition. With "Run/Backup" you can back up all marked files in the current file list. Before starting, TNCbackup asks you for the name of the backup file to be saved. In addition to the actual backup file \*.BCK, the file list \*.LST is saved. For a backup to be restored, the \*.BCK file and the associated \*.LST file must be located in the same folder.

The customer, too, should save his data before exchanging the control. It is also advisable that the customer save all of the files and programs created on the control at regular intervals on a PC. The CD-ROM supplied with the machine should therefore also contain the current version of TNCremoNT.

## 2.8 Software Releases

### 2.8.1 NC software 548 328-xx

**NC software  
548 328-01** Release: 05/2008  
Initial version

**NC software  
548 328-02** Release: 07/2009

- A summary of the improvements is given in the Update Information No. 1, see "Description of the new functions" on page 57.

**NC software  
548 328-03** Release: 08/2010

- A summary of the improvements is given in the Update Information No. 2, see "Description of the new functions" on page 57.

**NC software  
548 328-04** Release: 09/2011

- A summary of the improvements is given in the Update Information No. 4, see "Description of the new functions" on page 57.



# 3 Mounting and Electrical Installation

## 3.1 General Information



### Warning

Keep the following in mind during mounting and electrical installation:

- National regulations for power installations
- Interference and noise immunity
- Operating conditions
- Mounting position

### 3.1.1 Safety precautions



### Danger

Ensure that the main switch of the control or machine is switched off when you engage or disengage connecting elements or connection clamps.



### Danger

Ensure that the grounding conductor is connected. Interruptions in the equipment grounding conductor may cause damage to persons or property.



### Danger

Incorrect or non-optimized input values can lead to faulty machine performance and therefore to serious injury to persons and damage to equipment. Modifications of the machine configuration should be done with caution and uncontrolled axis motions should be taken into account.



### Warning

In order to be able to judge the behavior of an NC controlled machine, you need to have fundamental knowledge about drives, inverters, controls and encoders. Inappropriate use may cause considerable damage to persons or property.

HEIDENHAIN does not accept any responsibility for direct or indirect damage caused to persons or property through improper use or incorrect operation of the machine.



#### Danger

The interfaces for the PLC inputs/outputs, machine operating panel and PL connection comply with the requirements for basic insulation in accordance with **IEC 742 EN 50 178**.

Only units that comply with the requirements of **IEC 742 EN 50 178** for basic insulation may be connected, otherwise damage to persons or property may be caused. The maximum dc voltage mean value of the PLC inputs is 31 V.

### 3.1.2 Degrees of protection

The following components fulfill the requirements for IP54 (dust and splash-proof protection).

- Visual display unit (front, when properly installed)
- Keyboard unit (front, when properly installed)
- Machine operating panel (front, when properly installed)
- Handwheel (built-in or connected, depending on the type)

All electric and electronic control components must be installed in an environment (e.g. electrical cabinet, housing) that fulfills the requirements of protection class IP54 (dust and splash-proof protection) in order to fulfill the requirements of contamination level 2.



#### Note

All components of the OEM operating panel must also comply with protection class IP54, just like the HEIDENHAIN operating panel components.

### 3.1.3 Electromagnetic compatibility

This unit fulfills the requirements for Class A according to EN 55022 and is intended for operation in industrially zoned areas.

Protect your equipment from interference by observing the following rules and recommendations.

#### Likely sources of interference

Interference is mainly produced by capacitive and inductive coupling from electrical conductors or from device inputs/outputs, such as:

- Strong magnetic fields from transformers or electric motors
- Relays, contactors and solenoid valves
- High-frequency equipment, pulse equipment and stray magnetic fields from switch-mode power supplies
- Power lines and leads to the above equipment



## Protective measures

- Keep a minimum distance of 20 cm from the control and its leads to interfering equipment.
- Keep a minimum distance of 10 cm from the control and its leads to cables that carry interference signals. For cables in metallic ducting, adequate decoupling can be achieved by using a grounded separation shield.
- Shielding according to EN 50 178.
- Use equipotential bonding conductors with a cross section of 6 mm<sup>2</sup>
- Use only genuine HEIDENHAIN cables, connectors and couplings

### 3.1.4 ESD protection

Always assume that all electronic components and assemblies are endangered by electrostatic discharge (ESD).

To ensure protection from ESD, follow the precautionary measures described in IEC 61340-5-1, IEC 61340-5-2 and IEC 61340-4-1.




#### Note

Improper handling can result in damage to the components or assemblies due to ESD!

The following are some points covered in the above mentioned standards:


- When handling electrostatically endangered components or assemblies (e.g. exchange, installation, shipping), always comply with the precautionary measures described in IEC 61340-5-1, IEC 61340-5-2 and IEC 61340-4-1.
- Store and transport ESD-sensitive components in ESD protective containers.
- Ensure during handling the proper grounding of the working area (e.g. tool, workbench, packaging) and the person.
- Inspect the ESD protection system regularly.

The following figure shows how a suitable working area could look in accordance with IEC 61340.



- 1: Wristband with 1 MOhm grounding cable for grounding the person
- 2: Grounded connection for wristbands, floor mats, table mats etc. for equipotential bonding
- 3: Dissipative shoes
- 4: Dissipative flooring or floor mat

An important part of the working area is a suitable working surface with a wristband with 1 MOhm grounding resistance for personal grounding:



## 3.2 Environmental Conditions

### 3.2.1 Storage and operating temperatures

#### Limit values

Device	Air approaching the device in the panel / electrical cabinet	Temperature range outside the panel / electrical cabinet
MC 6110T	0°C to +50°C	0°C to +45°C (no direct exposure to sunlight)
MB 6xx, TE 6xx	0°C to +50°C	0°C to +45°C
HR 4xx		0°C to +45°C
PLB 6xxx, PLD-H, PLA-H	+5°C to +40°C	
Compact-Flash card	0°C to +70°C	0°C to +45°C (no direct exposure to sunlight)

#### Limit value for temperature inside the panel

Because the MC is installed in the operating panel, additional heat is generated that must be emitted to the surroundings through the panel wall. The required temperature difference depends on the design and the size of the panel.

The maximum permissible temperature of the air surrounding the panel is 45 °C. However, the temperature of the air inside the panel, which flows into the HEIDENHAIN devices (e.g. the MC), is decisive for the HEIDENHAIN devices integrated in the panel.



#### Warning

The temperature of the air inside the panel, which flows into the HEIDENHAIN devices, must not exceed a maximum temperature of +50 °C.

The panel must be designed in such a way that this maximum temperature of +50 °C is not exceeded. Please verify this through an appropriate temperature measurement.

With the recommended temperature limits, active cooling is not required for a typical panel.

## Humidity during operation



### Warning

Condensation on the electronics is not permitted!

Condensation can form, for example, if warm, moist air flows along cool surfaces of the electronics. Therefore, cooling units with discontinuous (e.g. two-position) temperature control must not be used. The resulting cyclic changes in temperature and humidity can cause condensation on the cool surfaces of the electronics. Furthermore, you must prevent condensate from reaching the electronics and ensure that it can drain away without causing damage.

In tropical areas it is recommended that the control not be switched off, so that condensation is avoided on the circuit boards.

## Storage temperatures

For all control components:  $-20\text{ °C}$  to  $+60\text{ °C}$ .





### 3.2.2 Heat generation and cooling


A heat exchanger or a cooling unit is preferable for controlling the internal temperature of the electrical cabinet.

If filtered air is blown into the electrical cabinet for cooling purposes, the standard IEC 61800-5-1 applies, which permits contamination level 2.



#### Danger

Be sure to take the measures required for preventing dust or water from entering the electrical cabinet or the housing. Dust depositing inside electrical devices may cause them to fail and impair the safety of the system. Max. contamination level 2 is permitted for the components.



### 3.2.3 Limit values for ambient conditions

HEIDENHAIN specifies the range of application 2 for the use of its control products.

Furthermore, the following limit values apply:

<b>Characteristic values during operation:</b>	<b>Limit values to be maintained</b>	<b>Standard to be complied with</b>
Vibration	$\pm 0.075$ mm, 10 Hz to 41 Hz; 5 m/s <sup>2</sup> , 41 Hz to 500 Hz;	DIN EN 60068-2-6
Shock	50 m/s <sup>2</sup> , 11 ms	DIN EN 60068-2-27
Relative air humidity	75 % in continuous operation; 95 % for not more than 30 days a year (randomly distributed)	
IP protection	IP 54 for HW, TFT, MB, TE	DIN EN 60529
ESD 61000-4-2	Severity level 3	DIN EN 6100-4-2
HF field 61000-4-3	Severity level 3	DIN EN 6100-4-3
Burst 61000-4-4	Severity level 3	DIN EN 6100-4-4
Surge 61000-4-5	Severity level 3	DIN EN 6100-4-5
Conducted disturbances	Severity level 3	DIN EN 6100-4-6

### 3.2.4 Installation elevation


The maximum elevation for installation is 3000 m above sea level.

### 3.2.5 UEC 11x (FS) mounting position



#### Warning

When mounting, please observe proper minimum clearance, space requirements, length and position of the connecting cables.




### 3.2.6 MC 6110T mounting position



#### Warning

When mounting, please observe proper minimum clearance, space requirements, length and position of the connecting cables.




### 3.2.7 CC 61xx, UV xxx, UM xxx, UE 2xx B(D) mounting position



#### Warning

When mounting, please observe proper minimum clearance, space requirements, length and position of the connecting cables.




### 3.2.8 PLB 6xxx mounting position



#### Warning

When mounting, please observe proper minimum clearance, space requirements, length and position of the connecting cables.



### 3.3 Overview of Components

Hardware component		ID
MC 6110T	Main computer (compact) 1 GHz	731 604-xx
CFR MANUALplus 620	Memory card for MC 6110T with MANUALplus 620 software	733 606-51
SIK MANUALplus 620	NC software license for MC 6110T, 3 control loops, SW option "Teach-in," "smart.Turn," "Thread recutting," "C-axis machining"	733 604-53
SIK MANUALplus 620	NC software license for MC 6110T, 3 control loops, SW option "Teach-in"	733 604-55
SIK MANUALplus 620	NC software license for MC 6110T, 4 control loops, SW option "Teach-in"	733 604-56
SIK MANUALplus 620	NC software license for MC 6110T, 3 control loops	733 604-53
CC 6106	Controller unit for HSCI for max. 6 control loops	662 636-xx
CC 6108	Controller unit for HSCI for max. 8 control loops	662 637-xx
CC 6110	Controller unit for HSCI for max. 10 control loops	662 638-xx
UEC 111	Controller unit with inverter and PLC, 4 control loops	625 777-xx
UEC 112	Controller unit with inverter and PLC, 5 control loops	625 779-xx
MS 110	Mounting case for multi-row configuration	658 132-xx
MS 111	Mounting case for multi-row assembly, additional connection for 24 V supply to the fan	673 685-xx
PSL 130	Low-voltage power supply unit, 750 W, for +24 V NC and +24 V PLC	575 047-xx
PSL 135	Low-voltage power supply unit, 750 W, for +24 V NC and +24 V PLC, also suitable for non-HEIDENHAIN systems	627 032-xx
MB 620T	Machine operating panel for HSCI connection with spindle and feed rate override potentiometers	737 610-xx
PLB 6001	HSCI adapter for OEM-specific machine operating panel, 64 digital inputs, 32 digital outputs	668 792-xx
PLB 6104	PLB for HSCI, 4 slots	591 828-xx
PLB 6106	PLB for HSCI, 6 slots	630 058-xx
PLB 6108	PLB for HSCI, 8 slots	630 059-xx
PLB 6204	PLB for HSCI, 4 slots, with system module	591 832-xx
PLB 6206	PLB for HSCI, 6 slots, with system module	630 054-xx
PLB 6208	PLB for HSCI, 8 slots, with system module	630 055-xx
PLD-H 16-08-00	PL for PLB 6xxx: 16 digital inputs, 8 digital outputs	594 243-xx
PLD-H 08-16-00	PL for PLB 6xxx: 8 digital inputs, 16 digital outputs	650 891-xx
PLA-H 04-00-04	PL for PLB 6xxx, four $\pm 10$ V inputs, 0 analog outputs, four PT 100 inputs	599 070-xx

Hardware component		ID
PLA-H 08-04-04	PL for PLB 6xxx, eight $\pm 10$ V inputs, four $\pm 10$ V analog outputs, four PT 100 inputs	675 572-xx
PL empty housing	Empty housing for slots of a PL 6xxx	383 022-11
CMA-H 04-04-00	SPI expansion module for CC/UEC for analog axes/spindles for HSCI, four analog outputs $\pm 10$ V	688 721-01
HSCI cable	HSCI connecting cable	618 893-xx



#### Warning

In HSCI systems with integrated functional safety (FS) you may use only devices that have been certified for use in such systems. For components and devices permitted for use in systems with functional safety, please refer to the Technical Manual for Functional Safety (FS). Upon request, your contact partner at HEIDENHAIN can provide you with the manual.

If you want to design the control system in accordance with the new standard ISO 13849-1, you need the corresponding validation values of the individual control components for calculating the required performance level. This also applies to the inverters and power supply modules used in a system with HSCI but without integrated functional safety (FS). Only devices whose index or version number is greater than or equal to the device version numbers listed below in the right column are permitted for use in accordance with ISO 13849-1. The devices listed in the middle column can also be used.



#### Warning

Furthermore, in HSCI systems with integrated functional safety (FS) you may use only inverters or power supply modules that have been certified for use in such systems. Please take this into account when configuring your machine. Suitable devices are listed below in the middle column.



Below you will find an overview of the devices that—according to 13849-1—are permitted for use in systems with and without FS.

<b>Device designation</b>	<b>Device ID for systems with integrated FS</b>	<b>Device ID for systems without integrated FS</b>
Inverter modules		
UM 116D	667954-01	542998-01
UM 116DW	667946-01	369629-01 index B
UM 115D	671566-01	387852-01 index E
UM 114D	671288-01	510509-01 index E
UM 113D	730435-01	518703-01 index B
UM 112D	731984-01	519971-01 index C
UM 122D	667633-01	519972-01 index C
UM 121BD	667942-01	513037-01 index C
UM 111BD	671968-01	513035-01 index E
UM 121D	667838-01	392319-01 index F
UM 111D	667945-01	392318-01 index F
Power supply modules		
UVR 120D	728252-01	390188-01 index K
UV 130D	728250-01	389311-01 index E
UVR 130D	728248-01	377639-01 index K
UVR 140D	728253-01	390281-01 index N
UVR 150D	728255-01	390421-01 index P
UVR 160D	728257-01	530341-01 index G
UVR 160DW	728258-01	560106-01 index G
Non-regenerative compact inverters		
UE 210D	733 421-01	558302-01 index C
UE 211D	733 423-01	558303-01 index C
UE 212D	733 424-01	558304-01 index C
UE 230D	733 425-01	558305-01
UE 240D	733 426-01	558306-01
UE 241D	733 427-01	558307-01
UE 242D	733 428-01	558308-01
UEC 111(FS)	Not yet available	625 777-xx
UEC 112(FS)	Not yet available	625 779-xx
UE 110	Not yet available	375713-02 index B
UE 111	Not yet available	375714-02 index B
UE 112	Not yet available	375715-02 index B



Device designation	Device ID for systems with integrated FS	Device ID for systems without integrated FS
Regenerative compact inverter		
UR 242D	741 359-01	536565-01 index A
UR 230D	741 356-01	536561-01 index A
UR 240D	741 357-01	536564-01 index B

With the following HSCI control components, you must also make a distinction between those that are required in a system with functional safety and those that can be used in a system without functional safety. Devices with FS are listed below in the middle column:

Device designation	Device ID for systems with integrated FS	Device ID for systems without integrated FS
Machine operating panels and keyboard units		
In systems with FS you must use a machine operating panel for functional-safety applications. In these operating panels, all keys have twin channels. A movement can therefore be executed without additional permissive button/key.		
MB 620 (FS)	660 090-xx	617 973-xx
TE 635Q (FS)	662 255-xx	617 975-xx
PLB basic modules		
In FS systems, mixed use of PLB basic modules with and without FS is possible. However, at least one PLB 62xx FS must be used in systems with FS.		
PLB 6104 (FS)	590 479-xx	591 828-xx
PLB 6204 (FS)	586 789-xx	591 832-xx
PLB 6206 (FS)	622 721-xx	630 054-xx
PLB 6208 (FS)	620 927-xx	630 055-xx
PLB 6001 (FS)	Not yet available	668 792-xx
PLD-H I/O modules		
In systems with FS, the mixed use of PLD-H modules with and without FS is possible in PLB basic modules with FS. However, do not insert PLD-H modules with FS in PLB basic modules without FS. Furthermore, the modules with FS must always be inserted into the PLB with FS starting from the left.		
PLD-H 16-08-00, PLD-H 08-04-00 FS	598 905-xx	594 243
PLD-H 08-16-00, PLD-H 04-08-00 FS	727 219-xx-xx	650 891-xx

The other control components (MC 6xxx, CC 6xxx, PSL 13x, MS 1xx, BF 2xx) can be used regardless of whether the system is a system with or without functional safety (FS).



#### Warning

In HSCI systems with integrated functional safety (FS) you may use only devices that have been certified for use in such systems. For components and devices permitted for use in systems with functional safety, please refer to the Technical Manual for Functional Safety (FS). Upon request, your contact partner at HEIDENHAIN can provide you with the manual.

## 3.4 HSCI

### 3.4.1 Introduction

The main computer is connected to the controller units (CC or UxC) and the PLB 6xxx PLC basic modules in the electrical cabinet via **HSCI** (HEIDENHAIN Serial Controller Interface). The MB machine operating panel is also connected via HSCI. The connection of the various control components via HSCI offers numerous benefits, including:

- Simple and uncomplicated wiring
- High noise immunity
- Comprehensive yet straightforward possibilities for diagnostics

The logic area of the control system is supplied with power via two separate power loops:

- The MC, MB, PLs and BF are supplied with power via the PSL 130 power supply unit. The voltages of the PSL 130 correspond to the PELV system as per EN 50178.
- The logic voltages of the CC are voltages derived from the DC-link voltage of the inverters, and are transmitted via connector X69 "NC supply voltages and control signals." These voltages also correspond to PELV as per EN 50178.



The following table shows the maximum permissible number of individual HSCI participants:

HSCI component	Maximum number	
MC (HSCI master)	1 in the system	
CC, UEC, UMC (HSCI slave)	4 drive-control motherboards, (distributed to CC, UEC, UMC as desired)	
MB 6xx (FS), PLB 6001 (FS) (HSCI slave)	2 in the system	Total number of 9 components must not be exceeded in this case
PLB 62xx (FS) (HSCI slave)	1 in the system (not with UEC 11x)	
PLB 61xx (FS), PLB 62xx (FS) (HSCI slave)	7 in the system	
HR (FS) handwheel (at the MB 6xx or PLB 6001)	1 in the system	
PLD-H xx-xx FS (in PLB 6xxx FS)	8 in the system	
PLD-H xx-xx (in PLB 6xxx FS)	64 in the system	



#### Danger

If you use more than one operating station or machine operating panel, the PLC program must ensure that only one of the operating devices is active at any one time so as to avoid danger to the operator.

The order of the HSCI participants at X500 of the main computer can be freely chosen. Each HSCI participant is assigned its HSCI address based on its position in the HSCI chain:

- First device after the master (main computer): Bus address 1
- Second device after the master (main computer): Bus address 2 etc.

The main computer selects a master controller unit, based on the position of the controller units in the HSCI network. The first controller unit in the system (nearest the main computer) becomes the master controller unit.

### 3.4.2 Topology

The HSCI slaves are connected—in series—to connector X500 of the main computer. Connector X502 is always the HSCI input to the HSCI slaves and X500 the HSCI output to the next HSCI slave.

The nonsynchronized second HSCI output X501 of the MC 6xxx can be used to connect a machine operating panel or a PLB 6001. However, do not connect any devices other than a machine operating panel or a PLB 6001 to X501 (no other or further HSCI components).

The HSCI components are connected via special shielded HSCI cables adapted for the increased demands of machine tool environments.

Terminating resistors are not required in the HSCI system.

The HSCI network is to be structured as an "open" ring (line structure). Connector X500 on the main computer is the beginning of the HSCI network. The HSCI connection is then led to X502 of the next HSCI participant (CC, UxC, PL or MB), where X500 again serves as the output for continuing the HSCI network to the next participant (X502). The last HSCI participant in the ring detects its position automatically (X500 remains open) and internally and independently closes the ring of the HSCI network.




#### Note

A star configuration of the HSCI network (e.g. by using a hub) is not possible.

### 3.4.3 HSCI interface

Face of the connector:



**X500**  
**X501**  
**X502**

Pin layout:

The order of the HSCI participants at X500 of the MC is freely selectable. Each HSCI participant is assigned its HSCI address based on its position in the HSCI chain, see page 170.

Pin layout of the HSCI cable:

ID 618893-xx			
Female	Color	Assignment	Female
1	White/Green	Data	1
2	Green	Data	2
3	White/Orange	Data	3
4	Not assigned	Not assigned	4
5	Not assigned	Not assigned	5
6	Orange	Data	6
7	Not assigned	Not assigned	7
8	Not assigned	Not assigned	8

## 3.5 MANUALplus 620 Connection Overview

### 3.5.1 MC 6110T main computer

MC 6110T, compact main computer, integrated screen and keyboard, HSCI interface			
Connection overview	Connector	Function	Page
	X3	Screen soft keys	
	X10	Feed-rate/spindle-speed override potentiometer	274
	X26	Ethernet data interface	265
	X27	RS-232-C/V.24 data interface	267
	X29	Reserved, do not assign	
	X101	Power supply for NC, 24 V–	205
	X116	Reserved, do not assign	
	X121	Profibus (only on MC 6120 with ID 680 391-xx)	237
	X125	SIK (System Identification Key)	
	X141 X142	USB interface	268
	X500	HSCI output 1 (synchronized)	171
	X501	HSCI output 2	171
	X600	CompactFlash Removable CFR	
	X601	Reserved, do not assign	
	⊕	Protective ground	



#### Warning

Do not engage or disengage any connecting elements while the unit is under power!



### 3.5.2 CC 6106

CC 6106, controller unit with 6 control loops and HSCI interface			
Pin layout	Connector	Function	Page
	X15 to X20	Speed encoder	246
	X51 to X56	PWM output	254
	X69	Supply bus	186
	X201 to X206	Position encoder	243
	X500	HSCI output	171
	X502	HSCI input	171
	–	SPI slot 1 (on bottom, reserved for expansion modules)	–
	–	SPI slot 2 (on bottom, reserved for expansion modules)	–
	X74	+ 5 V supply	187
	X7	Bridge for signal ground (= functional ground) (on bottom)	188
⊕	Protective ground	–	



#### Warning

Do not engage or disengage any connecting elements while the unit is under power!

### 3.5.3 CC 6108

CC 6108 controller unit with 8 control loops and HSCI interface

Pin layout	Connector	Function	Page
	X15A to X18A	Speed encoder Drive-control motherboard A	246
	X15B to X18B	Speed encoder Drive-control motherboard B	246
	X51A to X54A	PWM output Drive-control motherboard A	254
	X51B to X54B	PWM output Drive-control motherboard B	254
	X69A	Supply bus Drive-control motherboard A	186
	X69B	Supply bus Drive-control motherboard B	186
	X201A to X204A	Position encoder Drive-control motherboard A	243
	X201B to X204B	Position encoder Drive-control motherboard B	243
	X500A	HSCI output Drive-control motherboard A	171
	X502A	HSCI input Drive-control motherboard A	171
	X500B	HSCI output Drive-control motherboard B	171
	X502B	HSCI input Drive-control motherboard B	171
	X74	+ 5 V supply	187
	–	SPI slot 1 (on bottom, reserved for expansion mod- ules)	–
	–	SPI slot 2 (on bottom, reserved for expansion mod- ules)	–
	X7	Bridge for signal ground (= functional ground) (on bottom)	188
	⊕	Protective ground	–



#### Warning

Do not engage or disengage any connecting elements while the unit is under power!



### 3.5.4 CC 6110

CC 6110 controller unit with 10 control loops and HSCI interface			
Pin layout	Connector	Function	Page
	X15A to X18A	Speed encoder Drive-control motherboard A	246
	X15B to X20B	Speed encoder Drive-control motherboard B	246
	X51A to X54A	PWM output Drive-control motherboard A	254
	X51B to X56B	PWM output Drive-control motherboard B	254
	X69A	Supply bus Drive-control motherboard A	186
	X69B	Supply bus Drive-control motherboard B	186
	X201A to X204A	Position encoder Drive-control motherboard A	243
	X201B to X206B	Position encoder Drive-control motherboard B	243
	X500A	HSCI output Drive-control motherboard A	171
	X502A	HSCI input Drive-control motherboard A	171
	X500B	HSCI output Drive-control motherboard B	171
	X502B	HSCI input Drive-control motherboard B	171
	X74	+ 5 V supply	187
	–	SPI slot 1 (on bottom, reserved for expansion mod- ules)	–
	–	SPI slot 2 (on bottom, reserved for expansion mod- ules)	–
	X7	Bridge for signal ground (= functional ground) (on bottom)	188
⊕	Protective ground	–	



#### Warning

Do not engage or disengage any connecting elements while the unit is under power!

### 3.5.5 UEC 11x

UEC 11x: Compact controller unit with integrated inverter and PLC I/Os <b>(without functional safety (FS))</b>			
Pin layout	Connector	Function	Page
	X4, X5	PLC inputs	229
	X6	PLC outputs	232
	X15 to X19	Speed encoder	246
	X31	Supply voltage for UEC 11x (3 x 400 V ± 10 %)	207
	X71	Spindle safety relay (pulse inhibitor for spindle)	209
	X72	Axis safety relay (pulse inhibitor for axes)	209
	X80	Motor connection for spindle (24 A rated current at 3.3 kHz)	209
	X81	Motor connection axis 1 (6 A rated current at 3.3 kHz)	209
	X82	Motor connection axis 2 (6 A rated current at 3.3 kHz)	209
	X83	Motor connection axis 3 (9 A rated current at 3.3 kHz)	209
	X84	Motor connection axis 4 (6 A rated current at 3.3 kHz)	209
	X89	Braking resistor	210
	X90	24 V NC output / 3.5 A	210
	X112	TS touch trigger probe	260
	X113	TT touch-trigger probe	260
	X201 to X205	Position encoder	243
	X344	24 V supply for motor holding brake	210
	X394	Motor holding brake 1 to 4	210
	X500	HSCI output	171
	X502	HSCI input	171
⊕	Protective ground M5	–	




#### Warning


Do not engage or disengage any connecting elements while the unit is under power!




### 3.5.6 PLB 62xx


System module			
Pin layout	Connector	Function	Page
	X500	HSCI output	171
	X502	HSCI input	171
	X9	Safety-related PLC inputs/outputs	223
	X2	Reserved	–
	X3	+ 24 V NC, +24 V PLC power supply	216
	X112	TS or TT touch trigger probe	260
	X113	TS or TT touch trigger probe	260
	<b>Diagnosis:</b> For meanings of the LEDs, see page 217		


### 3.5.7 PLB 61xx

Expansion module			
Pin layout	Connector	Function	Page
	X500	HSCI output	171
	X502	HSCI input	171
	X2	Reserved	–
	X3	+ 24 V NC, +24 V PLC power supply	216
	<b>Diagnosis:</b> For meanings of the LEDs, see page 217		

### 3.5.8 PLD-H and PLA-H I/O modules

PLD-H 16-08-00			
Pin layout	Connector	Function	Page
	X11	PLC inputs, channel A	226
	X12	PLC inputs, channel A	226
	X21	PLC outputs, channel A	227
	<p><b>Diagnosis</b> (meanings of the LEDs):</p> <ul style="list-style-type: none"> <li>■ Red (X11/pin 1) status LED <ul style="list-style-type: none"> <li>• Flashes: status of I/O module OK</li> <li>• Continuously on or off: error on I/O module</li> </ul> </li> <li>■ Yellow (per output): Status of the output</li> </ul> <p><b>Error recognition:</b></p> <ul style="list-style-type: none"> <li>■ <b>Short circuit:</b> A short circuit is reported when a current <math>\geq 20</math> A flows for approximately 3 ms. Both the output-specific message and the group message are modal. After the short circuit has been removed, the PLC must reset the output before it can be activated again.</li> <li>■ <b>Open circuit operation (line break):</b> With load currents <math>\leq 300</math> mA, the PLD 16-8 reports a line breakage.</li> </ul>		

PLD-H 08-16-00			
Pin layout	Connector	Function	Page
	X11	PLC inputs, channel A	226
	X21	PLC outputs, channel A	227
	X22	PLC outputs, channel A	227
	<p><b>Diagnosis</b> (meanings of the LEDs):</p> <ul style="list-style-type: none"> <li>■ Red (X11/pin 1) status LED <ul style="list-style-type: none"> <li>• Flashes: status of I/O module OK</li> <li>• Continuously on or off: error on I/O module</li> </ul> </li> <li>■ Yellow (per output): Status of the output</li> </ul> <p><b>Error recognition:</b></p> <ul style="list-style-type: none"> <li>■ <b>Short circuit:</b> A short circuit is reported when a current <math>\geq 20</math> A flows for approximately 3 ms. Both the output-specific message and the group message are modal. After the short circuit has been removed, the PLC must reset the output before it can be activated again.</li> <li>■ <b>Open circuit operation (line break):</b> With load currents <math>\leq 300</math> mA, the PLD 08-16 reports a line breakage.</li> </ul>		

Pin layout	Connector	Function	Page
 <p>The diagram shows a vertical module with eight connector blocks. From top to bottom: X66 and X67 (each with 12 pins in a 2x6 grid), X46, X47, X48, and X49 (each with 12 pins in a 2x6 grid), X81 (with 12 pins in a 2x6 grid), and X82 (with 12 pins in a 2x6 grid). Lines connect the labels to their respective connector blocks.</p>	X66 to X67	±10 V analog outputs	236
	X46 to X49	± 10 V analog inputs	236
	X81 to X82	PT 100 analog inputs	236
	<p>A maximum of two PLA-H-08-04-04 I/O modules can be used per PLB 6xxx.</p>		

### 3.6 Supply Voltages in the HSCI System

Two separate 24 V power supplies must be used to supply the **+24 V power** to the individual control components in the HSCI system: +24 V NC and +24 V PLC.

HEIDENHAIN recommends using the DC-link buffered PSL 13x for supplying power to the HSCI components, see "PSL 13x low-voltage power supply unit" on page 189.

If you are using the UEC 11x, the main computer and other NC components are usually supplied via the 24 V power supply unit of the UEC (connection X90). A PSL 130 is not necessary if the total current consumption of the NC supply of all HSCI components does not exceed 3.5 A.

External PL assemblies with HSCI (e.g. the PL 6xxx or the PL in the UxC 11x) consist of an HSCI part (bus module and logic) and a PLC part (PLC input/output assemblies). Due to the topology of the HSCI system, the 24 V NC voltage supplied to the HSCI part must comply with the requirements for double basic insulation according to EN 50 178 (PELV). All other NC components with HSCI interface (e.g. main computer and machine operating panel) must also be supplied with 24 V NC voltage with double basic insulation. The reason for the double basic insulation is electrical safety, e.g. accessibility of connecting elements supplied with +24 V NC voltage.

PLC components, such as motor holding brakes and solenoid valves, usually have simple basic insulation. The PLC part must therefore be powered by another +24 V supply voltage. The two supply voltages must not be connected to each other. The double basic insulation of the NC power supply is removed through "mixed operation," i.e. +24 V NC voltage with double basic insulation is connected to PLC components with simple basic insulation. This is not permitted in an HSCI system.

The following components are powered by +24 V NC supply voltage:

- MC 6xxx main computer unit or industrial PC
- BF 2xx TFT visual display unit
- MB 6xx machine operating panel
- TE 6xx keyboard unit

Protective Extra Low Voltage (PELV) according to EN 61800-5-1 must be complied with by the power supply unit for the +24 V NC supply voltage.

The following components are powered by +24 V PLC supply voltage:

- PLB 6xxx input/output module
- UxC 1xx input/output module
- PLD-H digital plug-in module for PLB
- PLA-H analog plug-in module for PLB
- Motor holding brakes, further components in the PLC circuit



#### Note

HEIDENHAIN recommends also using a power supply unit complying with Protective Extra Low Voltage (PELV) according to EN 61800-5-1 for the +24 V PLC power supply, although the circuit has only ELV status. In addition, HEIDENHAIN recommends connecting the 0 V PLC supply voltage to protective earth (PE). This is not strictly required according to the VDE standards. However, it provides additional safety in the event of insulation failure in the PLC circuit.





The CC 6xxx controller unit is supplied by the X69 supply bus of the HEIDENHAIN supply module and X74 (+5 V).



#### Danger

- The +24 V NC supply voltage (PELV system according to EN 50178) is required to be safely separated voltage for the entire HSCI system and must not be connected to the +24 V PLC supply voltage (ELV) of the system.
- Protective Extra Low Voltage (PELV) according to EN 61800-5-1 must be complied with for the +24 V NC power supply of the machine.
- VDE 0160/EN 50178 is to be observed for the +24 V NC voltage lines and cable routing. Lines or cables for safely separated electric circuits thus must have double or reinforced insulation between the wire and the surface if they are routed without spatial separation from other cables and lines.
- Due to the structure of the PLC area in the HSCI system, the +24 V PLC supply voltage is a voltage with basic insulation (ELV as per EN 61800-5-1).
- The 0 V signal of the NC power supply must be connected by a 6 mm<sup>2</sup> conductor to the machine's central functional ground (B).
- The 0 V signal of the PLC power supply must be connected by a 6 mm<sup>2</sup> conductor to the machine's central protective ground (PE).

The signal ground is used for functional-equipotential bonding. The signal-ground connections (B) of the HEIDENHAIN control components must be connected to the central functional ground of the machine (minimum cross section 6 mm<sup>2</sup>). The 0 V PLC and all of the protective-ground connections of the HEIDENHAIN control components must be connected separately from the signal-ground connections to the central protective ground (PE) of the machine (minimum cross section 6 mm<sup>2</sup>). The central signal ground and the central protective ground must be connected with each other for the machine! The cross section of this conductor must be at least as large as the largest cross section of the conductors for connecting the components used to protective ground or functional ground.



#### Note

The line cross section of the +24 V NC power supply must be designed for the power consumption of the connected devices. EN 60204-1 lists the protection provided by line cross sections.

**Minimum cross section of the +24 V NC power supply: 0.75 mm<sup>2</sup>**



#### Note

The motor brakes are controlled by 24 V PLC voltage. The trigger circuit and the brake itself are usually separated from the line power only by basic insulation according to EN 618100-5-1 (also EN 50178). Also, other add-on devices that are controlled by PLC circuits usually have only basic insulation from the line power.

### 3.6.1 Current consumption of the HSCI components

The following table shows the current consumption of the HSCI components at 24 V DC:

HSCI component		Current consumption at 24 V DC
Main computer	MC 6240 / 6241	1.7 A
	MC 6341	1.8 A
Machine operating panel	PLB 6001	0.2 A (without hand-wheel)
	MB 6x0	0.2 A (without hand-wheel)
Keyboard	TE 6xx	0.2 A (without hand-wheel)
PLC inputs/outputs	PLB 62xx	0.3 A (without touch probe)
	PLB 62xx	0.2 A
	PLD	0.05 A
	PLA	0.1 A
Handwheels	HR 410	0.05 A
	HR 130	0.05 A
	HR 110 + 3 x HR 150	0.2 A
Touch probes	See specifications of the touch probes	



### 3.6.2 X90: +24 V NC output of the UxC 11x (FS)

#### Assignment

Connecting terminal X90	Assignment
+	+24 V (max. 3.5 A)
-	0 V

#### Load capacity

Device	Load capacity of 24 V NC supply (X90)
UEC 11x (FS)	3.5 A

#### Current consumption of the HSCI components

Device	Current consumption of the 24 V NC supply
MC 6110T	1.5 A
MB 620T	1.0 A
PL 62xx (incl. TS and TT)	0.5 A
PL 61xx	0.2 A

Example: MANUALplus 620 configuration with UEC 11x

Device	Current consumption 24 V NC
MC 6110T	1.5 A
MB 620T	1.0 A
PL 61xx	0.2 A
<b>Total</b>	<b>2.7 A &lt; 3.5 A</b>

A PSL 130 unit is not needed for this application. The +24 V NC supply of the UEC 11x (X90) suffices for the connected components.

### 3.6.3 X101: NC power supply

The MC main computer is supplied with +24 V NC (control voltage) of the machine, for example by the PSL 130, see "PSL 13x low-voltage power supply unit" on page 189 or by the integrated 24 V power supply unit of the UEC 11x (FS).

Protective Extra Low Voltage (PELV) according to EN 61800-5-1 must be complied with for the +24 V NC power supply.

Power supply: Minimum absolute value: +20.4 V–  
Maximum absolute value +28.8 V–

Pin layout:

Connecting terminals at X101	Assignment	Fuse
+	+24 V NC	7 A safety fuse integrated in the MC
–	0 V NC	



#### Warning

Ensure that either the DC-link power supply unit is switched off or the line power is disconnected before connecting the power cables!

Power consumption:

Device	Power consumption
MC 6110T	35 W



#### Note

If USB components that are connected to X141/X142 require more than 0.5 A, a separate power supply becomes necessary for these components. One possibility is the USB hub from HEIDENHAIN (582 884-02).

### 3.6.4 Power supply of the CC 61xx

The CC 61xx controller unit is supplied with a power of **+5 V** by the power supply units via supply bus X69 and connector X74, see page 186.

The control monitors the 5 V supply voltage. If it drops below 4.75 V, the error message **5 V power supply too low** appears. If it rises above 5.4 V, **5 V power supply too high** is indicated.

**For information on the power supply units, refer to the "Inverter Systems and Motors" Technical Manual.**

Device	Load capacity
UVR 1xxD, UE 2xxD	20.00 A via X74 10.00 A via X69

Device	Current consumption of the 5 V supply
CC 6106/6 control loops	3.80 A Consisting of: 1 drive-control motherboard: 2.00 A 2 drive-control expansion boards: 0.90 A each
CC 6108/8 control loops	5.80 A Consisting of: 2 drive-control motherboards: 2.00 A 2 drive-control expansion boards: 0.90 A each
CC 6110/10 control loops	6.70 A Consisting of: 2 drive-control motherboards: 2.00 A 3 drive-control expansion boards: 0.90 A each
UxC drive control board	2.50 A
LS, LB	0.15 A
ERN, ROD, RON	0.20 A
Absolute rotary encoders	0.25 A (+0.085 A with line-drop compensator) <sup>a</sup>
Absolute angle encoders	0.35 A (+0.085 A with line-drop compensator) <sup>a</sup>
LC	0.30 A (+0.085 A with line-drop compensator) <sup>a</sup>

- a. For cable lengths > 10 m between the logic unit and the encoders with EnDat interfaces, a line drop compensator is required (efficiency = 75 %).

**X69: CC-supply  
voltage and control  
signals**

Pin layout:

50-pin ribbon connector	Assignment	50-pin ribbon connector	Assignment
1a to 5b	+5 V	16b	GND
6a to 7b	+12 V	17a	RDY.PS
8a	+5 V (low-voltage separation)	17b	GND
8b	0 V (low-voltage separation)	18a	ERR.ILEAK
9a	+15 V	18b	GND
9b	-15 V	19a	PF.PS.AC (only UV 120, UV 140, UV 150, UR 2xx)
10a	UZAN	19b	GND
10b	0 V	20a	Do not assign
11a	IZAN	20b	GND
11b	0 V	21a	Do not assign
12a	RES.PS	21b	GND
12b	0 V	22a	Do not assign
13a	PF.PS.ZK	22b	GND
13b	GND	23a	Reserved (SDA)
14a	ERR.UZ.GR	23b	GND
14b	GND	24a	Reserved (SLC)
15a	ERR.IZ.GR	24b	GND
15b	GND	25a	RES.LE
16a	ERR.TMP	25b	GND



## X74: +5 V power supply for CC

Maximum wire cross section: 2.5 mm<sup>2</sup>

Connecting terminal at X74	Assignment
1	+5 V from the UV supply module (X74)
2	0 V



### Warning

The +5 V supply via X74 from the supply module is mandatory for the CC 61xx!

If the system includes several CCs 61xx that are connected to the same supply bus (X69) via a UV supply module, it is usually sufficient to connect only the last CC 61xx (usually the unit at the extreme right) to the UV via X74. The other CC 61xx units are then supplied via supply bus X69.

If several CC 61xx units are supplied by more than one UV supply module, which means that they are connected to different supply bus systems (X69), then the last CC 61xx (usually the unit at the extreme right) of the respective supply bus must also be supplied with the additional +5 V of the UV via X74.

Please check whether the +5 V supply of all drive control motherboards is ensured when initially configuring the control. The voltage is displayed in the DriveDiag diagnosis tool. On the "Voltages and currents" tab for the drive control boards, you will find the +5 V supply voltage. The value of this voltage should not be below +4.90 V. If it is, further CC 61xx units must also be powered with +5 V via X74.

**X7: Bridge for  
signal ground  
(= functional  
ground)**

<b>Connecting terminal X7</b>	<b>Assignment</b>
1	Connection for signal ground (= functional ground)
2	Connection on housing

In shipping condition of the CC 61xx, the signal ground (pin 1) is connected to the housing (pin 2) over an external bridge. If only one CC 61xx is in the system, it ensures the correct signal-ground connection of the CC.



If there are two or more CC 61xx units in the system that are connected over a UV power module to the same supply bus (X69), this external signal-ground bridge can stay connected with only one CC 61xx. Disengage these bridges on all other CCs in order to prevent ground loops.

If there are two or more CC 61xx units powered over more than one UV power module and are therefore connected with different supply bus systems (X69), then the external signal-ground bridge is to be connected with only one CC 61xx of the respective supply bus. In order to prevent ground loops, disengage this bridge for the signal ground on all other CC 61xx units that are on a common supply bus (X69).





### 3.6.5 PSL 13x low-voltage power supply unit

PSL 130 pin layout	Connector	Function
	Conductor bar	Connection of DC-link voltage $U_z$
	B – Signal ground (= functional ground)	Signal ground (0 V signal of the +24 V NC signal connected internally to protective ground)
	X90	Output for supply voltages: <ul style="list-style-type: none"> <li>■ Terminal 1: +24 V NC</li> <li>■ Terminal 2: 0 V NC (ground +24 V NC)</li> <li>■ Terminal 3: + 24 V– PLC</li> <li>■ Terminal 4: 0 V PLC (ground +24 V– PLC)</li> </ul>
	X33	Input voltages L1, L2
		Protective ground



#### Warning

Do not engage or disengage any connecting elements while the unit is under power!

PSL 135 pin layout	Connector	Function
<p>The diagram shows the PSL 135 pin layout. At the top is connector X31 with terminals for L1/L2 and +U<sub>DC</sub> / -U<sub>DC</sub>. Below it is connector X74 with +5V and 0V terminals. Further down is connector X69. At the bottom is connector X90 with two 24V terminals and two 0V terminals. A protective ground symbol is shown at the very bottom.</p>	X31	Input voltages L1, L2 and connection of the DC link voltage U <sub>z</sub>
	B – Signal ground (= functional ground)	Signal ground (0 V signal of the +24 V NC signal connected internally to protective ground)
	X74	Output for supply voltages: <ul style="list-style-type: none"> <li>■ Terminal 1: +5 V</li> <li>■ Terminal 2: 0 V</li> </ul>
	X69	Power supply and control signals for CC 61xx (for X69 on CC)
	X90	Output for supply voltages: <ul style="list-style-type: none"> <li>■ Terminal 1: +24 V NC</li> <li>■ Terminal 2: 0 V NC (ground +24 V NC)</li> <li>■ Terminal 3: + 24 V– PLC</li> <li>■ Terminal 4: 0 V PLC (ground +24 V– PLC)</li> </ul>
		Protective ground



### Warning

Do not engage or disengage any connecting elements while the unit is under power!

## General information

The two 24 V output voltages of the PSL 13x are generated by two separate power supplies. The + 24 V NC and + 24 V PLC voltages are separated from each other by basic insulation and fulfill the requirements of EN 61800-5-1 for low voltage electrical separation.

The 0 V line of the NC supply voltage must be connected separately to the central grounding point of the machine (= central functional ground). The 0 V NC voltage in the PSL 130 is therefore connected internally with the outward conductor to signal ground (= central functional ground). An outward connector to protective ground will not be available for the 0 V PLC voltage until variant 03. With the variants up to and including variant 02, the 0 V PLC must be tapped at terminal X90.4 and led to the central protective ground. In variant 03 and later variants, an outward connector at the PSL will be available for connecting the 0 V PLC voltage, too.

With the PSL 135, the connections to the central functional ground and protective ground must be realized over the 0 V connections. The respective outward connections will not be available until the next hardware variants of the PSL 135.

The +24 V PLC voltage is also electrically separated by the power supply unit. However, because of the connection to the PLC part of the HSCI system this is a supply voltage with basic insulation. This voltage must not be linked with other voltages.

The +5 V NC supply voltage for X74 of the PSL 135 is taken from the +24 V NC supply voltage and is therefore galvanically connected with it.



### Danger

- For the entire HSCI system, the +24 V NC power supply voltage is required to be safely separated voltage and must not be connected with the +24 V PLC voltage of the system.
- Protective Extra Low Voltage (PELV) according to EN 61800-5-1 must be complied with for the +24 V NC power supply of the machine.
- The 0 V signal of the PLC power supply must be connected by a 6 mm<sup>2</sup> conductor to the machine's central protective ground (PE).
- Refer to your control's grounding diagram!

## Specifications

Specifications	PSL 130	PSL 135
Power supplies: at X33 (L1, L2)	400 V~ ± 10 % 50 Hz	
Power supplies: DC-link power bar or X31	400 V- to 750 V-	
Protection	Page 194, 195	
Output voltages: Accuracy of the +24 V NC Accuracy of the +24 V PLC	+24 V NC: ± 5 % +24 V PLC: Variations depending on the load, between 20 V and 28 V (adjustment to 25.0 V)	+24 V NC: ± 5 % +24 V PLC: Variations depending on the load, between 20 V and 28 V (adjustment to 25.0 V)
Accuracy of the +5 V NC	---	+5 V NC: ± 5 % (power supply unit is adjusted to 5.2 V)
Output power	24 V NC output: max. 500 W 24 V PLC output: max. 500 W  Total power output: max. 750 W	24 V NC output: max. 350 W 24 V PLC output: max. 500 W 5 V NC output: max. 100 W +/-15 V at X69: max. 50 W Total power output: max. 750 W
Output current 24 V NC	Max. 20 A	Max. 14.5 A
24 V PLC output current	Max. 20 A	Max. 20 A
5 V NC output current	---	Max. 20 A
24 V output current total	Continuous load: max. 31 A Max. load time 1 s: max. 41 A Max. load time 0.1 s: max. 46 A  The outputs are short-circuit-proof and switch off automatically when overloaded.	
5 V output current	---	Max. 20 A  The outputs are short-circuit proof and switch off automatically when overloaded.
Power consumption	Max. 1000 W	
Degree of protection	IP 20	
Module width	50 mm	
Weight	2.1 kg	3.2 kg
ID	575 047-xx	627 032-xx



It is possible to connect both 24 V output voltages of the PSL 13x in parallel. In this way the PSL supplies only a maximum output power of 750 W, which fulfills the requirements for PELV according to EN 61800-5-1. However, because of the parallel circuit, a PSL 130 supplies only an output voltage of +24 V, which can then be used as desired for the 24 V NC voltage or the 24 V PLC voltage. An additional PSL 13x can be used for the respective other voltage.



#### Danger

When using it to supply the PLC, the common 0 V signal must be connected by a 6 mm<sup>2</sup> conductor to the machine's central ground.

### U<sub>Z</sub> DC-link current

Since the power to the PSL 130 is supplied through the DC-link, the voltage fed into the DC-link by the motors that are still running can be used during line voltage failures. The PSL 130 uses the supply voltage buffered via the DC-link to maintain the power supply for the control until the non-HEIDENHAIN inverter system has been shut down properly by the control.

If the PSL is connected over litz wires instead of the DC-link conductor bars, a wire cross section of at least 1.5 mm<sup>2</sup> must be used. Fuses or a motor protection switch of 6.3 A or greater for conductor protection must be selected depending on the wire cross section used. The PSL 130 is protected internally by a fuse (4 A).

Connecting terminals	Assignment
-U <sub>Z</sub>	DC-link voltage -
+U <sub>Z</sub>	DC-link voltage +

HEIDENHAIN offers insulated conductor bars if you want to position the PSL 130 next to the left of the UVR inverter and connect it to the DC-link via conductor bars. Two conductor bars are required for each connection. The conductor bars are shipped in packaging units. Also, this position makes it possible to connect the grounding conductor of the PSL via conductor bars. Therefore, angulated non-insulated conductor bars are also included in this packaging unit. This makes it possible to continue using the straight conductor bar included with the UVR for the grounding conductor connection from the UVR to the inverters via the right side.

Length	For connection to	ID (conductor bar set)
150 mm	UVR 120D/130D	687 669-01
200 mm	UVR 140D/150D	687 670-01
250 mm	UVR 160D/160DW	687 671-01




#### Note

Tightening torque for the screws of the DC-link conductor bars = 3.5 Nm.

### X33: Input voltage of the PSL 130

Supply voltage: 400 V  $\pm$  10 %

Connection:

Connecting terminal	Assignment
L1	Phase 1 / 400 V~ $\pm$ 10 % / 50 Hz to 60 Hz
L2	Phase 2 / 400 V~ $\pm$ 10 % / 50 Hz to 60 Hz
	Protective ground (YL/GN), $\geq 10 \text{ mm}^2$
	<b>Connecting lead:</b> Wire cross section: at least $1.5 \text{ mm}^2$ (AWG 16) <b>Conductor protection (back-up fuse):</b> Fuses or a motor protection switch of 6.3 A or greater depending on the wire cross section used. <b>Line fuse:</b> Internal protection of the PSL (4 A).
<b>Tightening torque:</b> for the connecting terminals 0.5 to 0.6 Nm <b>Grounding terminal:</b> $\geq 10 \text{ mm}^2$ (AWG 6) <b>Strain relief:</b> Ensure that the connecting cables are not subject to excessive strain.	

Through the connection to the 400 V AC line voltage (L1, L2) via X33, the output voltages of the PSL 130 are available as soon as the machine's main switch has been turned on. The connection of L1 and L2 is absolutely essential for booting the control.

Since the power to the PSL 130 is supplied through the DC-link, the voltage fed into the DC-link by the motors that are still running can be used during line voltage failures. The PSL 130 uses the supply voltage buffered via the DC-link to maintain the power supply for the control until the inverter system has been shut down properly by the control.



#### Note

HEIDENHAIN recommends connecting the PSL 130 power supply unit to the  $U_z$  DC-link voltage and the 400 V supply voltage (X33).

Operation of the PSL 130 without a connection to the  $U_z$  dc-link voltage is possible, e.g. as PLC supply in combination with the UEC 11x.

However, be aware that operation with the  $U_z$  DC-link voltage but without the power connection (L1 and L2) at X33 is not possible. The line voltage is necessary for the PSL 130 to start correctly.



### X31: Input voltage of the PSL 135

Supply voltage: 400 V  $\pm$  10 % or 400 V– to 750 V–

Connection:

Connecting terminal	Assignment
L1	Phase 1 / 400 V~ $\pm$ 10 % / 50 Hz to 60 Hz
L2	Phase 2 / 400 V~ $\pm$ 10 % / 50 Hz to 60 Hz
+UDC	400 V– to 750 V–
–UDC	0 V–
	Protective ground (YL/GN), $\geq 10 \text{ mm}^2$
	<b>Connecting lead:</b> Wire cross section: at least $1.5 \text{ mm}^2$ (AWG 16) <b>Conductor protection (back-up fuse):</b> Fuses or a motor protection switch of 6.3 A or greater depending on the wire cross section used. <b>Line fuse:</b> Internal protection of the PSL (4 A).
<b>Tightening torque:</b> for the connecting terminals 0.5 to 0.6 Nm <b>Grounding terminal:</b> $\geq 10 \text{ mm}^2$ (AWG 6) <b>Strain relief:</b> Ensure that the connecting cables are not subject to excessive strain.	

Through the connection to 400 V (L1, L2) via X31, the output voltages of the PSL 135 are available as soon as the machine's main switch has been turned on. These voltages are indispensable to be able to boot the control.

Since the power to the PSL 135 is supplied through the DC-link, the voltage fed into the DC-link by the motors that are still running can be used during line voltage failures. The PSL 135 uses the supply voltage buffered via the DC-link to maintain the power supply for the control until the inverter system has been shut down properly by the control.



#### Note

If the power supply is other than 400 V, an autotransformer is required. Otherwise, an isolating transformer is not necessary when using a PSL 135.



#### Note

HEIDENHAIN recommends connecting the PSL 135 power supply unit to the Uz DC-link voltage and the 400 V supply voltage (X31).

### X90: Output voltage of the PSL 13x

Output voltages: + 24 V (2 x)

Connection:



#### Note

The interface complies with the requirements of EN 61800-5-1 for "protective extra-low voltage" (PELV).

Connecting terminal	Assignment
Terminal 1 (top)	+ 24 V NC
Terminal 2	0 V NC (ground + 24 V NC)
Terminal 3	+ 24 V PLC
Terminal 4 (bottom)	0 V PLC (ground + 24 V PLC)

#### Tightening torque:

for the connecting terminals  
0.5 to 0.6 Nm

#### Strain relief:

Ensure that the connecting cables are not subject to excessive strain.

### X74: Output voltage of the PSL 135

Output voltages: + 5 V

Connection:



#### Note

The interface complies with the requirements of EN 61800-5-1 for "protective extra-low voltage" (PELV).

Connecting terminal	Assignment
Terminal 1 (top)	+ 5 V NC
Terminal 2	0 V NC (also ground + 24 V NC)

#### Tightening torque:

for the connecting terminals  
0.5 to 0.6 Nm

#### Strain relief:

Ensure that the connecting cables are not subject to excessive strain.

**Maximum wire cross section:** 4 mm<sup>2</sup>

### Signal ground (= functional ground)

Connections for signal ground, which are connected internally in the PSL 13x to 0 V NC and 0 V PLC signals.

Connection:




#### Note

Conductor cross section of at least 6 mm<sup>2</sup> for connecting to signal ground (= central functional ground).



## Power connection



The 0 V line of the NC supply voltage must be connected separately to the central grounding point of the machine (= central functional ground). The 0 V NC voltage of the PSL 130 is therefore connected internally with the outward conductor to signal ground (= central functional ground).

An outward connector to protective ground will not be available for the 0 V PLC voltage until variant 03. With the variants up to and including variant 02, the 0 V PLC must be tapped at terminal X90.4 and led to the central protective ground. In variant 03 and later variants, an outward connector at the PSL will be available for connecting the 0 V PLC voltage, too.

With the PSL 135, the connections to the central functional ground and protective ground must be realized over the 0 V connections. The respective outward connections will not be available until later hardware variants of the PSL 135.

If a suitable type of network (see Technical Manuals for Inverters and Motors) is used, the inverter system from HEIDENHAIN and the PSL 13x are connected to the main power line without an additional isolating transformer.

If an isolating transformer is required for the inverter system due to the type of network, then the PSL 13x must also be powered via the isolating transformer of the inverter system.

If the line voltage is 3 x 480 V~ and inverters suitable for this voltage (UE compact inverters) are used, then the PSL 13x must be powered via an additional autotransformer. The required output voltage of the autotransformer is 400 V~ +0 % / -15 %.

## Conducted interference

To suppress conducted interference, the conductors for the 24 NC and 24 V PLC output voltages (X90 of the PSL) must be passed through a toroidal core (ID 309 694-07, inside diameter 14 mm). There are different ways to do this depending on the PSL variant:

■ **Variants 02 and 03 of the PSL 130, variant 01 of the PSL 135**

The toroidal core is included with the PSL. The output lines of connector X90 (24 V NC, 24 V PLC) must be passed through the toroidal core in order to suppress conducted interference. The lines must not be wound around the toroidal core, however.

■ **Variant 02 of the PSL 135, variant 04 of the PSL 130**

The toroidal core is integrated in the unit. No further external measures for noise suppression must be taken.

## 3.7 MS 110 / MS 111 Installation Kit for Double-Row Configuration

### 3.7.1 General information

Sometimes limited space prevents the control and inverter system from being mounted in the same row in a machine's electrical cabinet, meaning that they must be mounted in two separate rows. In other cases the design calls for a second electrical cabinet to house the inverter system. This means that the distribution and arrangement of the components can be very different from case to case.

In order to establish an electrical connection (immune to noise) between the components of the inverter system, the MS 1xx installation kits are needed. The ribbon cables (unit bus, PWM lines, supply bus) from the other components are connected to the MS mounting cases, and shielded round cables of the appropriate lengths connect the MS mounting cases with each other.

In some cases, in order to ensure that the power supply for the fans of the inverters is maintained under all circumstances, it is also necessary to feed 24 V from an external power supply unit to the unit bus (since this is handled by the unit bus).

In most cases the additional 24 V are not needed, since the UVR 1xxD provides enough current for the fans.

If this is the case, and a double-row configuration is used, then two MS 110 mounting cases are necessary (see basic circuit diagram). For the current consumption of the fans, refer to the "Inverter Systems and Motors" Technical Manual. Based on these values you can calculate whether feeding in the additional 24 V is necessary.

For inverter systems with many powerful UM 1xxD power modules, it might be the case that the current provided by the UV(R)1xx power supply unit for the fans of the UMs does not suffice to guarantee safe and reliable operation of the fans. The sum of the currents must not exceed the maximum current provided by the UV(R).

If it is exceeded, then an MS111 must be used in the inverter row where the current consumption is very high.

With the MS 111, the 24 V from an external 24 V power supply unit are fed to the unit bus X79 in order to ensure reliable operation of the fans, and therefore the reliable cooling of the inverters. The 24 V supply that is routed via X79C is interrupted internally at the MS 111.



#### Note

With the MS 111, an additional power supply unit must be used for the 24 V power supply of the fans.

### 3.7.2 Double-row configuration


Components and cables for double-row configuration:

Component/Cable	ID
Unit bus cable (shielded, round) with 37-pin D-sub at both ends; max. length: 3 m	ID 664 023-xx
PWM cable (round) with ribbon connector at both ends; max. length: 5 m	ID 664 023-xx
Supply bus cable (round) with ribbon connector at both ends; max. length: 5 m (only necessary if the UV(R) 1xxD is not in the same row as the CC/MC)	ID 361 508-xx
Wire for DC-link (16 mm <sup>2</sup> , shielded, color: red); max. length: 3 m	ID 655 440-xx
Wire for DC-link (16 mm <sup>2</sup> , shielded, color: blue); max. length: 3 m	ID 655 438-xx



When using a double-row configuration, please keep the following in mind:

- The litz wires used for the DC-link connection of the power modules in the "second row" must not be longer than 3 m.
- Litz wires with 16 mm<sup>2</sup> cross section make a DC-link current of approx. 67 A possible. In a regenerative system, this results in approx. 35 kW of continuous power for the system connected by these wires.
- In a nonregenerative system the resulting maximum power is approx. 25 kW.
- Use fast-acting semiconductor fuses for protection of the UV(R) 1xxD on the primary side.
- The length of the unit bus ribbon cable must not exceed 1 m!
- If necessary, place the MS 110 or MS 111 in the "second row" in the center of the UMs.
- When calculating the length of the ribbon cables, make sure to include the module width of the MS 110 or MS 111.

Basic circuit diagram for double-row configuration:



### 3.7.3 Connection overview



MS 110 pin layout	Connector	Function	Page
	DC-link conductor bar	400 V– to 750 V–	–
	Screw fastening	For fastening the PWM round cable shields	–
	X79	Unit bus (connection for ribbon cable)	204
	X79C	Unit bus (connection for round cable)	205
		Protective ground	



#### Warning

Do not engage or disengage any connecting elements while the unit is under power!



MS 111 pin layout	Connector	Function	Page
	DC-link conductor bar	400 V– to 750 V–	–
	Screw fastening	For fastening the PWM round cable shields	–
	X79	Unit bus (connection for ribbon cable)	204
	X79C	Unit bus (connection for round cable)	205
	LED	+24 V supply for fans is available	
	X101	Connection for +24 V supply for fans	205
		Protective ground	



#### Warning

Do not engage or disengage any connecting elements while the unit is under power!

40-pin ribbon connector	Assignment
1a to 3b	0 V *1
4a	+24 V *1
4b	+24 V *1
5a	+15 V *1
5b	+24 V *1
6a	+15 V *1
6b	+15 V *1
7a to 8b	Do not assign
9a	Reserved (SDA)
9b	Do not assign
10a	Reserved (SCL)
10b	$\overline{\text{ERR.TEMP}}$
11a	$\overline{\text{PF.PS}}$
11b	0 V
12a	$\overline{\text{RES.PS}}$
12b	0 V
13a	$\overline{\text{PWR.OFF}}$
13b	0 V
14a	5 V FS (spindle enable)
14b	0 V
15a	5 V FA (axis enable)
15b to 16b	0 V
17a and 17b	-15 V
18a and 18b	+15 V
19a to 20b	+5 V

These voltages must not be linked with other voltages (only basic insulation)!



#### Danger

The interface complies with the requirements of EN 61800-5-1 for low voltage electrical separation (except for 1a to 6b).



**X79C: Unit bus**

Connection:

Round cable connector 37-pin	Assignment
17 -19, 35 -37	0 V *1
16	+24 V *1
34	+24 V *1
15	+15 V *1
33	+24 V *1
14	+15 V *1
32	+15 V *1
12, 13	Do not assign
11	Reserved (SDA)
30, 31	Do not assign
29	Reserved (SCL)
10	ERR.TEMP
28	PF.PS
9	0 V
27	RES.PS
0	0 V
26	PWR.OFF
25	0 V
7	5 V FS (spindle enable)
6	5 V FA (axis enable)
5, 23, 24	0 V
4,22	-15 V
3,21	+15 V
1,2,20	+5 V

These voltages must not be linked with other voltages (only basic insulation)!

**Danger**

The interface complies with the requirements of EN 61800-5-1 for low voltage electrical separation (except for 1a to 6b).

**X101: Power supply**

Pin layout:

Connecting terminals	Assignment
+	+24 V NC
-	0 V NC

## 3.8 UxC 11x (FS): Power Supply and Motor Connection

### 3.8.1 UEC 11x (FS)

#### General information

Number of available control loops

- UEC 111 (FS): 4 control loops
- UEC 112 (FS): 5 control loops

Specifications	UEC 112 (FS)			UEC 111 (FS)		
	3 axes	1 axis	Spindle	2 axes	1 axis	Spindle
Power supply	3 x 400 V to 480 V ~ ±10 % (50 Hz to 60 Hz)					
DC-link voltage	565 V– (with supply voltage of 400 V)					
Power loss	Approx. 450 W			Approx. 450 W		
Rated current at a PWM frequency of 3333 Hz	6.0 A	9.0 A	24.0 A	6.0 A	9.0 A	24.0 A
4000 Hz	5.5 A	8.3 A	22.0 A	5.5 A	8.3 A	22.0 A
5000 Hz	5.0 A	7.5 A	20.0 A	5.0 A	7.5 A	20.0 A
6666 Hz	4.2 A	6.3 A	16.8 A	4.2 A	6.3 A	16.8 A
8000 Hz	3.6 A	5.5 A	14.6 A	3.6 A	5.5 A	14.6 A
10000 Hz	3.0 A	3.0 A	12.2 A	3.0 A	3.0 A	12.2 A
Peak power 6-40 % <sup>a</sup>	18 kW			18 kW		
DC-link power	14 kW			14 kW		
Maximum current <sup>b</sup> at a PWM frequency of 3333 Hz	12.0 A	18.0 A	36.0 A	12.0 A	18.0 A	36.0 A
4000 Hz	11.0 A	16.5 A	33.0 A	11.0 A	16.5 A	33.0 A
5000 Hz	10.0 A	15.0 A	30.0 A	10.0 A	15.0 A	30.0 A
6666 Hz	8.4 A	12.6 A	25.2 A	8.4 A	12.6 A	25.2 A
8000 Hz	7.3 A	11.0 A	21.9 A	7.3 A	11.0 A	21.9 A
10000 Hz	6.0 A	6.0 A	18.3 A	6.0 A	6.0 A	18.3 A
Integral braking resistor						
Continuous power	2.1 kW			2.1 kW		
Peak power <sup>c</sup>	27 kW			27 kW		
Resistance	18 ohms			18 ohms		
Load capacity +24 V NC	3.5 A			3.5 A		
Weight	Approx. 20 kg			Approx. 20 kg		

- a. Spindle: 40 % cyclic duration factor for duty cycle time of 10 minutes (S6-40 %)
- b. Axis: 0.2 s cyclic duration factor for duty cycle time of 10 s with 70 % rated current preload  
Spindle: 10 s cyclic duration factor for duty cycle time of 60 s with 70 % rated current preload
- c. 1.5 % cyclic duration factor for duration of 120 s



#### Note

Under some circumstances, certain high-speed spindles cannot be satisfactorily controlled with 3.3 kHz PWM frequency. In this case, increase the PWM frequency of the spindle. The spindle (X80) and the 1st axis (X81) share a controller group. You therefore have to set the same PWM frequency for X80 and X81. (Note the D rating!)

For more information about the controller groups of the UEC 11x (FS), see "Configuring the Controller Unit and Drive Motors" on page 1044.

### **X31: UEC power supply**



#### **Danger**

Danger of electrical shock!  
The UEC 11x controller unit must be opened only by HEIDENHAIN service engineers.  
Do not engage or disengage any terminals while they are under power.



#### **Note**

EN 61800-5-1 requires a non-detachable connection to the line power supply.



#### **Note**

If the power supply is other than 400 V/ 480 V, an autotransformer is required. It must comply at least with the connection specifications of the UEC 11x.

With a power supply of 400 V, the inverter voltage  $U_z$  is 565 V–, and with a power supply of 480 V it is 678 V–.

For information on the power connection, refer to the Technical Manual for "Inverter Systems and Motors."

Connecting terminals	UEC 111, UEC 112
<b>Operation on 400 V~</b>	
L1	400 V~ ± 10 % 50 Hz to 60 Hz
L2	
L3	
	Cable / single conductor (HT wire): 6 mm <sup>2</sup> (AWG 10) Single conductor H07 V2-K: 4 mm <sup>2</sup> (AWG 10) Line fuse: 25 A (gR) Siemens Sitor type Grounding terminal: ≥ 10 mm <sup>2</sup> (AWG 6)
	Tightening torque for connecting terminals: 0.7 Nm (6.5 to 7 psi)
<b>Operation on 480 V~</b>	
L1	480 V~ ± 10 % 50 Hz to 60 Hz
L2	
L3	
	Cable / single conductor (HT wire): 6 mm <sup>2</sup> (AWG 10) Single conductor H07 V2-K: 4 mm <sup>2</sup> (AWG 10) Line fuse: 25 A (gR) Siemens Sitor type Grounding terminal: ≥ 10 mm <sup>2</sup> (AWG 6)
	Tightening torque for connecting terminals: 0.7 Nm (6.5 to 7 psi)



**X80: Spindle motor**  
**X81: Axis motor 1**  
**X82: Axis motor 2**  
**X83: Axis motor 3**  
**X84: Axis motor 4**

Connection:

Connecting terminals	Assignment
U	Motor connection U
V	Motor connection V
W	Motor connection W

For information on synchronous motors, asynchronous motors and power cables, refer to the Technical Manual on Inverter Systems and Motors, "Motors for Axis and Spindle Drives" chapter.

**X71: Safety relay for spindle**  
**X72: Safety relay for axes**

For information on the wiring and function, see the Basic Circuit Diagram for your control. Registered customers can download the Basic Circuit Diagram from the HEIDENHAIN FileBase on the Internet.

Connecting terminals X71 to X72	Assignment
1	+24 V pulse release output (max. 250 mA) for control of the relays at X71.3 and X72.3 for drive enabling (Axis ON, Spindle ON).
2	0 V for pulse release output
3	+24 V pulse release input for Axis ON, Spindle ON
4	Do not assign
5	Do not assign
6 <sup>a</sup>	Normally closed contact (OE1, OE1A or OE1S)
7 <sup>a</sup>	Normally closed contact (OE2, OE2A or OE2S)

a. Max. 125 V



Note

The +24 V pulse release voltage at terminals X71.1 and X72.1 is generated internally by a separate power supply unit of the UxC 11x (FS). Use this voltage exclusively for drive enabling – for supplying the relay coils that are internally connected to X71.3 and X72.3.



Warning

The +24 V pulse release voltage must not be linked with other voltages (e.g. +24 V NC or +24 V PLC) of the HEIDENHAIN control system.



Warning

A recovery diode is required in the proximity of inductive loads, e.g. relay or contactor coils.

**X89: Braking resistor**

Connection at the UEC 11x:

Connecting terminal X89 UE 11x	Assignment	PW 21x	PW 1x0(B); connecting terminal X1
1	+U <sub>Z</sub>	RB1	1
2	Switch to -U <sub>Z</sub>	RB2	2

**X90: 24 V output**

Connecting terminal X90	Assignment
+	+24 V (max. 3.5 A)
-	0 V

**X344: 24 V supply for motor holding brakes**


Connecting terminals	Assignment
1	+24 V PLC
2	0 V PLC

**X394: Motor holding brakes**

Connecting terminals	Assignment
1	Holding brake X80
2	0 V PLC
3	Holding brake X81
4	0 V PLC
5	Holding brake X82
6	0 V PLC
7	Holding brake X83
8	0 V PLC
9	Holding brake X84
10	0 V PLC

**Mounting the toroidal cores**

To suppress occurrence of conducted interference, toroidal cores must be mounted in the motor leads (X80 to X84), in the voltage supply lead (X31) and in the lead to the optional, external braking resistor (X89).



### 3.9 UxC 11x (FS): Meaning of the LEDs

On the front of the UxC 11x (FS) are several LEDs for functional control, with the following meaning:

UxC 11x	LED	Meaning	Signal direction	Signal
	NC RESET	Reset signal from the MC computer unit to the UxC	MC → UxC	RES.LE
	PWR FAIL	$U_Z$ too low, $U_Z < 410$ V (e.g. failure of a phase under load, power < 290 V)	UxC → MC	PF.PS
	PWR RES	Reset signal from the UxC to the MC computer unit	UxC → MC	RES.PS
	READY	Inverter ready	UxC → MC	RDY
	TEMP >>	Temperature of heat sink too high (> 100 °C)	UxC → MC	ERR.TEMP
	$U_{DC}$ LINK >>	$U_Z$ too high (> approx. 850 V); power modules are switched off	UxC → MC	ERR.UZ.GR
	STO A (RED)	Safe Torque Off; no enable from control (main contactor not active, DSP error, PLC error with Emergency Stop, hardware or software error of MC, CC)	MC → UEC	STO.A.x
	READY (GREEN)	Axis/Spindle enabled	UxC → MC	RDY
	STO B	Safe Torque Off; no drive enable from control (e.g. by the PLC, active via external signal or STO A active)	MC → UxC	STO.B.x



UxC 11x	LED	Meaning	Signal direction	Signal
LED at X9 on top surface of the UxC	PL green	<ul style="list-style-type: none"> <li>■ PL not ready</li> <li>■ PL ready</li> <li>■ PL initialization</li> <li>■ Error with SS2 reaction is present</li> <li>■ Error with SS1F reaction is present</li> </ul>	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ On</li> <li>■ Slow blinking</li> <li>■ Blinking twice</li> <li>■ Fast blinking</li> </ul>	
	HSCI green	<ul style="list-style-type: none"> <li>■ Not ready for HSCI communication</li> <li>■ Ready for HSCI communication</li> <li>■ Error in HSCI communication</li> <li>■ No HSCI communication</li> </ul>	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ On</li> <li>■ Blinking twice</li> <li>■ Fast blinking</li> </ul>	



### 3.10 Power Supply for PLC Outputs

The PLC outputs of the PLB 62xx are powered by the 24 V control voltage of the machine (in accordance with VDE 0551). The power to the PLC outputs is supplied via the corresponding terminals on the respective I/O module connectors for PLC outputs.

The control voltage must be smoothed with a capacitance of 150  $\mu\text{F}$  per amp of rated current, and in any case with at least 1000  $\mu\text{F}$ . At a current load of 15 A, for example, this corresponds to a capacitance of 2250  $\mu\text{F}$ . If the PSL 130 is used as 24 V– supply unit, this additional smoothing is not necessary.



#### Note

HEIDENHAIN recommends the PSL 130 (575 047-01) as 24 V– power supply unit (see "PSL 13x low-voltage power supply unit" on page 189).

EN 61 131-2:1994 permits:

- Minimum absolute value: 20.4 V–
- Maximum absolute value: 25.4 V– at 200 W power output
- Maximum absolute value: 28.8 V– at 100 W power output



#### Warning

Use only original replacement fuses.

#### Power consumption

If half of the outputs are switched at the same time, the following are the values for power consumption:

PL 6xxx:      approx. 485 W  
UxC 11x:     48 W

#### Power output

The maximum permissible power output of a PLD-H xx-xx-xx is 200 W.



**Rated operating  
current per output**

UxC 11x: 0.150 A

PLD-H xx-xx-xx: 2 A

Simultaneity with a supply voltage of 25.4 V:

2 outputs with 4 A each

4 outputs with 2 A each

8 outputs with 1 A each

Total current:

Out0 to Out7:  $\leq 8$  A

Out0 to Out3:  $\leq 4$  A

Out4 to Out7:  $\leq 4$  A

For all PLD-H xx-xx-xx units, it must be remembered that a total current of max. 8 A per slot (PLD-H) must not be exceeded! This applies regardless of the number of outputs of the PLD-H. With the UxC 11x, a total current of 1.2 A for the eight outputs of a connector must not be exceeded.

In the event of an overload or short circuit and as a consequence of excessive temperature, the individual PLC outputs of a PLD or UxC switch off automatically. Then the outputs will try to switch on again cyclically.

Furthermore, the modules have a fuse that prevents an excessive total current per output module with eight outputs ( $> 8$  A not self-healing on PLD,  $> 1.2$  A self-healing on UxC) and thus destruction of the modules.

### 3.11 Power Supply for PLB 6xxx (FS)



#### Note

The control cyclically monitors the supply voltage of the PL 6xxx.

#### **X3: +24 V NC, +24 V PLC power supply**

Power consumption of the PL 6xxx via X3 if every slot is used (including the TS, TT):


- at +24 V NC: max. 48 W
- at +24 V PLC: max. 21 W

For more details regarding the power supply, see page 182.

The power to the PLC outputs is also supplied via the corresponding terminals on the respective I/O module connectors for PLC outputs. The power consumption of the +24 V PLC via X3 and the power consumption of the PLC outputs add to each other.


#### **Pin layout of X3:**

Supply voltage for logic and PLC outputs

Connecting terminal	Assignment
1 (top terminal)	+ 24 V NC
2	0 V NC (ground + 24 V NC)
3	 Protective ground Minimum wire cross section of the power cables for 24 V PLC
4	+ 24 V PLC
5 (bottom terminal)	0 V PLC (ground + 24 V PLC)



### 3.12 Meaning of the LED on PLB 6xxx

PLB 6xxx	LED	LED status	Meaning
	PL green (right)	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ On</li> <li>■ Slow blinking</li> </ul>	<ul style="list-style-type: none"> <li>■ PL not ready</li> <li>■ PL ready</li> <li>■ PL initialization</li> </ul>
	PL yellow (left)	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Fast blinking</li> <li>■ Blinking twice</li> </ul>	<ul style="list-style-type: none"> <li>■ No error</li> <li>■ Error with SS1F reaction is present</li> <li>■ Error with SS2 reaction is present</li> </ul>
	HSCI green (right)	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ On</li> </ul>	<ul style="list-style-type: none"> <li>■ PL not ready for HSCI communication</li> <li>■ PL ready for HSCI communication</li> </ul>
	HSCI yellow (left)	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Fast blinking</li> <li>■ Blinking twice</li> </ul>	<ul style="list-style-type: none"> <li>■ No HSCI communication error</li> <li>■ No HSCI communication</li> <li>■ Error in HSCI communication</li> </ul>
	Channel A/Channel B refers to the safety channels A and B of the PLB 6xxxFS		

### 3.13 Power Supply for Control-Is-Ready Signal

#### X9: Power supply for control-is-ready signal

The control-is-ready signal output is powered by 24 V– provided by the UE 2xxB inverter or the UV 1xx power supply unit. The voltage is connected with terminal X9 of the PLB 620x.

Pin layout:

Connecting terminal X8	Assignment	Connection when using a HEIDENHAIN inverter
1a	+24 V	X72/1
2b	0 V	X72/2

Power consumption via X9, +24 V PLC: max. 120 W (depending on the connection of PLC outputs to X9)

### 3.14 Drive Controller Enable

A drive controller can be enabled by the NC software only if the controller is enabled with 24 V at terminal X9, pin 7b of the PLB 620x.

#### X9/7b: Global drive controller enable

Pin layout:

Connection X9 on the PLB	Assignment
..	..
7b	+24 V- (drive controller enable)
..	..

#### Drive controller enabling for axis groups

A CC 61xx or a UEC 11x does not have an X150 connector for axis-specific or axis-group-specific drive controller enabling. But in the **MP\_driveOffGroupInput** machine parameter, you can enter up to six numbers of those PLC inputs that simulate the inputs of X150.

With the axis-specific parameter **MP\_driveOffGroup** you have to define the axes to be switched off if the 24 V are no longer available at the specified PLC input.

For more information, see „HSCI: switching drives on and off, enabling the drive controller“ on page 874

#### MP\_driveOffGroupInput

PLC inputs belonging to the switch-off groups  
Available from NCK software version: 597 110-03.

Format: Array

Input: **Group1...Group8**

You can specify up to 8 PLC inputs for the switch-off groups. Depending on the number of switch-off groups you want to realize, you have to enter the parameters here and define the PLC inputs.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

#### MP\_driveOffGroup

Assignment of the axis to the switch-off group  
Available from NCK software version: 597 110-03.

Format: Array [0...7]

Input: You can assign the axis to a maximum of 8 switch-off groups. To do so, insert one parameter each under MP\_driveOffGroup and select the desired switch-off group in the selection menu.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET



### 3.15 Digital PLC Inputs/Outputs

#### Input signals and addresses

Input signals of the switching inputs:

Voltage range	PLD-H (with LED)	UEC 11x, X9 of PL 62xx, and machine operating panel (without LED)
"1" signal: $U_i$	11 V to 30.0 V	11 V to 30.0 V
"0" signal: $U_i$	-3.0 V to 2.2 V	-3 V to 2.2 V

Current range	PLD-H (with LED)	UEC 11x, X9 of PL 62xx, and machine operating panel (without LED)
"1" signal: $I_i$	2.0 mA to 6.1 mA	2.1 mA to 6.0 mA
"0" signal: $I_i$ at $U_i = 2.2 \text{ V}$	0.3 mA	0.43 mA

If 24 V DC is present, and therefore a "1" signal is transmitted, the PLC inputs of the HSCI system consume a current of 5 mA.

#### Output signals and addresses

The switching outputs are transistor outputs with current limitation.

Please note:

- Permissible load: Resistive load (ohmic load). Inductive loads (e.g. relay, contactor) with an energy content of up to 100 mJ do not require a quenching diode. If the energy content exceeds 100 mJ: only with quenching diode parallel to inductance. Pay attention to the manufacturer's specification of the energy content when selecting the switching devices.
- For the rated operating currents of the PLC outputs, see "Rated operating current per output" on page 215.
- If an output is operated with an inductive load without a quenching diode and is read back to an input, the input must be protected by varistors or RC circuits.
- PLD-H: The outputs are short-circuit proof.
- For component-related reasons, the switching outputs should be loaded with at least 5 mA in "1" state. They conform to EN 61131-2. If a resistive load consumes less than 5 mA, it is necessary to either insert a relay or perform a usability test in accordance with the calculation described in the following, see "Calculation of the voltage drop in "0" state" on page 220.
- For component-related reasons, a current of  $I_{\text{Off}} = 500 \mu\text{A}$  flows through the switching outputs also in "0" state. If high-impedance loads with a low-level lower switching threshold are connected directly to the output, the voltage drop can lead to a "1" state. In such a case, a shunt resistor must be connected to the output, see "Calculation of the voltage drop in "0" state" on page 220.

- If the holding brakes of motors are not driven exclusively over the inverter outputs for brakes, a protective circuit in the form of a varistor must be used. Due to the inductance of the holding brakes and any relays used, a voltage peak that may exceed 1000 V occurs when the exciting current is switched off. This may destroy other electronics, such as connected PLC inputs/ outputs.
- A protective circuit is not necessary only if the holding brakes are driven exclusively over the inverter outputs for brakes, because the voltage is limited internally by electronic switches in the inverters.

Output signals:

	PLD-H
Min. output voltage for "1" signal	3 V below supply voltage



#### Warning

PLC outputs must neither be connected to a 24 V supply, nor to other PLC outputs with a difference in potential. Otherwise, the voltage present at the PLC outputs is transmitted to the power supply. As a result, the PLC outputs that can be switched off may nevertheless be supplied with this voltage.

#### Calculation of the voltage drop in "0" state

Current ( $I_{\text{Off}} = 500 \mu\text{A}$ ) also flows in "0" state of the PLC output for component-related reasons.

If resistive loads with high input impedances ( $> 15 \text{ kW}$ ) and a low-level lower switching threshold are operated directly (without an interconnected relay) on the PLC output, a shunt resistor may be necessary under certain circumstances. Typical values of the shunt resistor are 5 kW or 10 kW, for example. The voltage at the output in "0" state should be clearly (approx. 50 %) below the lower switching threshold of the resistive load.

#### Calculation example – Resistive load does not require shunt resistor:

Reversing load relay directly on PLC output, data sheet specifications:

Rated control voltage $U_c$ :	24 V DC
Rated operating current $I_c$ :	3 mA
Switching threshold "0" state $U_{\text{Low}}$ :	9.6 V
Switching threshold "1" state $U_{\text{High}}$ :	19.2 V

In "0" state of the output, the voltage drop has to be less than 9.6 V. Calculation of the input resistance  $R_c$  of the reversing load relay:

$$R_c = \frac{U_c}{I_c} = \frac{24\text{V}}{3\text{mA}} = 8\text{k}\Omega$$

Calculation of the voltage drop  $U_{\text{Low}}$  in "0" state at the output:

$$U_{\text{Low}} = R_c \cdot I_{\text{Off}} = 8\text{k}\Omega \cdot 500\mu\text{A} = 4\text{V}$$

With 4 V, the voltage drop is clearly below the switching threshold for the "0" state (9.6 V). The reversing load relay can be operated directly at the PLC output.



**Calculation example—Resistive load requires shunt resistor:**

Interlocking switch directly at PLC output, data sheet specifications:

Rated control voltage $U_c$ :	28 V DC
Rated operating current $I_c$ :	2.2 mA
Switching threshold "0" state $U_{Low}$ :	3.6 V
Switching threshold "1" state $U_{High}$ :	17.4 V

In "0" state of the output, the voltage drop has to be less than 3.6 V. Calculation of the input resistance  $R_c$  of the interlocking switch:

$$R_c = \frac{U_c}{I_c} = \frac{28V}{2.2 \text{ mA}} = 12.73 \text{ k}\Omega$$

Calculation of the voltage drop  $U_{Low}$  in "0" state at the output:

$$U_{Low} = R_c \cdot I_{Off} = 12.73 \text{ k}\Omega \cdot 500\mu\text{A} = 6.36 \text{ V}$$

The shunt resistor at the output should be such that the voltage drop at the output in "0" state goes clearly below the lower switching threshold, e.g.  $R_p = 5 \text{ kW}$ :

$$\frac{1}{R_{total}} = \frac{1}{R_c} + \frac{1}{R_p}$$

$$\frac{1}{R_{total}} = \frac{1}{12.73 \text{ k}\Omega} + \frac{1}{5\text{k}\Omega}$$

$$R_{total} = 3.59\text{k}\Omega \quad U_{Low} = 3.59 \text{ k}\Omega \cdot 500\mu\text{A} = \mathbf{1.79 \text{ V}}$$

With a voltage drop of 1.79 V in "0" state, the value falls below the lower switching threshold of the interlocking switch. If the shunt resistor of 5 kW is used, operation directly at the PLC output is possible in this case.

**Terminal X9 on PLB  
62xx (FS)**

Properties	Socket connectors on the PLA-H 08-04-04
Connection:	Socket connector with tension clamp connection, type: Weidmüller B2L 3.5/30 SN SW 2-row, 30-pin
Connectable conductors:	Usable conductor cross sections without wire-end sleeve: 0.08 mm <sup>2</sup> to 1.0 mm <sup>2</sup> Usable conductor cross sections with wire-end sleeve: 0.14 mm <sup>2</sup> 0.34 mm <sup>2</sup> 0.5 mm <sup>2</sup> (only with Weidmüller PZ 6/5 crimping pliers)



Note

**HEIDENHAIN recommends:**

Preferably use a conductor cross section of 0.34 mm<sup>2</sup> if you use stranded wires with wire-end sleeves. This cross section can be clamped appropriately and ensures a reliable terminal connection.

If you use stranded wires with wire-end sleeves and a conductor cross section of 0.5 mm<sup>2</sup>, the Weidmüller PZ 6/5 crimping pliers (setting 0.25–0.5 mm<sup>2</sup>) must be used for crimping. In this case, orient the crimped wire-end sleeve before inserting it into the socket connector. If crimping pliers from other manufacturers are used for crimping conductors with a cross section of 0.5 mm<sup>2</sup>, the crimped wire-end sleeves cannot be inserted into the socket connector and clamped appropriately, and therefore do not result in a reliable terminal connection.



## X9: Safety-related PLC inputs/outputs

### Pin layout of PLB 620x:

The triggering outputs at X9 each supply up to 150 mA of output current. The only exceptions are the two outputs –STOS.A.G and –STO.A.G with max. 2 A of output current. In the event of an overload or short circuit and as a consequence of excessive temperature, the individual PLC outputs switch off automatically. Then the outputs will try to switch on again cyclically. Seven outputs and twelve inputs are available at X9 of a PLB 620x for free use. Further PLC inputs/outputs must be realized by means of I/O modules.

Terminal	NEW signal design.	OLD connector/signal design. (MC 42xC)	Assignm. / Function
1a	24 V.A	X34	24 V supply of the outputs MC.RDY, O.0 to O.2
2a	Do not assign	–	–
3a	MC.RDY <sup>a</sup>	–SH1A (safe stop) X41.34 / O33	24 V output: (safe torque off) Control-is-ready signal
4a	O0		24 V outputs (high-side driver)
5a	O1		
6a	O2		
7a	–ES.A	–NE1 / X42.4 / I3 Acknowledgment: "Control is ready"	24 V input Emergency Stop input 1
8a	I0		24 V inputs (PLC)
9a	I1		
10a	I2		
11a	I3		
12a	I4		
13a	I5		
14a	–PF.PS.AC	–PF.PS.AC (signal on X69)	24 V outputs for powerfail
15a	–PF.PS.DC	–PF.PS.ZK (signal on X69)	
1b	24 V.B	X44	24 V supply of the outputs O.3 to O.6
2b	0 V		0 V PLC for all I/Os
3b	O3 <sup>a</sup>		24 V outputs (high-side driver)
4b	O4		
5b	O5		
6b	O6		
7b	–ES.B	–NE2 / X42.33 / I32 "Drive enabling"	24 V input Emergency Stop input 2
8b	I6		24 V inputs (PLC)
9b	I7		
10b	I8		
11b	I9		
12b	I10		
13b	I11		
14b	–SP.REF+	X30	Optocoupler input, Spindle ref.
15b	–SP.REF–	X30	

a. 2 A outputs

## X9 – Safety: Safety-related PLC inputs/ outputs

### Pin layout of PLB 620x FS:

The triggering outputs at X9 each supply up to 150 mA of output current. The only exceptions are the two outputs –STOS.A.G and –STO.A.G with max. 2 A of output current. In the event of an overload or short circuit and as a consequence of excessive temperature, the individual PLC outputs switch off automatically. Then the outputs will try to switch on again cyclically.

Two outputs and six inputs are available at X9 of a PLB 620x FS for free use. Further PLC inputs/outputs must be realized by means of I/O modules.

Terminal	NEW signal design.	OLD connector/signal design. (MC 42xC)	Assignm. / Function
1a	24 V.A	X44	24 V supply of the outputs MC.RDY, O.0 to O.1
2a	–STOS.A.G <sup>a</sup>	–SHS1A (safe stop of spindle) X41.32	24 V output: (spindle safe torque off)
3a	–STO.A.G <sup>a</sup>	–SH1A (safe stop) X41.34 / O33	24 V output: (safe torque off) Control-is-ready signal
4a	TEST.A	T.2 / X165.2	24 V output for emergency stop chain
5a	O0.A		24 V outputs (high-side driver)
6a	O1.A		
7a	–ES.A	–NE1 / X42.4 / I3 Acknowledgment: "Control is ready"	24 V input Emergency Stop input 1
8a	I0.A		24 V inputs (PLC)
9a	I1.A		
10a	I2.A		
11a	I3.A		
12a	I4.A		
13a	I5.A		
14a	–PF.PS.AC	–PF.PS.AC (signal on X69)	24 V outputs for powerfail
15a	–PF.PS.DC	–PF.PS.ZK (signal on X69)	
1b	24 V.B	X44	24 V supply of the outputs O.0 to O.1
2b	0 V		0 V PLC for all I/Os
3b	Do not assign		24 V outputs (high-side driver)
4b	TEST.B	T.1 / X165.1	24 V output for emergency stop chain
5b	O0.B		24 V outputs (high-side driver)
6b	O1.B		
7b	–ES.B	–NE2 / X42.33 / I32 "Drive enabling"	24 V input Emergency Stop input 2



Terminal	NEW signal design.	OLD connector/signal design. (MC 42xC)	Assignm. / Function
8b	I0.B		24 V inputs (PLC)
9b	I1.B		
10b	I2.B		
11b	I3.B		
12b	I4.B		
13b	I5.B		
14b	-SP.REF+	X30	Optocoupler input, Spindle ref.
15b	-SP.REF-	X30	

a. 2 A outputs





Note

The 0 V terminals of X11, X12 and X14 of the PLD-H are connected internally. These connections are used for connecting the potential of the electronics and for operating the LEDs. Since only a low current is required (max. 50 mA), it is sufficient to establish only one 0 V connection (preferably at X11).

<b>X11: PLC inputs channel A</b>											
Assignment	Terminal										
	1	2	3	4	5	6	7	8	9	10	
PL 6xxx Slot 1	0 V PLC	0 V PLC	I0	I1	I2	I3	I4	I5	I6	I7	I8

<b>X12: PLC inputs channel A</b>											
Assignment	Terminal										
	1	2	3	4	5	6	7	8	9	10	
PL 6xxx Slot 1	0 V PLC	0 V PLC	I8	I9	I10	I11	I12	I13	I14	I15	

<b>X14: PLC inputs channel B</b>											
Assignment	Terminal										
	1	2	3	4	5	6	7	8	9	10	
PL 6xxx Slot 1	0 V PLC	0 V PLC	I0.B	I1.B	I2.B	I3.B	I4.B	I5.B	I6.B	I7.B	I8.B

<b>X17: PLC inputs, channel A/B</b>											
Assignment	Terminal										
	1	2	3	4	5	6	7	8	9	10	
PL 6xxx Slot 1	0 V PLC	0 V PLC	I0.A	I1.A	I2.A	I3.A	I0.B	I1.B	I2.B	I3.B	

Please note that a system with functional safety (FS) permits up to 100 safe, dual-channel inputs (channels A and B). An MB 6xx FS from HEIDENHAIN requires 56 of the 100 safe inputs, and connector X9 of a system PL requires eight additional safe inputs. This means that max. 36 safe inputs can be distributed to the PLD-H xx-xx-xx FS.

The designation "Channel A" or ".A" for the PLC inputs is relevant only for I/O modules with functional safety (FS).

**Fast  
PLC inputs**

Only the first four slots of a PL 6xxx can be used for fast PLC inputs. The fifth slot and the successive slots (on PL 6x06, PL 6x08) must not be defined as fast PLC inputs.

The configuration of fast PLC inputs in the HSCI system corresponds to the previous configuration using machine parameters.



**PLC outputs on the PLD-H xx-xx-xx input/output module:**

<b>X21: PLC outputs, channel A</b>											
Assignment	Terminal										
	1	2	3	4	5	6	7	8	9	10	
PL 6xxx Slot 1	O0.A	O1.A	O2.A	O3.A	O4.A	O5.A	O6.A	O7.A	24 V PLC for O0 to O3	24 V PLC for O4 to O7	

<b>X22: PLC outputs, channel A</b>											
Assignment	Terminal										
	1	2	3	4	5	6	7	8	9	10	
PL 6xxx Slot 1	O08.A	O09.A	O10.A	O11.A	O12.A	O13.A	O14.A	O15.A	24 V PLC for O8 to O11	24 V PLC for O12 to O15	

<b>X24: PLC outputs, channel B</b>											
Assignment	Terminal										
	1	2	3	4	5	6	7	8	9	10	
PL 6xxx Slot 1	O0.B	O1.B	O2.B	O3.B	O4.B	O5.B	O6.B	O7.B	24 V PLC for O0 to O3	24 V PLC for O4 to O15	

<b>X27: PLC outputs, channel A / channel B</b>											
Assignment	Terminal										
	1	2	3	4	5	6	7	8	9	10	
PL 6xxx Slot 1	O0.A	O1.A	O2.A	O3.A	O0.B	O1.B	O2.B	O3.B	24 V PLC for O0.A to O3.A	24 V PLC for O0.B to O3.B	

Please note that a system with functional safety (FS) permits up to 64 safe, dual-channel outputs (channels A and B). Connector X9 of a system PL requires three of the outputs. This means that max. 61 safe outputs can be distributed to the PLD-H xx-xx-xx FS.

"Channel A" or ".A" of the PLC outputs needs to be entered only for I/O modules with functional safety (FS).

### 3.15.1 UxC 11x (FS): Digital PLC inputs/outputs

#### Type of terminals on the UxC 11x (FS)

Socket connectors X4, X5, X6, X104, X106 on the UxC 11x (FS)	
Connection:	Socket connector with tension clamp connection, type: Weidmüller B2L 3.5/24 SN SW 2-row, 24-pin
Connectable conductors:	Usable conductor cross sections without wire-end sleeve: 0.08 mm <sup>2</sup> to 1.0 mm <sup>2</sup> Usable conductor cross sections with wire-end sleeve: 0.14 mm <sup>2</sup> 0.34 mm <sup>2</sup> 0.5 mm <sup>2</sup> (only with Weidmüller PZ 6/5 crimping pliers)



#### Note

##### HEIDENHAIN recommends:

Preferably use a conductor cross section of 0.34 mm<sup>2</sup> if you use stranded wires with wire-end sleeves. This cross section can be clamped appropriately and ensures a reliable terminal connection.

If you use stranded wires with wire-end sleeves and a conductor cross section of 0.5 mm<sup>2</sup>, the Weidmüller PZ 6/5 crimping pliers (setting 0.25–0.5 mm<sup>2</sup>) must be used for crimping. In this case, orient the crimped wire-end sleeve before inserting it into the socket connector. If crimping pliers from other manufacturers are used for crimping conductors with a cross section of 0.5 mm<sup>2</sup>, the crimped wire-end sleeves cannot be inserted into the socket connector and clamped appropriately, and therefore do not result in a reliable terminal connection.

The digital inputs/outputs described below are available on the UxC 11x (FS).



**X4: Single-channel  
PLC inputs  
(on the front)**

**Connections on the front of the UxC 11x (FS):**

- 18 single-channel PLC inputs are freely available:  
I0 to I17

Terminal	Signal designation	Assignm. / Function
1a	+24 V PLC.01	24 V supply of the outputs MC.RDY, O16 to O22
2a	+24 V PLC.02	24 V supply of the outputs O8 to O15
3a	+24 V PLC.03	24 V supply of the outputs O0 to O7
4a	0 V PLC	0 V for all I/Os
5a	-REF.SP	Reserved, do not assign
6a	0 V PLC	0 V for all I/Os
7a	I12	24 V inputs
8a	I13	
9a	I14	
10a	I15	
11a	I16	
12a	I17	
1b	I0	24 V inputs
2b	I1	
3b	I2	
4b	I3	
5b	I4	
6b	I5	
7b	I6	
8b	I7	
9b	I8	
10b	I9	
11b	I10	
12b	I11	



**X5: Single-channel  
PLC inputs  
(on the front)**

**Connections on the front of the UxC 11x (FS):**

- 20 single-channel PLC inputs are freely available:  
I18 to I37

Terminal	Signal designation	Assignm. / Function
1a	I30	24 V inputs
2a	I31	
3a	I32	
4a	I33	
5a	I34	
6a	I35	
7a	I36	
8a	I37	
9a	-ES.A	+24 V input Acknowledgment: "Control is ready"
10a	-ES.B	24 V input "Drive enabling"
11a	Do not assign	
12a	Do not assign	
1b	I18	24 V inputs
2b	I19	
3b	I20	
4b	I21	
5b	I22	
6b	I23	
7b	I24	
8b	I25	
9b	I26	
10b	I27	
11b	I28	
12b	I29	



**Note**

If the integrated PLC inputs do not suffice for your application, you can connect up to 7 additional external PL 61xx expansion PLs to the UxC 111FS via the HSCI interface.



**X104 – Safety:  
Dual-channel PLC  
inputs (on the front)**

**Connections on the front of the UxC 11x FS:**

- 8 dual-channel PLC inputs:  
I0.A to I7.A  
I0.B to I7.B

Terminal	Signal designation	Assignm. / Function
1a	+24 V.A	24 V supply of the outputs O0.A to O7.A
2a	+24 V.B	24 V supply of the outputs O0.B to O7.B
3a	+24 V.C	24 V supply of the outputs O8.A to O15.A
4a	Do not assign	
5a	I4.B	24 V inputs
6a	I5.B	
7a	I6.B	
8a	I7.B	
9a	I4.A	
10a	I5.A	
11a	I6.A	
12a	I7.A	
1b	Do not assign	
2b	Do not assign	
3b	Do not assign	
4b	Do not assign	
5b	I0.B	24 V inputs
6b	I1.B	
7b	I2.B	
8b	I3.B	
9b	I0.A	
10b	I1.A	
11b	I2.A	
12b	I3.A	



**Note**

If the integrated PLC inputs do not suffice for your application, you can connect up to 7 additional external PL 61xx expansion PLs to the UxC 111FS via the HSCI interface.

**X6: Single-channel PLC outputs (at the top)**

**Connections at the top of the UxC 11x:**

- 23 single-channel PLC outputs  
O0 to O22

Terminal	Signal designation	Assignm. / Function
1a	O4	24 V outputs, can be switched off via terminal X4.3a (+24 V PLC.03)
2a	O5	
3a	O6	
4a	O7	
5a	O12	24 V outputs, can be switched off via terminal X4.2a (+24 V PLC.02)
6a	O13	
7a	O14	
8a	O15	
9a	O20	24 V outputs, cannot be switched off
10a	O21	
11a	O22	
12a	MC.RDY	24 V output Control-is-ready signal
1b	O0	24 V outputs, can be switched off via terminal X4.3a (+24 V PLC.03)
2b	O1	
3b	O2	
4b	O3	
5b	O8	24 V outputs, can be switched off via terminal X4.2a (+24 V PLC.02)
6b	O9	
7b	O10	
8b	O11	
9b	O16	24 V outputs, cannot be switched off
10b	O17	
11b	O18	
12b	O19	



**Note**

Each output of the UxC 11x can be loaded with a maximum current of 150 mA.



**Note**

If the integrated PLC outputs do not suffice for your application, you can connect up to 7 additional external PL 61xx expansion PLs to the UxC 11x via the HSCI interface.



**X6 – Safety:  
Single-channel PLC  
outputs (at the top)**

**Connections at the top of the UxC 11x FS:**

- 20 single-channel PLC outputs

Terminal	Signal designation	Assignm. / Function
1a	O4	24 V outputs, can be switched off via terminal X4.3a (+24 V PLC.03)
2a	O5	
3a	O6	
4a	O7	
5a	O12	24 V outputs, can be switched off via terminal X4.2a (+24 V PLC.02)
6a	O13	
7a	O14	
8a	O15	
9a	-TEST.A	24 V output for emergency stop chain
10a	-TEST.B	24 V output for emergency stop chain
11a	-STOS.A.G	24 V output: (spindle safe torque off)
12a	-STO.A.G	24 V output: (safe torque off) Control-is-ready signal
1b	O0	24 V outputs, can be switched off via terminal X4.3a (+24 V PLC.03)
2b	O1	
3b	O2	
4b	O3	
5b	O8	24 V outputs, can be switched off via terminal X4.2a (+24 V PLC.02)
6b	O9	
7b	O10	
8b	O11	
9b	O16	24 V outputs, cannot be switched off
10b	O17	
11b	O18	
12b	O19	



**Note**

Each output of the UxC 11x can be loaded with a maximum current of 150 mA.



**Note**

If the integrated PLC outputs do not suffice for your application, you can connect up to 7 additional external PL 61xx expansion PLs to the UxC 11x via the HSCI interface.

**X106 – Safety:  
Single-/dual-  
channel PLC  
outputs (on the  
front)**

**Connections on the front of the UxC 11x FS:**

- 8 dual-channel PLC outputs:  
O0.A to O7.A  
O0.B to O7.B
- 8 single-channel PLC outputs:  
O8.A to O15.A

Terminal	Signal designation	Assignm. / Function
1a	O4.B	24 V outputs, can be switched off via terminal X104.2a (+24 V.B)
2a	O5.B	
3a	O6.B	
4a	O7.B	
5a	O4.A	24 V outputs, can be switched off via terminal X104.1a (+24 V.A)
6a	O5.A	
7a	O6.A	
8a	O7.A	
9a	O12.A	24 V outputs, can be switched off via terminal X104.3a (+24 V.C)
10a	O13.A	
11a	O14.A	
12a	O15.A	
1b	O0.B	24 V outputs, can be switched off via terminal X104.2a (+24 V.B)
2b	O1.B	
3b	O2.B	
4b	O3.B	
5b	O0.A	24 V outputs, can be switched off via terminal X104.1a (+24 V.A)
6b	O1.A	
7b	O2.A	
8b	O3.A	
9b	O8.A	24 V outputs, can be switched off via terminal X104.3a (+24 V.C)
10b	O9.A	
11b	O10.A	
12b	O11.A	



**Note**

Each output of the UxC 11x (FS) can be loaded with a maximum current of 150 mA.



**Note**

If the integrated PLC outputs do not suffice for your application, you can connect up to 7 additional external PL 61xx expansion PLs to the UxC 111FS via the HSCI interface.



### 3.16 Analog PLC Inputs/Outputs



#### Note

The interfaces of the PLA-H 08-04-04 module are electrically separated from the 230 V line power in accordance with EN 50178.

Sensors and external devices that are connected to the PLA-H 08-04-04 module must be supplied exclusively either with 24 V NC or with 24 V PLC. The inputs and outputs of the module are not galvanically isolated internally. In the HSCI system, the two supply voltages must not be connected with each other, however.

Sensors and external devices that are connected to the PLA-H 08-04-04 module and are supplied with 24 V NC must have double basic insulation.

Specifications:

#### Analog inputs

Voltage range: -10 V to +10 V  
 Input resistance: > 40 kΩ  
 Resolution: 10 mV

#### Analog outputs

Voltage range: -10 V to +10 V  
 Load impedance: > 5 kΩ  
 Output current: < 2 μA  
 Resolution: 10 mV

#### Inputs for Pt 100 thermistors

Constant current: 4.096 mA  
 Temperature range: 0 °C to 100 °C  
 Resolution: 0.01 °C, increment: 0.03 °C

#### Terminals on the PLA-H 08-04-04

Properties	Socket connectors on the PLA-H 08-04-04
Connection:	Socket connector with tension clamp connection, type: X81, X82: Weidmüller B2L 3.5/10 SN SW 2-row, 10-pin X66, X67, X46, X47, X48, X49: Weidmüller B2L 3.5/6 SN SW 2-row, 6-pin
Connectable conductors:	Usable conductor cross sections without wire-end sleeve: 0.08 mm <sup>2</sup> to 1.0 mm <sup>2</sup> Usable conductor cross sections with wire-end sleeve: 0.14 mm <sup>2</sup> 0.34 mm <sup>2</sup> 0.5 mm <sup>2</sup> (only with Weidmüller PZ 6/5 crimping pliers)



## Note

### HEIDENHAIN recommends:

Preferably use a conductor cross section of  $0.34 \text{ mm}^2$  if you use stranded wires with wire-end sleeves. This cross section can be clamped appropriately and ensures a reliable terminal connection.

If you use stranded wires with wire-end sleeves and a conductor cross section of  $0.5 \text{ mm}^2$ , the Weidmüller PZ 6/5 crimping pliers (setting  $0.25\text{--}0.5 \text{ mm}^2$ ) must be used for crimping. In this case, orient the crimped wire-end sleeve before inserting it into the socket connector. If crimping pliers from other manufacturers are used for crimping conductors with a cross section of  $0.5 \text{ mm}^2$ , the crimped wire-end sleeves cannot be inserted into the socket connector and clamped appropriately, and therefore do not result in a reliable terminal connection.

Power consumption of a PLA-H 08-04-04 I/O module:

- Without load: 2.6 W
- Under full load: 4.5 W

### X46 to X49: Analog inputs

#### Pin layout

Connecting terminals	Assignment
1a/1b	-10 V to +10 V (input)
2a/2b	0 V (reference potential)
3a/3b	Shield

### X66 to X67: Analog output

#### Pin layout

Connecting terminals	Assignment
1a/1b	-10 V to +10 V (output)
2a/2b	0 V (reference potential)
3a/3b	Shield

### X81 to X82: Connection for Pt 100

#### Pin layout:

Connecting terminals	Assignment
1a/1b	I+ Constant current for Pt 100
2a/2b	U+ Measuring input for Pt 100
3a/3b	U- Measuring input for Pt 100
4a/4b	I- Constant current for Pt 100
5a/5b	Shield





### 3.17 PROFIBUS Connection

Pin layout on X121 of the MC main computer or IPC and on X1 of the PLB 550 PROFIBUS slave

Main computer X121		Connecting cable 515 845-01			PLB 550 X1	
D-sub connctn. (female) 9-pin	Assignment	D-sub connctr. (male) 9-pin		D-sub connctr. (male) 9-pin	X1 D-sub connctn. (female) 9-pin	Assignment
1	Do not assign	1	–	1	1	Do not assign
2	Do not assign	2	–	2	2	Do not assign
3	B line	3	B line	3	3	B line
4	RTS (signal type: TTL)	4	–	4	4	RTS (signal type: TTL)
5	GND	5	–	5	5	GND
6	+5 V	6	–	6	6	+5 V
7	Do not assign	7	–	7	7	Do not assign
8	A line	8	A line	8	8	A line
9	Do not assign	9	–	9	9	Do not assign
Housing	External shield	Housing	External shield	Housing	Housing	External shield

All signals on the PL 550 are electrically isolated.

All signals are electrically isolated at X121 of the MC 6xxx main computer or the IPC 6xxx.

The +5 V and GND pins supply the terminating resistor in the connector.



#### Note

For more information about PROFIBUS on HEIDENHAIN controls, refer to the documentation about the IOconfig software for PCs.



HEIDENHAIN provides device files (HDD files) for all HSCI components with the technical characteristics of these components. These HDD files are of critical importance for the configuration of the HSCI system. You should therefore make sure that you always use the latest version of IOconfig and the HDD files for the configuration.

When configuring a project, the IOconfig program takes the description of the HSCI components from the HDD file and transfers it to the configuration file (IOC file).



#### Note

HEIDENHAIN recommends updating all IOC files and EAZ projects with the IOconfig version 2.2.02. This is the only way to ensure that you can use all of the features provided by the new HSCI components.

For more information about using IOconfig, please refer to the program's on-line help.

## Updating the HSCI configuration

To update the HSCI configurations, proceed as follows:

Install the IOconfig version 2.2.02 or a later IOconfig version. In the HEIDENHAIN FileBase, you will find the current version of the IOconfig software for PCs for downloading. With IOconfig version 2.2.02, however, changes to the HDD files are not transferred automatically.

If new HDD files exist on the PC, IOconfig 2.x does not update these files automatically until these files:

- are copied into the directory in which IOconfig searches for HDD files (to be defined in Extras/Options and Project/Settings), and
- are read in with the HDD import function or imported via an IOC import of GSD/HDD files.

HDD files cannot be imported in any other way, e.g. when EAZ files are loaded. Any existing new HDD files will therefore be ignored.

Do the following steps manually in order to be able to use all available features of new HSCI components:

### 1. Transfer the HDD files

Check where the standard directory and the project directory for HDD files are located. The two directories should usually be identical:

- Extras -> Options: Standard directory for HDD library: xxxxxxxx
- Project -> Project Settings: Directory of HDD library: xxxxxxxx

Move or delete all HDD files being used.

Then copy all current HDD files from IOconfig (e.g. from C:\Programs\HEIDENHAIN\IOconfig\HDD ) to the standard directory or the project directory of the HDD library.

## 2. Update the EAZ project

The only way to ensure that all HDD files specified in the IOC file are evaluated and used for generating the HSCI components in an IOC project is exporting and importing an IOC file. These steps are required to be able to detect new components, diagnostic information and parameters in new HDD files. The essential steps are creating an IOC file and re-importing this IOC file. These steps ensure that all diagnostic information is updated and all new parameterization possibilities become visible.

If the message **Missing HDD files** is displayed during import, press **CONTINUE** to continue the process. Then the slave is inserted, but it will not have any diagnostic or parametric properties.

This can happen if the names of HDD files were changed and the IOC file still contains the previous file names. A new IOconfig version with current HDD files will usually not find these old files. **If it finds them nevertheless, then move the old HDD files and make sure that you do not use them anymore.**

Something similar can occur if the name of an HDD file is correct, but the name of the slave contained in it was changed and the IOC file still contains the old name of the slave. The error message **Missing HDD files** will then not be displayed, but the diagnostic and parametric properties of the slave will be missing.

In such cases, the slave in question must be deleted and reinserted from the correct HDD file. The new functions provided by IOconfig 2.2.02 for this purpose can be used to transfer the terminal names during the Delete/Paste actions.

## 3. Check the machine operating panels and keyboard units

If the **Override** module is shown for an MB/TE slave, then the respective slave must be deleted and reinserted from the correct HDD file. The new functions provided by IOconfig 2.2.02 for this purpose can be used to transfer the terminal names during the Delete/Paste actions.



## 3.19 Buffer Battery



### Note

Make a data backup before changing the buffer battery.



### Danger

When exchanging the buffer battery, remember:


- Switch off the machine and the control.
- The buffer battery may be exchanged only by trained personnel.

Battery type: 1 Lithium battery, type CR 2450N (Renata), ID 315 878-01

If the voltage of the buffer battery falls below 2.6 V, the error message **Exchange buffer battery** appears. If the voltage does not rise above 2.6 V again, the error message is reactivated after 30 minutes. You can determine the voltage of the buffer battery with the OLM, see "Diagnosis with the Online Monitor (OLM)" on page 1162.

To exchange the battery:

- ▶ The buffer battery is on the main board of the MC.
- ▶ Loosen the screws securing the rear housing cover of the MC.
- ▶ Remove the cover.
- ▶ The buffer battery is at the border of the PCB:



- ▶ Exchange the buffer battery; the new battery can be inserted in only one position.

## 3.20 Encoder Connections

### 3.20.1 General information

HEIDENHAIN contouring controls are designed for use with incremental or absolute linear and angular encoders as measuring systems. The encoder signals are subdivided 1024-fold.

Encoders with one reference mark or distance-coded reference marks and with EnDat interface are permissible.

HEIDENHAIN recommends the use of absolute encoders with EnDat interface or the use of encoders with distance-coded reference marks because they greatly reduce the traverse distance required to establish the absolute position.



#### Note

On controller units with HSCI interface (e.g. CC 61xx, UEC 11x) you can no longer directly connect encoders with 11  $\mu$ A signals. You need an adapter ID 313 119-xx to adjust the signals; see "Adapters for Encoder Signals" on page 250.

Please use only HEIDENHAIN encoder cables, connectors and couplings. For maximum cable lengths, see "Cable Overview" at the end of this chapter.

	Position encoder	Speed encoder
Signal amplitude	EnDat, 1 V <sub>PP</sub> (to be defined in <b>MP_posEncoderSignal</b> )	EnDat, 1 V <sub>PP</sub>
Input frequency 1 V <sub>PP</sub>	CC 61xx: 27 kHz/400 kHz (to be defined in <b>MP_posEncoderFreq</b> )	CC 61xx: 400 kHz



#### Note

Keep in mind the line count of the speed encoders when choosing the motors:

$$x = \frac{f \cdot 60 \cdot 1000}{n}$$

x: line count of the speed encoder

f: maximum input frequency

n: maximum speed

Example:

$$f = 350 \text{ kHz}; n = 10\,000 \text{ min}^{-1}$$

$$x = \frac{350 \cdot 60 \cdot 1000}{10000} \approx 2048$$

### 3.20.2 Position encoder input

**X201 to X206:**  
**Position encoder**  
**1 V<sub>PP</sub>**

Pin layout:

CC 6106		Adapter cable 309 783-xx Adapter cable 310 199-xx			Encoder	
Male	Assignment	Female	Color	Female	Male	Color
1	+5 V (U <sub>P</sub> )	1	Brown/Green	12	12	Brown/Green
2	0 V (U <sub>N</sub> )	2	White/Green	10	10	White/Green
3	A+	3	Brown	5	5	Brown
4	A-	4	Green	6	6	Green
5	Do not assign	5				
6	B+	6	Gray	8	8	Gray
7	B-	7	Pink	1	1	Pink
8	Do not assign	8				
9	+5 V (sensor)	9	Blue	2	2	Blue
10	R+	10	Red	3	3	Red
11	0 V (sensor)	11	White	11	11	White
12	R-	12	Black	4	4	Black
13	0 V	13				
14	Do not assign	14	Violet	7	7	Violet
15	Do not assign	15				
Hsg.	External shield	Hsg.	External shield	Hsg.	Hsg.	External shield



#### Note

The interface complies with the requirements of EN 50178 for "low voltage electrical separation."

**X201 to X206:**  
**Position encoder**  
**with EnDat interface**

Pin layout:

CC 6106		Adapter cable 332 115-xx			Connecting cable 323 897-xx			Adapter cable 313 791-xx		
Male	Assign.	Female	Color	Female	Male	Color	Fem.	Male	Color	Fem.
1	+5 V (U <sub>P</sub> )	1	Brown/ Green	7	7	Brown/ Green	7	7	Brown/ Green	5b
2	0 V (U <sub>N</sub> )	2	White/ Green	10	10	White/ Green	10	10	White/ Green	6a
3	A+	3	Green/ Black	15	15	Green/ Black	15	15	Green/ Black	2a
4	A-	4	Yellow/ Black	16	16	Yellow/ Black	16	16	Yellow/ Black	2b
5	Data	5	Gray	14	14	Gray	14	14	Gray	3b
6	B+	6	Blue/ Black	12	12	Blue/ Black	12	12	Blue/ Black	1a
7	B-	7	Red/ Black	13	13	Red/ Black	13	13	Red/ Black	1b
8	$\overline{\text{Data}}$	8	Pink	17	17	Pink	17	17	Pink	3a
9	+5 V (Sensor)	9	Blue	1	1	Blue	1	1	Blue	5a
10	Not assigned	10		3	3	Red	3	3		
11	0 V (Sensor)	11	White	4	4	White	4	4	White	6b
12	Not assigned	12		2	2	Black	2	2		
13	Internal shield	13	Internal shield	11	11	Inter- nal shield	11	11	Internal shield	
14	Clock	14	Violet	8	8	Violet	8	8	Violet	4a
15	$\overline{\text{Clock}}$	15	Yellow	9	9	Yellow	9	9	Yellow	4b
Hsg.	Housing	Hsg.	External shield	Hsg.		Exter- nal shield			Hsg.	Exter- nal shield

Line drop compensator ID 336 697-02, if required



**Note**

The interface complies with the requirements of EN 50178 for "low voltage electrical separation."







#### Note

For cable lengths > 10 m between the CC 61xx or UxC 11x and the encoders with EnDat interfaces (EnDat 2.1), a line-drop compensator (336 697-xx) is required (efficiency = 75 %).



### 3.20.3 Speed encoder input



#### Warning

If you connect angle or linear encoders from HEIDENHAIN to the speed encoders (such as for torque motors), you must pay attention to the different connector layouts!

HEIDENHAIN offers special cables and line-drop compensators for such applications. More information is in the Cable Overviews.

#### X15 to X20: Speed encoder 1 V<sub>PP</sub>

Pin layout:

CC 61xx		Adapter cable 289 440-xx				Connecting cable 336 847-xx		
Male	Assignment	Female	Color	Female		Male	Color	Female
1	+5 V (U <sub>P</sub> )	1	Brown/Green	10	Line drop compensator ID 370 226-01, if required	10	Brown/Green	10
2	0 V (U <sub>N</sub> )	2	White/Green	7		7	White/Green	7
3	A+	3	Green/Black	1		1	Green/Black	1
4	A-	4	Yellow/Black	2		2	Yellow/Black	2
5	0 V							
6	B+	6	Blue/Black	11		11	Blue/Black	11
7	B-	7	Red/Black	12		12	Red/Black	12
8	0 V	8	Internal shield	17		17	Internal shield	17
9	Do not assign							
10	Do not assign							
11	Do not assign							
12	Do not assign							
13	Temperature+	13	Yellow	8		8	Yellow	8
14	+5 V (sensor)	14	Blue	16		16	Blue	16
15	Do not assign							
16	0 V (sensor)	16	White	15		15	White	15
17	R+	17	Red	3		3	Red	3
18	R-	18	Black	13		13	Black	13
19	C+	19	Green	5		5	Green	5
20	C-	20	Brown	6		6	Brown	6
21	D+	21	Gray	14		14	Gray	14
22	D-	22	Pink	4		4	Pink	4
23	Do not assign							
24	0 V							
25	Temperature-	25	Violet	9		9	Violet	9
Hsg.	Housing	Hsg.	External shield	Hsg.	Hsg.	External shield	Hsg.	



#### Note

The interface complies with the requirements of EN 61800-5-1 for "protective extra-low voltage" (PELV).



**X15 to X20: Speed encoder with EnDat interface**

Pin layout:

CC 61xx		Adapter cable 336 376-xx				Connecting cable 340 302-xx		
Male	Assignment	Female	Color	Female		Male	Color	Female
1	+5 V (U <sub>P</sub> )	1	Brown/Green	10	Line drop compensator ID 370 224-01, if required	10	Brown/Green	10
2	0 V (U <sub>N</sub> )	2	White/Green	7		7	White/Green	7
3	A+	3	Green/Black	1		1	Green/Black	1
4	A-	4	Yellow/Black	2		2	Yellow/Black	2
5	0 V							
6	B+	6	Blue/Black	11		11	Blue/Black	11
7	B-	7	Red/Black	12		12	Red/Black	12
8	0 V	8	Internal shield	17		17	Internal shield	17
9	Do not assign							
10	Clock	10	Green	5		5	Green	5
11	Do not assign							
12	Clock	12	Brown	14		14	Brown	14
13	Temperature+	13	Yellow	8		8	Yellow	8
14	+5 V (sensor)	14	Blue	16		16	Blue	16
15	Data	15	Red	3		3	Red	3
16	0 V (sensor)	16	White	15		15	White	15
17	Do not assign							
18	Do not assign							
19	Do not assign							
20	Do not assign							
21	Do not assign							
22	Do not assign							
23	Data	23	Black	13		13	Black	13
24	0 V							
25	Temperature-	25	Violet	9		9	Violet	9
Hsg.	Housing	Hsg.	External shield	Hsg.	Hsg.	External shield	Hsg.	



**Note**

The interface complies with the requirements of EN 61800-5-1 for "protective extra-low voltage" (PELV).



**Danger**

Only units that comply with the requirements of EN 61800-5-1 for "protective extra-low voltage" (PELV) may be connected.

Pin layout (for the LC or RCN):

CC 61xx		Adapter cable 336 376-xx				Adapter cable 369 124-xx Adapter cable 369 129-xx	
Male	Assignment	Female	Color	Female		Male	Color
1	+5 V (U <sub>P</sub> )	1	Brown/Green	10	Line drop compensator ID 368 210-02, if required	7	Brown/Green
2	0 V (U <sub>N</sub> )	2	White/Green	7		10	White/Green
3	A+	3	Green/Black	1		15	Green/Black
4	A-	4	Yellow/Black	2		16	Yellow/Black
5	0 V						
6	B+	6	Blue/Black	11		12	Blue/Black
7	B-	7	Red/Black	12		13	Red/Black
8	0 V	8	Internal shield	17		11	Internal shield
9	Do not assign						
10	Clock	10	Green	5		8	Violet
11	Do not assign						
12	Clock	12	Brown	14		9	Yellow
13	Temperature+	13	Yellow	8			
14	+5 V (sensor)	14	Blue	16		1	Blue
15	Data	15	Red	3		14	Gray
16	0 V (sensor)	16	White	15		4	White
17	Do not assign						
18	Do not assign						
19	Do not assign						
20	Do not assign						
21	Do not assign						
22	Do not assign						
23	Data	23	Black	13		17	Pink
24	0 V						
25	Temperature-	25	Violet	9			
Hsg.	Housing	Hsg.	External shield	Hsg.	Hsg.	External shield	
					1		
					2	tempera- ture+	
					3	tempera- ture-	
					4		



**Note**

The interface complies with the requirements of EN 61800-5-1 for "protective extra-low voltage" (PELV).



Pin layout (for the LC or RCN):

CC 61xx		Adapter cable 509 667-xx			Adapter cable 369 124-xx Adapter cable 369 129-xx or RCN	
Male	Assignment	Female	Color	Female	Male	Color
1	+5 V (U <sub>P</sub> )	1	Brown/ Green	7	7	Brown/ Green
2	0 V (U <sub>N</sub> )	2	White/ Green	10	10	White/ Green
3	A+	3	Green/ Black	15	15	Green/Black
4	A-	4	Yellow/ Black	16	16	Yellow/ Black
5	0 V					
6	B+	6	Blue/ Black	12	12	Blue/Black
7	B-	7	Red/Black	13	13	Red/Black
8	0 V	8	Internal shield	11	11	Internal shield
9	Do not assign					
10	Clock	10	Green	8	8	Violet
11	Do not assign					
12	Clock	12	Brown	9	9	Yellow
13	Temperature+	13	Yellow	5		
14	+5 V (sensor)	14	Blue	1	1	Blue
15	Data	15	Red	14	14	Gray
16	0 V (sensor)	16	White	4	4	White
17	Do not assign					
18	Do not assign					
19	Do not assign					
20	Do not assign					
21	Do not assign					
22	Do not assign					
23	Data	23	Black	17	17	Pink
24	0 V					
25	Temperature-	25	Violet	6		
Hsg.	Housing	Hsg.	External shield	Hsg.	Hsg.	External shield




**Note**

The interface complies with the requirements of EN 61800-5-1 for "protective extra-low voltage" (PELV).

### 3.21 Adapters for Encoder Signals

Encoder signals with  $11 \mu\text{A}_{\text{PP}}$  or TTL levels can be adapted to the  $1 \text{ V}_{\text{PP}}$  interface with HEIDENHAIN adapter connectors.



#### Note

Please note:

- The adapters adjust only the levels, not the signal shape.
- The contamination signal of the square-wave encoder cannot be evaluated.
- A square-wave signal can be subdivided no more than 4-fold.

**Adapter connector  
TTL (HEIDENHAIN)/  
1 V<sub>PP</sub>**

Pin layout of D-sub connector (female) and D-sub connector (male):

D-sub connector (female) 15-pin	Assignment	D-sub connection (male) 15-pin	Assignment
1	+5 V (U <sub>P</sub> )	1	+5 V (U <sub>P</sub> )
2	0 V (U <sub>N</sub> )	2	0 V (U <sub>N</sub> )
3	A+	3	U <sub>a1</sub>
4	A-	4	-U <sub>a1</sub>
5	Not assigned	5	Not assigned
6	B+	6	U <sub>a2</sub>
7	B-	7	-U <sub>a2</sub>
8	Not assigned	8	Not assigned
9	+5 V	9	+5 V
10	R+	10	U <sub>a0</sub>
11	0 V	11	0 V
12	R-	12	-U <sub>a0</sub>
13	Not assigned	13	Not assigned
14	<b>Do not assign<sup>a</sup></b>	14	<b>Do not assign<sup>a</sup></b>
15	Not assigned	15	Not assigned

- a. The control assigns the EnDat clock to pin 14. Therefore, you must not assign any signals to this pin when using the TTL adapter connector.

**Adapter connector  
TTL (SIEMENS)/  
1 V<sub>PP</sub>**

Pin layout of D-sub connector (female) and D-sub connector (male):

D-sub connector (female) 15-pin	Assignment	D-sub connection (male) 15-pin	Assignment
1	Not assigned	1	Not assigned
2	0 V	2	0 V
3	A+	3	U <sub>a1</sub>
4	A-	4	-U <sub>a1</sub>
5	Not assigned	5	Not assigned
6	B+	6	U <sub>a2</sub>
7	B-	7	-U <sub>a2</sub>
8	Not assigned	8	Not assigned
9	Not assigned	9	Not assigned
10	R+	10	Not assigned
11	Not assigned	11	Not assigned
12	R-	12	U <sub>a0</sub>
13	Not assigned	13	-U <sub>a0</sub>
14	Not assigned	14	Not assigned
15	Not assigned	15	Not assigned

**Adapter connector**  
**11  $\mu A_{PP}$  / 1 V<sub>PP</sub>**

Pin layout of D-sub connector (female) and D-sub connector (male):

D-sub connector (female) 15-pin	Assignment	D-sub connection (male) 15-pin	Assignment
1	+5 V ( $U_P$ )	1	+5 V ( $U_P$ )
2	0 V ( $U_N$ )	2	0 V ( $U_N$ )
3	A+	3	0°+
4	A-	4	0°-
5	0 V	5	0 V
6	B+	6	90°+
7	B-	7	90°-
8	0 V	8	0 V
9	+5 V	9	+5 V
10	R+	10	R+
11	0 V	11	0 V
12	R-	12	R-
13	0 V	13	0 V
14	Not assigned	14	Not assigned
15	Not assigned	15	Not assigned







### 3.22 Connecting the Motor Power Modules (Only CC 61xx)

The MANUALplus 620 is connected with HEIDENHAIN or non-HEIDENHAIN inverters through a PWM interface.

For a description of the HEIDENHAIN inverter systems, refer to the Technical Manual "Inverter Systems and Motors." The components required for operation of the MANUALplus 620 with non-HEIDENHAIN inverter systems are described in the manual "Technical Information for the Operation of SIMODRIVE and POWER DRIVE Inverter Systems." The individual PWM outputs of the CC 61xx are assigned to different controller groups.

For more information on the controller groups of the CC 61xx, see "Configuring the Controller Unit and Drive Motors" on page 1044.

The following applies to the output signals to the power module:

Logic level:	5 V
Analog signals I <sub>ACTL</sub> :	±7.5 V
PWM frequency:	Can be set at 3333 Hz, 4166 Hz, 5000 Hz, 6666 Hz, 8333 Hz and 10000 Hz

#### X51 to X56: PWM output

Pin layout:

Ribbon connector, 20-pin	Assignment
1a	PWM U1
1b	0 V U1
2a	PWM U2
2b	0 V U2
3a	PWM U3
3b	0 V U3
4a	SH2
4b	0 V (SH2)
5a	SH1
5b	0 V (SH1)
6a	+IACTL 1
6b	-IACTL 1
7a	0 V (analog)
7b	+IACTL 2
8a	-IACTL 2
8b	0 V (analog)
9a	BRK
9b	Do not assign
10a	ERR
10b	RDY



#### Note

The interface complies with the requirements of EN 61800-5-1 for "protective extra-low voltage" (PELV).

### 3.23 Analog Nominal Value Output

In the HSCI system, analog nominal-value outputs are available via the CMA-H 04-04-00, e.g. for controlling spindles and auxiliary axes.

The CMA-H 04-04-00 is an optional SPI expansion module (ID 688 721-xx). It adds four analog nominal-value outputs to the CC 61xx controller unit or the UEC 11x.

Controller unit	Number of CMA-H 04-04-00 modules per unit	Max. number of nominal-value outputs
CC 61xx	2	8
UEC 11x	1	4

The CMA-H 04-04-00 is supported by the following CC 61xx and UEC 11x:

- CC 6106 as of ID 662 636-01 (as of index A, Jun. 29, 2010)
- CC 6108 as of ID 662 637-01 (as of index A, Jun. 29, 2010)
- CC 6110 as of ID 662 638-01 (as of index A, Jun. 29, 2010)
- UEC 111 as of ID 625 777-02 (as of index A, Feb. 3, 2010)
- UEC 112 as of ID 625 779-02 (as of index A, Feb. 3, 2010)



#### Note

- The analog nominal-value outputs can only be accessed via the NC, and not via the PLC. The PL 6xxx provides PLC analog outputs, see "Analog PLC Inputs/Outputs" on page 235.
- It is not possible to control interpolating axes; only spindles and auxiliary axes that are not interpolated together with other digital axes can be controlled.

Properties	Socket connectors
Output:	±10 V
Smallest voltage step:	0.328 mV
Maximum load capacity of the outputs:	10 mA
Maximum capacity:	3 nF
Connection:	4 socket connectors with tension spring connection, type: Weidmüller B2L 3.5/6 SN SW 2-row, 6-pin
Connectable conductors:	Usable conductor cross sections without wire-end sleeve: 0.08 mm <sup>2</sup> to 1.0 mm <sup>2</sup> Usable conductor cross sections with wire-end sleeve: 0.14 mm <sup>2</sup> , 0.34 mm <sup>2</sup> , 0.5 mm <sup>2</sup> (only with Weidmüller PZ 6/5 crimping pliers)



#### Note

**HEIDENHAIN recommends:**



Preferably use a conductor cross section of  $0.34 \text{ mm}^2$  if you use stranded wires with wire-end sleeves. This cross section can be clamped appropriately and ensures a reliable terminal connection.

If you use stranded wires with wire-end sleeves and a conductor cross section of  $0.5 \text{ mm}^2$ , the Weidmüller PZ 6/5 crimping pliers (setting  $0.25\text{--}0.5 \text{ mm}^2$ ) must be used for crimping. In this case, orient the crimped wire-end sleeve before inserting it into the socket connector. If crimping pliers from other manufacturers are used for crimping conductors with a cross section of  $0.5 \text{ mm}^2$ , the crimped wire-end sleeves cannot be inserted into the socket connector and clamped appropriately, and therefore do not result in a reliable terminal connection.

Each CMA-H 04-04-00 has four analog outputs, see "CMA-H 04-04-00 – Pin layout" on page 257.



### 3.23.1 CMA-H 04-04-00 – Pin layout



#### CMA-H Analog outputs

X66: Analog outputs 1 and 2			
Function	Analog output 1		
Connecting terminal	1a	2a	3a
Assignment	±10 V	0 V	Shield
Function	Analog output 2		
Connecting terminal	1b	2b	3b
Assignment	±10 V	0 V	Shield

X67: Analog outputs 3 and 4			
Function	Analog output 3		
Connecting terminal	1a	2a	3a
Assignment	±10 V	0 V	Shield
Function	Analog output 4		
Connecting terminal	1b	2b	3b
Assignment	±10 V	0 V	Shield



#### Note

The terminals X46 and X47 on the CMA-H 04-04-00 are reserved for future functions and are not yet supported by the NC software. Please do not assign them.



## Note

Please note:

- Connect the shield of the connecting cable leading to the nominal-value output both to pin 3 a/b on the CMA-H and to the ground potential of the housing of the CC 61xx or UEC 11x.  
HEIDENHAIN recommends using EMC shielding terminals. The max. distance between the CMA-H and the ground point is 500 mm.
- On the analog servo amplifier, you also connect the shield of the connecting cable to the ground potential of the housing via an EMC shielding terminal.
- Use only shielded twisted-pair connecting cables.
- The connecting cables to the nominal-value outputs must not have more than one intermediate terminal.

### Configuration with MP\_analogOutput

Use **MP\_analogOutput** to assign analog auxiliary axes and analog spindles to the nominal-value outputs on the CMA-H 04-04-00, see "MP\_analogOutput" on page 669.


One CC 61xx has slots for up to two CMA-H 04-04-00 modules.

**MP\_analogOutput** = analog Output 1...4 is used to address the first CMA-H,

**MP\_analogOutput** = analog Output 5...8 is used to address the second CMA-H, see table:

Setting in MP_analogOutput	Active analog output on the CMA-H
analog Output 1	X66: Analog output 1 (SPI slot 1 on CC 61xx or UEC 11x)
analog Output 2	X66: Analog output 2 (SPI slot 1 on CC 61xx or UEC 11x)
analog Output 3	X67: Analog output 3 (SPI slot 1 on CC 61xx or UEC 11x)
analog Output 4	X67: Analog output 4 (SPI slot 1 on CC 61xx or UEC 11x)
analog Output 5	X66: Analog output 1 (SPI slot 2 on CC 61xx)
analog Output 6	X66: Analog output 2 (SPI slot 2 on CC 61xx)
analog Output 7	X67: Analog output 3 (SPI slot 2 on CC 61xx)
analog Output 8	X67: Analog output 4 (SPI slot 2 on CC 61xx)





## 3.24 Touch Probe Systems

The following touch probes can be connected to the MANUALplus 620:

- TS 220, touch-trigger probe with cable connection for workpiece setup and measurement during machining
- TS 440, TS 444, TS 640, TS 740, touch-trigger probes with infrared transmission for workpiece setup and measurement during machining
- TT 130, TT 140, touch probes for tool measurement



### Note

The touch probes are connected to the PLB 620x PLC system module or UEC 11x at X112 (TS) and X113 (TT).



### Note

For the PLB 62xx up to and including variant -02, please note:

To connect a TT touch probe to the PLB 62xx, you have to connect the touch probe adapter, ID 667 674-01, to X113 see "Adapter for connection of a TT touch probe to X113" on page 263. The adapter is supplied with the PL.

For suitable connecting cables, see "Cable Overview" at the end of the chapter.

### X112/X113: Triggering touch probe



### Note

The touch probes are connected to the PLB 620x PLC system module or UEC 11x at X112 (TS) and X113 (TT).



### Note

For the PLB 62xx up to variant -02, please note:

To connect a TT touch probe to the MANUALplus 620, you have to connect the touch probe adapter, ID 667 674-01, to X113.



## X112/X113 pin layout on PLB 62xx as of variant-03 and UEC 11x (FS):

(15-pin D-sub, triple-row)



### Note

The interface complies with the requirements of EN 60204-1:2006 for protective extra-low voltage (PELV).

Female	Assignment of X112 (TS)	Assignment of X113 (TT)
1	Trigger signal	Trigger signal
2	Trigger signal <sup>a</sup>	Trigger signal <sup>a</sup>
3	TS ready	Do not assign
4	Battery warning	Do not assign
5	+ 5 V NC ( $\pm 5$ %)	+ 5 V NC ( $\pm 5$ %)
6	TS start	Do not assign
7	TT start	TT start
8	0 V NC	0 V NC
9	0 V NC	0 V NC
10	+ 24 V NC	+ 24 V NC
11	TT ready <sup>b</sup>	TT ready
12	Do not assign	Do not assign
13	Do not assign	Do not assign
14	Do not assign	Do not assign
15	Do not assign	Do not assign

a. Stylus at rest means logic level HIGH.

b. Only if SE 642 is configured at X112 via machine parameter

Load capacity of output voltages of X112, X113:

- Socket 10, +24 V NC: max. 0.8 A
- Socket 5, +5 V NC: max. 0.8 A

The currents are total currents for X112 and X113 together; they are not the output currents per connector.



### Danger

Please note that the outputs of connectors X112 and X113 are supplied internally with 24 V NC and thus supply NC voltages derived from it at the outputs.

For the entire HSCI system, the +24 V NC supply voltage is required to be safely separated voltage. The +24 V NC supply voltage must not, under any circumstances, be connected with the +24 V PLC supply voltage, because this removes the double basic insulation.

Readiness of the TS at socket 3 is detected at a voltage of +8 V NC to +24 V NC.

Wire colors of adapter cable ID 633 608-xx for X112/X113 to TS or TT:

<b>X112/X113 on PLB 62xx or UEC 11x (FS)</b>	<b>Adapter cable 633 608-xx</b>		
	<b>Female (D-sub)</b>	<b>Male (D-sub)</b>	<b>Color</b>
1	1	Not assigned	
2	2	Pink	4
3	3	Green	5
4	4	Gray	6
5	5	Not assigned	
6	6	Blue	3
7	7	White	7
8	8	Not assigned	
9	9	White/Green	1
10	10	Brown/Green	2
11	11	Brown	8
12 to 15	12 to 15	Not assigned	



**Adapter for connection of a TT touch probe to X113**

**Only up to variant -02 of PLB 62xx:**

The items supplied with the PLB 62xx include a cable adapter with the ID 667 674-01.

If you want to connect a TT touch probe to X113 of the PLB 62xx, you need the cable adapter. It makes the Start and Ready signals of the TT touch probes available on the correct pins of X113.

**Pin layout of adapter with ID 667 674-01:**

(D-sub, 15-pin, 3-row)

Female	Assignment of X113 (TT) up to variant -02	Adapter ID 667 674-01	TT adapter cable ID 633 616-xx
1	Trigger signal	_____	Trigger signal
2	Trigger signala	_____	Trigger signala
3	TS ready	_____	Do not assign
4	Battery warning	_____	Battery warning
5	+ 5 V NC ( $\pm 5\%$ )	_____	+ 5 V NC ( $\pm 5\%$ )
6	Start	_____	Do not assign
7	0 V NC	_____	TT start
8	0 V NC	_____	0 V NC
9	0 V NC	_____	0 V NC
10	+ 24 V NC	_____	+ 24 V NC
11	TT ready	_____	TT ready
12	Do not assign	_____	Do not assign
13	Do not assign	_____	Do not assign
14	Do not assign	_____	Do not assign
15	Do not assign	_____	Do not assign



## 3.25 Data Interfaces

### X26, X116: Ethernet interface RJ45-port

- Maximum cable length:
  - Unshielded: 100 m
  - Shielded: 400 m
- Network topology: Star configuration

This means a hub serves as a central node that establishes the connection to the other participants.



#### Danger


The Ethernet interfaces of the MC 6xxx comply with the requirements of PELV ("low voltage electrical separation") according to EN 61800-5-1 and are powered internally by 24 V NC. All devices connected to these Ethernet interfaces must comply with the requirements of SELV or PELV according to EN 61800-5-1.

Maximum data transfer rate:

- For integration into the company network via NFS or SMB protocol: 10 or 100 Mbps
- For **LSV2 protocol** (in conjunction with TNCremoNT or RemoTools): 2 to 5 Mbps (depending on file type and network utilization)

RJ45 connection (female) 8-pin	Assignment
1	TX+
2	TX-
3	REC+
4	Do not assign
5	Do not assign
6	REC-
7	Do not assign
8	Do not assign
Housing	External shield

Face of the connector:



Meanings of the LEDs on the Ethernet data interface:

<b>LED</b>	<b>Status</b>	<b>Meaning</b>
Green	Blinking	Interface active
	Off	Interface inactive
Yellow	On	100 Mb network
	Off	10 Mb network

For more information on the Ethernet interface, see "The Ethernet Interface" on page 1760.



**X27:**  
**RS-232-C/V.24 data**  
**interface**

■ Maximum cable length with RS-232-C/V.24 is 20 meters

Pin layout:



Note

The interface complies with the requirements of EN 50178 for "low voltage electrical separation."

For more information on the USB interface, see "The Serial Interface of the Control" on page 1766.

25-pin adapter block:

MC 6xxx		Connecting cable 365 725-xx			Adapter block 310 085-01		Connecting cable 274 545-xx		
Male	Assignment	Female	Color	Female	Male	Female	Male	Color	Female
1	Do not assign	1		1	1	1	1	White/ Brown	1
2	RXD	2	Yellow	3	3	3	3	Yellow	2
3	TXD	3	Green	2	2	2	2	Green	3
4	DTR	4	Brown	20	20	20	20	Brown	8
5	Signal GND	5	Red	7	7	7	7	Red	7
6	DSR	6	Blue	6	6	6	6		6
7	RTS	7	Gray	4	4	4	4	Gray	5
8	CTS	8	Pink	5	5	5	5	Pink	4
9	Do not assign	9					8	Violet	20
Hsg.	External shield	Hsg.	External shield	Hsg.	Hsg.	Hsg.	Hsg.	External shield	Hsg.

9-pin adapter block:

MC 6xxx		Connecting cable 355 484-xx			Adapter block 363 987-02		Connecting cable 366 964-xx		
Male	Assignment	Female	Color	Male	Female	Male	Female	Color	Female
1	Do not assign	1	Red	1	1	1	1	Red	1
2	RXD	2	Yellow	2	2	2	2	Yellow	3
3	TXD	3	White	3	3	3	3	White	2
4	DTR	4	Brown	4	4	4	4	Brown	6
5	Signal GND	5	Black	5	5	5	5	Black	5
6	DSR	6	Violet	6	6	6	6	Violet	4
7	RTS	7	Gray	7	7	7	7	Gray	8
8	CTS	8	White/ Green	8	8	8	8	White/ Green	7
9	Do not assign	9	Green	9	9	9	9	Green	9
Hsg.	External shield	Hsg.	External shield	Hsg.	Hsg.	Hsg.	Hsg.	External shield	Hsg.



### 3.25.1 USB interface (USB 2.0)

**X141, X142, X143,  
X144**

Pin layout for USB connection (Type A):

USB connection (female) 4-pin	Assignment
1	+5 V
2	USBP-
3	USBP+
4	GND



#### Note

If USB components that are connected to one of the USB ports require more than 0.5 A, a separate power supply becomes necessary for these components. One possibility is the USB hub (USB 2.0) from HEIDENHAIN (582 884 02).

If a USB hub is connected to one of the USB ports, the maximum permissible length of the USB cable (ID 624 775-xx) is reduced to 20 m.

#### USB hub

The power supply for the USB hub must comply with EN 50 178, 5.88 requirements for "low voltage electrical separation."



For more information on the USB interface, see "The USB Interface of the Control (USB 2.0)" on page 1763.



### 3.26 MB 620T Machine Operating Panel

For lathes, HEIDENHAIN offers the MB 620T machine operating panel with HSCI interface. It is based on the MB 620 and contains in addition two override potentiometers for adjusting the spindle speed and the feed rate.

On the underside of the machine operating panel are terminal strips bearing the PLC inputs as well as the PLC outputs. Also, connection X23 (283) for HR serial handwheels is on the underside of the MB 620T.

Pin layout for MB 620T (FS)	Connector	Function	Page
	X17	Emergency stop (MB)	270
	X18	Emergency stop (MB)	270
	X500	HSCI output	171
	X502	HSCI input	171
	X6	PLC inputs	272
	X7	PLC outputs	270
	X10	Interface to keyboard and potentiometers	274
	X23	Handwheel connection	283
	X30	Connection for handwheel adapter	276
	X31	Permissive key, NC Start, NC Stop	273
	X101	24 V NC power supply	275
		Protective ground	

## **X17/X18: EMERGENCY STOP on MB**

Connectors X17 and X18 are electrically parallel.

With the MB 620T without FS, the EMERGENCY STOP must be wired externally in the EMERGENCY STOP chain as before. In the MB 620T without FS, the connectors X17 and X18 do not support dual channel evaluation of the EMERGENCY STOP button. These inputs must therefore not be used for evaluating EMERGENCY STOP!

With the MB 620T FS, the EMERGENCY STOP is evaluated by the control via HSCI and has HEIDENHAIN standard wiring.

Emergency stop buttons are to be used only for emergency stop purposes. Under normal operating conditions, a machine must not be switched off via the emergency stop buttons. The proper functioning of all emergency stop buttons must be tested annually by pressing these buttons.

Pin layout X18 on MB 620 FS (X17 without function):

<b>Connecting terminals</b>	<b>Assignment</b>
1	Power supply for emergency stop channel A (-TEST.A)
2	Emergency stop channel A
3	Power supply for emergency stop channel B (-TEST.B)
4	Emergency stop channel B

## **X7: PLC outputs**

Pin layout:

<b>Connecting terminals</b>	<b>Assignment</b>
1	O0 (illumination for the NC Start key) <sup>a</sup>
2	O1 (illumination for the NC Stop key) <sup>a</sup>
3	O2 (illumination for the Control voltage ON key) <sup>a</sup>
4	O3
5	O4
6	O5
7	O6
8	O7
9	+24 V NC (available here)
10	0 V NC (available here)

a. With standard wiring

Ampacity of the outputs: Maximum 150 mA per output



### Danger

Please note that the outputs of connector X7 are powered internally by +24 V NC, and therefore supply +24 V NC at HIGH level.

For the entire HSCI system, the +24 V NC supply voltage is required to be safely separated voltage. The +24 V NC supply voltage must not, under any circumstances, be connected with the +24 V PLC supply voltage, because this removes the double basic insulation.

Each of the switching outputs at X7 supplies up to 150 mA of output current and are provided for driving the lamps on the MP 620T.

## X6: PLC inputs

Pin layout of MB 620T without FS:

Connecting terminals	Assignment
1	I0
2	I1
3	I2 (control voltage ON, CVO) <sup>a</sup>
4	I3
5	I4
6	I5
7	I6
8	I7
9	Reserved (do not use)
10	Reserved (do not use)

a. With standard wiring

Pin layout of MB 620T FS:

Connecting terminals	Assignment
1	I0.A
2	I1.A
3	I2.A (control voltage ON, CVO.A) <sup>a</sup>
4	I3.A
5	I0.B
6	I1.B
7	I2.B (control voltage ON, CVO.B) <sup>a</sup>
8	I3.B
9	Power supply for channel A (-TEST.A)
10	Power supply for channel B (-TEST.B)

a. With standard wiring



### Danger

Please note that the MB 620T is powered by +24 V NC.

For the entire HSCI system, the +24 V NC power supply voltage is required to be safely separated voltage. It must also be safely separated from the +24 V PLC!

**X31: MB 620T,  
permissive button /  
NC start / NC stop**

Standard wiring of connection X31 for MB 620T without FS:

Connecting terminals	Assignment
1	Reserved (do not use)
2	Reserved (do not use)
3	Reserved (do not use)
4	Reserved (do not use)
5	NC Start <sup>a</sup>
6	Reserved (do not use)
7	NC Start power supply (+24 V NC) <sup>a</sup>
8	NC Stop <sub>a</sub>
9	Reserved (do not use)
10	NC Stop power supply (+24 V NC) <sup>a</sup>

a. With standard wiring

Pin layout of MB 620T FS:

Connecting terminals	Assignment
1	Optional: Permissive key channel A / terminal 1 (+24 V)
2	Optional: Permissive key channel A / terminal 2
3	Optional: Permissive key channel B / terminal 1 (+24 V)
4	Optional: Permissive key channel B / terminal 2
5	NC Start channel A / terminal 1 a
6	NC Start channel B / terminal 2 a
7	NC Start shared terminal (+24 V NC) <sub>a</sub>
8	NC Stop channel A / terminal 1a
9	NC Stop channel B / terminal 2a
10	NC Stop shared terminal (+24 V NC) <sup>a</sup>

a. With standard wiring

NC Start and NC Stop are normally-open contacts on the MB 620 (FS).




**Danger**

Please note that the MB 620T is powered by +24 V NC.

For the entire HSCI system, the +24 V NC supply voltage is required to be safely separated voltage. The +24 V NC supply voltage must not, under any circumstances, be connected with the +24 V PLC supply voltage, because this removes the double basic insulation.

## X10: Interface to keyboard and potentiometers

Designation of the terminals:



Pin layout of the ribbon cable (included):

Connecting terminals	Assignment
1a	Potentiometer 1
2a	Potentiometer 3
3a	Do not assign
4a	Do not assign
5a	Do not assign
6a	+ 5 V
7a	0 V
1b	Potentiometer 2
2b	---
3b	Do not assign
4b	Do not assign
5b	---
6b	+ 5 V
7b	0 V

**X101: Power supply** Pin layout:

Connecting terminals	Assignment
1	+24 V NC
2	0 V NC

Power consumption of the operating panel units without HR handwheel and controlled inputs/outputs:

Power consumption of the MB 620T:4.0 W

Power consumption of the PLB 6001:5.0 W



**X30: Handwheel connection, permissive button / emergency stop**

With the MB 620T without FS, the permissive buttons and the EMERGENCY STOP of the handwheel must be wired externally in corresponding safety circuits as before.

Pin layout of MB 620T FS:

Connecting terminals	Assignment
1	Permissive button channel A / terminal 1 (+24 V NC)
2	Permissive button channel A / terminal 2
3	Permissive button channel B / terminal 1 (+24 V NC)
4	Permissive button channel B / terminal 2
5	Emergency stop channel A / supply for channel A (-TEST.A)
6	Emergency stop channel A / terminal 2
7	Emergency stop channel B / supply for channel B (-TEST.B)
8	Emergency stop channel B / terminal 2

The emergency stop inputs (pin 6 and pin 8) are active even if the HR handwheel has been deactivated via machine parameter MP\_type (100601). It is therefore always necessary to wire the Emergency Stop inputs correctly.

Emergency stop buttons are to be used only for emergency stop purposes. Under normal operating conditions, a machine must not be switched off via the emergency stop buttons. The proper functioning of all emergency stop buttons must be tested annually by pressing these buttons.



**Danger**

Please note that the MB 620T is powered by +24 V NC.


For the entire HSCI system, the +24 V NC supply voltage is required to be safely separated voltage. The +24 V NC supply voltage must not, under any circumstances, be connected with the +24 V PLC supply voltage, because this removes the double basic insulation.

Connection X30 not used on MB 620T without FS.





**Machine operating  
panel: Key  
assignment**



### 3.27 HSCI Adapter for PLB 6001 OEM-Specific Machine Operating Panel

HEIDENHAIN offers the PLB 6001 HSCI adapter with HSCI interface for connecting an OEM-specific machine operating panel.

On the underside of the machine operating panel are terminal strips bearing the PLC inputs as well as the PLC outputs. Also, connection X23 for HR handwheels is on the underside of the PLB 6001 (see "Handwheel Input" on page 287).



#### Danger

Please note that the PLB 6001 is supplied with +24 V NC.

For the entire HSCI system, the +24 V NC supply voltage is required to be safely separated voltage. The +24 V NC supply voltage must not, under any circumstances, be connected with the +24 V PLC supply voltage, because this removes the double basic insulation.



PLB 6001 pin layout	Connector	Function	Page
	X500	HSCI output	171
	X502	HSCI input	171
	X6	PLC inputs	281
	X7	PLC outputs	280
	X10	Interface to keyboard and potentiometers	282
	X18	Reserved	–
	X23	Handwheel connection	287
	X30	Reserved	–
	X31	Permissive key, NC Start, NC Stop	283
	X101	24 V NC power supply	275
	X111	Potentiometer connection 1	286
	X112	Potentiometer connection 2	286
	X113	Potentiometer connection 3	286
	X121	Reserved	–
	X122	Reserved	–
	X123	Reserved	–
	X161	PLC inputs I0 to I7	285
	X162	PLC inputs I8 to I15	285
	X163	PLC inputs I16 to I23	285
	X164	PLC inputs I24 to I31	285
	X165	PLC inputs I32 to I39	285
	X166	PLC inputs I40 to I47	285
	X167	PLC inputs I48 to I55	285
	X168	PLC inputs I56 to I63	285
X171	PLC outputs O0 to O7	286	
X172	PLC outputs O8 to O15	286	
X173	PLC outputs O16 to O23	286	
X174	PLC outputs O24 to O31	286	
⊕	Protective ground	286	



### Warning

Do not engage or disengage any connecting elements while the unit is under power!

## X7: PLC outputs

Pin layout:

Connecting terminals	Assignment
1	O0 (illumination for the NC Start key) <sup>a</sup>
2	O1 (illumination for the NC Stop key) <sup>a</sup>
3	O2 (illumination for the Control voltage ON key) <sup>a</sup>
4	O3
5	O4
6	O5
7	O6
8	O7
9	+24 V NC (available here)
10	0 V NC (available here)

a. With standard wiring

Ampacity of the outputs: Maximum 150 mA per output. In the event of an overload or short circuit and as a consequence of excessive temperature, the individual PLC outputs switch off automatically. Then the outputs will try to switch on again cyclically.



### Danger

Please note that the outputs of connector X7 are powered internally by +24 V NC, and therefore supply +24 V NC at HIGH level.

For the entire HSCI system, the +24 V NC supply voltage is required to be safely separated voltage. The +24 V NC supply voltage must not, under any circumstances, be connected with the +24 V PLC supply voltage, because this removes the double basic insulation.

Each of the switching outputs at X7 supplies up to 150 mA of output current. They are provided for driving the lamps on the operating panel.

## X6: PLC inputs

Pin layout of PLB 6001 without FS:

Connecting terminals	Assignment
1	I0
2	I1
3	I2 (control voltage ON, CVO) <sup>a</sup>
4	I3
5	I4
6	I5
7	I6
8	I7
9	Reserved (do not use)
10	Reserved (do not use)

a. With standard wiring




### Danger

Please note that the PLB 6001 is supplied with +24 V NC.

For the entire HSCI system, the +24 V NC power supply voltage is required to be safely separated voltage. It must also be safely separated from the +24 V PLC!

## X10: Interface to keyboard and potentiometers

Designation of the terminals:



Pin layout of the ribbon cable (included, length 54 cm):

Connecting terminals	Assignment
1a	Potentiometer 1
2a	Potentiometer 3
3a	Do not assign
4a	Do not assign
5a	Do not assign
6a	+ 5 V
7a	0 V
1b	Potentiometer 2
2b	---
3b	Do not assign
4b	Do not assign
5b	---
6b	+ 5 V
7b	0 V

### X23: Handwheel input

Pin layout:

D-sub connector (female) 9-pin	Assignment
1	CTS
2	0 V
3	RTS
4	+12 V
5	Do not assign
6	DTR
7	TxD
8	RxD
9	DSR
Housing	External shield



#### Note

The interface complies with the requirements of EN 61800-5-1 for "protective extra-low voltage" (PELV).



#### Danger

The connector for the handwheel on the machine operating panel, as well as the connector on the handwheel itself, may be removed only by trained and qualified personnel, even if it can be removed without using a tool. If the handwheel connector is removed, only basic insulation from line power (230 V) is provided!

### X31: Permissive button/NC start, NC stop

Connection X31 of PLB 6001:

Connecting terminals	Assignment
1	Reserved (do not use)
2	Reserved (do not use)
3	Reserved (do not use)
4	Reserved (do not use)
5	NC start
6	Reserved (do not use)
7	NC Start power supply (+24 V NC)
8	NC Stop
9	Reserved (do not use)
10	NC Stop power supply (+24 V NC)



### Danger

Please note that the MB 620 is powered by +24 V NC.

For the entire HSCI system, the +24 V NC supply voltage is required to be safely separated voltage. The +24 V NC supply voltage must not, under any circumstances, be connected with the +24 V PLC supply voltage, because this removes the double basic insulation.





**X161 to X168:  
PLC inputs**

<b>X161: PLC inputs</b>									
<b>Assignment</b>	<b>Terminal</b>								
	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>
PL 6001	0 V PLC	I0	I1	I2	I3	I4	I5	I6	I7

<b>X162: PLC inputs</b>									
<b>Assignment</b>	<b>Terminal</b>								
	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>
PL 6001	0 V PLC	I8	I9	I10	I11	I12	I13	I14	I15

<b>X163: PLC inputs</b>									
<b>Assignment</b>	<b>Terminal</b>								
	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>
PL 6001	0 V PLC	I16	I17	I18	I19	I20	I21	I22	I23

<b>X164: PLC inputs</b>									
<b>Assignment</b>	<b>Terminal</b>								
	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>
PL 6001	0 V PLC	I24	I25	I26	I27	I28	I29	I30	I31

<b>X165: PLC inputs</b>									
<b>Assignment</b>	<b>Terminal</b>								
	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>
PL 6001	0 V PLC	I32	I33	I34	I35	I36	I37	I38	I39

<b>X166: PLC inputs</b>									
<b>Assignment</b>	<b>Terminal</b>								
	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>
PL 6001	0 V PLC	I40	I41	I42	I43	I44	I45	I46	I47

<b>X167: PLC inputs</b>									
<b>Assignment</b>	<b>Terminal</b>								
	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>
PL 6001	0 V PLC	I48	I49	I50	I51	I52	I53	I54	I55

<b>X168: PLC inputs</b>									
<b>Assignment</b>	<b>Terminal</b>								
	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>
PL 6001	0 V PLC	I56	I57	I58	I59	I60	I61	I62	I63



## X171 to X174: PLC outputs

X171: PLC outputs									
Assignment	Terminal								
	1	2	3	4	5	6	7	8	9
PL 6001	O0	O1	O2	O3	O4	O5	O6	O7	24 V PLC for O0 to O7

X172: PLC outputs									
Assignment	Terminal								
	1	2	3	4	5	6	7	8	9
PL 6001	O8	O9	O10	O11	O12	O13	O14	O15	24 V PLC for O8 to O15

X173: PLC outputs									
Assignment	Terminal								
	1	2	3	4	5	6	7	8	9
PL 6001	O16	O17	O18	O19	O20	O21	O22	O23	24 V PLC for O16 to O23

X174: PLC outputs									
Assignment	Terminal								
	1	2	3	4	5	6	7	8	9
PL 6001	O24	O25	O26	O27	O28	O29	O30	O31	24 V PLC for O24 to O31

Ampacity of the outputs: Maximum 150 mA per output

Please note that the outputs of connectors X171 to X174 are galvanically isolated internally from the +24 V NC supply voltage supplied via X101. The outputs can therefore be supplied with +24 V PLC or +24 V NC.

For the entire HSCI system, the +24 V NC supply voltage is required to be safely separated voltage. The +24 V NC supply voltage must not, under any circumstances, be connected with the +24 V PLC supply voltage, because this removes the double basic insulation.

## X111 to X113: Potentiometer connection

Pin layout:

Connecting terminals	Assignment
1	0 V potentiometer
2	Potentiometer arm
3	+5 V potentiometer

## 3.28 Handwheel Input

The following handwheels can be used with the MANUALplus 620.

- HR 130 panel-mounted handwheel
- HR 180 panel-mounted handwheel for connection to the position input at CC 61xx
- Up to three HR 150 panel-mounted handwheels via HRA 110 handwheel adapter
- HR 410 portable handwheel

The handwheel is connected to the MANUALplus 620 via X23 on the MB 620T machine operating panel.

### 3.28.1 HR 410 portable handwheel

The HR 410 is a portable electronic handwheel.

For the assignment of the keys of the HR 410 to the PLC inputs and outputs, see "HR 410 portable handwheel" on page 1348.

#### Pin layout


Pin layout for the various extension cables, adapter cables, connecting cables, and the handwheel:

Extension cable, ID 281 429-xx			Adapter cable, ID 296 466-xx			Connecting cable ID: see "Introduction" chapter			HR 4xx	
D-sub connector (male) 9-pin		D-sub cncntr. (female) 9-pin	D-sub connector (male) 9-pin		Cplg. on mntg. base (female) (5+7)-pin	Cnnctr. (male) (5+7)-pin		Cnnctr. (female) (5+7)-pin	Connector (male) (5+7)-pin	
Housing	Shield	Housing	Housing	Shield	Housing	Housing	Shield	Housing	Housing	Shield
2	White	2	2	White	E	E	White	E	E	
4	Brown	4	4	Brown	D	D	Brown	D	D	
6	Yellow	6	6	Yellow	B	B	Yellow	B	B	
7	Gray	7	7	Gray	A	A	Gray	A	A	
8	Green	8	8	Green	C	C	Green	C	C	
					6	6	BK	6	6	
					7	7	RD/BL	7	7	
					5	5	Red	5	5	
					4	4	Blue	4	4	
					2	2	WH/GN	2	2	
					3	3	BN/GN	3	3	
					1	1	GY/PK	1	1	
					WH/BN	3			Contacts 1 + 2	
					WH/YL	2			Contact 2 (left) permissive button	
					WH/GN	1			Contact 1 (right)	
					WH/BL	1			Contact 1	
					WH/RD	2			Contact 1 emergency stop	
					YL/BK	3			Contact 2	
					WH/BK	4			Contact 2	

The adapter includes plug-in terminal strips for the contacts of the emergency stop button and permissive button (max. load 24 V-, 1.2 A).

The plug-in terminal strips are supplied together with the adapter cable. If you have an immediate need for these terminal strips, they can be ordered in advance. See the "Additional components" table below.

Internal wiring of the contacts for the emergency stop button and permissive button:



Additional components	ID
Dummy plug for emergency stop circuit	271 958-03
<b>Connecting cable</b>	
Spiral cable	312 879-01
Normal cable	296 467-xx
Metal armor	296 687-xx
<b>Plug-in terminal strips for advance ordering</b>	
3-pin terminal block	266 364-06
4-pin terminal block	266 364-12

### 3.28.2 HR 130 panel-mounted handwheel

The standard cable length for the HR 130 is 1 meter.


Pin layout for extension cable and handwheel:

Extension cable, ID 281 429-xx			HR 130 ID 254 040-xx	
D-sub connctr. (male) 9-pin		D-sub connctr. (female) 9-pin	D-sub connctr. (male) 9-pin	
Housing	Shield	Housing	Housing	Shield
2	White	2	2	White
4	Brown	4	4	Brown
6	Yellow	6	6	Yellow
8	Green	8	8	Green
7	Gray	7		

### 3.28.3 HRA 110 handwheel adapter

With the handwheel adapter you can connect two or three HR 150 panel-mounted handwheels to the MANUALplus 620.

The first and second handwheels are permanently assigned to two axes through **MP\_selectAxes** (CfgHandwheel). The third handwheel can be assigned through a selection switch (option). You also use **MP\_selectAxes** to define the axes for the third handwheel. (See "MP\_selectAxes" on page 1338.)



An additional switch enables you to select, for example, the interpolation factor for the handwheels. In the PLC you must evaluate the current position of the handwheel selection switch and activate the corresponding interpolation factor with Module 9036.

#### X1 to X3: Inputs on the HRA 110 for the HR 150

Pin layout:

HRA 110	
Connection (female) 9-pin	Assignment
1	$I_1 +$
2	$I_1 -$
5	$I_2 +$
6	$I_2 -$
7	$I_0 -$
8	$I_0 +$
3	+ 5 V
4	0 V
9	Internal shield
Housing	External shield

### X23: Connection to MB 620 / MB 620T

Pin layout on the HRA 110:

HRA 110	
D-sub connector (female) 9-pin	Assignment
1	RTS
2	0 V
3	CTS
4	+12 V +0.6 V ( $U_V$ )
5	Do not assign
6	DSR
7	RxD
8	TxD
9	DTR
Housing	External shield

### X31: HRA 110 supply voltage

Pin layout on the HRA 110:



#### Warning

The power supply of the PLC must not be used simultaneously for the HRA 110, otherwise the metallic isolation of the PLC inputs/outputs would be bridged.

HRA 110	
Connecting terminal	Assignment
1	+24 V– as per IEC 742 (VDE 551)
2	0 V

Maximum current consumption 200 mA.

### HR 180 panel-mounted handwheel

The **HEIDENHAIN HR 180 panel-mounted handwheels** supply  $1 V_{PP}$  signals. They are connected with the connecting cable ID 310 199-xx to the position inputs X201...X20x of the CC61xx or UEC11x (see "Position encoder input" on page 243).

## 3.29 CML 110 Capacitor Module



### Danger

Before service or maintenance work, you must ensure that the CML 110 has been completely discharged.

The CML 110 (Capacitor Module Low Voltage) can be used to realize the LIFT-OFF function if line power fails.

The LIFTOFF function can protect workpieces and tools from damage. When a power failure occurs and the LIFT OFF function is active, the MANUALplus 620 tries to lift the tool off of the contour, using the residual energy of the DC-link. In this case, the various enablings for operating the control system must be maintained during the LIFTOFF. The CML 110 ensures the 24 V supply for this.

### Connection

The CML 110 capacitor module is connected via X1 parallel to the 24 V power supply (+ +/ -).

The two ++ and -- terminals of the CML 110 are each connected to each other internally. This makes it possible to connect several CMLs 110 in parallel without needing to use additional external terminals.

### Utilizability

Calculating the utilizability of the CML 110:

A successful LIFTOFF mainly depends on sufficient energy being available in the DC-link of the inverter system. Generally it suffices if the energy in the DC-link is available for the duration of one second. The 24 V supply must also be ensured for precisely this time. The following formula can be used to check this:

$$t = R_L \times C \times \ln(U_O/U_C)$$

where:

t = time until  $U_C$  is reached

$R_L$  = ohmic load of the consumers

C = capacitance of the CML (for CML 110 = 8.3 F)

ln = natural logarithm

$U_O$  = output load of the power supply unit with which the CML is operated

$U_C$  = lowest voltage at which the consumers still fulfill their function

Example:

During operation at 24 V, a total current of 10 A is required for switching the control components on. This corresponds to an ohmic load of 2.4 ohms. In addition, the voltage for the 24 V components may not sink below 18 V (e.g. switching voltage of the contactors), for example.

This means:

$$t = 2.4 \text{ Ohm} \times 8.3 \text{ F} \times \ln(24 \text{ V}/18 \text{ V})$$

$$t = \mathbf{5.73 \text{ s}}$$

If the line voltage fails, then in the best case the voltage will not fall below 18 V until 5.73 seconds have passed. This is significantly longer than 1 second, and so the CML 110 is suitable for LIFTOFF here.





If the capacitance of the CML 110 should not suffice, then you can also switch more than one CML 110 in parallel. However, here you must note that a maximum charging current of 2.4 A per CML 110 is to be expected at switch-on. The full power of the 24 V power supply unit can only be used once all CMLs have finished charging.



### 3.30 Connecting Cables: Specifications

Device	ID number	Max. bend radius (rigid configuration)	Max. bend radius (frequent flexing)	Cable diameter
HSCI	618 893-xx	≥ 40 mm	≥ 100 mm	ø 6.8 mm
Position 1 V <sub>PP</sub>	298 429-xx, 298 430-xx	≥ 20 mm	≥ 75 mm	ø 6 mm
Position 1 V <sub>PP</sub>	310 199-xx, 309 783-xx	≥ 40 mm	≥ 100 mm	ø 8 mm
Position EnDat	332 115-xx, 323 897-xx	≥ 40 mm	≥ 100 mm	ø 8 mm
Position EnDat	313 791-xx, 332 790-xx	≥ 20 mm	≥ 75 mm	ø 6 mm
Speed 1 V <sub>PP</sub>	289 440-xx, 336 376-xx	≥ 40 mm	≥ 100 mm	ø 8 mm
Speed EnDat	336 376-xx, 340 302-xx, 369 502-xx	≥ 40 mm	≥ 100 mm	ø 8 mm
Analog output	290 110-xx, 290 109-xx	≥ 40 mm	<sup>a</sup>	ø 7.3 mm
TS 220	274 543-xx	≥ 40 mm	≥ 100 mm	ø 8 mm
SE 640, SE 540	310 197-xx, 517 518-xx	≥ 40 mm, ≥ 10 mm	≥ 100 mm, ≥ 50 mm	ø 8 mm ø 4.5 mm
HR 130, HR 410 (extension cable)	281 429-xx	≥ 20 mm	<sup>a</sup>	ø 5.6 mm
HR 410 (extension cable)	296 466-xx	≥ 20 mm	<sup>a</sup>	ø 5.6 mm
HR 410	296 687-xx	≥ 40 mm	≥ 100 mm	ø 8 mm
RS232, 9-pin	355 484-xx	≥ 20 mm	≥ 75 mm	ø 6 mm
RS232, 9-pin (extension cable)	366 964-xx	≥ 20 mm	≥ 75 mm	ø 6 mm
RS232, 25-pin	365 725-xx	≥ 40 mm	≥ 100 mm	ø 7.1 mm
RS232, 25-pin (extension cable)	274 545-xx	≥ 20 mm	≥ 75 mm	ø 6 mm
USB <sup>b</sup>	354 770-xx	≥ 20 mm	≥ 75 mm	ø 4.5 mm
USB (with hub) <sup>c</sup>	624 775-xx	Cable like 354 770-xx, hub: ø ~ 20 mm, length ~ 115 mm		

a. Conditionally resistant to frequent flexing and torsion

b. These USB cables support USB 1.1 and USB 2.0

c. The hubs integrated in the USB cable (ID 624 775-xx) only support USB 1.1

#### Cables – Instructions for wiring

Keep the following in mind for wiring inside the electrical cabinet:

The stray magnetic field of a KDR 1xx commutating reactor can disturb conductors routed in its proximity. This means that no conductors (such as dc-voltage lines and signal lines), except for the power connections of the motor and the connections between the UVR 1xx and KDR 1xx, should be routed in the proximity of the KDR 1xx. HEIDENHAIN recommends leaving a space of 20 cm around the commutating reactor. This distance is to be maintained regardless of the KDR 1xx used.

### 3.31 Dimensions




Note

All dimensions are in millimeters [mm].




### 3.31.1 MC 6110T

Weight: 5.6 kg




### 3.31.2 MB 620T


Weight: 1.2 kg




### 3.31.3 CC 6106



### 3.31.4 CC 6108 / CC 6110




### 3.31.5 UEC 11x (FS)






### 3.31.6 PL 6xxx (FS)

Weight: 1.0 kg




Dashed line: Space for air circulation

### 3.31.7 PLB 6001(FS)




### 3.31.8 PSL 130






### 3.31.10 MS 11x




### 3.31.11 Adapter block for the data interface

RS-232-C/V.24 adapter block and  
RS-422/V.11 adapter block




### 3.31.12 USB hub




### 3.31.13 Line-drop compensator

Line drop compensator for encoders with EnDat interface



### 3.31.14 Handwheels


#### HR 410








## Adapter cable







## Adapter cable for TT and TS

Mounted coupling for quick connection




Mounted coupling for HEIDENHAIN standard connector:







Adapter cable for  
TS 120/TS 220




**SE 640 transmitter-receiver unit**




**SE 540 transmitter-receiver unit**












### 3.31.16 CML 110




### 3.31.17 USB hub for operating panel




3.32 HSCI Connection Overview of the MANUALplus 620 with CC 61xx



3.33 HSCI Connection Overview of the MANUALplus 620 with UEC 11x



### 3.34 Grounding Diagram for MANUALplus 620 with Modular HEIDENHAIN Inverter System



### 3.35 Basic Circuit Diagram for MANUALplus 620


You can find the current basic circuit diagrams in the download area of the HEIDENHAIN FileBase on the Internet at <http://filebase.heidenhain.de>. For this area you need access rights that you can request via e-mail.



### 3.36 Cable Overview for MANUALplus 620 with UEC 11x – Basic Configuration

VL: Extension cable  
 – for separation points with connecting cable  
 – for extending existing connecting cable


HSCI total length 100 m 27.07.2011








### 3.38 Cable Overview for HEIDENHAIN Inverter System



### 3.39 Cable Overview for MANUALplus 620 – Accessories



# 4 Machine Parameters

## 4.1 General Information

A control must have access to specific machine data (e.g. traverse distances, acceleration, speeds) before it can execute its programmed instructions. You define these data in machine parameters. Each machine has its own set of machine parameters.

The parameter values are entered in the **configuration editor**. This document also uses the abbreviated form "config editor" to refer to the configuration editor.

The machine parameters are grouped as parameter objects in a tree structure in the configuration editor. As an alternative you can use unique parameter numbers to access the desired machine parameters directly (see "Accessing machine parameters via MP numbers" on page 342).

The machine parameters are saved in **parameter files** with the extension **.cfg** on the **TNC:\**, **PLC:\** and **SYS:\** drives.

These drives should always be addressed with the system variables %OEM% ( PLC:\ ), %SYS% ( SYS:\ ) and %USR% ( TNC:\ ).



### Note

Only use the configuration editor to make your changes to the machine configuration!  
Only in exceptional cases should the \*.cfg files be edited directly. This could accidentally lead to faulty syntax, which would prevent the control from starting up.

The parameter objects appear as folders in the configuration editor. Each parameter object (also referred to as entity, data object or object) has a name (beginning with **Cfg...**) that gives information about the machine parameters it contains.

Depending on the function, the parameters are differentiated into system-specific, channel-specific and axis-specific types. Each object has a **key** for unique identification. The key name can have a maximum of 18 characters.

The following applies:

- **System data** (parameters that are valid for the entire system) only occur once. The configuration editor does not require a key name for these parameters, nor is one entered. These objects are identified with an "empty" key in the \*.cfg files.
- **Parameter objects that apply to axes** occur more than once. A unique key name is assigned to each axis. All objects that apply to a certain axis must be identified with this key. You can choose and specify the individual key names yourself, or you can use the predefined key names supplied by HEIDENHAIN.

Example:

- The key name "X" or "X axis" for all objects that belong to the X axis
- The key name "S" or "S axis" for all objects that belong to the spindle

■ **Parameter objects that apply to channels** occur more than once. A unique key name is assigned to each channel. All objects that apply to a certain channel must be identified with this key.

Example:

- Key name "CH\_NC" for all objects that belong to the channel for executing the NC program
- Key name "CH\_SIM" for all objects that belong to the channel for simulating the NC program




#### Note

Key names should be short and clear, and refer to the function.



## 4.2 The "Machine Parameters" Mode of Operation
















### 4.2.1 Calling the configuration editor

- ▶ Switch to the **Organization** mode of operation.
- ▶ Press the  soft key.
- ▶ Enter the code number **95148** or press the **CONFIG EDIT** soft key if the code number was already entered
- ▶ Press the **END** soft key to exit the **Machine Parameter** mode of operation.




## Soft keys

The following functions can be called through the soft-key row of the **Machine Parameters** mode of operation's opening screen:

Soft key	Function
	Sorts the contents of the *.cfg files
	Backs up the machine parameters
	Activates MP subfiles
	Selects various data records
	Path information for the *.cfg files of the machine configuration
	Opens the configuration editor for editing the machine parameters in tree or table view
	Calls additional functions
	Shuts down/restarts the control
	Appears dimmed during normal operation. Only active after a software update or with faulty configuration data. Used for finding and fixing errors in the machine configuration.
	Displays and edits rules for the software exchange
	Resetting the update version
	Protects data from unauthorized access
	Displays access rights, selection lists, limit values and units of measurement
	Return to the previous menu
	Exits the <b>Machine Parameter Programming</b> mode of operation

## 4.2.2 Entering and changing machine parameters

After pressing the **CONFIG DATA** soft key, the object tree for the machine parameters is displayed.



The **Parameter:** line above the object tree shows the unique MP number of the currently selected machine parameter or object folder (see "Accessing machine parameters via MP numbers" on page 342). If the help function is open or the table view is active, you can see the current input value next to the MP number, as well as the parameter's unit of measure, if there is one.

The actual machine parameters with their values are located on the lowest level of the tree.

The cursor is positioned within the tree either with the arrow keys or with the optionally connected USB mouse.

To open a branch:

- ▶ Press the **+** key or **ENT** key or the right arrow key, or click the folder symbol with the left mouse button

To close a branch:











- ▶ Press the **-** key or **ENT** key or the left arrow key, or click the folder symbol with the left mouse button

Double-click the parameter symbol with the left mouse button or press the **ENT** key to open the editing window.




Soft keys and screen buttons can also be clicked with the mouse.

## Icons in the object tree

A symbol (icon) is displayed at the beginning of each line in the parameter tree. The icons have the following meanings:

Icon	Function
	Branch is closed
	Branch is open
	Empty parameter object, cannot be opened
	Initialized machine parameter
	Uninitialized (optional) machine parameter
	Machine parameter was changed but not saved yet
	Machine parameter or parameter object can be read but not changed
	Machine parameter or parameter object cannot be read
	Machine parameter with comment
	Derived parameter set (KEY SYNONYM function)

The type of the configuration object is identified by its folder symbol:

Icon	Function
	Entity (object)
	Array (list)
	Key (key name)



## Table view

You can activate a table view in the configuration editor. This is especially useful for the configuration of parameter blocks, since now the parameters of all axes are visible at a glance:

Machine | smart.Turn | Tool editor | Machine par.

Basic data  
Parameter: PS1\_0.400004 = 360 [mm]

	PS1_0	PS1_1	PS1_2	PS1_3	PS1_C1	PS2_0	PS3_0
CfgAxisHardware							
signCorrActualVal	off	off	off	off	off	off	off
signCorrNominalVal	off	off	off	off	off	off	off
posEncoderType	CC_MOTOR...	CC_MOTOR...	CC_MOTOR...	CC_MOTOR...	CC_MOTOR...	CC_MOTOR...	CC_MOT...
distPerMotorTurn	360	360	360	360	360	360	360
posEncoderDist	360	360	360	360	360	360	360
posEncoderIncr	2048	2048	2048	2048	2048	2048	2048
posEncoderRefDist	1000	1000	1000	1000	1000	1000	1000
genExtIntPolFactor							
posEncoderInput	none	none	none	none	none	none	none
posEncoderSignal	1 Vss	1 Vss	1 Vss	1 Vss	1 Vss	1 Vss	1 Vss
posEncoderFreq	fast	fast	fast	fast	fast	fast	fast
posEncoderResistor	without	without	without	without	without	without	without
speedEncoderInput	X17	X17	X17	X17	X17	X18	X19
pwmSignalOutput	X53	X53	X53	X53	X53	X54	X55
ctrlPerformance							
hsciCcIndex							

PAGE ↑ | PAGE ↓ | FIND | HELP PAGE | VIEW TABLE | STORE | MORE FUNCTIONS | END


All editing functions available in the tree view are also available in the table view. Changed table columns are highlighted dark blue. The **Info** key of the operating panel can also be used in the table view to call the help function.

## Detailed text view

Press the **SHOW SYSTEM NAME** soft key to have the name of the parameter tree be shown in detail, or as the system short-form text:




- ▶ Press the "split screen layout" key to the left of the control's TFT flat panel screen.
- ▶ Press the **SHOW SYSTEM NAME** soft key: the control now shows the folder and parameter names in detail.
- ▶ Press the **SHOW SYSTEM NAME** soft key again to switch the display back to the system short-form name.



## Displaying help texts

The **Info** key enables you to call a help text for each parameter object or attribute.



If the help text does not fit on one page (1/2 is then displayed at the upper right, for example), press the **HELP PAGE** soft key to scroll to the second page.



Additional information, such as the unit of measure, the initial value, or a selection list, is also displayed. If the selected machine parameter matches a parameter in the iTNC 530, the corresponding compatible MP number is shown.

To exit the help text, press the **Info** key again.



## Entering and changing parameters

In order to change machine parameters, you must open an input or selection field by pressing the right arrow key, the **ENT** key or the **CHANGE VALUE** soft key, or by double-clicking the selected parameter:



Open and close selection lists (pull-down menus) by pressing the GOTO key or clicking the arrow symbol. Use the arrow keys (up and down) or the mouse to navigate through the pull-down menu. Press the **ENT** key to select the desired value from the list.

Units of measure can be defined for numeric machine parameters. The unit of measure assigned to this parameter is displayed. Enter a value appropriate to this unit.

When editing a numerical value, you can also switch the number system. You can choose between decimal (DEC), hexadecimal (HEX) and binary (BIN). The current value entered is converted when the number system is switched.

## Limit values

Limit values are preset for numeric machine parameters. If you attempt to enter a value outside of these limits, a message is issued and the entry is not accepted.


## Deleting objects

Press the **DELETE** soft key to delete objects or parameters from a list (an axis, for example).

## Inserting and copying objects

Press the **MORE FUNCTIONS** and **INSERT** or **COPY** soft keys to insert or copy objects or items in lists (an axis, for example). Items in lists (arrays) are inserted after the cursor.

When inserting an object, the object name (key name) and memory file must be given. The memory file is the \*.cfg file in which the inserted object is to be saved. Press the up or down arrow keys and the **ENT** key to select the file. Open the pull-down menu by pressing the GOTO key.




Insert data object

Key name?  
ParSatzB-0

Storage file?  
0:\config\axis\_b.cfg

OK CANCEL



Copy data object

Previous key name  
ParSatzB-0

Key name?  
ParSatzC-0

Storage file?  
0:\config\axis\_c.cfg

OK CANCEL

The icons of empty objects, lists and parameters appear dimmed. They can be activated with the **INSERT** soft key.

## Copying and inserting values

When a dialog box for entering a value is open, you can use the **COPY FIELD** soft key to copy the content of the current parameter to the clipboard. The value you have copied can be inserted with the **PASTE COPIED VALUE** soft key at any other location in the configuration if an entry dialog is open.

## Changing key names

Press the **CHANGE KEY NAME** soft key to change the key name of an object, for example, from Kinem1 to Kinem\_XYZ.

## Saving input values

The input values are buffered with the **OK** soft key. The **CANCEL** soft key closes the dialog box without buffering the value. All changes that have been made but not yet saved are marked with a symbol on the left side of the screen.

Press the **SAVE** soft key to actually save the changes you have made.


Certain data cannot be stored while an NC program is running. The message **Cannot change parameter during program run** appears. In this case the program must first be stopped and exited. Then the data can be saved.

Some data take effect as soon as they have been saved.

Others require that the axes be referenced again, or that the system be restarted. This is indicated in a corresponding message.

## Change list

A machine-parameter change list is displayed after pressing the **SAVE** or **END** soft key. The **Configuration data changed** window gives you an overview of all changed parameters. You can save, discard or cancel the changes:



The control also saves a list of the last 20 changes to the configuration data. In this list you can see all changes performed, and can undo any of them. The change list is maintained upon power-off of the control. The change list is reached in the configuration editor via the **MORE FUNCTIONS** and **DISCARD CHANGES** soft keys.

Settings in the configuration editor	MP number
System	
CfgConfigSettings	
<b>undoListSize</b>	106501
<b>dispParamNumbers</b>	106503

With the **MP\_undoListSize** parameter you can specify the number of entries in the change list:

### MP\_undoListSize

Specifies the number of entries in the change list  
Available from NCK software version: 597 110-04.

Format: Numerical value  
Default: 20  
Access: LEVEL3  
Reaction: NOTHING

With the **MP\_dispParamNumber** parameter you specify whether the number of machine parameters or the symbolic name is displayed in the change list.

### MP\_dispParamNumbers


Display the symbolic names or the number of machine parameters in the change list  
Available from NCK software version: 597 110-04.

Format: Selection menu  
Selection: TRUE  
Number of the machine parameter is displayed  
FALSE  
Symbolic name of the machine parameter is displayed.  
Default: No value, parameter optional (= FALSE)  
Access: LEVEL3  
Reaction: NOTHING

## Finding/Replacing

You can search for and replace objects and parameters within the configuration editor using a dialog box.

Open the dialog box with the **FIND** soft key.



You can specify which areas of the machine configuration are to be searched. This is done by ticking the respective area on the left-hand side of the dialog box. You can also select more than one area at the same time for searching. The following possibilities for searching are available:

<b>Selection</b>	<b>Function</b>
<b>Names</b>	Search for object and parameter names.  You can also enter just a part of the text to be searched for as search criteria in the <b>Find text:</b> field. The <b>CURRENT WORD</b> button and soft key load the term marked with the cursor into the search field. The search term can be written in capitals or small letters.
<b>Numbers</b>	Search for an MP number. You can also enter just part of the number to be found.
<b>MP number</b>	Search for the compatible iTNC MP number. In many parameters the parameter number of the iTNC 530 contouring control is displayed in the help text. After this function is selected and an iTNC parameter number is entered, the configuration is searched for equivalents.
<b>Values</b>	Search for certain parameter values.  As soon as you have selected the <b>Values</b> function, the <b>Replace with:</b> input field becomes active.  By entering a value in the "Replace with" field, you can change the string found by pressing the <b>REPLACE</b> soft key. This replacement only affects the current search hit.
<b>Key name</b>	Search for a certain key name.  As soon as you have selected the <b>Key name</b> function, the <b>Replace with:</b> input field becomes active.  By entering a value in the "Replace with" field, you can change the string found by pressing the <b>REPLACE</b> soft key. This replacement only affects the current search hit.
<b>Comment</b>	Search for certain user comments. (see "User comment" on page 341.)

If the machine configuration has been searched down to the end or up to the beginning (depending on the search direction) and the search term has not been found, the control inquires whether the search is to be continued in the direction opposite to the selected one.



### **User comment**

You can comment objects. A dialog box for entering a comment is opened after pressing the **MORE FUNCTIONS** and **COMMENT** soft keys. A maximum of four comment lines can be entered.

Objects with comments are displayed on the right side of the parameter tree and are identified with the letter "i." The complete text, including the help text for the object, appears after you press the **COMMENT** soft key.

The current value of a parameter can be buffered together with the comment and can, for example, be reactivated later.

### **Finish editing**


Press the **END** soft key to return to the main menu of the **Machine Parameter** mode of operation.

If any changes have been made, the control displays the **Configuration data changed** window (see "Saving input values" on page 338).

### 4.2.3 Accessing machine parameters via MP numbers

In order to reach a certain point in the machine configuration as quickly and directly as possible, a unique MP number has been assigned to each machine parameter.


The MP number is shown above the object tree or the table view in the **Parameter:** line. The current input value, as well as the parameter's unit of measure, if there is one, are shown after the MP number:



The MP number consists of a 6-digit number. The key name precedes the 6-digit MP number, and the index number (e.g. for list parameters) is appended to the MP number. The three parts are each separated by a period.

The MP numbers are permanently assigned to a specific configuration object or machine parameter, and can occur more than once in the system, for example in the axis-parameter sets or in the kinematics configuration. The prefixed key names then serve to distinguish between the numbers.

Structure of an MP number:




## Parameter groups

Similar to the parameter tree-structure of the control, the MP numbers are collected in groups:


Machine parameters	Group
100000 to 199999	System configuration + miscellaneous
200000 to 299999	Channel-dependent settings
300000 to 399999	Axis configuration
400000 to 499999	Parameter blocks
500000 to 599999	Range of parameters for TNC milling (displayed only on HEIDENHAIN milling controls)
600000 to 699999	Range of parameters for CNC lathe machining
700000 to 799999	Range of parameters for grinding (displayed only on HEIDENHAIN grinding controls)
800000 to 899999	Reserved
900000 to 999999	Number range for OEM parameters

## GOTO key

Press the GOTO key on the control's operating panel to jump directly to any MP number. If the GOTO key is pressed while in the configuration parameter, the **Go to** dialog box appears:



If an MP number exists more than once in the configuration (e.g. axis parameters), the control displays the available parameters as soon as you have entered the entire number. You can then select the desired parameter and jump to it by pressing the **ENT** key.



## Defining numbers for OEM parameters

The machine configuration of the control enables you to make your own PLC machine parameters through the config objects **CfgOemBool**, **CfgOemInt**, **CfgOemString** and **CfgOemPosition**, see "Data transfer machine parameters => PLC" on page 1657. The following describes how you can assign your own MP numbers to these PLC machine parameters. The number range 900000 to 999999 is available so that the OEM can group his own parameters and find them better.

The numbering of the OEM parameters is configured over a dedicated XML file. This XML file must be called **PlcUniqueNumbers.xml** and saved in the **PLC:\config\layout** folder. The file is optional—if the file is not available, the OEM parameters are not specially numbered.



### Note

The OEM parameter must be known to the system for it to be assigned a number. So first configure all required OEM parameters using the config editor, then specify the assignment to the OEM specific numbers.

In the following example, the number 901000 is assigned to an OEM position value (CfgOemPosition) with the designation **NP\_LimitSwitch1**:

```
<?xml version="1.0" encoding="utf-8"?>
<UniqueNumbers xmlns="http://www.hng.ch/UniqueNumbers/1"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
xsi:schemaLocation="http://www.hng.ch/UniqueNumbers/1
UniqueNumbers.xsd">
  <!-- PLC parameters -->
  <Group Number="9">
    <OemGroup>
      <Parameter Number="01000" Name="CfgOemBool-NP_LimitSwitch1
      -value"/>
    </OemGroup>
  </Group>
</UniqueNumbers>
```

Note that the name of the config object, the key name (in this case the name of the operand) and the parameter name must each be entered separated by a hyphen:

```
...Name="[config object]-[key name]-[parameter name]"
```




## 4.2.4 Managing configuration files

The configuration data is saved in several files with the extension **.cfg**. This enables different types of machines to establish the correct configuration by selecting the appropriate files from the paths entered.

There are two types of configuration file lists: HEIDENHAIN files and OEM files.

The HEIDENHAIN files are permanently defined and cannot be changed (e.g. **CfgJhConfigDataFiles**).



The paths and names of OEM files can be changed with the **CONFIG FILE LISTS** soft key. New configuration files can also be added (for a new axis, for example). The paths are saved in the **configfiles.cfg** file.

The paths and names of the configuration files are stored in the **dataFiles** list (see "Allocation of Configuration Data" on page 379). The control searches for the parameter objects and their parameters in these \*.cfg files.

The paths of these files can be changed. Use the right arrow key to open an input dialog for entering the new path or file name.

#### 4.2.5 Sorting file content

Pressing the **SORT FILE CONTENT** soft key in the main menu of the **Machine Parameters** mode of operation sorts the contents of the \*.cfg configuration files so that the objects are in the same order as they are listed in the configuration editor.

However, since the data in the configuration editor comes from multiple files, there is no direct correlation between the display in the configuration editor and the contents of each file.


This sorting makes it easier to compare the contents of similar files (such as \*.cfg for axes), since the entries are now in the same order.



## 4.2.6 Attribute information

Use the **ATTRIBUTE INFO** soft key to display write-accesses, reactions, selection lists, limit values, units of measure, and format instructions.

These data are permanently defined by HEIDENHAIN. The OEM cannot change them.




### Access rights

Entering a code number also grants access rights to the machine parameters. There is a difference between the four levels, from Level1 to Level4. Level1 grants few rights, whereas Level4 grants all rights.

#### LEVEL1 access rights

Machine parameters on LEVEL1 can be reached and changed without the need to enter a code number.

#### LEVEL2 access rights

Machine parameters on LEVEL2 can be reached and changed with **code number 123**. Enter the code number in the **Organization** mode using the soft key. 

#### LEVEL3 access rights

Machine parameters on LEVEL3 can be reached and changed with **code number 95148**.

The end user must not be told of the code number 95148.

#### LEVEL4 access rights

Machine parameters on LEVEL4 can only be accessed by **HEIDENHAIN**. The machine manufacturer can only read them.

## Reaction to change (behavior)

The following reactions can occur when machine parameters are changed using the config editor:

- **Change at any time**  
(NOTHING)
- **Program run is locked**  
(RUN)
- **PLC program prevents changes during program run**  
(PLC/RUN)
- **Allowed in strobe**  
(SYNC)
- **Move to ref. point**  
(REF)
- **Shut down control**  
(RESET)
- **Restart control**  
(REBOOT)

The abbreviated form of the detailed description for each parameter in this manual includes the reactions that occur for each machine parameter.

### Reaction NOTHING

Machine parameters with this reaction can be changed at any time, including during program run.

### Reaction RUN

Changes are only possible during a PLC strobe or NC stop.

### Reaction PLC/RUN:

If machine parameters are changed while **NN\_GenCycleAfterReConfig** is set, the PLC program is recompiled. Changes to parameters are prevented in any case while the NC program is running. In this case, the control issues the error message **Parameter change during program run**, even if the reaction of the parameter is NOTHING. Therefore, for parameters with the behavior NOTHING, the text **PLC/Pgm. run is locked** is displayed in the config editor to indicate the changed behavior.

### Reaction SYNC:

Basically, the same characteristics apply as for the RUN reaction. In addition, machine parameters with this reaction can, for example, be loaded from the NC program by means of an MP subfile if a strobe with synchronization of the advance calculation (SYNC\_CALC) is pending. The parameter cannot be activated through the PLC or the config editor during program run.

### Reaction REF

After a machine parameter to which the REF reaction is assigned has been changed, the affected axis is set to unreferenced.

A new reference run must be made for this axis.

Data objects with this reaction must not be changed during program run.





### **Reaction RESET**

After a machine parameter to which the RESET reaction is assigned has been changed, the error message **Machine parameters were changed. Shut down and restart the control** is displayed.

This message cannot be cleared. The machine must be restarted. If you want to make more changes in the configuration editor, you can also perform the restart later.


Data objects with this reaction must not be changed during program run.

### **Reaction REBOOT**

Basically, the same characteristics apply as for the RESET reaction. However, the behavior during shutdown is different. If a parameter with the REBOOT reaction is changed, the saving of the configuration data will lead immediately to a restart of the control. In contrast to the RESET reaction, no error message is displayed.

## 4.2.7 Access protection / Options

Press the **ACCESS PROTECTION / OPTIONS** soft key to get to the configuration options for protecting data from unauthorized access.



### Display of write-protected parameters

Settings in the configuration editor	MP number
System CfgConfigSettings <b>hideWriteProtected</b>	106504

With **MP\_hideWriteProtected** you can specify whether write-protected parameters are to be displayed or hidden in the configuration editor. This applies especially to all data saved on the SYS partition.

#### MP\_hideWriteProtected

Hiding write-protected parameters

Format: Selection menu

Selection: **TRUE**  
Hide write-protected configuration objects  
**FALSE**  
Display all configuration objects

Default: FALSE


Access: LEVEL3

Reaction: NOTHING

## 4.2.8 Update rules

### Introduction

You can use update rules to insert, delete, rename and move OEM machine parameters. You can also change parameter types and the sizes of list fields. The update rules define rules that are required for automatically updating the machine parameters during a software update. To get to the update rules, press the **MORE FUNCTIONS** soft key in the main menu of the **Machine Parameter** mode of operation, and then the **UPDATE RULES** soft key.



If you want to transfer a new PLC program to the control, for example as part of an NC-software update via USB stick, then often it is also necessary to change or expand the OEM machine parameters. You can use the update rules to have these changes performed automatically.

These update rules are also a tool for keeping track of the versions. You can assign version numbers when changing machine parameters. During a software update, the control automatically detects an increase in the version number, and the update rules are applied.

The update rules can only be used to change or create new OEM machine parameters. You can also change input values for parameters accessible via the MP code number **95148**.

During the first restart of the control after the update, the service technician who updated the NC software must check and confirm the changes made by the update rules to the configuration.

If the user attempts to leave the configuration editor without saving the changes, a dialog window appears prompting the user to save them. The configuration editor cannot be exited until the data are saved.



#### Note

The first restart of the control after the update cannot be continued without saving the configuration changes made by the update rules.

If configuration objects are to be added or deleted during a software update, then you must define a command for this action in the **update rules**. You can call the **update rules** function to view all previous changes to the configuration made with update rules.

These rules no longer need to be followed once the software has been exchanged (see "NC software exchange on the MANUALplus 620" on page 137).

## Using update rules

You must save update rules in a file with the extension **.cfg**.

- ▶ Ensure that a file with the name **PLC:\config\[update rule].cfg** exists on the control.
- ▶ Enter the Machine Parameters mode of operation, and use the **CONFIG FILE LISTS** soft key to enter the path to the [update rule].cfg file as described below:

<b>Settings under CONFIG FILE LISTS</b>	
CfgConfigDataFiles	
updateFiles	
<b>[0]:</b>	%oemPath%\[update rule].cfg

- ▶ Edit the **[update rule].cfg** file with an ASCII editor, such as Notepad or UltraEdit32. The following pages describe the available commands.



The following software version-dependent files for the machine manufacturers' update rules are already available in the directory PLC:\config\lathe\Manplus:

- UpdateOemRel001.cfg    Update rules for software version -01
- UpdateOemRel002.cfg    Update rules for software version -02
- UpdateOemRel003.cfg    Update rules for software version -03
- UpdateOemRel004.cfg    Update rules for software version -04

The machine manufacturer is responsible for the update rules specified in these files. When the control is shipped, the files are empty.

The current OEM update version can be reset with the **RESET VERSION** soft key in the configuration editor, in the same way as the HEIDENHAIN update rules.

Always save an **[update rule].cfg** file in the final configuration of your machine, and include this file with **CONFIG FILE LISTS** as described above. This way you can have this file be overwritten with a new version at any time as part of a software update, and have the update rules be followed.

## UpdObjectInsert

The indicated configuration object is inserted. The procedure is performed if...

- the control determines during startup that the indicated object does not exist
- the current OEM version number of the configuration is less than the version number indicated in the update rule.

There are various possibilities for inserting parameters into the new configuration object:

- The name of the new configuration object is entered directly as a string. Only parameters that are to be set to specific input values must be entered.

### Syntax:

```
UpdObjectInsert (  
    entity      := STRING,      ; Name of the configuration object  
    version     := REAL,        ; Version number  
    key         := STRING,      ; Key name of the configuration  
                                object  
    file        := STRING,      ; Path/file name of where the new  
                                object is to be saved  
    object      := STRING  
                (OPTIONAL)     ; Name of the new configuration  
                                object (identifier)  
)
```

### Example:

```
UpdObjectInsert (  
    entity:="CfgOemBool",  
    version:=1.00,  
    key:="MG_OemBool",  
    file:="%OEM%\\config\\plc_oem.cfg",  
    object:="CfgOemBool (value:= [FALSE, TRUE])"  
)
```

If the version code of the OEM configuration is < 1.00, this update rule creates the symbolic operand MG\_OemBool in the configuration object CfgOemBool. Possible values are TRUE and FALSE.



## UpdObjectRemove

The indicated configuration object is removed from the current machine configuration. If the name of a \*.cfg file is entered, the configuration object is removed only from the entered file. This procedure is performed during startup of the control if the version number of the OEM configuration on the control is older than the version number of the update rule.

The object to be removed is marked in the configuration editor. The user must confirm the final removal by pressing the **SAVE** soft key in the configuration editor.

### Syntax:

```
UpdObjectRemove (  
    entity      := STRING,      ; Name of the configuration object  
    version     := REAL,       ; Version number  
    key         := STRING,     ; Key name of the configuration  
                                object  
    file        := STRING      ; Configuration object is removed  
                                (OPTIONAL) only from the entered file  
)
```

### Example:

```
UpdObjectRemove (  
    entity:="Cfg0emBool",  
    version:=1.01,  
    key:="MG_0emBool",  
    file:="%0EM%\\config\\plc_oem.cfg"  
)
```

The indicated configuration object is removed from the plc\_oem.cfg file. Other \*.cfg files of the machine configuration in which the object also exists are not affected.

## UpdObjectMove

The indicated configuration object is moved to another \*.cfg file. If the indicated configuration object already exists in the file entered (\*.cfg), no action is performed.

This procedure is performed during startup of the control if the version number of the OEM configuration on the control is older than the version number of the update rule.

### Syntax:

```
UpdObjectMove (  
    entity      := STRING,      ; Name of the configuration object  
    version     := REAL,       ; Version number  
    key         := STRING,     ; Key name of the configuration  
                                object  
    file        := STRING      ; Move configuration object to  
                                indicated file  
  
)
```

### Example:

```
UpdObjectMove (  
    entity:="CfgOemBool",  
    version:=1.01,  
    key:="MG_OemBool",  
    file:="%0EM%\\config\\plc.cfg"  
  
)
```

The indicated configuration object is moved from the current file to the file plc.cfg.





## UpdKeyRename

The key name of the indicated configuration object is changed. The file is not changed.

This procedure is performed during startup of the control if the version number of the OEM configuration on the control is older than the version number of the update rule.

### Syntax:

```
UpdKeyRename (  
    entity      := STRING,      ; Name of the configuration object  
    version     := REAL,        ; Version number  
    key         := STRING,      ; Key name of the configuration  
                                object  
    keyNew      := STRING      ; New key name  
)
```

### Example:

```
UpdKeyRename (  
    entity:="CfgOemBool",  
    version:=1.01,  
    key:="MG_OemBool",  
    keyNew:="MG_Boolean"  
)
```

The symbolic marker MG\_OemBool is renamed as MG\_Boolean.

## UpdAttributeInsert

The indicated machine parameter is inserted in the machine configuration. The procedure is performed if...

- the control determines that the parameter is currently hidden or does not exist
- the current OEM version number of the configuration is less than the version number indicated in the update rule.

If you would like to insert a value for an optional machine parameter, you must set **insertOptional:=TRUE**.

If you do not enter a value, the control automatically uses the default parameter value when following the update rule.

### Syntax:

```
UpdAttributeInsert (  
    entity           := STRING,           ; Name of the configuration  
                                     object  
    version          := REAL,            ; Version number  
    key              := STRING,           ; Key name of the configuration  
                   (OPTIONAL)           object  
    attrName        := STRING,           ; Name of the machine  
                                     parameter to be inserted  
    index           := UNSIGNED,         ; Index for list parameters  
                   (OPTIONAL)         (arrays). If the parameter is a list,  
                                     then it is inserted at the given  
                                     location  
    insertOptional  := BOOLEAN,         ; Insert optional parameter  
                   (OPTIONAL)  
    value           := STRING            ; Parameter value. Default value  
                   (OPTIONAL)         is used if nothing is entered.  
)
```

### Example:

```
UpdAttributeInsert (  
    entity:="CfgOemBool",  
    version:=1.02,  
    key:="MG_OemBool",  
    attrName:="value"  
    index:=2,  
    insertOptional:=TRUE,  
    value:="TRUE"  
)
```

A new index with the value TRUE is inserted for the marker MG\_OemBool.



## UpdAttribute Remove

The indicated machine parameter is removed from all configuration objects of the machine configuration.

This update rule is needed in case a machine parameter is not supported by a newer version of the NC software. This way you can automatically correct your configurations in the field.

### Syntax:

```
UpdAttributeRemove (  
    entity           := STRING,           ; Name of the configuration  
                                     object  
    version          := REAL,            ; Version number  
    attrName         := STRING,         ; Name of the machine  
                                     parameter to be removed  
)
```

### Example:

```
UpdAttributeRemove (  
    entity:="CfgSimulation",  
    version:=1.02,  
    attrName:="cc424"  
)
```

The **MP\_cc424** parameter is removed from all configuration objects with the name CfgSimulation.

## UpdAttributeNew Value

The input value of the indicated machine parameter is checked. If the input value corresponds to the value entered in the update rule or is within the given value range...

- either the input value is changed or
- the input value is multiplied by the given factor and then changed. The conversion is only effective for numeric parameter values.

If no value range is defined (minValue and maxValue are not set), the new parameter value is always inserted.

If a single value is entered (minValue or maxValue is set), the new value is inserted if the old value exactly equals the given value.

This procedure is performed during startup of the control if the version number of the OEM configuration on the control is older than the version number of the update rule.

### Syntax:

```
UpdAttributeNewValue (  
    entity           := STRING,           ; Name of the configuration  
                                     object  
    version          := REAL,             ; Version number  
    key              := STRING,           ; Key name, if the value is to be  
                                     changed in only one specific  
                                     configuration object. Otherwise  
                                     do not enter anything.  
    attrName        := STRING,           ; Name of the machine  
                                     parameter  
    index            := UNSIGNED,         ; Index for list parameters  
    (OPTIONAL)      (arrays). Is only checked if the  
                                     parameter is an index  
    minValue        := STRING,           ; Minimum value  
    (OPTIONAL)  
    maxValue        := STRING,           ; Maximum value  
    (OPTIONAL)  
    value           := STRING             ; New input value  
    (OPTIONAL)  
    factor          := REAL               ; Multiplication factor  
    (OPTIONAL)  
)
```



**Example:**

```
UpdAttributeNewValue (
    entity:="CfgOemBool",
    version:=1.01,
    key:="MG_OemBool",
    attrName:="value",
    value:="TRUE"
)
```

The MG\_OemBool marker is changed to the input value TRUE in the configuration object CfgOemBool.

#### 4.2.9 Removing syntax errors

The REMOVE SYNTAX ERROR soft key in the MORE FUNCTIONS soft-key menu becomes selectable when the configuration data in the \*.cfg files is being changed manually, or when faulty or incomplete update rules are being used during a software update.

Pressing it opens the faulty file as well as a text editor so that the file can be corrected manually.

Since this soft key can only be selected in one of the above cases, and these cases do not occur during normal operation, the soft key cannot be selected during normal operation.

The start-up of the control is interrupted if a faulty file is detected. The window for entering a code number appears. You must enter the OEM or HEIDENHAIN code number for the configuration editor. The main menu of the configuration editor appears. The REMOVE SYNTAX ERROR and END soft keys can be selected. Pressing the END soft key continues start-up. However, this will lead to many error messages, since only faulty or no configuration data is available.


The END soft key saves and reloads the file. This can take a moment. If there are still errors, the soft key remains active.

Otherwise the CONFIG DATA soft key becomes selectable. You can use it for further corrections in the configuration editor. If the data is now correct, the END soft key in the main menu of the configuration editor will continue start-up.

If any other errors are reported, they must be fixed with the configuration editor.

#### 4.2.10 Resetting the update version


The RESET VERSION soft key in the MORE FUNCTIONS soft-key menu enables you to return to the previous software version of machine parameters (configuration data).



If, after a software update, configuration errors occur while the control is starting up, the previous executable version can be reactivated. Then find and correct the error by using the update rules.

## 4.2.11 Backup of parameters

The DATA BACKUP soft key in the MORE FUNCTIONS menu enables you to save and restore configuration data as well as to create text files with the current machine parameters:



The following functions are available:

### ■ Save parameter files in backup

The following file name is suggested:

%OEM%\service\BKUPyear-month-day\_.ZIP

Append meaningful information to this name, for example, the control model, software version, etc.

All active \*.cfg configuration files from %OEM% and %USR% are saved in the selected backup file, e.g. BKUP2005-04-05\_tnc320-sw123.ZIP; see %OEM%\config\Configfiles.cfg:

- All files from %OEM% in the "\_Oem\_Config\_Files\_.zip" file
- All files from %USR% in the "\_Usr\_Config\_Files\_.zip" file

The update files listed in Configfiles.cfg under updateFiles:= are not saved in the backup file.

### ■ Activate parameter files from backup

The \*.cfg configuration files from %OEM% and %USR% are retrieved from the selected backup file and activated.

### ■ Save help information in file

**The following file name (to be amended) is suggested:**

%OEM%\service\HELPyear-month-day\_.TXT

The created text file with the selected name contains the help information about all parameter objects and attributes. If a parameter exists more than once, for example for several axes, only the information about the first parameter is saved.

### ■ Save data tree in file

**The following file name (to be amended) is suggested:**

%OEM%\service\TREEyear-month-day\_.TXT

The created text file with the selected name contains the current values of all parameter objects and attributes.



#### Note

You can also use the PC software TNCbackup for backing up your data in an easy and convenient way. TNCbackup is part of TNCremoNT and is available free of charge from HEIDENHAIN, for example from the FileBase on the Internet ([filebase.heidenhain.de](http://filebase.heidenhain.de)).



#### Note

**A backup should be performed after commissioning and every time the machine parameters have been edited.**

## 4.2.12 Resetting system settings


The RESET SETTINGS soft key in the MORE FUNCTIONS soft-key menu resets all nonvolatile system settings. Nonvolatile system settings are retained when the control is switched off.

Nonvolatile system settings include:

- Screen layout defined in the Manual Operation and Program Run modes of operation
- Active machine kinematics and tilting-axis situation
- Settings of the integrated oscilloscope
- NC programs selected in the Program Run, Programming and Test Run modes of operation
- Settings for automatic program start
- File sorting defined in the file manager
- Information saved to undo changes made to the machine configuration

It may sometimes be necessary to reset these settings, for example, if incorrect system settings cause problems during startup.

After pressing the soft key, the user is prompted to confirm deletion of the system settings:




- ▶ Press the OK soft key to delete the system settings. You can restart the MANUALplus 620 manually later on. However, restarting is necessary, because no new system settings can be saved until the control is restarted.
- ▶ Press the CANCEL soft key to cancel the process.
- ▶ Press the CLOSE CONTROL soft key to delete the system settings and to shut down the MANUALplus 620. The MANUALplus 620 must be restarted immediately.



## 4.3 User Parameters

You can provide the machine tool operator with easy access to parameters known as user parameters. These parameters can, for example, refer to language settings or data evaluated by the PLC. You can display a freely definable help text for every user parameter on the right half of the screen. Press the HELP key to show the help text. You define the help text in a language-sensitive \*.CSV file.



### Freely definable code numbers

Press the **USER PARAMETER** soft key in the **Organization** operating mode to view the predefined user parameters. Enter the following code numbers (default settings) for advanced views of the user parameters:

- Basic view via the **USER PARAMETER** soft key
- Advanced view of **USER PARAMETERS** with possibility of setting the conversational language: Enter code number 123
- **PLC PARAMETER** view with grouped parameters of the PLC basic program: Enter code number 5555.

You can assign separate soft keys to the parameters. The control displays these soft keys on the third soft-key row level.

You can configure the code numbers for the user parameters any way you wish (see "Definition of code numbers" on page 371).

## Layout file in XML format

You define the layout of the user parameters in layout files. These layout files are in XML file format. The layout of the user parameters consists of a general part prescribed by HEIDENHAIN (userparam.xml, user123.xml) and an OEM-specific part (userparamOem.xml, user123Oem.xml). The OEM-specific files are empty when shipped, and can be used by the OEM to display further parameters.

XML (= extensible markup language) is a standard language for data exchange. It uses tags, allowing for exact description of the data and the structure. You will find a list of all XML commands supported by the control in "XML commands for creating the layout files" on page 374.

On page 372 a simple example illustrates how you create a layout file for your user parameters and separate help texts for the parameters.

### 4.3.1 Configuration of the user parameters

Settings in the configuration editor	MP number
System	
Key code	
CfgOemPassword	106900
[Key name]	
<b>funcList</b>	106901
CfgModOemSoftkey	107100
[Key name of the parameter view]	
<b>activation</b>	107101
<b>skPos</b>	107102
buttonText	107103
<b>dialogRes</b>	
<b>text</b>	
<b>buttonImage</b>	107104
<b>funcKey</b>	107105
<b>helpId</b>	107106
CfgCfgEditActivate	107200
[Key name of the parameter view]	
<b>layoutFile</b>	107201
<b>dispLangText</b>	107202
System	
Paths	
CfgOemPath	102000
<b>dialogTextfile</b>	102002

#### ■ CfgOemPassword

[Key name]

Define a key name for your own parameter view under **MP\_funcList**, for example: **MP\_funcList[0]: CFGEDIT-OEM**.



Note

If you also want to grant your machine operators access to LEVEL3 machine parameters (see "Access rights" on page 347), you also have to enter the following value under **MP\_funcList**:  
**MP\_funcList[1]: CONFIG-LEVEL3**

### ■ **CfgModOemSoftkey:**

After entering an OEM code number, you can display a soft key to call the user parameters. For configuration, enter the same key name as in CfgOemPassword/funcList, e.g. CONFIGEDIT-OEM. You can define an image, a language-neutral or a language-sensitive text for the soft key. The individual parameters of CfgModOemSoftkey are described in more detail below.

### ■ **CfgCfgEditActivate**

Specifies the XML layout file for the depiction of the user parameters. You have to enter the same name as in CfgOemPassword/funcList as key name. The views for the code number "5555" (CONFIGEDIT-PLC\_Parameter), code number "123" (CONFIGEDIT-USER123) and the view without any code number (CONFIGEDIT-USERPARAM) are already defined.

- **MP\_layoutFile: path to the XML layout file:**

You define the layout for the tree structure of the user parameters in the XML file. You define the path to the layout file in **MP\_layoutFile**.

HEIDENHAIN recommends saving the XML layout files under **%OEM%\config\layout**.

Three views are already defined by HEIDENHAIN.

(CONFIGEDIT-PLC\_Parameter, CFGEDIT-USER123 and CFGEDIT-USERPARAM). The configuration possibilities for the parameters of the PLC basic program (code number 5555) are located under CONFIGEDIT-PLC\_Parameter. The settings in CONFIGEDIT-USER123 apply to the user parameters that are displayed after you have entered the code number 123.

CONFIGEDIT-USERPARAM applies to the user parameters you call by pressing the **USER PARAM** soft key. You can adapt these views to your requirements or remove them from the configuration. The associated XML layout files are available at:

**%SYS%\config\layout\userparam.xml** and

**%SYS%\config\layout\user123.xml**

**%OEM%\config\layout\PLC\_Parameter.xml**

- **MP\_dispLangText – show language-sensitive parameter name**

Set the machine parameter **MP\_dispLangText** to TRUE if you want to display by default your own parameter names from the \*.CSV file (e.g. "conversational language") for the user parameters instead of the system names (e.g. CfgDisplayLanguage).

### ■ **MP\_dialogTextfile – language-sensitive help texts and parameter names:**

You can configure the parameter names and the parameter help texts (to be shown in the help window) in multiple languages. In **MP\_dialogTextfile**, enter the file name of the \*.CSV file containing the parameter texts. The path is permanently defined: **%OEM%\plc\language\en** (or another language abbreviation). Therefore, enter only the file name without path. The language abbreviation defined in MP\_System/DisplaySettings/CfgDisplayLanguage/ncLanguage is used. If the file is not available in the selected language, the control attempts to open the English file (directory: **%OEM%\plc\language\en**).

Machine parameters in the **CfgOemPassword** configuration object:

**MP\_funcList**

List of function names (= key names) that are called by entering the password:  
Available from NCK software version: 597 110-01.

Format: Array 0...200  
Input: Key name of max. 18 characters  
Name of the functions that are called by entering the password. Enter these names as key names in CfgModOemSoftkey and CfgCfgEditActivate.  
The key name of CfgOemPassword defines the password.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

Machine parameters in the **CfgModOemSoftkey** config object:

**MP\_activation**

Specifies whether the defined function is a foreground application.  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: **TRUE**  
The defined function is a foreground application, e.g. configuration editor. Set this value if the soft key opens the configuration editor to display user parameters.  
**FALSE**  
Function performed in the background

Default: FALSE  
Access: LEVEL3  
Reaction: RESET

**MP\_skPos**

Position of the soft key in the 3rd menu bar  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to 7  
0: first soft key from the left  
No input: the soft key is not displayed  
Menu bars 1 and 2 are reserved for HEIDENHAIN.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

The **buttonText** folder contains two machine parameters used to define the labeling of the soft key. You can either define a reference to the text in a language-sensitive \*.CSV file or a language-neutral text. Leave the **buttonText** empty if you want to define an image for the soft key with **MP\_buttonImage**.



### **MP\_dialogRes**

Reference to a language-sensitive text in a \*.CSV file.  
Available from NCK software version: 597 110-01.

Format: String  
Input: Max. 40 characters  
Example:

#### **OEMTXT\_001\_ncLanguage**

The designator must be available in a text resource file (\*.CSV).  
The text file must be defined under  
System/Paths/CfgOemPath/dialogTextfile.  
Leave the parameter empty if you do not want the soft key  
labeling to be language-sensitive. Enter the text directly under  
**MP\_text** instead.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### **MP\_text**

Soft key designator.  
Available from NCK software version: 597 110-01.

Format: String  
Input: Max. 60 characters  
Enter a language-neutral text. If a language-sensitive text was  
defined with **MP\_dialogRes** you must not change the displayed  
string; the control displays the entry from a \*.CSV file.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### **MP\_buttonImage**

Image for soft keys  
Available from NCK software version: 597 110-01.

Format: String  
Input: Path/file name to an image for a soft key  
Leave the parameter empty if you have defined a text for the  
soft key under **buttonText**.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### **MP\_funcKey**

Key name of the function being activated when the soft key is  
pressed  
Available from NCK software version: 597 110-01.

Format: String  
Input: Max. 18 characters  
The key name must be entered only if the name of the function  
does not match the key name.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### **MP\_helpId**

Symbolic name of the context information for online help (\*.CHM)

Available from NCK software version: 597 110-04.

Format: String

Input: Max. 80 characters

The entered symbolic name can belong to a HEIDENHAIN or OEM manual.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

Machine parameters in the **CfgCfgEditActivate** configuration object:

### **MP\_layoutFile**

Path/name of the XML layout file for user parameters

Available from NCK software version: 597 110-01.

Format: String

Input: Max. 80 characters

Default: Example for user parameters (code number 123)

%OEM%\config\layout\user123.xml

Access: LEVEL3

Reaction: NOTHING

### **MP\_dialogTextfile**

Name of the text file for OEM texts

Available from NCK software version: 597 110-01.

Format: Array [0...9]

Input: Enter the name (without the path!) for OEM text files. You can enter any files with the extension \*.CSV in which you define your OEM-specific texts

The path %OEM%\plc\language\

Default: UserParam.CSV

Access: LEVEL3

Reaction: RESET

### **MP\_readOnly**

Open the configuration editor with read access only.

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: TRUE

The configuration editor is opened with read access only; the parameter values cannot be changed

FALSE

The configuration editor is opened with read and write access

Default: No value, parameter optional (= read and write access)

Access: LEVEL3

Reaction: RESET



Machine parameters in the **CfgOemPath** configuration object:

### MP\_dispLangText

Display language-sensitive names in the configuration editor?  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**  
Language-sensitive names are displayed.  
**FALSE**  
System names are displayed.

Default: TRUE

Access: LEVEL3

Reaction: NOTHING



#### Note

All files can be managed with PLCdesignNT, as well as transmitted to the control. PLCdesignNT is available from HEIDENHAIN.

### Definition of file types

Settings in the configuration editor	MP number
CfgConfigDataFiles <b>dataFiles</b>	106303

The file types and default settings of the PLC parameters are defined in the file **plc\_oem.cfg**. The file can be named anything you want. The path of the file is to be entered in the **dataFiles** list of the **CfgConfigDataFiles** entity, which appears after pressing the **CONFIG FILE LISTS** soft key. The file types **CfgOemBool**, **CfgOemInt**, **CfgOemPosition** and **CfgPlcTimer** can be used in the parameter layout.

### Definition of code numbers

In order to change the code number for PLC parameters (5555), the file **plc\_attr.cfg** must be modified.

Example:

In order to display the PLC parameters, the new code number 123456 is to be valid in addition to the previous code number 5555.

Add the following entity to the **plc\_attr.cfg** file:


```
CfgPassword (  
key:="123456",  
funcList:= [  
"CONFIGEDIT-PLC_Parameter",  
"CONFIG-LEVEL1"  
])
```

### 4.3.2 Example:

Creating a layout for the user parameters. The example illustrates how you enable the machine operator to access a parameter from your machine configuration as a user parameter.

#### Goal:

Creation of a menu for selecting the language. The menu is to appear on the screen after entering the code number 123. The user's own parameter names and help text are to be displayed.



The best solution for handling XML files is to use an XML editor. These editors are available from software vendors, or as freeware from the Internet for example. As an alternative, the XML layout file can also be edited with a text editor, such as Notepad. However, XML editors will help you a great deal in working with structured XML files.

- First step: Create a new empty XML file with the file name "user123.xml". Example:

```
<?xml version="1.0" encoding="UTF-8"?>
<!-- user123.xml from HEIDENHAIN 19.07.2005 -->
```


- Then specify the name of the XML schema file (XSD file). The XML editor uses the XML schema file to validate the created XML file. The XML editor verifies the file formally each time it is saved. This formal verification is based on the information in the \*.XSD file. You will find the "configreelayout.xsd" file on the control under %OEM%\config\layout\ . You can use this file to validate your new user parameter layout. For this purpose, you must copy the file into the project directory of your XML editor on your PC by using TNCremoNT.



- ▶ The XML file will look like this:

```
<?xml version="1.0" encoding="UTF-8"?>
<!-- user123.xml from HEIDENHAIN 19.07.2005 -->
<ConfigtreeLayout xmlns="http://www.hng.ch/ConfigEditLayout/1"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
xsi:schemaLocation="http://www.hng.ch/ConfigEditLayout/1
configtreelayout.xsd">
```

- ▶ Then the "conversational language" folder is created:



The following entry is therefore added to the XML file:

```
<Node Name="CfgDisplayLanguage"
DialogRes="OEMTXT_CfgDisplayLanguage">
```

Use the command **DialogRes=** to assign a language-sensitive name (here: "conversational language") from the OEM text file (\*.CSV) to the **CfgDisplayLanguage** folder. If you want to display this text as folder name by default, you must set **MP\_disPLangText** to TRUE.

- ▶ In the previously created "conversational language" folder, two machine parameters for setting the language of the NC dialog texts and the help texts are to be defined:



For this, the following entries are required in the XML files:

```
<SimpleAttribute Keyfilter="*" Name="ncLanguage"
Entity="CfgDisplayLanguage" DialogRes="OEMTXT_ncLanguage">
</SimpleAttribute>
<SimpleAttribute Keyfilter="*" Name="helpLanguage"
Entity="CfgDisplayLanguage" DialogRes="OEMTXT_helpLanguage">
</SimpleAttribute>
```

- ▶ Then you conclude the "conversational language" folder and the XML schema:

```
</Node>
</ConfigtreeLayout>
```

- ▶ The file is now complete and can be transferred to the control by using TNCremoNT.
- ▶ Then you still need to make the entries for the OEM texts in the \*.CSV file and to adjust the machine configuration accordingly.



**Note**

You will find a preconfigured version of the "user123.xml" file on the control under %OEM%\config\layout\. This file is only meant as a suggestion and you can adjust it to your specific requirements.



### 4.3.3 XML commands for creating the layout files

Overview of XML commands for defining the layout of the user parameters:

XML command	Description
<p><b>Include</b> Example: &lt;Include File="%0EM%\config\layout\axes.xml"/&gt;</p>	<ul style="list-style-type: none"> <li>■ Inserts the layout definition of the specified file in the layout.</li> <li>■ <b>File:</b> File name and path of the file to be inserted.</li> </ul>
<p><b>Node</b> Example: &lt;Node Name="DisplaySettings" DialogRes="0EMTXT_DisplaySettings"&gt;&lt;/Node&gt;</p>	<ul style="list-style-type: none"> <li>■ Defines a directory (branch, node) in the layout.</li> <li>■ Permissible elements are: Node, Keylist, Object, UniqueObject, SimpleAttribute, Group, Key, Array</li> <li>■ <b>Name:</b> Language-neutral designation. Can be chosen as desired.</li> <li>■ <b>DialogRes:</b> Text name from the OEM text file for displaying a language-sensitive designation.</li> </ul>
<p><b>Keylist</b> Example: &lt;Keylist Name="ChannelSettings" Keyfilter="*"&gt;</p>	<ul style="list-style-type: none"> <li>■ List of key names. The key names are displayed as directories.</li> <li>■ Permissible element: Entity</li> <li>■ <b>Keyfilter:</b> Filter for the key name. Permissible control characters for the filter are *, ? (wildcards) and . (period).</li> <li>■ <b>DialogRes:</b> Text name from the OEM text file for displaying a language-sensitive designation.</li> </ul>
<p><b>Entity</b> Example: &lt;Entity Name="CfgNcErrorReaction"/&gt;</p>	<ul style="list-style-type: none"> <li>■ Data object as element of a key list. The object name is displayed as directory.</li> <li>■ Permissible element: Attribute</li> <li>■ <b>Name:</b> Name of the data object</li> <li>■ <b>DataOfAttribute:</b> Name of an attribute whose data is displayed here. The name of the attribute is not displayed.</li> <li>■ <b>DialogRes:</b> Text name from the OEM text file for displaying a language-sensitive designation.</li> </ul>



XML command	Description
<p><b>Object</b> Example: <code>&lt;Object Name="CfgPosDisplayPace" Keyfilter="*" /&gt;</code></p>	<ul style="list-style-type: none"> <li>■ List with objects. The object name is displayed as the first directory, and the key name as the second. The key name can be filtered.</li> <li>■ Permissible element: Attribute</li> <li>■ <b>Name:</b> Name of the data object</li> <li>■ <b>Keyfilter:</b> Filter for the key name. For permissible control characters, see above.</li> <li>■ <b>DataOfAttribute:</b> Name of an attribute whose data is displayed here. The name of the attribute is not displayed.</li> <li>■ <b>DialogRes:</b> Text name from the OEM text file for displaying a language-sensitive designation.</li> </ul>
<p><b>UniqueObject</b> Example: <code>&lt;UniqueObject Name="CfgDisplayLanguage" /&gt;</code></p>	<ul style="list-style-type: none"> <li>■ Data object with an empty key name. These are data objects that occur only once. Only the object name is displayed.</li> <li>■ Permissible element: Attribute</li> <li>■ <b>Name:</b> Name of the data object</li> <li>■ <b>DataOfAttribute:</b> Name of an attribute whose data is displayed here. The name of the attribute is not displayed.</li> <li>■ <b>DialogRes:</b> Text name from the OEM text file for displaying a language-sensitive designation.</li> </ul>
<p><b>Attribute</b></p>	<ul style="list-style-type: none"> <li>■ Use this command if only certain attributes are to be displayed. If this element is not specified, all attributes of a data object will be displayed (standard behavior). If the attribute is a field or a list, an element of a list can be defined by specifying its index in square brackets. Example: <b>[3]</b></li> <li>■ <b>Name:</b> Name of the attribute</li> <li>■ <b>DialogRes:</b> Text name from the OEM text file for displaying a language-sensitive designation.</li> </ul>

XML command	Description
<p><b>SimpleAttribute</b>  Example:  &lt;SimpleAttribute Keyfilter="*" Name="ncLanguage" Entity="CfgDisplayLanguage"  DialogRes="OEMTXT_ncLanguage"&gt;&lt;/SimpleAttribute&gt;</p>	<ul style="list-style-type: none"> <li>■ Attribute without display of object name and key name. If the attribute is used as a subelement of a node, an existing key name must be specified (i.e. the key filter must not contain any filter characters).</li> <li>■ <b>Entity:</b> Object name</li> <li>■ <b>Keyfilter:</b> Filter for the key name.</li> <li>■ <b>Name:</b> Name of the attribute. If the attribute is a field or a list, an element of a list can be defined by specifying its index in square brackets.  Example: <b>[3]</b></li> <li>■ <b>DialogRes:</b> Text name from the OEM text file for displaying a language-sensitive designation.</li> </ul>



## 4.4 The KeySynonym Function

Settings in the configuration editor	MP number
KeySynonym CfgKeySynonym [Key name for the new parameter set] <b>relatedTo</b> <b>excludeList</b>	109501 109502

KeySynonym is a very helpful function for creating a new parameter set. You use KeySynonym to create parameter sets that refer to existing parameter sets and reuse the data contained in them. New parameter sets can be linked to existing ones in

**KeySynonym/CfgKeySynonym.** As a result, you only have to define the parameters that differ from the ones of the parameter set to which you have linked the present parameter set.

Proceed as follows if you want to create a new parameter set using the KeySynonym function:

- ▶ Open the configuration editor.
- ▶ You will find the KeySynonym folder at the bottom of the configuration editor. Move the cursor to the folder and open it.
- ▶ Move the cursor to the **CfgKeySynonym** configuration object.
- ▶ Press the **INSERT** soft key.
- ▶ The control prompts you to enter a new key name. Now enter a name for the new parameter set, such as ParSetS-1 for an additional set of parameters for the spindle. Also specify via the pull-down menu the memory file in which the data of the new parameter set are to be stored.
- ▶ The parameter-set key you just created contains the machine parameter **MP\_relatedTo**. Now enter the original parameter set, i.e. the one to which the new parameter set is to be linked, e.g. ParSetS-0. This assigns (links) the values from your 0-set for the spindle to all parameters of the new set. Changes to the 0-set are automatically loaded by the linked parameter set.
- ▶ Save your changes with the **SAVE** soft key.
- ▶ A red message appears, stating that the control must be rebooted. Restart the control now.
- ▶ Open the configuration editor when the control has rebooted.
- ▶ If you look in the ParameterSets configuration folder now, you will see a new ParSetS-0 parameter set there. The yellow arrow in front of the parameter set and entities indicates that the parameters are being mirrored by the KeySynonym function.

- ▶ Now you can undo the linking of entities, as required. This means you enter values that deviate from the original set of parameters. Select the desired entity and press the **MORE FUNCTIONS** soft key and then the **INSERT** soft key. The yellow arrow then disappears.
- ▶ Select the memory file via the pull-down menu.
- ▶ Save your changes with the **SAVE** soft key.
- ▶ The parameter set has now been created with the KeySynonym function, and can be used.

### **MP\_relatedTo**

Link to key name  
 Available from NCK software version: 597 110-01.

Format: String  
 Input: Max. 18 characters

The synonym name refers to the key name specified here.  
 The data of the parameter object with the indicated key name are used for the parameter object with the synonym name.  
 Example:  
**CH\_SIM** uses the same data as **CH\_NC**

Default: No value, parameter optional  
 Access: LEVEL3  
 Reaction: RESET

### **MP\_excludeList**

List with configuration objects to be excluded  
 Available from NCK software version: 597 110-01.

Format: Array [0...49]  
 Input: Name of configuration objects; example:  
 CfgPositionLimits

Cancel the reference at CfgKeySynonym/relatedTo for the entered parameter objects.

Default: No value, parameter optional  
 Access: LEVEL3  
 Reaction: RESET



## 4.5 Allocation of Configuration Data

The configuration data is saved in several files with the extension .cfg (see "Managing configuration files" on page 345). Paths saved in the file **configfiles.cfg** refer to these files. This allocation has already been specified by HEIDENHAIN when the software is delivered, but it can be adapted by the OEM to his requirements.

### Allocation of configuration data

O:\config contains the following data:

- configfiles.cfg Paths to the configuration data
- version.cfg Version number of the update rules (JH, OEM)

O:\config\lathe\manplus contains the following data:

- aggregate.cfg Data for the aggregates
- axis\_\*.cfg Each drive has its own configuration file. This way you can change the drive easily.
- ch1.cfg Data for the machining channel
- configVersion.cfg Directory path of the config. data
- dashboard.cfg Dashboard settings
- KeyList.cfg Configuration of the system key names
- kin\_ch1\_s1.cfg Old kinematics description
- kinem\*.cfg New kinematics description
- oem.cfg General data for systems and channels
- oempassword.cfg OEM-specific password settings, e.g. for file and directory release or special config data views.
- oemtable.cfg OEM-specific settings for tables
- plc.cfg Config. data for the PLC run-time system
- plc\_attr.cfg Config. data for PLC user parameters
- plc\_oem.cfg PLC parameters that are relevant for the OEM, e.g.
- plc\_user.cfg PLC user parameters
- proc\_data.cfg Data for the machining mode of operation
- runtime.cfg General data for the run-time system of the control (reserved for HEIDENHAIN)
- simu.cfg Simulation settings
- table.cfg General settings for tables
- table\_mplus.cfg MANUALplus 620 specific table settings
- th1.cfg Configuration of the 1st tool holder
- UpdateOemRel\*.cfg OEM-specific update rules for PLC parameters

### **MP\_stoppingAngle** and **MP\_maxSpeedSpindle**

V:\config contains the following data:

- mptransfer.cfg Configuration of network settings
- user.cfg General user parameters
- user\_ch1.cfg User parameters for the machining channel

## 4.6 Structure of a Parameter File

The individual machine parameters are collected into parameter objects in the \*.cfg parameter files. A parameter object has a name, of which the first three letters are always "Cfg." The name is followed by an open parenthesis and a "key" for identifying the parameter object. This is followed by the individual machine parameters. A parameter object must be surrounded by parentheses.

If there are several input values for a parameter (such as separate parameter settings for each axis), then the corresponding parameter objects are addressed via the key, and therefore occur more than once.

The parameter objects in the system files have an "empty" key.



### Note

HEIDENHAIN recommends changing the parameter values directly in the \*.cfg files only in exceptional cases.

### Rules for entries

If changes are to be made directly in a text editor, the following rules must be followed:

- "Key": Each parameter object has a key at the beginning, which generally represents the name of the axis or channel, but in certain cases can also be empty. The control assigns this parameter object to the object addressed by the key, for example to the axis "X axis."
- The characters ":@" must come between the parameter name and the value.
- Individual parameters must be separated by commas. No comma may follow the last parameter.
- Individual components, such as strings in a list or the components in the array must be separated by commas. No comma may follow the last component.
- The different levels in path entries must always be separated by "\", for example, "%SYS%\\CONFIG\\AXIS\\..".
- A list must always be in brackets [ ].
- If data objects with the same names and same identifications (keys) are present, the error message "Data object already exists in file" is displayed.
- Comments are text that is ignored during transfer. You can enter two types of comments:
  - Comment in one line: After a double hyphen "--" the text until the end of the line is ignored.
  - Comments that are on more than one line must be surrounded like this: (\*comment\*).
- Comments in files that are overwritten by the control (such as files with axis-setting parameters or oscilloscope parameters) are deleted. For this reason you should only add comments to files that are not written to by the control.





Example of a parameter file \*.cfg:

Parameter object	Description
CfgChannelAxes(	Name of the parameter object with open parenthesis. You cannot change this name.
Key:= "Channel1",	Identification of the parameter object with a string, such as the name of the NC channel or an axis.
progAxis:= [	Data variable of the list type
"X axis",	The individual elements of a list are separated by commas. No comma may follow the last element in a list. A list must always be in brackets [ ].
"Y axis",	
"Z axis",	
"A axis",	
"B axis"	
],	
.....	
[	More parameters follow...
.....	
],	
.....	
)	No comma is allowed before the closing parenthesis. Conclusion of the parameter object
- Comment to the end of the line	The text in the line after "-" (double hyphen) is ignored
(*	Characters for comment beginning
Comment distributed over several lines	Everything between the comment beginning and end is ignored
*)	Characters for comment end

Parameter object	Description
CfgAxis(	Name of the parameter object with open parenthesis. You cannot change this name.
Key:= "S1",	Identification of the parameter object with a string, such as the name of the NC channel or an axis.
isAng:= TRUE,	Boolean type data variable
.....,	More data variables follow...
parList:= [	Data variable of the list type

Parameter object	Description
"PS1_0", "PS1_1", "PS1_2", "PS1_3", "PS1_C1"	The individual elements of a list are separated by commas. No comma may follow the last element in a list. A list must always be in brackets [ ].
], noActToNomAtEmSt:=FALSE	One more parameter follows...
)	No comma is allowed before the closing parenthesis. Conclusion of the parameter object
- Comment to the end of the line	The text in the line after "-" (double hyphen) is ignored
(* Comment distributed over several lines	Characters for comment beginning Everything between the comment beginning and end is ignored
*)	Characters for comment end

## 4.7 Machine-Parameter Subfiles

Individual data from the configuration files can be taken into the MP subfiles. These subfiles can be superimposed on the machine parameters during run time.

In principle, all files that do not require a system restart can be superimposed. The MP subfiles are usually activated by the PLC, but they can also be activated manually by using the configuration editor.

### 4.7.1 Syntax of machine-parameter subfile

The syntax of an MP subfile corresponds to that of a basic file. Subfiles differ from basic files in that only the entities or attributes to be changed must be described.

In basic files a data object (entity) must be described completely. This means that the basic file must contain the "key" and all "attributes" of the entity.

```
entity(  
  key:= Key4711,  
  attribute1:= value1,  
  attribute2:= value2,  
  attribute3:= value3,  
  attribute4:= value4,  
)
```

In subfiles, only the required data needs to be indicated. Entity and key, however, must always be indicated.

**Please note: MP subfiles must not contain any reset parameters.**

Example of MP subfile with a new value for attribute 3:


```
entity(  
  key:= Key4711,  
  attribute3:= valuex  
)
```

## 4.7.2 Activating the machine-parameter subfile

MP subfiles can be activated in the configuration editor or by the PLC.

### Activation in the configuration editor

Use the **LOAD MP SUBFILE** soft key to activate individual subfiles.



Soft key	Function
LOAD MP SUBFILE	Calls the function for activating/editing MP subfiles.
LOAD AND SELECT	The selected MP subfile is loaded and activated. The parameters are effective immediately and can be edited in the configuration editor.
ONLY EDIT	The selected MP subfile is opened only for editing and is not effective. For example, this function can also be used to edit reset parameters in MP subfiles without having to restart the MANUALplus 620.

The PLC marker **NN\_GenCycleAfterReConfig** is set upon activation of an MP subfile if data relevant to the PLC have changed. All parameters that are not relevant to the PLC and therefore do not cause NN\_GenCycleAfterReConfig to be set are contained in the following list:

- CfgMillTurn
- CfgOsci
- CfgOsciFile
- CfgOsciColor
- CfgOsciSetup
- CfgOsciTrigger
- CfgOsciDisplay
- CfgSelectFile
- CfgInterpretOption
- CfgHandWheelFactor
- CfgStartupData
- CfgShutDown
- CfgAutoStartData
- CfgAutoStart
- CfgFeedRate
- CfgLayoutData
- CfgGmActQData
- CfgPlcPeriphery
- CfgPlcPath
- CfgModSoftkey
- CfgModOemSoftkey
- CfgNcPgmParState
- CfgNcPgmParSet
- CfgNcPgmParSetQR
- CfgNcPgmParRealL
- CfgNcPgmParStringL
- CfgSelectFile
- CfgUndoModif
- CfgObsDiskWatch
- CfgObsMemWatch
- CfgOsciChannel
- CfgPathProtection
- CfgFileType
- CfgRecentFileList
- CfgPgmMgtSettings
- CfgCycleConvert
- CfgTable
- CfgTablePrototype
- CfgPlcVersion
- CfgPlcOperTimes
- CfgPlcChannelAuto
- CfgPlcAxisManual
- CfgTablePath
- CfgColumnDescription
- CfgColumnText
- CfgTableProperties
- CfgEditor
- CfgEditorSelect
- UpdAttributeNewType
- CfgMachiningMode
- CfgNcVersion
- CfgCompVersion
- CfgUserPath
- CfgUnitOfMeasure
- CfgProgramMode
- CfgPassword
- CfgOemPassword
- CfgFunctionProtection
- CfgActualProtection
- CfgJhProtection
- CfgTableFilter
- CfgTableSelect
- CfgBinFileCache
- CfgDisplayData
- CfgPosDisplayPace
- CfgSystemTime
- CfgKeyboard
- CfgJogIncrement
- CfgEditorSelectElem
- CfgAttrEntity
- CfgAttrInt
- CfgAttrReal
- CfgAttrBool
- CfgAttrString
- CfgAttrBinary
- UpdAttributeInsert
- UpdAttributeRemove
- UpdAttributeRename
- UpdEndityRemove
- UpdEntityRename
- UpdObjectRemove
- UpdObjectInsert
- CfgGeoRotWorkPlane
- CfgWrkPIByPISel
- CfgActivateKinem
- CfgTrafoByDir
- CfgTrafoByAngle
- CfgKinSimpleTrans
- CfgToolGeoDataType
- CfgMillToolGeoData

## Activation by the PLC

Subfiles are activated by Module 9034. In this case the symbolic PLC operand **NN\_GenCycleAfterReConfig** (M4174) will not be set.

### Module 9034 Load a machine parameter subfile

With this module you load the contents of the given configuration file into the main memory. All configuration data not listed in this file remain unchanged.

The configuration file to be selected is checked. A faulty file is not loaded. If the file contains parameters that require a system reset, the file is not loaded.

The file name is transferred in a string that must contain the complete path, name and file extension. Further characters, even space characters, are not permitted.

If the PLC program is created externally, ensure that lower-case letters are not used for the file name!

Once the NC program has started, the module operates only during the output of an M/S/T/Q strobe.

Call only in a submit job.

Call:

PS B/W/D/K <String number>  
0 to 99

CM 9034

PL B/W/D <Error code>  
0: No error  
1: String does not contain a valid file name,  
or the name (including the path) is too long  
2: File not found  
3: File is faulty / contains reset parameters  
4: Incorrect string number was transferred (0 to 3)  
5: Call was not in a submit job  
6: Call not possible with a running program without  
strobe or change not possible with a running NC program  
7: Access rights insufficient, or access already reserved  
8: Internal system error


### Error recognition:

Marker	Value	Meaning
M4203 or NN_GenApiModule	0	Parameter subfile was loaded
Error	1	Error—see error code above




### 4.7.3 Displaying/editing data records in the configuration editor

Use the **SELECT DATA RECORD** soft key to choose between the following views:



The following overview shows which values of an object (object1, 2, 3) are displayed in the individual views:



<b>Basic data</b>	This view shows the data imported during system start-up. Any changes will be rewritten to the respective basic files.
<b>Loaded subfile(s)</b>	You must have loaded a subfile during system start-up (with "CfgPortionFiles") or by soft key for the subfile to be shown. If you select a subfile, only the data of the subfile are displayed in the configuration editor. The attributes contained in the subfile can be edited and rewritten to the subfile while saving. The subfile must be reloaded for the edited data to become effective.
<b>Temporary data</b>	The complete data objects of all loaded subfiles are shown. They can be edited, but they are not rewritten to the file. If a subfile from the PLC is loaded, the data is saved only as temporary data.
<b>Effective data</b>	The "effective data" view does not permit data to be edited. The displayed data refer to the current data loaded by the PLC or by selecting the data record of basic data or subfiles, and therefore show the data effective in the system. Exception: Configuration data written with FN17 are not shown in this view.
<b>Unload subfile</b>	The <b>UNLOAD</b> soft key can be used to unload the selected subfile. This automatically activates the basic data and the subfiles that are still loaded. The result is also shown in "Temporary data" and "Effective data."





## 4.8 Reading or Changing Machine Parameters via PLC Modules

Modules 9430 to 9433, 9436 and 9438 can be used to read or overwrite machine parameters via the PLC.

Use Module 9430 to overwrite the numerical value of a machine parameter temporarily. The value of the parameter is only overwritten in the run-time memory. The value stored in the **\*.cfg** file is retained. The original value becomes effective again the next time the control is started.

Use Module 9431 to read the numerical value of a machine parameter from the run-time memory.

Use Module 9432 to overwrite any string in the machine configuration temporarily. Only the currently effective string parameter in the run-time memory is overwritten. The string stored in the **\*.cfg** file is retained. The original value becomes effective again the next time the control is started.

Use Module 9433 to read any string from the run-time memory.

Use Module 9436 to save the numerical value of a machine parameter permanently. The value written with Module 9436 is stored in both the run-time memory and the **\*.cfg** file. The change is retained in the nonvolatile memory when the control is switched off.

Use Module 9438 to save any string in the machine configuration permanently. The string written with Module 9438 is stored in both the run-time memory and the **\*.cfg** file. The change is retained in the nonvolatile memory when the control is switched off.



### Note

HEIDENHAIN recommends:

Use the Modules 9436 and 9438 very carefully and perform intensive tests on the PLC program. Changes made using these modules might affect the machine configuration to such an extent that the MANUALplus 620 cannot be started properly anymore.

Entries for PS/PL	Description of the module entries
<Name of the configuration object>	Name of the folder in the machine configuration (= config object or entity), in which the machine parameter to be changed is located; e.g.: "CfgOemBool"
<Key name>	Key name where the object is located; e.g. "CH_NC". Key names are used to structure the machine configuration – they gather associated areas together, such as a machining channel ("CH_NC") or the parameter set of an axis ("PX"). Transfer an empty string for parameters without key names.
<Name of the machine parameter>	Name of the machine parameter (attribute) that is to be changed; e.g.: "swLimitSwitchPos"
<Index>	Index within an array (list field); Enter 0 for parameters without an array
<Factor>	Division factor for conversion to a floating-point number Enter 1 to receive integer parameters
<Value of the machine parameter>	Value of the parameter, e.g.: 123456
<String>	String number (0 to 15)
<Errors>	See "Return codes of PLC Modules 9430 to 9433, 9436, 9438 (error stack)" on page 397.



## Module 9430 Temporarily change the numeric value of a machine parameter

Use this module to enter a numeric value in the machine parameter given. The value of the machine parameter is overwritten in the run-time memory. The machine parameter in the \*.cfg file is not overwritten. The overwritten parameters are only in effect until the next time the control is started.

The NC software prescribes when a machine parameter can be changed. This information is included in the description of each parameter in the Technical Manual under "Reaction" or in the help display of the configuration editor under "Behavior."

Constraints:

- The module can only be called in a spawn or submit job.
- The module can only be called while the PLC has control over the machine.

Call:

```
PS   B/W/D/K/S<Name of the configuration object>
      e.g. "CfgPositionLimits"
PS   B/W/D/K/S<Key name>
      Key name of the config object, e.g. "PX"
      Transfer empty string if config object has no key name
PS   B/W/D/K/S<Name of the machine parameter>
      e.g. "swLimitSwitchNeg"
PS   B/W/D/K <Index>
      Index of the parameter within an array (list field)
      0: Parameter without array (list field)
PS   B/W/D/K <Factor>
      Division factor for conversion to a floating-point number
      Enter 1 to receive integer parameter values
PS   B/W/D/K <Value of the machine parameter>
CM   9430
PL   B/W/D <Error>
      See "Return codes of PLC Modules 9430 to 9433, 9436,
      9438 (error stack)" on page 397.
```

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	No error; data was changed
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Parameter out of value range
	2	Parameter invalid or does not exist, or other error
	3	Invalid string number
	6	Changing this value not allowed
	13	Error while communicating with the config server
	20	Module was not started from a spawn or submit job

### Module 9431 Read the numeric value of a machine parameter

Use this module to read the value of the given machine parameter from the run-time memory.

Constraints:

- The module can only be called in a spawn or submit job.

Call:

PS B/W/D/K/S<Name of the configuration object>  
e.g. "CfgPositionLimits"

PS B/W/D/K/S<Key name>  
Key name of the config object, e.g. "PX"  
Transfer empty string if config object has no key name

PS B/W/D/K/S<Name of the machine parameter>  
e.g. "swLimitSwitchNeg"

PS B/W/D/K <Index>  
Index of the parameter within an array (list field)  
0: Parameter without array (list field)

PS B/W/D/K <Factor>  
Division factor for conversion to a floating-point number  
Enter 1 to receive integer parameters

CM 9431

PL B/W/D/K <Value of the machine parameter>

PL B/W/D <Error>  
See "Return codes of PLC Modules 9430 to 9433, 9436, 9438 (error stack)" on page 397.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	No error, data was read
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Parameter out of value range
	2	Parameter invalid or does not exist
	13	Error while communicating with the config server
	20	Module was not started from a spawn or submit job



### Module 9432 Change the string value of a machine parameter

Use this module to enter a string in the machine parameter given. The value of the machine parameter is overwritten in the run-time memory. The machine parameter in the .cfg file is not overwritten. The overwritten parameters are only in effect until the next control start-up.

Constraints:

- The module can only be called in a spawn or submit job.

Call:

```
PS   B/W/D/K/S<Name of the configuration object>
      e.g. "CfgActivateKinem"
PS   B/W/D/K/S<Key name>
      Key name of the configuration object, e.g. "CH_NC"
      Transfer empty string if config object has no key name
PS   B/W/D/K/S<Name of the machine parameter>
      e.g. "kinemToActivate"
PS   B/W/D/K  <Index>
      Index of the parameter within an array (list field)
      0: Parameter without array (list field)
PS   B/W/D/K/S<New string>
CM   9432
PL   B/W/D  <Error>
      See "Return codes of PLC Modules 9430 to 9433, 9436,
      9438 (error stack)" on page 397.
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	No error; data was changed
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Parameter out of value range
	2	Parameter invalid or does not exist, or other error
	3	Invalid string number
	13	Error while communicating with the config server
	20	Module was not started from a spawn or submit job

### Module 9433 Read the string value of a machine parameter

Use this module to read the value of the given machine parameter from the run-time memory.

Constraints:

- The module can only be called in a spawn or submit job.

Call:

```
PS    B/W/D/K/S<Name of the configuration object>
      e.g. "CfgActivateKinem"
PS    B/W/D/K/S<Key name>
      Key name of the configuration object, e.g. "CH_NC"
      Transfer empty string if config object has no key name
PS    B/W/D/K/S<Name of the machine parameter>
      e.g. "kinemToActivate"
PS    B/W/D/K <Index>
      Index of the parameter within an array (list field)
      0: Parameter without array (list field)
PS    B/W/D/K <String number 0...15>
CM    9433
PL    B/W/D <Error>
      See "Return codes of PLC Modules 9430 to 9433, 9436,
      9438 (error stack)" on page 397.
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	No error, data was read
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Parameter out of value range
	2	Parameter invalid or does not exist
	13	Error while communicating with the config server
	20	Module was not started from a spawn or submit job



## Module 9436 Change the numeric value of a machine parameter permanently

Use Module 9436 to enter a numeric value in the indicated machine parameter. The value of the machine parameter is overwritten in the run-time memory, and the new value is stored (persistently) in the \*.cfg file, overwriting the previous value.

The new parameter value takes effect immediately, and is not lost when the machine is switched off.

Constraints:

- The module can only be called in a spawn or submit job.
- The module can only be called while the PLC has control over the machine.

Call:

```
PS    B/W/D/K <Name of the config object>
        e.g. "CfgPositionLimits"
PS    B/W/D/K <Key name>
        Key name of the config object, e.g. "PX"
PS    B/W/D/K <Name of the machine parameter>
        e.g. "swLimitSwitchNeg"
PS    B/W/D/K <Index>
        Index of the parameter within an array (list field)
        0: Parameter without array (list field)
PS    B/W/D/K <Factor>
        Division factor for conversion to a floating-point number
        Enter 1 to receive integer parameters
PS    B/W/D/K <New value of machine parameter>
CM    9436
PL    B/W/D   <Error>
        See "Return codes of PLC Modules 9430 to 9433, 9436,
        9438 (error stack)" on page 397.
```

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Machine parameter was written
	1	Machine parameter was not written, for error see W1022 or NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode (W1022)	1	Parameter out of value range
	2	Parameter invalid or does not exist, or other error
	3	Invalid string number
	6	Changing this value not allowed
	13	Error while communicating with the config server
	20	Module was not started from a spawn or submit job

### Module 9438 Change the string value of a machine parameter permanently

Use Module 9438 to enter a string in the indicated machine parameter. The value of the machine parameter is overwritten in the run-time memory, and the new value is stored (persistently) in the **\*.cfg** file, overwriting the previous value.

The new parameter value takes effect immediately, and is not lost when the machine is switched off.

Constraints:

- The module can only be called in a spawn or submit job.

Call:

```
PS   B/W/D/K/S<Name of the configuration object>
      e.g. "CfgActivateKinem"
PS   B/W/D/K/S<Key name>
      Key name of the configuration object, e.g. "CH_NC"
      Transfer empty string if config object has no key name
PS   B/W/D/K/S<Name of the machine parameter>
      e.g. "kinemToActivate"
PS   B/W/D/K <Index>
      Index of the parameter within an array (list field)
      0: Parameter without array (list field)
PS   B/W/D/K/S<New value of machine parameter>
CM   9438
PL   B/W/D <Error>
      See "Return codes of PLC Modules 9430 to 9433, 9436,
      9438 (error stack)" on page 397.
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Machine parameter was written
	1	Machine parameter was not written, for error see W1022 or NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode (W1022)	1	Parameter out of value range
	2	Parameter invalid or does not exist, or other error
	3	Invalid string number
	6	Changing this value not allowed
	13	Error while communicating with the config server
	20	Module was not started from a spawn or submit job





**Return codes of PLC  
Modules 9430 to  
9433, 9436, 9438  
(error stack)**

The error codes returned by Modules 9430 to 9433, 9436 and 9438 have the following meanings:

<b>Value (error stack)</b>	<b>Meaning</b>
0	Module executed successfully – machine parameter was read from or written to
1	<ul style="list-style-type: none"> <li>■ No access for the OEM to the machine parameter</li> <li>■ Access to the machine parameter is disabled by another process</li> <li>■ Access to the machine parameter is disabled during program run</li> <li>■ Access to the machine parameter is not possible via a synonym</li> </ul>
6	Module was not called in a submit/spawn job
7	<ul style="list-style-type: none"> <li>■ Invalid string number transferred for configuration object, key name or machine parameter</li> <li>■ Division factor is 0 or negative</li> </ul>
8	<ul style="list-style-type: none"> <li>■ No configuration object with the given name exists</li> <li>■ No machine parameter with the given name exists in the given configuration object</li> </ul>
9	<ul style="list-style-type: none"> <li>■ The transferred machine parameter does not exist under the given key name</li> <li>■ The machine parameter does not have the given index</li> <li>■ The given machine parameter is not an array or the index is not 0</li> </ul>
11	The machine parameter is not a numeric value
12	New value is invalid (outside of the value range)
13	Faulty contents of configuration object
14	<ul style="list-style-type: none"> <li>■ Error while communicating with the config server</li> <li>■ Internal error of the config server</li> </ul>
16	Internal error of the PLC run-time system

## 4.9 Switching Parameter Sets

You can store multiple parameter sets for an axis or spindle in the configuration editor.

Switching of parameter sets can be necessary, for example,

- if other parameters are necessary for a motor for different load or shaft speed ranges.
- if control is to be dependent on the load during C-axis operation.
- if a wye/delta connection switchover is carried out for the spindle motor.

If there is more than one parameter set for one axis, use Module 9434 to select the desired parameter set and Module 9435 to check the currently active parameter set.



### Danger

Ensure that switching the machine parameters does not result in the machine entering an uncontrolled state.

HEIDENHAIN recommends:

When switching the parameters, the affected drive should be switched off, or at least brought to a standstill! Controller and filter parameters should only be switched while a drive is at a standstill, and not during machining, since the switchover could affect the workpiece surface.

Incorrect or non-optimized parameter input values can lead to faulty machine performance.

HEIDENHAIN does not accept any responsibility for direct or indirect damage or injury caused to property or persons through improper use or incorrect parameterization of the machine.

### Conditions of the axis:

In principle, you are free to change any machine parameters of an axis parameter set. However, when some parameters are changed, the configuration editor triggers a reboot (RESET) of the control. These parameters therefore cannot be switched.

If when activating or deactivating axes over the PLC you also switch parameter sets (e.g. when exchanging milling heads), you have to observe particular conditions, see "Writing axis information—activating and deactivating axes" on page 678. The control checks for individual changed parameters immediately after the change to another activation condition. However, only those parameters are checked that are relevant for the respective activation condition. An axis in the activation condition "manually operated axis," for example, does not require controller parameters, and an axis in the "deactivated axis" activation condition does not need any parameters at all.

If the activation condition is switched over Module 9226 or 9418, the control then checks

- whether all required machine parameters are available, and
- whether the machine parameters have changed since the last use of this activation condition.

In this way, for example in a milling head exchange, an axis can be switched to the "deactivated axis" activation condition, the parameter set can be switched over (to other encoder configurations) and then the axis can be reactivated.

With some parameters you have to comply with the following conditions with regard to the switchover:

- **DRIVE OFF:**

The motor of the affected axis must be switched off. If this is not the case, the control releases an error message with the reaction EMERGENCY STOP. This causes the drives to be switched off. The control conducts a parameter-set switchover.

- **AXIS DEACTIVATED:**

The axis must be deactivated (e.g. over Module 9226).

If this is not the case, the control issues the error message **For a parameter change the drive has to be deactivated** (EMERGENCY STOP reaction). This switches the drives off. The control **does not** conduct a parameter-set switchover. If a parameter requiring the AXIS DEACTIVATED condition is changed in the configuration editor, the change will not become effective until the next startup of the control.

- **REF:**

The axis concerned must be homed again after the parameter set switchover.

The following table shows the parameters for which you must fulfill these conditions

### Synchronization with NC-program calculation

Before the parameter set can be switched, some machine parameters require a synchronization with the look-ahead capability of the NC program. Perform this synchronization with a strobe in which the value SYNC\_CALC is configured for **MP\_sync**. The strobe with SYNC\_CALC interrupts the interpretation of the NC program, and the path is calculated internally.

The following table presents an overview of the conditions for switching parameter sets and indicates all drive parameters which require either a strobe with SYNC\_CALC or that the drive be switched off before the switchover.



#### Warning

The directives of this table must be followed in order to avoid uncontrolled behavior of the machine!

Machine parameters	RESET	Strobe with SYNC_CALC	DRIVE OFF	AXIS DISABLED	REF
<b>CfgHardware</b>					
hardwareType	X	–	–	–	–
I32stopsMonitoring	–	–	–	–	–
I32driveEnabling	–	–	–	–	–
currentControlAdjust	X	–	–	–	–
maxTouchFeed	–	–	–	–	–
driveOffGroupInput	–	–	–	–	–
<b>CfgCycleTimes</b>					
ipoCycle	X	–	–	–	–
plcCount	X	–	–	–	–
watchdogTime	–	–	–	–	–
<b>CfgFilter</b>					
typeFilter1	–	–	–	–	–
orderFilter1	–	–	–	–	–
typeFilter2	–	–	–	–	–
orderFilter2	–	–	–	–	–
<b>CfgHandwheel</b>					
All parameters	–	–	–	–	–
<b>CfgPosCorrection</b>					
enable	–	–	–	–	–
feed	–	–	–	–	–
<b>CfgPlcFastInput</b>					
All parameters	–	–	–	–	–
<b>CfgChannelAxes</b>					
All parameters	–	–	–	–	–

Machine parameters	RESET	Strobe with SYNC_CALC	DRIVE OFF	AXIS DISABLED	REF
<b>CfgLaPath</b>					
minPathFeed	-	-	-	-	-
minCornerFeed	-	-	-	-	-
maxG1Feed	-	-	-	-	-
maxPathJerk	-	-	-	-	-
maxPathJerkHi	-	-	-	-	-
pathTolerance	-	-	-	-	-
pathToleranceHi	-	-	-	-	-
maxPathYank	-	-	-	-	-
<b>CfgAxis</b>					
isAng	X	-	-	-	-
isModulo	-	X	X	-	-
restoreModuloCntr	-	-	-	-	-
isHirth	-	-	-	-	-
axisHw	-	X	X	-	-
axisMode	X	-	-	-	-
testMode	X	-	-	-	-
parList	X	-	-	-	-
realAxis	X	-	-	-	-
noActToNomAtEmSt	-	-	-	-	-
deactivatedAtStart	-	-	-	-	-
advancedSettings	-	-	-	-	-
<b>CfgAxisHardware</b>					
signCorrActualVal		X	X		X
signCorrNominalVal		X	X		X
posEncoderType	-	X	-	X	X
distPerMotorTurn	-	-	-	-	-
posEncoderDist	-	-	-	-	X
posEncoderIncr	-	-	-	-	X
posEncoderSignal	-	-	-	-	-
posEncoderFreq	-	-	-	-	-
posEncoderResistor	-	-	-	-	-
posEncoderRefDist	-	-	-	-	X
genExtIntPolFactor	-	-	-	-	X
posEncoderInput	-	X	X	-	X
speedEncoderInput	-	X	-	X	X
hsciCclIndex	-	X	-	X	X
inverterInterface	-	X	-	X	X
ctrlPerformance	-	X	X	-	-
driveOffGroup	-	-	-	-	-
checkPhiFieldRef	X	-	-	-	-

Machine parameters	RESET	Strobe with SYNC_CALC	DRIVE OFF	AXIS DISABLED	REF
<b>CfgAxisAnalog</b>					
analogOutput	–	–	–	X	–
analogOffset	–	–	–	–	–
kvFactor2	–	–	–	–	–
kvSpeedLimit	–	–	–	–	–
maxFeedAt9V	–	–	–	–	–
accForwardFactor	–	–	–	–	–
compStrength	–	–	–	–	–
compWidth	–	–	–	–	–
compTimeOffset	–	–	–	–	–
compFFAdjust	–	–	–	–	–
compRefAcc	–	–	–	–	–
compLimitFactor	–	–	–	–	–
noOffsetAdjust	–	–	–	–	–
unipolar	–	–	–	–	–
<b>CfgFeedLimits</b>					
minFeed	–	X	–	–	–
maxFeed	–	X	–	–	–
rapidFeed	–	X	–	–	–
manualFeed	–	X	–	–	–
maxAcceleration	–	X	–	–	–
maxAccSpeedCtrl	–	X	–	–	–
maxDecSpeedCtrl	–	X	–	–	–
M19MaxSpeed	–	X	–	–	–
M19NcSpeed	–	X	–	–	–
nominalSpeed	–	X	–	–	–
restoreFeed	–	X	–	–	–
<b>CfgReferencing</b>					
refType	–	X	–	–	X
endatSerial	–	X	–	X	X
refPosition	–	X	–	–	X
refSwitchActive	–	X	–	–	X
externRefPulse	–	–	–	–	X
endatDiff	–	X	–	–	–
refFeedLow	–	X	–	–	–
refFeedHigh	–	X	–	–	–
refDirection	–	X	–	–	X
moveAfterRef	–	X	–	–	–
moveAfterRefType	–	X	–	–	–
moveAfterRefPos	–	X	–	–	–
moveAfterRefFeed	–	X	–	–	–



Machine parameters	RESET	Strobe with SYNC_CALC	DRIVE OFF	AXIS DISABLED	REF
<b>CfgPositionLimits</b>					
swLimitSwitchPos	-	X	-	-	-
swLimitSwitchNeg	-	X	-	-	-
lubricationDist	-	X	-	-	-
<b>CfgControllerAuxil</b>					
driveOffLagMonitor	-	-	-	-	-
checkPosStandstill	-	-	-	-	-
maxPosDiff	-	-	-	-	-
posDiffCountDir	-	-	-	-	X
<b>CfgEncoderMonitor</b>					
checkAbsolutPos	-	X	X	-	-
checkSignalLevel	-	-	-	-	-
checkFrequency	-	-	-	-	-
checkRefDistance	-	-	-	-	-
movementThreshold	-	-	-	-	-
thresholdDistance	-	-	-	-	-
<b>CfgSpindle</b>					
All parameters	-	-	-	-	-
<b>CfgPosControl</b>					
kvFactor	-	-	-	-	-
servoLagMin1	-	-	-	-	-
servoLagMax1	-	-	-	-	-
servoLagMin2	-	-	-	-	-
servoLagMax2	-	-	-	-	-
feedForwardFactor	-	-	-	-	-
controlOutputLimit	-	-	-	-	-
<b>CfgSpeedControl</b>					
vCtrlPropGain	-	-	-	-	-
All further parameters	-	-	-	-	-
<b>CfgCurrentControl</b>					
All parameters	-	-	-	-	-
<b>CfgControllerTol</b>					
All parameters	-	-	-	-	-
<b>CfgPowerStage</b>					
ampName	-	X	-	X	X
ampPowerSupplyType	-	X	-	X	X
ampBusVoltage	-	X	-	X	-
ampPwmFreq	-	X	-	X	-
ampVoltProtection	-	X	-	X	-
ampReadyWaitTime	-	X	-	X	-
ampAcFailSelection	-	X	-	X	-

Machine parameters	RESET	Strobe with SYNC_CALC	DRIVE OFF	AXIS DISABLED	REF
ampFactorI2t	–	X	–	–	–
powStatusCheckOff	–	X	–	–	–
ampAdditionalInfo	–	–	–	–	–
limitOfDcVoltage	–	–	–	–	–
<b>PowerStage-Table</b>					
AmpPeakCurrent	–	X	X	X	–
AmpNomCurrent	–	X	X	X	–
AmpCurrentSensorVoltage	–	X	X	X	–
<b>CfgServoMotor</b>					
motName	–	X	X	–	X
starDelta	–	X		–	–
motEncCheckOff	–	X	–	–	–
motFactorI2t	–	X	–	–	–
motSlipTimeConstant	–	X	X	–	–
motEmergencyStopRamp	–	X	–	–	–
motPbrMax	–	X	–	–	–
motPMax	–	X	–	–	–
motPbrMaxAcFail	–	X	–	–	–
motMMax	–	X	–	–	–
motSupply	–	X	X	–	–
motEncType	–	X	–	X	X
motDir	–	X	–	X	X
motStr	–	X	–	X	X
motTypeOfFieldAdjust	–	–	–	–	–
motFieldAdjustMove	–	–	–	–	–
motPhiRef	–	–	–	–	–
motEncSerialNumber	–	–	–	–	–
motAdditionalInfo	–	–	–	–	–
motSpeedSwitchOver	–	–	–	–	–
motSpeedSwitchBack	–	–	–	–	–
<b>CfgControllerComp</b>					
All parameters	–	–	–	–	–
<b>CfgPositionFilter</b>					
filter1Shape	–	X	–	–	–
filter1LimitFreq	–	X	–	–	–
filter2Shape	–	X	–	–	–
filter2LimitFreq	–	X	–	–	–
manualFilterOrder	–	–	–	–	–
<b>CfgAxisComp</b>					
All parameters	–	–	–	–	–



Machine parameters	RESET	Strobe with SYNC_CALC	DRIVE OFF	AXIS DISABLED	REF
<b>CfgAxisCoupling</b>					
All parameters	–	–	–	–	–
<b>CfgLaAxis</b>					
axTransJerk	–	–	–	–	–
axPathJerk	–	–	–	–	–
axPathJerkHi	–	–	–	–	–
axFilterErrWeight	–	–	–	–	–
<b>CfgAxisHandwheel</b>					
All parameters	–	–	–	–	–
<b>CfgCCAuxil</b>					
All parameters	–	–	–	–	–

### Sequence

A parameter set is selected for an axis with a strobe via the PLC program using Module 9434. Here you must indicate the logical axis number (index from CfgAxis\axisList) and the name of the parameter set (key name from Axes\ParameterSets). The strobe can then be acknowledged, and machining continues with the new parameter set.

Module 9434 responds immediately after execution and reports in the result whether the parameter set could be selected (result=0). It may take some time to switch to the selected parameter set. Use Module 9435 to check which parameter set is active.

Important:



#### Note

Module 9434 does **not** switch off the drive controller. You can switch the drive controller off via your PLC program using **PP\_AxDriveOnRequest** and **PP\_AxPosControlRequest** and reactivate it after the parameter set has been switched.

If the axis is assigned to a machining channel, the execution of an NC program must be synchronized with the module call.



### Module 9435 Status of the parameter set of an axis

The module returns the active parameter set and (if it exists) the selected parameter set of the control loop.

Call:

PS B/W/D/K <Axis number>  
Index from CfgAxes/axisList  
If you are using the iTNC-compatible programming interface  
(API 1.0), you must enter 15 for the spindle.

CM 9435

PL B/W/D <Index of active parameter set>

PL B/W/D <Index of selected parameter set>

-1: No selected parameter set present

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	No error
	1	Error, addressed control loop not present (indicated axis does not exist)

## 4.10 List of Machine Parameters

### 4.10.1 "System" group

Globally effective machine parameters, valid for the entire system.

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgAxes</b>			
Definition of existing axes of all channels in the system; Create entries for all axes of the machine. Also for spindles and PLC axes.			
<b>axisList</b> 100001	<b>Key names for all axes on the machine</b> Enter the axes of all channels of the machine, including spindles and PLC axes. <b>Format:</b> List [0 to 20] <b>Input:</b> Selection menu with the axis key names from Axes/PhysicalAxes <b>Examples:</b> X, Y, Z, etc. or X axis, Y axis etc.	RESET LEVEL3	614
<b>spindleIndices</b> 100002	<b>Key names of all spindles on the machine</b> The key names of the spindle(s) defined here must be listed in MP_axisList. The list index of a spindle key defines the programmable spindle number used by the PLC to identify the spindle. <b>Format:</b> List [0 to 6] <b>Input:</b> Selection menu with the spindle key names from Axes/PhysicalAxes <b>Examples:</b> Index 0 for spindle1, index 1 for spindle2, etc.	RESET LEVEL3	998
<b>specCoordSysList</b> 100003 (optional parameter)	<b>Key names of special axes for the kinematics description</b> If in <b>MP_specKinCoordSys</b> (CfgAxisPropKin) the value <b>FixedTransAxis</b> , <b>DefPointTrans</b> or <b>DefPointRot</b> is defined for an axis, you must enter the respective axis here. <b>Format:</b> List [0 to 20] <b>Input:</b> Selection menu with the axis key names from Axes/PhysicalAxes <b>Examples:</b> C1, Y1, etc.	RESET LEVEL3	616

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgHardware</b>			
Specification of the controller hardware; definition of type of drive controller.			
<b>hardwareType</b> 100101	<b>Type of drive controller hardware</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>automatic:</b> Automatic identification of controller unit</li> <li>■ <b>CC422:</b> CC 422 controller unit for conventional axes</li> <li>■ <b>CC424:</b> CC 424 controller unit for direct drives with high control loop requirements (very short cycle times)</li> <li>■ <b>CC61xx:</b> CC 61xx controller unit with HSCI interface. Define also if the UEC 11x or UMC 11x is used.</li> <li>■ <b>NoCC:</b> No controller unit</li> </ul>	RESET LEVEL3	625
<b>i32stopsMonitoring</b> 100102	<b>Behavior of input I32 (drive enabling)</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>on:</b> If I32=0, all monitoring functions that can be influenced by the PLC are switched off.</li> <li>■ <b>off:</b> Input I32 has no effect on the monitoring functions.</li> </ul> <b>Default:</b> off	RUN LEVEL3	946
<b>maxTouchFeed</b> 100104	<b>Absolute, maximum probing feed rate</b> Limitation of values from touch probe table. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 99 960.000 [mm/min] <b>Default:</b> 960.000 [mm/min]	RUN LEVEL3	1383

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgMachineSimul</b> Switch the MANUALplus 620 to the programming station mode; No drives are enabled. You can create and test NC programs, but you cannot run them. Machine functions are simulated.			
<b>simMode</b> 100201 MP7210	<b>Specifies the type of programming station mode</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>FullOperation:</b>  Programming station mode is switched off.  The wiring of the machine must be complete.  The motors are moving.</li> <li>■ <b>CcOnly:</b>  The programming station is active.  Simulation of the CC controller unit. All PLC inputs and outputs, as well as the emergency-stop circuit, must be connected correctly in order to switch the control on correctly.</li> <li>■ <b>CcAndExt:</b>  The programming station is active.  Simulation of the CC controller unit and all PLC inputs and outputs.</li> <li>■ <b>Delivery:</b>  Mode for commissioning.  During power-up, all axes are automatically put into the test mode. The drives cannot be switched on. In this way, the control can be started even with an incomplete or faulty axis configuration.</li> </ul>	RESET LEVEL3	1234
<b>skipReferencing</b> 100202 (optional parameter)	<b>Fast reference run</b> In programming station mode, the reference run in the axes can be skipped. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b>  The axes are set automatically on the reference positions when the control is started.</li> <li>■ <b>FALSE:</b>  Reference run is also active in the programming station mode.</li> </ul>	RESET LEVEL3	1234



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>skipEmStopTest</b> 100203 (optional parameter)	<b>Do not perform the emergency stop test</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> If the programming station mode is active, the emergency stop test is not performed.</li> <li>■ <b>FALSE:</b> The emergency stop test is performed even if the programming station mode is active.</li> </ul>	RESET LEVEL3	1235
<b>simHardwareType</b> 100200 (optional parameter)	<b>Type of drive controller hardware to be simulated in Programming Station mode</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>automatic:</b> Automatic identification of controller unit</li> <li>■ <b>CC422:</b> CC 422 controller unit for conventional axes</li> <li>■ <b>CC424:</b> CC 424 controller unit for direct drives with high control loop requirements (very short cycle times)</li> <li>■ <b>CC61xx:</b> CC 61xx controller unit with HSCI interface. Also define if the UEC 11x is used.</li> <li>■ <b>NoCC:</b> No controller unit</li> </ul>	RESET LEVEL3	1235
<b>CfgCycleTimes</b> Specification of cycle times for IPO, PLC and look-ahead			
<b>ipoCycle</b> 100301 MP7600.0	<b>Position controller cycle time (interpolation clock)</b> At present, only a cycle time of 3 [ms] for the position controller is supported. The value of 3 ms is therefore preset by the system. <b>Format:</b> Selection menu <b>Input:</b> 3 ms <b>Default:</b> 3 ms	RESET LEVEL3	838
<b>plcCount</b> 100302 MP7600.1, MP7602	<b>PLC cycle time (look-ahead cycle time)</b> The PLC and the Look Ahead run at a clock rate that is a multiple of the IPO clock (interpolation clock). The Look Ahead function is triggered exactly two IPO clock pulses after the PLC. <b>Format:</b> Numerical value <b>Input:</b> 3 to 10 [· MP_ipoCycle] <b>Default:</b> 7 (= 21 ms)	RESET LEVEL3	1481

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>watchdogTime</b> 100303 MP2172	<b>Delayed switch-off of SH1</b> Define the recovery time for watchdog 2 here. <b>Format:</b> Numerical value <b>Input:</b> 1 to 30 [s] <b>Default:</b> 3 [s]	RUN LEVEL3	989
<b>CfgFilter</b> Default configuration of position command filters, applies to all axes. Can be overwritten axis-specifically. ■ <b>defaultPosition:</b> Default configuration of the position command filter for all linear axes			
<b>shape</b> 100405	<b>Shape of the nominal position value filter</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>Off:</b> Filter is off ■ <b>Average:</b> Mean-value filter ■ <b>Triangle:</b> Single filter ■ <b>HSC:</b> HSC filter (High Speed Cutting) (setting for "accuracy" criterion) ■ <b>Advanced HSC:</b> Advanced HSC filter (High Speed Cutting) (setting for "surface" criterion)	Allowed in strobe LEVEL3 597 110-05	814
<b>frequency</b> 100405	<b>Cutoff frequency of the nominal position value filter</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 1000 [Hz] Max. 9 decimal places <b>Default:</b> 20 [Hz]	Allowed in strobe LEVEL3 597 110-05	814



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>hscMode</b> 100405	<b>Operating mode of the nominal position value filter</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>Smoothing:</b> Mode for finishing operations</li> <li>■ <b>Roughing:</b> Mode for roughing operations</li> </ul> <b>Default:</b> Smoothing	Allowed in strobe  LEVEL3  597 110-05	814
<b>defaultManualOrder</b> 100407	<b>Order of the mean-value filter for the Manual Operation mode</b>  <b>Format:</b> Numerical value  <b>Input:</b> 1 to 51  <b>Default:</b> 11	Allowed in strobe  LEVEL3  597 110-05	814

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgPosCorrection</b>			
Parameters for asynchronous position compensation			
<b>enable</b> 100501 (optional parameter)	<b>Asynchronous position compensation on/off</b> <b>Input:</b> ■ <b>on:</b> Asynchronous position compensation is switched on ■ <b>off:</b> Asynchronous position compensation is switched off	RUN LEVEL3	1253
<b>feed</b> 100502 (optional parameter)	<b>Velocity for asynchronous position compensation</b> Velocity intended for compensations. Input: 0 to 99 960 [mm/min] Default: 960 [mm/min]	RUN LEVEL3	1253
<b>CfgHandwheel</b>			
Parameters for configuring the electronic handwheel; Configuration of serial handwheel connected to X23.			
<b>type</b> 100601 MP7640	<b>Type of handwheel</b> Enter the model of the connected handwheel. If you set the value <b>HRNAX</b> , you must enter more details on the connected handwheel in <b>MP_CfgAxisHandwheel</b> . <b>Format:</b> Selection menu <b>Input:</b> ■ <b>NONE:</b> No serial handwheel connected ■ <b>HRNAX:</b> Up to three HR 150 handwheels via HRA 110 handwheel adapter ■ <b>HR410:</b> HR 410 portable handwheel ■ <b>HR332:</b> HR 332 portable handwheel ■ <b>HR330:</b> HR 330 portable handwheel ■ <b>HR130:</b> HR 130 panel-mounted handwheel	RUN LEVEL3	1334
<b>initValues</b> 100602 MP7645	<b>Initialization values for handwheel</b> <b>Format:</b> List [0 to 7] <b>Input:</b> 0 to 255 <b>Default:</b> 0	RUN LEVEL3	1334

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>incrPerRevol</b> 100603 (optional parameter)	<b>Increments per handwheel revolution</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 100 000 [incr] <b>Default:</b> 0, this corresponds to 20 000 [incr]	RUN LEVEL3	1335
<b>rasterPerRevol</b> 100604 (optional parameter)	<b>Detent steps per handwheel revolution</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 100 000 <b>Default:</b> 0	RUN LEVEL3	1335
<b>countDir</b> 100605 MP7650	<b>Counting direction for handwheel</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>positive:</b> Positive counting direction</li> <li>■ <b>negative:</b> Negative counting direction</li> </ul> <b>Default:</b> positive	RUN LEVEL3	1335
<b>sensitivity</b> 100606 MP7660	<b>Sensitivity for electronic handwheel</b> Shock or vibrations can cause a slight motion at the handwheel. You can define a threshold sensitivity for the handwheel to prevent unintentional axis movements. <b>Format:</b> Numerical value <b>Input:</b> 0 to 10 000 [pulses] <b>Default:</b> 0	RUN LEVEL3	1336
<b>speedFactor</b> 100607 MP7670.0 MP7670.1 MP7670.2	<b>Handwheel transmission ratio</b> Three transmission ratios [%]. Distance per handwheel revolution: Transmission ratio defined in <b>MP_CfgAxisHandwheel : MP_distPerRevol.</b> <b>Format:</b> List [0 to 2] <b>Input:</b> [0] = First ratio [%] [1] = Second ratio [%] [2] = Third ratio [%] <b>Default:</b> 1, 10 and 100 [%]	RUN LEVEL3	1336

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>feedFactor</b> 100608	<b>Manual feed rates in the E1. Handwheel</b> mode Percentage factor for the 3 velocity levels. The effective handwheel feed rate is equal to the feed-rate percentage factor multiplied by the maximum handwheel feed rate of the selected axis.  Format: List [0 to 2]  Input:  [0] = First ratio [%] [1] = Second ratio [%] [2] = Third ratio [%]  Default: 1, 10 and 100 [%]	RUN  LEVEL3	1336
<b>selectAxes</b> 100610 (optional parameter)	<b>Selection of axes for the handwheel</b> Select the axes to be moved with the handwheel.  <b>Extra information:</b> <ul style="list-style-type: none"> <li>■ On portable handwheels with axis keys, e.g. HR 410: Make a list entry for each axis key on the handwheel. The sequence of the list sets the assignment to the axis keys X, Y, Z, IV, V on the handwheel.</li> <li>■ With HR 150 panel-mounted handwheels through HRA 110: Handwheel on X1 of HRA 110: 1st list entry Handwheel on X2 of HRA 110: 2nd list entry Handwheel on X3 of HRA 110: The initialization parameters and the position of the selection switch set which list entry is to be used.</li> <li>■ With HR 130 panel-mounted handwheel: Do not define parameter. The axes are assigned via the PLC program (e.g. Module 9036).</li> </ul> Format: List [0 to 8]  Input: Select the axes using the selection menu	RUN  LEVEL3	1338
<b>crossShortSafety</b> 100609 MP7640 (optional parameter)	<b>Cross-circuit-proof handwheel</b> Specifies whether a cross-circuit test is performed on the permissive buttons.  Format: Selection menu  Input: <ul style="list-style-type: none"> <li>■ <b>on:</b> Cross-circuit test is active</li> <li>■ <b>off:</b> No cross-circuit test</li> </ul>	RUN/ LEVEL3	1337



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>DisplaySettings</b> Configuration of the user interface			
<b>CfgUnitOfMeasure</b> Definition of unit of measure in effect for display			
<b>unitOfMeasure</b>  101101	<b>Unit of measure for display and user interface</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>metric:</b> Metric system</li> <li>■ <b>inch:</b> Inches</li> </ul> <b>Default:</b> metric	RUN  LEVEL1	1224



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgDisplayLanguage</b>			
Definition of the NC and PLC conversational language			
<b>ncLanguage</b> 101301 MP7230.0	<b>NC conversational language</b>  <b>Format:</b> Selection menu  <b>Input:</b> <b>ENGLISH</b> – English dialog text <b>GERMAN</b> – German dialog text <b>CZECH</b> – Czech dialog text <b>FRENCH</b> – French dialog text <b>ITALIAN</b> – Italian dialog text <b>SPANISH</b> – Spanish dialog text <b>PORTUGUESE</b> – Portuguese  dialog text  <b>SWEDISH</b> – Swedish dialog text <b>DANISH</b> – Danish dialog text <b>FINNISH</b> – Finnish dialog text <b>DUTCH</b> – Dutch dialog text <b>POLISH</b> – Polish dialog text <b>HUNGARIAN</b> – Hungarian dialog  text  <b>RUSSIAN</b> – Russian dialog text <b>CHINESE</b> Chinese (simplified) dialog text <b>CHINESE_TRAD</b> Chinese (traditional) dialog text <b>SLOVENIAN</b> Slovenian dialog text (option #41) <b>ESTONIAN</b> Estonian dialog text (option #41) <b>KOREAN</b> Korean dialog text (option #41) <b>LATVIAN</b> Latvian dialog text (option #41) <b>NORWEGIAN</b> Norwegian dialog text (option #41) <b>ROMANIAN</b> Romanian dialog text (option #41) <b>SLOVAK</b> Slovak dialog text (option #41) <b>TURKISH</b> Turkish dialog text (option #41) <b>LITHUANIAN</b> Lithuanian dialog text (option #41)  <b>Default:</b> ENGLISH	RUN LEVEL1	1226
<b>plcDialogLanguage</b> 101301 MP7230.1	<b>PLC conversational language</b>  <b>Format:</b> Selection menu  <b>Input:</b> see <b>MP_ncLanguage</b>  <b>Default:</b> ENGLISH	RUN LEVEL1	1227

<b>Parameter MP number iTNC MP number</b>	<b>Function and input</b>	<b>Behavior Access SW vers.</b>	<b>Page</b>
<b>plcErrorLanguage</b> 101303 MP7230.2	<b>PLC error message language</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_ncLanguage</b> <b>Default:</b> ENGLISH	RUN LEVEL1	1227
<b>helpLanguage</b> 101304 MP7230.3	<b>Language for online help</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_ncLanguage</b> <b>Default:</b> ENGLISH	RUN LEVEL1	1227
<b>CfgOsciColor</b> Color settings for the internal oscilloscope			
<b>background</b> 101401 MP7365.0	<b>Background color</b> <b>Format:</b> Selection menu <b>Input:</b> black blue light_gray red dark_gray light_green really_light_gray really_dark_gray light_violet dark_green light_blue light_red medium_gray yellow white <b>Default:</b> white	NOTHING LEVEL3	1159
<b>channel1</b> 101402 MP7365.4	<b>Color for channel 1</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_background</b> <b>Default:</b> blue	NOTHING LEVEL3	1160
<b>channel2</b> 101403 MP7365.5	<b>Color for channel 2</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_background</b> <b>Default:</b> light_green	NOTHING LEVEL3	1160
<b>channel3</b> 101404 MP7365.6	<b>Color for channel 3</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_background</b> <b>Default:</b> light_blue	NOTHING LEVEL3	1160

<b>Parameter MP number iTNC MP number</b>	<b>Function and input</b>	<b>Behavior Access SW vers.</b>	<b>Page</b>
<b>channel4</b> 101405 MP7365.7	<b>Color for channel 4</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_background</b> <b>Default:</b> yellow	NOTHING LEVEL3	1160
<b>channel5</b> 101406 MP7365.8	<b>Color for channel 5</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_background</b> <b>Default:</b> light_violet	NOTHING LEVEL3	1160
<b>channel6</b> 101407 MP7365.9	<b>Color for channel 6</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_background</b> <b>Default:</b> dark_green	NOTHING LEVEL3	1160
<b>logicTrace</b> 101408	<b>Color for logic-trace channels</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_background</b> <b>Default:</b> black	NOTHING LEVEL3	1161
<b>select</b> 101409 MP7365.3	<b>Color for selected channel</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_background</b> <b>Default:</b> red	NOTHING LEVEL3	1161
<b>grid</b> 101410 MP7365.1	<b>Color for graduation</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_background</b> <b>Default:</b> medium_gray	NOTHING LEVEL3	1161
<b>cursorText</b> 101411 MP7365.2	<b>Color for cursor and text</b> <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_background</b> <b>Default:</b> really_dark_gray	NOTHING LEVEL3	1161



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgStartupData</b> Behavior during control startup			
<b>powerInterruptMsg</b> 101501	<b>Acknowledge the Power interrupted message</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> Start-up is only continued after the message has been acknowledged. ■ <b>FALSE:</b> The <b>Power interrupted</b> message does not appear. <b>Default:</b> TRUE	PLC/Pgm run is locked LEVEL1	1314

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgShutDown</b> Behavior when exiting control operation			
<b>shutdownOnConfig</b> 101601 MP4040 (optional parameter)	<b>Behavior when RESET configuration data is changed</b> Specifies the MANUALplus 620's reaction to a change that requires a RESET. <b>Note:</b> If no value is entered for this parameter (icon appears dimmed), no automatic reset will be performed. In this case you start the reset by soft key. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>RESTART:</b> Control shuts down and restarts</li> <li>■ <b>TERMINATE:</b> Control shuts down. For controls with additional Windows operating system: Windows keeps running.</li> <li>■ <b>SHUTDOWN:</b> Control shuts down. For controls with additional Windows operating system: Windows shuts down.</li> <li>■ <b>POWEROFF:</b> Shut down the control</li> </ul> <b>Default:</b> RESTART	PLC/Pgm run is locked LEVEL1	1320
<b>shutdownOnError</b> 101602 MP4040	<b>Behavior when RESET errors are acknowledged</b> Specifies the MANUALplus 620's behavior when a RESET error is acknowledged. <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_shutdownOnConfig</b> <b>Default:</b> RESTART	PLC/Pgm run is locked LEVEL1	1320
<b>shutdownOnUser</b> 101603 MP4040	<b>Behavior when the MANUALplus 620 is shut down by soft key</b> Specifies the MANUALplus 620's behavior when it is shut down by soft key. <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_shutdownOnConfig</b> <b>Default:</b> TERMINATE	PLC/Pgm run is locked LEVEL1	1321



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>shutdownOnOem</b> 101604 MP4040	<b>Behavior when PLC module 9279 is called</b> Specifies the MANUALplus 620's behavior when the OEM shuts down the control using PLC module 9279. <b>Format:</b> Selection menu <b>Input:</b> see <b>MP_shutdownOnConfig</b> <b>Default:</b> TERMINATE	PLC/Pgm run is locked LEVEL1	1321
<b>maxTermTime</b> 101605 (optional parameter)	<b>Delay time until control is shut down</b> Defines the time before the process is terminated. <b>Format:</b> Numerical value <b>Input:</b> 0 to 1000 [s] <b>Default:</b> 0 [s]	PLC/Pgm run is locked LEVEL1	1322
<b>powerOffDevice</b> 101608 (optional parameter)	<b>Number of the device in the HSCI chain</b> System with HSCI interface: Enter the number of the device in the HSCI chain (= bus address) at which the control is to set a PLC output after shutting down in order to switch off the power supply, for example. System without HSCI interface: Do not assign the parameter. <b>Format:</b> Numerical value <b>Input:</b> 0 to 20 <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1322
<b>powerOffSlot</b> 101609 (optional parameter)	<b>Number of the PL module in the HSCI device</b> System with HSCI interface: Enter the number of the PL module on the HSCI PL at which a PLC output is to be set after shutting down. System without HSCI interface: Do not assign the parameter. <b>Format:</b> Numerical value <b>Input:</b> 0 to 8 <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1322



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>powerOffPort</b> 101606 MP4041 (optional parameter)	<b>Number of terminal in the PL module or on the internal PL</b> System with HSCI interface: Enter the number of the PLC output of the module, which is to be set after shutting down. System without HSCI interface: Enter the number of the PLC output of the integrated PL, which is to be set after shutting down. <b>Format:</b> Numerical value <b>Input:</b> 0 to 31 <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1323
<b>powerOffDelay</b> 101607 MP4042 (optional parameter)	<b>Delay time until the PLC output is set</b> Time after shutting down the control until the PLC output from <b>MP_powerOffPort</b> is set. <b>Format:</b> Numerical value <b>Input:</b> 0 to 1000 [s] <b>Default:</b> 0 [s]	PLC/Pgm run is locked LEVEL1	1323



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgDashboardElemnt</b>			
Configuration of the dashboard elements			
<b>[Key name of the dashboard element]</b>			
e.g. DB_ADD_CORR1, DB_ALL_AXES1, etc.			
<b>dashboardpicType</b> 113101	<b>Image type of a dashboard element</b> Defines the image assigned to this dashboard element. <b>Format:</b> Selection menu <b>Input:</b> Name of the dashboard element	RUN LEVEL1	1294
<b>attribut</b> 113102 (optional parameter)	<b>Attribute more closely describing the dashboardpicType</b> Defines the attribute assigned to this dashboard element. <b>Format:</b> Numerical value <b>Input:</b> 0 to 2147483647	RUN LEVEL1	1294
<b>entityList</b> 113103 (optional parameter)	<b>Key name as parameter for the selected dashboardpicType</b> Defines the machining channel or axes to be displayed in this dashboard element. <b>Format:</b> List [0 to 40] <b>Input:</b> Max. 18 characters	RUN LEVEL1	1294
<b>CfgDashboard</b>			
Configuration of the dashboard			
<b>[Key name of the dashboard]</b>			
e.g. DB_DEFAULT, DB_DEFAULT1, etc.			
<b>elementList</b> 113201	<b>List of dashboard elements, filled from the CfgDashboardElemnt pool</b> Defines the dashboard elements to be contained in a configured dashboard. For each dashboard you enter the key names of up to 16 dashboard elements. <b>Format:</b> List [0 to 40] <b>Input:</b> Selection menu	RUN LEVEL3	1292

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgOemWindow</b>			
Position of the OEM windows in the dashboard			
<b>[Key name of the OEM window]</b>			
e.g. Dashboard_1, Dashboard_2, etc.			
<b>upperLeft</b> 605201 (optional parameter)	<b>Dashboard element number of upper left corner of OEM window</b> The dashboard elements are counted from upper left to right. <b>Format:</b> Numerical value <b>Input:</b> 0 to 19	PLC/Pgm run is locked LEVEL1	1294
<b>bottomRight</b> 605202 (optional parameter)	<b>Dashboard element number of lower right corner of OEM window</b> The dashboard elements are counted from upper left to right. <b>Format:</b> Numerical value <b>Input:</b> 0 to 19	PLC/Pgm run is locked LEVEL1	1294
<b>CfgCoordSystem</b>			
Setting the world coordinate system			
<b>coordSystem</b> 114901	<b>World coordinate system</b> Defines the coordinate system of the lathe. The coordinate system influences the graphical display in the ICP editor and of the support graphics, as well as the position of the axes in the simulation. <b>Format:</b> Selection menu <b>Input:</b> +X, +Z -X, +Z +X, +Z +Z, -X <b>Default:</b> +X, +Z	PLC/Pgm run is locked LEVEL3	1388

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgMMISettings</b> General settings for the Machine mode of operation			
<b>extManualMode</b> 604901 (optional parameter)	<b>Enhanced mode for machine operation</b> Defines the menu guidance of the user interface (3x3 menu) in the <b>Machine</b> mode of operation. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> The manual cycles are consolidated to the submode MDI in the user interface.</li> <li>■ <b>FALSE:</b> The Manual cycles are not shown consolidated in the user interface.</li> </ul>	PLC/Pgm run is locked LEVEL1	1229
<b>extProgramMode</b> 604902 (optional parameter)	<b>Enhanced mode for program run</b> Defines whether a horizontal menu for selecting additional functions is to be inserted below the dashboard in the <b>Program Run</b> mode of operation. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> A horizontal menu is displayed below the dashboard in the <b>Program Run</b> mode.</li> <li>■ <b>FALSE:</b> No horizontal menu shown.</li> </ul>	PLC/Pgm run is locked LEVEL1	1229

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgGlbDispSettings</b> General display settings			
<b>plcSpindleSelect</b> 604801 (optional parameter)	<b>Selection of spindle number via PLC</b> Defines whether spindle selection by the PLC is to be enabled. The selected spindle is then entered in a non-editable input field in the TSF dialog. When the spindle data is saved, it is assigned only to the selected spindle. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Spindle-dependent input (speed, direction of rotation, etc.) refers to the spindle number selected by the PLC.</li> <li>■ <b>FALSE:</b> Input refers to the spindle assigned to the tool carrier</li> </ul> <b>Default:</b> FALSE	PLC/Pgm run is locked LEVEL1	1411
<b>plcChannelSelect</b> 604802 (optional parameter)	<b>Selection of channel number via PLC</b> Defines whether channel selection by the PLC is to be enabled. Currently without function. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Channel-dependent input refers to the channel number selected by the PLC</li> <li>■ <b>FALSE:</b> Input is possible for only one channel</li> </ul> <b>Default:</b> FALSE	PLC/Pgm run is locked LEVEL1	1411





Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>axesDisplayMode</b> 604803 (optional parameter)	<b>Axis display</b> Specifies the type of axis display. Display of the actual value, nominal value, following error or distance-to-go can be configured. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>Default:</b> Display as defined in the attribute of the dashboard element</li> <li>■ <b>REFACTL:</b> Display of the actual value</li> <li>■ <b>RFNOML:</b> Display of the nominal value</li> <li>■ <b>LAG:</b> Display of the following error (lag)</li> <li>■ <b>DIST:</b> Display of the distance yet to go</li> </ul> <b>Default:</b> Default	PLC/Pgm run is locked LEVEL1	1295
<b>mmiFilePreview</b> 604804 (optional parameter)	<b>File preview during program selection</b> Defines whether a file preview window is to be displayed below the program list when selecting the programs. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> File preview window is displayed below the program list when selecting programs.</li> <li>■ <b>FALSE:</b> No file preview window is displayed when selecting programs.</li> </ul> <b>Default:</b> FALSE	PLC/Pgm run is locked LEVEL1	1410

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>Paths</b>			
Definition of the paths and file names in effect for entire system			
<b>CfgOemPath</b>			
Paths for OEM files; File paths that can be created and changed by the OEM.			
<b>oemTable</b> 102001	<b>Path for OEM tables</b> <b>Format:</b> String <b>Input:</b> Path, max. 260 characters Path entry via selection window <b>Default:</b> %OEM%\table	RESET LEVEL3	1605
<b>dialogTextfile</b> 102002 (optional parameter)	<b>Name of the text file for OEM texts</b> The path %OEM%\plc\language\en is preset by the system, whereby the last subdirectory is formed from the configured language (here en = English). Enter the name (without the path) for OEM text files. You can enter a maximum of 11 files of the *.CSV type in which you define your OEM-specific texts. <b>Format:</b> List [0 to 10] <b>Input:</b> Name of the text file Max. 80 characters	RESET LEVEL3	370
<b>cycleMainTreeFile</b> 102003 (optional parameter)	<b>Path and name for the OEM cycle file (.CDF)</b> <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	RESET LEVEL3	1546
<b>cycleSubTreeFiles</b> 102004 (optional parameter)	<b>List of path/names of user cycle files (.CDF)</b> The soft key rows of these files are appended to the soft key rows of the HEIDENHAIN or OEM files. <b>Format:</b> List [0 to 10] <b>Input:</b> Path and name, max. 260 characters	RESET LEVEL3	1546
<b>oemCycle</b> 102005 (optional parameter)	<b>Path for OEM cycles</b> <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	RESET LEVEL3	1546



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>ncDir</b>  102006	<b>List of drives and/or directories</b>  The drives and directories entered here are visible in the file manager, provided that you have the required access rights. The respective paths contain NC programs or tables, for example, floppy disk drive directories, HDR or CFR directories, network drives, etc.  Format: List [0 to 10]  Input: String, max. 260 characters	RESET  LEVEL3	1538
<b>CfgUserPath</b>  Paths for the end user; Directories that are to be visible in the file manager. These entries can be edited by the machine operator .			
<b>ncDir</b>  102201	<b>List of drives and/or directories</b>  The drives and directories entered here are visible in the file manager, provided that you have the required access rights. The respective paths contain NC programs or tables, for example, floppy disk drive directories, HDR or CFR directories, network drives, etc.  <b>Format:</b> List [0 to 10]  <b>Input:</b> String, max. 260 characters	NOTHING  LEVEL1	1539

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgPlcPath</b>			
Path/name of most recently compiled PLC program files			
<b>mainPgm</b> 102301	<b>Path/name of the PLC main program</b> <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	NOTHING LEVEL2	1543
<b>pwmPgm</b> 102302	<b>Path/name of the PLC commissioning program</b> PLC program for commissioning the current controller. This PLC program is alternately compiled and used if the special mode of operation for adjusting the current controller is opened before acknowledgment of the "Power interrupted" message. <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	NOTHING LEVEL2	1543
<b>splcMainPgm</b> 102313 (optional parameter)	<b>Path/name of the SPLC main program</b> Define only for controls with integrated functional safety (FS).	NOTHING LEVEL2 597 110-05	–
<b>errorTable</b> 102303	<b>Path/name of the PLC error message table (PET table)</b> <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	NOTHING LEVEL2	1543
<b>errorText</b> 102304	<b>Name of the text file for PLC error messages</b> The path %OEM%\plc\language\en is preset by the system, whereby the last subdirectory is formed from the configured language (here en = English). <b>Format:</b> String <b>Input:</b> File name, max. 260 characters <b>Default:</b> ErrorText.csv	NOTHING LEVEL2	1543
<b>dialog</b> 102305	<b>Name of text file for PLC dialogs</b> The path %OEM%\plc\language\en is preset by the system, whereby the last subdirectory is formed from the configured language (here en = English). <b>Format:</b> String <b>Input:</b> File name, max. 260 characters	NOTHING LEVEL2	1544

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>softkeyProject</b> 102306	<b>Path/name of project file for PLC soft keys (*.XRS)</b>  <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	NOTHING LEVEL2	1544
<b>compCfgFile</b> 102308	<b>Path/name of configuration file for PLC compiler (*.MCG)</b>  <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	NOTHING LEVEL2	1545
<b>spicCompCfgFile</b> 102314	<b>Path/name of configuration file for S PLC compiler (*.MCG)</b>  Define only for controls with integrated functional safety (FS). <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	NOTHING LEVEL2 597 110-05	–
<b>events</b> 102309	<b>Path/name of the event list (SPAWN processes)</b>  Reserved, do not define. If evaluation is not in process, events for SPAWN processes are to be defined over PLC modules. <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	NOTHING LEVEL2	–
<b>keymapFile</b> 102310	Path/name of configuration file for keyboard mapping  <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	NOTHING LEVEL2	1545
<b>magazineRules</b> 102311	<b>Path/name for a file with magazine rules</b>  Enter the path and name of a file with magazine rules for managing the tool memory. Example: <b>%OEM%\plc\tchrules.tcr</b> <b>Format:</b> String <b>Input:</b> Path and name, max. 260 characters	NOTHING LEVEL2	1545

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>pythonScripts</b> 102315 (optional parameter)	<b>Python scripts to be started</b> Specifies which Python scripts are automatically started after compilation of the PLC program. Enter the key names of the Python scripts from <b>CfgPythonScript</b> . <b>Format:</b> List [0 to 8] <b>Input:</b> Key name, max. 18 characters	NOTHING LEVEL2 597 110-05	1545
<b>CfgTablePath</b> Path for tables that can be activated in SQL commands through the symbolic name (SQL synonym) given as the key name. If you use SQL commands for accessing the table, only enter the synonym instead of the complete path and file name, for example, TOOL instead of TNC:\table\tool.t. Some synonym names for tables are already predefined by HEIDENHAIN. You can also add your own synonym names.			
<b>path</b> 102501	<b>Symbolic table names for access via SQL commands</b> Path for tables that can be activated in SQL commands through the symbolic name (SQL synonym) given as the key name. These symbolic names are used in cycles or in the PLC. <b>Format:</b> String <b>Input:</b> Path/name, max. 500 characters	NOTHING LEVEL1	1606
<b>readOnlyMode</b> 102502	Write protection for this table in the table editor <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> The table can no longer be changed through the table editor. Access is only possible via SQL commands.</li> <li>■ <b>FALSE:</b> The table can be changed through the table editor.</li> </ul> <b>Default:</b> FALSE	NOTHING LEVEL1	–



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>ProgramManager</b> Configuration of the program manager for file management.			
<b>CfgFileType</b> Assignment of the editor to a file type; Depending on the file extension, a standard editor as well as further data required for controlling the editing process are assigned.			
<b>[Key name of the file extension]</b> e.g.: H (HEIDENHAIN programs), I (ISO programs), CMA (table for axis-error compensation), etc.			
<b>unitOfMeasure</b>  102901	<b>Unit of measure for length (metric/inch)</b> Position display, NC programs, tables etc. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>UNIT_MM:</b> Input in mm</li> <li>■ <b>UNIT_INCH:</b> Input in inches</li> <li>■ <b>UNIT_MMINCH:</b> Input in mm or inches</li> <li>■ <b>UNIT_INDEPENDENT:</b> Input without unit of measure</li> </ul>	PLC/Pgm run is locked LEVEL3	1595
<b>standardEditor</b>  102902	<b>Standard editor used for this file</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TEXT EDITOR</b></li> <li>■ <b>PROGRAM EDITOR</b></li> <li>■ <b>TABLE EDITOR</b></li> <li>■ <b>HELP VIEWER</b></li> <li>■ <b>PATTERN EDITOR</b></li> </ul>	PLC/Pgm run is locked LEVEL3	1595
<b>fileSize</b>  102903  (optional parameter)	<b>File size above which the alternative editor is used</b> Files larger than <b>MP_fileSize</b> are no longer converted into binary format by the program editor. <b>Format:</b> Numerical value <b>Input:</b> File size [KB]	PLC/Pgm run is locked LEVEL3	1595

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>alternateEditor</b> 102904 (optional parameter)	<b>Alternative editor for files larger than MP_fileSize</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ TEXT EDITOR</li> <li>■ PROGRAM EDITOR</li> <li>■ TABLE EDITOR</li> <li>■ HELP VIEWER</li> <li>■ PATTERN EDITOR</li> </ul>	PLC/Pgm run is locked LEVEL3	1596
<b>softkeyIcon</b> 102905 (optional parameter)	<b>Path/name of a graphic file for a graphic soft key (soft-key icon)</b> An icon can be used instead of a text in the table editor if, in addition, the parameter <b>MP_choice</b> (TableSettings/Columns/CfgColumnText) is defined. <b>Format:</b> String <b>Input:</b> Path/name of the icon Max. 260 characters	PLC/Pgm run is locked LEVEL3	1596
<b>softkeyIconVariant</b> 102906 (optional parameter)	<b>Variant number of the soft-key icon</b> You can specify a variant number in addition to the path/name of a soft-key icon (for BMX files with multiple levels). <b>Format:</b> Numerical value <b>Input:</b> 0 to 100	PLC/Pgm run is locked LEVEL3	1596
<b>protect</b> 102900 (optional parameter)	<b>Disable file types</b> Lock the soft keys for selecting the file type. You can also lock the EDITING ON/OFF soft key to prevent any editing of the file type. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>LOCK_OFF:</b> File type not locked</li> <li>■ <b>LOCK_SOFTKEY:</b> Lock the <b>SELECT TYPE</b> soft key for selection of the file type</li> <li>■ <b>LOCK_FILETYPE:</b> Lock file types from editing</li> <li>■ <b>LOCK_ALL:</b> Lock the <b>SELECT TYPE</b> soft key for selection of the file type and lock the file type to prevent editing</li> </ul>	PLC/Pgm run is locked LEVEL3	1597





Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>PLC</b>			
Settings for PLC run-time system			
<b>CfgPlcPeriphery</b>			
Configuration of PLC peripheral devices: IOC configuration, assignment of logical to physical PLs; behavior of the override potentiometers; Reaction of the PT100 inputs, etc.			
<b>iocProject</b> 103402	<b>Configuration file for IOC hardware</b> Specifies the path/file name of the configuration file for HSCI and PROFIBUS components. <b>Format:</b> String <b>Input:</b> Path/name of the IOC file Max. 260 characters	RESET LEVEL3 597 110-03	1516
<b>iocOption</b> 103403	<b>Option data for IOC hardware (HSCI, PROFIBUS)</b> By inserting "-" in front of the name of the option, it can be disabled. <b>Format:</b> List [0 to 100] <b>Input:</b> String, max. 32 characters	RESET LEVEL3	1517
<b>pt100Discrete</b> 103404 MP4020.7	<b>Transfer of PT100 values</b> Format: Selection menu <b>Input:</b> ■ <b>TRUE:</b> Transfer value immediately ■ <b>FALSE:</b> Transfer value at 1 K/s <b>Default:</b> TRUE	PLC/Pgm run is locked LEVEL3	1369
<b>tempCompensation</b> 103405 MP4070	<b>Compensation of thermal expansion</b> Compensation speed for lag-tracking axis-error compensation <b>Format:</b> Numerical value <b>Input:</b> 0 to 359 999.64 [mm/min]	PLC/Pgm run is locked LEVEL3	721
<b>overrideFullRatio</b> 103406 (optional parameter)	<b>Compensation for cable losses of the override potentiometers</b> <b>Format:</b> Numerical value <b>Input:</b> 0.5 to 1.0 <b>Default:</b> 0.98	PLC/Pgm run is locked LEVEL3	1360

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>override100Ratio</b> 103411	<b>Compensation for differing adjustment of the override potentiometers</b> Reserved for HEIDENHAIN, do not make any entries in this parameters on your own. <b>Format:</b> Numerical value <b>Input:</b> 0.5 to 1.0 <b>Default:</b> 0.6275	PLC/Pgm run is locked LEVEL3	–
<b>overrideDelta</b> 103407 (optional parameter)	<b>Compensation for thermal noise in override potentiometers</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0001 to 0.1 <b>Default:</b> 0.0005	PLC/Pgm run is locked LEVEL3	1360
<b>overrideIntegDelta</b> 103408 (optional parameter)	<b>Compensation for thermal noise in override potentiometers</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0001 to 1.0 <b>Default:</b> 0.025	PLC/Pgm run is locked LEVEL3	1360

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgPlcTimer</b> Default values for PLC timers and counters Changes do not become effective until the PLC program has been restarted.			
<b>[Key name of the PLC timer or counter]</b>			
<b>run</b> 103503 (optional parameter)	<b>Process marker for the timer or counter</b> Identifies the timer or counter, for which the respectively configured time applies. <b>Timer:</b> T48 to T999 <b>Counter:</b> C48 to C95 If two or more times are configured, the parameter identifies the first timer or counter. <b>Format:</b> String <b>Input:</b> Process marker, max. 80 characters	RUN LEVEL3 597 110-03	1527
<b>start</b> 103504 (optional parameter)	<b>Start marker for the timer or counter</b> Identifies the start marker for the timer or counter. <b>Timer:</b> T0 to T47 <b>Counter:</b> C0 to C47 There is no start marker for timers T96 to T999. They can be started only through Module 9006. This parameter is not evaluated by the control. The PLCdesignNT development environment uses it for the automatic generation of PLC definition files. <b>Format:</b> String <b>Input:</b> Start marker, max. 80 characters	RUN LEVEL3 597 110-03	1527
<b>gate</b> 103505 (optional parameter)	Release marker for counters Identifies the enabling marker (gate marker) for the corresponding counter. <b>Gate markers:</b> C96 to C143 This parameter is not evaluated by the control itself. The PLCdesignNT development environment uses it for the automatic generation of PLC definition files. <b>Format:</b> String <b>Input:</b> Gate marker, max. 80 characters	RUN LEVEL3 597 110-03	1528

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>unit</b> 103501	<b>Unit of measure</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>SECONDS:</b> Input in seconds [s] ■ <b>PLC_CYCLES:</b> Input in number of PLC cycles <b>Default:</b> SECONDS	RUN LEVEL3	1528
<b>value</b> 103502 MP4110 / 4120	<b>Default value for PLC timers/counters</b> <b>Format:</b> List [1 to 100] <b>Input:</b> 0 to 1 000 000 [s or PLC cycles] <b>Default:</b> 0 [s or PLC cycles]	RUN LEVEL3	1528
<b>CfgPlcFastInput</b> Configuration of fast PLC inputs; Specifies the numbers, operands and edge detection. Keep in mind that the time between two edges must be longer than the time from 'MP_CfgCycleTimes/ipoCycle'.			
<b>number</b> 103701 MP4130	<b>Numbers of fast PLC inputs</b> <b>Format:</b> List [0 to 4] <b>Input:</b> 0 to 9999 <b>Default:</b> 0	RUN LEVEL3	1532
<b>significance</b> 103702 MP4131	<b>Activation criteria for fast PLC inputs</b> <b>Format:</b> List [0 to 4] with selection menu <b>Input:</b> ■ <b>lowActive:</b> Activate at LOW level ■ <b>highActive:</b> Activate at HIGH level ■ <b>allEdges:</b> Activate at both levels ■ <b>disabled:</b> Switched off	RUN LEVEL3	1533
<b>operand</b> 103703 (optional parameter)	<b>PLC operand for fast PLC inputs</b> Name or number of the operand that is set through the fast PLC input. <b>Format:</b> List [0 to 4] <b>Input:</b> String, max. 24 characters	RUN LEVEL3	1533

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgPlcMStrobe</b> Settings for M functions; Output of M strobe from NC to PLC: Specifies the treatment of the M function during NC program run and the mapping to the PLC markers.			
<b>[Key names with the name or numerical code of the M strobe]</b> e.g. M00, M917, G26, G720, etc.			
<b>min</b>  103901	<b>Number of the first M Function</b>  First M function code described in the parameter object. The properties described in this parameter object apply for the specified M functions.  <b>Format:</b> Numerical value <b>Input:</b> 0 to 9999 <b>Default:</b> 0	RESET  LEVEL3	1550
<b>max</b>  103902  (optional parameter)	<b>Number of the largest M function</b>  Code of the last (greatest) M function described in the parameter object. No input: The properties of the parameter object apply only to the M function defined in <b>MP_min</b> .  <b>Format:</b> Numerical value <b>Input:</b> 0 to 9999 <b>Default:</b> 0	RESET  LEVEL3	1550
<b>signal</b>  103903  (optional parameter)	<b>Symbolic name or number of the PLC marker that is set when the function is decoded.</b>  If you have not entered a value in the parameter <b>MP_acknowledge</b> , resetting this marker means an acknowledgment of the strobe. No input: The data connected with the output of the strobe are saved without synchronization with the PLC program and the output is immediately acknowledged.  <b>Format:</b> String <b>Input:</b> PLC operand, max. 80 characters	RESET  LEVEL3	1551
<b>acknowledge</b>  103904  (optional parameter)	<b>Symbolic name or number of the PLC marker that is set for acknowledging the strobe</b>  No input: The strobe is reset with the PLC marker entered in <b>MP_signal</b> .  <b>Format:</b> String <b>Input:</b> PLC operand, max. 80 characters	RESET  LEVEL3	1551

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>code</b> 103905 (optional parameter)	<p>Symbolic name or number of the PLC word marker for the M code</p> <p>Name of the PLC word marker in which the M code is passed to the PLC.</p> <p><b>Example:</b>    <b>DG_M_Function_M10</b></p> <p><b>Format:</b>     String</p> <p><b>Input:</b>        PLC operand, max. 80 characters</p>	RESET LEVEL3	1552
<b>data</b> 103906	<p><b>Symbolic name or number of the PLC word marker for additional data</b></p> <p>Symbolic name or number of the PLC word marker in which the additional data of the M function is transmitted to the PLC.</p> <p>The field size determined from the symbol defines up to how many data can be saved in the programmed sequence. If an absolute number is given, only one value is saved. If no value is entered, no data can be passed to the PLC.</p> <p><b>Format:</b>     String</p> <p><b>Input:</b>        PLC operand, max. 80 characters</p>	RESET LEVEL3	1552
<b>revoke</b> 103907	<p><b>Numbers of M functions whose effect will be canceled by the output of the strobe.</b></p> <p>In the list, enter the numbers of the functions whose effect will be canceled when this code is output.</p> <p>Example: Configuration of M5 function When the M5 function is called, the effect of the M3 and M4 functions is canceled. In this example, you would enter the key names of the functions M3 and M4.</p> <p>The parameter is effective for implementing the state of the function in the status display and during block scan.</p> <p><b>Format:</b>     List [0 to 10]</p> <p><b>Input:</b>        0 to 9999</p>	RESET LEVEL3	1552



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>split</b> 103908 (optional parameter)	<p><b>The M function is split into the specified M functions</b></p> <p>The currently active M function can be split into the two specified M functions. You can cancel it in part by canceling one of the specified M functions. The currently active M function is split up if part of it is canceled by the <b>MP_revoke</b> parameter.</p> <p>Example: M13 = Spindle ON clockwise (M3) + coolant ON (M8)            If function M13 is active and an M5 is collected during the block scan, for example, the function M3 contained in M13 is canceled. Only function M8 remains active. In this case, enter <b>3</b> and <b>8</b> in the parameter.</p> <p><b>Format:</b> List [2] with numerical values  <b>Input:</b> Numbers of M functions</p>	RESET LEVEL3	1553
<b>group</b> 103915 (optional parameter)	<p><b>Group ID</b></p> <p>After the block scan, the collected M functions are implemented in the order of their group IDs (starting from the lowest).</p> <p><b>Format:</b> Numerical value  <b>Input:</b> 0 to 2147483647</p>	RESET LEVEL3	1553
<b>track</b> 103914 (optional parameter)	<p><b>Automatic tracking of the active M functions</b></p> <p>Normally the PLC program has to use the module 9088 to track the status of the active M function. Set this parameter to TRUE if the PLC run-time system is to implement the status automatically.</p> <p><b>Format:</b> Selection menu  <b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b>              The status of the active M function is tracked automatically, depending on the <b>MP_trackMState</b> parameter (CfgPlcOptions).</li> <li>■ <b>FALSE:</b>              The status of the active M function must be tracked by calling Module 9088.</li> </ul>	RESET LEVEL3	1553



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>singular</b> 103909 (optional parameter)	<b>Function is output in a separate strobe</b> With the "singular" parameter you can prevent the function from being output in a strobe together with other functions. If several M, S, T functions are programmed in an NC block, the strobes can be set in parallel by the NC. With this parameter, you can exclude the current function from this parallel collection and simultaneous transmission in one strobe. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Function is output in a separate strobe. Combined output is prevented.</li> <li>■ <b>FALSE:</b> Function can be combined with other functions</li> </ul>	RESET LEVEL3	1554
<b>blockEnd</b> 103910	<b>M function output at block end or block start</b> <b>Format:</b> Selection menu <b>Input:</b> TRUE or FALSE <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Function is executed at block end.</li> <li>■ <b>FALSE:</b> Function is executed at beginning of block.</li> </ul> <b>Default:</b> FALSE	RESET LEVEL3	1554
<b>blockSearch</b> 103911	<b>Code output also during block scan</b> <b>Format:</b> Selection menu <b>Input:</b> TRUE or FALSE <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Function is also output during the block scan</li> <li>■ <b>FALSE:</b> Function is not output during the block scan. The function is collected and restored.</li> </ul> <b>Default:</b> FALSE	RESET LEVEL3	1554





Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<p><b>sync</b></p> <p>103912</p>	<p><b>Synchronization of function with the NC</b></p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>SYNC_EXEC:</b> The function is synchronized with program run. The output of movement by the interpolator is stopped; then the function is executed. Please note: After this function has been executed, the look-ahead calculation continues using the position values that were active <b>before</b> execution of the function. This setting is not suitable, for example, for M functions executing PLC positioning movements!</li> <li>■ <b>SYNC_CALC:</b> The function is synchronized with program calculation. The interpretation of the NC program is stopped and the path is calculated internally; then the function is executed. The M function is completely executed. After successful execution has been acknowledged, calculation continues with new position values.</li> <li>■ <b>ASync:</b> The function is output without synchronization.</li> </ul>	<p>RESET</p> <p>LEVEL3</p>	<p>1555</p>
<p><b>macro</b></p> <p>103913</p>	<p><b>Calling an NC macro with an M function</b></p> <p>This makes it possible to indicate and run an NC subprogram instead of outputting the M function.</p> <p><b>Format:</b> String</p> <p><b>Input:</b> Path/name of the macro Max. 80 characters</p>	<p>RESET</p> <p>LEVEL3</p>	<p>1555</p>

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgPlcSStroke</b> Settings for the S function of a spindle Output of S strobe from NC to PLC: Specifies the treatment of the S function during NC program run and the mapping to the PLC markers.			
[Key name with the number or name of the spindle] e.g. S, etc.			
<b>type</b> 104017 (optional parameter)	<b>Type of S strobe</b> If the control supports more than one type of S strobe for one NC channel, you have to indicate the type of S strobe applicable for the config object CfgPlcSStrobes. If the control supports a single S strobe for an NC channel, the parameter must not be defined. <b>Format:</b> Numerical value <b>Input:</b> 0 to 5	RESET LEVEL3	1563
<b>condition</b> 104001 (optional parameter)	<b>Condition for sending the strobe to the PLC</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>COND_ALWAYS:</b> Strobe is output with every programmed S code</li> <li>■ <b>COND_ST:</b> Strobe is output only if spindle speed changes</li> <li>■ <b>COND_GP:</b> Strobe is output only if gear range changes If the parameter is missing from the configuration, the strobe is always output.</li> </ul>	RESET LEVEL3	1562
<b>signal</b> 104002 (optional parameter)	<b>Symbolic name or number of the PLC marker that is set when the function is decoded.</b> If you have not entered a value in the parameter <b>MP_acknowledge</b> , resetting this marker means an acknowledgment of the strobe. No input: The data connected with the output of the strobe are saved without synchronization with the PLC program and the output is immediately acknowledged. <b>Format:</b> String <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1562

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>acknowledge</b> 104003 (optional parameter)	<b>Symbolic name or number of the PLC marker that is set for acknowledging the strobe</b>  No input: The strobe is reset with the PLC marker entered in <b>MP_signal</b> .  <b>Format:</b> String  <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1562
<b>spindleSpeed</b> 104004 (optional parameter)	<b>Symbolic name or number of the PLC word for transmitting the spindle speed</b>  Name of the PLC word in which the spindle speed is transmitted to the PLC.  No input: The spindle speed cannot be read as a numerical value.  <b>Format:</b> String  <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1563
<b>badSpeed</b> 104005 (optional parameter)	<b>Symbolic name or number of the PLC marker for impermissible spindle speeds</b>  Name of the PLC marker that is set if the spindle speed is outside the permissible range.  No input: The spindle speed is not monitored.  <b>Format:</b> String  <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1564
<b>cuttingSpeed</b> 104018 (optional parameter)	<b>Symbolic name or number of the PLC word for transmitting the constant cutting speed</b>  Name of the PLC word in which the constant surface speed is transmitted to the PLC.  No input: The constant surface speed cannot be read as a numerical value.  <b>Format:</b> String  <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1564

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>spindleMode</b> 104006 (optional parameter)	<b>Symbolic name or the number of a word marker</b>  Name or number of the word marker in which the spindle mode of rotation (96 = constant spindle speed, 97 = constant cutting speed) is transmitted to the PLC. Depending on the value of the word marker, the PLC evaluates either the content of MP_spindleSpeed or MP_cuttingSpeed.  No input: The spindle mode of rotation cannot be read as a numerical value.  <b>Format:</b> String  <b>Input:</b> PLC operand, max. 80 characters	RESET  LEVEL3	1564
<b>gearCode</b> 104007 (optional parameter)	<b>Symbolic name or number of the PLC word for the gear range</b>  Name of the PLC word in which the gear range is transmitted to the PLC.  No input: No gear range is transmitted  <b>Format:</b> String  <b>Input:</b> PLC operand, max. 80 characters	RESET  LEVEL3	1569
<b>gearSpeed0</b> 104008 (optional parameter)	<b>Key names of parameter sets for gear ranges (operating mode 0)</b>  <b>Format:</b> List [0 to 100]  <b>Input:</b> Key name of parameter sets (operating mode 0)	RESET  LEVEL3	1569
<b>gearSpeed1</b> 104009 (optional parameter)	<b>Key names of parameter sets for gear ranges (operating mode 1)</b>  <b>Format:</b> List [0 to 100]  <b>Input:</b> Key name of parameter sets (operating mode 1)	RESET  LEVEL3	1569
<b>gearStop</b> 104010 MP3030, bit 1 (optional parameter)	<b>Switch off the spindle when the gear range is changed</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> If a strobe for changing the gear range is output, the control automatically switches the spindle off.</li> <li>■ <b>FALSE:</b> If a strobe for changing the gear range is output, the spindle is not switched off.</li> </ul>	RESET  LEVEL3  597 110-03	1569

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>sCode</b> 104011	<b>Symbolic name or number of the PLC word for the coded output of the spindle speed</b>  Name of the PLC word in which the S code of the spindle speed is transmitted to the PLC  <b>Format:</b> String <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1572
<b>revoke</b> 104012  (optional parameter)	<b>Numbers of functions whose effect will be canceled by the output of the strobe.</b>  In the list, enter the numbers of the functions whose effect will be canceled when this code is output.  The parameter is effective for implementing the state of the function in the status display and during block scan.  <b>Format:</b> List [0 to 10] <b>Input:</b> 0 to 9999	RESET LEVEL3	1565
<b>singular</b> 104013  (optional parameter)	<b>Function is output in a separate strobe</b>  With the "singular" parameter you can prevent the function from being output in a strobe together with other functions. If several M, S, T functions are programmed in an NC block, the strobes can be set in parallel by the NC. With this parameter, you can exclude the current function from this parallel collection and simultaneous transmission in one strobe.  <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> Function is output in a separate strobe. Combined output is prevented. ■ <b>FALSE:</b> Function can be combined with other functions	RESET LEVEL3	1565
<b>blockSearch</b> 104014	<b>Code output also during block scan</b>  <b>Format:</b> Selection menu <b>Input:</b> TRUE or FALSE ■ <b>TRUE:</b> Function is also output during the block scan ■ <b>FALSE:</b> Function is not output during the block scan. The function is collected and restored.  <b>Default:</b> FALSE	RESET LEVEL3	1566

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>sync</b>  104015	<p><b>Synchronization of function with the NC</b></p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>SYNC_EXEC:</b> The function is synchronized with program run. The output of movement by the interpolator is stopped; then the function is executed. Please note: After this function has been executed, the look-ahead calculation continues using the position values that were active <b>before</b> execution of the function. This setting is not suitable for functions executing PLC positioning movements, for example!</li> <li>■ <b>SYNC_CALC:</b> The function is synchronized with program calculation. The interpretation of the NC program is stopped and the path is calculated internally; then the function is executed. The S function is completely executed. After successful execution has been acknowledged, calculation continues with new position values.</li> <li>■ <b>ASYNC:</b> The function is output without synchronization.</li> </ul>	RESET  LEVEL3	1570
<b>syncGear</b>  104016	<p><b>Synchronization of function with the NC if the gear range changes</b></p> <p>If the parameter is missing, synchronization is as given by the parameter <b>MP_sync</b>.</p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>SYNC_EXEC:</b> The function is synchronized with program run. The output of movement by the interpolator is stopped; then the function is executed. Please note: After this function has been executed, the look-ahead calculation continues using the position values that were active <b>before</b> execution of the function. This setting is not suitable for functions executing PLC positioning movements, for example!</li> <li>■ <b>SYNC_CALC:</b> The function is synchronized with program calculation. The interpretation of the NC program is stopped and the path is calculated internally; then the function is executed. The S function is completely executed. After successful execution has been acknowledged, calculation continues with new position values.</li> <li>■ <b>ASYNC:</b> The function is output without synchronization.</li> </ul>	RESET  LEVEL3	1571



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgPlcTStrobe</b> Settings of the T functions (ToolCall and ToolDef); Output of the T strobe from the NC to the PLC; Specifies the treatment of the T function during NC program run, and the mapping to the PLC marker.			
<b>[Key name of the T strobe]</b> e.g. ToolCall, ToolDef, etc.			
<b>type</b> 104101	<b>Type of T function</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>T0:</b> Remove tool from spindle</li> <li>■ <b>T1:</b> Insert tool in spindle</li> <li>■ <b>T2:</b> Prepare the next tool change</li> </ul>	RESET LEVEL3	1576
<b>condition</b> 104102 (optional parameter)	<b>Condition for sending the strobe to the PLC</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>COND_ALWAYS:</b> Strobe is output with every programmed S code</li> <li>■ <b>COND_ST:</b> Strobe is output only if spindle speed changes</li> <li>■ <b>COND_GP:</b> Strobe is output only if gear range changes If the parameter is missing from the configuration, the strobe is always output.</li> </ul>	RESET LEVEL3	1576
<b>signal</b> 104103 (optional parameter)	<b>Symbolic name or number of the PLC marker that is set when the function is decoded.</b> If you have not entered a value in the parameter <b>MP_acknowledge</b> , resetting this marker means an acknowledgment of the strobe.  No input: The data connected with the output of the strobe are saved without synchronization with the PLC program and the output is immediately acknowledged.  <b>Format:</b> String <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1577

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>acknowledge</b> 104104 (optional parameter)	<b>Symbolic name or number of the PLC marker that is set for acknowledging the strobe</b>  No input: The strobe is reset with the PLC marker entered in <b>MP_signal</b> .  <b>Format:</b> String <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1577
<b>toolNumber</b> 104105 (optional parameter)	<b>Symbolic name or number of the PLC word for transmitting the tool number</b>  No input: The tool number cannot be read as a numerical value.  <b>Format:</b> String <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1577
<b>toolIndex</b> 104106 (optional parameter)	<b>Symbolic name or number of the PLC word for transmitting the tool index</b>  No input: The index cannot be read as a numerical value.  Input: String, max. 24 characters	RESET LEVEL3	1578
<b>toolMagazine</b> 104107 (optional parameter)	<b>Symbolic name or number of the PLC word for transmitting the magazine number of the tool</b>  No input: The magazine number cannot be read as a numerical value.  <b>Format:</b> String <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1578
<b>pocketNumber</b> 104108 (optional parameter)	<b>Symbolic name or number of the PLC word for transmitting the pocket number of the tool</b>  No input: The pocket number cannot be read as a numerical value.  <b>Format:</b> String <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1578
<b>unloadTool</b> 104109 (optional parameter)	<b>Symbolic name or number of the PLC marker that is set during decoding if no tool is loaded</b>  The definition of this marker is not necessary, if the T0 and T1 strobes are otherwise distinguished.  <b>Format:</b> String <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3 597 110-03	1578



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>externalTool</b> 104110 (optional parameter)	<b>Symbolic name or number of the PLC marker that is set during decoding if a tool is loaded that is not in the magazine</b>  The definition of the marker is not necessary if the magazine and pocket numbers are evaluated elsewhere or are irrelevant.  <b>Format:</b> String  <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3 597 110-03	1579
<b>internalTool</b> 104111	<b>Symbolic name or number of the PLC marker that is set during decoding if a tool is loaded that is in the magazine</b>  The definition of the marker is not necessary if the magazine and pocket numbers are evaluated elsewhere or are irrelevant.  <b>Format:</b> String  <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3	1579
<b>specialTool</b> 104112 (optional parameter)	<b>Symbolic name or number of the PLC marker that is set during decoding if a special tool is loaded</b>  The definition of this marker is not necessary if no special tools are used.  <b>Format:</b> String  <b>Input:</b> PLC operand, max. 80 characters	RESET LEVEL3 597 110-03	1579
<b>revoke</b> 104113 (optional parameter)	<b>Numbers of functions whose effect will be canceled by the output of the strobe.</b>  In the list, enter the numbers of the functions whose effect will be canceled when this code is output.  The parameter is effective for implementing the state of the function in the status display and during block scan.  <b>Format:</b> List [0 to 10]  <b>Input:</b> 0 to 9999	RESET LEVEL3	1580

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>singular</b> 104114 (optional parameter)	<b>Function is output in a separate strobe</b> <p>With the "singular" parameter you can prevent the function from being output in a strobe together with other functions. If several M, S, T functions are programmed in an NC block, the strobes can be set in parallel by the NC. With this parameter, you can exclude the current function from this parallel collection and simultaneous transmission in one strobe.</p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Function is output in a separate strobe. Combined output is prevented.</li> <li>■ <b>FALSE:</b> Function can be combined with other functions</li> </ul>	RESET LEVEL3	1580
<b>blockSearch</b> 104115	<b>Code output also during block scan</b> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b> TRUE or FALSE</p> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Function is also output during the block scan</li> <li>■ <b>FALSE:</b> Function is not output during the block scan. The function is collected and restored.</li> </ul> <p><b>Default:</b> FALSE</p>	RESET LEVEL3	1581



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>sync</b>  104116	<b>Synchronization of function with the NC</b>  <b>Format:</b> Selection menu  <b>Input:</b>  <ul style="list-style-type: none"> <li>■ <b>SYNC_EXEC:</b> The function is synchronized with program run. The output of movement by the interpolator is stopped; then the function is executed. Please note: After this function has been executed, the look-ahead calculation continues using the position values that were active <b>before</b> execution of the function. This setting is not suitable for functions executing PLC positioning movements, for example!</li> <li>■ <b>SYNC_CALC:</b> The function is synchronized with program calculation. The interpretation of the NC program is stopped and the path is calculated internally; then the function is executed. The S function is completely executed. After successful execution has been acknowledged, calculation continues with new position values.</li> <li>■ <b>ASYNC:</b> The function is output without synchronization.</li> </ul>	RESET  LEVEL3	1581

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgPlcStrobeAlias</b> Conversion to M functions; Reproduction of control-dependent functions through the output of M functions to the PLC program.			
<b>[Key names of the converted functions (alias strobes)]</b> e.g. GFUNCTION, TCHPROBE etc.			
<b>type</b>  104201	<b>Type of alias strobe</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>FN19:</b> Two values are transmitted synchronously from the NC program to the PLC.</li> <li>■ <b>FN29:</b> Up to eight values are transmitted asynchronously from the NC program to the PLC.</li> <li>■ <b>CYCLE13:</b> Define spindle position for M19</li> <li>■ <b>TCHPROBE:</b> Call the measuring cycles.</li> <li>■ <b>GFUNCTION:</b> G functions are transmitted to the PLC. The G functions, including the function parameters, are transferred in an M strobe.</li> </ul>	RESET LEVEL3	1583
<b>mCode</b>  104202	<b>Number of the M function</b> Number of the M function for which the control-dependent function is mapped. <b>Format:</b> Numerical value <b>Input:</b> 0 to 9999 <b>Default:</b> 0	RESET LEVEL3	1584
<b>mOffset</b>  104203	<b>Transferred M code is offset</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> The first numerical value transferred is used as an offset and entered in the parameter <b>MP_min</b> of the associated M function. The remaining numerical values are written to the double word entered in <b>MP_data</b>.</li> <li>■ <b>FALSE:</b> No offset is used. The MANUALplus 620 always issues the M function given under <b>MP_min</b>. Both transferred numerical values are written to the array of double words entered in <b>MP_data</b>.</li> </ul>	RESET LEVEL3	1584



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgPlcOverrideDev</b> Configuration of sources for override values; Define the hardware input of the potentiometers and the evaluation.			
<b>[Key name of override device]</b> e.g. potentiometerF, potentiometerS, etc.			
<b>source</b> 104301	<b>Selection of configurable source for override values</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>OVR1:</b> Potentiometer 1 Feed-rate override input <b>F</b> on the rear side of the TE.</li> <li>■ <b>OVR2:</b> Potentiometer 2 Spindle-override input <b>S</b> on the rear side of the TE.</li> <li>■ <b>OVR3:</b> Potentiometer 3 Rapid-traverse override input <b>E</b> on the rear side of the TE.</li> <li>■ <b>KEY:</b> Group of keys</li> </ul> <b>Default:</b> OVR1	RESET LEVEL3	1353
<b>mop</b> 104304	<b>Enter the key name of the machine operating panel on which the override source is located</b> Defines the operating panel on which the override source is located. <b>Format:</b> Selection menu <b>Input:</b> Key name from <b>CfgPlcMop</b>	RESET LEVEL3	1353

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>mode</b>  104302	<b>Evaluation of override values</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>DISCRETE:</b> The key inputs or potentiometer settings are converted in up to 25 discrete <b>override</b> values from <b>MP_values</b>.</li> <li>■ <b>LINEAR:</b> The input from the override device is interpolated linearly between the minimum and maximum override value.</li> <li>■ <b>CURVE:</b> The input values of the override device are converted using the curve defined in <b>MP_values</b>. You define the curve with up to 64 interpolation points in <b>MP_values</b>. The input values of the override device are again interpolated linearly above the last interpolation point specified. If no curve is defined in <b>MP_values</b>, the control uses a standard curve.</li> </ul> Default: DISCRETE	RESET  LEVEL3	1353
<b>values</b>  104303  (optional parameter)	<b>Discrete values or interpolation points for curve</b>  The mode of operation of the parameter depends on the setting in <b>MP_mode</b> : <ul style="list-style-type: none"> <li>■ <b>MP_mode = DISCRETE:</b> Enter override values for a maximum of 64 key inputs or potentiometer settings.</li> <li>■ <b>MP_mode = LINEAR:</b> MP_values has no function</li> <li>■ <b>MP_mode = CURVE:</b> Define a curve with up to 64 interpolation points. The override values are taken from the curve. Linear interpolation is again effective above the last interpolation point specified.</li> </ul> Format: Array [0...63] Input: 0 to 200	RESET  LEVEL3	1354



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgPlc OverrideS</b>			
Configuration of the spindle override			
<b>[Key name of spindle]</b>			
e.g. S, spindle, etc.			
<b>minimal</b> 104401	<b>Minimum value for override</b> Format: Numerical value Input: 0 to 100 [%] Default: 0	RESET LEVEL3	1355
<b>maximal</b> 104402	<b>Maximum value for override</b> Format: Numerical value Input: 0 to 200 [%] Default: 150	RESET LEVEL3	1355
<b>source</b> 104403	<b>Source for override values</b> Format: Selection menu Input: Device name from <b>CfgOverrideDev</b>	RESET LEVEL3	1355
<b>CfgOemBool</b>			
User parameter with Boolean data (logical values)			
<b>[Key name of the user status value]</b>			
The key names of these objects are arbitrary and are defined by the OEM. If the data is to be copied into the PLC run time image, the key names must match the PLC marker names, e.g. M4017 (for API 1.0) or NP_MG_Doors_Inactive (for API 3.0), etc.			
<b>value</b> 104501 (optional parameter)	<b>List of user status values (Boolean)</b> Format: List [1 to 100] Input: TRUE or FALSE	PLC/Pgm run is locked LEVEL3	1658
<b>ignorePlc</b> 104502 (optional parameter)	<b>Do not copy data object into the PLC image</b> Format: Selection menu Input: ■ <b>TRUE:</b> The parameter value is not copied to the PLC run-time system ■ <b>FALSE:</b> The parameter value is copied to the PLC run-time system	PLC/Pgm run is locked LEVEL3	1658

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgOemInt</b>			
User parameter with integer data (whole number)			
<b>[Key name of the user integer value]</b>			
The key names of these objects are arbitrary and are defined by the OEM. If the data is to be copied into the PLC run time image, the key names must match the PLC word names, e.g. W960, W976 (for API 1.0) or NP_DG_Lubrication_Time (for API 3.0), etc.			
<b>value</b> 104601 (optional parameter)	<b>List of user whole-number values (integers)</b> <b>Format:</b> List [1 to 100] <b>Input:</b> -2 147 483 648 to +2 147 483 647	PLC/Pgm run is locked LEVEL3	1658
<b>ignorePlc</b> 104602 (optional parameter)	<b>Do not copy data object into the PLC image</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> The parameter value is not copied to the PLC run-time system ■ <b>FALSE:</b> The parameter value is copied to the PLC run-time system	PLC/Pgm run is locked LEVEL3	1658
<b>CfgOemString</b>			
User parameter with text data (strings)			
<b>[Key name of the user string]</b>			
The key names of these objects are arbitrary and are defined by the OEM. The data of the user strings is not available in the PLC run-time system, but can be used in user cycles, for example.			
<b>value</b> 104701 (optional parameter)	<b>List of user text parameters (strings)</b> <b>Format:</b> List [1 to 100] <b>Input:</b> String, max. 100 characters	PLC/Pgm run is locked LEVEL3	1658
<b>ignorePlc</b> 104702 (optional parameter)	<b>Do not copy data object into the PLC image</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> The parameter value is not copied to the PLC run-time system ■ <b>FALSE:</b> The parameter value is copied to the PLC run-time system	PLC/Pgm run is locked LEVEL3	1658



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgOemPosition</b>			
User parameter with fixed-point data (position value)			
<b>[Key name of the user fixed-point value]</b>			
The key names of these objects are arbitrary and are defined by the OEM. If the data is to be copied into the PLC run time image, the key names must match the PLC double word names, e.g. D768 (for API 1.0) or NP_DG_TOOLCH_Pos_Spindle (for API 3.0), etc.			
<b>value</b> 104701 (optional parameter)	<b>List of user fixed-point values (position)</b> Format: List [1 to 100] Input: -30 000 to +30 000 max. 4 decimal places	PLC/Pgm run is locked LEVEL3	1658
<b>ignorePlc</b> 104702 (optional parameter)	<b>Do not copy data object into the PLC image</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> The parameter value is not copied to the PLC run-time system ■ <b>FALSE:</b> The parameter value is copied to the PLC run-time system	PLC/Pgm run is locked LEVEL3	1658
<b>PythonSettings</b>			
Settings for software option #46 (Python OEM process)			
<b>Process</b>			
Settings for the automatic start of Python scripts (software option #46)			
<b>CfgPythonScript</b>			
Python scripts to be started automatically; Specifies Python processes that are automatically started by the PLC run-time system during startup and not by calling a PLC module. The scripts defined below must be activated under CfgPlcPath/pythonScripts.			
<b>[Key name of the Python script to be started automatically]</b>			
<b>path</b> 120401	<b>Path/name of the Python script</b> When the soft key entered in the key name is pressed, the given Python script is started. <b>Format:</b> String <b>Input:</b> Path/name of the Python script Max. 260 characters	PLC/Pgm run is locked LEVEL3 597 110-05	1586

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>jobName</b> 120402	<b>Name of the Python application</b> Specifies the name of the Python application. You can choose any name you want. The application will be displayed with this name, e.g. in the PLC process monitor. <b>Format:</b> String <b>Input:</b> Max. 17 characters	PLC/Pgm run is locked LEVEL3 597 110-05	1586
<b>parameter</b> 120403 (optional parameter)	<b>Calling parameters for the Python script</b> Specifies expanded calling parameters for the Python script. <b>Format:</b> String <b>Input:</b> Max. 127 characters	PLC/Pgm run is locked LEVEL3 597 110-05	1586
<b>memLimit</b> 120404	<b>Memory limit for the Python application</b> Specifies the maximum memory available for the Python application to be started. <b>Format:</b> Numerical value <b>Input:</b> Memory limit [MB]	PLC/Pgm run is locked LEVEL3 597 110-05	1586
<b>CfgPlcSymName</b> Names for PLC variable (marker)			
<b>stoppingAngle</b> 116101 (optional parameter)	<b>PLC operand for transfer of the spindle stopping angle</b> Name of the PLC word in which the current spindle stopping angle is transmitted to the PLC <b>Format:</b> String <b>Input:</b> Double word, max. 500 characters	PLC/Pgm run is locked LEVEL1	1404
<b>maxSpeedSpindle</b> 116102 (optional parameter)	<b>PLC operand for transfer of the maximum spindle speed</b> Name of the PLC word in which the maximum spindle speed is transmitted to the PLC. <b>Format:</b> String <b>Input:</b> Double word, max. 500 characters	PLC/Pgm run is locked LEVEL1	1404
<b>dbLoadDisplay</b> 116103 (optional parameter)	<b>PLC operand for dashboard load display</b> Name of the PLC word in which the respective axis or spindle utilization value is transferred from the PLC to the utilization display of the dashboard. <b>Format:</b> String <b>Input:</b> Double word, max. 500 characters	PLC/Pgm run is locked LEVEL1	1405



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>readTsfData</b> 116104 (optional parameter)	<b>Reading TSF data with the PLC</b> PLC reads data from "Set T, S, F" dialog <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> The PLC reads the data on feed rate per revolution or per minute and constant cutting speed / spindle speed from the <b>ch_tsf.mch</b> and <b>sp_tsf.msp</b> tables. ■ <b>FALSE:</b> The control always starts with feed per revolution and constant cutting speed.	PLC/Pgm run is locked LEVEL1	1406
<b>displayMode</b> 116105 (optional parameter)	<b>Transfer display mode to PLC</b> Name of the PLC word in which the current display mode (manual, automatic, reference) is transmitted to the PLC <b>Format:</b> String <b>Input:</b> Double word, max. 500 characters	PLC/Pgm run is locked LEVEL1	1406
<b>setToolPlace</b> 116106 (optional parameter)	<b>Tool pocket preset by the PLC</b> Name of the PLC word under which the PLC can define a tool pocket, which is then inserted by the user interface and displayed. <b>Format:</b> String <b>Input:</b> Double word, max. 500 characters	PLC/Pgm run is locked LEVEL1	1406
<b>CfgPlcOperTimes</b> Configuration of machining time display			
<b>displayPlcTimes</b> 105001 MP7237.0	<b>Display PLC operating times</b> <b>Format:</b> Bit-encoded value <b>Input:</b> %xxxxxxx Bit 0 to bit 7 = PLC time 1 to 8 0: Do not display 1: Display	PLC/Pgm run is locked LEVEL2	1374
<b>resetPlcTimes</b> 105002 MP7237.1	<b>Reset PLC operating times with code number 857282</b> <b>Format:</b> Bit-encoded value <b>Input:</b> %xxxxxxx Bit 0 to bit 7 = PLC time 1 to 8 0: Do not reset 1: Reset	PLC/Pgm run is locked LEVEL2	1374

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>resetNcTimes</b> 105003 MP7237.2	<b>Reset NC operating times with code number 857282</b>  <b>Format:</b> Bit-encoded value  <b>Input:</b> %xxx Bit 0 to bit 2 = NC time 1 to 3 Bit 0 – Nonfunctional Bit 1 – "Machine on" operating time Bit 2 – "Program run" operating time 0: Do not reset 1: Reset	PLC/Pgm run is locked  LEVEL2	1374
<b>textNumber</b> 105004 MP7238	<b>Dialogs for PLC operating times</b>  Lists 0 to 7, field 0 is the text for PLC time 1. In the text file for PLC dialogs, indicate the line number of the dialog text. This text file is located under %OEM%\plc\language\en, whereby the last subdirectory is formed from the configured language (here en=English).  <b>Format:</b> List [0 to 7]  <b>Input:</b> 0 to 2147483647	PLC/Pgm run is locked  LEVEL2	1375
<b>CfgSystemTime</b> Universal time (Greenwich Mean Time)			
<b>offsetToUTC</b> 105201 MP7235	<b>Time difference to universal time</b>  This is used in the real-time system (HeROS). Difference to universal time (UTC: Universal Time Coordinated), e.g. UTC+1h for Central European Time (CET)  <b>Format:</b> Selection menu  <b>Input:</b> Time difference from UTC UTC–10h, UTC–9h, UTC–8h, UTC–7h, UTC–6h, UTC–5h, UTC–4h 30min, UTC–4h, UTC–3h, UTC–2h, UTC–1h, <b>UTC,</b> UTC+1h, UTC+2h, UTC+3h, UTC+4h, UTC+5h, UTC+5h 30min, UTC+6h, UTC+7h, UTC+8h, UTC+9h, UTC+9h 30min, UTC+10h, UTC+11h, UTC+12h  <b>Default:</b> UTC+1h (CET)	RESET  LEVEL1	1379



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>TableSettings</b> Description of the table types of the MANUALplus 620; Specifies the properties of the tables.			
<b>CfgTableProperties</b> Assignment of columns to a table type; Specifies: <ul style="list-style-type: none"> <li>■ The columns in the table</li> <li>■ The primary and foreign key</li> </ul> With this information you can import a table or create a new one.			
<b>[Key name with the file extension of the table]</b> E. g. CMA, COM, TCH, etc.			
<b>columnKeys</b> 105501	<b>List of key names of the columns used</b> Key names of all columns that form the table. The column names must be available under <b>Columns</b> . <b>Format:</b> List [0 to 79] <b>Input:</b> Column name, max. 18 characters	PLC/Pgm run is locked LEVEL3	1598
<b>primaryKey</b> 105502	<b>Primary key (column name) for sorting</b> Name of the column, based upon which the data is sorted in ascending order. The column name must be available under <b>CfgTableProperties/[key name]/columnKeys</b> . <b>Format:</b> String <b>Input:</b> Column name, max. 18 characters	PLC/Pgm run is locked LEVEL3	1598
<b>foreignKey</b> 105503 (optional parameter)	<b>Foreign key for this table</b> Specify a string for every list entry: <b>&lt;column name&gt; &lt;blank space&gt; &lt;referential action&gt;</b> Valid values for <b>&lt;referential action&gt;</b> are: <ul style="list-style-type: none"> <li>■ NO ACTION</li> <li>■ RESTRICT</li> <li>■ SET NULL</li> <li>■ SET DEFAULT</li> <li>■ INHERIT</li> </ul> <b>Format:</b> List [1 to 80] <b>Input:</b> String, max. 40 characters	PLC/Pgm run is locked LEVEL3	1598
<b>modificationKey</b> 105504 (optional parameter)	<b>Key name of the column in which the timestamp is to be entered if a line is modified</b> <b>Format:</b> String <b>Input:</b> <extension>.<column name> Max. 18 characters	PLC/Pgm run is locked LEVEL3	1598

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>Columns</b> Specifies the column names for all columns of all tables			
<b>[Key name = Name of the column]</b> As key name, enter the name of the table column. If the column is to be used only in a certain table, you must enter a unique key name. The column name must be preceded by the table type (i.e. the table extension) followed by a period: <b>[Table extension].[Column name]</b> E.g. MOT.Mmax, TCH.T, etc. If a column is used in two or more tables, a simple key name is enough, for example NAME (without a period).			
<b>CfgColumnDescription</b> Definition of a table column, column description			
<b>width</b>  105601	<b>Column width</b> Defines the width for the column made in the table file. At least one character for the column name and one character for spacing from the next column. <b>Format:</b> Numerical value <b>Input:</b> 2 to 50 (column width of max. 50 characters) <b>Default:</b> 2	PLC/Pgm run is locked LEVEL3	1600



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>unit</b> 105602	<b>Data type of values in the column</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TEXT:</b> Text entry</li> <li>■ <b>SIGN:</b> Algebraic sign + or –</li> <li>■ <b>BIN:</b> Binary number</li> <li>■ <b>DEC:</b> Decimal, positive, whole number (cardinal number)</li> <li>■ <b>HEX:</b> Hexadecimal number</li> <li>■ <b>INT:</b> Whole number</li> <li>■ <b>LENGTH:</b> Length</li> <li>■ <b>FEED:</b> Feed rate (mm/min or 0.1 ipm)</li> <li>■ <b>IFEED:</b> Feed rate (mm/min or ipm)</li> <li>■ <b>FEED_CUT:</b> Cutting speed in m/min or feet/min</li> <li>■ <b>FEED_ROT:</b> Feed rate in mm/revolution or inch/revolution</li> <li>■ <b>FLOAT:</b> Floating-point number</li> <li>■ <b>BOOL:</b> Logical value</li> <li>■ <b>INDEX:</b> Index with subindices</li> <li>■ <b>TSTAMP:</b> Time/Date</li> </ul>	PLC/Pgm run is locked LEVEL3	1601

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>initial</b> 105603 (optional parameter)	<b>Value automatically entered in a column when a new table is created.</b> <ul style="list-style-type: none"> <li>■ <b>NULL:</b> No default value. This column may be left blank. If a default value other than NULL is given, then a valid value must always be entered in the column.</li> <li>■ <b>Value:</b> Default value. When a new line is inserted, this value is assigned as a default to the column.</li> </ul> <b>Format:</b> String <b>Input:</b> Max. 50 characters NULL: Value:	PLC/Pgm run is locked LEVEL3	1602
<b>minimum</b> 105604 (optional parameter)	<b>Smallest permissible input value</b> Depending on the unit of measure selected in <b>MP_unit</b> , the input ranges defined in „MP_minimum" on page 1603 apply: <b>Format:</b> String <b>Input:</b> Max. 50 characters	PLC/Pgm run is locked LEVEL3	1603
<b>maximum</b> 105605 (optional parameter)	<b>Largest permissible input value</b> Depending on the unit of measure selected in <b>MP_unit</b> , the input ranges defined in „MP_minimum" on page 1603 apply: <b>Format:</b> String <b>Input:</b> Max. 50 characters	PLC/Pgm run is locked LEVEL3	1603
<b>charset</b> 105606 (optional parameter)	<b>Permissible number of characters for columns with text</b> Evaluated only for columns with <b>MP_unit = TEXT</b> . If the parameter is not defined, all characters are allowed; otherwise, only the characters listed here are allowed. <b>Format:</b> String <b>Input:</b> Max. 224 characters	PLC/Pgm run is locked LEVEL3	1603
<b>unique</b> 105607 (optional parameter)	<b>Specifies whether only unambiguous values are allowed in the column</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Only unambiguous values allowed</li> <li>■ <b>FALSE:</b> Values may occur more than once</li> </ul> <b>Default:</b> FALSE	PLC/Pgm run is locked LEVEL3	1604





Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>readonly</b> 105608 (optional parameter)	<b>Write protection on column entry</b> If the attribute is set to TRUE, the value assigned when inserting the line cannot be changed. If the attribute is not set or set to FALSE, values may be overwritten. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Values are write-protected</li> <li>■ <b>FALSE:</b> Values may be overwritten</li> </ul> <b>Default:</b> FALSE	PLC/Pgm run is locked LEVEL3	1604
<b>unitsInch</b> 105609 (optional parameter)	<b>Column entry in inches</b> If lengths and feed rates are to be specified in the column in a definite unit of measure, enter TRUE here for values in inches and FALSE for values in mm. If the parameter is not set, the unit of measure is taken from the corresponding table. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Column entry in inches</li> <li>■ <b>FALSE:</b> Column entry in mm</li> </ul>	PLC/Pgm run is locked LEVEL3	1604

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgColumnText</b>			
Definition of the language-sensitive text of a column. Language-sensitive dialog text and selection lists for columns.			
<b>dialogText</b>			
Language-sensitive dialog text and selection lists for columns. Text name from the text resource file (for language-sensitive texts) or texts that are understood in all languages.			
<b>dialogRes</b> 105701 (optional parameter)	<b>Name of a text</b> The text must be available with this name in a text resource file. Leave the parameter empty if the text is to be the same for all languages. Enter the text in the <b>MP_text</b> parameter instead. <b>Format:</b> String <b>Input:</b> String, max. 40 characters	PLC/Pgm run is locked LEVEL3	–
<b>text</b> 105701 (optional parameter)	<b>Language-sensitive text</b> This text is loaded from a text resource file and should not be changed here. If the text is not language-sensitive, you must enter it here directly. In this case do not enter anything for the <b>MP_dialogRes</b> attribute. <b>Format:</b> String <b>Input:</b> Max. 60 characters	PLC/Pgm run is locked LEVEL3	–
<b>softkeyIcon</b> 105702 (optional parameter)	<b>Path/name of a soft-key icon</b> Specifies a graphic soft key for opening a selection list. If instead of a text, a graphic soft key is to be displayed, you have to enter here the path and name of the icon. <b>Format:</b> String <b>Input:</b> Max. 80 characters	PLC/Pgm run is locked LEVEL3	–
<b>iconVariant</b> 105703 (optional parameter)	<b>Number of a soft-key variant</b> Additional data for graphic soft key: Variant number of the soft-key icon in the BMX file. <b>Format:</b> Numerical value <b>Input:</b> 0 to 2147483647	PLC/Pgm run is locked LEVEL3	–

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>choice</b> 105704 (optional parameter)	<b>Define a selection list for input values</b> A selection element consists of a value/text pair. The text is displayed. When selected, the value belonging to the text is entered in the table. The value cannot be directly edited, but only changed using the selection. For the associated <b>MP_text</b> parameter, the text can consist of two parts separated by a comma. This will have the following effect: <ul style="list-style-type: none"> <li>■ Text in front of the comma is displayed in the selection list</li> <li>■ The following part in the table editor</li> </ul> <b>Format:</b> List [2 to 30]	PLC/Pgm run is locked LEVEL3	–
<b>value</b> 105704 (optional parameter)	<b>Value for a selection element</b> A selection element consists of a value/text pair. Here the value belonging to the text is entered. <b>Format:</b> String <b>Input:</b> Max. 20 characters	PLC/Pgm run is locked LEVEL3	–
<b>dialog</b> Text for a selection element. A selection element consists of a value/text pair.			
<b>dialogRes</b> 105704 (optional parameter)	<b>Name of a text</b> See entry under CfgColumnText/dialogText	PLC/Pgm run is locked LEVEL3	–
<b>text</b> 105704 (optional parameter)	<b>Language-sensitive text</b> See entry under CfgColumnText/dialogText	PLC/Pgm run is locked LEVEL3	–
<b>lockValue</b> Locked due to certain input values. If the value entered in the column corresponds to the value specified under <b>MP_value</b> , the replacement text is displayed. It cannot be edited. This makes it possible to disable editing depending on the value.			
<b>value</b> 105705 (optional parameter)	<b>Value for a selection element</b> A selection element consists of a value/text pair. Here the value belonging to the text is entered. <b>Format:</b> String <b>Input:</b> Max. 20 characters	PLC/Pgm run is locked LEVEL3	–

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>dialog</b>			
Text for a selection element. A selection element consists of a value/text pair.			
<b>dialogRes</b> 105705 (optional parameter)	<b>Name of a text</b> See entry under CfgColumnText/dialogText	PLC/Pgm run is locked  LEVEL3	–
<b>text</b> 105705 (optional parameter)	<b>Language-sensitive text</b> See entry under CfgColumnText/dialogText	PLC/Pgm run is locked  LEVEL3	–
<b>CfgConfigSettings</b>			
Settings for the configuration editor ( <b>Machine Parameter Programming</b> mode of operation)			
<b>undoListSize</b> 106501	<b>Specifies the number of entries in the change list</b>  <b>Format:</b> Numerical value <b>Input:</b> 0 to 20 <b>Default:</b> 20	PLC/Pgm run is locked  LEVEL3	339
<b>suppressUsrMsg</b> 106502 (optional parameter)	<b>Suppress the Key non-functional error message</b>  <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> The MANUALplus 620 does not output the <b>Key non-functional</b> error message. ■ <b>FALSE:</b> The MANUALplus 620 displays all error messages. <b>Default:</b> FALSE	PLC/Pgm run is locked  LEVEL3	–
<b>dispParamNumbers</b> 106503 (optional parameter)	<b>Display the symbolic names or the number of machine parameters in the change list</b>  <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> Number of the machine parameter is displayed ■ <b>FALSE:</b> Symbolic name of the machine parameter is displayed. <b>Default:</b> FALSE	PLC/Pgm run is locked  LEVEL3	339

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>hideWriteProtected</b> 106504	<b>Hide write-protected parameters</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> Hide write-protected configuration objects. ■ <b>FALSE:</b> Display all configuration objects <b>Default:</b> TRUE	PLC/Pgm run is locked LEVEL3	350
<b>Network</b>			
Configuration of interface connections			
<b>Serial</b>			
Configuration of serial interfaces			
<b>CfgSerialPorts</b>			
Data record belonging to the serial port; The data record for configuring the serial port is stored in <b>MP_CfgSerialInterface</b> .			
<b>activeRs232</b> 106601 (optional parameter)	<b>Enable the RS-232 interface in the program manager</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> The RS-232 interface is enabled in the program manager and shown as a drive icon ( <b>RS232:</b> ) . ■ <b>FALSE:</b> The RS-232 interface cannot be accessed via the program manager. <b>Default:</b> FALSE	NOTHING LEVEL2 597 110-03	1773
<b>interfaceRs232</b> 106602	<b>Key name of the data record for the RS-232 interface</b> Define the default parameter set for the serial RS-232 interface here. The "Default" data record is selected by default. But you can use any desired designation. The specified data record must be contained in <b>CfgSerialInterface</b> . The data record is not effective if another record was activated by the PLC. <b>Format:</b> String <b>Input:</b> Max. 18 characters	NOTHING LEVEL2	1773

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>interfacePlc</b> 106605	<p><b>Key names of the data records for interface access by the PLC</b></p> <p>Here you can enter a maximum of three different key names for interface accesses by the PLC. If no parameter set is specified, the control automatically uses the default parameter set defined in <b>CfgSerialInterface</b>.</p> <p><b>Format:</b> List [0 to 2]</p> <p><b>Input:</b> String, max. 18 characters</p>	NOTHING LEVEL2	1773
<b>baudRateLsv2</b> 106606	<p><b>Data transfer rate for LSV2 communication in baud</b></p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b> BAUD_110 BAUD_150 BAUD_300 BAUD_600 BAUD_1200 BAUD_2400 BAUD_4800 BAUD_9600 BAUD_19200 BAUD_38400 BAUD_57600 BAUD_115200</p> <p><b>Default:</b> BAUD_115200</p>	NOTHING LEVEL2	1774
<b>CfgSerialInterface</b>			
Definition of data records for the serial ports;			
<b>[Key name of the data record for the serial port]</b>			
Under each key name, the properties of a serial port are defined. The data record to be active is specified under CfgSerialPorts.			
<b>baudRate</b> 106701 MP5040	<p><b>Data transfer rate in baud</b></p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b> BAUD_110 BAUD_150 BAUD_300 BAUD_600 BAUD_1200 BAUD_2400 BAUD_4800 BAUD_9600 BAUD_19200 BAUD_38400 BAUD_57600 BAUD_115200</p> <p><b>Default:</b> BAUD_9600</p>	NOTHING LEVEL2	1775



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>protocol</b> 106702 MP5030	<b>Communications protocol</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>STANDARD:</b> Standard data transfer. Data transferred line-by-line.</li> <li>■ <b>BLOCKWISE:</b> Packet-based data transfer, "ACK/NAK" protocol. Blockwise data transfer is controlled by the control characters ACK (Acknowledgment) and NAK (Negative Acknowledgment).</li> <li>■ <b>RAW_DATA:</b> Data transferred without protocol. Transfer of characters without control characters. Protocol intended for transfer of data of the PLC.</li> </ul> <b>Default:</b> STANDARD	NOTHING LEVEL2	1775
<b>dataBits</b> 106703 MP5020 bit 0	<b>Data bits in each transferred character</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>7 bits:</b> 7 data bits are transferred for each character transferred.</li> <li>■ <b>8 bits:</b> 8 data bits are transferred for each character transferred.</li> </ul> <b>Default:</b> 8 bits	NOTHING LEVEL2	1776
<b>parity</b> 106704 MP5020 bit 4/5	<b>Type of parity checking</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>NONE:</b> No parity formation</li> <li>■ <b>EVEN:</b> Even parity</li> <li>■ <b>ODD:</b> Odd parity</li> </ul> <b>Default:</b> NONE	NOTHING LEVEL2	1776

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>stopBits</b> 106705 MP5020 bit 6/7	<b>Number of stop bits</b> <b>Format:</b> Selection menu <b>■ 1 stop bit:</b> 1 stop bit is appended after each transferred character. <b>■ 2 stop bits:</b> 2 stop bits are appended after each transferred character. <b>Default:</b> 1 stop bit	NOTHING LEVEL2	1777
<b>flowControl</b> 106706 MP5020 bit 2/3	<b>Type of data-flow checking (handshake)</b> <b>Format:</b> Selection menu <b>Input:</b> <b>■ NONE:</b> No data-flow checking; handshaking not active <b>■ RTS_CTS:</b> Hardware handshaking; transfer is stopped with RTS active <b>■ XON_XOFF:</b> Software handshaking; transfer is stopped with DC3 (XOFF) active <b>Default:</b> RTS_CTS	NOTHING LEVEL2	1780
<b>fileSystem</b> 106707 (optional parameter)	<b>File system for file operation via serial interface</b> <b>Format:</b> Selection menu <b>Input:</b> <b>■ EXT:</b> Minimum file system for external devices. Corresponds to the EXT1 and EXT2 modes of earlier TNC controls. Use these settings if you are using printers, punches, or non-HEIDENHAIN data transfer software. <b>■ FE1:</b> Use this setting for communication with the external HEIDENHAIN FE 401 B or FE 401 floppy disk unit as of software 230 626-03, or for communication with the "TNCserver" PC software from HEIDENHAIN. <b>Default:</b> EXT	NOTHING LEVEL2	1780





Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>bccAvoidCtrlChar</b> 106708 MP5020 bit 1 (optional parameter)	<b>Block Check Character (BCC) is not a control character</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Ensures that the check sum does not correspond to a control character</li> <li>■ <b>FALSE:</b> Function not active</li> </ul> <b>Default:</b> FALSE	NOTHING LEVEL2	1781
<b>rtsLow</b> 106709 MP5020 bit 8	<b>Idle state of the RTS line</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> The idle state of the RTS line is logical LOW</li> <li>■ <b>FALSE:</b> The idle state of the RTS line is at logical HIGH.</li> </ul> <b>Default:</b> FALSE	NOTHING LEVEL2 597 110-03	1782
<b>noEotAfterEtx</b> 106710 MP5020 bit 9	<b>Defines the behavior after reception of an ETX control character</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> No EOT control character is sent after reception of an ETX control character.</li> <li>■ <b>FALSE:</b> The control sends an EOT control character after reception of an ETX control character.</li> </ul> <b>Default:</b> FALSE	NOTHING LEVEL2	1782

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgServiceRequest</b>			
Settings for the TeleService 2.0 software for PCs; Configuration of the SERVICE-REQUEST soft keys. Can be used by the machine operator to initiate a service request if servicing is required.			
<b>name</b> 114601 (optional parameter)	<b>Logical name of the service host</b> The name identifies the remote service host and can be displayed on the user interface of the control. <b>Format:</b> String <b>Input:</b> Max. 500 characters	NOTHING LEVEL2 597 110-03	1790
<b>host</b> 114602 (optional parameter)	<b>Network address or host name of the remote service host</b> Enter the network address as four decimal numbers separated by periods (IP address in dotted-decimal notation) or as a fully qualified host name (e.g. <b>192.168.10.51</b> <b>\HOME\DATA\SERVICE</b> <b>Format:</b> String <b>Input:</b> Max. 500 characters	NOTHING LEVEL2 597 110-03	1791
<b>port</b> 114603 (optional parameter)	<b>Port number of the remote service host</b> The control sends the service request report to the port entered here <b>Format:</b> Numerical value <b>Input:</b> 0 to 2147483647 <b>Default:</b> 19001	NOTHING LEVEL2 597 110-03	1791
<b>content</b> 114604 (optional parameter)	<b>Contents of the message to the remote service host</b> The contents serve to identify the machine, e.g. machine model and serial number. <b>Format:</b> String <b>Input:</b> Max. 500 characters	NOTHING LEVEL2 597 110-03	1791
<b>period</b> 114605 (optional parameter)	<b>Duration of repeated transmission of the message to the service host</b> Transmission of the report is repeated during the specified period of time in seconds until the function is activated or the time entered in the <b>MP_timeOut</b> parameter is exceeded. <b>Format:</b> Numerical value <b>Input:</b> 0 to 10 [s]	NOTHING LEVEL2 597 110-03	1791

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>timeout</b> 114606 (optional parameter)	<b>Timeout in minutes for transmission of the message to the remote service host</b>  <b>Format:</b> Numerical value <b>Input:</b> 0 to 15 [min]	NOTHING LEVEL2 597 110-03	1792
<b>serverIp</b> 114607 (optional parameter)	<b>Network address or host name of the server</b> The data traffic of the specified server(s) is checked. The default value is the server given in the <b>MP_host</b> parameter. <b>Format:</b> String <b>Input:</b> Max. 500 characters	NOTHING LEVEL2 597 110-03	1792
<b>serverIpMask</b> 114608 (optional parameter)	<b>Subnet mask of the server network</b> Enter the subnet mask of the server as four decimal numbers separated by periods (IP address in dotted-decimal notation). <b>Format:</b> String <b>Input:</b> Max. 500 characters	NOTHING LEVEL2 597 110-03	1792
<b>Key code</b> Define code numbers			
<b>CfgChangePassword</b> Changing of existing HEIDENHAIN code numbers into OEM code numbers			
<b>[Key name = Existing HEIDENHAIN code number]</b> Specify the existing HEIDENHAIN code number to be replaced by an OEM code number, e.g. <b>807667</b> , <b>95148</b> , etc.			
<b>replaceWith</b> 120501	<b>New OEM password or code number</b> Specify numerals and/or capital letters. The HEIDENHAIN password indicated in the key name is replaced by the new OEM password defined here. <b>Format:</b> String <b>Input:</b> Max. 18 characters	PLC/Pgm run is locked LEVEL3 597 110-05	1232
<b>hideOriginal</b> 120502 (optional parameter)	<b>Lock previous HEIDENHAIN code number</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> The previous HEIDENHAIN code number is disabled. ■ <b>FALSE:</b> The previous HEIDENHAIN code number remains in effect. <b>Default:</b> FALSE	PLC/Pgm run is locked LEVEL3 597 110-05	1232

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<p><b>CfgOemPassword</b></p> <p>Define OEM-specific code numbers / passwords: The code numbers or passwords are used to enable functions. Examples:</p> <ul style="list-style-type: none"> <li>■ Activating the configuration editor with a specific layout</li> <li>■ Displaying soft keys in the MOD dialog</li> <li>■ Evaluating the password / code number in the PLC program</li> </ul>			
<p><b>[Key name = OEM-specific code number / password]</b></p> <p>If soft keys are to be provided in the MOD dialog permanently, enter the key name <b>Default</b>.</p>			
<p><b>funcList</b></p> <p>106901</p>	<p><b>List of function names (= key names) that are called by entering the password:</b></p> <p>Name of the functions that are called by entering the password. Enter these names as key names in <b>CfgModOemSoftkey</b> and <b>CfgCfgEditActivate</b>.</p> <p>The password is defined by the key name in <b>CfgOemPassword</b>.</p> <p>Format:       List [0 to 200]</p> <p>Input:         Max 18 characters</p>	<p>RESET</p> <p>LEVEL3</p>	<p>368</p>
<p><b>CfgModOemSoftkey</b></p> <p>Soft key in the MOD dialog; Define a soft key in the MOD dialog, e.g. for activating the configuration editor with a certain layout.</p>			
<p><b>[Key name of the soft key]</b></p> <p>The key name must be entered in <b>CfgOemPassword/funcList</b>.</p>			
<p><b>activation</b></p> <p>107101</p>	<p><b>Specifies whether the defined function is a foreground application.</b></p> <p><b>Format:</b>       Selection menu</p> <p><b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> The defined function is a foreground application, e.g. configuration editor. Set this value if the soft key opens the configuration editor to display user parameters.</li> <li>■ <b>FALSE:</b> Function performed in the background</li> </ul> <p><b>Default:</b>       FALSE</p>	<p>RESET</p> <p>LEVEL3</p>	<p>368</p>
<p><b>skPos</b></p> <p>107102 (optional parameter)</p>	<p><b>Position of the soft key in the 3rd menu bar</b></p> <p>0= First soft key at left. Menu bars 1 and 2 are reserved for HEIDENHAIN. Leave empty if no soft key is to be displayed.</p> <p><b>Format:</b>       Numerical value</p> <p><b>Input:</b>         0 to 7</p>	<p>RESET</p> <p>LEVEL3</p>	<p>368</p>



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>buttonText</b> Soft-key text; Specify a language-neutral text or the name of a text from a language-sensitive text file. Leave empty if you enter an image for a graphic soft key in <b>MP_buttonImage</b> .			
<b>dialogRes</b> 107103	<b>Name of a text</b> See entry under CfgColumnText/dialogText	RESET LEVEL3	369
<b>text</b> 107103	<b>Language-sensitive text</b> See entry under CfgColumnText/dialogText	RESET LEVEL3	369
<b>buttonImage</b> 107104 (optional parameter)	<b>Image for graphic soft key</b> Path/file name to an image for a soft key  Do not assign the parameter if you have defined a text for the soft key under <b>buttonText</b> .  <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	369
<b>funcKey</b> 107105 (optional parameter)	<b>Key name of the function being activated when the soft key is pressed</b> Key name of the function that is activated by entering the password. Only specify if the name of the function to be activated does not match the key name under <b>CfgModOemSoftkey</b> .  <b>Format:</b> String <b>Input:</b> Max. 18 characters	RESET LEVEL3	369
<b>helpId</b> 107106 (optional parameter)	<b>Symbolic name of the context information for online help (*.CHM)</b> The entered symbolic name can belong to a HEIDENHAIN or OEM manual.  <b>Format:</b> String <b>Input:</b> Context ID Max. 80 characters	RESET LEVEL3	370

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgCfgEditActivate</b> Specifies the configuration editor view that is opened by entering the OEM password; The OEM can configure the tree structure and parameter display according to his requirements.			
<b>[Key name of view of configuration editor]</b> As key name, use the function name entered in <b>CfgOemPassword/funcList</b> or <b>CfgModOemSoftkey/funcKey</b> . HEIDENHAIN has already configured <b>CFGEDIT-USER123</b> and <b>CFGEDIT-USERPARAM</b> .			
<b>layoutFile</b> 107201	<b>Path/name of the XML layout file for user parameters</b> The layout file defines the tree structure and the attributes to be displayed for the configuration editor. <b>Format:</b> String <b>Input:</b> Max. 80 characters	PLC/Pgm run is locked LEVEL3	370
<b>disPLangText</b> 107202 (optional parameter)	<b>Display language-sensitive names in the configuration editor?</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> The detailed language-sensitive names are displayed.</li> <li>■ <b>FALSE:</b> The symbolic English system names are displayed.</li> </ul> <b>Default:</b> TRUE	PLC/Pgm run is locked LEVEL3	371
<b>readOnly</b> 107203 (optional parameter)	<b>Open the configuration editor with read access only.</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> The configuration editor is opened with read access only; the parameter values cannot be changed</li> <li>■ <b>FALSE:</b> The configuration editor is opened with read and write access</li> </ul> <b>Default:</b> FALSE	PLC/Pgm run is locked LEVEL3	370



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>Versions</b>			
Software version of the PLC, software type and version of the NC			
<b>CfgPlcVersion</b>			
PLC program version			
<b>plcVersion</b> 107301	<b>PLC software version</b> <b>Format:</b> String <b>Input:</b> Software version (max. 32 characters)	NOTHING LEVEL2	–
<b>versionText</b>			
Language-sensitive description for PLC version. Text name from the text resource file (for language-sensitive texts) or texts that are understood in all languages.			
<b>dialogRes</b> 107103	<b>Name of a text</b> See entry under CfgColumnText/dialogText	NOTHING LEVEL2	–
<b>text</b> 107103	<b>Language-sensitive text</b> See entry under CfgColumnText/dialogText	NOTHING LEVEL2	–
<b>CfgNcVersion</b>			
Software version of the control; The version is entered by HEIDENHAIN when the system is created.			
<b>[Key name for the exact software designation]</b>			
The HEIDENHAIN defaults are <b>KERNEL</b> and <b>PRODUCT</b> .			
<b>ncType</b> 107501	<b>Control model</b> <b>Format:</b> String <b>Input:</b> Max. 16 characters, e.g. "MANUALplus 620"	PLC/Pgm run is locked LEVEL4	–
<b>ncVersion</b> 107502	<b>NC software version</b> <b>Format:</b> String <b>Input:</b> Version number of the NC software	PLC/Pgm run is locked LEVEL4	–
<b>CfgConfigVersion</b>			
Version of the configuration			
<b>configVersion</b> 115501	<b>Version code for config data</b> <b>Format:</b> String <b>Input:</b> Max. 32 characters	PLC/Pgm run is locked LEVEL3	–
<b>versionText</b> 115502 (optional parameter)	<b>Description of the configuration</b> <b>Format:</b> String <b>Input:</b> Max. 80 characters	PLC/Pgm run is locked LEVEL3	–

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>ProbeSettings</b> Touch-probe configuration			
<b>CfgToolMeasuring</b> Specifies the behavior of the MANUALplus 620 during tool measurement.			
<b>measuringType</b>  604601	<b>Type of tool measurement</b> Enter the type of tool measurement (optical gauge, touch probe). Format:        Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>None:</b> No tool measurement possible</li> <li>■ <b>Probe:</b> Tool measurement with touch probe</li> <li>■ <b>Optic:</b> Tool measurement with optical gauge</li> </ul>	PLC/Pgm run is locked LEVEL1	1386
<b>feed</b>  604602	<b>Measuring feed rate</b> Feed rate for approaching the touch probe. Format:        Numerical value Input:         -59999999940 to +59999999940 [mm/min] <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1386
<b>distance</b>  604603	<b>Measuring path</b> The tool stops when it has traversed the measuring range without reaching the touch probe. Format:        Numerical value [mm] Input:         -999999999 to 999999999 <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1386





Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>Simulation</b>			
Settings for the simulation			
<b>CfgSimGeneral</b>			
General settings			
<b>restartAtM99</b> 114801	<b>Restart with M99</b> Specifies whether an NC program ending with M99 is to be simulated repeatedly. <b>Format:</b> Selection menu <b>Input:</b> ■ <b>on:</b> If M99, then the NC program is simulated again. ■ <b>off:</b> If M99, then the NC program is not simulated again. <b>Default:</b> off	PLC/Pgm run is locked LEVEL1	1422
<b>pathDelay</b> 114802	<b>Path delay</b> Influences the simulation speed. After the output of a distance traversed, the control waits for the time defined in that parameter. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 60 [s] <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1422
<b>CfgTimeDetGeneral</b>			
Calculating the operating times			
<b>toolChangeTime</b> 115001	<b>Time allowance for tool change</b> Defines the time for a tool change that is taken into account during the simulation. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 10 000 000 [s] <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1423
<b>gearShiftingTime</b> 115002	<b>Time allowance for gear shifting</b> Defines the time for gear shifting that is taken into account during the simulation. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 10 000 000 [s] <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1423

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>mFunTimeAllow</b> 115003	<b>General time allowance for M function</b> Defines the time for the execution of M functions to be generally taken into account during the simulation. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 10 000 000 [s] <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1423
<b>ProcessingTime</b> Specific time allowances for M functions			
<b>CfgmFunKeys</b> Assignment of specific time allowances for selected M functions			
<b>mFunTimeKeys</b> 115401	<b>List of the key names of all M functions with specific time allowances.</b> Enter the key names of the M functions that are to have specific time allowances. <b>Format:</b> List [0 to 30] <b>Input:</b> Key name from <b>CfgTimeDetMfun</b>	PLC/Pgm run is locked LEVEL1	1424
<b>CfgTimeDetMfun</b> Specific time allowances for selected M functions			
<b>[Key name of the M function]</b>			
<b>mFun</b> 115101	<b>Number of the M function</b> Number of the M function for which a specific time allowance is to be defined. <b>Format:</b> Numerical value <b>Input:</b> 0 to 999 <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1424
<b>timeAllow</b> 115102	<b>Time allowance of the M function</b> Time allowance that is to be taken into account for the execution of this M function during the simulation in addition to the general time allowance for M functions from MP_mFunTimeAllow. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 10 000 000 [s] <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1424



Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgSimWindowSize</b>			
Specification of the standard window size			
<b>zeroPosX</b> 115201	<b>Zero position in X</b> Defines the distance of the coordinate origin referenced to the lower window. <b>Format:</b> Numerical value <b>Input:</b> -100 000.000 to 100 000 [mm] <b>Default:</b> -100	PLC/Pgm run is locked LEVEL1	1425
<b>zeroPosZ</b> 115202	<b>Zero position in Z</b> Defines the distance of the coordinate origin referenced to the left-hand window. <b>Format:</b> Numerical value <b>Input:</b> -100 000.000 to 100 000 [mm] <b>Default:</b> -150	PLC/Pgm run is locked LEVEL1	1425
<b>deltaX</b> 115203	<b>Delta X</b> Defines the vertical expansion of the graphics window. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 100 000 [mm] <b>Default:</b> 200	PLC/Pgm run is locked LEVEL1	1425
<b>deltaZ</b> 115204	<b>Delta Z</b> Defines the horizontal expansion of the graphics window. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 100 000 [mm] <b>Default:</b> 200	PLC/Pgm run is locked LEVEL1	1426

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>CfgSimBlank</b>			
Specification of the standard workpiece blank			
<b>outsideDiameter</b> 115301	<b>Outside diameter</b> Specifies the outside diameter of the workpiece blank. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 100 000 [mm] <b>Default:</b> 100	PLC/Pgm run is locked LEVEL1	1426
<b>blankLength</b> 115302	<b>Workpiece blank length</b> Specifies the total length of the workpiece blank. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 100 000 [mm] <b>Default:</b> 80	PLC/Pgm run is locked LEVEL1	1426
<b>rightBlankEdge</b> 115303	<b>Oversize of the workpiece blank</b> Specifies the oversize of the workpiece blank referenced to the workpiece datum. <b>Format:</b> Numerical value <b>Input:</b> -100 000.000 to 100 000 [mm] <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1426
<b>insideDiameter</b> 115304	<b>Inside diameter of the blank</b> Specifies the inside diameter of the workpiece blank. <b>Format:</b> Numerical value <b>Input:</b> For hollow cylinders: Inside diameter in 0.000 to 100 000 [mm] For solid workpieces: enter 0 [mm] <b>Default:</b> 0	PLC/Pgm run is locked LEVEL1	1426

Parameter MP number iTNC MP number	Function and input	Behavior Access SW vers.	Page
<b>Backup</b> Configuration of backup lists			
<b>CfgBackup</b> Key names of all backup lists			
<b>groupList</b> 605501	<b>List with the key names of all backup lists</b> Enter the key names of all backup lists defined beforehand in CfgBackupGroup. <b>Format:</b> List [0 to 12] <b>Input:</b> Key names from <b>CfgBackupGroup</b>	PLC/Pgm run is locked LEVEL1	1794
<b>CfgBackupGroup</b> Definition of backup lists			
<b>[Key name of the backup list]</b>			
<b>backupFiles</b> 605601	<b>Paths of the configuration files</b> For each backup list, enter the paths of the configuration files that are to be contained in the respective backup list. The placeholders %oemPath% and %usrPath% should be used instead of the absolute paths. <b>Format:</b> String <b>Input:</b> Max. 500 characters	PLC/Pgm run is locked LEVEL1	1794

## 4.10.2 "Channels" group

Channel-specific machine parameters.

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>Kinematics</b>			
Configuration of the machine kinematics			
<b>CfgKinComposModel</b>			
Kinematic model, composed of partial kinematics			
<b>[Key name of the kinematics model]</b>			
<b>subKinList</b> 202901	<b>List of key names of the subkinematics</b> Enter the subkinematics comprising the machine kinematics, going from the tool to the workpiece. Format: List [0 to 5] Input: Key name from <b>CfgKinSimpleModel</b>	RUN LEVEL3 597 110-03	736
<b>activeSpindle</b> 202902	<b>Key name of the active spindle of this kinematics model</b> Format: String Input: Key name of the spindle from <b>System/CfgAxes/axisList</b>	RUN LEVEL3 597 110-03	736
<b>tiltingAllowed</b> 202904 (optional parameter)	<b>Tilting the working plane is allowed</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> Tilting the working plane is allowed with this kinematic model. ■ <b>FALSE:</b> Tilting the working plane is not allowed with this kinematic configuration. The MANUALplus 620 displays an error message. <b>Default:</b> TRUE	RUN LEVEL3 597 110-04	736
<b>CfgKinSimpleModel</b>			
Definition of subkinematics			
<b>[Key name of subkinematics]</b>			
<b>kinObjects</b> 202801	<b>List of key names of objects in the kinematics chain</b> <b>Format:</b> List [0 to 49] <b>Input:</b> Key names of objects from <b>CfgKinSimpleTrans</b> <b>CfgKinSimpleAxis</b> <b>CfgKinAnchor</b>	RUN LEVEL3 597 110-03	735



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgKinSimpleTrans</b>			
Definition of transformations in three dimensions			
<b>dir</b> 202602	<b>Direction of the transformation</b> The selection of X, Y and Z indicates that it is a shift of the coordinate system in X, Y or Z direction. If A, B, or C is indicated, then it is a rotation of the coordinate system about the A, B or C axis. <b>Format:</b> Selection menu <b>Input:</b> X, Y, Z, A, B, C	RUN LEVEL3 597 110-03	732
<b>val</b> 202602	<b>Value of the transformation</b> <b>Format:</b> Numerical value <b>Input:</b> -999 999 999 to +999 999 999 [mm] or [°] Max. 9 decimal places	RUN LEVEL3 597 110-03	734
<b>CfgKinSimpleAxis</b>			
Definition of the machine axes in the kinematics chain			
<b>[Key name of the machine axis]</b>			
<b>dir</b> 202701	<b>Direction of the machine axis</b> <b>Format:</b> Selection menu <b>Input:</b> X, Y, Z, A, B, C	RUN LEVEL3 597 110-03	732
<b>axisRef</b> 202702	<b>Reference to the associated axis</b> Enter here the key name of the associated axis from <b>System/CfgAxes/axisList</b> . <b>Format:</b> String <b>Input:</b> Key name of the axis	RUN LEVEL3 597 110-03	733

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgKinAnchor</b>			
Definition of fixed points in the kinematics chain, e.g. machine base			
<b>[Key name of the anchor]</b>			
<b>kindOfAnchor</b>  200001	<b>Fixed point in the kinematics chain</b>  Specifies a fixed point in the kinematics chain. At present, only the definition of a machine base is supported.  In the desired subkinematics ( <b>CfgKinSimpleModel</b> ), enter the machine base (e.g. with the key name <b>Base</b> ) at the appropriate position in the list.  <b>Format:</b> Selection menu <b>Input:</b> MachBase	RUN  LEVEL3  597 110-03	731
<b>KinematicsByDir</b>			
Kinematic model up to NC-SW 548 328-02, based on translation axes and rotation axes which are linked to each other.			
<b>CfgKinModel</b>			
Description of the kinematic model (up to NC software 548 328-02)			
<b>[Key name of the kinematic model]</b>			
<b>axesToolSide</b>  200001	<b>Key names of the axes on the tool side</b>  Enter here the key names of the axes from <b>System/CfgAxes/axisList</b> .  <b>Format:</b> List [0 to 9] <b>Input:</b> Key name of the axis	RUN  LEVEL3	753
<b>trafoToolSide</b>  200002	<b>Coordinate transformations on the tool side</b>  Enter the key names of all coordinate transformations on the tool side. Definition of the sequence as in <b>CfgKinModel/axesToolSide</b> .  <b>Format:</b> List [0 to 9] <b>Input:</b> Key name of the coordinate transformation	RUN  LEVEL3	753
<b>trafoDirToolSide</b>  200003	<b>Coordinate transformations defined by direction vectors</b>  List with the key names of the coordinate transformations on the tool side, where the orientation is defined by direction vectors.  <b>Format:</b> List [0 to 9] <b>Input:</b> Key name of the coordinate transformation	RUN  LEVEL3	753



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>trafoAngleToolSide</b> 200004	<b>Coordinate transformations defined by angle</b>  List with the key names of the coordinate transformations on the tool side, where the orientation is defined by direction angles.  <b>Format:</b> List [0 to 9] <b>Input:</b> Key name of the coordinate transformation	RUN LEVEL3	754
<b>toolCoordSys</b> 200005	<b>Key name of the tool coordinate system</b>  Enter the key names of the tool coordinate system. Indicates the end of the kinematics chain from the machine base system to the tool.  <b>Format:</b> String <b>Input:</b> Max. 18 characters	RUN LEVEL3	754
<b>axesWpSide</b> 200006	<b>Key names of the axes on the workpiece side</b>  Enter here the key names of the axes from <b>System/CfgAxes/axisList</b> .  <b>Format:</b> List [0 to 9] <b>Input:</b> Key name of the axis	RUN LEVEL3	755
<b>trafoWpSide</b> 200007	<b>Coordinate transformations on the workpiece side</b>  Enter the key names of all coordinate transformations on the workpiece side. Definition of the sequence as in <b>CfgKinModel/axesWpSide</b> .  <b>Format:</b> List [0 to 9] <b>Input:</b> Key name of the axis	RUN LEVEL3	755
<b>trafoDirWpSide</b> 200008	<b>Coordinate transformations defined by direction vectors</b>  List with the key names of the coordinate transformations on the workpiece side, where the orientation is defined by direction vectors.  <b>Format:</b> List [0 to 9] <b>Input:</b> Key name of the coordinate transformation	RUN LEVEL3	755
<b>trafoAngleWpSide</b> 200009	<b>Coordinate transformations defined by angle</b>  List with the key names of the coordinate transformations on the workpiece side, where the orientation is defined by angles.  <b>Format:</b> List [0 to 9] <b>Input:</b> Key name of the coordinate transformation	RUN LEVEL3	755

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>machineTableSys</b> 200010	<b>Key name of the machine-table coordinate system</b>  Enter the key name of the machine-table coordinate system. Indicates the end of the kinematics chain from the machine base system to the workpiece.  <b>Format:</b> String <b>Input:</b> Max. 18 characters	RUN LEVEL3	756
<b>activeSpindle</b> 200011	<b>Key name of the active spindle</b>  Enter the key name of the active spindle from <b>CfgAxes/spindleIndices</b> for this kinematics model.  <b>Format:</b> String <b>Input:</b> Max. 18 characters	RUN LEVEL3	756
<b>CfgTrafoByDir</b>			
Description of the coordinate transformations with direction vectors (up to NC software 548 328-02)			
<b>[Key name of the coordinate transformation]</b>			
<b>location</b> 200101	<b>Origin of this coordinate system</b>  Position of the point of origin of this transformed system with respect to the previous coordinate system.  <b>Format:</b> List [0 to 2] <b>Input:</b> -999999999 to 999999999 <b>Default:</b> 0	RUN LEVEL3	758
<b>zDir</b> 200102	<b>Z-base vector expressed in the previous coordinate system</b>  Enter the Z-basis vector of this transformed coordinate system relative to the previous coordinate system. Note: Translation axes move in this direction and rotation axes rotate around this vector.  <b>Format:</b> List [0 to 2] <b>Input:</b> -1.000 000 to +1.000 000 <b>Default:</b> 0	RUN LEVEL3	759

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>xDir</b> 200103	<b>X-base vector expressed in the previous coordinate system</b>  Enter the X-basis vector of this transformed coordinate system relative to the previous coordinate system.  <b>Format:</b> List [0 to 2] <b>Input:</b> -1.000 000 to +1.000 000 <b>Default:</b> 0	RUN LEVEL3	759
<b>CfgTrafoByAngle</b>			
Description of the coordinate transformations with angles (up to NC software 548 328-02)			
<b>[Key name of the coordinate transformation]</b>			
<b>location</b> 200201	<b>Origin of this coordinate system</b>  Position of the point of origin of this transformed system with respect to the previous coordinate system.  <b>Format:</b> List [0 to 2] <b>Input:</b> -999999999 to 999999999 <b>Default:</b> 0	RUN LEVEL3	760
<b>angleDef</b> 200202	<b>Interpretation of the angles</b>  Specifies the interpretation of the angles  <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>Cardan:</b> Orientation by Cardan angles</li> <li>■ <b>RollPitchYaw:</b> Orientation by rotation around fixed axes</li> <li>■ <b>Euler:</b> Orientation by Eulerian angles</li> </ul> <b>Default:</b> Cardan	RUN LEVEL3	760
<b>angle1</b> 200203	<b>Angle 1</b>  Significance according to the attribute in <b>MP_angleDef</b> .  <b>Format:</b> Numerical value <b>Input:</b> -360.000 to 360.000 [°] <b>Default:</b> 0	RUN LEVEL3	760

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>angle2</b> 200204	<b>Angle 2</b> Significance according to the attribute in <b>MP_angleDef.</b> <b>Format:</b> Numerical value <b>Input:</b> -360.000 to 360.000 [°] <b>Default:</b> 0	RUN LEVEL3	760
<b>angle3</b> 200205	<b>Angle 3</b> Significance according to the attribute in <b>MP_angleDef.</b> <b>Format:</b> Numerical value <b>Input:</b> -360.000 to 360.000 [°] <b>Default:</b> 0	RUN LEVEL3	760



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>ChannelSettings</b>			
Channel-specific settings			
<b>[Key name of the machining channel]</b>			
Two channels are permanently defined:			
<ul style="list-style-type: none"> <li>■ <b>CH_NC:</b> Machining channel</li> <li>■ <b>CH_SIM:</b> Simulation channel</li> </ul>			
<b>CfgChannelAxes</b>			
Definition of the axes and axis names of this channel			
<b>progAxis</b> 200301	<b>Programmable axes</b> Programmable axis names and axis names for the position display in the workpiece system. <b>Format:</b> Array [0 to 8] <b>Input:</b> Selection of key names from <b>CfgAxes/axisList</b>	RESET LEVEL3	618
<b>refAxis</b> 200303	<b>Axes that are to be run over the reference point</b> Defines the axes that are to be referenced and the reference order. <b>Format:</b> List [0 to 6] <b>Input:</b> Selection of key names from <b>CfgAxes/axisList</b>	RESET LEVEL3	621
<b>refAllAxes</b> 200304 (optional parameter)	<b>Homing all axes in succession after an NC START</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Traverse the reference mark of all axes in succession after an NC START.</li> <li>■ <b>FALSE:</b> A reference run is not performed for all axes</li> </ul> Default: FALSE	RESET LEVEL3	621
<b>restoreAxis</b> 200305 (optional parameter)	<b>Sequence for returning to the contour</b> Specifies the sequence in which the axes are returned to the contour after NC stop or during block scan. After NC stop, the axes are moved to the stop position. During a block scan, they are moved to the calculated restore position. <b>Format:</b> List [0 to 6] <b>Input:</b> Selection of key names from <b>CfgAxes/axisList</b>	RESET LEVEL3	623

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>kinModels</b> 200306 (optional parameter)	<b>Key names of the available kinematic models for this channel</b> If there are multiple entries, the last one is valid The kinematics models are defined in <b>MP_CfgKinModel</b> . <b>Format:</b> List [0 to 15] <b>Input:</b> Selection menu with key names from <b>CfgKinModel</b>	RESET LEVEL3	619
<b>deactFastClamping</b> 200307 (optional parameter)	<b>Deactivation of "fast" clamping</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Deactivate fast clamping</li> <li>■ <b>FALSE:</b> Axis works with fast clamping.</li> </ul> <b>Default:</b> FALSE	RESET LEVEL3	618
<b>CfgKinList</b> List of all kinematic models available in this channel			
<b>kinCompositeModels</b> 203001	<b>List of key names of kinematic models for this machining channel</b> <b>Format:</b> List [0 to 9] <b>Input:</b> Selection menu with key names from <b>CfgKinComposModel</b>	RUN LEVEL3	738



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgActivateKinem</b>			
Active machine kinematics; A certain kinematic configuration can be activated with this entry.			
<b>kinemToActivate</b> 204001	<b>Kinematics to be activated / Active kinematics</b> Define here the key name of the kinematic configuration to be activated. You can also see from this parameter which kinematics configuration is currently active.  <b>Format:</b> Selection menu <b>Input:</b> Key name of the kinematics model from <b>CfgKinComposModel</b>	RUN LEVEL3	738
<b>CfgChannelFile</b>			
Definition of the initialization files for this channel; Specifies the paths of system cycles of the geometry calculation, for example. The parameters are predefined by HEIDENHAIN and should not be changed.			
<b>geoChainInit</b> 200401	<b>Path/name of the file for initializing the geometry chain</b>  <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>geolniProgram</b> 200402	<b>Path/name of the lead program for program run</b>  <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>geolniBlock</b> 200403	<b>Path/name of the lead program for MDI mode</b>  <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>geolniCycle</b> 200404	<b>Path/name of the lead program for manual cycles</b>  <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>geoCycleEnd</b> 200405	<b>Path/name of the trailing program for program end</b>  <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>geoCancelCycle</b> 200406	<b>Path/name of the trailing program if program aborts</b>  <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>geoTCallCycPath</b> 200407	<b>Path/name for the TOOL CALL cycle</b>  <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>geoTDefCycPath</b> 200408	<b>Path/name for the TOOL DEF cycle</b> <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>geoAutoTCallSycle</b> 200409	<b>Path/name for the automatic TOOL CALL cycle</b> TOOL CALL after expiration of tool life. <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>geoPalletCtrlCycle</b> 200410	<b>Path/name of the pallet control cycle</b> <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>plcSetPresetCycle</b> 200411	<b>Path/name of the preset set cycle for PLC module 9090/9281</b> <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>progSelectCycle</b> 200412	<b>Path/name of the program selection cycle</b> Is called when an NC program is selected via the file manager. <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>afterMdiCycle</b> 200413 (optional parameter)	<b>Path/name of the trailer program when leaving MDI</b> Is called when the <b>Positioning with Manual Data Input</b> mode is exited. <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–
<b>geoTConsCycle</b> 200414 (optional parameter)	<b>Path/name of the cycle for tool-data consistency</b> Path of the cycle for loading tool data if the current tool has changed outside of a program run. <b>Format:</b> String <b>Input:</b> Max. 260 characters	RESET LEVEL3	–



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgNcErrorReaction</b>			
Behavior of programmable errors <b>FN14: ERROR</b> ; FN14 errors are triggered only if the error warning level given in the PET table is smaller than or equal to the warning level set here. Note that errors with warning level 0 are always triggered and errors with warning level 5 are never triggered.			
<b>warningLevel</b> 200601	<b>Warning level of channel</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 4 0: FN14 errors with warning level = 0 are triggered 1: FN14 errors with warning level <= 1 are triggered 2: FN14 errors with warning level <= 2 are triggered 3: FN14 errors with warning level <= 3 are triggered 4: FN14 errors with warning level <= 4 are triggered <b>Default:</b> 0	RUN LEVEL1	619
<b>CfgNcPgmParState</b>			
Specification for storage of Q/QS parameters Defines the persistent storage and name of the current Q/QS parameter set			
<b>persistent</b> 200701	<b>Persistent storage of the Q/QS parameters</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> Q/QS parameters are saved persistently in the current parameter set at the end of the program, see <b>MP_currentSet</b> . ■ <b>FALSE:</b> Q/QS parameters are not stored <b>Default:</b> FALSE	RUN LEVEL1	620
<b>currentSet</b> 200702	<b>Name of the current Q/QS parameter set</b> If no other name is given, the key name of the machining channel is used for saving. <b>Format:</b> String <b>Input:</b> Max. 18 characters	RUN LEVEL1	620
<b>CfgNcPgmBehaviour</b>			
Defines the behavior of the MANUALplus 620 during NC program run			
<b>operatingTimeReset</b> 200801	Reset the machining time when program starts.	RESET LEVEL3	620

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgLaPath</b>			
<p>Parameters for calculation of the path feed rate profile;            Defines the minimum feed rates within one segment (path segment) and for the transition between two segments (corners). Feed rates lower than the minimum defined feed rates become effective only if they are programmed.</p> <p>Maximum values for jerk and yank are defined for acceleration on the path. A tolerance value is included. The feed rate for corners and curvatures is limited so that the filter error does not exceed this value.</p>			
<b>minPathFeed</b> 201501	<b>Minimum feed rate on the path</b> This feed rate is only violated within a segment if a lower feed rate is programmed. <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 600 000.0 [mm/min] <b>Default:</b> 60.0 [mm/min]	Allowed in strobe LEVEL3	826
<b>minCornerFeed</b> 201502	<b>Minimum feed rate at corners</b> This feed rate is only violated between two segments if a lower feed rate is programmed. <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 600 000.0 [mm/min] <b>Default:</b> 30.0 [mm/min]	Allowed in strobe LEVEL3	827
<b>maxG1Feed</b> 201503 MP1092	<b>Maximum machining feed rate. If this value is exceeded, the "-Hi" parameters go into effect.</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 99 999.0 [mm/min] <b>Default:</b> 99 999.0 [mm/min]	Allowed in strobe LEVEL3	828
<b>maxPathJerk</b> 201504 MP1090.0	<b>Maximum jerk on the path</b> This value applies to machining feed rates up to <b>maxG1Feed</b> . <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 1 000 000.0 [m/s <sup>3</sup> ] <b>Default:</b> 40.0 [m/s <sup>3</sup> ]	Allowed in strobe LEVEL3	829
<b>maxPathJerkHi</b> 201505 MP1090.1	<b>Maximum jerk on the path at rapid traverse</b> This value also applies to a feed rate greater than <b>MP_maxG1Feed</b> . <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 1 000 000.0 [m/s <sup>3</sup> ] <b>Default:</b> 40.0 [m/s <sup>3</sup> ]	Allowed in strobe LEVEL3	829

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>pathTolerance</b> 201506 MP1202.0	<b>Path tolerance for contour transitions after the filter</b>  The feed rate for corners and curvatures is limited so that the filter error does not exceed this value. The path tolerance can be changed with Cycle 32.  <b>Format:</b> Numerical value <b>Input:</b> 0.0001 to 10.000 [mm] <b>Default:</b> 0.010 [mm]	Allowed in strobe  LEVEL3	828
<b>pathToleranceHi</b> 201507 MP1202.1	<b>Path tolerance after the filter at rapid traverse</b>  This value also applies to feed rates greater than <b>MP_maxG1Feed</b> .  <b>Format:</b> Numerical value <b>Input:</b> 0.0001 to 10.000 [mm] <b>Default:</b> 0.010 [mm]	Allowed in strobe  LEVEL3	828
<b>maxPathYank</b> 201508	<b>Maximum yank on the path (dj/dt)</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 1 000 000.0 [mm/sec4] <b>Default:</b> 4 000.0 [mm/sec4]	Allowed in strobe  LEVEL3	830
<b>reduceCornerFeed</b> 201516 MP1205 (optional parameter)	<b>Reduction of the contouring feed rate at the beginning of a contour element</b>  <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> Reduction of contouring feed rate active (slower but more accurate if required) ■ <b>FALSE:</b> Reduction of contouring feed rate not active (fast, but can be a little less accurate)	Allowed in strobe  LEVEL3	836
<b>CfgPlcStrobes</b> Definition of the M, S and T strobes for this channel			
<b>mStrobes</b> 201601	<b>List of M strobe descriptions in this channel</b>  <b>Format:</b> List [0 to 300] <b>Input:</b> Key name of the M function Selection from <b>CfgPlcMStrobe</b>	RESET  LEVEL3	1548
<b>sStrobe</b> 201602	<b>List of S strobe descriptions in this channel</b>  <b>Format:</b> List [0 to 6] <b>Input:</b> Key name of the S function Selection from <b>CfgPlcSStrobe</b>	RESET  LEVEL3	1560

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>tStrobes</b> 201603	<b>List of T strobe descriptions in this channel</b>  <b>Format:</b> List [0 to 3] <b>Input:</b> Key name of the T function Selection from <b>CfgPlcTStrobe</b>	RESET LEVEL3	1574
<b>aliasStrobes</b> 201604	<b>List of implemented strobes in this channel</b>  Reproduction of control-dependent functions on a uniform M-function transfer to the PLC program. <b>Format:</b> List [0 to 5] <b>Input:</b> Key name of the M function Selection from <b>CfgPlcMStrobe</b>	RESET LEVEL3	1582
<b>unitOfMeasure</b> 201605 (optional parameter)	Symbolic name or number of the PLC marker for the unit of measure of the NC program  Name of the PLC marker that informs the PLC of the unit of measure of the NC program to be run. PLC marker = 1: Inches PLC marker = 0: Metric system <b>Format:</b> String <b>Input:</b> Max. 24 characters	RESET LEVEL3	1548
<b>CfgPlcOverrideF</b>			
Configuration of the feed rate override for this channel			
<b>minimal</b> 201901	<b>Minimum value for override</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.00 to 100.00 [%] <b>Default:</b> 0 [%]	RESET LEVEL3	1357
<b>maximal</b> 201902	<b>Maximum value for override</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.00 to 200.00 [%] <b>Default:</b> 150 [%]	RESET LEVEL3	1357
<b>source</b> 201903	<b>Source for override values</b>  <b>Format:</b> List [0 to 2] <b>Input:</b> Key name of the override device from <b>CfgPlcOverrideDev</b>	RESET LEVEL3	1357

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgPlcOverrideR</b>			
Configuration of rapid traverse override for this channel (optional)			
<b>minimal</b> 201901	<b>Minimum value for override</b> <b>Format:</b> Numerical value <b>Input:</b> 0.00 to 100.00 [%] <b>Default:</b> 0 [%]	RESET LEVEL3	–
<b>maximal</b> 201902	<b>Maximum value for override</b> <b>Format:</b> Numerical value <b>Input:</b> 0.00 to 200.00 [%] <b>Default:</b> 150 [%]	RESET LEVEL3	–
<b>source</b> 201903	<b>Source for override values</b> <b>Format:</b> List [0 to 2] <b>Input:</b> Key name of the override device from <b>CfgPlcOverrideDev</b>	RESET LEVEL3	–

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgPrefForPolarKin</b> Settings for the polar kinematics (optional)			
<b>kindOfPref</b> 202301 (optional parameter)	<b>Behavior of the polar kinematics at radius 0</b> If the tool center of a machine with polar kinematics lies exactly on the polar axis (C axis, radius 0), there are two possibilities for a linear positioning block: r,phi or -r,phi+180. Use this parameter to define the behavior of the MANUALplus 620 if the tool center point path runs through (crosses) the polar axis. Format:        Selection menu Input: <ul style="list-style-type: none"> <li>■ <b>RadiusPositive:</b> After crossover, the tool center point is at a position with positive radius.</li> <li>■ <b>RadiusNegative:</b> After crossover, the tool center point is at a position with negative radius.</li> <li>■ <b>MinimalAngle:</b> The crossover path is executed through a C-axis movement as small as possible.</li> <li>■ <b>NoChangeOfRadius:</b> After crossover, the radius has the same algebraic sign as before crossover.</li> <li>■ <b>Radius0NotAllowed:</b> A tool center point path that runs through (crosses) the polar axis is not allowed.</li> </ul>	RUN LEVEL1	–



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgChannDashboard</b>			
Channel-dependent dashboard configurations			
<b>defaultDashboard</b> 203401 (optional parameter)	<b>List of default dashboards</b> <b>Format:</b> List [0 to 40] <b>Input:</b> Key name of a dashboard configured under <b>DisplaySettings/CfgDashboard</b>	RUN LEVEL3	1289
<b>opmodeStartup</b> 203402 (optional parameter)	<b>List of dashboards for start-up phase</b> <b>Format:</b> List [0 to 40] <b>Input:</b> Key name of a dashboard configured under <b>DisplaySettings/CfgDashboard</b>	RUN LEVEL3	1289
<b>opmodeReference</b> 203403 (optional parameter)	<b>List of the dashboards for REFERENCE operating mode</b> <b>Format:</b> List [0 to 40] <b>Input:</b> Key name of a dashboard configured under <b>DisplaySettings/CfgDashboard</b>	RUN LEVEL3	1289
<b>opmodeManual</b> 203404	<b>List of the dashboards for Manual Operation mode</b> <b>Format:</b> List [0 to 40] <b>Input:</b> Key name of a dashboard configured under <b>DisplaySettings/CfgDashboard</b> <b>Default:</b> DB_DEFAULT	RUN LEVEL3	1289
<b>opmodeManualLarge</b> 203408 (optional parameter)	<b>List of the expanded dashboards of Manual Operation mode</b> <b>Format:</b> List [0 to 40] <b>Input:</b> Key name of a dashboard configured under <b>DisplaySettings/CfgDashboard</b>	RUN LEVEL3	1289
<b>opmodeMDI</b> 203405 (optional parameter)	<b>List of the dashboards for the MDI mode</b> <b>Format:</b> List [0 to 40] <b>Input:</b> Key name of a dashboard configured under <b>DisplaySettings/CfgDashboard</b>	RUN LEVEL3	1289

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>opmodeAutomatic</b> 203406	<b>List of the dashboards for Automatic mode</b>  <b>Format:</b> List [0 to 40] <b>Input:</b> Key name of a dashboard configured under <b>DisplaySettings/CfgDashboard</b>  <b>Default:</b> [0]: DB_DEFAULT [1]: DB_DEFAULT_1	RUN LEVEL3	1289
<b>opmodeAutomaticLarge</b> 203409 (optional parameter)	<b>List of the expanded dashboards for Automatic mode</b>  <b>Format:</b> List [0 to 40] <b>Input:</b> Key name of a dashboard configured under <b>DisplaySettings/CfgDashboard</b>	RUN LEVEL3	1289
<b>opmodeSGTest</b> 203407 (optional parameter)	<b>List of the dashboards for the safety-related-test operating mode</b>  <b>Format:</b> List [0 to 40] <b>Input:</b> Key name of a dashboard configured under <b>DisplaySettings/CfgDashboard</b>	RUN LEVEL3	1289
<b>CfgAssignAggregate</b> Assign tool carrier to the machining channel			
<b>assignToolHolder</b> 203901	<b>List of the key names of all tool carriers</b>  <b>Format:</b> List [0 to 3] <b>Input:</b> Key name of a tool carrier configured in <b>CfgAggregateKeys/toolHolder-Keys</b>  <b>Default:</b> TH1_REV	RESET LEVEL3	1397



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgChannelProperties</b> Characteristics of the machining channel			
<b>kinManualMode</b> 203804 (optional parameter)	<b>Switch kinematics off/on in Manual mode</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>on:</b> The coordinate transformation specified in the kinematic configuration (oblique-axis coupling) stays active even in Manual mode.</li> <li>■ <b>off:</b> No coordinate transformation of the axes in Manual mode. This means that there is no compensating movement when oblique axes are moved.</li> </ul>	RUN LEVEL3	1444



### 4.10.3 "Axes" group

Axis-specific machine parameters.

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgProgAxis</b>			
Settings for programmable/displayed axes, If you want to be able to program, display and/or edit axis names, you must enter the corresponding key name of the axis here.			
<b>[Key name of the axis]</b>			
The OEM can choose any key name for the axis, e.g. X, X axis, etc. The axis with this key name must be contained in <b>CfgAxis/axisList</b> . Other names can be assigned to axes whose names cannot be programmed until a certain kinematics model has been activated.			
<b>axName</b> 300001	<b>Designation of the axis for position display</b> This axis name is also valid for programming/ editing. <b>Format:</b> String <b>Input:</b> Programmable axis name, such as A, B, C, U, V, W, X, Y, Z	RESET LEVEL3	628
<b>dir</b> 300002	<b>Spatial orientation of the axis or center of rotation</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>XAxis:</b> Motion/rotary axis in X direction ■ <b>YAxis:</b> Motion/rotary axis in Y direction ■ <b>ZAxis:</b> Motion/rotary axis in Z direction ■ <b>SpecAxis:</b> Free/undefined spatial orientation, e.g. for spindle or PLC axis	RESET LEVEL3	628



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>progKind</b> 300003	<b>Type of axis</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>MainLinCoord:</b> Primary coordinate, always linear (X, Y, Z)</li> <li>■ <b>ParallelLinCoord:</b> Parallel linear coordinate (U, V, W)</li> <li>■ <b>ParallelAngCoord:</b> Parallel angular coordinate (A, B, C)</li> <li>■ <b>SatelliteLinCoord:</b> Minor linear coordinate: Reserved, not used at present</li> <li>■ <b>SatelliteAngCoord:</b> Minor angular coordinate: Reserved, not used at present</li> <li>■ <b>Spindle:</b> Spindle</li> </ul>	RESET LEVEL3	629
<b>relatedAxis</b> 300005 (optional parameter)	<b>Assigned physical axis</b> Only enter axis name if the key name of the programmable axis does not match the key name of the physical axis. <b>Format:</b> Selection menu <b>Input:</b> Key name of axis from Axes/PhysicalAxis	RESET LEVEL3	629

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>PhysicalAxis</b> Physical description of the axes			
<b>[Key name of the axis]</b> The OEM can choose any key name for the axis, e.g. X, X axis, etc. The axis with this key name must be contained in <b>CfgAxis/axisList</b> .			
<b>CfgAxis</b> General description of an axis; The parameter object <b>CfgAxis</b> must be configured for each axis or spindle.			
<b>isAng</b>  300101	<b>Rotary axis</b>  Remark: Rotary axes are not allowed as principal axes.  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b>    Rotary axis</li> <li>■ <b>FALSE:</b>    Linear axis (no rotary axis)</li> </ul> <b>Default:</b> FALSE	RESET  LEVEL3	631
<b>isModulo</b>  300102	<b>Modulo display</b>  Modulo limit of 360 degrees for the position display of rotary axes.  Format:       Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b>    Modulo display from 0 to 360 [°]</li> <li>■ <b>FALSE:</b>    No modulo display</li> </ul> Default:       FALSE	RUN  LEVEL3	632
<b>restoreModuloCnt</b>  300111 (optional parameter)	<b>Save modulo counter of the axis in SRAM</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b>    The modulo counter of the axis is saved cyclically in SRAM and restored during startup of the MANUALplus 620.</li> <li>■ <b>FALSE:</b>    The modulo counter of the axis is not saved in SRAM and not restored during control startup.</li> </ul> <b>Default:</b> FALSE	RUN  LEVEL3  597 110-05	632



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>isHirth</b> 300103 MP420 (optional parameter)	<b>Axis with Hirth coupling</b> Default grid increment in [°] or [mm] for Hirth coupling, measured from the machine datum. If the parameter is inactive or the value 0 is entered, no Hirth grid is supported. <b>Format:</b> Numerical value <b>Input:</b> Hirth grid in [°] or [mm]	RUN LEVEL3 597 110-02	703
<b>axisHw</b> 300104	<b>Hardware to which the axis is connected</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>None:</b> No hardware connection (virtual axis)</li> <li>■ <b>InOutCC:</b> Digital axis with connection to a CC controller unit</li> <li>■ <b>AnalogMC:</b> Analog drive interface; encoder connection to the MC</li> <li>■ <b>AnalogCC:</b> Analog drive interface; encoder connection to the CC</li> <li>■ <b>DisplayMC:</b> Display axis; encoder connection to the MC</li> <li>■ <b>DisplayCC:</b> Display axis; encoder connection to the CC</li> <li>■ <b>ManualMC:</b> Open-loop axis; encoder connection to the MC</li> <li>■ <b>ManualCC:</b> Open-loop axis; encoder connection to the CC</li> <li>■ <b>ProfiNet:</b> Digital Profinet axis (reserved, function not available yet)</li> </ul> Default: InOutCC	RESET LEVEL3	635

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>axisMode</b> 300105 MP10 (expanded)	<b>Axis operating mode</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>NotAllowed:</b> Reserved, do not use!</li> <li>■ <b>NotActive:</b> Axis does not exist</li> <li>■ <b>Active:</b> Axis physically present</li> <li>■ <b>Virtual:</b> Virtual axis for superimposed movements</li> <li>■ <b>PlcControlled:</b> e.g. for encoded spindles; axis is controlled solely by the PLC</li> </ul> Default: Active	RESET LEVEL3	636
<b>testMode</b> 300106	<b>Axis in test mode</b> Note: Axes in Test mode must be enabled in the SIK. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Test mode for commissioning, i.e. the axis needs not be connected</li> <li>■ <b>FALSE:</b> Test mode not active. If <b>MP_axisMode = Active</b>: Axis must be connected electrically.</li> </ul> Default: FALSE	RESET LEVEL3	636
<b>parList</b> (300107)	<b>List of all parameter sets of this axis</b> Multiple parameter sets can be created for an axis. The key name is used to select the desired set. Example: PX (parameter set for X axis). <b>Format:</b> List [0 to 10] <b>Input:</b> Key name(s) from ParameterSets	RESET LEVEL3	637
<b>realAxis</b> 300108 (optional parameter)	<b>Key name of the associated real axis</b> For TNC contouring controls: Parameter reserved, do not assign. The key name of the associated real axis is only to be entered if the current axis is a virtual axis (e.g. for noncylindrical grinding). <b>Format:</b> Selection menu <b>Input:</b> Key name of axis from Axes/PhysicalAxis	RESET LEVEL3	637



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>noActToNumAtEmSt</b> 300109 (optional parameter)	<b>Actual-to-nominal value transfer for all axes in an EMERGENCY STOP</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Actual-to-nominal value transfer for all axes in an EMERGENCY STOP is not performed.</li> <li>■ <b>FALSE:</b> The standard control behavior is actual-to-nominal value transfer for all axes in an EMERGENCY STOP.</li> </ul> <b>Default:</b> FALSE	RUN LEVEL3	638
<b>deactivatedAtStart</b> 300110 (optional parameter)	<b>Deactivate axis during startup</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> During startup of the MANUALplus 620 the axis is deactivated—irrespective of the parameter <b>MP_axisHw</b>. The same effect is attained with the setting as from calling PLC module 9226 or 9418 with mode 14.</li> <li>■ <b>FALSE:</b> During startup of the MANUALplus 620 the axis is treated as configured in the parameter axisHw.</li> </ul> <b>Default:</b> FALSE	RUN LEVEL3	682
<b>advancedSettings</b> 300112 (optional parameter)	<b>Advanced settings for individual axes</b> <b>Format:</b> Bit-encoded value <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>Bit 0 = 1:</b> A traverse commanded by the PLC is not interrupted if the touch probe is deflected.</li> <li>■ <b>Bit 1 = 1:</b> A traverse commanded by the PLC is not made in a bell-shaped curve but at a constant acceleration.</li> <li>■ <b>Bit 2 = 1:</b> For a spindle in position feedback control, the following error is not calculated in modulo counting mode.</li> <li>■ All other bits: Reserved</li> </ul>	RUN LEVEL3 597 110-05	640

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgAxisPropKin</b> Description of special axis properties; Specifies various properties that are important for the kinematics			
<b>specKinCoordSys</b> 300201 (optional parameter)	<b>Type of special coordinate system</b> Specifies whether the assigned coordinate transformation is used to define a fixed translation axis or a datum (DefPoint). Enter the key name of this axis in <b>CfgAxes/specCoordSysList</b> , too. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>FixedTransAxis:</b> Translation axis for which no physical axis exists (e.g. the Y axis of a grinding machine is represented by using the X and Z axes).</li> <li>■ <b>DefPointTrans:</b> Coordinate system in the kinematics model to which no physical axis is assigned (e.g. for defining auxiliary coordinate systems).</li> <li>■ <b>DefPointRot:</b> Same as DefPointTrans, but for rotary axis.</li> </ul>	RESET LEVEL3	641
<b>kindOfRotAxis</b> 300202 (optional parameter)	<b>Type of rotational axis, only for rotary axes</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>RollOver:</b> Axis can roll over</li> <li>■ <b>NotRollOver:</b> Axis has a limited angle of rotation</li> </ul>	RESET LEVEL3	641
<b>presetToAlignAxis</b> 300203 (optional parameter)	<b>Controls the treatment of the preset for rotational axes</b> If the parameter is not set or set to TRUE (default), the offset from the preset is subtracted from the axis value before the kinematic calculation. If the attribute is set to FALSE, the offset only affects the position display of the axis. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Offset is subtracted</li> <li>■ <b>FALSE:</b> Offset is only effective for the display</li> </ul> <b>Default:</b> TRUE	RESET LEVEL3	642



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>hasSpecAxisData</b> 300204 (optional parameter)	<b>Reserved: Special axis data available, only for special axes</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Special axis data available</li> <li>■ <b>FALSE:</b> No special axis data</li> </ul> <b>Default:</b> FALSE	RESET LEVEL3	642
<b>parAxComp</b> 300205 (optional parameter)	<b>Compensation of parallel linear axes</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>Off:</b> Compensation and display function is deactivated for parallel axes.</li> <li>■ <b>Display:</b> Display function for parallel secondary axes is active.</li> <li>■ <b>Move:</b> Compensation for parallel axes is active.</li> </ul>	RESET LEVEL3	763

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgRollOver</b> Configuration of a rollover axis; Rotary axes that are able to perform several—ideally any number of—revolutions are configured as rollover axes.			
<b>shortestDistance</b> 300401 MP7682 (optional parameter)	<b>Traverse path of rotary axis with modulo counting mode</b> If the parameter is set to <b>on</b> , the rotary axis approaches the target position on the shortest path ( $\leq 180^\circ$ ) if programming is non-incremental. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>on:</b> Always approach target position on the shortest path (<math>\leq 180^\circ</math>)</li> <li>■ <b>off:</b> Approach the target position without passing over zero (same behavior as linear axis)</li> </ul> Default: off	Allowed in strobe LEVEL1	633
<b>startPosToModulo</b> 300402 (optional parameter)	<b>Rollover axis moves start angle into the range of 0..360°</b> The parameter is effective only if MP_shortestDistance = off is set. The parameter causes the position of the rotary axis to be limited to the range from $0^\circ$ to $360^\circ$ at the beginning of each positioning block. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>on:</b> Move the rotary axis into the <math>0</math> to <math>360^\circ</math> range at the beginning of the positioning block.</li> <li>■ <b>off:</b> Do not move the rotary axis into the <math>0</math> to <math>360^\circ</math> range.</li> </ul> Default: off	Allowed in strobe LEVEL1	634
<b>showModuloDisp</b> 300403 (optional parameter)	<b>Display of rollover axis in the range of 0 to 360°</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>on:</b> Display of rollover axis within the modulo limits of <math>0..360^\circ</math></li> <li>■ <b>off:</b> Display of rollover axis not within the modulo limits</li> </ul> Default: off	Allowed in strobe LEVEL1	634



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>ParameterSets</b> Parameter sets for the axes			
<b>[Key name of the parameter set]</b> Any key name can be chosen for the parameter set. In the default configuration, the names are preconfigured according to the following pattern: <b>P.[axis designation]</b> , e.g. PX, PY, PZ, etc. The parameter sets must be assigned to the respective axis in CfgAxis/parList.			
<b>CfgAxisHardware</b> Specifies the settings for the axis hardware; e.g. wiring configuration, connection of the encoders, etc.			
<b>signCorrActualVal</b> 400001 MP1040, MP3130	<b>Sign reversal of the position-encoder signal</b> Invert counting direction of the actual value. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>on:</b> The algebraic sign of the position encoder is inverted</li> <li>■ <b>off:</b> The algebraic sign of the position encoder is not inverted</li> </ul> <b>Default:</b> off	RUN LEVEL3	664
<b>signCorrNominalVal</b> 400002 MP210, MP3130	<b>Sign reversal of the speed command signal</b> Invert counting direction of the nominal speed value. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>on:</b> The algebraic sign of the nominal speed value is inverted</li> <li>■ <b>off:</b> The algebraic sign of the nominal speed value is not inverted</li> </ul> <b>Default:</b> off	RUN LEVEL3	664

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>posEncoderType</b> 400003	<b>Position measurement via position encoder or motor encoder</b> Specifies the type of position encoder. <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>MC_DISTANCE_CODED:</b> Distance-coded position encoder on the MC (X01 to X06 and X35 to X38)</li> <li>■ <b>MC_NOT_DISTANCE_CODED:</b> Not a distance-coded position encoder on the MC (X01 to X06 and X35 to X38)</li> <li>■ <b>MC_ENDAT:</b> EnDat position encoder on the MC (X01 to X06 and X35 to X38)</li> <li>■ <b>NO_ENCODER:</b> No position measurement</li> <li>■ <b>CC_MOTOR_ENCODER:</b> Position measurement by speed encoder on the CC (X15 to X20 and X80 to X83)</li> <li>■ <b>CC_DISTANCE_CODED:</b> Distance-coded position encoder on the CC (X201 to X210)</li> <li>■ <b>CC_NOT_DISTANCE_CODED:</b> Not a distance-coded position encoder on the CC (X201 to X210)</li> <li>■ <b>CC_MOTOR_ENDAT:</b> Position measurement by EnDat speed encoder on the CC (X15 to X20 and X80 to X83)</li> <li>■ <b>CC_EXTERN_ENDAT:</b> External EnDat encoder on the CC (X201 to X210)</li> <li>■ <b>CC_MOTOR_ENDAT_INCR:</b> HEIDENHAIN EnDat interface box (EIB) on the CC (X201 to X210)</li> <li>■ <b>CC_EXTERN_ENDAT_INCR:</b> HEIDENHAIN EnDat interface box (EIB) on the CC (X201 to X210)</li> <li>■ <b>MC_NOT_DISTANCE_CODED_CC_ENDAT:</b> Reserved, do not use!</li> <li>■ <b>C_EXTERN_ENDAT_2_2:</b> External EnDat 2.2 encoder on the CC (X201 to X210)</li> </ul>	RUN LEVEL3	646
<b>distPerMotorTurn</b> 400004 MP1054	<b>Linear distance of one motor revolution</b> For analog feedback control (no motor encoder): Set the value 1, the parameter has no effect. <b>Format:</b> Numerical value <b>Input:</b> 0.001 to 999 999 999 [mm] or [°] <b>Default:</b> 5.000 [mm]	RUN LEVEL3	647



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>posEncoderDist</b> 400005 MP331	<b>Distance for number of signal periods from MP_posEncoderIncr</b> Enter 360° for spindles. For multiturn encoders with EnDat interface, enter the distance traversed per encoder revolution. <b>Format:</b> Numerical value <b>Input:</b> 0.001 to 999 999 999 [mm] or [°] <b>Default:</b> 5.000 [mm]	RUN LEVEL3	653
<b>posEncoderIncr</b> 400006 MP332, MP3142	<b>Number of signal periods for distance from MP_posEncoderDist</b> Number of increments of external encoder. For spindles, enter the line count of the encoder used. For multiturn encoders with EnDat interface, enter the increments per encoder revolution. <b>Format:</b> Numerical value <b>Input:</b> 1 to 100 000 [incr] <b>Default:</b> 2 048 [incr]	RUN LEVEL3	653
<b>posEncoderRefDist</b> 400007 MP334	<b>Nominal increment between two fixed reference marks</b> Number of signal periods between the reference marks. The attribute is only relevant for encoders with distance-coded reference marks. <b>Format:</b> Numerical value <b>Input:</b> 1 to 65 535 [incr] <b>Default:</b> 1 000 [incr]	RUN LEVEL3	653
<b>genExtIntPolFactor</b> 400017 MP340	<b>External interpolation for encoder signals</b> Only functional for the CC 61xx and CC 424 controller units. <b>Format:</b> Numerical value <b>Input:</b> 0 to 99 0, 1: No external interpolation	RUN LEVEL3	655

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>posEncoderInput</b> 400008 MP110, MP111	<b>Assignment of a position encoder input to the axis</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>none:</b> No position encoder connected</li> <li>■ <b>X01...X06:</b> Position encoder inputs are X01 to X06 (on the MC 42x)</li> <li>■ <b>X35...X38:</b> Position encoder inputs are X35 to X38 (on the MC 42x)</li> <li>■ <b>X201...X210:</b> Position encoder inputs are X201 to X210 (on the CC)</li> </ul> <b>Default:</b> none	RUN LEVEL3	657
<b>posEncoderSignal</b> 400009 MP115.0, MP116.0	<b>Signal amplitude at position encoder input</b> On the CC 61xx: Encoders with 11 $\mu\text{A}_{\text{PP}}$ signal are not supported! <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>1 Vpp:</b> Input signal of the encoder is 1 V<sub>PP</sub></li> <li>■ <b>11 <math>\mu\text{A}</math>:</b> Input signal of encoder is 11 <math>\mu\text{A}</math></li> </ul> <b>Default:</b> 1 Vpp	RUN LEVEL3	659
<b>posEncoderFreq</b> 400010 MP115.2, MP116.2	<b>Input frequency of position encoder inputs</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>fast:</b> Input frequency is                  At 11 V<sub>PP</sub>: 350 kHz                  At 11 <math>\mu\text{A}_{\text{PP}}</math>: 150 kHz</li> <li>■ <b>slow:</b> Input frequency is 33 kHz</li> </ul> <b>Default:</b> fast	RUN LEVEL3	659
<b>posEncoderResistor</b> 400011 MP115.1, MP116.1	<b>Terminating resistor at position encoder input</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>without:</b> Without terminating resistor</li> <li>■ <b>120 ohms:</b> With resistor</li> </ul> <b>Default:</b> 120 ohms	RUN LEVEL3	660

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>speedEncoderInput</b> 400012 MP112	<b>Assignment of a speed encoder input to the axis</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>none:</b> No speed encoder connected</li> <li>■ <b>X15...X20:</b> Speed encoder inputs are X15 to X20</li> <li>■ <b>X80...X83:</b> Speed encoder inputs are X80 to X83</li> </ul> <b>Default:</b> none	RUN LEVEL3	657
<b>inverterInterface</b> 400013 MP120, MP121	<b>Assignment of the speed command output to the axis</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>none:</b> Not a PWM output, no power module connected</li> <li>■ <b>X51...X56:</b> PWM outputs are X51 to X60</li> <li>■ <b>X80...X85:</b> Only on UEC 11x: Motor connections are X80 to X85</li> </ul> <b>Default:</b> none	RUN LEVEL3	657
<b>hsciCclIndex</b> 400014 (optional parameter)	<b>Index of the CC 61xx controller unit in the HSCI chain</b>  Assign the index based on the position of the CC 61xx in the HSCI chain: The first CC after the MC is assigned the number 0, the second one the number 1, etc.  <b>Format:</b> Numerical value  <b>Input:</b> 0 to 4  <b>Default:</b> 0	RUN LEVEL3	658
<b>driveOffGroup</b> 400015 (optional parameter)	<b>Assignment of the axis to the switch-off group</b>  You can assign the axis to a maximum of 8 switch-off groups. To do so, insert one line each in the list and select the desired switch-off group in the selection menu.  <b>Format:</b> List [0 to 7]  <b>Input:</b> Name of the switch-off group Group1 to Group8, or None	RUN LEVEL3 597 110-03	218

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgPosControl</b>			
Position control parameters			
<b>kvFactor</b> 400801 MP1510, MP1810, MP3440	<b>Kv factor (proportional component of position controller)</b>  Note: The unit of the kv factor of the MANUALplus 620 differs from that of the iTNC 530: Unit of the MANUALplus 620: mm / (mm · sec) Unit of the iTNC 530: m / (mm · min)  Therefore: <b>iTNC kv factor · 16.66 = MANUALplus 620 kv factor!</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 1000.000 [1/s] <b>Default:</b> 0.000 [1/s]	Allowed in strobe LEVEL3	842
<b>servoLagMin1</b> 400802 MP1410	<b>Minimum for following-error monitoring (clearable)</b>  Position monitoring during operation with feedforward.  This value applies to constant feed rates and clearable error messages.  <b>Format:</b> Numerical value <b>Input:</b> 0.0000 to 100.0000 [mm] or [°] <b>Default:</b> 1.0000 [mm]	Allowed in strobe LEVEL3	949
<b>servoLagMax1</b> 400803 MP1420	<b>Maximum for following-error monitoring (clearable)</b>  Position monitoring during operation with feedforward.  This value applies to changes in feed rate and clearable error messages.  <b>Format:</b> Numerical value <b>Input:</b> 0.0000 to 100.0000 [mm] or [°] <b>Default:</b> 5.0000 [mm]	Allowed in strobe LEVEL3	949



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>servoLagMin2</b> 400804	<b>Minimum for following-error monitoring (emergency stop)</b>  Position monitoring during operation with feedforward.  This value applies to constant feed rates and the emergency-stop error message. <b>Format:</b> Numerical value <b>Input:</b> 0.0000 to 100.0000 [mm] or [°] <b>Default:</b> 1.000 [mm]	Allowed in strobe  LEVEL3	950
<b>servoLagMax2</b> 400805 MP1420	<b>Maximum for following-error monitoring (emergency stop)</b>  Position monitoring during operation with feedforward.  This value applies for changes in feed rate and the emergency-stop error message. <b>Format:</b> Numerical value <b>Input:</b> 0.0000 to 100.0000 [mm] or [°] <b>Default:</b> 5.000 [mm]	Allowed in strobe  LEVEL3	950
<b>feedForwardFactor</b> 400806 MP1396, MP1391 MP1392	<b>Factor for velocity feedforward control</b>  Configuration of velocity feedforward in all modes of operation.  $V_{out} = K_v \cdot \text{following error} + V_{nom} \cdot f_{FF}$ <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 1.500 <b>Default:</b> 1.000	Allowed in strobe  LEVEL3	840
<b>controlOutputLimit</b> 400807	<b>Control-variable limit for the position controller</b>  Used only during switch-on of position feedback control without actual-to-nominal value transfer. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 1 666.000 [mm/min] <b>Default:</b> 0.000 [mm/min]	Allowed in strobe  LEVEL3	843

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgAxisAnalog</b>			
Description of an analog axis or spindle			
<b>analogOutput</b> 400101 MP120, MP121	<b>Speed command output of axis or spindle</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>none:</b> No analog output assigned ■ <b>analog Output 1...13:</b> Analog outputs 1 to 6 (connector X8 on MC 3xx or MC 4xx) Analog outputs 1 to 4 (CMA-H 04-04-00) Analog outputs 7 to 13 (connector X9 on MC 4xx) <b>Default:</b> analog Output 1	RUN LEVEL3	669
<b>analogOffset</b> 400102 MP1080	<b>Offset on analog axis</b> Offset that is only effective for analog axes. <b>Format:</b> Numerical value <b>Input:</b> -1.0 to 1.0 [V] <b>Default:</b> 0.0 [V]	RUN LEVEL3	912
<b>kvFactor2</b> 400103 (optional parameter)	<b>Proportional component of position controller above MP_kvSpeedLimit</b> Parameter only for analog axes. Note: The unit of the kv factor of the MANUALplus 620 differs from that of the iTNC 530: Unit of the MANUALplus 620: mm / (mm · sec) Unit of the iTNC 530: m / (mm · min) Therefore: <b>iTNC kv factor · 16.66 = MANUALplus 620 kv factor</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 1000.000 [1/s] <b>Default:</b> 0.000 [1/s]	RUN LEVEL3	903
<b>kvSpeedLimit</b> 400104 (optional parameter)	<b>Limit velocity for MP_kvFactor2</b> Parameter only for analog axes. <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 36 000 000.0 [mm/min] <b>Default:</b> 0.0 [mm/min]	RUN LEVEL3	903

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>maxFeedAt9V</b> 400105	<b>Velocity at 9 volts</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000000006 to 36 000 000 [mm/min] or [°/min] <b>Default:</b> 4 999.98 [mm/min]	RUN LEVEL3	670
<b>accForwardFactor</b> 400106 (optional parameter)	<b>Factor for acceleration feedforward control</b> <b>Parameter only for analog axes</b> <b>Format:</b> Numerical value <b>Input:</b> 0.00000 to 0.01000 Default: 0.0	RUN LEVEL3	905
<b>compStrength</b> 400107 (optional parameter)	<b>Strength of the compensation</b> Compensation of reversal spikes for analog axes. Specify the surface of the compensation curve that is superimposed on the nominal speed command during a reversal of the traverse direction. Definition of algebraic sign: ■ <b>0:</b> No compensation ■ <b>positive:</b> Compensation works in the direction of acceleration. ■ <b>negative:</b> Compensation works against the acceleration. <b>Format:</b> Numerical value <b>Input:</b> -999 999 999.999 999 999 to +999 999 999.999 999 999 [mm] <b>Default:</b> 0	RUN LEVEL3	906
<b>compWidth</b> 400108 (optional parameter)	<b>Duration of the compensation</b> Compensation of reversal spikes for analog axes. Specify the distance (with respect to <b>MP_compTimeOffset</b> = 0) to the reversal point within which the compensation curve is superimposed on the nominal speed command. Input: [mm] Default: 0.001	RUN LEVEL3	906

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>compTimeOffset</b> 400109 (optional parameter)	<b>Time offset of the compensation</b> Compensation of reversal spikes for analog axes. Specify the velocity of the axis at which the compensation curve reaches its maximum. Definition of algebraic sign: <ul style="list-style-type: none"> <li>■ <b>0:</b> The compensation curve reaches its maximum at the time of direction reversal.</li> <li>■ <b>positive:</b> The compensation curve is delayed and therefore reaches its maximum after the direction reversal.</li> <li>■ <b>negative:</b> The compensation curve is output earlier and therefore reaches its maximum before the actual direction reversal.</li> </ul> <b>Format:</b> Numerical value <b>Input:</b> -999 999 999.999 999 999 to +999 999 999.999 999 999 [mm/min] <b>Default:</b> 0	RUN LEVEL3	907
<b>compFFAdjust</b> 400110 (optional parameter)	<b>Acceleration compensation</b> With this parameter, you can take into account that the required compensation strength depends on acceleration during direction reversal. The value indicates by how much the compensation strength defined in <b>MP_compStrength</b> is corrected during low acceleration. Definition of algebraic sign: <ul style="list-style-type: none"> <li>■ <b>0:</b> The compensation strength is constant over all acceleration values.</li> <li>■ <b>positive:</b> The compensation strength is increased during low acceleration.</li> <li>■ <b>negative:</b> The compensation strength is decreased during low acceleration.</li> </ul> <b>Format:</b> Numerical value <b>Input:</b> -999 999 999.999 999 999 to +999 999 999.999 999 999 [mm] <b>Default:</b> 0	RUN LEVEL3	907



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>compRefAcc</b> 400111 (optional parameter)	<b>Reference acceleration</b> The value entered is required for acceleration compensation ( <b>MP_compFFAdjust</b> ). The compensation strength entered in <b>MP_compStrength</b> is used for the given acceleration. <b>Format:</b> Numerical value <b>Input:</b> 0 to 999 999 999.999 999 999 [m/s <sup>2</sup> ] <b>Default:</b> 0.03	RUN LEVEL3	908
<b>compLimitFactor</b> 400114 (optional parameter)	<b>Limit of reversal-spike compensation</b> Factor for raising or lowering the internal default software limit of 3 mm/s. <b>Format:</b> Numerical value <b>Input:</b> 0.50 to 5.00 <b>Default:</b> 1	RUN LEVEL3	908
<b>noOffsetAdjust</b> 400112 (optional parameter)	<b>Excludes the axis from automatic offset adjustment</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Axis will be excluded from offset adjustment.</li> <li>■ <b>FALSE:</b> Offset of this axis is adjusted.</li> </ul> <b>Default:</b> FALSE	RUN LEVEL3	912
<b>unipolar</b> 400113 (optional parameter)	<b>Algebraic sign with analog unipolar drives</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>off:</b> Not a unipolar drive.</li> <li>■ <b>always positive:</b> A positive voltage is output for each direction of rotation (M3, M4).</li> <li>■ <b>always negative:</b> A negative voltage is output for each direction of rotation (M3, M4).</li> </ul> <b>Default:</b> off	RUN LEVEL3	1032

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgAxisHandwheel</b>			
Configuration of the handwheel for this axis			
<b>input</b> 400201	<b>Connection of the encoder handwheel</b>  <b>Format:</b> Selection menu  <b>Input:</b> none or X01 to X06 X35 to X38 X201 to X210  <b>Default:</b> none	PLC/Pgm run is locked  LEVEL3	1340
<b>hsciCclndex</b> 400210	<b>Index of the CC controller unit on the HSCI chain</b>  If more than one CC controller unit is used on the HSCI chain, enter the CC index for the position encoder input to which the handwheel is connected. Only the CCs are counted, further HSCI devices (e.g. PLs) are not relevant.  If only one CC is used, enter the value 0.  <b>Format:</b> Numerical value  <b>Input:</b> 0 to 4  <b>Default:</b> 0	PLC/Pgm run is locked  LEVEL3	1340
<b>countDir</b> 400202	<b>Axis-dependent counting direction of the handwheel</b>  The parameter applies both for the handwheel at the position input and for the serial handwheel connected to X23.  <b>Format:</b> Selection menu  <b>Input:</b>  ■ <b>positive:</b> Counting direction is positive  ■ <b>negative:</b> Counting direction is negative  <b>Default:</b> positive	PLC/Pgm run is locked  LEVEL3	1335
<b>distPerRevol</b> 400203	<b>Axis traverse per handwheel revolution</b>  Applies to <b>all</b> connected handwheels (handwheel at position input and at X23).  The value is multiplied by <b>MP_speedFactor</b> (CfgHandwheel).  <b>Format:</b> Numerical value  <b>Input:</b> Distance in [mm]  <b>Default:</b> 1.0 [mm]	PLC/Pgm run is locked  LEVEL3	1344

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>incrPerRevol</b> 400204 (optional parameter)	<b>Increments per revolution of handwheel at encoder input</b>  <b>Format:</b> Numerical value <b>Input:</b> Number of increments <b>Default:</b> 1 024	PLC/Pgm run is locked  LEVEL3	1342
<b>rasterPerRevol</b> 400205 (optional parameter)	<b>Detent steps per revolution of handwheel at encoder input</b>  <b>Format:</b> Numerical value <b>Input:</b> Number of detent positions 0: Handwheel without detent <b>Default:</b> 0	PLC/Pgm run is locked  LEVEL3	1342
<b>encoderSignal</b> 400206 (optional parameter)	<b>Signal amplitude at position encoder input for handwheel</b>  <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>1 Vpp:</b> The input signal of the encoder is a 1 V<sub>pp</sub> signal.</li> <li>■ <b>11 uA:</b> The input signal of the encoder is an 11 μA signal. This setting is not supported by the CC 61xx controller unit! If the value is set nevertheless, the control outputs the <b>0400: 11 uA not supported</b> error message.</li> <li>■ <b>TTL:</b> The input signal of the encoder is a TTL signal.</li> </ul> <b>Default:</b> 1 Vpp	PLC/Pgm run is locked  LEVEL3	1340
<b>encoderFreq</b> 400207 (optional parameter)	<b>Input frequency of position encoder input for handwheel</b>  <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>fast:</b> Input frequency is 350 kHz</li> <li>■ <b>slow:</b> Input frequency is 50 kHz</li> </ul> <b>Default:</b> fast	PLC/Pgm run is locked  LEVEL3	1341

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>encoderResistor</b> 400208 (optional parameter)	<b>Terminating resistor of position-encoder input for handwheel</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>without:</b> Without terminating resistor ■ <b>120 ohms:</b> With terminating resistor <b>Default:</b> without	PLC/Pgm run is locked  LEVEL3	1341
<b>decToSoftLimit</b> 400209 (optional parameter)	<b>Braking ramp for handwheel movement to software limit switch</b> (MP_swLimitSwitchPos or MP_swLimitSwitchNeg) <b>Format:</b> Numerical value <b>Input:</b> Braking ramp [m/s <sup>2</sup> ] or [1000°/s <sup>2</sup> ] for rotary axes <b>Default:</b> 0	PLC/Pgm run is locked  LEVEL3  597 110-03	1343
<b>CfgFeedLimits</b> Define the axis velocities and acceleration; For rotary axes and spindles, the velocity is specified in [°/min] and the acceleration in [1000°/s <sup>2</sup> ].			
<b>minFeed</b> 400301 MP3240.1	<b>Applies only to the main spindle: minimum spindle speed</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 36 000 000.0 [°/min] <b>Default:</b> 0 [°/min]	Allowed in strobe  LEVEL3	831
<b>maxFeed</b> 400302 MP1010, MP3515	<b>Maximum axis feed rate (rapid traverse) or maximum spindle speed</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 36 000 000.0 [mm/min] or [°/min] <b>Default:</b> 16 000.2 [mm/min] or [°/min]	Allowed in strobe  LEVEL3	831
<b>rapidFeed</b> 400303 MP1010	<b>Rapid traverse in manual mode</b> Maximum axis feed rate in manual mode, using the rapid traverse key. For rotary axes and spindles, the velocity is specified in [°/min]. <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 36 000 000.0 [mm/min] or [°/min] <b>Default:</b> 4 999.98 [mm/min]	Allowed in strobe  LEVEL3	832



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>manualFeed</b> 400304 MP1020	<b>Maximum manual feed rate</b> In the <b>E1. Handwheel</b> mode of operation, this feed rate is multiplied by <b>CfgHandwheel/feedFactor</b> . <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 36 000 000.0 [mm/min] or [°/min] <b>Default:</b> 4 999.98 [mm/min]	Allowed in strobe LEVEL3	832
<b>maxAcceleration</b> 400305 MP1060, MP3411	<b>Max. permissible axis acceleration during position control</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 001 to 1000 [m/s <sup>2</sup> ] or [1000°/s <sup>2</sup> ] <b>Default:</b> 3	Allowed in strobe LEVEL3	832
<b>maxAccSpeedCtrl</b> 400311 (optional parameter)	<b>Optional acceleration for the spindle with shaft speed control</b> This parameter is effective only with spindles. If 0 is entered or there is no parameter, the acceleration from <b>MP_maxAcceleration</b> is used. <b>Format:</b> Numerical value <b>Input:</b> Value [1000°/s <sup>2</sup> ] <b>Default:</b> 0	Allowed in strobe LEVEL3 597 110-03	1012
<b>maxDecSpeedCtrl</b> 400312 (optional parameter)	<b>Optional braking ramp for the spindle with shaft speed control</b> This parameter is effective only with spindles. If the value 0 is entered or the parameter is not available, the value from <b>MP_maxAccSpeedCtrl</b> will be used for the brake acceleration. If <b>MP_maxAccSpeedCtrl</b> is also 0 or not present, the value from <b>MP_maxAcceleration</b> will be used. <b>Format:</b> Numerical value <b>Input:</b> Value [1000°/s <sup>2</sup> ] <b>Default:</b> 0	Allowed in strobe LEVEL3 597 110-03	1012
<b>limitSpeedAcc</b> 400313 (optional parameter)	<b>Limit speed for reduction of the acceleration</b> Acceleration of the spindle with a "kink" in the acceleration curve: The parameter sets the absolute limit speed above which the acceleration is reduced. <b>Format:</b> Numerical value <b>Input:</b> Value [°/min] or [mm/min] <b>Default:</b> 0	Allowed in strobe LEVEL3 597 110-05	1013

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>limitSpeedDec</b> 400314 (optional parameter)	<b>Limit speed for reduction of the braking deceleration</b> Braking of the spindle with a "kink" in the deceleration curve: The parameter sets the absolute limit speed above which the braking deceleration is reduced. <b>Format:</b> Numerical value <b>Input:</b> Value [°/min] or [mm/min] <b>Default:</b> 0	Allowed in strobe LEVEL3 597 110-05	1013
<b>limitAccSpeedCtrl</b> 400315 (optional parameter)	<b>Absolute acceleration. Effective above MP_limitSpeedAcc</b> Acceleration of the spindle with a "kink" in the acceleration curve: Specifies the absolute acceleration of the spindle, which becomes effective above the speed defined with <b>MP_limitSpeedAcc</b> . <b>Format:</b> Numerical value <b>Input:</b> Value [m/s <sup>2</sup> ] <b>Default:</b> 0	Allowed in strobe LEVEL3 597 110-05	1013
<b>limitDecSpeedCtrl</b> 400316 (optional parameter)	<b>Absolute deceleration during braking. Effective above MP_limitSpeedDec</b> Braking of the spindle with a "kink" in the deceleration curve: Specifies the absolute deceleration during braking, which becomes effective above the speed defined with <b>MP_limitSpeedDec</b> . <b>Format:</b> Numerical value <b>Input:</b> Value [m/s <sup>2</sup> ] <b>Default:</b> 0	Allowed in strobe LEVEL3 597 110-05	1013
<b>M19MaxSpeed</b> MP3520.1	<b>Maximum rotational speed limit for M19</b> <b>Format:</b> Numerical value <b>Input:</b> 100 to 20 000 [rpm] <b>Default:</b> 1 000 [rpm]	Allowed in strobe LEVEL3	1003
<b>M19NcSpeed</b> 400310	<b>Nominal speed for an oriented spindle stop commanded by the NC</b> <b>Format:</b> Numerical value <b>Input:</b> Shaft speed [rpm] <b>Default:</b> 8	Allowed in strobe LEVEL3 597 110-03	1003

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>nominalSpeed</b> 400308 (optional parameter)	<b>Rated speed for the gear range</b> Enter the greatest programmable shaft speed at which this spindle parameter set is to be used. If a shaft speed greater than the given one is programmed, the next higher gear range is switched to.  <b>Format:</b> Numerical value <b>Input:</b> Shaft speed [rpm] <b>Default:</b> 0	Allowed in strobe  LEVEL3	1570
<b>restoreFeed</b> 400309 (optional parameter)	<b>Feed rate for returning to the contour</b> <b>Format:</b> Numerical value <b>Input:</b> Feed rate [mm/min] or [°/min] <b>Default:</b> 0	Allowed in strobe  LEVEL3  597 110-02	623



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgReferencing</b> Axis parameters for the reference run; For rotary axes and spindles, the velocity is specified in [°/min].			
<b>refType</b> 400401 MP1350	<b>Sequence for finding the reference mark</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>None:</b> No traversing of the reference mark. If the reference run with the spindle is performed via a trip dog, this value must be set.</li> <li>■ <b>Switch, changing Dir:</b> For linear axes with speed encoder; reference run with NC start</li> <li>■ <b>Switch, no changing Dir:</b> For linear axes with speed encoder; reference run with NC start</li> <li>■ <b>without Switch:</b> For spindle, rotary table with angle encoder; reference run with NC start</li> <li>■ <b>distance coded:</b> For distance-coded linear encoders; reference run with NC start</li> <li>■ <b>distance coded + on the fly:</b> For distance-coded linear encoders; reference run with axis-direction keys or NC start</li> <li>■ <b>without switch + on the fly:</b> For spindle; reference run with M3, M4</li> <li>■ <b>Endat Encoder:</b> For axes with EnDat encoder; reference-mark traverse not necessary</li> </ul> <b>Default:</b> Switch, changing Dir	RUN LEVEL3	798
<b>endatSerial</b> 400402 (optional parameter)	<b>Connecting incremental encoders via the EIB</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> An incremental encoder is connected to the serial EnDat 2.2 interface via the EIB.</li> <li>■ <b>FALSE:</b> No EIB is used.</li> </ul>	RUN LEVEL3	647



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>refPosition</b> 400403 MP960, MP3430	<b>Position of the machine datum</b> Position given with respect to scale reference point. For encoders with distance-coded reference marks, with respect to the zero reference mark. For EnDat encoders, relative to the absolute encoder datum. <b>Format:</b> Numerical value <b>Input:</b> –100 000.0 to + 100 000.0 [mm] <b>Default:</b> 100.0 [mm]	RUN LEVEL3	805
<b>refSwitchActive</b> 400404	<b>Active level of the trip dog for reference end position</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>high:</b> Reference-end-position trip dog is active if PP_AxReferenceEndPosition = 1</li> <li>■ <b>low:</b> Reference-end-position trip dog is active if PP_AxReferenceEndPosition = 0</li> </ul> <b>Default:</b> high	RUN LEVEL3	799
<b>externRefPulse</b> 400413 (optional parameter)	<b>Referencing with external reference signal</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>Off:</b> The reference signal of the connected motor encoder or the position encoder is used.</li> <li>■ <b>spindleRef (X30):</b> On systems with HSCI, the reference signal at –SP.REF+ and –SP.REF– of the external PL is evaluated; on systems with MC 320 or MC 42x the reference signal at input X30 is evaluated.</li> </ul> <b>Default:</b> Off	RUN LEVEL3 597 110-04	1008
<b>endatDiff</b> 400405	<b>Permissible difference of EnDat encoders during switch-on</b> <b>Format:</b> Numerical value <b>Input:</b> –100 000.0 to + 100 000.0 [mm] <b>Default:</b> 0.0 [mm]	RUN LEVEL3	951

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>refFeedLow</b> 400406 MP1330	<b>Low speed when finding the reference mark</b> Depending on <b>MP_refType</b> , this low speed is used for finding the reference mark. <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 36 000 000.0 [mm/min] <b>Default:</b> 600.0 [mm/min]	RUN LEVEL3	799
<b>refFeedHigh</b> 400407 MP1330	<b>High speed when finding the reference mark</b> Depending on <b>MP_refType</b> , this high speed is used for finding the reference mark. <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 36 000 000.0 [mm/min] <b>Default:</b> 1200.0 [mm/min]	RUN LEVEL3	799
<b>refDirection</b> 400408 MP1320	<b>Traversing direction for finding the reference mark</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>positive:</b> Positive traverse direction ■ <b>negative:</b> Negative traverse direction <b>Default:</b> Negative	RUN LEVEL3	799
<b>moveAfterRef</b> 400409	<b>Activate movement after finding the reference mark</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>on:</b> Positioning after reference-mark traverse is active ■ <b>off:</b> No positioning after reference-mark traverse <b>Default:</b> off	RUN LEVEL3	806

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>moveAfterRefType</b> 400410	<p><b>Type of movement after finding the reference mark</b></p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>absolute:</b> Absolute positioning. This function is mainly intended for positioning rotary tables. Please ensure that no collision occurs as a result of this positioning. The software limit switches are already active.</li> <li>■ <b>relative:</b> Incremental positioning</li> <li>■ <b>HirthRasterPos:</b> Approach next Hirth grid position in positive direction.</li> <li>■ <b>HirthRasterNeg:</b> Approach next Hirth grid position in negative direction.</li> </ul> <p><b>Default:</b> absolute</p>	RUN LEVEL3	806
<b>moveAfterRefPos</b> 400411	<p><b>Position for positioning after traversing the reference mark</b></p> <p><b>Format:</b> Numerical value</p> <p><b>Input:</b> -100 000.0 to + 100 000.0 [mm]</p> <p><b>Default:</b> 0.0 [mm]</p>	RUN LEVEL3	806
<b>moveAfterRefFeed</b> 400412	<p><b>Feed rate for positioning after traversing the reference mark</b></p> <p><b>Format:</b> Numerical value</p> <p><b>Input:</b> 10.0 to 36 000 000.0 [mm/min] or [°/min]</p> <p><b>Default:</b> 6000.0 [mm/min] or [°/min]</p>	RUN LEVEL3	806

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgPositionLimits</b>			
Axis-specific setting of software limit switches; The MANUALplus 620 currently supports only one traverse range.			
<b>swLimitSwitchPos</b> 400501 MP910	<b>Positive software limit switch</b>  If positive and negative software limit switches = 0, monitoring is switched off.  <b>Format:</b> Numerical value <b>Input:</b> -100 000.0 to + 100 000.0 [mm] <b>Default:</b> 0.0 [mm]	RUN LEVEL3	689
<b>swLimitSwitchNeg</b> 400502 MP920	<b>Negative software limit switch</b>  If positive and negative software limit switches = 0, monitoring is switched off.  <b>Format:</b> Numerical value <b>Input:</b> -100 000.0 to + 100 000.0 [mm] <b>Default:</b> 0.0 [mm]	RUN LEVEL3	689
<b>lubricationDist</b> 400503 MP4050	<b>Path-dependent lubrication of axis</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.000 to +100 000.000 [mm] 0: No output of lubrication pulse to PLC  <b>Default:</b> 100.0 [mm]	RUN LEVEL3	690
<b>CfgControllerAuxil</b>			
General parameters for the position controller			
<b>driveOffLagMonitor</b> 400601	<b>Following-error monitoring with drive switched off</b>  <b>Format:</b> Selection menu <b>Input:</b> ■ <b>on:</b> Monitoring of hanging axes is active ■ <b>off:</b> Monitoring of hanging axes is not active <b>Default:</b> off	RUN LEVEL3	950
<b>checkPosStandstill</b> 400602 MP1110	<b>Standstill monitoring</b> (gross positioning error x D)  <b>Format:</b> Numerical value <b>Input:</b> 0.001 to 100 000.000 [mm] 0: Monitoring is switched off  <b>Default:</b> 10 000.000 [mm]	RUN LEVEL3	955



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>maxPosDiff</b> 400605 (optional parameter)	<b>Maximum position difference between position and shaft-speed measuring system</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 100 000.000 [mm] <b>Default:</b> 0	RUN LEVEL3 597 110-03	952
<b>posDiffCountDir</b> 400604 (optional parameter)	<b>Counting direction of the motor encoder</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>positive:</b> Motor encoder counts in positive direction ■ <b>negative:</b> Motor encoder counts in negative direction <b>Default:</b> positive	RUN LEVEL3 597 110-03	952
<b>reserve1</b> 400606 (optional parameter)	<b>Parameter reserved, do not assign</b>	RUN LEVEL3	–
<b>reserve2</b> 400607 (optional parameter)	<b>Parameter reserved, do not assign</b>	RUN LEVEL3	–
<b>reserve3</b> 400608 (optional parameter)	<b>Parameter reserved, do not assign</b>	RUN LEVEL3	–

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgEncoderMonitor</b> Hardware monitoring functions for the position encoders			
<b>checkAbsolutPos</b> 400701 MP20.0	<b>Monitoring the absolute position for distance-coded position encoder</b> <b>Format:</b> Selection menu <b>Input:</b> <input type="checkbox"/> <b>on:</b> Monitor the absolute position <input type="checkbox"/> <b>off:</b> No monitoring <b>Default:</b> off	RUN LEVEL3	666
<b>checkSignalLevel</b> 400702 MP20.1	<b>Monitoring the amplitude of the position-encoder signal</b> <b>Format:</b> Selection menu <b>Input:</b> <input type="checkbox"/> <b>on:</b> Monitor the encoder amplitude <input type="checkbox"/> <b>off:</b> No monitoring <b>Default:</b> off	RUN LEVEL3	666
<b>checkFrequency</b> 400703 MP20.2	<b>Monitoring the edge separation of the position encoder</b> <b>Format:</b> Selection menu <b>Input:</b> <input type="checkbox"/> <b>on:</b> Monitor the encoder frequency <input type="checkbox"/> <b>off:</b> No monitoring <b>Default:</b> off	RUN LEVEL3	666



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>checkRefDistance</b> 400704 MP2221 (optional parameter)	<b>Monitoring the reference mark of the spindle speed encoder</b> Monitoring the datum-datum distance of the spindle <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>on:</b> Monitor the reference mark of the speed encoder</li> <li>■ <b>off:</b> No monitoring</li> </ul> <b>Default:</b> off	RUN LEVEL3	1010
<b>movementThreshold</b> 400705 MP1140	<b>Threshold above which the movement monitoring functions</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 36 000 000.0 [mm/min] or [°/min] 0: Monitoring switched off <b>Default:</b> 199.98	RUN LEVEL3	954
<b>thresholdDistance</b> 400706 (optional parameter)	<b>Tolerance at and above which the following error is included</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 36 000 000.0 [mm] or [°] <b>Default:</b> 5	RUN LEVEL3	954

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgSpindle</b> Machine parameters for configuring the spindle; Only define for an axis that is configured as spindle.			
<b>fastInputType</b> 401501	<b>Treatment of the fast input for the spindle</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>none:</b> Spindle does not have any trip dog for reference end position (no signal) or the signal is not evaluated.</li> <li>■ <b>forStopping:</b> For M19 without rotary encoder, the spindle is stopped at the trip dog upon receiving this input signal.</li> <li>■ <b>forReferencing:</b> The input signal is used as spindle reference signal. The MANUALplus 620 handles the signal of the trip dog for reference end position as reference pulse of the encoder.</li> </ul> <b>Default:</b> none	RUN LEVEL3	1006
<b>fastInput</b> 401502 (optional parameter)	<b>Number of the fast PLC input for the spindle reference run</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 32767	RUN LEVEL3	1006
<b>zeroPosEdge</b> 401503 (optional parameter)	<b>Evaluation of the edge</b> Cam edge indicating the position of 0° for positive direction of spindle rotation. <b>Eingabe:</b> <ul style="list-style-type: none"> <li>■ <b>zeroOne:</b> Zero-one transition</li> <li>■ <b>oneZero:</b> One-zero transition</li> </ul>	RUN LEVEL3	1007
<b>stopOnSwitchSpeed</b> 401504 (optional parameter)	<b>Shaft speed for positioning to the trip dog</b> If the value <b>forStopping</b> is entered in <b>MP_fastInputType</b> , the shaft speed for positioning to the trip dog must be entered here. <b>Format:</b> Numerical value <b>Input:</b> Shaft speed [rpm] Max. 9 decimal places <b>Default:</b> 0	RUN LEVEL3	1007

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>gearShiftSpeed</b> 401505 (optional parameter)	<b>Speed for gear shifting</b> <b>Format:</b> Numerical value <b>Input:</b> Shaft speed [rpm] Max. 9 decimal places	RUN LEVEL3 597 110-03	1571
<b>gearShiftVoltage</b> 401506 (optional parameter)	<b>Nominal voltage value output for gear shifting</b> <b>Format:</b> Numerical value <b>Input:</b> Voltage in volts [V] Max. 9 decimal places	RUN LEVEL3	1571
<b>changeTurnDir</b> 401509 (optional parameter)	<b>Rotational direction reversal with M3 and M4</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> Reversal of rotational direction is active with M3/M4 ■ <b>FALSE:</b> Reversal of rotational direction is not active with M3/M4 <b>Default:</b> TRUE	RUN LEVEL3 597 110-05	664
<b>kvFactorM19</b> 401510 (optional parameter)	<b>kv factor for oriented spindle stop</b> Only effective with active spindle orientation (M19); replaces the value in <b>CfgPosControl/kvFactor</b> . If the parameter is not defined or 0, the value in <b>CfgPosControl/kvFactor</b> is used. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 1000.000 [1/s] <b>Default:</b> 0.000 [1/s]	RUN LEVEL3	1004
<b>kvFactorTapping</b> 401511 (optional parameter)	<b>kv factor for tapping</b> Only effective during thread cutting; replaces the value in <b>CfgPosControl/kvFactor</b> . If the parameter is not defined or 0, the value in <b>CfgPosControl/kvFactor</b> is used. <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 1000.000 [1/s] <b>Default:</b> 0.000 [1/s]	RUN LEVEL3	1039
<b>kvFactorSync</b> 401512 (optional parameter)	<b>kv factor for spindle synchronism</b> Reserved, do not assign.	RUN LEVEL3	–

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgDeadStop</b>			
Parameters for traverse to a fixed stop; Enter the parameters for all axes of the NC channel that are supposed move to a fixed stop.			
<b>deadStopLag</b> 403001 (optional parameter)	<b>Max. permissible following error</b>  This following error limit is effective with the "traverse to fixed stop" command at constant velocity.  During acceleration the parameter <b>CfgPosControl/servoLagMax2</b> is also in effect in this operating mode.  <b>Format:</b> Numerical value <b>Input:</b> Following error [mm] <b>Default:</b> 0.01	RUN LEVEL3	1465
<b>forthTorqueFactor</b> 403003 (optional parameter)	<b>Conversion factor of the programmed force to a torque</b>  Because a maximum force is produced, but physically only the motor torque can be limited, the force is converted with this factor to torque.  <b>Format:</b> Numerical value <b>Input:</b> 0.1 to 1000 <b>Default:</b> 1	RUN LEVEL3	1468
<b>minTorque</b> 403004 (optional parameter)	<b>Min. limit of current with quill function</b>  This no-load current (synchronous motor) or rated current (asynchronous motor) cannot fall below this percentage.  <b>Format:</b> Numerical value <b>Input:</b> 0 to 100 [%] <b>Default:</b> 20	RUN LEVEL3	1469
<b>maxTorque</b> 403005 (optional parameter)	<b>Max. limit of current with quill function</b>  This no-load current (synchronous motor) or rated current (asynchronous motor) cannot exceed this percentage.  <b>Format:</b> Numerical value <b>Input:</b> 0 to 100 [%] <b>Default:</b> 100	RUN LEVEL3	1469

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>torqueTolerance</b> 403006 (optional parameter)	<b>Tolerance window for status message</b> If the instantaneously consumed current of the axis is within this range of the no-load current (synchronous motor) or the rated current (asynchronous motor), a status report to the PLC is generated. <b>Format:</b> Numerical value <b>Input:</b> 0 to 100 [%] <b>Default:</b> 20	RUN LEVEL3	1469
<b>CfgPositionFilter</b> Axis-specific configuration of the nominal position value filters; Overwrites the default filters in CfgFilter. <b>axisPosition:</b> Axis-specific configuration of the nominal position value filter for all linear axes			
<b>shape</b> 401606	<b>Shape of the nominal position value filter</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>Off:</b> Filter is off</li> <li>■ <b>Average:</b> Mean-value filter</li> <li>■ <b>Triangle:</b> Single filter</li> <li>■ <b>HSC:</b> HSC filter (High Speed Cutting) (setting for "accuracy" criterion)</li> <li>■ <b>Advanced HSC:</b> Advanced HSC filter (High Speed Cutting) (setting for "surface" criterion)</li> </ul>	Allowed in strobe LEVEL3 597 110-05	817
<b>frequency</b> 401606	<b>Cutoff frequency of the nominal position value filter</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 1000 [Hz] Max. 9 decimal places <b>Default:</b> 20 [Hz]	Allowed in strobe LEVEL3 597 110-05	817

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>hscMode</b> 401606	<p><b>Operating mode of the nominal position value filter</b></p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>Smoothing:</b> Mode for finishing operations</li> <li>■ <b>Roughing:</b> Mode for roughing operations</li> </ul> <p><b>Default:</b> Smoothing</p>	Allowed in strobe LEVEL3 597 110-05	818
<b>manualFilterOrder</b> 401605	<p><b>Axis-specific order of the mean-value filter for the Manual operating modes.</b></p> <p>Overwrites the value in CfgFilter/defaultManualOrder.</p> <p>Only odd integral input values are permitted. If you enter an even number, the MANUALplus 620 displays an error message.</p> <p><b>Format:</b> Numerical value</p> <p><b>Input:</b> 1 to 251</p> <p><b>Default:</b> 11</p>	Allowed in strobe LEVEL3	818
<b>handwheelFilterOrder</b> 401608 (optional parameter)	<p><b>Axis-specific order of the mean-value filter in the EI. Handwheel operating mode</b></p> <p>Overwrites the value in <b>MP_manualFilterOrder</b> or <b>CfgFilter/defaultManualOrder</b>.</p> <p>Only odd integral input values are permitted. If you enter an even number, the MANUALplus 620 displays an error message.</p> <p><b>Format:</b> Numerical value</p> <p><b>Input:</b> 1 to 251</p> <p><b>Default:</b> 11</p>	Allowed in strobe LEVEL3 597 110-05	819



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgLaAxis</b>			
Axis-dependent parameters for look-ahead; Please keep in mind that the axis jerk is added to the path jerk (which can act in the same direction). <b>MP_axFilterErrWeight</b> is used to account for the behavior of rotary axes with a large effective radius.			
<b>axTransJerk</b> 401701 MP1230, MP1231, MP1232, MP1233, MP1240, MP1241, MP1242, MP1243	<b>Maximum axis jerk</b> Max. permissible axis-specific jerk at corners or tangential transitions, e.g. from a straight line to a circular arc. <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 1 000 000.0 [m/s <sup>3</sup> ] <b>Default:</b> 0.1 [m/s <sup>3</sup> ]	Allowed in strobe LEVEL3	833
<b>axPathJerk</b> 401703 MP1085 (optional parameter)	<b>Axis-specific maximum jerk on path contours</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 1 000 000.0 [m/s <sup>3</sup> ] <b>Default:</b> 5	Allowed in strobe LEVEL3	835
<b>axPathJerkHi</b> 401704 MP1086 (optional parameter)	<b>Axis-specific maximum jerk during rapid traverse</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 1 000 000.0 [m/s <sup>3</sup> ] <b>Default:</b> 5	Allowed in strobe LEVEL3	835
<b>axFilterErrWeight</b> 401702	<b>Factor for filter error (for rotary axes)</b> <b>Format:</b> Numerical value <b>Input:</b> 0.01 to 100.00 [factor] <b>Default:</b> 1.00 (for linear axes)	Allowed in strobe LEVEL3	837

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgAxisComp</b>			
Axis compensation parameters			
<b>active</b> 401801	<b>Switch on/off all axis compensations</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>on:</b> Backlash compensation, linear or nonlinear axis-error compensation, reversal-error compensation and thermal compensation are all active ■ <b>off:</b> Axis compensations are not active. <b>Default:</b> off	RUN LEVEL3	706
<b>backLash</b> 401802 MP710	<b>Backlash compensation; Backlash outside of the control loop</b> <b>Format:</b> Selection menu <b>Input:</b> -1.0000 to +1.0000 [mm] or [°] <b>Default:</b> 0	RUN LEVEL3	709
<b>linearCompValue</b> 401803 MP720	<b>Linear axis error compensation</b> <b>Format:</b> Numerical value <b>Input:</b> -1.000 to +1.000 [mm/m] <b>Default:</b> 0	RUN LEVEL3	712
<b>compType</b> 401804 MP730	<b>Selection of linear/nonlinear axis error compensation</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>linear:</b> Linear axis error compensation is active ■ <b>non-linear:</b> Nonlinear axis error compensation is active <b>Default:</b> linear	RUN LEVEL3	712
<b>filterTime</b> 401805 MP709 (optional parameter)	<b>Time constant for backlash compensation</b> <b>Format:</b> Numerical value <b>Input:</b> 1 to 1000 [ms] 0: Compensation is output as a step <b>Default:</b> 0	RUN LEVEL3 597 110-03	709

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>posCtrlRevErr</b> 401806 MP750 (optional parameter)	<b>Backlash compensation (distance)</b> <b>Format:</b> Numerical value <b>Input:</b> -9.9999 to +9.9999 [mm] or [°] <b>Default:</b> 0	RUN LEVEL3 597 110-03	710
<b>posCtrlRevErrTime</b> 401807 MP752 (optional parameter)	<b>Backlash compensation (time)</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 1000 [ms] <b>Default:</b> 0	RUN LEVEL3 597 110-03	710
<b>CfgSpeedControl</b> Settings for the integrated digital speed controller			
<b>vCtrlPropGain</b> 400901 MP2500.x, MP2501.x	<b>Proportional factor of the speed controller</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 1 000 000 [As/rev.] <b>Default:</b> 1	Allowed in strobe LEVEL 3	854
<b>vCtrlIntGain</b> 400902 MP2510.x, MP2511.x	<b>Integral factor of the speed controller</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 10 000 000 [A/rev.] <b>Default:</b> 100	Allowed in strobe LEVEL 3	854
<b>vCtrlIntTime</b> 400903 MP2512.x	<b>Limit of integral factor of the speed controller</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 10 000 000 [A/rev.] <b>Default:</b> 100	Allowed in strobe LEVEL 3	868
<b>vCtrlDiffGain</b> 400904 MP2520.x, MP2521.x	<b>Differential factor of the speed controller</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 1 [As <sup>2</sup> /rev.] <b>Default:</b> 0	Allowed in strobe LEVEL 3	856
<b>vCtrlFiltLowPassT</b> 400905 MP2530.x, MP2531.x	<b>PT2 element of the speed controller (second-order time delay element)</b> Try compensation with low-pass filter first (MP_vCtrlEnclInputFilt). <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 1 [s] <b>Default:</b> 0	Allowed in strobe LEVEL 3	857

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>vCtrlEnclInputFilt</b> 400906 MP2560.x, MP2561.x	<b>Filter order of the FIR filter (low-pass filter)</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 20 0: No low-pass filter 1: 1st-order low-pass filter ... 20: 20th-order low-pass filter <b>Default:</b> 0	Allowed in strobe LEVEL 3	861
<b>vCtrlFiltType1</b> 400907 MP2562.x (optional parameter)	<b>Filter type for filter 1</b> <b>Format:</b> Numerical value <b>Input:</b> 0: Filter deactivated 1: PT2 low-pass (speed ctrl.) 2: Band-rejection filter (speed ctrl.) 3: Phase increase (speed ctrl.) 11: PT2 low-pass (position ctrl.) 12: Band-rejection filter (position ctrl.) 13: Phase increase (position ctrl.) <b>Default:</b> 0	Allowed in strobe LEVEL 3	860
<b>vCtrlFiltFreq1</b> 400908 MP2550.x, MP2551.x, MP2552.x	<b>Center frequency of the band-rejection filter for filter 1</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 5000 [Hz] <b>Default:</b> 0	Allowed in strobe LEVEL 3	860
<b>vCtrlFiltBandWidth1</b> 400909 MP2572.x (optional parameter)	<b>Bandwidth of band-rejection filter for filter 1</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 5000 [Hz] <b>Default:</b> 0	Allowed in strobe LEVEL 3	860
<b>vCtrlFiltDamping1</b> 400910 MP2540.x, MP2541.x MP2542.x	<b>Damping the band-rejection filter for filter 1</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 40 [dB] <b>Default:</b> 0	Allowed in strobe LEVEL 3	860

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>vCtrlFiltType2</b> 400911 MP2563.x (optional parameter)	<b>Filter type for filter 2</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0: Filter deactivated 1: PT2 low-pass (speed ctrl.) 2: Band-rejection filter (speed ctrl.) 3: Phase increase (speed ctrl.) 11: PT2 low-pass (position ctrl.) 12: Band-rejection filter (position ctrl.) 13: Phase increase (position ctrl.)  <b>Default:</b> 0	Allowed in strobe LEVEL 3	860
<b>vCtrlFiltFreq2</b> 400912 MP2553.x (optional parameter)	<b>Center frequency of the band-rejection filter for filter 2</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0.000 000 000 to 5000 [Hz]  <b>Default:</b> 0	Allowed in strobe LEVEL 3	860
<b>vCtrlFiltBandWidth2</b> 400913 MP2573.x (optional parameter)	<b>Bandwidth of band-rejection filter for filter 2</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0.000 000 000 to 5000 [Hz]  <b>Default:</b> 0	Allowed in strobe LEVEL 3	860
<b>vCtrlFiltDamping2</b> 400914 MP2543.x (optional parameter)	<b>Damping the band-rejection filter for filter 2</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0.000 000 000 to 40 [dB]  <b>Default:</b> 0	Allowed in strobe LEVEL 3	860
<b>vCtrlFiltType3</b> 400915 MP2564.x (optional parameter)	<b>Filter type for filter 3</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0: Filter deactivated 1: PT2 low-pass (speed ctrl.) 2: Band-rejection filter (speed ctrl.) 3: Phase increase (speed ctrl.) 11: PT2 low-pass (position ctrl.) 12: Band-rejection filter (position ctrl.) 13: Phase increase (position ctrl.)  <b>Default:</b> 0	Allowed in strobe LEVEL 3	860
<b>vCtrlFiltFreq3</b> 400916 MP2554.x (optional parameter)	<b>Center frequency of the band-rejection filter for filter 3</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0.000 000 000 to 5000 [Hz]  <b>Default:</b> 0	Allowed in strobe LEVEL 3	860

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>vCtrlFiltBandWidth3</b> 400917 MP2574.x (optional parameter)	<b>Bandwidth of the band-rejection filter for filter 3</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 5000 [Hz] <b>Default:</b> 0	Allowed in strobe  LEVEL 3	860
<b>vCtrlFiltDamping3</b> 400918 MP2544.x (optional parameter)	<b>Damping the band-rejection filter for filter 3</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 40 [dB] <b>Default:</b> 0	Allowed in strobe  LEVEL 3	860
<b>vCtrlFiltType4</b> 400919 MP2565.x (optional parameter)	<b>Filter type for filter 4</b>  <b>Format:</b> Numerical value <b>Input:</b> 0: Filter deactivated 1: PT2 low-pass (speed ctrl.) 2: Band-rejection filter (speed ctrl.) 3: Phase increase (speed ctrl.) 11: PT2 low-pass (position ctrl.) 12: Band-rejection filter (position ctrl.) 13: Phase increase (position ctrl.)  <b>Default:</b> 0	Allowed in strobe  LEVEL 3	860
<b>vCtrlFiltFreq4</b> 400920 MP2555.x (optional parameter)	<b>Center frequency of the band-rejection filter for filter 4</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 5000 [Hz] <b>Default:</b> 0	Allowed in strobe  LEVEL 3	860
<b>vCtrFiltBandWidth4</b> 400921 MP2575.x (optional parameter)	<b>Bandwidth of the band-rejection filter for filter 4</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 5000 [Hz] <b>Default:</b> 0	Allowed in strobe  LEVEL 3	860
<b>vCtrlFiltDamping4</b> 400922 MP2545.x (optional parameter)	<b>Damping the band-rejection filter for filter 4</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 40 [dB] <b>Default:</b> 0	Allowed in strobe  LEVEL 3	860

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>vCtrlFiltType5</b> 400923 MP2566.x (optional parameter)	<b>Filter type for filter 5</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0: Filter deactivated 1: PT2 low-pass (speed ctrl.) 2: Band-rejection filter (speed ctrl.) 3: Phase increase (speed ctrl.) 11: PT2 low-pass (position ctrl.) 12: Band-rejection filter (position ctrl.) 13: Phase increase (position ctrl.)  <b>Default:</b> 0	Allowed in strobe  LEVEL 3	860
<b>vCtrlFiltFreq5</b> 400924 MP2556.x (optional parameter)	<b>Center frequency of the band-rejection filter for filter 5</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0.000 000 000 to 5000 [Hz]  <b>Default:</b> 0	Allowed in strobe  LEVEL 3	860
<b>vCtrlFiltBandWidth5</b> 400925 MP2576.x (optional parameter)	<b>Bandwidth of band-rejection filter for filter 5</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0.000 000 000 to 5000 [Hz]  <b>Default:</b> 0	Allowed in strobe  LEVEL 3	860
<b>vCtrlFiltDamping5</b> 400926 MP2546.x (optional parameter)	<b>Damping the band-rejection filter for filter 5</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0.000 000 000 to 40 [dB]  <b>Default:</b> 0	Allowed in strobe  LEVEL 3	860
<b>vCtrlSwitchOffDelay</b> 400927 MP2308.x (optional parameter)	<b>Time between the braking signal and switch-off of the controller (overlap time)</b>  Time in seconds [s] between output of the braking signal BRK and switching off of the controller (overlap time)  <b>Format:</b> Numerical value  <b>Input:</b> 0.000 000 000 to 5 [s]  <b>Default:</b> 0	Allowed in strobe  LEVEL 3	984

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>vCtrlSwithOnDelay</b> 400928 MP2309.x (optional parameter)	<p><b>The time after switch-on after which the controller parameters are adapted for a locked brake.</b></p> <p>The time in seconds [s] after switch-on in which the controller parameters are adapted for a locked brake. For the defined time, the parameters of the control loop are reduced after the motor switch-on in order to prevent oscillations.</p> <p><b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 5 [s] <b>Default:</b> 0</p>	Allowed in strobe LEVEL 3 597 110-05	984
<b>vCtrlTimeSwitchOff</b> 400928 MP2173.x (optional parameter)	<p><b>Pulse switch-off of the power modules</b></p> <p>Monitoring time for the braking process. If after the time has expired the axes are still in motion, the pulses of the power modules are switched off.</p> <p>The time must be greater than the maximum electrical braking time for the axis/spindle.</p> <p><b>Format:</b> Numerical value <b>Input:</b> 0.100 000 000 to 100 [s] <b>Default:</b> 3 [s]</p>	Allowed in strobe LEVEL 3 597 110-05	991
<b>vCtrlSpinSpeedTol</b> 400930 MP3540 (optional parameter)	<p><b>Permissible spindle speed shortfall</b></p> <p>Permissible lower limit of the actual spindle speed multiplied by a percentage of the nominal speed. If the current spindle speed falls below the defined value, the MANUALplus 620 outputs an error message.</p> <p><b>Format:</b> Numerical value <b>Input:</b> 0 to 100 [%] 0: Monitoring inactive <b>Default:</b> 0</p>	Allowed in strobe LEVEL 3 597 110-05	1026
<b>vCtrlSpinMinSpeed</b> 400931 MP3542 (optional parameter)	<p><b>Minimum spindle speed as of which the monitoring in MP_vCtrlSpinSpeedTol becomes active</b></p> <p><b>Format:</b> Numerical value <b>Input:</b> 0 to 16 666.666 666 667 [rpm] 0: Monitoring inactive <b>Default:</b> 0</p>	Allowed in strobe LEVEL 3 597 110-05	1026



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>delayEmStopSpin</b> 400933 MP3550 (optional parameter)	<b>Delay of emergency-stop reaction of spindles</b> <b>Format:</b> Numerical value <b>Input:</b> 0.001 to 0.1 [s] 0: Delay not active <b>Default:</b> 0	Allowed in strobe LEVEL 3 597 110-05	1026
<b>vCtrlEnInputFunc</b> 400932 MP2561.x (optional parameter)	<b>Maximum input frequency for motor encoders (only as of CC 61xx)</b> <b>Format:</b> Bit-encoded value <b>Input:</b> ■ <b>Bit 0 = 0:</b> Maximum input frequency for motor encoders = 400 kHz ■ <b>Bit 0 = 1:</b> Maximum input frequency for motor encoders = 800 kHz ■ <b>Bit 1 to bit 32:</b> Reserved, assign 0 <b>Default:</b> 0	Allowed in strobe LEVEL 3 597 110-05	1044
<b>CfgCurrentControl</b> Settings for the integrated digital current controller			
<b>iCtrlPropGain</b> 401001 MP2420.x, MP2421.x	<b>Proportional component for digital current controller</b> <b>Format:</b> Numerical value <b>Input:</b> 0.00 to 9999.99 [V/A] <b>Default:</b> 0	Allowed in strobe LEVEL 3	886
<b>iCtrlIntGain</b> 401002 MP2430.x, MP2431.x	<b>Integral-action component for digital current controller</b> <b>Format:</b> Numerical value <b>Input:</b> 0.00 to 9 999 999.99 [V/As] <b>Default:</b> 0	Allowed in strobe LEVEL 3	886
<b>iCtrlPwmType</b> 401003 MP2182.x (optional parameter)	<b>Current controller cycle time</b> The value from CfgPowerStage/ampPwmFreq is used as the PWM frequency $f_{PWM}$ . <b>Format:</b> Numerical value <b>Input:</b> 0: Cycle time = $1 / (2 \cdot f_{PWM})$ 1: Cycle time = $1 / f_{PWM}$ 2: Reserved <b>Default:</b> 0	Allowed in strobe LEVEL 3	1049

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>iCtrlMotVRedFact</b> 401005 MP2210.x (optional parameter)	<b>Factor for reducing the magnetizing current during idle running (only CC 61xx/UEC 11x)</b> <b>Format:</b> Numerical value <b>Input:</b> <b>Default:</b>	Allowed in strobe LEVEL 3	863
<b>iCtrlMotVRedSpeed</b> 401006 MP2211.x (optional parameter)	<b>Reserved, do not assign</b> <b>Format:</b> Numerical value <b>Input:</b> Reserved, do not assign <b>Default:</b> 0	Allowed in strobe LEVEL 3	–
<b>iCtrlDiffFreqFF</b> 401007 MP2440.x (optional parameter)	<b>Only CC 61xx/UEC 11x:</b> <b>Cutoff frequency of the feedforward current controller</b> <b>Format:</b> Numerical value <b>Input:</b> 0 Hz to $f_g$ The cutoff frequency $f_g$ depends on the PWM frequency (see table, see page 887). <b>Default:</b>	Allowed in strobe LEVEL 3	889
<b>iCtrlAddInfo</b> 401008 MP2450.x (optional parameter)	<b>Only CC 61xx/UEC 11x: Dead-time compensation</b> <b>Format:</b> Bit-encoded value <b>Input:</b> ■ <b>Bit 0 = 0:</b> Compensation switched off ■ <b>Bit 0 = 1:</b> Compensation switched on <b>Default:</b> 0	Allowed in strobe LEVEL 3	889
<b>CfgControllerTol</b> Position and speed tolerances in the servo control			
<b>posTolerance</b> 401101 MP1030.x, MP3420	<b>Positioning window</b> Control window for message <b>IN POSITION</b> . <b>Format:</b> Numerical value <b>Input:</b> 0.0010 to 100.0000 [mm] <b>Default:</b> 0.0050 [mm]	Allowed in strobe LEVEL 3	957
<b>timePosOK</b> 401102	<b>Hysteresis time for "positioning window reached"</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 20.000 [s] <b>Default:</b> 0.010 [s]	Allowed in strobe LEVEL 3	957

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>speedTolerance</b> 401103	<b>Rotational speed (feed rate) window</b> Control window for message <b>RPM ATTAINED</b> . <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 01 to 100 [%] <b>Default:</b> 10 [%]	Allowed in strobe LEVEL 3	1024
<b>timeSpeedOK</b> 401104	<b>Hysteresis time for monitoring the speed deviation</b> <b>Format:</b> Numerical value <b>Input:</b> 0.006 to 10 [s] <b>Default:</b> 0.010 [s]	Allowed in strobe LEVEL 3	1024
<b>syncTolerance</b> 401105	<b>Angle tolerance for spindle synchronism</b> Parameter reserved for lathe controls. <b>Format:</b> Numerical value <b>Input:</b> 0.001 000 000 to 2 [°] <b>Default:</b> 0.01 [mm]	Allowed in strobe LEVEL 3	–
<b>timeSyncOK</b> 401106	<b>Hysteresis time for spindle synchronism</b> Parameter reserved for lathe controls. <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 20 [s] <b>Default:</b> 0.010 [s]	Allowed in strobe LEVEL 3	–
<b>CfgPowerStage</b> Settings for the power module of the axis			
<b>ampName</b> 401201 MP2100.x	<b>Type of axis/spindle power module</b> <b>Format:</b> Selection menu <b>Input:</b> Name of the power module from the inverter.inv power module table (is entered by the MANUALplus 620)	RUN LEVEL3	1074
<b>ampPowerSupplyType</b> 401202 MP2191 (optional parameter)	<b>Power module with or without energy recovery</b> Define the parameter only if no power module table is defined through <b>CfgSupplyModule</b> and <b>MP_motSupply</b> for the axis/spindle. <b>Format:</b> Selection menu <b>Input:</b> ■ <b>without power recovery:</b> Power module without energy recovery ■ <b>with power recovery:</b> Power module with energy recovery <b>Default:</b> without power recovery	RUN LEVEL3	1085

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>ampBusVoltage</b> 401203 MP2190.x (optional parameter)	<b>DC-link voltage Uz</b> If a supply-module table is defined ( <b>CfgSupplyModule, MP_motSupply</b> ), the parameter does not need to be configured. However, you can overwrite the value from the supply-module table through <b>MP_ampBusVoltage</b> . <b>Format:</b> Numerical value <b>Input:</b> DC-link voltage [V] Regenerative inverter: 650 [V] Non-regenerative inverter: 565 [V] <b>Default:</b> 650 [V]	RUN LEVEL3	1085
<b>ampPwmFreq</b> 401204 MP2180.x	<b>PWM frequency</b> <b>Format:</b> Selection menu <b>Input:</b> <b>0</b> 5 kHz for HEIDENHAIN inverters <b>3.333 kHz</b> <b>4.166 kHz</b> <b>5 kHz</b> <b>6.666 kHz</b> <b>8.333 kHz</b> <b>10 kHz</b> <b>Default:</b> 0	RUN LEVEL3	1048



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>ampVoltProtection</b>  401205  MP2160.x	<b>Field weakening for synchronous motors</b>  A voltage-protection module (e.g. SM 1xx) protects the motor and inverter when the power supply is interrupted. It may be required for synchronous motors during operation with field weakening.  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>not installed – mode 1:</b> (cf. iTNC 530: MP2160.x = 0) Mode 1: There is no voltage-protection module (SM). No field weakening possible.</li> <li>■ <b>installed – mode 2:</b> (cf. iTNC 530: MP2160.x = 1) Mode 2: Voltage-protection module (SM) exists. Field weakening without speed limitation is possible. Use this mode e.g. for synchronous spindles and torque motors.</li> <li>■ <b>not installed – mode 3:</b> (cf. iTNC 530: MP2160.x = 2) Mode 3: There is no voltage-protection module (SM). Field weakening with speed limitation is possible. Use this mode for EcoDyn motors, for example.</li> <li>■ <b>installed – mode 4:</b> (cf. iTNC 530: MP2160.x = 9) Mode 4: Like mode 2, but with minimized total current.</li> <li>■ <b>not installed – mode 5:</b> (cf. iTNC 530: MP2160.x = 10) Mode 5: Like mode 3 but with minimized total current.</li> </ul> <b>Default:</b> not installed – mode 1	RUN  LEVEL3  597 110-05	934
<b>ampReadyWaitTime</b>  401206  MP2170	<b>Waiting time between the switch-on of the drive and the drive's standby signal</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0.001 to 4.999 [s] 0: Waiting time of 2 [s]  <b>Default:</b> 0	RUN  LEVEL3	880

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>ampAcFailSelection</b>  401207	<b>Signal for powerfail</b>  Defines whether the powerfail in the control is generated via the AC-fail and/or the powerfail signal of the power module.  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>AC fail only generated:</b> Only AC-fail signal</li> <li>■ <b>Power fail and AC fail generated:</b> Powerfail and AC-fail signals</li> <li>■ <b>AC fail / power fail inactive:</b> AC fail and powerfail deactivated</li> <li>■ <b>Power fail only generated:</b> Only powerfail signal</li> </ul> <b>Default:</b> Power fail only generated	RUN  LEVEL3	934
<b>ampFactorI2t</b>  401208  MP2304.x  (optional parameter)	<b>Reference value for I<sup>2</sup>t monitoring of the power module</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0.000 000 000 to 1000 [·: rated current of power module] 0: Monitoring is switched off 1: Rated current of power module  is  reference value  <b>Default:</b> 1	RUN  LEVEL3	970



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<p><b>powStatusCheckOff</b></p> <p>401209</p> <p>MP2195</p>	<p><b>Suppress error messages of the HEIDENHAIN supply units</b></p> <p><b>Format:</b> Bit-encoded value (32 bits)</p> <p><b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>Bit 0</b> – Status signals that are already active during control power-up. 0: Missing signals are ignored 1: Missing signals are evaluated</li> <li>■ <b>Bit 1</b> – <math>\overline{\text{ERR.UZ.GR}}</math> signal 0: Error message is not suppressed 1: Error message is suppressed</li> <li>■ <b>Bit 2</b> – <math>\overline{\text{ERR.TMP}}</math> signal 0: Error message is not suppressed 1: Error message is suppressed</li> <li>■ <b>Bit 3</b> – Reserved</li> <li>■ <b>Bit 4</b> – <math>\overline{\text{ERR.IZ.GR}}</math> signal 0: Error message is not suppressed 1: Error message is suppressed</li> <li>■ <b>Bit 5</b> – RDY.PS signal 0: Error message is not suppressed 1: Error message is suppressed</li> <li>■ <b>Bit 6</b> – <math>\overline{\text{ERR.ILEAK}}</math> signal 0: Error message is not suppressed 1: Error message is suppressed</li> <li>■ <b>Bit 7</b> – PF.PS.AC signal (only on CC 61xx/UEC 11x) 0: Error message is not suppressed 1: Error message is suppressed</li> <li>■ <b>Bit 8</b> – PF.PS.DC signal (only on CC 61xx/UEC 11x) 0: Error message is not suppressed 1: Error message is suppressed</li> <li>■ <b>Bit 9</b> – Monitoring of DC-link voltage Uz or LIFTOFF function (only on CC 61xx/UEC 11x) 0: Uz monitoring and LIFTOFF function are active 1: Uz monitoring and LIFTOFF function are not active</li> </ul> <p><b>Default:</b> All bits = 0</p>	<p>RUN</p> <p>LEVEL3</p>	<p>982</p>

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>ampAdditionalInfo</b> 401210 (optional parameter)	Configure the switch position of the current sensor (column <b>S</b> of the <b>inverter.inv</b> power module table).  Is required for the D series of HEIDENHAIN inverters (UM 1xx D) in order to use the higher currents at the lower PWM frequencies.  <b>Format:</b> Bit-encoded value (32 bits)  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>Bit 0</b> – Configure the switch position of the current sensor in HEIDENHAIN inverters of the "D" series (UM 1xx D). 0: Column <b>S</b> in <b>inverter.inv</b> table = 0 1: Column <b>S</b> in <b>inverter.inv</b> table = 1</li> <li>■ <b>Bit 1</b> – Reserved</li> <li>■ <b>Bit 2</b> – Reserved</li> <li>■ <b>Bit 3</b> – Inverter manufacturer: 0: Non-HEIDENHAIN inverter 1: HEIDENHAIN inverter</li> <li>■ <b>Bit 4 to bit 31</b> – Reserved</li> </ul> <b>Default:</b>	RUN  LEVEL3  597 110-04	1075
<b>CfgServoMotor</b> Specifies the settings for the motor			
<b>motName</b> 401301 MP2200.x	<b>Name of the motor</b>  <b>Format:</b> Selection menu  <b>Input:</b> Name of the motor from the motor table (is entered by the MANUALplus 620)	RUN  LEVEL3	1056
<b>starDelta</b> 401302	<b>Motor with wye/delta switchover</b>  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>star-connection:</b> Wye connection</li> <li>■ <b>delta-connection:</b> Delta connection</li> </ul> <b>Default:</b> star-connection	RUN  LEVEL3	936



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>motEncCheckOff</b> 401303 MP2220, MP2221	<b>Monitoring functions</b> <b>Format:</b> Bit-encoded value (32 bits) <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>Bit 0</b> – Monitoring the reference mark:                0: Monitoring active                1: Monitoring inactive</li> <li>■ <b>Bit 1</b> – Monitoring the direction of rotation                0: Monitoring active                1: Monitoring inactive</li> <li>■ <b>Bit 2</b> – Power limit of spindle with <u>ERR.IZ.GR</u>                (only for HEIDENHAIN inverters, except UE                2xx):                0: Power limit active                1: Power limit inactive</li> <li>■ <b>Bit 3</b> – Switching off the controller when the                motor brakes are activated:                0: Suppress oscillations                1: Oscillations are allowed</li> <li>■ <b>Bit 4:</b> – Monitoring for excessive motor                temperature:                0: Monitoring active                1: Monitoring inactive</li> <li>■ <b>Bit 5:</b> – Monitoring for too low a motor                temperature                0: Monitoring active                1: Monitoring inactive</li> <li>■ <b>Bit 7</b> – Monitoring the input frequency of the                speed encoder                0: Monitoring active                1: Monitoring inactive</li> <li>■ <b>Bit 8</b> – Adjust mechanical offset by gradually                increasing the <math>k_V</math> factor                0: Function active                1: Function inactive</li> <li>■ <b>Bit 9 to bit 31</b> – Reserved</li> </ul> <b>Default:</b> All bits = 0	RUN LEVEL3	1009 1009 896 984 997 997 997 997
<b>motFactorI2t</b> 401301 MP2302.x	<b>Reference value for I<sup>2</sup>t monitoring of motor</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 1000 [· rated or stall current of the motor] 0: Monitoring is switched off 1: Rated current of motor as reference value <b>Default:</b> 1	RUN LEVEL3	970

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>motSlipTimeConstant</b> 401305	<b>Delay of friction compensation during braking</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 100 [s] 0: No friction compensation Typical: 0.015 [s] <b>Default:</b> 0	RUN LEVEL3	–
<b>motEmergencyStopRamp</b> 401306 MP2590.x	<b>Braking ramp in an emergency stop</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 3200.0 [kW] 0: Braking power is not limited <b>Default:</b> 0	RUN LEVEL3	893
<b>motPbrMax</b> 401307 MP2390.x	<b>Maximum brake power for emergency stop</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 3200.0 [kW] <b>Default:</b> 0	RUN LEVEL3	893
<b>motPMax</b> 401308 MP2392.x	<b>Power limiting of motor</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 3200 [kW] <b>Default:</b> 0	RUN LEVEL3	896
<b>motPbrMaxAcFail</b> 401309 MP2394.x	<b>Maximum brake power for power failure</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0 to 3200 [kW] <b>Default:</b> 0	RUN LEVEL3	893
<b>motMMax</b> 401310 MP2396.x	<b>Maximum torque</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 30 000 [Nm] <b>Default:</b> 0	RUN LEVEL3	896
<b>motSupply</b> 401321 (optional parameter)	<b>Key name of the motor's power supply module</b> Enter the key name of the power supply module that drives this motor. All power-supply-module key names defined under CfgSupplyModule are available for selection. <b>Format:</b> Selection menu <b>Input:</b> Key name from <b>CfgSupplyModule</b> <b>Default:</b> –	RUN LEVEL3 597 110-05	1072

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>motEncType</b> 401311 MP2206.x	<p><b>Overwrite the type of speed encoder from the motor table</b></p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>off:</b> The encoder type entered in the motor table is valid</li> <li>■ <b>ROTATING_WITH_Z1:</b> Incremental rotary encoder with Z1 track</li> <li>■ <b>ROTATING_ENDAT_ADJUSTED:</b> Aligned absolute rotary encoder</li> <li>■ <b>LINEAR_ENDAT:</b> Absolute linear encoder</li> <li>■ <b>LINEAR_INCREMENTAL:</b> Incremental linear encoder</li> <li>■ <b>ROTATING_ENDAT_NOT_ADJUSTED:</b> Unaligned absolute rotary encoder</li> <li>■ <b>ROTATING_WITHOUT_Z1:</b> Incremental rotary encoder without Z1 track</li> <li>■ <b>ROT_DIST_CODED_NOT_ADJUSTED:</b> Unaligned incremental rotary encoder with distance-coded reference marks</li> <li>■ <b>LIN_DIST_CODED_NOT_ADJUSTED:</b> Unaligned linear encoder with distance-coded reference marks</li> <li>■ <b>DIG_ENDAT_2_2_ADJUSTED:</b> Purely digital and aligned EnDat 2.2 rotary encoder</li> <li>■ <b>DIG_ENDAT_2_2_NOT_ADJUSTED:</b> Purely digital and unaligned EnDat 2.2 rotary encoder</li> <li>■ <b>LIN_ENDAT_2_2:</b> Purely digital EnDat 2.2 linear encoder</li> </ul> <p><b>Default:</b> off</p>	RUN LEVEL3	1056
<b>motDir</b> 401312 MP2204.x (optional parameter)	<p><b>Overwrite the counting direction of the motor encoder from the motor table</b></p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b></p> <ul style="list-style-type: none"> <li>■ <b>Off:</b> The counting direction entered in the motor table is valid.</li> <li>■ <b>Positive:</b> Positive counting direction.</li> <li>■ <b>Negative:</b> Negative counting direction.</li> </ul> <p><b>Default:</b> Off</p>	RUN LEVEL3	1057

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>motStr</b> 401313 MP2202.x (optional parameter)	<b>Overwrite the line count of the motor encoder from the motor table</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0: Value from the motor table active >0: Line count of the motor encoder  <b>Default:</b> 0	RUN  LEVEL3	1057
<b>motTypeOfFieldAdjust</b> 401314 MP2250 (optional parameter)	<b>Rough determination of the field angle without motor motion</b>  If a precise value is available for the field-angle orientation, the rough value is used until the axis has been referenced.  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>mode 0:</b> Recommended for all motors. Do not use for hanging axes!</li> <li>■ <b>mode 1:</b> Reserved, do not use!</li> <li>■ <b>mode 2:</b> Field angle determination with brake applied. A "minimum" movement of the motor must be possible when the brakes are applied.</li> <li>■ <b>mode 3:</b> Like "mode 2" with the difference that the brake is opened. Not suitable for hanging axes!</li> <li>■ <b>mode 4:</b> Reserved. Use only in consultation with HEIDENHAIN. (For very noisy encoder signals.)</li> </ul> <b>Default:</b>	RUN  LEVEL3  597 110-02	1066



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>motFieldAdjustMove</b> 401315 MP2254.x (optional parameter)	<b>Feed-angle adjustment mode</b> <b>Format:</b> Selection menu <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>mode 0:</b>                Rough determination of the field angle during operation (soft key has no function)                Field angle is determined for a motor at standstill. No plausibility tests. Use parameter <b>MP_motTypeOfFieldAdjust</b> to specify the method for rough determination of the field angle.</li> <li>■ <b>mode 1:</b>                Only on CC 422.                Precise determination of the field angle via soft key. Use only for spindles or motors without limit switches!                Do not use for hanging axes! Drive is moved during field angle determination.</li> <li>■ <b>mode 2:</b>                Only with CC 424, CC 61xx.                Precise determination of the field angle via soft key. Drive is moved during field angle determination.                Caution: No position monitoring (following error or software limit switch)! Recommended for horizontal axes or hanging axes with full weight compensation.</li> <li>■ <b>mode 3:</b>                Like mode 2. However, the drive does not have to be enabled via the PLC.</li> </ul> <b>Default:</b> mode 0	RUN LEVEL3 597 110-05	1062
<b>motFieldAdjustInfo</b> 401322 MP2252.x (optional parameter)	<b>Field-angle determination (reserved)</b> Only for the CC 61xx. Additional parameters for field-angle adjustment with plausibility check. <b>Format:</b> Numerical value <b>Input:</b> Reserved <b>Default:</b> 0	RUN LEVEL3	–
<b>motPhiRef</b> 401316 MP2256.x (optional parameter)	<b>Field angle determined (is entered by the MANUALplus 620 after it has been determined)</b> <b>Format:</b> Numerical value <b>Input:</b> Is entered by the MANUALplus 620 0: Field angle not yet determined <b>Default:</b> 0	RUN LEVEL3	1070

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>motEncSerialNumber</b> 401317 MP2257.x (optional parameter)	<b>Control or encoder identification for the field angle from MP_motPhiRef</b>  <b>Format:</b> Numerical value <b>Input:</b> Is entered by the MANUALplus 620 0: Field angle not yet determined <b>Default:</b> 0	RUN LEVEL3	1070
<b>motAdditionalInfo</b> 401318 (optional parameter)	<b>Reserved, do not assign</b>  <b>Format:</b> Numerical value <b>Input:</b> Reserved <b>Default:</b> 0	RUN LEVEL3	1075
<b>motSpeedSwitchOver</b> 401319 MP2186.x (optional parameter)	<b>Shaft speed for PWM switchover</b> Only for the CC 61xx/UEC 11x and CC 424. Specifies the shaft speed at which the PWM frequency is switched to twice the PWM frequency. Use only in combination with HEIDENHAIN power modules! <b>Format:</b> Numerical value <b>Input:</b> 0 to 100 000 [rpm] <b>Default:</b> 0	RUN LEVEL3 597 110-03	940
<b>motSpeedSwitchBack</b> 401320 MP2188.x (optional parameter)	<b>Shaft speed for PWM switchover</b> Only for the CC 61xx/UEC 11x and CC 424. Specifies the shaft speed at which the factor 2 PWM frequency is switched to a factor 1. Use only in combination with HEIDENHAIN power modules! <b>Format:</b> Numerical value <b>Input:</b> 0 to 100 000 [rpm] <b>Default:</b> 0	RUN LEVEL3	940
<b>testBrakeCurrent</b> 401323 MP2230.x (optional parameter)	<b>Test of motor brake: Factor for motor stall current</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.1 to 30 [- motor stall current] Recommended: $1.3 \cdot M_L / M_0$	RUN LEVEL3 597 110-05	987
<b>testBrakeTolerance</b> 401324 MP2232.x (optional parameter)	<b>Test of motor brake: Maximum permissible path</b>  <b>Format:</b> Numerical value <b>Input:</b> 0 to 10 [mm] or [°]	RUN LEVEL3	987

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgControllerComp</b>			
Specifies compensation settings in the controller unit			
<b>compFriction0</b> 401401 MP2610.x (optional parameter)	<b>Friction compensation at low speed</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 30 [A] <b>Default:</b> 0	Allowed in strobe LEVEL3	725
<b>compFrictionT1</b> 401402 MP2612.x (optional parameter)	<b>Distance before the reversal point for reducing the current from MP_compFriction0</b> The following units of measure apply: <b>MP_compFrictionT1</b> = [s] if <b>MP_compFrictionT2</b> = 0 (same behavior as CC 422) <b>MP_compFrictionT1</b> = [mm] if <b>MP_compFrictionT2</b> > 0 <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 1 [mm] or [°] 0: No friction compensation <b>Default:</b> 0	Allowed in strobe LEVEL3	725
<b>compFrictionT2</b> 401403 MP2614.x (optional parameter)	<b>Distance after the reversal point for current from MP_compFriction0</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 1 [mm] or [°] 0: No friction compensation <b>Default:</b> 0	Allowed in strobe LEVEL3	725
<b>compFrictionNS</b> 401404 MP2620.x (optional parameter)	<b>Friction compensation at rated speed</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000 000 000 to 30 [A] 0: No friction compensation (or analog axis) <b>Default:</b> 0	Allowed in strobe LEVEL3	–
<b>compCurrentOffset</b> 401405 MP2630.x (optional parameter)	<b>Holding current of vertical axis (weight compensation)</b> <b>Format:</b> Numerical value <b>Input:</b> –100.000 to +100.000 [A] <b>Default:</b> 0	Allowed in strobe LEVEL3	–
<b>compAcc</b> 401406 MP2600.x (optional parameter)	<b>Acceleration feedforward control</b> <b>Format:</b> Numerical value <b>Input:</b> 0 to 1000 [As <sup>2</sup> ] <b>Default:</b> 0	Allowed in strobe LEVEL3	867

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>complpcT1</b> 401407 MP2602.x (optional parameter)	<b>IPC time constant T1</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0000 to 1.0000 [s] 0: IPC inactive <b>Default:</b> 0	Allowed in strobe LEVEL3	869
<b>complpcT2</b> 401408 MP2604.x (optional parameter)	<b>IPC time constant T2</b> <b>Format:</b> Numerical value <b>Input:</b> 0.0000 to 1.0000 [s] 0: IPC inactive <b>Default:</b> 0	Allowed in strobe LEVEL3	869
<b>complpcJerkFact</b> 401409 MP2606.x (optional parameter)	<b>Following error in the jerk phase</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000000000 to 10 <b>Default:</b> 0	Allowed in strobe LEVEL3	869
<b>compActDampFact</b> 401410 MP2607.x (optional parameter)	<b>Factor for active damping of low-frequency oscillations</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000000000 to 30 0: No damping 1.5: Typical damping factor	Allowed in strobe LEVEL3	869
<b>compActDampTime</b> 401411 MP2608.x (optional parameter)	<b>Time constant for active damping of low-freq. oscillations</b> <b>Format:</b> Numerical value <b>Input:</b> 0.000000000 to 0.999999999 [s] 0: No damping 0.005 to 0.02: Typical damping time constant	Allowed in strobe LEVEL3	869
<b>compTorqueRipple</b> 401412 MP2260.x (optional parameter)	<b>Name of the file for "torque ripple compensation" (TRC)</b> Is entered by TNCopt during TRC adjustment. <b>Format:</b> String <b>Input:</b> File name generated in TNCopt xx_<MotorNamefromMotorTable>.TRC	Allowed in strobe LEVEL3	943
<b>compTorsionFact</b> 401413 MP2640.x (optional parameter)	<b>Torsion compensation between position encoder and speed encoder</b> <b>Format:</b> Numerical value <b>Input:</b> 0.001 to 100.000 [µm/A] 0: Compensation not active <b>Default:</b> 0	Allowed in strobe LEVEL3	945



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>compSwitchOff</b> 401414 MP2261.x (optional parameter)	<b>Switch-off of compensation in speed ctrlr or current ctrlr</b>  <b>Format:</b> Bit-encoded value (32 bits)  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>Bit 0</b> – Torque ripple compensation:                0: Torque ripple compensation is switched on                1: Torque ripple compensation is switched off</li> <li>■ <b>Bit 1 to bit 31</b> – Reserved</li> </ul> <b>Default:</b> 0	Allowed in strobe  LEVEL3	943



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgAxisCoupling</b>			
Specifies the settings for the coupling of axes, e.g. for gantry axes or axes in master-slave-torque control			
<b>masterAxis</b> 402301 MP850.x	<b>Assign a master axis to the slave axis.</b> <b>Format:</b> Selection menu <b>Input:</b> Key name of the master axis from <b>CfgAxes/axisList</b> <b>Default:</b> 0	RUN LEVEL3 597 110-04	769
<b>mode</b> 402302	<b>Mode of the coupling</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>None:</b> Axis has no coupling ■ <b>Position:</b> Axis coupled via gantry (position coupling) ■ <b>Torque:</b> Torque coupling <b>Default:</b> None	RUN LEVEL3 597 110-04	770
<b>type</b> 402303	<b>Type of coupling</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>Static:</b> Static coupling – is automatically closed in the start-up phase without PLC involvement. ■ <b>Dynamic:</b> Dynamic coupling – is closed only by PLC command. <b>Default:</b> Static	RUN LEVEL3 597 110-04	770
<b>typeOfOffset</b> 402304 MP860.x, bit 0	<b>Specifies how the position offset between master and slave axis is handled.</b> <b>Format:</b> Selection menu <b>Input:</b> ■ <b>None / Actual:</b> The offset when a coupling is closed is retained as static offset. There is no compensating movement on stationary axes. ■ <b>Parameter:</b> After the reference run, the value of the <b>MP_posOffset</b> parameter is taken as the absolute position offset. When the coupling closes, there is an immediate compensating movement. <b>Default:</b> None	RUN LEVEL3	771

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>posOffset</b> 402305 MP855.x	<b>Value of the position offset with closed coupling</b>  <b>Format:</b> Numerical value  <b>Input:</b> Position offset in millimeters [mm] or degrees [°] that is compensated and maintained if <b>MP_typeOfOffset = Parameter</b> is set  <b>Default:</b> 0	RUN LEVEL3 597 110-04	771
<b>offsetFeed</b> 402306 MP1330.x	<b>The velocity with which an offset between the master axis and the slave axis is compensated for</b>  <b>Format:</b> Numerical value  <b>Input:</b> Velocity [mm/min] or [°/min]  <b>Default:</b> 999.996 [mm/min] or [°/min]	RUN LEVEL3 597 110-04	771
<b>maxPosDiff</b> 402307 MP855.x	<b>Synchronization monitoring – deletable emergency stop message</b>  <b>Format:</b> Numerical value  <b>Input:</b> Permissible offset [mm]  <b>Default:</b> 0	RUN LEVEL3 597 110-04	771
<b>ultimatePosDiff</b> 402308	<b>Synchronization monitoring – non-deletable emergency stop message</b>  <b>Format:</b> Numerical value  <b>Input:</b> Max. permissible offset [mm]  <b>Default:</b> 0	RUN LEVEL3 597 110-04	772
<b>scalingFactor</b> 402309	<b>Scaling factor for calculating the slave position</b>  <b>Format:</b> Numerical value  <b>Input:</b> Any values, even negative values (on modulo axes only ±1 is can be entered)  <b>Default:</b> 1	RUN LEVEL3 597 110-04	772
<b>accFilterTime</b> 402315	<b>Time constant for filtering the acceleration curve</b>  <b>Format:</b> Numerical value  <b>Input:</b> 0 to 200 [ms]  <b>Default:</b> 30	RUN LEVEL3 597 110-04	772

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>torqueBias</b> 402310 MP2900.x	<b>Tensioning torque between master and slave for master-slave torque control (entry for the slave axis)</b>  <b>Format:</b> Numerical value <b>Input:</b> -1000.00 to +1000.00 [Nm] <b>Default:</b> 0	RUN LEVEL3 597 110-04	782
<b>propGain</b> 402311 MP2910.x	<b>P factor of the torque controller for master-slave torque control (entry for the slave axis)</b>  <b>Format:</b> Numerical value <b>Input:</b> 0 to 1666.666666667 [1/(Nm · min)] <b>Default:</b> 0	RUN LEVEL3 597 110-04	782
<b>torqueDistrFactor</b> 402312 MP2920.x	<b>Factor for variable torque distribution</b>  <b>Format:</b> Numerical value <b>Input:</b> 0.000000000 to 100 <b>Default:</b> 1	RUN LEVEL3 597 110-04	782
<b>speedCorrectRatio</b> 402313 MP2930.x	<b>Rotational velocity compensation ratio</b>  <b>Format:</b> Numerical value <b>Input:</b> -100.000000000 to +100 <b>Default:</b> 1	RUN LEVEL3 597 110-04	782
<b>inverseVelocity</b> 402314 MP1040	<b>Reversal of the algebraic sign of the nominal speed value</b>  <b>Format:</b> Selection menu <b>Input:</b> ■ <b>FALSE:</b> Algebraic sign reversal inactive ■ <b>TRUE:</b> Algebraic sign reversal active <b>Default:</b> FALSE	RUN LEVEL3 597 110-04	783
<b>autoBrakeTest</b> 402316 MP860, bit 2 (optional parameter)	<b>Motor brake test for synchronized axes</b>  <b>Format:</b> Selection menu <b>Input:</b> ■ <b>off:</b> The brake is tested separately for this axis. ■ <b>with Master:</b> The brake for this axis is tested at the same time as the master axis. <b>Default:</b> off	RUN LEVEL3 597 110-05	786

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgCCAuxil</b> Extended settings for the CC controller unit (optional); Use only in consultation with HEIDENHAIN.			
<b>miscCtrlFunct0</b> 402201 MP2222.x (optional parameter)	<b>Reserved, do not assign</b> <b>Format:</b> Bit-encoded value (16 bits) <b>Input:</b> Reserved	PLC/Pgm run is locked LEVEL3	–
<b>miscCtrlFunct1</b> 402202 MP2223.x (optional parameter)	<b>Reserved, do not assign</b> <b>Format:</b> Bit-encoded value (16 bits) <b>Input:</b> Reserved	PLC/Pgm run is locked LEVEL3	–



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>Settings</b>			
Lathe-specific parameter sets for the axes			
<b>LinearAxis</b>			
Lathe-specific parameter sets for linear axes			
<b>[Key name of the linear axis]</b>			
<b>CfgAxisProperties</b>			
Defines the lathe-specific characteristics of the existing linear axes			
<b>threadSafetyDist</b> 300902	<b>Approach path for the thread start</b> When starting a thread, the programmed feed rate must be attained within the approach path. <b>Format:</b> Numerical value <b>Input:</b> Approach path in [mm] with up to 9 decimal places <b>Default:</b> 3	RUN LEVEL3	1389
<b>CfgProtectionZone</b>			
Positive and negative value for defining the protection zone			
<b>limitPositive</b> 301001	<b>Positive protection zone</b> Positive limit value for the protection zone. <b>Format:</b> Numerical value <b>Input:</b> Positive limit value for the protection zone [mm] with up to 9 decimal places 0: No monitoring of protection zone <b>Default:</b> +999999999 [mm]	RUN LEVEL3	1390
<b>limitNegative</b> 301002	<b>Negative protection zone</b> Negative limit value for the protection zone. <b>Format:</b> Numerical value <b>Input:</b> Negative limit value for the protection zone [mm] with up to 9 decimal places 0: No monitoring of protection zone <b>Default:</b> -999999999 [mm]	RUN LEVEL3	1390

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgProbePosition</b> Definition of the touch probe positions			
<b>positionProbePos</b> 604701	<b>Positive position of probe/optics</b> Position of the touch probe (or optical gauge) in positive axis direction with respect to the machine datum  <b>Format:</b> Numerical value  <b>Input:</b> Positive position in [mm] with up to 9 decimal places	RUN LEVEL3	1386
<b>positionProbeNeg</b> 604702	<b>Negative position of probe/optics</b> Position of the touch probe (or optical gauge) in negative axis direction with respect to the machine datum  <b>Format:</b> Numerical value  <b>Input:</b> Negative position in [mm] with up to 9 decimal places	RUN LEVEL3	1386
<b>maxMeasuringFeed</b> 604703	<b>Maximum measuring feed</b> Maximum permissible feed rate for traverse to the touch probe  <b>Format:</b> Numerical value  <b>Input:</b> Max. feed rate in [mm] with up to 9 decimal places	RUN LEVEL3	1387

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>SpindleAxis</b>			
Lathe-specific parameter sets for spindles			
<b>[Key name of spindle]</b>			
<b>CfgMachineTable</b>			
Description of the machine base system			
<b>sysKinSimple</b> 300703	<b>Subkinematics of the tool spindle</b> Enter here the key name of the subkinematics of the tool spindle. <b>Format:</b> Selection menu <b>Input:</b> Key name from <b>CfgKinSimpleModel</b>	RESET LEVEL3	1391
<b>basisTransKinSim</b> 300704	<b>Subkinematics of the machine base</b> Enter here the key of the subkinematics of the machine base. <b>Format:</b> Selection menu <b>Input:</b> Key name from <b>CfgKinSimpleModel</b>	RESET LEVEL3	1391
<b>sys</b> 300701	<b>Machine base system (up to NC software 548328-02)</b> Assignment of the machine base system to a spindle number. <b>Format:</b> Selection menu <b>Input:</b> Key name from <b>CfgTrafoByDir</b>	RESET LEVEL3	1392
<b>basisTrans</b> 300702	<b>Standard vector for datum shifts (up to NC software 548328-02)</b> Enter the key name of the standard vector for definition of the coordinate transformation for datum shifts. <b>Format:</b> Selection menu <b>Input:</b> Key name from <b>CfgTrafoByDir</b>	RESET LEVEL3	1392



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>C axis</b>			
Lathe-specific parameter sets for the C axes			
<b>[Key name of the C axis]</b>			
<b>CfgCAxisProperties</b>			
Properties of the existing C axes			
<b>blockBrake</b> 300801	<b>Shoe brake</b> Enter here whether a shoe brake is present. <b>Format:</b> Selection menu <b>Input:</b> ■ <b>TRUE:</b> Shoe brake present ■ <b>FALSE:</b> Shoe brake not present <b>Default:</b> FALSE	RUN LEVEL3	1393
<b>spindlePrePosit</b> 300802	<b>Spindle pre-positioning with M19</b> Enter the angle to which the spindle is positioned before the C axis is positioned. <b>Format:</b> Numerical value <b>Input:</b> 0 to 99 Value as a whole number in [°] <b>Default:</b> 0	RUN LEVEL3	1394
<b>relatedWpSpindle</b> 300803	<b>Assigned workpiece spindle</b> For C axes with separate drive, enter here the workpiece spindle assigned to the C axis. <b>Format:</b> Selection menu <b>Input:</b> Key name from <b>Axes/PhysicalAxis</b> <b>Default:</b> No entry = The C axis was assigned  a workpiece spindle via <b>CfgProgAxis/relatedAxis</b>	RUN LEVEL3	1394

#### 4.10.4 KeySynonym

Definition of synonym names

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<p><b>CfgKeySynonym</b></p> <p>Definition of a synonym name; If parameter objects with the same content but different key names are needed, you can define a synonym name—comparable with a link.</p> <p>Examples:</p> <ul style="list-style-type: none"> <li>■ Parameter objects for the simulation channel (<b>CH_NC</b>)—<b>Test Run</b> mode of operation</li> <li>■ Further parameter sets for axes</li> </ul>			
<p><b>[Key name = Synonym name]</b></p> <p>Example: <b>CH_SIM</b> for the simulation channel</p>			
<p><b>relatedTo</b></p> <p>109501</p>	<p><b>Reference to key name</b></p> <p>The synonym name refers to the key name specified here. The data of the parameter object with the key name are used for the parameter object with the synonym name.</p> <p><b>Format:</b> String</p> <p><b>Input:</b> Key name, max. 18 characters</p>	<p>RESET LEVEL3</p>	<p>378</p>
<p><b>excludeList</b></p> <p>109502</p>	<p><b>List with configuration objects to be excluded</b></p> <p>For the config objects shown in the list, cancel the reference at <b>CfgKeySynonym/relatedTo.</b></p> <p><b>Format:</b> List [0 to 50]</p> <p><b>Input:</b> Key names to be excluded</p>	<p>RESET LEVEL3</p>	<p>378</p>



## 4.10.5 Aggregates

Lathe-specific parameters

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>General</b>			
<b>CfgAggregateKeys</b>			
Definition of the existing machine components; Enter all machine components of the lathe.			
<b>toolHolderKeys</b> 600001	<b>List of the tool carriers of the machine</b> Enter the key names of all tool carriers existing on the machine. <b>Format:</b> List [0 to 6] <b>Input:</b> Selection menu with the key names of the tool carriers from the folder <b>ToolHolder</b>	RESET LEVEL3	1396
<b>tailstockKeys</b> 600002	<b>List of the tailstocks of the machine</b> Enter the key names of all tailstocks existing on the machine. <b>Format:</b> List [0 to 1] <b>Input:</b> String (max. 18 characters)	RESET LEVEL3	1395
<b>steadyRestKeys</b> 600003	<b>List of the steady rests of the machine</b> Enter the key names of all steady rests existing on the machine. <b>Format:</b> List [0 to 1] <b>Input:</b> String (max. 18 characters)	RESET LEVEL3	1395
<b>caxisKeys</b> 600004	<b>List of all C axes of the machine</b> Enter the key names of all C axes existing on the machine. <b>Format:</b> List [0 to 2] <b>Input:</b> Key names from <b>PhysicalAxis</b>	RESET LEVEL3	1393

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgGlobalProperties</b> General settings for automatic operation			
<b>lifeTime</b>  601801	<b>Tool life management</b>  Enable/disable the tool management according to either the tool life or the workpiece quantity  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>on:</b> Monitoring on</li> <li>■ <b>off:</b> Monitoring off</li> </ul> <b>Default:</b> Off	RUN  LEVEL1	1408
<b>iStopT</b>  601802	<b>Tool change with interpreter stop</b>  Configure whether an interpreter stop is to take place before the tool change.  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> Interpreter stop before tool change</li> <li>■ <b>FALSE:</b> No interpreter stop</li> </ul> <b>Default:</b> FALSE	RUN  LEVEL1	1415
<b>threadDwell</b>  601803	<b>Dwell time for tapping</b>  Specify for how many seconds the NC program is to be halted during tapping when the end of the thread has been reached.  <b>Format:</b> Numerical value  <b>Input:</b> 0 to 65535 Value as a whole number in [s]  <b>Default:</b> 0	RUN  LEVEL1	1415



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>threadLiftOff</b>  601804	<b>Liftoff out of the thread</b>  Specify if a tapping process can be interrupted by an NC stop. During such an interruption, the threading tool retracts by the programmed distance.  <b>Format:</b> Selection menu  <b>Input:</b>  ■ <b>TRUE:</b> Upon NC stop in the thread the tool is lifted off by the programmed distance.  ■ <b>FALSE:</b> NC stop not permitted while in the thread.  <b>Default:</b> FALSE	RUN  LEVEL1	1416
<b>threadHandWheelOn</b>  601807	<b>Activate handwheel in the thread</b>  Enter here whether the function G922, which is required for the "handwheel in thread" function, is to be inserted automatically in the thread cycles.  <b>Format:</b> Selection menu  <b>Input:</b>  ■ <b>TRUE:</b> The function G922 is automatically inserted in the thread cycles.  ■ <b>FALSE:</b> The function G922 is not automatically inserted in the thread cycles.	RUN  LEVEL1	1417
<b>protectionZone</b>  601805	<b>Switch off protective zone monitoring</b>  Configure here whether monitoring of the protection zone is to be enabled.  <b>Format:</b> Selection menu  <b>Input:</b>  ■ <b>TRUE:</b> Protection zone monitoring with the values from <b>CfgProtectionZone</b> active.  ■ <b>FALSE:</b> Protection zone monitoring inactive  <b>Default:</b> Off	RUN  LEVEL1	1390

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>doProgAfterTCall</b>  601806	<b>Subprogram after tool change</b>  Configure here whether a specific subprogram is to be executed after the tool change.  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> The subprogram _tcall1.ncs is run after the tool change</li> <li>■ <b>FALSE:</b> No subprogram is run after the tool change</li> </ul>	RUN  LEVEL1	1445
<b>freezeVconst</b>  601808	<b>Freezing the spindle speed for rapid traverse movements and active constant surface speed.</b>  Configure here whether the spindle should change its speed according to the current diameter at a constant cutting velocity Vconst and when performing several rapid-traverse movements.  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>TRUE:</b> The spindle speed is held constant for rapid traverse movements and active constant surface speed.</li> <li>■ <b>FALSE:</b> The spindle speed is always adjusted to the current diameter for rapid traverse movements and active constant surface speed.</li> </ul>	RUN  LEVEL1	1392
<b>ncStartWithActCyc</b>  601809	<b>Program run with the most recently selected cycle</b>  Configure here whether the most recently selected cycle is to remain active when switching to Program Run mode.  <b>Format:</b> Selection menu  <b>Input:</b> <ul style="list-style-type: none"> <li>■ <b>On:</b> When Program Run is selected, the most recently selected cycle remains active</li> <li>■ <b>Off:</b> When switching to Program Run, the first cycle of the cycle program is always selected.</li> </ul>	RUN  LEVEL1	1417



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>ToolHolder</b>			
<b>[Key name of the too carriers]</b>			
<b>CfgTHDescription</b>			
Description of the tool carrier			
<b>ordinalNr</b> 600203	<b>Reference number of the tool carrier</b> Enter the reference number of the tool carrier. <b>Format:</b> Numerical value <b>Input:</b> 0 to 9 Value as a whole number (integer) <b>Default:</b> 1	RESET LEVEL3	1397
<b>type</b> 600204	<b>Type of tool carrier</b> Enter the type of tool carrier. <b>Format:</b> Selection menu <b>Input:</b> <b>None</b> <b>Turret</b> <b>MultiFix</b> <b>Default:</b> MultiFix	RESET LEVEL3	1397
<b>spindleNr</b> 600207	<b>Spindle number of the driven tool.</b> Enter the spindle number to be assigned to the driven tool. The selection menu refers to the spindle key in <b>CfgAxes/spindleIndices</b> . The "Spindle S1" is reserved for the main spindle and cannot be assigned here. <b>Format:</b> Selection menu <b>Input:</b> <b>NoSpindle</b> <b>Spindle-S2</b> <b>Spindle-S3</b> <b>Spindle-S4</b> <b>Spindle-S5</b> <b>Spindle-S6</b> <b>Default:</b> NoSpindle	RESET LEVEL3	1398
<b>maxSwivelPosition</b> 600208	<b>Turret swivel positions</b> Enter the number of tool turret swivel positions. <b>Format:</b> Numerical value <b>Input:</b> 1 to 99 Value as a whole number (integer) <b>Default:</b> 12 (turret) 1 (Multifix)	RESET LEVEL3	1398

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>xDimToslideRef</b> 600210	<b>X dimension for slide reference</b>  Enter the distance between the slide reference point and the tool carrier reference point in [mm]. If the slide reference and the tool carrier reference are identical, enter the value zero.  <b>Format:</b> Numerical value <b>Input:</b> -100000.000 to 100000.000 [mm] <b>Default:</b> 0	RESET LEVEL3	1398
<b>zDimToslideRef</b> 600211	<b>Z dimension for slide reference</b>  Enter the distance between the slide reference point and the tool carrier reference point in [mm]. If the slide reference and the tool carrier reference are identical, enter the value zero.  <b>Format:</b> Numerical value <b>Input:</b> -100000.0000 to 100000.0000 [mm] <b>Default:</b> 0	RESET LEVEL3	1399
<b>yDimToslideRef</b> 600212	<b>Y dimension for slide reference</b>  Enter the distance between the slide reference point and the tool carrier reference point in [mm]. If the slide reference and the tool carrier reference are identical, enter the value zero.  <b>Format:</b> Numerical value <b>Input:</b> -100000.0000 to 100000.0000 [mm] <b>Default:</b> 0	RESET LEVEL3	1399
<b>coolantCirc</b> 600213	<b>Coolant circuits</b>  List with the numbers of the allocated coolant circuits.  <b>Format:</b> Numerical value <b>Input:</b> -2147483648 to 2147483647 Value as a whole number (integer)	RESET LEVEL3	1399
<b>Definition of the existing tool holders</b> Entries for all tool holders of the machine			
<b>toolMountKeys</b> 600101	<b>Key names of all holders of this tool carrier</b>  Enter the key names of all tool holders of the tool carrier in the list.  <b>Format:</b> List [0 to 64] <b>Input:</b> Selection menu Key names from the folder <b>ToolMount</b>	RESET LEVEL3	1399



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>ToolMount</b>			
<b>[Key names of the tool holders]</b>			
<b>CfgToolMount</b>			
Description of the tool holder			
<b>mountPosWAPP</b> 600401	<b>(W)APP designation of holder location</b> Enter the number of this tool holder according to the WAPP principle:  W = Tool carrier number (1 to 6) A = Holder position (0 to 3) PP = Swivel position of the turret  <b>Format:</b> Numerical value <b>Input:</b> 1 to 6999 Value as a whole number (integer)	RESET LEVEL3	1400
<b>freeTnr</b> 600402	<b>Free T number of the tool holder</b> Enter a unique T number for each tool holder. The value 0 is reserved by the control, and represents a tool whose geometric dimensions are 0.  <b>Format:</b> Numerical value <b>Input:</b> 1 to 899 Value as a whole number (integer)	RESET LEVEL3	1401
<b>distCarrierRefX</b> 600407	<b>Distance to carrier reference point in X</b> Enter the distance between the tool holder reference point and the tool carrier reference point in [mm].  <b>Format:</b> Numerical value <b>Input:</b> -100000.000 to 100000.000 [mm] <b>Default:</b> 0	RESET LEVEL3	1401
<b>distCarrierRefZ</b> 600408	<b>Distance to carrier reference point in Z</b> Enter the distance between the tool holder reference point and the tool carrier reference point in [mm].  <b>Format:</b> Numerical value <b>Input:</b> -100000.000 to 100000.000 [mm] <b>Default:</b> 0	RESET LEVEL3	1401

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>distCarrierRefY</b> 600409	<b>Distance to carrier reference point in Y</b> Enter the distance between the tool holder reference point and the tool carrier reference point in [mm]. <b>Format:</b> Numerical value <b>Input:</b> -100000.000 to 100000.000 [mm] <b>Default:</b> 0	RESET LEVEL3	1402
<b>correctionX</b> 600410	<b>Compensation in X of the tool-holder position</b> Enter an X compensation value for the tool holder position that the control adds to the value from MP_distCarrierRefX. <b>Format:</b> Numerical value <b>Input:</b> -100000.000 to 100000.000 [mm] <b>Default:</b> 0	RESET LEVEL3	1402
<b>correctionZ</b> 600411	<b>Compensation in Z of the tool-holder position</b> Enter a Z compensation value for the tool holder position that the control adds to the value from MP_distCarrierRefZ. <b>Format:</b> Numerical value <b>Input:</b> -100000.000 to 100000.000 [mm] <b>Default:</b> 0	RESET LEVEL3	1402
<b>correctionY</b> 600412	<b>Compensation in Y of the tool-holder position</b> Enter a Y compensation value for the tool holder position that the control adds to the value from MP_distCarrierRefY. <b>Format:</b> Numerical value <b>Input:</b> -100000.000 to 100000.000 [mm] <b>Default:</b> 0	RESET LEVEL3	1402
<b>coorTrafoToModify</b> 600414	<b>Coordinate transformations to be modified (up to NC software 548 328-02)</b> Enter the key names of the coordinate transformations that are to be replaced by the transformations in <b>coorTrafo</b> at the same position during axis mirroring. <b>Format:</b> List [0 to 100] <b>Input:</b> Selection menu Coordinate transformations off <b>CfgTrafoByDir</b>	RESET LEVEL3	761

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>coorTrafo</b> 600415	<b>Modified coordinate transformations (up to NC software 548 328-02)</b>  Enter the key names of the coordinate transformations that are to replace the transformations in <b>coorTrafoToModify</b> at the same position during axis mirroring.  <b>Format:</b> List [0 to 100]  <b>Input:</b> Selection menu Coordinate transformations off <b>CfgTrafoByDir</b>	RESET LEVEL3	761
<b>kinModelToModify</b> 600418	<b>Subkinematics to be replaced</b>  Enter the key names of the subkinematics that are to be replaced by the subkinematics in <b>kinModel</b> at the same position during axis mirroring.  <b>Format:</b> List [0 to 100]  <b>Input:</b> Selection menu Coordinate transformations off <b>CfgKinSimpleModel</b>	RESET LEVEL3	746
<b>kinModel</b> 600419	<b>Subkinematics to be activated</b>  Enter the key names of the subkinematics that are to replace the subkinematics in <b>kinModelToModify</b> at the same position during axis mirroring.  <b>Format:</b> List [0 to 100]  <b>Input:</b> Selection menu Coordinate transformations off <b>CfgKinSimpleModel</b>	RESET LEVEL3	746
<b>mirroringAxes</b> 600416	<b>Axes to be mirrored</b>  Enter the key names of the axes that are to be mirrored for this tool holder.  <b>Format:</b> List [0 to 100]  <b>Input:</b> Selection menu Key names from <b>Axes/PhysicalAxis</b>	RESET LEVEL3	1403

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>convTbINr</b> 600417	<b>Conversion table to be activated</b> Enter the number of the conversion table that is to be activated when this tool holder is inserted. <b>Format:</b> Numerical value <b>Input:</b> 0: Do not perform any conversion 1: Activate conversion table 1 (file: conv1.hc) 2: Activate conversion table 2 (file: conv2.hc) 3: Activate conversion table 3 (file: conv3.hc)	RESET LEVEL3	1403
<b>RearSideMachining</b>			
<b>CfgRearSideKinem</b> Kinematic configurations for rear-face machining			
<b>[Key name of the machining channel]</b> Two channels are permanently defined: ■ <b>CH_NC:</b> Machining channel ■ <b>CH_SIM:</b> Simulation channel			
<b>kinList</b> 605701	<b>Kinematic configurations for rear-face machining</b> Enter here the key names of all kinematic configurations for rear-face machining <b>Format:</b> List [0 to 100] <b>Input:</b> Selection menu Kinematic models off <b>CfgKinComposModel</b>	RUN LEVEL1	1462
<b>specWpSpindleList</b> 605702	<b>Workpiece spindles for rear-face machining</b> Enter the key names of all workpiece spindles with special transformations for rear-face machining. <b>Format:</b> List [0 to 100] <b>Input:</b> Selection menu Spindle key names from <b>Axes/PhysicalAxis</b>	RUN LEVEL1	1462

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>CfgRearSideTrafo</b>			
Transformations for rear-face machining			
<b>[Key name of the spindle for rear-face machining]</b>			
<b>mirAxis</b> 605804	<b>Axis to be mirrored</b>  Enter the axes for which transformations for mirroring are to be assigned in <b>MP_trafoMirAxis</b> . The transformation is assigned to the axis through the list index.  <b>Format:</b> List [0 to 100] <b>Input:</b> Selection menu Key names from <b>Axes/PhysicalAxis</b>	RUN LEVEL1	1462
<b>trafoMirAxis</b> 605801	<b>Transformations for axis mirroring</b>  For the axes located in <b>MP_mirAxis</b> , enter here the transformations for mirroring axes. The transformation is assigned to the axis through the list index.  <b>Format:</b> List [0 to 100] <b>Input:</b> Selection menu Key names from <b>CfgKinSimpleTrans</b>	RUN LEVEL1	1462
<b>toolLengthDir</b> 605805	<b>Axis directions of the mirrored tool lengths</b>  Enter here the axis directions of the mirrored tool lengths for which <b>MP_trafoMirToolLength</b> contains transformations for mirroring of the tool lengths. The transformation is assigned to the axis through the list index.  <b>Format:</b> List [0 to 100] <b>Input:</b> Selection menu XAxis YAxis ZAxis SpecAxis	RUN LEVEL1	1462
<b>trafoMirToolLength</b> 605802	<b>Transformations for mirroring the tool length</b>  For the axis directions located in <b>MP_toolLengthDir</b> , enter here the transformations for mirroring the tool lengths. The transformation is assigned to the direction of the mirrored tool length through the list index.  <b>Format:</b> List [0 to 100] <b>Input:</b> Selection menu Key names from <b>CfgKinSimpleTrans</b>	RUN LEVEL1	1463

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>zeroPointOffsAxis</b>  605806	<b>Axes with zero-point offset</b>  Enter the axes for which transformations of the datum shift are assigned in <b>MP_zeroPointOffset</b> . The transformation for the datum shift is assigned to the axis through the list index.  <b>Format:</b> List [0 to 100]  <b>Input:</b> Selection menu Key names from <b>Axes/PhysicalAxis</b>	RUN  LEVEL1	1463
<b>zeroPointOffset</b>  605803	<b>Datum shift of the axis</b>  For the axes located in <b>MP_zeroPointOffsAxis</b> , enter here the transformations for the datum shift. The transformation of the datum shift is assigned to the axis through the list index.  <b>Format:</b> List [0 to 100]  <b>Input:</b> Selection menu Key names from <b>CfgKinSimpleTrans</b>	RUN  LEVEL1	1463



## 4.10.6 ProcessingData

### General settings

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>ProcessingData</b>			
<b>CfgGlobalTechPara</b>			
General settings			
<b>safetyDistBlankOut</b> 602005	<b>External safety clearance (SAR)</b> Global safety clearance to the workpiece blank— outside <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 100 000.000 [mm] <b>Default:</b> 0	RUN LEVEL1	1418
<b>safetyDistBlankIn</b> 602006	<b>Internal safety clearance (SIR)</b> Global safety clearance to the workpiece blank— inside <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 100 000.000 [mm] <b>Default:</b> 0	RUN LEVEL1	1418
<b>safetyDistWorkpOut</b> 602007	<b>Safety clearance on machined part outside (SAT)</b> Global safety clearance to the prepared workpiece—outside <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 100 000.000 [mm] <b>Default:</b> 0	RUN LEVEL1	1418
<b>safetyDistWorkpIn</b> 602008	<b>Safety clearance on machined part inside (SIT)</b> Global safety clearance to the prepared workpiece—inside <b>Format:</b> Numerical value <b>Input:</b> 0.000 to 100 000.000 [mm] <b>Default:</b> 0	RUN LEVEL1	1418

Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>DefaultG14</b> 602009	<p><b>Tool change position "GWW" for new units</b></p> <p>Specify the default setting for the axis order in the START unit (GWW parameter) that is used to approach the tool change position.</p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b> No axis 0: Simultaneous 1: First X, then Z 2: First Z, then X 3: Only X 4: Only Z</p> <p><b>Default:</b> 0: Simultaneous</p>	RUN LEVEL1	1419
<b>DefaultCLT</b> 602010	<p><b>Coolant for new units</b></p> <p>Specify the default setting for the coolant in the START unit (CLT parameter).</p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b> 0: Without 1: Circuit 1 on 2: Circuit 2 on</p> <p><b>Default:</b> 1: Circuit 1 on</p>	RUN LEVEL1	1419
<b>DefaultG60</b> 602011	<p><b>Protection zone "G60" for new units</b></p> <p>Specify the default setting for the protection zone in the START unit (parameter G60).</p> <p><b>Format:</b> Selection menu</p> <p><b>Input:</b> 0: Active 1: Inactive</p> <p><b>Default:</b> 0: Active</p>	RUN LEVEL1	1419
<b>DefGlobG47P</b> 602012	<p><b>Global safety clearance G47</b></p> <p>Specify here the default setting for the global safety clearance in the START unit (parameter G47).</p> <p><b>Format:</b> Numerical value</p> <p><b>Input:</b> -999999999 to 999999999 [mm] Max. 9 decimal places</p> <p><b>Default:</b> 2 [mm]</p>	RUN LEVEL1	1419



Parameter MP number iTNC MP number	Function and input	Reaction/ Access	Page
<b>DefGlobG147SCI</b> 602013	<b>Global safety clearance G147 in the plane</b> Specify here the default setting for the global safety clearance in the plane for the START unit (SCI parameter). <b>Format:</b> Numerical value <b>Input:</b> –999999999 to 999999999 [mm] Max. 9 decimal places <b>Default:</b> 2 [mm]	RUN LEVEL1	1419
<b>DefGlobG147SCK</b> 602014	<b>Global safety clearance G147 in infeed direction</b> Specify here the default setting for the global safety clearance in infeed direction for the START unit (SCK parameter). <b>Format:</b> Numerical value <b>Input:</b> –999999999 to 999999999 [mm] Max. 9 decimal places <b>Default:</b> 2 [mm]	RUN LEVEL1	1419
<b>DefGlobOverMeasl</b> 602015	<b>Global oversize in X direction</b> Specify here the default setting for the global safety clearance in X direction for the START unit (I parameter). <b>Format:</b> Numerical value <b>Input:</b> –999999999 to 999999999 [mm] Max. 9 decimal places <b>Default:</b> 0.5 [mm]	RUN LEVEL1	1419
<b>DefGlobOverMeasK</b> 602016	<b>Global oversize in Z direction</b> Specify here the default setting for the global safety clearance in Z direction for the START unit (K parameter). <b>Format:</b> Numerical value <b>Input:</b> –999999999 to 999999999 [mm] Max. 9 decimal places <b>Default:</b> 0.2 [mm]	RUN LEVEL1	1419
<b>DefaultM3M4</b> 602017	<b>Rotational direction for new units</b> Default for the spindle "direction of rotation MD" in the "Tool" tab when creating/opening a new unit. <b>Format:</b> Selection menu <b>Input:</b> M3 M4 <b>Default:</b> M3	RUN LEVEL1	1419



# 5 Modules and PLC Operands

## 5.1 Overview of Modules

Module	Function	SW version	Page
9000/ 9001	Copy in the marker or word range	597 110-01	1752
9002	Read the inputs of a PLC input/output unit	597 110-01	1366
9003	Transfer the analog input of the MC	597 110-01	1368
9004	Build the edges of PLC inputs	597 110-01	1366
9005	Set the outputs of a PLC input/output unit	597 110-01	1367
9006	Set and start PLC timer	597 110-01	1530
9010/ 9011/ 9012	Read in the word range	597 110-01	1753
9019	Size of the processing stack	597 110-01	1660
9020/ 9021/ 9022	Write in the word range	597 110-01	1754
9025	Write as BCD code	597 110-01	–
9030	Read machine parameter for Hirth coupling	597 110-01	–
9034	Load a machine parameter subfile	597 110-01	386
9035	Read NC status information <ul style="list-style-type: none"> <li>■ Function 9: Read assigned handwheel axis</li> <li>■ Function 26: Read jog increment</li> </ul>	597 110-01	1346
9036	Write NC status information <ul style="list-style-type: none"> <li>■ Function 6: Select handwheel axis</li> <li>■ Function 7: Set handwheel transmission ratio</li> <li>■ Function 10: Limit value for jog increment</li> </ul>	597 110-01	1345
9037	Read the safety-oriented status	597 110-01	–
9038	Read the status information of axes	597 110-01	671
9040	Read axis coordinates (format 0.001 mm)	597 110-02	674
9041	Read axis coordinates (format 0.0001)	597 110-01	675
9048	Interrogate the operating states of axes	597 110-05	687
9049	Read position value and speed value of an axis	597 110-03	673
9050	Conversion from binary → decimal	597 110-01	1755
9051	Conversion from binary → decimal (format)	597 110-01	1756
9052	Convert decimal string to decimal number with an exponent	597 110-01	1757
9053	Conversion binary → ASCII/hexadecimal	597 110-01	1757
9054	Conversion ASCII/hexadecimal → binary	597 110-01	1758
9055	Convert time (binary) to formatted string	597 110-01	1380
9065	Status of the commissioning function	597 110-05	1069
9066	Status of HEIDENHAIN hardware	597 110-04	979
9067	Status of HEIDENHAIN software	597 110-04	980

Module	Function	SW version	Page
9070	Copy a number from a string	597 110-01	1730
9071	Find the string length	597 110-01	1731
9072	Copy a byte block into a string	597 110-01	1731
9073	Copy a string into a byte block	597 110-01	1732
9084	Display PLC error messages with additional data	597 110-01	1271
9085	Display PLC error message	597 110-01	1272
9086	Clear PLC error message	597 110-01	1273
9087	Status of PLC error message	597 110-01	1274
9095	Activate axis-error compensation	597 110-01	719
9100	Assign data interface	597 110-01	1796
9101	Release data interface	597 110-01	1797
9102	Status of data interface	597 110-01	1798
9103	Transmit string through data interface	597 110-01	1799
9104	Receive string through data interface	597 110-01	1800
9105	Transmit binary data through data interface	597 110-01	1801
9106	Receive binary data through data interface	597 110-01	1802
9107	Binary data from receive buffer	597 110-01	1803
9110	Transmit a message via LSV2	597 110-01	
9111	Receive a message via LSV2	597 110-01	1804
9112	Transmit ASCII characters via data interface	597 110-01	1805
9113	Receive ASCII characters via data interface	597 110-01	1806
9117	Reset a BIS C-6002 BALLUFF identification system	597 110-04	–
9118	Read and convert data from a BIS C-6002 BALLUFF identification system	597 110-04	–
9119	BIS C-6002 BALLUFF processor unit: Write tool data to a data carrier	597 110-04	–
9120	Position PLC axis	597 110-01	692
9121	Stop PLC axis	597 110-01	693
9122	Status of PLC axis	597 110-01	694
9123	Traverse the reference marks of PLC axes	597 110-01	695
9124	Feed rate override for PLC axis	597 110-01	696
9125	Stop PLC axis at next Hirth grid position	597 110-01	704
9126	Configure axis coupling	597 110-04	773
9127	Request status of an axis coupling	597 110-04	774
9128	Torque limiting by the PLC (in mA or %)	597 110-04	897
9129	Status of torque limiting by the PLC	597 110-04	898
9133	Download the internal ADCs	597 110-01	962
9143	Activate motor brake test	597 110-05	987
9144	Configuration of the emergency stop test	597 110-04	994
9145	Actual-to-nominal value transfer	597 110-01	851
9146	Save and reestablish actual position values	597 110-04	–
9147	Set a reference value	597 110-02	–
9149	Read or set the commutation angle of an axis	597 110-05	–

Module	Function	SW version	Page
9155	Switch axes from closed-loop to open-loop condition	597 110-04	685
9156	Switch axes from open-loop to closed-loop condition	597 110-04	686
9157	Transfer the status of the drive controller	597 110-01	882
9158	Torque limiting by the PLC (in mA)	597 110-04	899
9159	200 ms early warning for standstill of the drives	597 110-01	883
9160	Interrogate the status of temperature and I2t monitoring	597 110-01	971
9161	Enable the drive controller (current controller)	597 110-01	883
9162	Interrogate the status of the drive controllers (speed controllers)	597 110-01	883
9163	Switch between wye/delta	597 110-01	1031
9164	Read the actual speed value of a motor	597 110-01	855
9165	Sample the current motor temperature	597 110-01	963
9166	Read momentary utilization of drive motor	597 110-01	978
9167	Supply voltage monitoring	597 110-01	963
9168	Read the commissioning status	597 110-05	
9169	Axis-specific input "speed 0"	597 110-03	883
9171	Spindle orientation (when using the symbolic API, use <b>Module 9414</b> )	597 110-01	1021
9173	Activate speed-dependent monitoring of the wye/delta switchover	597 110-01	937
9174	Read momentary spindle status in reference to the wye/delta switchover	597 110-01	937
9180	Keystroke simulation	597 110-01	1326
9181	Disable NC key by PLC	597 110-01	1326
9182	Re-enable NC key by PLC	597 110-01	1327
9183	Disable NC key groups by PLC	597 110-01	1327
9184	Re-enable locked NC key groups by PLC	597 110-01	1328
9189	Shut down the control	597 110-01	1323
9190	Start the PLC operating hours counter	597 110-01	1376
9191	Stop the PLC operating hours counter	597 110-01	1376
9192	Transfer the operating hours counter	597 110-01	1377
9193	Set the operating hours counter	597 110-01	1377
9194	Alarm when operating time exceeded	597 110-01	1378
9195	Transfer the real-time clock	597 110-01	1380
9196	Find the PLC cycle time	597 110-01	1481
9197	Start cyclic timers	597 110-01	1531
9220	Traverse the reference mark	597 110-01	793
9221	Start a PLC positioning movement	597 110-01	697
9222	Request the status of a PLC positioning movement	597 110-01	698
9224	Stop PLC positioning movements	597 110-01	699
9226	Set the status for an axis	597 110-03	–
9227	Position auxiliary axes and NC axes	597 110-04	700
9231	Compensation of thermal expansion	597 110-01	722

Module	Function	SW version	Page
9240	Open a file	597 110-01	1606
9241	Close a file	597 110-01	1607
9242	Position in a file	597 110-01	1608
9243	Read from a file line by line	597 110-01	1609
9244	Write to a file line by line	597 110-01	1610
9245	Read a field from a table	597 110-01	1611
9246	Write to a field in a table	597 110-01	1612
9247	Search for a condition in a table	597 110-01	1613
9248	Copy, rename or delete a file	597 110-01	–
9249	Transfer BS variable "errno"	597 110-01	1614
9250	Start the table editor by PLC	597 110-05	1615
9251	Stop the table editor by PLC	597 110-05	1617
9252	Position the cursor in the table editor	597 110-05	1618
9255	Read a field from a table	597 110-01	1619
9256	Write to a field in a table	597 110-01	1620
9260	Receive events and wait for events	597 110-01	1738
9261	Send events	597 110-01	1740
9262	Context change between spawn processes	597 110-01	1741
9263	Interrupt a spawn process for a defined time	597 110-01	1741
9264	Wait for a condition	597 110-01	1742
9270	Read an entry from the CfgOemString configuration object	597 110-02	–
9271	Write an entry to the CfgOemString configuration object	597 110-02	–
9275	Write ASCII data into the log	597 110-01	1275
9276	Write operand contents into the log	597 110-01	1276
9277	Write data into the OEM log	597 110-01	1266
9279	Shutdown by PLC	597 110-01	1324
9285	Set OEM access rights	597 110-04	1238
9321	Find the current block number	597 110-01	1246
9322	Request information of the current NC program	597 110-02	1246
9330	Read the status of an OEM application	597 110-01	–
9331	Send data to the OEM application	597 110-01	–
9332	Receive data from the OEM application	597 110-01	–
9355	Interrogate tool life	597 110-05	–
9360	Monitor the temperature of the power modules	597 110-01	964
9367	I2t monitoring	597 110-01	972
9382	Profibus: Read data from a DPV1 data block of analog SIEMENS AS-i slaves (to Module 9385)	597 110-01	–
9383	Profibus: Set data for a DPV1 data block of analog SIEMENS AS-i slaves (from Module 9386)	597 110-01	–
9385	Profibus: Read DPV1 data	597 110-01	–
9386	Profibus: Send DPV1 data	597 110-01	–
9404	Beginning of a movement within an active strobe (channel-specific)	597 110-01	1250

<b>Module</b>	<b>Function</b>	<b>SW version</b>	<b>Page</b>
9410	Read spindle status	597 110-01	1017
9411	Read spindle position / speed	597 110-01	676
9412	Stop the spindle	597 110-01	1018
9413	Move the spindle	597 110-01	1019
9414	Position the spindle	597 110-01	1027
9415	Synchronize spindles	597 110-01	1035
9416	Select gear range and assigned settings for spindle	597 110-02	1568
9417	Set default shaft speed for spindle	597 110-02	1020
9418	Set status for spindle	597 110-02	684
9429	Interrogate the status of the executed NC program	597 110-04	1248
9430	Temporarily change the numeric value of a machine parameter	597 110-01	391
9431	Read the numeric value of a machine parameter	597 110-01	392
9432	Temporarily change the string value of a machine parameter	597 110-01	393
9433	Read the string value of a machine parameter	597 110-01	394
9434	Select parameter set	597 110-01	406
9435	Determine the active parameter set	597 110-01	407
9436	Change the numeric value of a machine parameter permanently	597 110-05	395
9438	Change the string value of a machine parameter permanently	597 110-05	396
9440	SQL: Open a transaction	597 110-01	1635
9441	SQL: Save changes and end the transaction	597 110-01	1636
9442	SQL: Find a record in the result set	597 110-01	1637
9443	SQL: Get a record from the result set	597 110-01	1638
9444	SQL: Change a record in the result set	597 110-01	1639
9445	SQL: Read a single value in a table	597 110-01	1640
9447	SQL: Delete record from result set	597 110-01	1641
9448	SQL: Load column description	597 110-01	1642
9449	SQL: Extract a value from a list separated by comma	597 110-01	1643
9450	Execute SQL command	597 110-01	1644
9451	SQL: Reject changes and end transaction	597 110-01	1645
9452	SQL: Find next record in the result set of a query	597 110-01	1646
9453	SQL: Pull binary data from the query result	597 110-01	1647
9454	SQL: Update binary data in the result set of a query	597 110-01	1648
9455	SQL: Read a single numeric value in a table	597 110-01	1649
9458	SQL: Unload column description	597 110-01	1650
9459	SQL: Change or insert a value in a list separated by comma	597 110-01	1651
9480	Select the channel display	597 110-04	1412
9481	Find the channel display	597 110-04	1413
9482	Select the spindle display	597 110-04	1413
9483	Find the spindle display	597 110-04	1414



## 5.2 Overview of the PLC Operands

### 5.2.1 PLC operands of the General Data group

	Operand	Description	SW version	Page
<b>General – Control configuration</b>				
D	NN_GenOmgCount	Number of configured operating mode groups	597 110-01	–
D	NN_GenChnCount	Number of configured machining channels	597 110-01	614
D	NN_GenAxCount	Number of configured logical axes (including spindles)	597 110-01	615
D	NN_GenSpiCount	Number of configured spindles	597 110-01	999
<b>General – Control status</b>				
D	NN_GenOmgManual	Selected operating mode group for manual control	597 110-01	1236
D	NN_GenChnManual	Selected machining channel for manual control	597 110-01	1252
D	NN_GenSpiManual	Selected spindle for manual control	597 110-01	1252
M	NN_GenCycleAfterPowerOn (M4172)	First PLC scan after power on	597 110-01	1314
M	NN_GenCycleAfterPlcStop (M4173)	First PLC scan after interruption of the PLC program	597 110-01	1314
M	NN_GenCycleAfterReConfig (M4174)	First PLC scan after changing of the configuration data	597 110-01	1314
M	NN_GenNcnInitialized (M4184)	Control is being initialized (after start-up cycles)	597 110-01	1314
M	NN_GenNcEmergencyStop (M4178)	Control in external emergency stop state	597 110-01	990
<b>General – Error handling</b>				
M	NN_GenApiModuleError (M4203)	An error occurred while using an API module.	597 110-01	–
D	NN_GenApiModuleError Code (W1022)	Error code that occurred while using an API module.	597 110-01	–
M	PP_GenReactApiModuleError	Perform the configured reaction to errors in an API module: The reaction defined in CfgPlcOptions apiErrorReaction is only performed if this marker is set.	597 110-01	–





	<b>Operand</b>	<b>Description</b>	<b>SW version</b>	<b>Page</b>
<b>General – Key information</b>				
D	NP_GenKeyCode (W274)	Code of the depressed key	597 110-01	1325
D	NP_GenModCode (D276)	Code of the code number last entered	597 110-01	1231
M	PP_GenHandwheelLocked (M4576)	Disable handwheel motion	597 110-01	1338
<b>General – Measuring touch probe</b>				
M	NN_GenTchProbeReady	Touch probe ready (hardware signal)	597 110-01	1384
M	NN_GenTchProbeDeflected	Stylus deflected (hardware signal)	597 110-01	1384
M	NN_GenTchProbeBatteryLow	Battery voltage too low (hardware signal)	597 110-01	1384
M	NN_GenTchProbeX13	TT (at X13) active for tool measurement	597 110-01	1384
<b>General – Safety self-test / Emergency stop test</b>				
M	NN_GenSafetySelftest (M4282)	Control performs a self-test	597 110-01	992
<b>General – Table editor</b>				

## 5.2.2 PLC operands of the Operating Mode Group group

	Operand	Description	SW version	Page
<b>OMG – Operating modes</b>				
D	NN_OmgChnCount	Number of machining channels in this operating mode group		–
D	NN_OmgChn	Assigned channels in this operating mode group		–
M	NN_OmgManual (M4150)	Manual Operation operating mode	597 110-01	1236
M	NN_OmgHandwheel (M4151)	Electronic Handwheel operating mode	597 110-01	1236
M	NN_OmgMdi (M4152)	Positioning with Manual Data Input operating mode	597 110-01	1236
M	NN_OmgProgramSingle (M4153)	Program Run, Single Block operating mode	597 110-01	1236
M	NN_OmgProgramRun (M4154)	Program Run, Full Sequence operating mode	597 110-01	1236
M	NN_OmgReference (M4155)	Reference operating mode	597 110-01	1236
M	NN_OmgJogIncrement (M4579)	Incremental Jog operating mode	597 110-01	1236
D	NN_OmgAuxiliaryMode	Product-specific code for special modes and submodes	597 110-01	1237
M	PP_OmgHandwheelNotAllowed	Reserved for advanced handwheel functions (disable activation of the HR 420/5** handwheel for this operating mode group)	597 110-04	–
M	NN_OmgHandwheelControl	Reserved for advanced handwheel functions (operation via the HR 420/5** handwheel for this operating mode group)	597 110-04	–
<b>OMG – Program run</b>				
M	PP_OmgNcStart	NC start for all machining channels of this operating mode group	597 110-01	1240
M	PP_OmgNCStop	NC stop for all machining channels of this operating mode group	597 110-01	1240

### 5.2.3 PLC operands of the Machining Channels group

	Operand	Description	SW version	Page
<b>Channel – Configuration</b>				
D	NN_ChnAxisCount	Number of axes of this machining channel	597 110-01	618
D	NN_ChnAxis	Array DI[8] of the axes of this machining channel	597 110-01	618
<b>Channel – Error handling</b>				
M	NN_ChnErrorWarning	Error or warning occurred	597 110-01	1251
M	NN_ChnErrorFStop (M4220)	Feed stopped because of an error	597 110-01	1251
M	NN_ChnErrorNCStop (M4221)	NC stop because of an error	597 110-01	1251
M	NN_ChnErrorCancel (M4223)	Program canceled because of an error	597 110-01	1251
M	NN_ChnErrorEmergency Stop (M4222)	Emergency stop because of an error	597 110-01	1251
M	NN_ChnErrorReset	Reset because of an error	597 110-01	1251
<b>Channel – Program run</b>				
M	PP_ChnNcStart (M4564)	NC start or cycle on	597 110-01	1241
M	PP_ChnNCStop (M4560)	NC stop or cycle off	597 110-01	1243
M	NN_ChnNcStartExtern Request	External request for an NC start	597 110-01	1241
M	NN_ChnNcStopExtern	NC stop or cycle off	597 110-01	1243
M	NN_ChnControlInOperation (M4176)	Control is in operation	597 110-01	1249
M	NN_ChnProgStoppedAsync	Asynchronous NC program interruption	597 110-01	1243
M	NN_ChnProgStopped	NC program interruption	597 110-01	1243
M	NN_ChnProgCancel	NC program cancelation	597 110-01	1244
M	NN_ChnProgEnd	End of NC program reached	597 110-01	1242
M	NN_ChnAutostart (M4182)	Autostart function: Request for program start	597 110-01	–
M	NN_ChnAutostartTime Expired	Autostart function: Request for program start	597 110-01	–
M	PN_ChnAutostartEnable (M4586)	Enable autostart	597 110-01	–
M	NP_ChnProgSelected (M4181)	NC program was selected: Support depends on the product	597 110-04	–

	<b>Operand</b>	<b>Description</b>	<b>SW version</b>	<b>Page</b>
M	NN_ChnBlockScan (M4158)	Mid-program startup (or block scan) active	597 110-01	1245
M	NN_ChnBlockScanStrobe Transfer (M4161)	Restore status at block scan (M/S/T/Q transfer)	597 110-01	1245
M	NN_ChnProgManTraverse (M4156)	Manual traverse of the axes active (for lathes: inspection operation)	597 110-01	1244
M	NN_ChnProgReturnContour (M4157)	Return to contour active (after manual traverse or block scan)	597 110-01	1244
M	NN_ChnTchProbeCycle	Probing process active		1381
M	PP_ChnTchProbeMonitor	NC stop in all operating modes if stylus is deflected		1381
<b>Channel – Feed rate</b>				
D	NN_ChnProgFeedMinute (D360)	Programmed feed per minute [mm/rev]	597 110-01	846
D	NN_ChnProgFeedRevolution	Programmed feed per revolution [mm/min]	597 110-01	846
D	NN_ChnProgFeedThread	Programmed feed rate per thread [mm/rev]	597 110-01	846
M	NN_ChnFeedMinuteActive	Feed rate per minute active	597 110-01	846
M	NN_ChnFeedRevolution Active	Feed per revolution is active	597 110-01	846
M	NN_ChnFeedThreadActive	Feed rate per thread active	597 110-01	846
M	NN_ChnFeedRapidTraverse Active (M4180)	Rapid traverse active (FMAX)	597 110-04	846
D	NN_ChnContourFeed (D388)	Current contouring feed rate [mm/min]	597 110-01	846
D	PP_ChnContourFeedMax (D596)	Max. feed rate from PLC [mm/min]	597 110-01	846
D	NN_ChnFeedOverrideInput (W494)	Feed-rate override set [%]	597 110-01	1358
D	PP_ChnFeedOverride (W766)	Feed-rate override entered by the PLC [%]	597 110-01	1358
D	NN_ChnRapidFeedOverride Input (W496)	Rapid traverse override set [%]	597 110-01	–
D	PP_ChnRapidFeedOverride (W752)	Rapid traverse override entered by the PLC [%]	597 110-01	–
D	PP_ChnConfigOverride	Configurable override (e.g. rapid traverse)	597 110-01	–
M	PP_ChnFeedEnable	Feed-rate enable for all axes	597 110-01	852

	<b>Operand</b>	<b>Description</b>	<b>SW version</b>	<b>Page</b>
M	PP_ChnWorkFeedEnable	Enabling of machining feed rate: if this marker is not set, only rapid-traverse movements are permitted.	597 110-01	852
M	NN_ChnToolLifeExpired	Tool life 1 expired		–
<b>Channel – Status</b>				
M	PP_ChnRapidTraverseKey (M4561)	Rapid-traverse key	597 110-01	–

## 5.2.4 PLC operands of the Axis group

	<b>Operand</b>	<b>Description</b>	<b>SW version</b>	<b>Page</b>
<b>Axis – Configuration</b>				
D	NN_AxLogNumber	Logical axis number (identical to the axis number from "Axes of the machining channel") –1: Axis is deactivated	597 110-01	615
<b>Axis – Drive</b>				
M	NN_AxDriveReady	Axis drive is ready	597 110-01	848
M	PP_AxDriveOnRequest (CM9161)	Switch axis drive on	597 110-01	848
M	NN_AxDriveOn (CM9162)	Axis drive is switched on (and is at least speed-controlled)	597 110-01	848
M	PP_AxPosControlRequest (W1040)	Position-control the axis	597 110-01	848
M	NN_AxPosControl (W1024)	Axis is position-controlled	597 110-01	848
M	PP_AxValueActToNominal	Actual-to-nominal value transfer	597 110-01	851
M	NN_AxCorrectingLagError	Following error eliminated	597 110-01	851
M	PP_AxClampModeRequest (W1038)	Prepare to open the position control loop	597 110-01	850

	<b>Operand</b>	<b>Description</b>	<b>SW version</b>	<b>Page</b>
<b>Axis – Control</b>				
M	NN_AxReferenceAvailable (W1032)	Reference mark not yet traversed	597 110-01	804
M	PP_AxReferenceEndPosition (W1054)	Reference end position	597 110-01	804
D	PP_AxManualFeedMax	Maximum axis feed rate in all operating modes [mm/rev]	597 110-01	847
M	PP_AxFeedEnable (W1060)	Axis-specific feed-rate enable	597 110-01	852
M	NN_AxMotionRequest	Axis movement by the interpolator	597 110-01	957
M	NN_AxInMotion (W1028)	Axes in motion	597 110-01	958
M	NN_AxInPosition (W1026)	Axes in position	597 110-01	957
M	NN_AxStopExtern	Axis motion is stopped and canceled by run-time system (e.g. upon demand by functional safety FS)	597 110-05	–
M	PP_AxTraversePos (W1046)	Manual traverse in positive direction	597 110-01	847
M	PP_AxTraverseNeg (W1048)	Manual traverse in negative direction	597 110-01	847
M	PP_AxHandwheelLocked (W1062)	Disable handwheel motion for specific axes	597 110-01	1338
M	PP_AxDeactivateMonitoring (W1042)	Deactivate monitoring functions	597 110-01	947
M	NN_AxLubricationPulse (W1056)	Lubrication pulse: Value in MP_lubricationDist exceeded. Remains set until the path is reset by PP_AxLubricationDistReset.	597 110-01	690
M	PP_AxLubricationDistReset (W1058)	Reset the accumulated distance	597 110-01	690

## 5.2.5 PLC operands of the Spindle group

	Operand	Description	SW version	Page
<b>Spindle – Configuration</b>				
D	NN_SpiLogNumber	Logical axis number of the spindle	597 110-01	999
<b>Spindle – Drive</b>				
M	NN_SpiDriveReady	Spindle drive is ready	597 110-01	1015
M	PP_SpiDriveOnRequest (CM9161)	Switch spindle drive on	597 110-01	1015
M	NN_SpiDriveOn (CM9162)	Spindle drive is switched on (and is at least speed-controlled)	597 110-01	1015
<b>Spindle – Control</b>				
M	NN_SpiReferenceAvailable (M4018)	Reference position found	597 110-01	1000
M	PP_SpiReferenceMarkSignal	Trip dog	597 110-01	1000
D	PP_SpiSpeedMax (D604)	Maximum spindle speed	597 110-01	1016
M	PP_SpiEnable (M4008)	Spindle enabling	597 110-01	1016
M	NN_SpiMotionRequest (M4000)	Spindle movement by interpolator	597 110-01	957
M	NN_SpiInMotion (M4002)	Spindle in motion	597 110-01	1016
M	NN_SpiSpeedOK (M4001)	Spindle speed reached	597 110-01	1024
M	NN_SpiControl	Spindle in position control loop	597 110-01	1028
M	NN_SpiControlInPos (M4000)	Spindle in position	597 110-01	1028
M	NN_SpiSyncSpeed	Rotational speed synchronism active	597 110-01	1034
M	NN_SpiSyncAngle	Angle synchronism active	597 110-01	1034
M	NN_SpiSyncReached	Synchronism attained	597 110-01	1034
D	NN_SpiOverrideInput (W492)	Speed override set [%]	597 110-01	1356
D	PP_SpiOverride (W764)	Speed override entered by the PLC [%]	597 110-01	1356
M	NN_SpiTapping (M4030)	Tapping active	597 110-01	1028
M	NN_SpiRigidTapping (M4031)	Tapping with spindle interpolated with Z axis active	597 110-01	1028






# 6 Configuring the Axes and Spindle

## 6.1 Machine Structure

### 6.1.1 Adapting the MANUALplus 620 to the machine



Legend:

- OMG: Operating mode group (OperatingModeGroup)
- CH: Machining channel (NC channel)
- Axis: Axis or spindle

Use the following organizational structure to configure the machine structure in the MANUALplus 620:

- The machine consists of operating mode groups (OMGs).
- Every operating mode group manages machining channels.
- Every machining channel manages axes.

The operating mode groups of a machine as well as the machining channels of an operating mode group operate independently of each other.

All machines have this organizational structure – even if a simple machine requires only one OMG and one channel.

A structure for simulation corresponding to the physical structure of the machine must be configured. As a rule, the machine structure and the structure for simulation have the same configuration.

## 6.1.2 Definition of axes

Settings in the configuration editor	MP number
System CfgAxes <b>axisList</b> <b>specCoordSysList</b>	100001 100003

PLC operand / Description	Type
NN_GenChnCount Number of configured machining channels	D

### Defining the logical axes

Within the geometry and interpolator processing, a unique identifier (=logical axis number) must be assigned to each axis. The identifier corresponds to the index in **MP\_axisList**. Logical axes are defined by sequential numbering starting from the index [0].

The definition of the logical axes is independent of their assignment to the machining channels.

- ▶ Enter the axes of all channels of the machine, including spindles and PLC axes.

#### MP\_axisList

Key names for all axes on the machine  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: List with all axes of the machine

max. 20 entries allowed

Index = logical axis number

[0]: Key name from Axes/PhysicalAxis for logical axis 0

[1]: Key name from Axes/PhysicalAxis for logical axis 1

[2]: Key name from Axes/PhysicalAxis for logical axis 2

[3]: Key name from Axes/PhysicalAxis for logical axis 3

.

.

.

[19]: Key name from Axes/PhysicalAxis for logical axis 19

Default: –

Access: LEVEL3

Reaction: RESET

The PLC indicates the number of configured logical axes in **NN\_GenAxCount**. The logical axis number is listed in **NN\_AxLogNumber**; it is needed as axis number in different PLC modules, for example (e.g. 9165).

**NN\_AxLogNumber changes its value if you deactivate an axis with Modules 9226 or 9418.** **NN\_AxLogNumber** is set to the value -1 for deactivated axes. **NN\_AxLogNumber** shows the current operating status of the axis and therefore does not change immediately when the module is called, but rather a little later.



Note

Please note that activating a deactivated axis can take up to half a second.

The logical axis number corresponds to the index from **NN\_ChnAxis** (see "Configuring a machining channel" on page 617).

PLC operand / Description	Type
NN_GenAxCount Number of configured logical axes (including spindles)	D
NN_AxLogNumber Logical axis number (identical to the axis number of "axes of the machining channel") -1: The axis is deactivated (e.g. via Module 9226 or the machine configuration)	D

## Spindles

In the control software, spindles and axes are treated in largely the same way. Spindles are considered a special kind of axis and are defined as a logical axis. For parameters, PLC operands and spindle functions, see "Spindles" on page 998.



## Special kinematics axes

Axes that are used in the kinematic model but are not contained in **CfgAxes/axisList** are defined in **MP\_specCoordSysList**.

► In **MP\_specCoordList**, enter the axes for which in **CfgAxisPropKin/specKinCoordSys** one of the following attributes is defined (see "Kinematic properties of axes" on page 641):

- FixedTransAxis
- DefPointTrans
- DefPointRot

The special kinematics axes are indicated by sequential numbering starting with the index [0].

### **MP\_specCoordSysList**

Key names of special axes for the kinematics description  
Available from NCK software version: 597 110-01.

Format: Array [0...9]  
Input: Max. 18 characters  
Default: [0]: Y1  
Access: LEVEL3  
Reaction: RESET



## 6.2 Configuration of Machining Channels

### 6.2.1 Configuring a machining channel

Settings in the configuration editor	MP number
Channels	
ChannelSettings	
[Key name of the machining channel]	
CfgChannelAxes	
<b>progAxis</b>	200301
<b>restoreAxis</b>	200305
<b>kinModels</b>	200306
<b>deactFastClamping</b>	200307
CfgKinList	
<b>kinCompositeModels</b>	203001
CfgNcErrorReaction	
<b>warningLevel</b>	200601
CfgNcPgmParState	
<b>persistent</b>	200701
<b>currentSet</b>	200702
CfgNcPgmBehaviour	
<b>operatingTimeReset</b>	200801

Two NC channels are permanently defined for the MANUALplus 620 and CNC PILOT 620. The name of the channel is also its key name in the system. The parameters below it are uniquely assigned via the key name.

- **CH\_NC**  
  Machining channel
- **CH\_SIM**  
  Simulation channel

This setting cannot be changed.

#### Axes of machining channel

In the parameter object **CfgChannelAxes**, you specify the axes of the machining channel (NC channel) and define the behavior of the axes during reference run.

In **MP\_progAxis**, enter the axes which can be used within the NC program. Axes that are **not** included are, for example, slave axes in master-slave operation or axes that are for display only.

## MP\_progAxis

Programmable axes  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: Programmable axis names and axis names for the position display in the workpiece system. The key names of the axes are taken from the System/CfgAxes/axisList parameter and automatically shown as a selection menu.

Default: –

Access: LEVEL3

Reaction: RESET

## Deactivating "fast" clamping

There is an accelerated procedure for clamping axes: the unclamping command for an axis is already sent to the PLC before the nominal position value filter. A clamping command is not sent to the PLC until after the nominal position value filter.



### Note

This procedure cannot be used for a central drive, since the clamping and unclamping commands refer to the same axis for a central drive.

## MP\_deactFastClamping

Deactivation of "fast" clamping  
Available from NCK software version: 597 110-03.

Format: Selection menu

Selection: **TRUE**  
Deactivate fast clamping  
**FALSE**  
Axis works with fast clamping

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

In **NN\_ChnAxisCount**, the NC informs the PLC of the number of axes assigned to this machining channel. The axes assigned to this machining channel are indicated in the array **NN\_ChnAxis**.

PLC operand / Description	Type
NN_ChnAxisCount Number of axes of this machining channel	D
NN_ChnAxis Only the axes (and not the spindles) are entered. The order of the entries has no meaning.	D



## Kinematics of machining channel

### Up to HEIDENHAIN NCK software version 597 110-02:

In **MP\_kinModels**, enter the kinematic models of this machining channel. After control start-up, the last entry will be activated.

#### MP\_kinModels

Key names of the available kinematic models for this channel  
Available from NCK software version: 597 110-01.

Format: Array [0...15]  
Input: Key names from CfgKinModels  
Default: -  
Access: LEVEL3  
Reaction: REF

Please also note the documentation regarding the configuration of the machine kinematics under "Machine Kinematics (Up to NC Software 548 328-02)" on page 747.

### As of HEIDENHAIN NCK software version 597 110-03:

Enter in the CfgKinList/kinCompositeModels parameter the key names of the kinematics configurations defined for this machining channel. After control start-up, the last active kinematics description will be used.

## Error behavior of machining channel

The parameter **MP\_warningLevel** specifies the behavior when FN14 errors occur (there are no FN14 errors for lathe controls!). Errors are triggered only if according to the PET table the warning level of the error is maximally as high as the warning level set here. Note that errors with warning level 0 are always triggered and errors with warning level 5 are never triggered.

#### MP\_warningLevel

Warning level of channel  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to 4  
0: FN14 errors with warning level = 0 are triggered  
1: FN14 errors with warning level </= 1 are triggered  
2: FN14 errors with warning level </= 2 are triggered  
3: FN14 errors with warning level </= 3 are triggered  
4: FN14 errors with warning level </= 4 are triggered  
Default: 0  
Access: LEVEL2  
Reaction: RUN

## Saving Q/QS parameters

In the parameter object **CfgNcPgmParState**, you specify whether and where Q/QS parameters are to be stored in non-volatile memory. If **MP\_persistent** is set to **TRUE**, the tool that was last active is displayed again after the control is booted. If the machine parameter is set to **FALSE**, T0 is displayed after the control is booted.

If **MP\_currentSet** is not defined, the name of the machining channel is used as name for the Q/QS parameter set. However, you can also specify any other key name as the name of the Q/QS parameter set. This way you can, for example, save and later restore the Q/QS state with an OEM cycle.

### MP\_persistent

Defines the storage of Q/QS parameters  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: **TRUE**  
Q/QS parameters are stored in non-volatile memory.  
The tool that was last active will be displayed again after the control is booted.  
**FALSE**  
Q/QS parameters are not stored  
The tool T0 will always be displayed after the control is booted.

Default: FALSE  
Access: LEVEL2  
Reaction: RUN

### MP\_currentSet

Name of Q/QS parameter set  
Available from NCK software version: 597 110-01.

Format: String  
Input: Max. 18 characters  
Name of active Q/QS parameter set  
If no name is indicated, the key name of the machining channel is used for storage

Default: –  
Access: LEVEL2  
Reaction: RUN

## Totaling the program machining time

With the **CfgNcPgmBehaviour/operatingTimeReset** parameter you specify whether the machining time is to be totaled, or whether it is reset at each program start.

### MP\_operatingTimeReset

Specify the totaling of the program machining time  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: **TRUE**  
The machining time is reset at each program start  
**FALSE**  
The machining time is totaled

Default: FALSE  
Access: LEVEL3  
Reaction: RESET





## 6.2.2 Traversing the reference marks

Settings in the configuration editor	MP number
Channels	
ChannelSettings	
[Key name of the machining channel]	
CfgChannelAxes	
<b>refAxis</b>	200303
<b>refAllAxes</b>	200304

In **MP\_refAllAxis**, you specify whether all axes are to be referenced in the sequence defined in **MP\_refAxis**, or whether the reference point in these axes is to be traversed by pressing the axis-direction keys.

The automatic or MDI operating mode cannot be used until all axes entered in **MP\_refAxes** have been referenced.

### MP\_refAllAxes

Homing all axes in succession after an NC START  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**

Traverse the reference mark of all axes in succession after an NC START.

**FALSE**

A reference run is not performed for all axes

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

**MP\_refAxis** specifies the axes to be referenced. The sequence of the reference run is determined by the index.

Index [0] = First axis

### MP\_refAxis

Axes that are to be run over the reference point  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: The key names of the axes are taken from the CfgAxes/axisList parameter and automatically shown as a selection menu.

Default: –

Access: LEVEL3

Reaction: RESET

### 6.2.3 Returning to the contour/block scan

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the machining channel] CfgFeedLimits <b>restoreFeed</b>	400309
Channels ChannelSettings [Key name of the machining channel] CfgChannelAxes <b>restoreAxis</b>	200305

With the MANUALplus 620 you can resume an interrupted NC program at the desired block number by scanning the previous blocks (please refer to the User's Manual).

Moving the axes:

- After an NC STOP the axes are moved to the last interpolated position (stop position).
- During a block scan, they are moved to the calculated restore position.

Markers inform the PLC about individual conditions during mid-program startup (block scan). Depending on these markers you can enable certain functions such as the axis-direction buttons for **MANUAL TRAVERSE**.

**NN\_ChNProgManTraverse** is set if the **MANUAL TRAVERSE** soft key is pressed.

**NN\_ChNProgReturnContour** is set if the **RESTORE POSITION** soft key is pressed ("Return to Contour").

**NN\_ChNBlockScan** is set if the **BLOCK SCAN TO BLOCK N** soft key is pressed. **NN\_ChNBlockScan** is reset if the **RESTORE POSITION** or **INTERNAL STOP** soft key is pressed.



To move to the restore position:

- ▶ In **MP\_restoreAxis**, specify the sequence in which the axes are to move.

### **MP\_restoreAxis**

Sequence for returning to the contour

Available from NCK software version: 597 110-03.

Format: Selection menu

Selection: The key names of the axes are taken from the System/CfgAxes/axisList parameter and automatically shown as a selection menu.

Default: –

Access: LEVEL3

Reaction: RESET

- ▶ In **MP\_restoreFeed**, specify the feed rate at which positions are to be approached.

### **MP\_restoreFeed**

Feed rate for returning to the contour

Available from NCK software version: 597 110-02.

Format: Numerical value

Input: Feed rate in [mm/min] or [°/min] for returning to the contour after an NC stop or block scan.

Default: 1200 [mm/min] or [°/min]

Access: LEVEL3

Reaction: RUN

## 6.3 Configuration of Axes

Overview of the types of axes supported by the MANUALplus 620:

■ **Digital axes (not MC 320(T)):**

Closed-loop axes with encoder; controlled by a controller unit (CC)

■ **Analog axes:**

Closed-loop and open-loop axes with and without encoder; with analog output of nominal value

■ **Manual axes:**

Axes with encoder but without motor; these axes can be programmed and are taken into account in the kinematics (e.g. manually operated axes with mechanical handwheels)

■ **Display axes:**

Axes with encoder but without motor; these axes cannot be programmed, and are not taken into account in the kinematics

■ **Virtual axes:**

Axes with neither an encoder nor a motor; however, their nominal values are added to real axes (non-circular grinding)

■ **PLC axes:**

Axes that are controlled by the PLC run-time system, e.g. magazine axes or spindles with coded spindle speed output.

## Specifying the drive-controller hardware

Settings in the configuration editor	MP number
System CfgHardware <b>hardwareType</b>	100101

- Specify the type of the drive-controller hardware with the **MP\_hardwareType** parameter:

### MP\_hardwareType

Type of drive controller hardware

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection:

**automatic**

Automatic identification of controller unit

**CC422**

CC 422 controller unit for conventional axes

**CC424**

CC 424 controller unit for direct drives with high control loop requirements (very short cycle times)

**CC61xx**

CC 61xx controller unit with HSCI interface

**NoCC**

No controller unit installed—select this setting for analog controlled machines (e.g. TNC 320 with MC 320 or MANUALplus 620 with MC 320T with analog interface to the drives)

Default: automatic

Access: LEVEL3

Reaction: RESET

### 6.3.1 Axis designations and coordinates

Principal, parallel and rotary axes are distinguished.


#### Properties of the principal axes X, Y, Z

X, Y and Z axes are principal axes. These axes have a defined spatial orientation in a coordinate system model, and are always linear.

It is of no importance to the editor whether the current coordinate system is that of the machine base system, or is aligned otherwise.

They are the principal coordinates for programming in the editor.

An easy way to remember this system is to use the "right-hand rule":




#### Algebraic signs of the axes

When the programmer writes an NC program, he always assumes that the tool (not the workpiece) is in motion. If the machine moves its workpiece holding element (spindle with C axis) in a particular axis instead of the tool, then the direction of actual motion is opposite to the direction of axis motion. In this case the direction of motion is designated with the same algebraic sign as the axis direction, but with an apostrophe:  $+X'$ ,  $+Y'$  and  $+Z'$


#### Properties of the rotary axis C

For the rotary axis C, the turning axis is in the direction of the principal coordinate Z. The C axis is therefore a "parallel" rotary axis. The direction of the rotary axis C follows the "right-fist rule." The fingers of the closed right hand point in the proper rotation direction of an axis when the thumb points in the direction of the associated linear axis Z. The angle values of the C axis are given with respect to the zero point of the C axis.



**Properties of the linear axes U, V, W**

The additional axes U, V and W are parallel linear axes. They are parallel coordinates for programming in the editor.



**Standard coordinates**

The meanings of the coordinates X, Y, Z, A, B, C, U, V and W are specified in **DIN 66 217**.

The MANUALplus 620 views coordinates whose **MP\_axName** parameter begins with X, Y, Z, A, B, C, U, V or W as standardized coordinates.

For these standardized coordinates, the parameters of the object **CfgProgAxis** must obey the following rules:

First letter of parameter MP_axName	Parameter MP_dir	Parameter MP_progKind
X	XAxis	MainLinCoord
Y	YAxis	MainLinCoord
Z	ZAxis	MainLinCoord
U	XAxis	ParallelLinCoord
V	YAxis	ParallelLinCoord
W	ZAxis	ParallelLinCoord
A	XAxis	ParallelAngCoord
B	YAxis	ParallelAngCoord
C	ZAxis	ParallelAngCoord

### 6.3.2 Programmable axes

Settings in the configuration editor	MP number
Axes CfgProgAxis [Key name of the axis] <b>axName</b> <b>dir</b> <b>progKind</b> <b>index</b> <b>relatedAxis</b>	          300001 300002 300003 300004 300005

In the parameter object **CfgProgAxis**, define and describe all axes that are programmable and/or are displayed. This description is independent of the assignment to NC channels.

For information about programmable axes, see "Standard coordinates" on page 627.

The name entered in **MP\_axName** is used for programming/editing and in the position display.

#### **MP\_axName**

Designation of the axis for position display  
 Available from NCK software version: 597 110-01.

Format: String  
 Input: Max. 1 letter  
 e.g.: X, Y, Z, A, B, C, U, V, W  
 Default: –  
 Access: LEVEL3  
 Reaction: RESET

#### **MP\_dir**

Spatial orientation of the axis or center of rotation  
 Available from NCK software version: 597 110-01.

Format: Selection menu  
 Selection: **XAxis**  
 Motion/rotation in X direction  
**YAxis**  
 Motion/rotation in Y direction  
**ZAxis**  
 Motion/rotation in Z direction  
**SpecAxis**  
 Free/undefined spatial orientation, e.g. for spindle  
 Default: –  
 Access: LEVEL3  
 Reaction: RESET





## MP\_progKind

Type of axis  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **MainLinCoord**  
Main coordinate, always linear (X, Y, Z)  
**ParallelLinCoord**  
Secondary linear coordinate (U, V, W)  
**ParallelAngCoord**  
Parallel coordinate, rotary (A, B, C)  
**SatelliteLinCoord**  
Minor linear coordinate: Reserved, not used at present  
**SatelliteAngCoord**  
Minor rotary coordinate: Reserved, not used at present  
**Spindle**  
Spindle

Default: -

Access: LEVEL3

Reaction: RESET

### Axis without a separate drive motor

Enter the axis name of the assigned physical axis in **MP\_relatedAxis** if the key name of the programmable axis does not correspond to the key name of the physical axis. This links the axis with the physical axis. The axes concerned are usually axes that do not have a separate drive motor.

**Example:** If the spindle drive is used for the C axis, you link the C axis with the physical axis "spindle."

## MP\_relatedAxis

Assigned physical axis  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: Select the key name of the programmable axis from the selection menu.  
Only enter an axis name if the key name of the programmable axis does not correspond to the key name of the physical axis. The key names of the axes are taken from the System/CfgAxes/axisList parameter and automatically shown as a selection menu.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

## Position preset for programmable axes

### Module 9142 Position preset for programmed axis

Use Module 9142 to preset a programmable axis to a new position value. The position value of another axis or a freely selected position value can be transmitted as the target position.

Constraints:

- The module functions only in the cyclic PLC program.
- The position preset is only possible when the control is not active (NN\_ChnControlInOperation=0) or if an M/S/T/G/ strobe is pending.
- When calling the module for an NC axis during a strobe, the synchronization SYNC\_CALC must be configured for this strobe.

Call:

```

PS    B/W/D/K  <>Type of position preset>
          1: For <logical axis number target>, set the new position to
              the <position value>,
              <Logical axis number source> is not necessary.
              (corresponds to CM 9147)
          2: For <logical axis number target>, set the new position to
              the value of <logical axis number source>, <position
              value> is not necessary

PS    B/W/D/K  <>Logical axis number target>
PS    B/W/D/K  <>Logical axis number source>
PS    B/W/D/K  <>Position value>
          Input unit: [0.0001 mm]

CM    9142
PL    D        <>Error code>
          0: Position preset has been read
          1: <Logical axis number target> axis is outside the valid
              range
          2: <Logical axis number target> axis is not configured
          3: Missing strobe or control is active
          4: <Logical axis number source> axis is outside the valid
              range
          5: <Logical axis number source> axis is not configured
          6: <Logical axis number source> axis has not traversed the
              reference position
          7: <Type of position preset> not known
          8: The module was called in a submit/spawn job.
  
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule ErrorCode	0	No error
	2	An invalid axis number was transferred.
	2	An invalid type of position preset was transferred.
	21	Missing strobe or control is active
	24	The module was called in a submit/spawn job.



### 6.3.3 Physical axes

Settings in the configuration editor	MP number
Axes	
PhysicalAxis	
[Key name of the axis]	
CfgAxis	
<b>isAng</b>	300101
<b>isModulo</b>	300102
<b>restoreModuloCntr</b>	300111
<b>isHirth</b>	300103
<b>axisHw</b>	300104
<b>axisMode</b>	300105
<b>testMode</b>	300106
<b>parList</b>	300107
<b>realAxis</b>	300108
<b>noActToNomAtEmSt</b>	300109
<b>deactivatedAtStart</b>	300110
<b>advancedSettings</b>	300112

In the parameter object **PhysicalAxis**, define all axes that can be instructed by the interpolator to execute a command. The description in **PhysicalAxis** is independent of the assignment to NC channels.

In the parameter object **CfgAxis**, you specify the axis type and drive interface, you assign a parameter set to the axis and define the operating mode of the axis.

#### MP\_isAng

Rotary axis

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**

This axis is a rotary axis.

**FALSE**

This axis is a linear axis (not a rotary axis).

Note:

Rotary axes are not allowed as principal axes.

Default: FALSE

Access: LEVEL3

Reaction: RESET

**Position display for rotary axes and PLC auxiliary axes (modulo display)**

In **MP\_isModulo** you define whether the modulo limit of 360 degrees should apply to the position display of rotary axes or PLC auxiliary axes.

**MP\_isModulo**

Modulo display  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: **TRUE**  
Position display for rotary axes: modulo 0 to 360°  
**FALSE**  
Position display is not modulo display.  
Default: FALSE  
Access: LEVEL3  
Reaction: RESET



Note

You must always configure spindles as modulo axes:  
**MP\_isModulo = True.**

In **MP\_restoreModuloCnt**, you specify whether the modulo counter of the axis is to be saved cyclically in SRAM and restored during control startup.

**MP\_restoreModuloCnt**

Save modulo counter of the axis in SRAM  
Available from NCK software version: 597 110-04.  
Format: Selection menu  
Selection: **TRUE**  
The modulo counter of the axis is saved cyclically in SRAM and restored during startup of the MANUALplus 620.  
**FALSE**  
The modulo counter of the axis is not saved in SRAM and not restored during control startup.  
Default: -  
Access: LEVEL3  
Reaction: RUN



Settings in the configuration editor	MP number
Axes PhysicalAxis [Key name of the axis] CfgRollOver <b>shortestDistance</b> <b>startPosToModulo</b> <b>showModuloDisp</b>	    300401 300402 300403

Roll-over axes are rotary axes with modulo counting mode that are able to execute several or any number of revolutions. Example:  
 A machine with C axis as rotary table.

If you want to configure a rotary axis as rollover axis, you have to insert the optional configuration object **CfgRollOver** in the machine configuration for the respective axis.

With the three machine parameters **MP\_shortestDistance**, **MP\_startPosToModulo** and **MP\_showModuloDisp** you define the characteristics of the rollover axis.

Set the parameter **MP\_shortestDistance = on** so that the axis approaches the target position on the shortest path ( $\leq 180^\circ$ ) if programming is non-incremental. The nominal and the target value display is always between  $0^\circ$  and  $360^\circ$ , also with incremental programming.

### MP\_shortestDistance

Traverse path of rotary axis with modulo counting mode  
 Available from NCK software version: 597 110-01.  
 Format: Selection menu  
 Selection: **on**  
           Always approach target position on the shortest path ( $\leq 180^\circ$ )  
           **off**  
           Approach target position without passing over zero  
 Default: No value, parameter optional (= off)  
 Access: LEVEL3  
 Reaction: RUN

Set the parameter **MP\_startPosToModulo = on**, to move the position of the rotary axis into the module limits ( $0 \dots 360^\circ$ ) before the beginning of the positioning block. The **MP\_startPosToModulo** parameter is effective only if you configure **MP\_shortestDistance = off**.

### MP\_startPosToModulo

Rollover axis moves start angle into the range of 0 to 360°  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **on**  
Move the rotary axis into the 0 to 360° range at the beginning of the positioning block.

**off**

Do not move the rotary axis into the 0 to 360° range.

Default: No value, parameter optional (= off)

Access: LEVEL3

Reaction: RUN

The **MP\_showModuloDisp** parameter defines the display type for the modulo axis. Set the parameter to **on** to display the position of the rotary axis within the modulo limits 0 to 360°. The **MP\_showModuloDisp** parameter is effective only if you configure **MP\_shortestDistance = off**.

### MP\_showModuloDisp

Display of rollover axis in the range of 0 to 360°  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **on**  
Display of rollover axis within the modulo limits of 0..360°

**off**

Display of rollover axis not within the modulo limits

Default: No value, parameter optional (= off)

Access: LEVEL3

Reaction: RUN

### Example:

Effect of the **MP\_shortestDistance** and **MP\_startPosToModulo** parameters

Programmed movement	shortestDistance = on			startPosToModulo = on			shortestDistance = off startPosToModulo = off		
	Noml.	Ref	Dist.	Noml.	Ref	Dist.	Noml.	Ref	Dist.
G110 C0	0	0	–	0	0	–	0	0	–
G110 C185	185	–175	–175	185	185	+185	185	185	+185
G110 C–5	355	355	+170	–5	–5	–190	–5	–5	190
G110 C180	180	180	–175	180	180	–175	180	180	+185
G110 C0	0	0	–180	0	0	–180	0	0	–180
G110 Ci 720	0	720	+720	720	720	+720	720	720	+720
G110 Ci –800	280	–800	–800	–800	–800	–800	–80	–80	–800



## Setting the drive interface

Use the **MP\_axisHw** machine parameter to define the drive interface. The parameter defines the hardware type of the axis at the time of the control startup. The parameter is evaluated only if the value "active" was entered in **MP\_axisMode**.

### MP\_axisHw

Hardware to which the axis is connected  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **None**  
No hardware connection (virtual axis)

#### **InOutCC**

Digital axis with connection to a controller unit

#### **AnalogMC**

Analog drive interface; encoder connection to the MC

#### **AnalogCC**

Analog drive interface; encoder connection to the CC

#### **DisplayMC**

Display axis; encoder connection to the MC

#### **DisplayCC**

Display axis; encoder connection to the CC

#### **ManualMC**

Open-loop axis; encoder connection to the MC

#### **ManualCC**

Open-loop axis; encoder connection to the CC

#### **ProfiNet**

Digital Profinet axis (reserved, function not available yet)

Default: InOutCC

Access: LEVEL3

Reaction: RESET

## Activate axis

An axis can only be moved in a closed loop after it has been activated with the **MP\_axisMode** machine parameter.

For commissioning, use the **MP\_testMode** parameter to switch an axis to test mode. In this operation, the interpolator views the axis as a fully-functional axis, but the nominal values are not passed on to the drive motor. There is only an internal nominal-to-actual transfer. Such an axis does not need to have all the hardware connections made (position and speed input, PWM output), but can be "positioned."

For the linear axes X, Y and Z, the default value **Active** of the parameter **MP\_axisMode** must not be changed to **NotActive**; otherwise an error message will be issued. If you want to deactivate one of these axes, you should set the parameter **MP\_testMode** to **True**.

### MP\_axisMode

Axis operating mode  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **NotAllowed**  
Reserved, do not use!  
**NotActive**  
Axis does not exist  
**Active**  
Axis physically present  
**Virtual**  
Virtual axis for superimposed movements  
**PlcControlled**  
e.g. for encoded spindles; axis is controlled solely by the PLC

Default: Active

Access: LEVEL3

Reaction: RESET

### MP\_testMode

Axis in test mode  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**  
Test mode for commissioning, i.e. the axis needs not be connected  
**FALSE**  
Test mode not active.  
If **MP\_axisMode** = **Active**: Axis must be connected electrically

Default: FALSE

Access: LEVEL3

Reaction: RESET



#### Note

Please note that hanging axes cannot be supported in test mode. The PLC must ensure that these axes are braked in test mode.

**Hanging axes need 100 % weight compensation.**



## Assigning parameter sets

In **MP\_parList** enter the key name of the parameter set that is assigned to this axis. The parameter set describes the axis control response, the encoder connection, the encoder signals, etc.

You can create more than one parameter set for one axis. This enables you to define different controller settings, for example.

### Examples:

a) You define different controller settings to ensure appropriate control response depending on the load.

b) The spindle and the C axis are realized by using a physical axis. This enables you to define separate parameter sets for the spindle and the C axis.

### MP\_parList

List of all parameter sets of this axis  
Available from NCK software version: 597 110-01.  
Format: Array [0...9]  
Input: Key name of the parameter set  
Max. 18 characters  
e.g.: ParSetX-0 or PX (parameter set for the X axis)  
Default: –  
Access: LEVEL3  
Reaction: RESET



#### Note

The first parameter set must be fully defined. In **KeySynonym/CfgKeySynonym**, you can relate the other parameter sets to the first one. Then you only have to define the parameters that differ from the ones of the parameter set to which you have related the present parameter set.

## Virtual axis

In **MP\_realAxis**, enter the key name of the associated real axis.

For virtual axes, see "Configuration of Axes" on page 624.

### MP\_realAxis

Key name of the associated real axis  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: The key name of the associated real axis is only to be entered if the current axis is a virtual axis (e.g. for noncylindrical grinding). The key names of the axes are taken from the System/CfgAxes/axisList parameter and automatically shown as a selection menu.  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

## Actual-to-nominal value transfer

In **MP\_noActToNomAtEmSt**, you can define whether an actual-to-nominal value transfer is to be conducted for all axes in an EMERGENCY STOP.

### MP\_noActToNomAtEmSt

Actual-to-nominal value transfer for all axes in an EMERGENCY STOP

Format: Selection menu

Selection: **TRUE**  
No actual-to-nominal value transfer for any axis in an EMERGENCY STOP  
**FALSE**  
The standard control behavior is actual-to-nominal value transfer for all axes in an EMERGENCY STOP.

Default: -

Access: LEVEL3

Reaction: RESET

## Advanced settings for individual axes

Settings in the configuration editor	MP number
Axes PhysicalAxis [Key name of the axis] CfgAxis <b>advancedSettings</b>	300112

With **MP\_advancedSettings**, you can define advanced settings for individual axes. The parameter is bit-encoded (32 bits). Currently (NCK software version 597 110-05) the bits 0, 1 and 2 are evaluated; all other bits are reserved.

#### ■ **MP\_advancedSettings**, bit 0 = 1:

If the current axis is moved by the PLC, the movement is not stopped when the touch probe is deflected. This setting is useful if, for example, certain auxiliary axes (e.g. axes for controlling the tool changer) are to also be moved during a probing process.

Use this setting only for axes that are not involved in the probing process and that cannot mechanically endanger the touch probe!


#### ■ **MP\_advancedSettings**, bit 1 = 1:

A movement of this axis commanded by the PLC (e.g. when the manual direction key is pressed or any other PLC positioning) is no longer made with a bell-shaped acceleration curve (standard behavior) but with a ramp-shaped acceleration profile. You should use this function only in exceptional cases—prefer the bell-shaped acceleration curve instead. This ensures acceleration with minimum machine excitation.

Under certain circumstances, a ramp-shaped acceleration profile (**MP\_advancedSettings**, bit 1 = 1) can improve the time behavior of the axis. The axis thus reaches its programmed speed earlier, which saves time, and higher speeds are attained on short traverse paths. You can still limit the jerk with the **MP\_manualFilterOrder** parameter.



Comparison of the acceleration behavior:



- **MP\_advancedSettings**, bit 2 = 1:  
Only effective for a spindle in position feedback control. If bit 2 = 1, the control does not use the modulo counting mode to calculate the following error (servo lag) that results from acceleration or braking. If a spindle motor tends to vibrate, the control response of the spindle can thus be improved in certain cases. Vibrations are suppressed, but the axis is "lagging" because the following error that has built up is corrected in any case. The nominal speed is reached with some delay because of the reduction of the following error.

## MP\_advancedSettings

Advanced settings for individual axes

Available from NCK software version: 597 110-05.

Format: Numerical value

Input: Bit-encoded advanced axis settings

Max. 32 bits available, of these currently supported:

**Bit 0 = 1:**

A traverse commanded by the PLC is not interrupted if the touch probe is deflected.

**Bit 1 = 1:**

A traverse commanded by the PLC is not made in a bell-shaped curve but at a constant acceleration.

**Bit 2 = 1:**

For a spindle in position feedback control, the following error is not calculated in modulo counting mode.

Default: No value, parameter optional (= all bits = 0)

Access: LEVEL3

Reaction: RUN



### 6.3.4 Kinematic properties of axes

Settings in the configuration editor	MP number
Axes PhysicalAxis [Key name of the axis] CfgAxisPropKin <b>specKinCoordSys</b> <b>kindOfRotAxis</b> <b>presetToAlignAxis</b> <b>hasSpecAxisData</b>	    300201 300202 300203 300204

In the parameter object **CfgAxisPropKin**, specify the properties important for the kinematics configuration.

In **MP\_specKinCoordSys** define whether the assigned coordinate transformation is used for defining a fixed translation axis or a datum (DefPoint).

#### MP\_specKinCoordSys

Type of special coordinate system  
 Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **FixedTransAxis**  
 Translation axis for which no physical axis exists

**DefPointTrans**  
 Coordinate system in the kinematic model of a translation axis to which no physical axis is assigned

**DefPointRot**  
 Coordinate system in the kinematic model of a rotational axis to which no physical axis is assigned

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

For rotary axes, specify in **MP\_kindOfRotAxis** whether the axis concerned can rotate completely or has a limited angle of rotation.

#### MP\_kindOfRotAxis

Type of rotational axis, only for rotary axes  
 Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **RollOver**  
 Axis can roll over

**NotRollOver**  
 Axis has a limited angle of rotation

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

**MP\_presetToAlignAxis** controls the treatment of presets for rotational axes. If the attribute is set to TRUE, the offset from the preset is subtracted from the axis value before the kinematics calculation. If it is set to FALSE, the offset is only effective for the position display of the axis.

**MP\_presetToAlignAxis**

Controls the treatment of the preset for rotational axes  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**  
Offset is subtracted

**FALSE**  
Offset is only effective for the display

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

**MP\_hasSpecAxisData** is only for special axis data—the parameter is not used at present.

**MP\_hasSpecAxisData**

Reserved: Special axis data available, only for special axes  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**  
Special axis data available

**FALSE**  
No special axis data

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET



### 6.3.5 Manually operated axis (counter axis)

An open-loop axis has a position encoder for determining and displaying the current position value. There is no nominal value output for the axis. The target position is set by the machine operator manually (e.g. via mechanical handwheels).

An open-loop axis can be programmed together with closed-loop axes in an NC program. When an NC block with an open-loop axis is reached during machining, a dialog window appears, prompting the machine operator to traverse the axis to the nominal coordinates:

Position the axes manually			
	NOML.	ACTL.	DIST.
B	+25.00000	+17.05070	+7.94930

The dialog window shows the nominal and actual position, as well as the distance-to-go, in **axis coordinates**. The MANUALplus 620 automatically triggers an NC STOP when opening the window. The axis must now be traversed by the machine operator until the target has been reached, taking into account the positioning window defined under **MP\_posTolerance**. The MANUALplus 620 then automatically closes the dialog window. Machining of the NC program is continued with NC START.



#### Note

If an open-loop axis is programmed together with closed-loop axes in an NC block, then the open-loop axis does not have to be traversed to the target position immediately upon appearance of the dialog window. For example, you can first retract the open-loop axis, then position the controlled axes with the NC START key, and then finish positioning the open-loop axis. The dialog window then disappears. Press NC START again to continue the NC program.

## Configuring a manual axis

Settings in the configuration editor	Input:
Axes PhysicalAxis [Key name of the axis] CfgAxis <b>axisHw</b> <b>axisMode</b> ParameterSets [Key name of the axis] CfgReferencing <b>refType</b> CfgControllerAuxil <b>checkPosStandstill</b> CfgEncoderMonitor <b>movementThreshold</b> CfgControllerTol <b>posTolerance</b>	  <b>ManualMC or ManualCC</b> <b>Active</b>  <b>distance coded + on the fly</b> or <b>without switch + on the fly</b>  0 0 Desired positioning window

- ▶ For the manually operated axis, set the **MP\_axisHw** and **MP\_axisMode** machine parameters to the values indicated in the table.
- ▶ Because the control itself cannot move the axis over the reference marks, the reference run mode must be set accordingly:  
 With **MP\_refType** you can either set the value **distance coded + on the fly** or **without switch + on the fly** as the reference run mode..
- ▶ Deactivate standstill monitoring. Set **MP\_checkPosStandstill** = 0.
- ▶ Deactivate movement monitoring for the axis: Set **MP\_movementThreshold** = 0.



## 6.4 Encoders

Encoders report positions and movements of the machine to the MANUALplus 620. HEIDENHAIN contouring controls operate with incremental encoders with a 1 V<sub>PP</sub> signal and absolute encoders with EnDat interface.

In the parameter object **CfgAxisHardware**, define the connections of the encoders, the type of encoder, the type of signals, etc.

### 6.4.1 Type of position encoder

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgAxisHardware	
<b>posEncoderType</b>	400003
<b>distPerMotorTurn</b>	400004
<b>posEncoderDist</b>	400005
<b>posEncoderIncr</b>	400006
CfgReferencing	
<b>endatSerial</b>	400402

The parameter object CfgAxisHardware is not required for:

- Virtual axes (MP\_axisMode = Virtual)
- ▶ In **MP\_posEncoderType**, define the type of position measurement and the type of position encoder or speed encoder.
- ▶ In **MP\_distPerMotorTurn**, define the traverse distance per motor revolution.

## MP\_posEncoderType

	Position measurement via position encoder or motor encoder Available from NCK software version: 597 110-01.
Format:	Selection menu
Selection:	<b>MC_DISTANCE_CODED</b> Distance-coded position encoder on the MC (X01 to X06 and X35 to X38) <b>MC_NOT_DISTANCE_CODED</b> Not a distance-coded position encoder on the MC (X01 to X06 and X35 to X38) <b>MC_ENDAT</b> EnDat position encoder on the MC (X01 to X06 and X35 to X38) <b>NO_ENCODER</b> No position measurement <b>CC_MOTOR_ENCODER</b> Position measurement by speed encoder on the CC (X15 to X20 and X80 to X83) <b>CC_DISTANCE_CODED</b> Distance-coded position encoder on the CC (X201 to X210) <b>CC_NOT_DISTANCE_CODED</b> Not a distance-coded position encoder on the CC (X201 to X210) <b>CC_MOTOR_ENDAT</b> Position measurement by EnDat speed encoder on the CC (X15 to X20 and X80 to X83) <b>CC_EXTERN_ENDAT</b> External EnDat encoder on the CC (X201 to X210) <b>CC_MOTOR_ENDAT_INCR</b> HEIDENHAIN EnDat interface box (EIB) on the CC (X201 to X210) <b>CC_EXTERN_ENDAT_INCR</b> HEIDENHAIN EnDat interface box (EIB) on the CC (X201 to X210) <b>MC_NOT_DISTANCE_CODED_CC_ENDAT</b> In development <b>CC_EXTERN_ENDAT_2_2</b> External EnDat 2.2 encoder on the CC (X201 to X210)
Default:	CC_MOTOR_ENCODER
Access:	LEVEL3
Reaction:	RESET

Connectors X35 to X38, X80 to X83 and X201 to X210 are not available on the MC 420 and MC 320T (only X1 to X4, X5 optional). X35 to X38 are available only on the MC 422x with 10 control loops, X80 to X83 only on the CC 42x with 10 or 12 control loops, and X201 to X210 only on the CC 424.



### Note

When EnDat encoders that have not yet been adjusted are put into service, field orientation must be performed prior to operation, see "Field orientation" on page 1058.

### MP\_distPerMotorTurn

Linear distance of one motor revolution  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 001 to 1000 [mm] or [°]  
Default: 5 [mm] or [°]  
Access: LEVEL3  
Reaction: REF



#### Note

The parameter **MP\_distPerMotorTurn** is not effective for analog axes.

### Connecting encoders through the EIB

The EIB (External Interface Box) makes it possible to connect encoders with incremental 1 V<sub>PP</sub> signals to the purely serial EnDat 2.2 interface of the control. This has the advantage that single-shielded cables with smaller connectors and a smaller diameter can be used as encoder cables. In **MP\_endatSerial**, enter the value TRUE if you want to connect incremental encoders to the EnDat 2.2 interface of the control via an EIB:

### MP\_endatSerial

Connecting incremental encoders via the EIB  
Available from NCK software version: 597 110-04.  
Format: Selection menu  
Selection: **TRUE**  
An incremental encoder is connected to the serial EnDat 2.2 interface via the EIB.  
**FALSE**  
No EIB is used.  
Default: -  
Access: LEVEL3  
Reaction: RUN

## 6.4.2 Signal period of encoders

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisHardware <b>distPerMotorTurn</b> <b>posEncoderDist</b> <b>posEncoderIncr</b> <b>posEncoderRefDist</b>	    400004 400005 400006 400007

For any given distance the position encoder supplies a fixed number of signal periods. The signal (except for EnDat 2.2 encoders) is also interpolated in the control.

The settings you need to define may vary depending on the type of position measurement on your machine.

### Linear encoder

#### General information

The MANUALplus 620 requires the following values:

- ▶ **MP\_posEncoderDist**: For each axis, enter the distance required for the number of grating periods given in **MP\_posEncoderIncr**.
- ▶ **MP\_posEncoderIncr**: Enter the number of grating periods required for the distance given in **MP\_posEncoderDist**.
- ▶ **MP\_distPerMotorTurn**: Enter the traverse distance per motor revolution.

The MANUALplus 620 calculates the quotient:

$$\text{Signal period} = \frac{\mathbf{MP\_posEncoderDist}}{\mathbf{MP\_posEncoderIncr}}$$

The MANUALplus 620 needs the following values for linear encoders with **EnDat 2.1 interface** or for linear encoders with **EnDat 2.2 interface, which supply a grating period**:

- ▶ **MP\_posEncoderDist**: For each axis, enter the length of one grating period of the encoder.
- ▶ **MP\_posEncoderIncr**: Enter the number of increments per grating period.
- ▶ **MP\_distPerMotorTurn**: Enter the traverse distance of the axis per motor revolution.



#### Note

The MC 320 (TNC 320) and MC 320T (MANUALplus 620) main computers do not yet support the connection of EnDat 2.2 encoders.



Linear encoders with an **EnDat 2.2 interface without grating period** may be available in future. In this case, the controller unit will treat the linear encoder as if it had an interpolation of "1." The MANUALplus 620 requires the following values:

- ▶ **MP\_posEncoderDist**: Enter the **resolution** of the linear encoder (indicated on the ID label, e.g. 0.005 µm).



#### Note

The resolution always has to be entered in the unit [mm]!

- ▶ **MP\_posEncoderIncr**: Enter the value 1.
- ▶ **MP\_distPerMotorTurn**: Enter the traverse distance of the axis per motor revolution.

HEIDENHAIN offers incremental linear encoders with **distance-coded reference marks**. The nominal increment between two fixed reference marks depends on the encoder being used.

- ▶ For encoders with distance-coded reference marks, enter for each axis the nominal increment between two fixed reference marks in **MP\_posEncoderRefDist**.

#### Examples:

##### ■ LS 487C:

Incremental linear encoder with distance-coded reference marks. Grating period of 20 µm (1 signal period covers 0.02 mm). Nominal increment between reference marks is 20 mm. The axis moves 10 mm per motor revolution.

**MP\_posEncoderDist** = 0.02

**MP\_posEncoderIncr** = 1

**MP\_distPerMotorTurn** = 10

**MP\_posEncoderRefDist** =  $\frac{20 \text{ mm}}{0,02 \text{ mm}} = 1000$  [signal periods]

##### ■ LC 483:

Absolute linear encoder with EnDat. Grating period of 20 µm (1 signal period covers 0.02 mm). The axis moves 10 mm per motor revolution.

**MP\_posEncoderDist** = 0.02

**MP\_posEncoderIncr** = 1

**MP\_distPerMotorTurn** = 10

##### ■ LC 483 (EnDat 2.2 without signal period):

Absolute linear encoder with EnDat 2.2 without indication of the grating period. Resolution 0.005 µm. The axis moves 10 mm per motor revolution.

**MP\_posEncoderDist** = 0.000005

**MP\_posEncoderIncr** = 1

**MP\_distPerMotorTurn** = 10

## Rotary encoders angle encoder, motor encoder

### General information

The MANUALplus 620 requires the following values:

- ▶ **MP\_posEncoderDist**: For each axis, enter the traverse distance per motor revolution.
- ▶ **MP\_posEncoderIncr**: For each axis, enter the number of grating periods per motor revolution.
- ▶ **MP\_distPerMotorTurn**: For each axis, enter the traverse distance per motor revolution.



#### Note

Ensure that the line count per rotary encoder revolution specified by the manufacturer is entered in the **MP\_posEncoderIncr** parameter. This value is used for the plausibility check of the measured value. If you enter a line count that differs from the one specified by the manufacturer, the MANUALplus 620 displays an error message.

The MANUALplus 620 calculates the quotient:

$$\text{Signal period} = \frac{\mathbf{MP\_posEncoderDist}}{\mathbf{MP\_posEncoderIncr}}$$

For **motor encoders with EnDat 2.2 interface** the MANUALplus 620 requires the following values:



#### Note

Encoders with EnDat 2.2 interface usually do not supply any incremental signals. Only a purely digital measured value is transferred to the MANUALplus 620. For this reason, the number of signal periods per encoder revolution (**MP\_posEncoderIncr**) must be set to the value 1.



#### Note

The MC 320 (TNC 320) and MC 320T (MANUALplus 620) main computers do not yet support the connection of EnDat 2.2 encoders.



The controller unit assumes that the motor encoder has only one line per revolution. Set the following:

- ▶ **MP\_posEncoderDist:** For each axis, enter the traverse distance per motor revolution.
- ▶ **MP\_posEncoderIncr:** Enter the value "1".
- ▶ **MP\_distPerMotorTurn:** For each axis, enter the traverse distance per motor revolution.
- ▶ **CfgServoMotor - MP\_motStr** (401313): Enter the value "1" for the line count of the motor encoder.



#### Note

HEIDENHAIN recommends:

The optimum manufacturing precision can only be attained with linear encoders. A control without linear encoders finds the axis position through the pitch of the ball screw. The problem is, the ball screw gets hot during machining and expands. And the result is a position measurement that deviates from the actual position, causing error. With linear encoders, the control always determines the correct slide position. This means that your machine positions its axes with constantly high precision.

More information is available on the Internet at:

<http://www.heidenhain-shows-the-way.com>

#### Examples:

■ **ERN 1387 – Only motor encoder (no linear encoder):**

Incremental rotary encoder for servo drives. 2048 lines per 360°. The axis moves 10 mm per motor revolution.

**MP\_posEncoderDist** = 10  
**MP\_posEncoderIncr** = 2048  
**MP\_distPerMotorTurn** = 10  
**MP\_posEncoderType** = CC\_MOTOR\_ENCODER

■ **RON 785C on rotary table with direct drive:**

Incremental angle encoder with integral bearing and distance-coded reference marks. 18 000 lines per 360°. 36 reference marks. Nominal increment between reference marks is 20°.

**MP\_posEncoderDist** = 360  
**MP\_posEncoderIncr** = 18000  
**MP\_distPerMotorTurn** = 360  
**MP\_posEncoderRefDist** =  $20 \div \frac{360}{18000} = 1000$  [signal periods]  
**MP\_posEncoderType** = CC\_DISTANCE\_CODED

■ **RCN 729 with gear transmission on rotary table:**

Absolute angle encoder with EnDat 2.1 interface and integral bearing. 32 768 lines per 360°. Gear transmission ratio: 17:1

**MP\_posEncoderDist** = 360  
**MP\_posEncoderIncr** = 32768  
**MP\_distPerMotorTurn** =  $\frac{360}{17} = 21.17647059$   
**MP\_posEncoderType** = CC\_EXTERN\_ENDAT

■ **RCN 2310 on rotary table with direct drive:**

Absolute angle encoder with EnDat 2.2 (without incremental signals). The rotary table moves by 3° per motor revolution.

**MP\_posEncoderDist** = 360

**MP\_posEncoderIncr** = 1

**MP\_distPerMotorTurn** = 3

**MP\_posEncoderType** = CC\_EXTERN\_ENDAT\_2\_2

■ **EQN 1325 – Only motor encoder (no linear encoder):**

Absolute multiturn rotary encoder for servo drives with EnDat 2.1. 2048 lines per 360°. The axis moves 10 mm per motor revolution.

**MP\_posEncoderDist** = 10

**MP\_posEncoderIncr** = 2048

**MP\_distPerMotorTurn** = 10

**MP\_posEncoderType** = CC\_MOTOR\_ENDAT

■ **EQN 1337 – Only motor encoder (no linear encoder):**

Absolute multiturn rotary encoder for servo drives with EnDat 2.2. (without incremental signals). The axis moves 10 mm per motor revolution.

**MP\_posEncoderDist** = 10

**MP\_posEncoderIncr** = 1

**MP\_distPerMotorTurn** = 10

**MP\_posEncoderType** = CC\_MOTOR\_ENDAT





For **spindles**, the MANUALplus 620 requires the following values:

- ▶ **MP\_posEncoderDist**: Enter 360.
- ▶ **MP\_posEncoderIncr**: Enter the line count of the encoder used.
- ▶ **MP\_distPerMotorTurn**: Enter 360.

#### **MP\_posEncoderDist**

Distance for number of signal periods from MP\_posEncoderIncr  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.001 to 100 000 [mm] or [°]  
For spindles: 360°  
For multiturn encoders with EnDat interface:  
Distance per encoder revolution

Default: 5 [mm] or [°]  
Access: LEVEL3  
Reaction: REF

#### **MP\_posEncoderIncr**

Number of signal periods for distance from  
MP\_posEncoderDist  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 1 to 100 000 [incr.]  
Enter the number of increments of the external encoder. For  
spindles you must enter the line count of the rotary encoder  
used.  
For multiturn encoders with EnDat interface:  
Signal periods per encoder revolution

Default: 2048 [incr.]  
Access: LEVEL3  
Reaction: REF

#### **MP\_posEncoderRefDist**

Nominal increment between two fixed reference marks  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 1 to 65 535 [signal periods]  
Number of signal periods between the reference marks. The  
parameter is only relevant for encoders with distance-coded  
reference marks.

Default: 1000 [signal periods]  
Access: LEVEL3  
Reaction: REF

### 6.4.3 Distance-coded reference marks

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisHardware <b>posEncoderRefDist</b>	400007

The parameter object CfgAxisHardware is not required for:

- Virtual axes (MP\_axisMode=Virtual)

HEIDENHAIN offers linear encoders with **distance-coded reference marks**. The nominal increment between two fixed reference marks depends on the encoder being used.

- ▶ For encoders with distance-coded reference marks, enter for each axis the nominal increment between two fixed reference marks in **MP\_posEncoderRefDist**.

**Example:**

LS 486C: Incremental linear encoder with distance-coded reference marks  
 Grating period 20 µm (= one signal period covers 0.02 mm), nominal increment between reference marks is 20 mm.

**MP\_posEncoderDist** = 0.02

**MP\_posEncoderIncr** = 1

**MP\_posEncoderRefDist** =  $\frac{20 \text{ mm}}{0,02 \text{ mm}}$  = 1000 [signal periods]

**MP\_posEncoderRefDist**

Nominal increment between two fixed reference marks  
 Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 1 to 65 535 [signal periods]

Number of signal periods between the reference marks. The parameter is only relevant for encoders with distance-coded reference marks.

Default: 1000 [signal periods]

Access: LEVEL3

Reaction: REF



**External interpolation (only CC 61xx and CC 424)**

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisHardware <b>genExtIntPolFactor</b>	400017

If you connect encoders with TTL signals and external interpolation electronics through the TTL/1 V<sub>PP</sub> adapter to the control:

- ▶ In **MP\_genExtIntPolFactor**, enter the interpolation factor of the external interpolation unit.

**MP\_genExtIntPolFactor**

External interpolation for encoder signals  
 Available from NCK software version: 597 110-03.

Format: Numerical value  
 Input: 0 to 99  
 0, 1: No external interpolation (default)  
 Default: No value, parameter optional  
 Access: LEVEL3  
 Reaction: RUN





### MP\_speedEncoderInput

Assignment of a speed encoder input to the axis  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **none**  
No speed encoder connected  
**X15...X20**  
Speed encoder inputs are X15 to X20  
**X80...X83**  
Speed encoder inputs are X80 to X83

Default: none

Access: LEVEL3

Reaction: RESET

### MP\_inverterInterface

Assignment of the speed command output to the axis  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **none**  
Not a PWM output, no power module connected  
**X51...X56**  
PWM outputs are X51 to X60  
**X80...X85**  
Only on UEC 11x: Motor connections are X80 to X85

Default: none

Access: LEVEL3

Reaction: RESET

### MP\_posEncoderInput

Assignment of a position encoder input to the axis  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **none**  
No position encoder connected  
**X01...X06**  
Position encoder inputs are X01 to X06 (on the MC 42x)  
**X35...X38**  
Position encoder inputs are X35 to X38 (on the MC 42x)  
**X201...X210**  
Position encoder inputs are X201 to X210 (on the CC)

Default: none

Access: LEVEL3

Reaction: RESET

## Assigning axes to the drive-control motherboard

Use the **MP\_hsciCclIndex** parameter to assign the axes to the individual drive-control motherboards of the CC 61xx in the HSCI system. The HSCI address of the respective drive-control motherboard serves as entry in **MP\_hsciCclIndex**. The HSCI address is obtained from the position of the drive-control motherboard in the HSCI system. However, the HSCI address to be entered only depends on the drive-control motherboards in the system. I/O units (PLs) and machine operating panels (MBs) are not taken into account. This means that for the first controller basic PCB, you have to enter the address 0 in **MP\_hsciCclIndex**, regardless of whether there are I/O units or machine operating panels in the HSCI chain before the CC.

The parameter is optional and, when it is hidden, automatically has the default value 0. Therefore you do not have to enter anything when using a CC 6106. **MP\_inverterInterface** is used for further assignment of the axes to the outputs of the respective drive-control motherboard.

### **MP\_hsciCclIndex**

Index of the CC 61xx controller unit in the HSCI chain  
Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: Index of the CC in the HSCI system, e.g. "0"  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

## Position encoder signal

Incremental position encoders with 1 V<sub>PP</sub> signals and absolute encoders with EnDat interface can be connected to the CC 61xx.

Define the type of signal, input frequency and terminating resistance in the following machine parameters.

- ▶ **MP\_posEncoderSignal:** 1 V<sub>PP</sub> signal. On encoders with EnDat interface you set the signal type 1 V<sub>PP</sub>.



### Note

The CC 61xx does not support encoders with 11 μA<sub>PP</sub> signal!

- ▶ **MP\_posEncoderFreq:** Maximum input frequency
- ▶ **MP\_posEncoderResistor:** Terminating resistor

### MP\_posEncoderSignal

Signal amplitude at position encoder input  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **1 Vpp**

Input signal of the encoder is 1 V<sub>PP</sub>

**11 uA**

Input signal of encoder is 11 μA<sub>PP</sub>

Default: 1 V<sub>pp</sub>

Access: LEVEL3

Reaction: RUN

### MP\_posEncoderFreq

Input frequency of position encoder inputs  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **fast**

Input frequency is

At 11 V<sub>PP</sub>: 350 kHz

At 11 μA<sub>PP</sub>: 150 kHz

**slow**

Input frequency is 33 kHz

Default: fast

Access: LEVEL3

Reaction: RUN

With **MP\_posEncoderResistor** you define whether a terminating resistor is required. (120 ohms)

This parameter may be required if the encoder signals are looped through a drive motor, or if Y cables are used. It is usually sufficient to set the parameter to **without**.

### MP\_posEncoderResistor

Terminating resistor at position encoder input  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **without**  
Without terminating resistor  
**120 ohms**  
With resistor

Default: without

Access: LEVEL3

Reaction: RUN



#### Note

The incremental track data must be entered for the corresponding position encoder inputs for encoders with EnDat interfaces.





## 6.4.5 Connecting the encoders to the UEC 11x

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisHardware <b>posEncoderInput</b> <b>posEncoderSignal</b> <b>posEncoderFreq</b> <b>posEncoderResistor</b> <b>speedEncoderInput</b> <b>inverterInterface</b>	    400008 400009 400010 400011 400012 400013

On the UEC 11x there is a **fixed assignment** between the input of the speed encoder, the motor connection and the input of the position encoder.

The PWM outputs of the controller unit integrated in the UEC 11x are connected internally with the inverter and are not routed toward the outside. Therefore you have to enter the number of the motor connection (X80 to X84) in the **MP\_pwmSignalOutput** parameter.

- ▶ You must wire all connections as listed in the table below.
- ▶ Enter the machine parameters **MP\_posEncoderInput**, **MP\_speedEncoderInput** and **MP\_inverterInterface** as shown in the table.
- Fixed connector assignment when using a UEC 11x:

Motor connection (MP inverterInterface)	Speed input (MP_speedEncoderInput)	Position input (MP_posEncoderInput)
X80	X15	X201
X81	X16	X202
X82	X17	X203
X83	X18	X204
X84	X19	X205

### MP\_speedEncoderInput

Assignment of a speed encoder input to the axis  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **none**  
No speed encoder connected  
**X15...X20**  
Speed encoder inputs are X15 to X20  
**X80...X83**  
Speed encoder inputs are X80 to X83

Default: none

Access: LEVEL3

Reaction: RESET

### MP\_inverterInterface

Assignment of the speed command output to the axis  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **none**  
Not a PWM output, no power module connected  
**X51...X56**  
PWM outputs are X51 to X60  
**X80...X85**  
Only on UEC 11x: Motor connections are X80 to X85

Default: none

Access: LEVEL3

Reaction: RESET

### MP\_posEncoderInput

Assignment of a position encoder input to the axis  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **none**  
No position encoder connected  
**X01...X06**  
Position encoder inputs are X01 to X06 (on the MC 42x)  
**X35...X38**  
Position encoder inputs are X35 to X38 (on the MC 42x)  
**X201...X210**  
Position encoder inputs are X201 to X210 (on the CC)

Default: none

Access: LEVEL3

Reaction: RESET



## 6.4.6 Defining the traverse direction


Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisHardware <b>signCorrActualVal</b> <b>signCorrNominalVal</b> CfgSpindle <b>changeTurnDir</b>	   400001 400002  401509

The parameter object CfgAxisHardware is not required for:

- Virtual axes (MP\_axisMode=Virtual)

When using the CC 61xx, define the counting directions and the traverse direction of the axis, depending on the mounting attitude of the encoders.

### Block diagram: Defining the traverse direction



### Legend:

Signal	Parameter	Entry / Effect
A	MP_signCorrActualVal	Invert the value if the counting direction of the position encoder is opposite to the direction of rotation of the motor.
B	MP_signCorrNominalVal	Changing the value inverts the nominal and actual values of the position encoder. The axis changes the traverse direction.
C	DIR column from motor table	Counting direction of the motor encoder

## Direction of rotation for spindles with C axis

If a spindle is also to be used as a C axis, the rotational direction of the C axis must first be set in the parameters **MP\_signCorrActualVal** and **MP\_signCorrNominalVal** in such a way that the angle moves in the mathematically positive sense (counterclockwise) if the physical spindle axis rotates in the mathematically negative sense (i.e. clockwise).

Since, if there is no separate drive for the C axis, the two parameters also influence the spindle, the rotational direction of the spindle might need to be corrected if M3 and M4 are used.

Therefore, if the functions M3 and M4 are called, correct the rotational direction of the spindle in **MP\_changeTurnDir**, as well as the status display (M3/M4) of the spindle in the dashboard.

### MP\_signCorrActualVal

Reversal of the algebraic sign of the position encoder signal  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: **on**  
The algebraic sign of the position encoder is inverted  
**off**  
The algebraic sign of the position encoder is not inverted

Default: off  
Access: LEVEL3  
Reaction: REF

### MP\_signCorrNominalVal

Reversal of the algebraic sign of the nominal speed value  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: **on**  
The algebraic sign of the nominal speed value is inverted  
**off**  
The algebraic sign of the nominal speed value is not inverted

Default: off  
Access: LEVEL3  
Reaction: REF



#### Note

The counting direction of the motor encoder for speed control is defined in the motor table (DIR column). An incorrect entry results in the error message **C3B0 Motor does not rotate <AXIS>** appearing.

### MP\_changeTurnDir

Rotational direction reversal with M3 and M4  
Available from NCK software version: 597 110-04.

Format: Selection menu  
Selection: **TRUE**  
Reversal of rotational direction is active with M3/M4  
**FALSE**  
Reversal of rotational direction is not active with M3/M4

Default: TRUE  
Access: LEVEL3  
Reaction: RUN



## 6.4.7 Encoder monitoring

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgEncoderMonitor	
<b>checkAbsolutPos</b>	400701
<b>checkSignalLevel</b>	400702
<b>checkFrequency</b>	400703
<b>checkRefDistance</b>	400704

HEIDENHAIN contouring controls monitor the signal transmission from the encoders.

The parameter object **CfgEncoderMonitor** is not required for:

- Virtual axes (MP\_axisMode = Virtual)

### Position encoder

Activate the following monitoring functions for the position encoders:

- ▶ **MP\_checkAbsolutPos:**  
Monitor the absolute position of position encoders with distance-coded reference marks
- ▶ **MP\_checkSignalLevel:**  
Monitor the encoder signal level of the position measuring systems
- ▶ **MP\_checkFrequency:**  
Monitor the edge separation of the position measuring systems



#### Note

The edge separation is monitored by the CC controller unit. Therefore, the **MP\_checkFrequency** parameter is currently not available on the TNC 320 and the MANUALplus 620 with analog command interface to the drive motors.

- ▶ **MP\_checkRefDistance:**  
Monitor the reference mark of the spindle encoder (distance between zero crossovers of the spindle)

The interpolator calculates the absolute position when a reference mark of a distance-coded encoder is crossed over. If **MP\_checkAbsolutPos** is active, the nominal values are compared to the actual values. If deviations are found, an error message is displayed and an EMERGENCY STOP is initiated.

### **MP\_checkAbsolutPos**

Monitoring the absolute position with distance-coded encoder  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **on**  
Monitor the absolute position  
**off**  
No monitoring

Default: off

Access: LEVEL3

Reaction: RESET

### **MP\_checkSignalLevel**

Monitoring the amplitude of the position-encoder signal  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **on**  
Monitor the encoder amplitude  
**off**  
No monitoring

Default: on

Access: LEVEL3

Reaction: RUN

### **MP\_checkFrequency**

Monitoring the edge separation of the position encoder  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **on**  
Monitor the encoder frequency  
**off**  
No monitoring

Default: off

Access: LEVEL3

Reaction: RUN

<b>Criterion</b>	<b>Error message</b>
Absolute position with distance-coded reference marks	<b>Encoder &lt;AXIS&gt; DEFECTIVE</b>
Amplitude of encoder signals	<b>Encoder AMPLITUDE TOO LOW &lt;AXIS&gt;</b>
Edge separation of encoder signals	<b>Encoder &lt;AXIS&gt;: FREQUENCY TOO HIGH</b>



## Monitoring of encoders with EnDat interface

In the event of a disturbance, the error message **EnDat defective <error code> <axis>** will appear.

The error code is shown in hexadecimal notation. Error codes may also appear combined, in which case they are added together.

There are two possible types of errors:

- The encoder reports an error.
- Access to the encoder via the EnDat interface is faulty.

Codes for errors reported by the encoder:

Error code	Meaning
0x00000001	Light source defective
0x00000002	Signal amplitude too low
0x00000004	Incorrect position value
0x00000008	Overvoltage
0x00000010	Undervoltage
0x00000020	Overcurrent
0x00000040	Replace the battery
0x00000080	Reserved
0x00000100	Reserved
0x00000200	Reserved
0x00000400	Reserved
0x00000800	Reserved
0x00001000	Reserved
0x00002000	Reserved
0x00004000	Reserved
0x00008000	Reserved

Error codes if the access to the encoder via the EnDat interface is faulty:

Error code	Meaning
0x80010000	Delete the alarm bit
0x80020000	Read the alarm status
0x80040000	Read the number of pulses
0x80080000	Read the number of signal periods
0x80100000	Read the number of differentiable revolutions
0x80200000	Read the measuring steps
0x80400000	Read the serial number
0x80800000	Read the type of encoder
0x81000000	Read the position value
0x82000000	Reserved
0x84000000	Reserved
0x88000000	Read the checksum
0x90000000	Alarm bit remains set
0xA0000000	Timeout while waiting for data signal "high"
0xC0000000	Timeout while waiting for data signal "low"
0x80000000	Error during access to EnDat interface

### Speed encoder

The MANUALplus 620 uses the **Type of encoder** entry in the "motor.mot" motor table. If an encoder with Z1 track is entered in the motor table, the message **C310 Z1 track error** appears in the event of an error. If an encoder with EnDat interface is entered in the motor table, the MANUALplus 620 attempts to communicate with the encoder. If this fails, the error message **C3F0 EnDat not found <axis>** appears.



#### Warning

If you use the HEIDENHAIN standard motor table motor.mot and motors with EnDat encoders, you might have to change the entry for the motor in the SYS column (type of encoder) of the motor table or enter a new motor.

- SYS = 1: Incremental rotary encoder with Z1 track
- SYS = 2: Absolute speed encoder with EnDat interface



## 6.5 Analog Axes

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisAnalog <b>analogOutput</b> <b>maxFeedAt9V</b>	    400101 400105

The parameter object

- CfgAxisAnalog is not required for:
  - Virtual axes (MP\_axisMode = Virtual)
  - Axes that are for display only (MP\_axisMode = Display)
  - **Digital axes (MP\_axisHw = CC or None)**

In **CfgAxis/axisHw = Analog**, analog closed-loop axes are defined as such and are described in the parameter object **CfgAxisAnalog** (see "Controller parameters for analog axes" on page 902).

### Analog output

- ▶ In **MP\_analogOutput**, you define the number of the analog nominal-value output at connector X8 or X9.

#### MP\_analogOutput

Speed command output of axis or spindle  
 Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **none**  
 No analog output assigned

#### **analog Output 1...13**

Analog outputs 1 to 6 (connector X8 on MC)  
 Analog outputs 1 to 4 (CMA-H 04-04-00)  
 Analog outputs 7 to 13 (connector X9 on MC 4xx)

Default: analog Output 1

Access: LEVEL3

Reaction: RUN

Connector X9 is only available on the MC 422x hardware with 10 control loops and can therefore not be used on the MANUALplus 620.

## Rapid traverse for analog axes

- ▶ In **MP\_maxFeedAt9V**, enter the rapid-traverse rate to be reached at an analog voltage of 9 V (e.g. for drives reaching the rapid traverse rate at 6 V, the corresponding value at 9 V must be calculated by linear calculation).
- ▶ Adjust the rapid traverse feed rate ( $v_{\max}$ ) with the analog voltage at the servo amplifier.

### MP\_maxFeedAt9v

Velocity at 9 volts  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000000006 to 36 000 000 [mm/min] or [°/min]  
Default: 4999.98  
Access: LEVEL3  
Reaction: RUN

## 6.5.1 Central drive

It is possible to use one drive for several or all machine axes. The NC software allows the user to use the same nominal position value output for more than one axis (**MP\_analogOutput**).

The PLC basic program for the MANUALplus 620 is already prepared for the central-drive functionality.



#### Note

Please refer to the PLC basic program documentation.

The most important basic requirements for realizing a machine with central drive:

- A common drive package with an analog nominal position value input exists for all axes.
- The machine axes are to be handled as clamping axes by the PLC.
- Use the PLC to monitor the drive regarding movement in multiple axes, and output an error message if necessary.



#### Note

In addition to the PLC, the drive is also monitored by the NC. If the attempt is made to traverse more than one axis of the central drive group, the control outputs the error message **Analog output of axis [axis] was assigned twice**.



#### Note

#### **If you are switching from the iTNC 530:**

Please note that each axis of the central drive group must be enabled individually in the SIK. This is different on the iTNC 530, where only one axis must be enabled in the SIK for all axes belonging to the central drive.

## 6.6 Reading and Writing Axis Information

### 6.6.1 Reading axis information

#### Module 9038 Read the status information of axes

With Module 9038 you can interrogate the general status information of the axes. You can interrogate the status of a specific axis or of all axes at once.

With bit-encoded information, the status request for a specific axis returns code 0 or 1. The meaning of the return codes is explained in the table below.

The desired information can be read for all axes in one run-through. For this the axis number -1 must be transferred. In this case the status request only returns bit-encoded information. The information is then passed on in the bit corresponding to the axis.

Status information	Bit information	Meaning
0	x	0: Axis not active (MP_axisMode is not "Active" or no encoder) 1: Axis active
1	x	Axis in interpolation context? 0: Axis is currently in interpolation context or not active. 1: Axis is currently not in interpolation context or this axis is a spindle. (Spindles are not in interpolation context.)
2	x	0: Open-loop axis 1: Closed-loop axis (MP_axisMode=Active)
3	-	Maximum temperature of the motor [°C]
4	x	0: Not a Hirth axis 1: Hirth axis
5	-	Hirth grid [1/10 µm] (MP_isHirth)
6	-	Reserved
7	x	0: Linear axis or not active 1: Rotary axis (MP_isAng=True)
8	x	0: Analog axis (MP_axisHw=Analog) or not active 1: Digital axis
9	x	0: Axis is not a slave axis 1: Axis is a slave axis

Constraints:

- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.
- For an axis set to the "displayed axis" or "manually operated axis" activation status the status information codes 2 and 8 are meaningless, and return the value 0. The other status information codes return a value corresponding to the configuration or activation status.

Call:

PS B/W/D/K <>Axis>  
Axis-specific: Index from CfgAxes/axisList  
For all axes: -1

PS B/W/D/K <>Status information>  
See table above

CM 9038

PL B/W/D <>Information>  
Axis-specific: Status information according to table  
For all axes: Bit-encoded  
(Bit 0 corresponds to logic axis 0, etc.)

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error	0	Information was read
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Status information not available
	2	Axis not found



## Module 9049 Read position value and speed value of an axis

Module 9049 reads the position value or speed value of an axis

Call:

PS B/W/D/K <>Logical axis number>

PS B/W/D/K <>Desired axis information>

2: Actual position in the reference system

3: Following error

8: Offset of the axis due to kinematic compensation in real time

9: Distance traversed [mm] since the last lubricating pulse

10: Actual speed

11: Nominal speed

CM 9049

PL D <>Axis information>

For 2, 3, 8: Value in 0.0001 mm or 0.0001°

For 9, 10, 11: Value in mm/min or °/min

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Axis information read
	1	No axis information read, error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Interrogated axis number or axis information invalid

## Reading axis coordinates

- ▶ Read the axis coordinates with Module 9040 (only API 1.0) or Module 9041.

The values are saved in double words beginning at the given address.

The values for all axes are read in, regardless of whether individual axes are excluded through the machine configuration. Values for excluded axes are undefined.

The coordinate value of an axis remains undefined until the reference point of an axis has been traversed.

### Module 9040 Reading of axis coordinates by the PLC in the format 1/1000 (0.001) mm

Module 9040 loads the axis coordinates from the control loop for all NC axes. The actual values in the reference system, the servo lag, the distance-to-go and the deflection of a triggering touch probe can be loaded.

The values are saved in 10 double words in the format 1/1000 mm, beginning at the given target address.

The module is only supported if you use the iTNC-compatible programming interface (API 1.0). The API 1.0 cannot be used with the MANUALplus 620.



#### Note

This PLC module was introduced in order to remain compatible with older PLC programs (with API version 1.0) of older HEIDENHAIN contouring controls. This PLC module is not supported if the symbolic programming interface is used! Use Module 9041 instead.

Possible errors:

- The argument for the type of coordinate is outside the permitted range (2).
- The specified target address is not a double word address (4).
- The double word block cannot be written to the specified target address (4).
- You are using the symbolic programming interface.

Call:

PS K/B/W/D <>Target address Dxxxx>

PS K/B/W/D <>Type of coordinate>

2: Actual values in the reference system

3: Following error

4: Distance-to-go

5: Deflection (measuring touch probe)

6: Actual values in the datum system

8: Temperature compensation

9: Distance counter [mm]

CM 9040

#### Error recognition:

Marker	Value	Meaning
M4203	0	Data was read
	1	Faulty call data

## Module 9041 Reading of axis coordinates by the PLC in the format 1/10000 (0.0001) mm

Module 9041 loads the axis coordinates from the control loop for all NC axes. The actual values in the reference system, the servo lag, the distance-to-go and the deflection of a triggering touch probe can be loaded.

The values are saved in 10 double words in the format 1/10000 mm, beginning at the given target address.

Possible errors:

- The argument for the type of coordinate is outside the permitted range (2).
- The specified target address is not a double word address (4).
- The double word block cannot be written to the specified target address (4).

Call:

PS K/B/W/D <>Target address Dxxxx>

PS K/B/W/D <>Type of coordinate>

2: Actual values in the reference system

3: Following error

4: Distance-to-go

5: Deflection (measuring touch probe)

6: Actual values in the datum system

7: Actual values in the reference system with backlash

8: Temperature compensation

9: Distance counter

CM 9041

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Data was read
Error (M4203)	1	Faulty call data

### Reading the actual spindle values

- Read the spindle coordinates with Module 9411.



#### Note

You can use this module only if you are working with the new symbolic API, see "The API 3.0 symbolic memory interface" on page 1482.

## Module 9411 Read the actual spindle values (speed, coordinates)

Use Module 9411 to read the position and speed values of the spindle.

Constraints:

- This module is only supported by the new symbolic memory interface (API 3.0). If the iTNC-compatible interface is used, then Module 9411 returns error code 99.
- If the spindle is not in a closed loop, the value 0 is returned for information #2 (nominal position in reference system) and information #4 (servo lag).
- The values for information #10, #11 and #12 (current speed and final speed) are signed.
- The accumulated traverse path for information #5 can be reset with Module 9418.
- Information #12 (final speed) results from the programmed speed or number of rotations under consideration of the override and limitations. It indicates the speed that the spindle is to reach at the end of the acceleration ramp.
- In order to receive one of the two "Request switchover" status values for information #20, the speed-dependent wye/delta switchover (Module 9417) must be active.
- The accumulated traverse path for information #21 (path-dependent lubrication) can be reset with Module 9418. Path-dependent lubrication is not usual for spindles, but is supported in special cases.

Call:

```
PS    B/W/D/K  <>Spindle index>
        0: Spindle 1
        1: Spindle 2
        etc.

PS    B/W/D/K  <>Desired spindle information>
        1 : Actual position in the reference system
        2 : Nominal position in the reference system
        4: Following error
        5 : Accumulated traverse path
        10: Actual speed
        11: Nominal speed
        12: Nominal speed at the end of acceleration
        20: Information about wye/delta operation
        21: Information about path-dependent lubrication

CM    9411
PL    D        <>Spindle information>
        For 1 to 5: Value in 0.0001°
        For 10 to 12: Value in 0.001 rpm
        For 20:   0: Spindle in wye operation
                  1: Request for wye/delta switchover
                  2: Spindle in delta operation
                  3: Request for delta/wye switchover
        For 21:   0: Traverse path for path-dependent lubrication
                  not reached yet
                  1: Traverse path for path-dependent lubrication
                  exceeded
```





**Error recognition:**

<b>Marker</b>	<b>Value</b>	<b>Meaning</b>
NN_GenApiModule Error	0	Actual spindle value read
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Interrogated spindle number or spindle information invalid
	99	Module is not supported (control operates with iTNC-compatible API).

## 6.6.2 Writing axis information—activating and deactivating axes

This chapter describes how to activate and deactivate axes during operation and without rebooting the MANUALplus 620, e.g. in order to exchange milling heads.

The MANUALplus 620 has two machine parameters in the CfgAxis configuration object. They describe the type of connection and the behavior of axes:

- **MP\_axisHw** (300104)
- **MP\_axisMode** (300105)



### Note

For activation and deactivation of axes to be possible at all, the **MP\_axisMode** parameter has to have the value **Active**.

With **MP\_axisMode** you specify whether the affected axis is known to the system (= Active) or not (= NotActive). If axes are not known, there is also no need for any further parameters. Virtual axes (= Virtual) and axes controlled by the PLC (= PlcControlled) are ignored in the checks for activating and deactivating.

With the **MP\_axisHw** parameter you define the hardware type of the axis at the time of the control startup. For the settings possible, see "MP\_axisHw" on page 635.



Axes connected to the MANUALplus 620 have different activation statuses:

Activation status	Parameter MP_axisHw	Data required in the parameter set	Functions
<b>Closed-loop axis</b>	InOutCC AnalogMC AnalogCC ProfiNet	There must be at least one parameter set with the controller parameters for the axis. The digital CC parameters are not required for analog axes.	Fully functional control loop, programmable physical axis
<b>Manually operated axis</b>	ManualMC ManualCC	All parameters except the controller parameters must be available.	Axis with a linear encoder but without drive motor—nevertheless programmable. Behaves like an active axis with respect to the PLC (axis is included in the geometry description)
<b>Displayed axis</b>	DisplayMC DisplayCC	All parameters except the controller parameters must be available.	Axis with a linear encoder but without servo drive—not programmable. (Axis included in the geometry information.)
<b>Deactivated axis</b>	(Axis is deactivated either over Module 9226 or 9418, or over the parameter MP_deactivatedAtS tart.)		No monitoring active. Encoder and drive motor can be removed mechanically.

The following table shows the assignment of available and configurable monitors of the axes to the various activation statuses.

Activation status	Monitoring active	Monitoring inactive
<b>Closed-loop axis</b>	<ul style="list-style-type: none"> <li>■ Following error monitoring</li> <li>■ Standstill monitoring</li> <li>■ Movement monitoring</li> <li>■ Monitoring of the amplitude of the encoder</li> <li>■ Monitoring of the frequency of the encoder</li> <li>■ Positioning window</li> </ul>	
<b>Manually operated axis</b>	<ul style="list-style-type: none"> <li>■ Monitoring of the amplitude of the encoder</li> <li>■ Monitoring of the frequency of the encoder</li> <li>■ Positioning window</li> </ul>	<ul style="list-style-type: none"> <li>■ Following error monitoring</li> <li>■ Standstill monitoring</li> <li>■ Movement monitoring</li> </ul>
<b>Displayed axis</b>	<ul style="list-style-type: none"> <li>■ Monitoring of the amplitude of the encoder</li> <li>■ Monitoring of the frequency of the encoder</li> <li>■ Positioning window</li> </ul>	<ul style="list-style-type: none"> <li>■ Following error monitoring</li> <li>■ Standstill monitoring</li> <li>■ Movement monitoring</li> </ul>
<b>Deactivated axis</b>		<ul style="list-style-type: none"> <li>■ Following error monitoring</li> <li>■ Standstill monitoring</li> <li>■ Movement monitoring</li> <li>■ Monitoring of the amplitude of the encoder</li> <li>■ Monitoring of the frequency of the encoder</li> <li>■ Positioning window</li> </ul>

**Switching parameter sets**

If you also switch parameter sets (e.g. when exchanging milling heads) when activating or deactivating axes over the PLC, you have to observe particular conditions (see "Switching Parameter Sets" on page 398).



## Switching the activation status

The activation status of an axis is switched through PLC Module 9226, and that of the spindle through PLC Module 9418. It must be kept in mind that the activation status cannot be increased beyond that configured in **MP\_axisHw**. An axis that is only displayed (**MP\_axisHw** = DisplayMC or DisplayCC), for example, cannot be switched up to the "manually operated axis" or "closed-loop axis" activation status. The following table shows the permissible changes of the activation status.

Parameter <b>MP_axisHw</b>	Permissible change of the activation status			
	Closed-loop axis	Manually operated axis	Displayed axis	Deactivated axis
InOutCC AnalogMC AnalogCC Profinet	X	X	X	X
ManualMC ManualCC	–	X	X	X
DisplayMC DisplayCC	–	–	X	X

For example, proceed as follows if you want to activate individual axes without rebooting:

- ▶ Switch off the servo control of the motor.
- ▶ Through Module 9226 for axes and 9418 for the spindle, use mode 14 to set the motor to the "deactivated all axis" activation status. This also deactivates all monitors of the drive motor. Now the servo motor can be mechanically removed, for example to exchange a milling head.

Reverse the sequence if you want to reactivate the previously deactivated axis.

- ▶ With Module 9226 or 9418, set the axis or spindle to the desired activation status (mode 11 to 13)
- ▶ The servo control of the motor can now be activated.



### Note

After the axis is activated, the interpolator automatically conducts an actual-to-nominal value transfer through mode 11 to 13.

**NN\_AxLogNumber** changes its value if you deactivate an axis with Modules 9226 or 9418. **NN\_AxLogNumber** is set to the value –1 for deactivated axes. **NN\_AxLogNumber** shows the current operating status of the axis and therefore does not change immediately when the module is called, but rather a little later.



### Note

Please note that activating a deactivated axis can take up to half a second.

## Deactivating an axis during startup



With the **MP\_deactivatedAtStart** parameter you can deactivate an axis or spindle already during startup and then activate it later for control operation.

### Note

For all axes that are removable, (e.g. exchangeable milling heads), HEIDENHAIN recommends setting the **MP\_deactivatedAtStart** parameter to the value **TRUE**. In this case, the PLC must ensure that the respective physically installed axes are correctly activated.

An axis that was deactivated through **MP\_deactivatedAtStart** behaves as if you have deactivated the axis through Module 9226 or 9418 with mode 14. A change of the parameter does not go into effect until the next startup of the MANUALplus 620.

### MP\_deactivatedAtStart

Deactivate axis during startup

Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **TRUE**

During startup of the MANUALplus 620 the axis is deactivated—irrespective of the parameter **MP\_axisHw**. The same effect is attained with the setting as from calling PLC module 9226 or 9418 with mode 14.

#### **FALSE**

During startup of the MANUALplus 620 the axis is treated as configured in the parameter axisHw.

Default: No value, parameter optional (= behavior as for FALSE)

Access: LEVEL3

Reaction: RUN



### Module 9226 Set status for axes

The module sets a new status for an NC axis or auxiliary axis (not for spindles).

Constraints:

- The module can only be called for NC axes or auxiliary axes. Module 9418 must be used for setting the status of a spindle.
- An axis not configured as "active" is treated as if it were not present.

Modes 10 to 14:

- The motor of the affected axis must be switched off during module call. The current and speed controllers must be inactive.
- The activation status must not be switched except in a strobe with synchronization of the advance calculation (SYNC\_CALC, interpreter stop).

Call:

```
PS    B/W/D/K  <>Axis>
      Index from the parameter CfgAxes/axisList
PS    B/W/D/K  <>Mode>
      1: Renewed evaluation of the axis reference mark
      10: Restore activation status from startup
      11: Closed-loop axis activation status
      12: Manually operated axis activation status
      13: Displayed axis activation status
      14: Deactivated axis activation status
CM    9226
PL    B/W/D    <>Error code>
      0: Module successfully executed
      1: Faulty module call (invalid axis number)
      2: Faulty module call (invalid mode)
      3: Faulty module call (axis is not an NC axis or auxiliary axis)
      4: Axis is controlled by the NC
      5: Activation status is being switched
      6: Activation status is already selected
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Module executed successfully
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid task data transferred (see error number in returned value)

## Module 9418 Set status for spindle

The module sets a new status for a spindle.

Constraints:

- This module is only supported by the symbolic memory interface (API 3.0). If the iTNC-compatible memory interface (API 1.0) is used, the module returns an error.
- Path-dependent lubrication (Mode #5) is usually not used for spindles, except in the special case that a spindle can also be a rotary axis.

Constraints for modes 10 to 14:

- The motor of the spindle must be switched off during module call. The current and speed controllers must be inactive.
- The activation status must not be switched except in a strobe with synchronization of the advance calculation (SYNC\_CALC, interpreter stop).

Call:

PS B/W/D/K <>Spindle index>

PS B/W/D/K <>Mode>

- 1: Renewed evaluation of the spindle's reference mark
- 2: Determine the actual speed value for speed control from the motor encoder
- 3: Determine the actual speed value for speed control from the position encoder
- 4: Reset accumulated traverse path
- 5: Reset accumulated traverse path for path-dependent lubrication
- 10: Restore activation status from startup
- 11: **Closed-loop axis** activation status
- 14: **Deactivated axis** activation status

CM 9418

PL B/W/D <>Error code>

- 0: Module successfully executed
- 1: Faulty module call (invalid spindle number)
- 2: Faulty module call (invalid mode)
- 3: Activation status is being switched
- 4: Activation status is already selected

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Module executed successfully
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid task data transferred (see error number in returned value)
	99	Module is not supported (control operates with iTNC-compatible API).





## Module 9155 Switch axes from closed-loop to open-loop condition

Module 9155 switches axes from the closed-loop to open-loop state.



### Note

This module was implemented to ensure compatibility with earlier HEIDENHAIN contouring controls. HEIDENHAIN recommends: Use preferably the Modules 9226 and 9418 described above.

Constraints:

- The module functions only in the cyclic PLC program.
- The function is only possible when the MANUALplus 620 is not active (NN\_ChnControlInOperation = 0) or if an M/S/T/T2/G strobe is pending.
- The function is only possible when the MANUALplus 620 is not active or if an M/S/T/T2/G strobe is pending.
- Only the last module call per PLC cycle is included.

Call:

PS B/W/D/K <>Bit-encoded axis mask>

CM 9155

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Module executed successfully
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid axis mask given
	21	Missing strobe or control is active
	24	Module was called in a submit/spawn job

### Module 9156 Switch axes from open-loop to closed-loop condition

Module 9156 switches axes that were previously switched by Module 9155 to the open-loop state back to the closed-loop state.



#### Note

This module was implemented to ensure compatibility with earlier HEIDENHAIN contouring controls. HEIDENHAIN recommends:  
Use preferably the Modules 9226 and 9418 described above.

#### Constraints:

- The module functions only in the cyclic PLC program.
- The function is only possible when the MANUALplus 620 is not active (NN\_ChnControlInOperation = 0) or if an M/S/T/T2/G strobe is pending.
- Only the last module call per PLC cycle is included.

#### Call:

PS B/W/D/K <>Bit-encoded axis mask>  
CM 9156

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Module executed successfully
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid axis mask given
	21	Missing strobe or control is active
	24	Module was called in a submit/spawn job



## Module 9048 Interrogate the operating states of axes

Module 9048 is used to interrogate the operating status/activation status of a certain axis or for all axes together.

Constraints:

- The module returns the actual activation status of the axis. At least one PLC clock pulse, and maybe more, passes between the order for changing the activation status by calling a PLC module (for example, 9226 or 9418) and the actual change of the activation status. During this time the module returns the previous activation status. This also means that the modules reports when the change of the activation status has been completed.
- An axis not configured as "active" is treated as if it were not present. For a deactivated axis the corresponding activation status is reported.

Call:

```
PS    B/W/D/K  <>Axis number>
        Axis number: Individual information for a programmed axis
        -1: Information for all axes, bit-encoded as axis mask

PS    B/W/D/K  <>Status information>
        0: Brake test active/inactive
        1: Free rotation active/inactive
        2: Position value assigned or actual value being transferred
        3: "Deactivated axis" activation status
        4: "Displayed axis" activation status
        5: "Manually operated axis" activation status
        6: "Closed-loop axis" activation status

CM    9048
PL    B/W/D    <>Status>
        Interrogation of an individual axis: 1/0 = active/inactive
        Interrogation of all axes: Bit-encoded axis mask
```

### Error recognition:

Marker	Value	Meaning
M4203 or NN_GenApiModule Error	0	Status ascertained
	1	Error code in W1022 or NN_GenApiModuleErrorCode
W1022 or NN_GenApiModule ErrorCode	2	Invalid axis programmed
		If status information 0 was transferred, then this error occurs if an invalid axis number, an open-loop axis or an axis that is temporarily not a closed-loop axis was selected.
		If status information 1 was transferred, then this error occurs if an invalid axis number, an open-loop axis or an axis that is temporarily not a closed-loop axis was selected.
		If status information 3 to 6 was transferred, then this error occurs if an invalid axis number or an open-loop axis was selected.

## 6.7 Traverse Ranges

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPositionLimits <b>swLimitSwitchPos</b> <b>swLimitSwitchNeg</b>	     400501 400702

The parameter object **CfgPositionLimits** is not required for:

- Virtual axes (**MP\_axisMode = Virtual**)
- Axes that are only for display (**MP\_axisMode=Display**)

Define the software limit switches in the parameter object

### **CfgPositionLimits:**

- The datum is the machine datum (**MP\_refPosition**).
- If the geometry detects that a software limit switch will be traversed, the traverse path concerned will not be executed and an error message will be displayed.
- If a software limit switch is traversed, the MANUALplus 620 stops the corresponding axis and displays an error message. The axis can be retracted in the opposite direction, however.
- On milling controls, the software limit switches can usually be overwritten from the NC program (see below).
- On lathe controls, the software limit switches can only be overwritten from the PLC.
- Limit-switch monitoring can be deactivated by entering 0 for positive and negative limit values.



If you open the **MP\_swLimitSwitchNeg** or **MP\_swLimitSwitchPos** parameter in the configuration editor (**Machine Parameter Programming** operating mode) you can press the ACTUAL POSITION CAPTURE soft key to apply the position value of an axis automatically.

The soft key displays a soft-key row showing the available axes. When you press an axis soft key, the MANUALplus 620 captures the position of the axis in the REFNOML system.

### **MP\_swLimitSwitchPos**

Positive software limit switch  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: -100 000.000 000 000 to +100 000 [mm] or [°]  
Default: 0 [mm] or [°]  
Access: LEVEL3  
Reaction: RUN

### **MP\_swLimitSwitchNeg**

Negative software limit switches  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: -100 000.000 000 000 to +100 000 [mm] or [°]  
Default: 0 [mm] or [°]  
Access: LEVEL3  
Reaction: RUN



#### Note

If positive and negative software limit switches = 0, limit-switch monitoring is switched off.

## 6.8 Lubrication Pulse

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPositionLimits <b>lubricationDist</b>	400503

The parameter object CfgPositionLimits is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)

- ▶ In **MP\_lubricationDist**, you define the traverse distance at which the lubrication pulse for the axis guideways is to be output. The NC reports in **NN\_AxLubricationPulse** when the entered distance in an axis has been exceeded.
- ▶ Reset **PP\_AxLubricationDistReset** after lubrication. This resets the distance counter to 0.



### Note

After the MANUALplus 620 has been reset, the accumulated distance is reset.

### MP\_lubricationDist

Path-dependent lubrication of axis

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to + 100 000 [mm] or [°]

0= no output of lubrication pulse to PLC

Default: 100 [mm] or [°]

Access: LEVEL3

Reaction: RUN

PLC operand / Description	Type
NN_AxLubricationPulse Lubrication pulse: Value in MP_lubricationDist exceeded 0: Value not exceeded 1: Value exceeded	M
PP_AxLubricationDistReset Reset the accumulated distance: 0: Do not reset accumulated distance 1: Reset accumulated distance	M





## 6.9 PLC Axes

Axes that are **not** in an interpolation context can be used by the PLC as required. The PLC can start more than one axis simultaneously, but they are not interpolated with each other. As soon as an axis is not part of the active kinematics, you can use the axis as PLC axis.



### Note

Please keep in mind that the axis interpolation context can be changed dynamically, for example by the activation of another kinematic model.

### Stopping/Starting axes by PLC

#### Module 9120 Position PLC axis

Module 9120 positions PLC axes that are assigned to the PLC. By entering a target position (in the reference system), a feed rate and a flag register, the positioning of a PLC axis is started. The axis is positioned regardless of any other processes in the control. In particular, there is no path interpolation with other axes.

Constraints:

- The axis must **not** be in an interpolation context.
- The parameter values for rapid traverse, acceleration, etc. must be set correctly.
- Rotary axes are positioned in the direction of the shortest path, except if the target position was transferred as an incremental value.
- Software limit switches are not active.
- The axis must be stationary. Any positioning movement must be aborted beforehand with Module 9121.
- Feed-rate override is disabled.
- If no reference mark has been traversed, the positioning process builds on the counter value as it was upon switch-on.
- If Modules 9120, 9121 and 9122 are called more than once for the same axis during one PLC scan, only the last command is transferred.
- A "positioning error" status set in this axis is cleared. The status must be evaluated by Module 9122.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Possible errors:

- A non-existing axis was transferred.
- An axis was transferred that was not declared as an auxiliary axis with MP10 and MP60 (MPs are only valid for non-symbolic memory interfaces).
- For a modulo axis, an absolute target position was transferred that is outside the permissible interval (0..modulo value).
- The axis is already being positioned.
- An axis currently not in a closed loop was programmed.
- An invalid feed rate was programmed.





Call:

PS B/W/D/K <>Axis>  
Index from CfgAxes/axisList

PS B/W/D/K <>Target position>  
Input unit: [0.0001 mm]

PS B/W/D/K <>Feed rate>  
Input unit: [mm/min]

PS B/W/D/K <>Mode>  
Bit 0 – Definition of the target position:  
0: Absolute, i.e. relative to the machine datum  
1: Incremental

CM 9120

PL B/W/D <>Error code>  
0: No error. Positioning was started.  
1: Axis does not exist  
2: Axis is still in interpolation context  
3: Axis is already being positioned  
4: Absolute position is outside of modulo range  
5: Programmed axis not in closed loop  
6: Invalid feed rate was programmed

### Module 9121 Stop PLC axis

The module stops a positioning movement that has been started by Module 9120 or 9123.

Constraints:

- If Modules 9120, 9121 and 9122 are called more than once for the same axis during one PLC scan, only the last command is transferred.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Call:

PS B/W/D/K <>Axis>  
Index from CfgAxes/axisList

CM 9121

PL B/W/D <>Error code>  
0: Positioning is canceled  
1: Axis does not exist  
2: Axis is still in interpolation context  
3: Axis was already stationary

## Module 9122 Status of PLC axis

The module provides information on the present operating status of the axis.

Constraints:

- Status changes through a PLC positioning command (Modules 9120, 9121, 9123) are not detected until the next PLC scan.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Call:

PS	B/W/D/K	<>Axis> Index from CfgAxes/axisList
CM	9122	
PL	B/W/D	<>Status> Bit 0 – Axis in interpolation context? 0: Axis does not exist or is in interpolation context 1: Axis is not in interpolation context Bit 1 – Reference mark 0: Reference mark not yet traversed 1: Reference mark traversed Bit 2 – Positioning 0: Positioning inactive 1: Positioning active Bit 3 – Direction of motion 0: Positive direction of motion 1: Negative direction of motion Bit 4 – Positioning error 0: No positioning errors occurred 1: Positioning error Bit 5 – Closed-loop or open-loop axis 0: Closed-loop axis 1: Open-loop axis Bit 6 – Target position reached? 0: Target position not yet reached 1: Target position reached

## Module 9123 Traverse the reference marks of PLC axes

The module starts a positioning movement in a defined direction. The positioning movement is continued until a reference mark is found or until the positioning movement is canceled by Module 9121.



### Note

Use Module 9123 only if no conventional procedure for traversing the reference marks is possible.

Constraints:

- The axis must **not** be in an interpolation context.
- The parameter values for rapid traverse, acceleration, etc. must be set correctly.
- Software limit switches are not active.
- The axis must be stationary. Any positioning movement must be aborted beforehand with Module 9121.
- Feed-rate override is disabled.
- If Modules 9120, 9121 and 9122 are called more than once for the same axis during one PLC scan, only the last command is transferred.
- A "positioning error" status set in this axis is cleared.
- The "find reference point" status is set for the axis.
- Any pre-existing reference point in this axis is cleared, but the numerical axis value remains. It will not be reinitialized until the reference point is found.
- The positioning movement is interrupted as soon as the reference point is found. However, due to the braking distance, the axis comes to a standstill somewhat beyond the reference mark.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Call:

```
PS   B/W/D/K  <>Axis>
      Index from CfgAxes/axisList
PS   B/W/D/K  <>Feed rate>
      Input unit: [mm/min]
PS   B/W/D/K  <>Mode>
      Bit 0: Direction of traverse
      0: Positive
      1: Negative
CM   9123
PL   B/W/D    <>Error code>
      0: No error. Positioning was started.
      1: Axis does not exist
      2: Axis is still in interpolation context
      3: Axis is already being positioned
      5: Programmed axis not in closed loop
```

### Module 9124 Feed rate override for PLC axis

The override value set in this module influences the traversing speed of an axis traversed by the PLC with Module 9120 or 9123.

Constraints:

- The axis must **not** be in an interpolation context.
- The override value is transferred as integral number (0 to 10000), which may be in the range from 0 % to 100.00 % (resolution 0.01 %).
- The last transmitted override value is accounted for at the beginning of movement.
- After a reset or interruption of the PLC program the override value is set to 100.00 %.
- The override value can be changed during positioning.
- The module can be called in addition to a module from the group (9120/9121/9123) during the same PLC scan.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Call:

PS	B/W/D/K	<>Axis> Index from CfgAxes/axisList
PS	B/W/D/K	<>Override> Input unit: 0 to 10 000, corresponds to 0 to 100 % in 0.01 % steps.
CM	9124	
PL	B/W/D	<>Error code> 0: No error, override value was set 1: Axis does not exist 2: Not a PLC axis 3: Override value incorrect

### Positioning of axes by PLC

You start a PLC positioning movement with Module 9221, and you can interrogate the status with Module 9222.

The following conditions apply to a PLC positioning command:

- Tool compensation is not included. Before a PLC positioning command you must end any tool compensation.
- A PLC positioning movement is not displayed in the test graphic.

The NC cancels a PLC positioning movement under the following conditions:

- If in the Manual or Handwheel modes there is an NC STOP.
- If in the automatic operating modes there is an NC STOP and "internal stop."
- If there is an EMERGENCY STOP.
- If there is an error message that results in a STOP.

## Module 9221 Start a PLC positioning movement

The module positions an axis. The target position and feed rate are transferred in the module call. Limit switch interrogation can be activated in a separate transfer parameter.

The axis is positioned regardless of any other processes in the control. In particular, there is no interpolation with other axes.



### Note

When calling the module for an NC axis during a strobe, the synchronization with the advance calculation (strobe with **MP\_sync** = SYNC\_CALC) must be configured for this strobe.

### Constraints:

- The module must only be called if no program is running, or if an M/G/S/T/T2/Q strobe is pending. No axis direction key may be pressed in the Manual operating mode.
- For rotary axes with transition to zero, positioning is by the shortest path.
- If you wish to change a parameter (e.g. target position, feed rate) of a positioning command already in progress, you must first abort positioning, then change the parameter and start again.
- A simultaneous PLC positioning movement of several axes is interpolated. If you start an additional axis (e.g. Z) while already positioning another (e.g. X and Y), the first movement is aborted automatically, and then all the programmed axes (e.g. X, Y and Z) are positioned together.

### Call:

PS	B/W/D/K	<>Axis> Index from CfgAxes/axisList
PS	B/W/D/K	<>Target position> Input unit: 0.0001 mm
PS	B/W/D/K	<>Feed rate> Input unit: mm/min
PS	B/W/D/K	<>Mode> Bit 0 – Definition of the target position: 0: Absolute, i.e. relative to the machine datum 1: Incremental Bit 1 – Software limit switch: 0: Inactive 1: Active
CM	9221	
PL	B/W/D	<>Error code> 0: Positioning is being started 1: Axis is not in a closed loop or is an auxiliary axis 2: Inadmissible values for the feed rate 3: Axis has not traversed the reference mark 4: No M/S/T/Q strobe during running program 5: Programmed axis not in closed loop 6: Positioning already started

## Module 9222 Status request of a PLC positioning movement

The module provides the PLC positioning status.

Status information is collected for a certain axis or for all axes. This includes the current status of PLC positioning movements. The respective status information of a certain axis, or bit-encoded for all axes, can be interrogated.

Constraints:

- The status of an axis remains until a new status is set when the next PLC positioning of this axis occurs.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Call:

PS    B/W/DK   <>Axis>  
                  Index from CfgAxes/axisList  
                  or bit-encoded output for all axes:  
                  1: Target position reached  
                  2: PLC positioning was started  
                  3: PLC positioning canceled  
                  4: Limit switch  
                  5: Positioning impossible  
                  6: Positioning temporarily stopped

CM    9222  
PL    B/W/D   <>Status>  
                  0: No PLC positioning was started  
                  1: Target position reached  
                  2: PLC positioning was started  
                  3: Due to cancelation, target position not reached  
                  4: Target position is outside of traverse range  
                  5: Positioning not possible (e.g. due to "free rotation")  
                  6: PLC positioning temporarily stopped (stop in Automatic operating modes)

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Status was transferred
	1	Error (error code in NN_GenApiModuleErrorCode)
NN_GenApiModule ErrorCode (W1022)	1	Invalid status information was requested
	2	The status of an open-loop axis, auxiliary axis or slave axis is being interrogated



### Module 9224 Stop PLC positioning movements

The module stops the positioning movement of an NC axis that has been started by Module 9220 or 9221.

Constraints:

- If a PLC strobe marker exists for the programmed axis, it is reset.
- It is still possible to stop PLC positioning movements by resetting the PLC strobe markers.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Call:

PS	B/W/DK	<>Axis> Index from CfgAxes/axisList
PS	B/W/DK	<>Mode> Not supported until now, 0 transferred
CM	9224	
PL	B/W/D	<>Error code> 0: Stop PLC positioning 1: Invalid axis number 2: Invalid axis type 3: Axis is not in motion 4: Axis is controlled by NC 5: Invalid mode

## Module 9227 Position auxiliary axes and NC axes

The module starts the positioning of an NC axis (PLC positioning like with Module 9221) or the positioning of an auxiliary axis (like with PLC Module 9120). With Module 9227, acceleration and jerk can be programmed in addition to the target position and feed rate parameters.

Further modes can be programmed for positioning NC axes (like with Module 9221):

- Rapid-traverse feed rate (only operating panels with rapid traverse override)
- Active limit switch interrogations
- Deactivated collision monitoring

See also documentation for PLC Modules 9120 and 9221

Conditions:

- The machine parameter configuration of an axis to be started with Module 9227 determines whether the positioning movement of an auxiliary axis or an NC axis is started.

Positioning of NC axes (PLC positioning):

- The module can only be called if no program is running, or if an M/G/S/T/T2/Q strobe is pending. No axis direction key may be pressed in the Manual operating mode. The entered positions are referenced to the machine datum. Rotary axes with transition to zero are positioned by the shortest path.
- If you wish to change a parameter (e.g. target position, feed rate) of a positioning command already in progress, you must first abort positioning, then change the parameter and start again.
- A simultaneous PLC positioning movement of several axes is interpolated. If you start an additional axis while already positioning another, the first movement is aborted, and then all the programmed axes (e.g. X, Y and Z) are positioned together.
- As soon as a PLC positioning with rapid traverse is active (bit 2 is set), all active PLC positioning movements are at rapid traverse, and instead of the feed-rate override the rapid-traverse override is effective.
- Error code 7 not possible.

Positioning auxiliary axes:

- Axes with automatic reduction (modulo value in MP\_isModulo) are always moved to the target position in the direction of the shortest traverse, unless the target position was given as an incremental value.
- The system does not check for limit switch overshoot.
- The axis must be stationary. Any positioning movement must be interrupted beforehand with Module 9121.
- The feed-rate override is not offset.
- If the axis was in the "search for reference mark" state before, this state is canceled. The positioning movement always starts from the current counter value.
- If Modules 9120, 9227 (Start Auxiliary Axis), 9121 (Stop Auxiliary Axis) and 9122 (Pass over Reference in Auxiliary Axis) are called several times for the same axis during a PLC scan, only the latest command is followed.
- Error codes 3 and 4 not possible



Call:

PS B/W/D/K <>Axis>

PS B/W/D/K <>Target position/Increment>  
in [0.0001 mm], ref system

PS B/W/D/K <>Feed rate>  
in [mm/min]

PS B/W/D/K <>Acceleration>  
in [mm/s2]  
0: Value from MP\_maxAcceleration is used

PS B/W/D/K <>Jerk>  
in [mm/s3]  
0: Value is transferred but not evaluated

PS B/W/D/K <>Mode>  
NC and auxiliary axes:  
Bit 0 = 0: Absolute positioning  
Bit 0 = 1: Incremental positioning  
Bit 1 = 1: Software limit switch active  
Only NC axes:  
Bit 2 = 1: Rapid traverse override effective  
Bit 3 = 1: DCM collision monitoring is deactivated

CM 9227

PL B/W/D <>Status>  
0: Function performed  
1: Illegal group number  
2: Incorrect parameterization via bit mask  
5: Axis is not controlled  
6: Axis is already being positioned  
20: Module was not called in a spawn job or submit job

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Function performed
	1	Error (error code in NN_GenApiModuleErrorCode)
NN_GenApiModule ErrorCode (W1022)	1	Invalid group number
	2	Invalid value for bit mask
	20	Module was not called in a spawn job or submit job



## 6.9.1 Hirth coupling

Settings in the configuration editor	MP number
Axes PhysicalAxis [Key name of the axis] CfgAxis <b>isHirth</b>	300103
Axes ParameterSets [Key name of the parameter set] CfgReferencing <b>moveAfterRefType</b>	400410

Hirth coupling describes a type of clamping of rotary axes and swivel heads. Finely splined disks mesh together in order to create a rigid connection.

With the **MP\_isHirth** parameter you specify whether the axis is capable of Hirth coupling. The parameter is optional. The Hirth axis is active as soon as you insert the **MP\_isHirth** parameter and enter a grid increment in [°] measured from the machine datum.

With the **MP\_moveAfterRefType** machine parameter you specify the type of movement after crossing the reference mark. For the Hirth axis you can specify either positive or negative direction of approach to the next Hirth grid position after a reference run.

Use PLC Module 9038 (Read Status Information of Axes) number 4 to ascertain the active Hirth axes. Use PLC Module 9038 number 5 to read the Hirth grid increment from the machine configuration.

With Module 9125 you stop a PLC axis at the next Hirth grid position.

- ▶ Configure the exact positioning of the axis in the Hirth grid as PLC positioning (Modules 9120, 9121, 9125 and 9122).

### Manual Operation mode

As soon as an axis direction key is pressed, the MANUALplus 620 resets the marker in **NN\_AxInPosition** (axis in position).

- ▶ As soon as the axis-in-position bit is set again, compare the nominal position with the Hirth grid and derive from it a PLC positioning command to the next grid point.



## Electronic Handwheel operating mode

For the current handwheel axis, the marker is reset in **NN\_AxInPosition** (axis in position).

As soon as you select another handwheel axis, the marker **NN\_AxInPosition** is set for the previous axis.

The Hirth axis can be positioned with the handwheel.

- ▶ Check the actual position with the Hirth grid and derive from it a PLC positioning command to the next grid point.

## Controlled positioning

The positions of the Hirth axis must be programmed in the grid.

- ▶ Check the positions in the PLC during program run.
- ▶ As soon as "axis in position" is reset, check the target position with the Hirth grid.
- ▶ You must output a PLC error message if the target position is not on the Hirth grid.

### MP\_isHirth

Axis with Hirth coupling

Available from NCK software version: 597 110-02.

Format: Numerical value

Input: Default grid increment in [°] for Hirth coupling, measured from the machine datum

If the parameter is inactive or the value 0 is entered, no Hirth grid is supported

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

### MP\_moveAfterRefType

Type of axis movement after traversing the reference mark

Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **absolute**

Absolute positioning

**relative**

Incremental positioning

**HirthRasterPos**

Approach next Hirth grid position in positive direction

**HirthRasterNeg**

Approach next Hirth grid position in negative direction

Default: absolute

Access: LEVEL3

Reaction: REF

### Module 9125 Stop PLC axis at next Hirth grid position

A positioning started with Module 9120 or Module 9123 can be interrupted with Module 9125 at the next grid position according to the configuration in **MP\_isHirth**.

Constraints:

- The given axis must be activated with **MP\_axisMode = active** and cannot be part of the currently active kinematics (= auxiliary axis).
- If Modules 9120, 9121, 9125 and 9122 are called more than once for the same axis during one PLC scan, then only the last command is transferred.
- The axis will be stopped at the next possible position in the braking direction whose reference coordinate is a multiple of the value from **MP\_isHirth**.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Possible errors:

- A non-existing axis was transferred.
- An axis that is not an auxiliary axis was transferred.
- The entered axis is already stationary.
- An axis was transferred that was not declared as an axis with a Hirth grid in **MP\_isHirth**.

Call:

PS B/W/D/K <>Axis number>  
0 to 8 represent axes 1 to 9

CM 9125

PL B/W/D <>Error code>  
0: Positioning is canceled  
1: Axis does not exist or slave axis was transferred  
2: Not a PLC axis  
3: Axis was already stationary  
4 Axis was not declared as a Hirth axis in MP\_isHirth

### Error recognition:

Marker	Value	Meaning
M4203 or NN_GenApiModule Error	0	Axis stopped successfully
	1	Axis not stopped successfully – See error code above



## 6.10 Axis Error Compensation

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisComp <b>active</b>	401801

The parameter object CfgAxisComp is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)

Axis errors are compensated for by changing the command variables for the position.

The MANUALplus 620 compensates the following mechanically caused axis errors:

- Backlash
- Linear axis errors
- Nonlinear axis errors (direction-dependent)
  - Screw-pitch error
  - Axis sag
- Thermal expansion
- Sliding friction (for digital axes, compensation is carried out in the speed controller)

You can activate either linear or nonlinear axis-error compensation per axis.

Backlash compensation can be activated in addition to linear axis-error compensation.

As of NCK software version 597110-04, if nonlinear axis-error compensation is active, **MP\_backLash** can be used to activate backlash compensation in addition to the compensation-value tables.

You can also add other types of compensation.

- ▶ In **MP\_active**, you switch all compensations (except stiction) on or off.

## **MP\_active**

Switch all axis compensations on/off

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **on**

Backlash compensation, linear or nonlinear axis-error compensation, reversal-error compensation and thermal compensation are all active

**off**

Axis compensations are not active

Default: off

Access: LEVEL3

Reaction: RUN

## 6.10.1 Backlash compensation

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisComp <b>backLash</b> <b>filterTime</b> <b>posCtrlRevErr</b> <b>posCtrlRevErrTime</b>	    401802 401805 401806 401807

The parameter object CfgAxisComp is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)


### Cause outside of the control loop

During a reversal in axis direction, there is often a little play between the rotary encoder and table. This play is referred to as backlash.

If the distance is measured using a speed encoder, the backlash compensation compensates the play between the rotary encoder and the table.

Positive backlash: The rotary encoder reading is ahead of the table. The table traverse is too short.


Negative backlash: The rotary encoder reading is behind the table. The table traverse is too long.



Compensation:

- ▶ Enter the backlash in **MP\_backLash**.
- ▶ In **MP\_filterTime** enter the time in which the distance to be compensated should be traversed.

The value of the backlash is added to the position value at every reversal of direction (even if it results from nonlinear axis-error compensation, for example) and is considered by the position controller. The value of the  $k_v$  factor therefore influences the settling time for backlash compensation.





### **MP\_backLash**

Backlash compensation; backlash outside of the control loop  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -1.0000 to +1.0000 [mm] or [°]  
Default: 0  
Access: LEVEL3  
Reaction: RUN

### **MP\_filterTime**

Time constant for backlash compensation  
Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 1 to 1000 [ms]  
0: Compensation is output as a step  
Default: No value, parameter optional (= 0)  
Access: LEVEL3  
Reaction: RUN

### **Example:**

**MP\_backLash:** 0.03 mm  
**MP\_filterTime:** 15 ms


For every change in direction, a nominal speed command signal is output for 15 ms, which corresponds to a feed rate of 120 mm/min:

$$\frac{0.03 \text{ mm}}{15 \text{ ms}} = 120 \text{ mm/min}$$

## Cause within the control loop

Only possible with digital drive control!

If a position encoder is used for direct distance measurement, the MANUALplus 620 can compensate the play between the motor and the table. At the same time, this compensates the reversal peaks in circular movements.



Compensation

- ▶ In **MP\_posCtrlRevErr** enter the reversal error in [mm].
- ▶ In **MP\_posCtrlRevErrTime** enter the time in which the distance to be compensated should be traversed.

### MP\_posCtrlRevErr

Backlash compensation (distance)

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: -9.9999 to +9.9999 [mm] or [°]

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

### MP\_posCtrlRevErrTime

Backlash compensation (time)

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 0 to 1000 [ms]

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

## 6.10.2 Linear axis error compensation

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisComp <b>linearCompValue</b> <b>compType</b>	    401803 401804

The parameter object CfgAxisComp is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)




### Note

Linear axis error compensation is not available for rotary axes!

For every linear axis you can compensate a linear axis error.

- Positive linear axis error: The table moves too far.
- Negative linear axis error: The table moves too short a distance.



Compensation:

- ▶ In **MP\_linearCompValue**, enter the axis error [mm/m].
- ▶ With **MP\_compType**, activate the linear axis error compensation.

### **MP\_linearCompValue**

Linear axis error compensation  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: -1.000 to +1.000 [mm/m]  
Default: 0  
Access: LEVEL3  
Reaction: RUN

### **MP\_compType**

Selection of linear/nonlinear axis error compensation  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: **linear**  
Linear axis error compensation is active  
**non-linear**  
Nonlinear axis error compensation is active  
Default: linear  
Access: LEVEL3  
Reaction: RUN



#### Note


If **nonlinear** axis-error compensation is active (**MP\_compType** = non-linear), linear axis-error compensation is not available.



### 6.10.3 Nonlinear axis error compensation

Depending on the design of the machine, production tolerances, or external factors (e.g. temperature), a nonlinear axis-error can occur. Typical errors are screw-pitch errors and axis sag.

These graphics show typical nonlinear axis errors:



The best way to measure nonlinear axis error is with a comparator measuring system such as the HEIDENHAIN VM 101.




#### Note

The control can compensate screw-pitch error and axis sag simultaneously.

Nonlinear axis error compensation is also effective for an open loop. In this case the compensation value is considered when the control loop is closed.

Nonlinear axis error compensation supports one compensation value group each for the positive and negative directions of traverse.

The following graphic shows the trace of an axis sag error in the Z axis as a function of Y ( $Z = f(Y)$ ):



## Compensation value tables

The compensation values for nonlinear axis error compensation are stored in the following tables:

- The **\*.COM** tables contain the compensation values for max. 256 compensation points. A \*.COM table is required for each axis and spindle. It consists of the following columns:
  - **AXISPOS:** Compensation points that are assigned compensation values. The compensation points are given with respect to the machine datum. Equidistant spacing between the measuring points is **necessary**.
  - **BACKLASH:** Compensation values for screw pitch errors in negative direction of traverse. The BACKLASH column is defined for the axis for which this compensation-value table is created. This way the backlash can be compensated directly via the compensation-value table.
  - **Axis \* – axis to which the table refers:** Compensation values for screw pitch errors in positive direction of traverse
  - **Axis \* – adjoining axis:** Compensation values for sag errors with respect to the adjoining axis
  - **Spindle:** The compensation values for a spindle are entered in this column
- In the **\*.CMA** table, the \*.COM tables are assigned to the error-causing axis.
  - **ACTIVE:** The character \* activates the compensation value tables.
  - **\* axis:** File name of the \*.COM file with the compensation values of this axis.
  - **Spindle:** File name of the \*.COM file with the compensation values of this spindle.

You will find the path of the \*.CMA tables in the parameter object **System/Paths/CfgTablePath/TABCMA** (standard name of the file: config.cma). The \*.CMA file contains the file names of the \*.COM files. The directory path of the \*.COM tables is entered in the parameter object **System/Paths/CfgOemPath/oemTable**.

## Entering compensation values

The following information must be entered in the <\*.COM> tables:

- ▶ In the AXISPOS column, enter the compensation points for the compensation values. The positions are given with respect to the machine datum (MP\_refPosition).
- ▶ If required, enter the compensation values measured in the negative direction of traverse in the BACKLASH column.
- ▶ Enter the compensation values to which the compensation points belong in the column of the axis for which a dependency relationship exists. The name of the column is the name from CfgAxes/axisList (see Table Format).

**Example:** The following dependencies apply to the Y axis and Z axis:

- Ball screw pitch error in Z and Y:  $Z = F(Z)$  and  $Y = F(Y)$
- Axis sag in Z depending on Y
- Range of traverse: Z axis = 800 mm, Y axis = 500 mm
- Start point for compensation values: Z = -200 mm, Y = -90 mm
- Desired spacing of compensation points: 5 mm

Number of compensation points:


$$\frac{500 \text{ mm}}{5 \text{ mm}} = 100 \text{ compensation points in Y axis}$$

$$\frac{800 \text{ mm}}{5 \text{ mm}} = 160 \text{ compensation points in Z axis}$$





How to access the tables:

- ▶ Switch to the **Organization** operating mode.
- ▶ Press the  soft key.
- ▶ Enter the code number 95148.
- ▶ Press the **PGMMGT** soft key (drive PLC: becomes visible).
- ▶ In the PLC:/table drive, open the tables \*.COM and \*.CMA.

Entries:

<div style="border: 1px solid black; padding: 5px;"> <p>Manual operation    <b>Table editing</b> <b>AXISPOS [mm]</b></p> <p>File: p1c:\table\axis.y.com    Line: 0    &gt;&gt;</p> <table border="1" style="width: 100%; border-collapse: collapse; font-size: 8px;"> <thead> <tr> <th>NR</th> <th>AXISPOS</th> <th>BACKLASH</th> <th>Axis-X</th> <th>Axis-Y</th> <th>Axis-Z</th> </tr> </thead> <tbody> <tr><td>0</td><td>-90</td><td></td><td></td><td>+0</td><td>-0.015</td></tr> <tr><td>1</td><td>-85</td><td></td><td></td><td></td><td>-0.0152</td></tr> <tr><td>2</td><td>-80</td><td></td><td></td><td>+0.004</td><td>-0.0156</td></tr> <tr><td>3</td><td>-75</td><td></td><td></td><td></td><td></td></tr> <tr><td>4</td><td>-70</td><td></td><td></td><td>+0.01</td><td>-0.2</td></tr> <tr><td>5</td><td>-65</td><td></td><td></td><td></td><td></td></tr> <tr><td>6</td><td>-60</td><td></td><td></td><td></td><td></td></tr> <tr><td>7</td><td>-55</td><td></td><td></td><td>+0</td><td></td></tr> <tr><td>8</td><td>-50</td><td></td><td></td><td></td><td>-0.216</td></tr> <tr><td>9</td><td>-45</td><td></td><td></td><td></td><td>-0.2915</td></tr> <tr><td>10</td><td>-40</td><td></td><td></td><td></td><td></td></tr> <tr><td>11</td><td>-35</td><td></td><td></td><td>-0.032</td><td>-0.3003</td></tr> <tr><td>12</td><td>-30</td><td></td><td></td><td></td><td></td></tr> <tr><td>13</td><td>-25</td><td></td><td></td><td>-0.04</td><td></td></tr> <tr><td>14</td><td>-20</td><td></td><td></td><td>-0.0455</td><td></td></tr> <tr><td>15</td><td>-15</td><td></td><td></td><td></td><td>-0.3</td></tr> <tr><td>16</td><td>-10</td><td></td><td></td><td></td><td></td></tr> <tr><td>17</td><td>-5</td><td></td><td></td><td>-0.0452</td><td>-0.302</td></tr> <tr><td>18</td><td>+0</td><td></td><td></td><td></td><td></td></tr> <tr><td>19</td><td>+5</td><td></td><td></td><td>-0.03</td><td></td></tr> <tr><td>20</td><td>+10</td><td></td><td></td><td></td><td>-0.3106</td></tr> <tr><td>21</td><td>+15</td><td></td><td></td><td></td><td></td></tr> <tr><td>22</td><td>+20</td><td></td><td></td><td></td><td></td></tr> <tr><td>23</td><td>+25</td><td></td><td></td><td>-0.0234</td><td>-0.31</td></tr> <tr><td>24</td><td>+30</td><td></td><td></td><td></td><td>-0.35</td></tr> <tr><td>25</td><td>+35</td><td></td><td></td><td></td><td>-0.3501</td></tr> <tr><td>26</td><td>+40</td><td></td><td></td><td></td><td></td></tr> </tbody> </table> <p style="text-align: center; font-size: 8px;"> <span>BEGIN</span> <span>END</span> <span>PAGE</span> <span>PAGE</span> <span>INSERT LINE</span> <span>DELETE LINE</span> <span>FIND</span> </p> </div>	NR	AXISPOS	BACKLASH	Axis-X	Axis-Y	Axis-Z	0	-90			+0	-0.015	1	-85				-0.0152	2	-80			+0.004	-0.0156	3	-75					4	-70			+0.01	-0.2	5	-65					6	-60					7	-55			+0		8	-50				-0.216	9	-45				-0.2915	10	-40					11	-35			-0.032	-0.3003	12	-30					13	-25			-0.04		14	-20			-0.0455		15	-15				-0.3	16	-10					17	-5			-0.0452	-0.302	18	+0					19	+5			-0.03		20	+10				-0.3106	21	+15					22	+20					23	+25			-0.0234	-0.31	24	+30				-0.35	25	+35				-0.3501	26	+40					<p><b>Axis Y:</b> Screw-pitch error in Y axis, sag error in Z axis</p>
NR	AXISPOS	BACKLASH	Axis-X	Axis-Y	Axis-Z																																																																																																																																																																				
0	-90			+0	-0.015																																																																																																																																																																				
1	-85				-0.0152																																																																																																																																																																				
2	-80			+0.004	-0.0156																																																																																																																																																																				
3	-75																																																																																																																																																																								
4	-70			+0.01	-0.2																																																																																																																																																																				
5	-65																																																																																																																																																																								
6	-60																																																																																																																																																																								
7	-55			+0																																																																																																																																																																					
8	-50				-0.216																																																																																																																																																																				
9	-45				-0.2915																																																																																																																																																																				
10	-40																																																																																																																																																																								
11	-35			-0.032	-0.3003																																																																																																																																																																				
12	-30																																																																																																																																																																								
13	-25			-0.04																																																																																																																																																																					
14	-20			-0.0455																																																																																																																																																																					
15	-15				-0.3																																																																																																																																																																				
16	-10																																																																																																																																																																								
17	-5			-0.0452	-0.302																																																																																																																																																																				
18	+0																																																																																																																																																																								
19	+5			-0.03																																																																																																																																																																					
20	+10				-0.3106																																																																																																																																																																				
21	+15																																																																																																																																																																								
22	+20																																																																																																																																																																								
23	+25			-0.0234	-0.31																																																																																																																																																																				
24	+30				-0.35																																																																																																																																																																				
25	+35				-0.3501																																																																																																																																																																				
26	+40																																																																																																																																																																								
<div style="border: 1px solid black; padding: 5px;"> <p>Manual operation    <b>Table editing</b> <b>Axis-Z [mm]</b></p> <p>File: p1c:\table\axis.z.com    Line: 0    &gt;&gt;</p> <table border="1" style="width: 100%; border-collapse: collapse; font-size: 8px;"> <thead> <tr> <th>NR</th> <th>AXISPOS</th> <th>BACKLASH</th> <th>Axis-X</th> <th>Axis-Y</th> <th>Axis-Z</th> </tr> </thead> <tbody> <tr><td>0</td><td>+55</td><td></td><td></td><td></td><td>+0.12</td></tr> <tr><td>1</td><td>+50</td><td></td><td></td><td></td><td>+0</td></tr> <tr><td>2</td><td>+45</td><td></td><td></td><td></td><td>+0.023</td></tr> <tr><td>3</td><td>+40</td><td></td><td></td><td></td><td></td></tr> <tr><td>4</td><td>+35</td><td></td><td></td><td></td><td></td></tr> <tr><td>5</td><td>+30</td><td></td><td></td><td></td><td></td></tr> <tr><td>6</td><td>+25</td><td></td><td></td><td></td><td>+0.12</td></tr> <tr><td>7</td><td>+20</td><td></td><td></td><td></td><td>+0.129</td></tr> <tr><td>8</td><td>+15</td><td></td><td></td><td></td><td>+0.049</td></tr> <tr><td>9</td><td>+10</td><td></td><td></td><td></td><td>+0.009</td></tr> <tr><td>10</td><td>+5</td><td></td><td></td><td></td><td></td></tr> <tr><td>11</td><td>+0</td><td></td><td></td><td></td><td></td></tr> <tr><td>12</td><td>-5</td><td></td><td></td><td></td><td></td></tr> <tr><td>13</td><td>-10</td><td></td><td></td><td></td><td></td></tr> <tr><td>14</td><td>-15</td><td></td><td></td><td></td><td>+0</td></tr> <tr><td>15</td><td>-20</td><td></td><td></td><td></td><td></td></tr> <tr><td>16</td><td>-25</td><td></td><td></td><td></td><td>-0.0065</td></tr> <tr><td>17</td><td>-30</td><td></td><td></td><td></td><td>-0.01</td></tr> <tr><td>18</td><td>-35</td><td></td><td></td><td></td><td></td></tr> <tr><td>19</td><td>-40</td><td></td><td></td><td></td><td>-0.0153</td></tr> <tr><td>20</td><td>-45</td><td></td><td></td><td></td><td>-0.019</td></tr> <tr><td>21</td><td>-50</td><td></td><td></td><td></td><td>-0.0251</td></tr> <tr><td>22</td><td>-55</td><td></td><td></td><td></td><td>-0.0213</td></tr> <tr><td>23</td><td>-60</td><td></td><td></td><td></td><td>-0.022</td></tr> <tr><td>24</td><td>-65</td><td></td><td></td><td></td><td>-0.0212</td></tr> <tr><td>25</td><td>-70</td><td></td><td></td><td></td><td>-0.0187</td></tr> <tr><td>26</td><td>-75</td><td></td><td></td><td></td><td>-0.0164</td></tr> </tbody> </table> <p style="text-align: center; font-size: 8px;"> <span>BEGIN</span> <span>END</span> <span>PAGE</span> <span>PAGE</span> <span>INSERT LINE</span> <span>DELETE LINE</span> <span>FIND</span> </p> </div>	NR	AXISPOS	BACKLASH	Axis-X	Axis-Y	Axis-Z	0	+55				+0.12	1	+50				+0	2	+45				+0.023	3	+40					4	+35					5	+30					6	+25				+0.12	7	+20				+0.129	8	+15				+0.049	9	+10				+0.009	10	+5					11	+0					12	-5					13	-10					14	-15				+0	15	-20					16	-25				-0.0065	17	-30				-0.01	18	-35					19	-40				-0.0153	20	-45				-0.019	21	-50				-0.0251	22	-55				-0.0213	23	-60				-0.022	24	-65				-0.0212	25	-70				-0.0187	26	-75				-0.0164	<p><b>Axis Z:</b> Screw-pitch error in Z axis</p>
NR	AXISPOS	BACKLASH	Axis-X	Axis-Y	Axis-Z																																																																																																																																																																				
0	+55				+0.12																																																																																																																																																																				
1	+50				+0																																																																																																																																																																				
2	+45				+0.023																																																																																																																																																																				
3	+40																																																																																																																																																																								
4	+35																																																																																																																																																																								
5	+30																																																																																																																																																																								
6	+25				+0.12																																																																																																																																																																				
7	+20				+0.129																																																																																																																																																																				
8	+15				+0.049																																																																																																																																																																				
9	+10				+0.009																																																																																																																																																																				
10	+5																																																																																																																																																																								
11	+0																																																																																																																																																																								
12	-5																																																																																																																																																																								
13	-10																																																																																																																																																																								
14	-15				+0																																																																																																																																																																				
15	-20																																																																																																																																																																								
16	-25				-0.0065																																																																																																																																																																				
17	-30				-0.01																																																																																																																																																																				
18	-35																																																																																																																																																																								
19	-40				-0.0153																																																																																																																																																																				
20	-45				-0.019																																																																																																																																																																				
21	-50				-0.0251																																																																																																																																																																				
22	-55				-0.0213																																																																																																																																																																				
23	-60				-0.022																																																																																																																																																																				
24	-65				-0.0212																																																																																																																																																																				
25	-70				-0.0187																																																																																																																																																																				
26	-75				-0.0164																																																																																																																																																																				



## Assigning the compensation value tables to the axes

General relationship for \*.CMA tables:

[Axis in column from \*.com] = F(Axis in column from \*.cma, in which \*.com is entered)

Enter the compensation-value tables in a table of the type <\*.CMA> (standard name config.cma).

(for table formatting, see the chapter Tables):

- ▶ Enter a column for each axis to be compensated. The column names must match the axis keys from CfgAxes/axisList.
- ▶ Enter the names of the compensation-value tables (\*.com) line-by-line in the appropriate axis columns.  
You can assign more than one compensation value table to each axis, however only one table can be active.
- ▶ Activate the compensations with an \* in the column ACTIVE, which can be entered via the table editor or via the PLC (SQL server).  
All compensations in this line become active.

### Example:

Z axis = F(Y axis); axis sag compensation  
Y axis = F(Y axis); nonlinear compensation

The first line is active.

Entries:

Manual operation

**Table editing**

**ACTIVE**

File: plc:\table\config.cma      Line: 0

NR	ACTIVE	Axis-X	Axis-V	Axis-Z	Axis-S
0		AXIS_X	AXIS_V	AXIS_Z	
1	*	AXIS_X AXIS			SPINDLE

M

S

T

DIAGNOSIS

BEGIN END PAGE PAGE INSERT DELETE FIND  
↑ ↓ ↑ ↓ LINE LINE

CMA table



## Activate error compensation

Three requirements must be fulfilled for activating nonlinear axis error compensation:

- ▶ Activate the general compensation procedures with **MP\_active = ON**.
- ▶ Activate the axis-specific nonlinear axis error compensation with **MP\_compType=non-linear** (see "Linear axis error compensation" on page 711).
- ▶ In the config.cma file, activate a line with an \* in the ACTIVE column or with Module 9095. The active line can be interrogated using Module 9035.



### Note

Compensation is not available for axis and spindle positioning by PLC.

### Module 9095 Activate axis-error compensation

Module 9095 activates a line in the selected file (\*.CMA) and assigns the arguments for the compensation value tables (\*.COM). Multiple measurement series (e.g.  $x=f()$ ,  $y=f()$ ..) can be stored in the compensation value tables. After the module has been executed, the argument is assigned. In this way the screw pitch error  $x=f(x)$  and axis sag  $x=f(y)$  can be compensated simultaneously, for example.

Constraints:

- The transferred line remains selected as the active line even after a control reset.
- Once the NC program has started, the module operates only during the output of an M/G/S/T/T2/Q strobe.
- The nominal axis values may change slightly when the compensation value table is switched over.

Call:

PS B/W/D/K <>Active line>

CM 9095

PL B/W/D <>Error code>

0: Compensation was selected

1: Line was not found in the \*.CMA table

2: Compensation value table (\*.COM) is missing

3: Compensation value table > 256 entries

4: Maximum total number of compensation points exceeded

5: Too many compensation value tables (>10)

6: \*.CMA file does not exist

7: Call was not from a submit job

8: Call during running program without strobe

10: \*.CMA file is protected

### Module 9035 Read NC status information

Module 9035 reads status information. A function number specifying the desired status information is transferred.

Function number 19: Display active line in the \*.CMA file



#### Note

The line number is displayed even if the active line does not contain any \*.COM file.

Call:

PS B/W/D/K <>19>  
Display active line of the \*.CMA file

CM 9035

PL B/W/D <>Active line number>  
0: Line number  
-1: No \*.CMA file active

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	No error
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	The transferred input parameter does not identify any status information available with the software version being used.
	20	Information which is only available in a submit/spawn job was requested in the cyclic PLC program.

#### Special case: Modulo rotary axis

For a rotary axis with modulo counting method (**MP\_isModulo = TRUE**), only the compensation values for the entries of 0° to +360° are effective, relative to the machine datum. Therefore, the datum for the nonlinear compensation must lie within the 0° to +360° range. To compensate a full circle, set the compensation value datum to the machine datum.

This special case does not apply to rotary axes without modulo counting mode. Compensation values in the \*.COM table can also have negative values on rotary axes without modulo counting method.

#### Special case: Master and slave axes

Separate compensation tables can be created for master axes and slave axes.



## 6.10.4 Compensation of thermal expansion

Settings in the configuration editor	MP number
System PLC CfgPlcPeriphery <b>tempCompensation</b>	103405
Axes ParameterSets [Key name of the parameter set] CfgAxisComp <b>active</b>	401801

The parameter object CfgAxisComp is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)

To compensate thermal expansion, exact measurements of machine thermal behavior as a function of temperature (e.g., the center of axis expansion, the amount of the expansion) are necessary. Since the thermal expansion of the axes is largely proportional to the temperature, you can determine the amount of expansion by multiplying the temperature value by a certain factor.

The temperature values measured by the Pt100 thermistors are transferred using Module 9003. Module 9231 activates the compensation for thermal expansion according to the lag tracking method.

Compensation:

- ▶ Activate the general compensation procedures with **MP\_active=ON** (see "MP\_active" on page 706).
- ▶ Transfer the distance to be compensated to Module 9231. At the same time, "lag tracking" becomes active. This means that the actual position is offset by a certain value per PLC cycle until the complete value is compensated.
- ▶ Define the amount of compensation per PLC cycle for lagged-tracking axis error compensation in MP\_tempCompensation.

For gantry axes, the compensation value must be transferred separately for each axis.

### MP\_tempCompensation

Compensation of thermal expansion

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.0000 to 359999.6400 [mm/min]  
0 = Compensation not active

Default: 0

Access: LEVEL2

Reaction: NOTHING

### Module 9231 Compensation of thermal expansion

Thermal expansion is compensated by Module 9231. The axis number and the compensation value are transferred.

The module activates lag tracking. This means that the actual position is offset by a certain value per PLC cycle until the complete value is compensated. The increment of change per PLC cycle must be defined in MP\_tempCompensation.

This does not change the value in the actual position display.

The module functions only in the cyclic PLC program.

Call:

```
PS    B/W/D/K <>Axis>
      Index from CfgAxes/axisList
PS    B/W/D/K <>Compensation value>
      Range: -30000 to +30000 [1/10 µm]
CM    9231
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	No error
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid axis number
	3	Invalid compensation value
	24	The module was called in a spawn job or submit job



## 6.10.5 Compensation of static friction

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgSpeedControl <b>vCtrlIntTime</b>	400903

The parameter object CfgSpeedControl is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)
- Analog axes (MP\_axisHw=Analog)

In machines with a great deal of static friction (stiction), a high integral-action component can accumulate over time if there is a position error at standstill. This can result in a jump in position when the axis begins moving. In such cases you can limit the integral-action component of the speed controller in

### **MP\_vCtrlIntTime:**

- ▶ Enter a limit in **MP\_vCtrlIntTime**. Realistic input values: 0.1 to 2.0

### **MP\_vCtrlIntTime**

Limit of integral factor of the speed controller  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 30 [s]  
Default: 0 [s]  
Access: LEVEL3  
Reaction: RUN

## 6.10.6 Compensation of sliding friction

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgControllerComp <b>compFriction0</b> <b>compFrictionT1</b> <b>compFrictionT2</b> <b>compFrictionNS</b>	    401401 401402 401403 401404

The parameter object CfgControllerComp is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)
- Analog axes (MP\_axisHw=Analog)

### CC 61xx, CC 424



#### Note

Machine parameters **MP\_compFrictionT1** and **MP\_compFrictionT2** now function with respect to distance rather than time (unit: [mm] or [°]).

With the CC 61xx and CC 424, this makes it possible to compensate quadrant transitions independently from velocity, acceleration, and diameter.

The CC calculates the distance from the zero crossover of velocity. The compensation current is reduced starting from the distance **before** the zero crossover defined in **MP\_compFrictionT1**. After the zero crossover, the compensation current is increased again. **MP\_compFrictionT2** defines the point **after** the zero crossover at which 63 % of the compensation current is reached.

- ▶ In **MP\_compFrictionT1**, define the distance before the reversal point from which a reduction of the current from **MP\_compFriction0** is to go into effect.
- ▶ In **MP\_compFrictionT2**, define the distance after the reversal point from which the current from **MP\_compFriction0** is to go into effect again.





### **MP\_compFriction0**

Friction compensation at low speed  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 30 [A]  
Default: 0 [A]  
Access: LEVEL3  
Reaction: RUN

### **MP\_compFrictionT1**

Distance before the reversal point for reducing the current from  
MP\_compFriction0  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 1 [mm] or [°]  
The following units of measure apply:  
**MP\_compFrictionT1** = [s] if **MP\_compFrictionT2** = 0  
(same behavior as CC 422)  
**MP\_compFrictionT1** = [mm] if **MP\_compFrictionT2** > 0  
0: No friction compensation  
Default: 0  
Access: LEVEL3  
Reaction: RUN

### **MP\_compFrictionT2**

Distance after the reversal point for current from  
MP\_compFriction0  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 1 [mm] or [°]  
0: Friction compensation same as with CC 422  
Default: 0 [mm]  
Access: LEVEL3  
Reaction: RUN

### Module 9311 Dynamically change values for friction compensation

Module 9311 is used at run-time to prescribe other values for the friction compensation. The original values from **MP\_compFriction0**, **MP\_compFrictionT1** and **MP\_compFrictionT2** are temporarily overwritten in the DSP. The values in the machine configuration remain unchanged.

Call:

PS B/W/D/K <>Axis number>  
PS B/W/D/K <>Current in [mA]>  
0...30000 replaces value in MP\_compFriction0  
PS B/W/D/K <>Path in [0.1 µm]>  
0...10000 replaces value in MP\_compFrictionT1  
PS B/W/D/K <>Path in [0.1 µm]>  
0...10000 replaces value in MP\_compFrictionT2

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	New values assumed for axis number
	1	Error in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Invalid value as replacement for machine parameter
	2	Invalid axis number programmed
	19	Function is not supported by the DSP board (e.g. CC 422)
	24	Call was not from a cyclic program



## 6.11 Machine Kinematics (As of NC Software 548328-03)

As of software version 548328-03, a new kinematic model is available for describing the machine kinematics of the MANUALplus 620. The MANUALplus 620 can be operated as selected with the old or the new kinematic model. The use of KinematicsDesign is possible only with the new kinematic model, which is also activated in the factory default condition.

Machine parameters in the MANUALplus 620 describe the machine kinematics. It is a precondition that the kinematic models consist of translation axes and rotation axes which are linked to each other. This structure can also be used for configuring axes that are not perpendicular with respect to each other.

Multiple sets of kinematics can be configured for one machining channel. Multiple sets of kinematics are needed, for example, if the spindle and C axis on a lathe are driven by the same motor. The kinematics description consists of a transformation chain, starting from the tool reference point to the linear axes, all the way to the last axis or transformation.

The transformation chain consists of

- fixed lengths (machine dimensions)
- variable lengths (linear axes)
- fixed rotations (machine conditions)
- variable rotations (rotary axes)

starting from the tool reference point (e.g. spindle housing, machine base, linear axes, machine envelope). Each translation is described.

All machine axes in the kinematic model are described in the position REF=0 (machine center).




### Note

The KinematicsDesign software for PCs can only be used in conjunction with the new kinematic model described below.

**Example 1:****Preconfigured kinematics in the factory default setting of the NC software**

In the factory default setting of the NC software, the kinematic properties of a lathe with spindle, X axis, Y axis and Z axis is already preconfigured in the kinematic model K4\_CH1\_S1.





### 6.11.1 Configuring the machine kinematics

Specify the machine kinematics as well as the resulting transformation model, starting from the machine reference point (REF 0).


- ▶ Set the axes to the machine datum

Basic procedure: Work your way "from the bottom up" through the folders of the kinematic configuration (System/Channels/Kinematics).

- ▶ Configure a machine base

Define the fixed points in the kinematics chain with the **CfgKinAnchor** configuration object. A machine base is such a fixed point.

- ▶ Create a key name (= folder) for the machine base under **CfgKinAnchor**, e.g. **Base**. Select the value **MachBase** for the parameter **MP\_kindOfAnchor**. You will need the machine base later for the configuration of subkinematics.



## MP\_kindOfAnchor

Fixed point in the kinematics chain  
Available from NCK software version: 597 110-03.

Format: Selection menu

Selection: **MachBase**

Specifies a fixed point in the kinematics chain.  
In the desired subkinematics (CfgKinSimpleModel), enter the machine base (e.g. with the key name "Base") at the appropriate position in the list, i.e.:

MachAxisY  
MachAxisZ  
MachAxisX  
MACH\_BASE

Default: –


Access: LEVEL3

Reaction: RUN

- ▶ Now define the machine axes in the kinematics chain

Define via **CfgKinSimpleAxis** the point at which a machine axis becomes effective in the kinematics sequence. Movements by the indicated axis (**MP\_axisRef**) change via the entry **MP\_dir** the positions of previously defined axes or objects relative to subsequent axes or objects. The start of the sequence is always the tool reference point.

- ▶ Define under **CfgKinSimpleAxis** a key name (= folder) for each machine axis, e.g. **MachAxisX**. Enter via **MP\_dir** the direction and via **MP\_axisRef** the axis from System/CfgAxes/axisList to which the machine axis belongs.



**MP\_dir**

Direction of the machine axis

Available from NCK software version: 597 110-03.

Format: Selection menu

Selection: **X, Y, Z, A, B, C**

Specifies the direction of the machine axis in the local coordinate system, which is given by the previous coordinate transformations.

An X or A entry means that the machine axis moves or rotates in the X direction of the local coordinate system. Y and B stand for the Y direction, Z and C for the Z direction.

Default: –

Access: LEVEL3

Reaction: RUN





## MP\_axisRef

Reference to the associated machine axis  
Available from NCK software version: 597 110-03.

Format: String

Input: Max. 18 characters

Enter here the key name of the associated axis from System/  
CfgAxes/axisList.

Default: -


Access: LEVEL3

Reaction: RUN

- ▶ Now define the transformations in three dimensions

Starting from the tool reference point, define in sequence the shifts or rotations via the linear, rotary and tilting axes to a center point of a (rotary) table.

- ▶ Enter the shifts and rotations under **CfgKinSimpleTrans**. Define key names for the transformations. Create a folder for each transformation. A transformation is performed in the axis direction entered under **MP\_dir** in the current kinematics sequence by the value entered in **MP\_val**. This can be a linear translation as well as a rotation about an axis.



Example: Rotation of the coordinate system around the C axis by  $-180^\circ$ :

**MP\_dir = C**

**MP\_val = -180**

Enter in **MP\_val** the value for the transformation. For linear axes (X, Y, Z, ...) the value is entered in [mm] or for rotary axes (A, B, C) in  $^\circ$ . Example:

**MP\_val = 47.092** [mm] or

**MP\_val = 45.05**  $^\circ$

The units are not entered. The MANUALplus 620 interprets the units of measurement from the axis designation indicated in **MP\_dir**.

As a rule, the MANUALplus 620 takes changes in the mechanical offset into account, meaning that these changes do not have to be compensated with a PLC datum shift.

## MP\_dir

Direction of the transformation

Available from NCK software version: 597 110-03.

Format: Selection menu

Selection: **X, Y, Z, A, B, C**

The selection of X, Y and Z indicates that it is a shift of the coordinate system in X, Y or Z direction. If A, B, or C is indicated, then it is a rotation of the coordinate system about the A, B or C axis.

Default: –

Access: LEVEL3

Reaction: RUN

## MP\_val

Value of the transformation

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: –999 999 999.999 999 999 to +999 999 999.999 999 999 [mm] or [°]

Default: –

Access: LEVEL3


Reaction: RUN

### ► Now define the subkinematics

Subkinematics can be included separately, and so increase the flexibility of the machine kinematics. On machines with exchangeable components you can use the subkinematics in multiple kinematic models.

Subkinematics are defined under **CfgKinSimpleModel**:

- Create a folder (= key name of the subkinematics) for each subkinematics under **CfgKinSimpleModel**. Under **MP\_kinObjects** you describe the structure of the subkinematics. Then, in sequence from the tool to the machine base you enter the names of the kinematics objects comprising the subkinematics. Kinematics objects can be machine axes (key names from CfgKinSimpleAxis), transformations (key names from CfgKinSimpleTrans) and fixed points (e.g. the machine base key name from CfgKinAnchor).



## MP\_kinObjects


List of key names of objects in the kinematics chain  
Available from NCK software version: 597 110-03.

Format: Array [0...49]  
Default: -  
Access: LEVEL3  
Reaction: RUN

► Now collect the subkinematics to form a kinematic model

Define kinematic models under **CfgKinComposModel**.

► Create a folder (= key name) for the kinematic model under **CfgKinComposModel**. Via **MP\_subKinList** you enter the subkinematics that comprise the kinematic model. The list must be in the sequence from the tool [0] to the machine table. It is also possible to enter just one subkinematics. Enter under **MP\_activeSpindle** the name of the spindle (from System/CfgAxes/axisList) that belongs to the kinematic model. If tilting of the working plane is allowed for the kinematic model, enter the value TRUE in the parameter **MP\_tiltingAllowed**.



### **MP\_subKinList**

List of key names of the subkinematics  
Available from NCK software version: 597 110-03.

Format: Array [0...5]  
Input: Enter the subkinematics comprising the machine kinematics, going from the tool to the workpiece.  
Default: –  
Access: LEVEL3  
Reaction: RUN

### **MP\_activeSpindle**

Key name of the active spindle of this kinematic model  
Available from NCK software version: 597 110-03.

Format: String  
Input: The name of the spindle can be taken from System/CfgAxes/AxisList, e.g. S, Spindle1, etc.  
Default: –  
Access: LEVEL3  
Reaction: RUN

### **MP\_tiltingAllowed**

Tilting the working plane is allowed  
Available from NCK software version: 597 110-04.


Format: Selection menu  
Selection: TRUE  
Tilting the working plane is allowed with this kinematic model.  
FALSE  
Tilting the working plane is not allowed with this kinematic configuration. The MANUALplus 620 displays an error message.  
Default: No value, parameter optional (= TRUE)  
Access: LEVEL3  
Reaction: RUN



- ▶ Last step: Assign the configured kinematics models to the machining channel.

The settings for the machining channel (ChannelSettings/CH\_NC1) must include the kinematic models valid for this channel:

- ▶ Open the **CfgKinList** configuration object. Enter in the **kinCompositeModels** list parameter the key names of the kinematic models for the machining channel.
- ▶ Open the **CfgAcitvateKinem** configuration object. Choose from the selection menu of the **MP\_kinemToActivate** parameter the key name of the kinematic model to be activated.



### **MP\_kinCompositeModels**

List of key names of kinematic models for this machining channel

Available from NCK software version: 597 110-03.

Format: Selection menu

Selection: Key names from Channels/Kinematics/CfgKinComposModel

Default: –

Access: LEVEL3

Reaction: RUN

### **MP\_kinemToActivate**

Kinematics to be activated / Active kinematics

Available from NCK software version: 597 110-03.

Format: Selection menu

Selection: Key names from Channels/Kinematics/CfgKinComposModel

Select the key name of the kinematics configuration to be activated. You can also see from this parameter which kinematics configuration is currently active.

Default: –

Access: LEVEL3

Reaction: RUN



#### Note

As an alternative you can configure the kinematics with the PC software KinematicsDesign. Registered customers can download the software from HESIS-Web Including Filebase on the Internet at <http://hesis.heidenhain.de>. The User's Manual is included with the software as online help.



## 6.11.2 Preconfigured subkinematics

The following table lists all preconfigured subkinematics that are included in the control when it is shipped.

Subkinematics	Meaning	Transformation	Meaning
TOOL_TH1	Tool carrier	TH1_Y TH1_X TH1_Z	Direction of the tool length in Y, X, Z
K_XYZ_CH1	Linear axes	TransMaAxDummy2_C0	Placeholder for automatic mirroring of the X axis <sup>1</sup>
		MachAxisY1	Position of Y axis
		TransMaAxDummy1_C0	Placeholder for automatic mirroring of the X axis <sup>1</sup>
		MachAxisX1	Position of X axis
		MachAxisZ1	Position of Z axis
		Mach_BASE	Fixed position of the kinematics chain
K_C1	C axis	K_C1	Position of C axis
K_WP_S1	Workpiece spindle	WpS1_Y	Position of workpiece spindle Y
		WpS1_X	Position of workpiece spindle X
		TransWpS1_C0	Placeholder for automatic mirroring of the X axis <sup>1</sup>
		WpS1_Z	Position of workpiece spindle Z
K_XYZ_CH1_MIR		TransMachAxis_C-180	Reverse rotation of X axis
		MachAxisY1	Position of Y axis
		TransMaAxDummy1_C0	Placeholder for mirroring of the X axis <sup>1</sup>
		MachAxisX1	Position of X axis
		MachAxisZ1	Position of Z axis
		Mach_BASE	Fixed position of the kinematics chain

Subkinematics	Meaning	Transformation	Meaning
K_WP_S1_MIR_X		WpS1_Y	Position of workpiece spindle Y
		WpS1_X	Position of workpiece spindle X
		TransWpS1_C180	Mirroring of the X axis
		WpS1_Z	Position of workpiece spindle Z
K_XYZ_CH1_Y30		TransMachAxis_C-30	Reverse rotation of Y axis
		MachAxisY1	Position of Y axis
		TransMachAxis_C30	Oblique-axis position (Y=30°)
		MachAxisX1	Position of X axis
		MachAxisZ1	Position of Z axis
		Mach_BASE	Fixed position of the kinematics chain
K_XYZ_CH1_Y30_MIR		TransMachAxis_C-210	Reverse rotation of: – Mirroring of X axis – Oblique-axis position (Y30)
		MachAxisY1	Position of Y axis
		TransMachAxis_C30	Oblique-axis position (Y=30°)
		MachAxisX1	Position of X axis
		MachAxisZ1	Position of Z axis
		Mach_BASE	Fixed position of the kinematics chain
K_WP_S1_MIR_X		WpS1_Y	Position of workpiece spindle Y
		WpS1_X	Position of workpiece spindle X
		TransWpS1_C180	Mirroring of the X axis
		WpS1_Z	Position of workpiece spindle Z

<sup>1)</sup> TransMaAxDummy1\_C0, TransMaAxDummy2\_C0 and TransWpS1\_C0 are required for automatic activation of kinematics "in front of the workpiece" for configurations with tool turrets and MultiFix.



During the installation of the configuration data for rear-face machining (see "Configuring rear-side machining" on page 1455), the following, pre-configured subkinematics are also installed on the control.

<b>Subkinematics</b>	<b>Meaning</b>	<b>Transformation</b>	<b>Meaning</b>
K_XYZ_CH1_RSB	Rear-face machining	MachAxisY1	Position of Y axis
		MachAxisX1	Position of X axis
		Trans_Z1	Datum offset
		MachAxisZ1	Position of Z axis
		MachAxisW1	Position of the W axis
		MACH_BASE	Fixed position of the kinematics chain
K_WP_S4_RSB	Opposing spindle	WpS4_Y	Position of the opposing spindle Y
		WpS4_X	Position of the opposing spindle X
		WpS4_Z	Position of the opposing spindle Z
		Trans_A180	Mirroring of the Z axis <sup>1</sup>

<sup>1)</sup> For rear-face machining, the transformation (Trans\_A180) of the workpiece spindle S4 is performed counterclockwise, i.e. the direction of the X axis and the Y axis can be retained if the Z axis is turned by 180° .

### 6.11.3 Standard kinematic models

In the factory default setting, the following subkinematics are assigned to the existing standard kinematic models:

Kinematic models	Subkinematics
K1_CH1_S12_C1 – Driven tool – With C axis	CfgKinComposModel -> subKinList [0] = TOOL_TH1 [1] = K_XYZ_CH1 [2] = K_C1 [3] = K_WP_S1 -> activeSpindle = S2
K1_CH1_S12 – Driven tool – No C axis	CfgKinComposModel -> subKinList [0] = TOOL_TH1 [1] = K_XYZ_CH1  [2] = K_WP_S1 -> activeSpindle = S2
K1_CH1_S1_C1 – Spindle – With C axis	CfgKinComposModel -> subKinList [0] = TOOL_TH1 [1] = K_XYZ_CH1 [2] = K_C1 [3] = K_WP_S1 -> activeSpindle = S1
K1_CH1_S1 [Standard kinematic model] – Spindle – No C axis	CfgKinComposModel -> subKinList [0] = TOOL_TH1 [1] = K_XYZ_CH1  [2] = K_WP_S1 -> activeSpindle = S1



During the installation of the configuration data for rear-face machining (see "Configuring rear-side machining" on page 1455), the following, pre-configured kinematic models are also installed on the control.

Kinematic models	Subkinematics
K10_CH1_S12_C2 - driven tool S2 - with C axis C2	CfgKinComposModel -> subKinList [0] = TOOL_TH1 [1] = K_XYZW_CH1 [2] = K_C2 [3] = K_WP_S1 -> activeSpindle = S2
K11_CH1_S1_C2 - C axis C2 with stationary tool	CfgKinComposModel -> subKinList [0] = TOOL_TH1 [1] = K_XYZW_CH1 [2] = K_C2 [3] = K_WP_S1 -> activeSpindle = S1
K41_CH1_S42_C2 - driven tool S2 - with opposing spindle S4 - with C axis C2	CfgKinComposModel -> subKinList [0] = TOOL_TH1 [1] = K_XYZ_CH1_RSB [2] = K_C2 [3] = K_WP_S4_RSB -> activeSpindle = S2
K42_CH1_S42 - driven tool S2 - with opposing spindle S4	CfgKinComposModel -> subKinList [0] = TOOL_TH1 [1] = K_XYZ_CH1_RSB [2] = K_WP_S4_RSB -> activeSpindle = S2
K43_CH1_S4_C2 - with opposing spindle S4 - with C axis C2	CfgKinComposModel -> subKinList [0] = TOOL_TH1 [1] = K_XYZ_CH1_RSB [2] = K_C2 [3] = K_WP_S4_RSB -> activeSpindle = S4
K44_CH1_S4 - with opposing spindle S4	CfgKinComposModel -> subKinList [0] = TOOL_TH1 [1] = K_XYZ_CH1_RSB [2] = K_WP_S4_RSB -> activeSpindle = S4



## 6.11.4 Finding/activating kinematics through the PLC

### Module 9097 Activate kinematics configuration

With Module 9097, the PLC activates a kinematic configuration. The kinematic model must be entered under CfgKinComposModel in the machine configuration. It must also be in CfgKinList of the NC machining channel.

Constraints:

- The module is not executable in the cyclic PLC program.
- While the module is being executed you must not abort the submit job with a CAN command.
- Selection is not possible with a running NC program.

Call:

PS B/W/D/K <>Index from CfgKinList>

PS B/W/D/K <>Mode setting>

0: Parameter currently has no function  
(Mode must be 0)

CM 9097

PL B/W/D <>Error condition>

0: Kinematic configuration was activated

1: Invalid mode setting was transferred

2: Axis does not exist in CfgKinList

6: Call was not from a submit/spawn job

7: Call during running program without strobe

8: Configuration datum CfgKinList is not defined

12: No NC channel defined, or more than one defined

13: Names of collision objects not unique

### Error recognition:

Marker	Value	Meaning
M4203 or NN_GenApiModule Error	0	Kinematic configuration was activated
	1	Error code in NN_GenApiModuleError
W1022 or NN_GenApiModule ErrorCode	2	Invalid mode setting programmed. Index in CfgKinList does not exist. Configuration datum CfgKinList is missing
	20	Module was not called in a spawn or submit job
	21	Call during already started PGM without strobe

### Module 9098 Find active kinematics configuration

The PLC uses Module 9098 to find the active kinematics configuration. Both the index from CfgKinList as well as the key name of the kinematic model can be interrogated.

Constraints:

- The module is not executable in the cyclic PLC program.

Call:

PS B/W/D/K <>String number for key name of the kinematic model  
0...15: String number for key name  
(the index from CfgKinList is also acquired)  
-1: Only find index from CfgKinList; do not acquire the name

CM 9098

PL B/W/D <>Index from CfgKinList  
-1: Index could not be acquired

### Error recognition:

Marker	Value	Meaning
M4203 or NN_GenApiModule Error	0	Kinematic configuration was selected
	1	Error code in NN_GenApiModuleErrorCode
W1022 or NN_GenApiModule ErrorCode	2	Invalid parameter programmed for string number
	20	Module was not called in a spawn or submit job
	30	Configuration datum CfgKinList or CfgActivateKinem is not defined, or the entry from CfgActivateKinem was not found in CfgKinList
	58	No NC channel configured, or more than one configured

## 6.11.5 Axis mirroring on lathes (as of NC software 548328-03)

Settings in the configuration editor	MP number
Aggregates	
ToolMount	
[Key name of the tool holder]	
CfgToolMount	
<b>kinModelToModify</b>	600418
<b>kinModel</b>	600419

Axis mirroring on lathes is required, for example, when carrying out machining operations above or below the turning center or on the rear side. Such axis mirroring is done within a kinematics group; there is no kinematics change.

Axis mirroring is activated/deactivated either via NC commands or by assigning the activation/deactivation to a tool holder.

With the tool holder (parameter object **CfgToolMount**), you can control axis mirroring with the following parameters:

- **MP\_kinModelToModify**: Subkinematics to be replaced of the axis or axes to be mirrored
- **MP\_kinModel**: Subkinematics of the mirrored axis/axes, which is to be activated

Axis mirroring that is configured with the tool holder will be activated when the tool holder is inserted. Axis mirroring will remain active until the next tool change.

### **MP\_kinModelToModify**

Keys of the subkinematics to be replaced  
Available from NCK software version: 597 110-04.

Format: Array [0...99]  
Default: -  
Access: LEVEL3  
Reaction: RESET

### **MP\_kinModel**

Keys of the subkinematics to be activated  
Available from NCK software version: 597 110-04.

Format: Array [0...99]  
Default: -  
Access: LEVEL3  
Reaction: RESET



## 6.12 Machine Kinematics (Up to NC Software 548 328-02)

Machine parameters in the control describe the machine kinematics. It is a precondition that the kinematic models consist of translation axes and rotation axes which are linked to each other. This structure can also be used for configuring axes that are not perpendicular with respect to each other.

Multiple sets of kinematics can be configured for one machining channel. Multiple sets of kinematics are needed, for example, if the spindle and C axis on a lathe are driven by the same motor.

After control startup, the last kinematics model entered in **CfgKinModel** will be active. If required, activate another kinematics model.



### Note

The prepared, standard machine kinematics of the MANUALplus 620 include all common lathe applications. If adjustments of the machine kinematics are nevertheless required, you will find all necessary information in the following sections.

The KinematicsDesign software for PCs **cannot** be used in conjunction with the old kinematics model described below.

## 6.12.1 Configuration of the machine kinematics

### Overview of machine parameters for the kinematics configuration

Settings in the configuration editor	MP number
Channels	
Kinematics	
CfgKinModel	
[Key name of the kinematic model]	
<b>axesToolSide</b>	200001
<b>trafoToolSide</b>	200002
<b>trafoDirToolSide</b>	200003
<b>trafoAngelToolSide</b>	200004
<b>toolCoordSys</b>	200005
<b>axesWpSide</b>	200006
<b>trafoWpSide</b>	200007
<b>trafoDirWpSide</b>	200008
<b>trafoAngleWpSide</b>	200009
<b>machineTableSys</b>	200010

Describe the kinematics models in the parameter object **CfgKinModel/Key name of kinematics model**.

Two transformation sequences are defined based on a **machine base system**  $C_{mb}$ :

- Transformation sequence on the **tool side**
- Transformation sequence on the **workpiece side**

Each axis on the machine is represented by a coordinate system in one of the two sequences.

The **Z axis** for these coordinate systems is always defined as the **direction of movement** (for translation axes) or the **rotary axis** (for rotation axes) (convention for internal kinematics model).

The Z axis of **translation axes** always indicates the positive direction of movement for the tool, and for the workpiece the negative direction of motion of the assigned physical axis. Positive direction of motion means that the REF display increases when the axis moves in this direction. On the other hand, a negative direction of motion means that the REF display decreases when the axis moves in this direction.

This means that, for **rotational axes**, the Z axis of a coordinate system indicates the positive direction of rotation for the tool, and for the workpiece the negative direction of rotation of the assigned physical axis. Positive direction of rotation for rotational axes means that the REF display increases when the axis rotates in this direction. On the other hand, a negative direction of rotation means that the REF display decreases when the axis rotates in this direction.





For machines with mutually perpendicular axes, the following results from this convention:

The machine base coordinate system  $C_{mb}$  must be selected so that its axes are parallel to the physical axes of the machine.

If the algebraic sign of an axis is defined oppositely on the machine, then the coordinate system of the affected axis must be rotated in the transformation so that its Z axis points in the opposite direction.

**Important rule of thumb:**

The position (location and orientation) of a coordinate system is always expressed in the coordinates of the **previous** coordinate system.

Example:

Position of  $C_Y$  in coordinates of  $C_{mb}$

Position of  $C_X$  in coordinates of  $C_Y$

Position of  $C_{mt}$  (machine table) in coordinates of  $C_X$

etc.

The following are defined as well:

- **Tool system** ( $C_{tool}$ ) in **MP\_toolCoordSystem** – in addition to the transformation sequence on the tool side
- **Machine table system** ( $C_{mt}$ ) in **MP\_machineTableSys** – in addition to the transformation sequence on the workpiece side

The transformation sequence can also contain other systems, such as the coordinate system of a 45° rotary axis (for horizontal/vertical spindles).

This system also represents an axis that can have the axis values 0° (vertical position) and 180° (horizontal position). Such an axis is moved to the appropriate position manually, via the PLC or an NC linear block.

Other coordinate systems can be auxiliary systems, which do not represent axes, but are only used to enter the values of the relevant factors in the kinematics chain. These systems are described as DefPoint systems. No axis values can be assigned to these DefPoint systems (as a default, the axis values are always null).


All axes defined in the kinematics chain must be entered in the parameter object **CfgAxes**. The axes with axis values are entered in **CfgAxes/axisList** and those without axis values (DefPoint systems) are entered in **MP\_specCoordSysList**.

**Example:**


Below is a sketch of a simple lathe with the linear axes X and Z and a C axis. Starting from the machine bed, the X axis is on the Z axis on the tool side.

The coordinate system of the machine bed is determined by the position of the main spindle and the arrangement of the tool carrier (here: "behind workpiece".) As the kinematics chains is evaluated three-dimensionally, an (imaginary) Y axis on the X axis is taken into account.

For the transformation sequence on the workpiece side, only the "machine table" must be taken into account. For kinematics with a C axis, the "machine table" and the C axis must be taken into account.



The kinematics chain for the example machine illustrated is as follows:











#### Note

For purposes of clarity, the origins of the coordinate systems are drawn distinct from each other even when they are at the same location.

As the origin of both kinematics chains is the machine base, it is not necessary to describe the coordinate system of the machine base.

In the machine configuration of the control, the kinematics chain shown above is described with vectors.

The following pages will inform you of all machine parameters necessary for this. In the following table you can see how the kinematics configuration of the example machine is represented in the machine configuration: Usually the axis directions but not the dimensions are specified in the kinematics model.

Kinematics configuration of a lathe with the axes X, Z and a C axis							
<b>Machine base</b>					Coordinate system		
$C_{mb}$ : Coordinate system of the machine base							
<b>Transformation sequence on the tool side</b>							
$C_z$ : Kinematics Z axis	location		zDir		xDir		Coordinate system 
	[0]	0	[0]	0	[0]	1	
	[1]	0	[1]	0	[1]	0	
	[2]	0	[2]	1	[2]	0	
$C_x$ : Kinematics X axis	location		zDir		xDir		Coordinate system 
	[0]	0	[0]	1	[0]	0	
	[1]	0	[1]	0	[1]	1	
	[2]	0	[2]	0	[2]	0	
$C_y$ : Kinematics Y axis	location		zDir		xDir		Coordinate system 
	[0]	0	[0]	1	[0]	0	
	[1]	0	[1]	0	[1]	1	
	[2]	0	[2]	0	[2]	0	
$C_{tool}$ : Kinematics of tool system	location		zDir		xDir		Coordinate system 
	[0]	0	[0]	1	[0]	0	
	[1]	0	[1]	0	[1]	1	
	[2]	0	[2]	0	[2]	0	
<b>Transformation sequence on the workpiece side for kinematics with a C axis</b>							
$C_c$ : Kinematics C axis	location		zDir		xDir		Coordinate system 
	[0]	0	[0]	0	[0]	1	
	[1]	0	[1]	0	[1]	0	
	[2]	0	[2]	1	[2]	0	
$C_{mt}$ : Kinematics of machine table	location		zDir		xDir		Coordinate system 
	[0]	0	[0]	0	[0]	0	
	[1]	0	[1]	1	[1]	0	
	[2]	0	[2]	0	[2]	1	
<b>Transformation sequence on the workpiece side for kinematics without a C axis</b>							
$C_{mt}$ : Kinematics of machine table	location		zDir		xDir		Coordinate system 
	[0]	0	[0]	0	[0]	0	
	[1]	0	[1]	1	[1]	0	
	[2]	0	[2]	0	[2]	1	

## Transformations on the tool side

The machine kinematics, i.e. the coordinate transformations, are described in the following parameters.

The key names of all axes on the tool side are entered in **MP\_axesToolSide**. The sequence of the entries reflects the physical arrangement of the axes. Enter the axis on which the other axes are based at position [0].

The control assumes a three-dimensional kinematics model. If the NC channel does not have all of the three principal axes, replace the missing principal axes by dummy axes.

### MP\_axesToolSide

Key names of the axes on the tool side

Available from NCK software version: 597 110-01.

Format: Array [0...9]

Input: Key names from CfgAxes/axisList (for dummy axes from CfgAxes/specCoordSysList)

Default: -

Access: LEVEL3

Reaction: RESET

Enter the key names of the coordinate transformations on the tool side in **MP\_trafoToolSide**. The sequence must correspond to the axes entered in **MP\_axesToolSide**.

### MP\_trafoToolSide

Coordinate transformations on the tool side

Available from NCK software version: 597 110-01.

Format: Array [0...9]

Input: Key names for coordinate transformations

Default: -

Access: LEVEL3

Reaction: RESET

Key names of the coordinate transformations defined by direction vectors are entered in **MP\_trafoDirToolSide**. They must also be entered in **MP\_trafoToolSide**, but cannot appear in **MP\_trafoAngleToolSide**.

### MP\_trafoDirToolSide

Coordinate transformation defined by direction vectors

Available from NCK software version: 597 110-01.

Format: Array [0...9]

Input: Key names for coordinate transformations

Default: -

Access: LEVEL3

Reaction: RESET

Key names of transformations defined by angles are entered in **MP\_trafoAngleToolSide**. They must also be entered in **MP\_trafoToolSide**, but cannot appear in **MP\_trafoDirToolSide**.

### **MP\_trafoAngleToolSide**

Coordinate transformations defined by angle

Available from NCK software version: 597 110-01.

Format: Array [0...9]

Input: Key names for coordinate transformations

Default: –

Access: LEVEL3

Reaction: RESET

**MP\_toolCoordSys** is the end of the kinematics chain on the tool side.

### **MP\_toolCoordSys**

Key name of the tool coordinate system

Available from NCK software version: 597 110-01.

Format: String

Input: Max. 18 characters

Default: –

Access: LEVEL3

Reaction: RESET



## Transformations on the workpiece side

The key names of all axes on the workpiece side are entered in **MP\_axesWpSide**. The sequence of the entries reflects the physical arrangement of the axes. Enter the axis on which the other axes are based at position [0].

### MP\_axesWpSide

Key names of the axes on the workpiece side  
Available from NCK software version: 597 110-01.

Format: Array [0...9]  
Input: Key names from CfgAxes/axisList (for dummy axes from CfgAxes/specCoordSysList)  
Default: –  
Access: LEVEL3  
Reaction: RESET

Enter the key names of the coordinate transformations on the workpiece side in **MP\_trafoWpSide**. The sequence must correspond to the axes entered in **MP\_axesWpSide**.

### MP\_trafoWpSide

Coordinate transformations on the workpiece side  
Available from NCK software version: 597 110-01.

Format: Array [0...9]  
Input: Key names for coordinate transformations  
Default: –  
Access: LEVEL3  
Reaction: RESET

Key names of the coordinate transformations defined by direction vectors are entered in **MP\_trafoDirWpSide**. They must also be entered in **MP\_trafoWpSide**, but cannot appear in **MP\_trafoAngleWpSide**.

### MP\_trafoDirWpSide

Coordinate transformation defined by direction vectors  
Available from NCK software version: 597 110-01.

Format: Array [0...9]  
Input: Key names for coordinate transformations  
Default: –  
Access: LEVEL3  
Reaction: RESET

Key names of transformations defined by angles are entered in **MP\_trafoAngleWpSide**. They must also be entered in **MP\_trafoWpSide**, but cannot appear in **MP\_trafoDirWpSide**.

### MP\_trafoAngleWpSide

Coordinate transformations defined by angle  
Available from NCK software version: 597 110-01.

Format: Array [0...9]  
Input: Key names for coordinate transformations  
Default: –  
Access: LEVEL3  
Reaction: RESET

**MP\_machineTableSys** is the end of the kinematics chain on the workpiece side.

**MP\_machineTableSys**

Key name of the machine-table coordinate system  
 Available from NCK software version: 597 110-01.  
 Format: String  
 Input: Max. 18 characters  
 Default: –  
 Access: LEVEL3  
 Reaction: RESET

Each coordinate transformation on the workpiece or tool side is defined with direction vectors or angles.

**Spindle of the kinematic model**

Settings in the configuration editor	MP number
Channels Kinematics CfgKinModel [Key name of the kinematic model] <b>activeSpindle</b>	200011

In **MP\_activeSpindle** you specify the spindle used in the kinematic model. This assignment is required for different calculations (for example: calculate feed per revolution, determine tool life, etc.)

**MP\_activeSpindle**

Key name of the active spindle of this kinematics model  
 Available from NCK software version: 597 110-01.  
 Format: String  
 Input: The key name of the spindle is read from CfgAxes/spindleIndices, e.g. "S", "Spindle1", etc.  
 Default: –  
 Access: LEVEL3  
 Reaction: RUN





## Activating the kinematics model

Settings in the configuration editor	MP number
Channels ChannelSettings [Key name of the machining channel] CfgActivateKinem <b>kinemToActivate</b>	204001

In **MP\_kinemToActivate**, enter the key name of the kinematics model to be activated for this machining channel. The key name of this model must be contained in **MP\_kinModels** in the list of the kinematics models available for this machining channel.

### **MP\_kinemToActivate**

Key name of the kinematics model to be activated  
Available from NCK software version: 597 110-01.

Format: String

Input: For the key name, please refer to CfgChannelAxes/kinModels, e.g. "K2\_CH1\_S12", etc.

Default: -

Access: LEVEL3

Reaction: RUN

## 6.12.2 Definition of the transformation with vectors

Settings in the configuration editor	MP number
Channels	
Kinematics	
CfgTrafoByDir	
[Key name of the transformation]	
<b>location</b>	200101
<b>zDir</b>	200102
<b>xDir</b>	200103
CfgTrafoByAngle	
[Key name of the transformation]	
<b>location</b>	200201
<b>angleDef</b>	200202
<b>angle1</b>	200203
<b>angle2</b>	200204
<b>angle3</b>	200205

A coordinate transformation is defined by the description of the position of a coordinate system in the previous coordinate system. This type of position is described by a position vector (**MP\_location**) and an orientation. The two principle possibilities for describing the orientation are described below:

### Definition of the transformation with direction vectors

**MP\_location** defines the position of the coordinate origin of the transformed system relative to the previous coordinate system.

#### MP\_location

Origin of this coordinate system in the previous system  
Available from NCK software version: 597 110-01.

Format: Array [0...2]

Input: -100 000.00000 to +100 000.00000 [mm]

Default: -

Access: LEVEL3

Reaction: RESET

In **MP\_zDir** you define the Z direction of the current coordinate system using the previous coordinate system. For more information about the position of the vector **MP\_zDir**, see "Overview of machine parameters for the kinematics configuration" on page 748.

### **MP\_zDir**

Z-base vector expressed in the previous coordinate system  
Available from NCK software version: 597 110-01.

Format: Array [0...2]

Input: -1 to +1

Enter the Z-basis vector of the transformed coordinate system relative to the previous coordinate system

Note:

Translation axes move in this direction and rotation axes rotate around this vector.

Default: -

Access: LEVEL3

Reaction: RESET

In **MP\_xDir** you define the X direction of the current coordinate system using the previous coordinate system. For more information about the position of the vector **MP\_xDir**, see "Overview of machine parameters for the kinematics configuration" on page 748.

### **MP\_xDir**

X-base vector expressed in the previous coordinate system  
Available from NCK software version: 597 110-01.

Format: Array [0...2]

Input: -1 to +1

Enter the X-basis vector of the transformed coordinate system relative to the previous coordinate system.

Default: -

Access: LEVEL3

Reaction: RESET

## Definition of the transformation with angles

**MP\_location** defines the position of the coordinate origin of the transformed system relative to the previous coordinate system.

### MP\_location

Origin of this coordinate system in the previous system  
Available from NCK software version: 597 110-01.

Format: Array [0...2]  
Input: -100 000.00000 to +100 000.00000 [mm]  
Default: –  
Access: LEVEL3  
Reaction: RESET

**MP\_angleDef** specifies the interpretation of the angles.

### MP\_angleDef

Specifies the interpretation of the angles  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: **Cardan**  
Orientation by Cardan angles  
**RollPitchYaw**  
Orientation by rotation around fixed axes  
**Euler**  
Orientation by Eulerian angles  
Default: Cardan  
Access: LEVEL3  
Reaction: RESET

### MP\_angle1

Angle 1 – Meaning as per parameter MP\_angleDef  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: –360.000 to +360.000 [°]  
Default: 0  
Access: LEVEL3  
Reaction: RESET

### MP\_angle2

Angle 2 – Meaning as per parameter MP\_angleDef  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: –360.000 to +360.000 [°]  
Default: 0  
Access: LEVEL3  
Reaction: RESET

### MP\_angle3

Angle 3 – Meaning as per parameter MP\_angleDef  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: –360.000 to +360.000 [°]  
Default: 0  
Access: LEVEL3  
Reaction: RESET

### 6.12.3 Axis mirroring for lathes

Settings in the configuration editor	MP number
Aggregates	
ToolMount	
[Key name of the tool holder]	
CfgToolMount	
<b>coorTrafoToModify</b>	600414
<b>coorTrafo</b>	600415
<b>mirroringAxes</b>	600416

Axis mirroring on lathes is required, for example, when carrying out machining operations above or below the turning center or on the rear side. Such axis mirroring is done within a kinematics group; there is no kinematics change.

Axis mirroring is activated/deactivated either via NC commands or by assigning the activation/deactivation to a tool holder.

With the tool holder (parameter object **CfgToolMount**), you can control axis mirroring with the following parameters:

- **MP\_coorTrafoToModify**: Kinematics of the axis/axes to be mirrored
- **MP\_coorTrafo**: Kinematics of the mirrored axis/axes

Axis mirroring that is configured with the tool holder will be activated when the tool holder is inserted. Axis mirroring will remain active until the next tool change.

#### **MP\_coorTrafoToModify**

Coordinate transformations to be modified  
 Available from NCK software version: 597 110-05.  
 Format: Array [0...100]  
 Input: Enter here the key names of the coordinate transformations to be modified.  
 Default: No value, parameter optional  
 Access: LEVEL3  
 Reaction: RESET

#### **MP\_coorTrafo**


Modified coordinate transformations  
 Available from NCK software version: 597 110-05.  
 Format: Array [0...100]  
 Input: Enter here the key names of the modified coordinate transformations.  
 Default: No value, parameter optional  
 Access: LEVEL3  
 Reaction: RESET



## 6.13 Parallel Axes

Settings in the configuration editor	MP number
Axes PhysicalAxis [Key name of the axis] CfgAxisPropKin <b>parAxComp</b>	300205

In addition to the principal axes X, Y and Z you can define the parallel secondary axes U, V and W.



Principal axis	Parallel axis	Rotary axis
X	U	A
Y	V	B
Z	W	C

The MANUALplus 620 supports various methods for treating movements of parallel axes.



### Note

Software option 94 "Parallel axis" is required to be able to use the display function or the compensation of parallel secondary axes.

In parameter **MP\_parAxComp** you define the default setting for the treatment of parallel axes. The machine operator can overwrite this setting in the NC program. After startup, however, the given default configuration always becomes effective.

Possible settings:

■ **MP\_parAxComp = off:**

Compensation and display function is deactivated for parallel axes.

Example: If a secondary (parallel) axis W is moved, the Z axis does not compensate the movement. The position display does not show the value of the W axis. HEIDENHAIN recommends that you avoid using this setting for machines with parallel axes.

■ **MP\_parAxComp = Display:**

Display function for parallel axes is active.

Example: Movements of a secondary (parallel) axis W are added in the position display to the corresponding principal axis (in this case Z) (sum display). The position display therefore always shows the relative distance from the tool to the workpiece—regardless of whether the principal or secondary axis is moved.

■ **MP\_parAxComp = Move**

Compensation for parallel axes is active. The MANUALplus 620 compensates the movement of parallel axes through compensating movements in the corresponding principle axis.

For example, if a parallel-axis movement is performed in the negative W-axis direction, the principal axis Z is moved simultaneously in the positive direction by the same value. The relative distance from the tool to the workpiece therefore remains the same.

Application in gantry-type milling machine: Retract the spindle sleeve to move the cross beam down simultaneously.

### **MP\_parAxComp**

Compensation of parallel linear axes

Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **Off**

Compensation and display function is deactivated for parallel axes.

**Display**

Display function for parallel secondary axes is active.

**Move**

Compensation for parallel axes is active.

Default: No value, parameter optional (= off)

Access: LEVEL3

Reaction: RESET

## 6.14 Synchronized Axes (Option 24)

### Conventions

For synchronized axes:

- Master and slave axes can be either linear or rotary axes.
- The axes must be either both analog or both digital.
- An axis cannot be both master and slave at the same time.
- More than one slave axes can be assigned to a master axis.
- The slave axis cannot be moved separately.
- After the MANUALplus 620 starts up, only one static coupling of axes can be automatically active. During run time, dynamic couplings can be activated only over the PLC.
- The PLC program must ensure that the master axis does not move until the slave axis is ready (clamping, feed-rate enable).
- If the master and slave axes are to be moved without a feed-rate enable, the IN\_POSITION bit is set to zero. This requests a feed-rate enable from the PLC.
- The values for rapid traverse, acceleration, jerk, software limit switches, feed rate for reference mark traverse, and manual feed rate are also taken over from the input values of the master axis for the slave axis.
- The minimal values of the software limit switches of master and slave axes are taken into account.
- It is possible to open or close each configured coupling of axes separately.
- When operating with following error, the  $k_v$  factors for master and slave must be the same.
- For gantry axes, one position encoder is sufficient.
- Linear and nonlinear axis error compensation as well as temperature compensation must be entered separately for each axis.
- The nonlinear axis-error compensation can be used separately for master and slave axes.
- For the nonlinear axis-error compensation, master and slave axes may be dependent on each other.
- The nominal value display of the slave axis shows the nominal value of the master axis.
- The nominal position of the slave axis is calculated from the nominal position of the master. The actual position of the master has no influence on the nominal position of the slave.
- If a coupled axis is stopped because of an error message, all other axes coupled with this axis are also brought to a stop.



#### Note

The number of slave axes in master-slave torque control and gantry combinations is restricted by the controller unit on which the master axis is configured. The slave axes and the master axis must be configured on the same drive-control motherboard (DSPs). Thus, up to five slave axes are possible per CC 61xx.



## 6.14.1 Gantry axes

In gantry axes, tandem tables, etc., two servo-controlled axes are coupled so that they can move only simultaneously. The main axis is referred to as the master, and the tracking axis as the slave.

Because a gantry coupling is configured exclusively over the slave axis, it is possible to assign more than one slave to the same master. However, a gantry slave axis cannot at the same time serve as a gantry master axis.

The function is effective during control both with following error and with velocity feedforward and can be used for digital and analog drive control.

### Activating gantry axes

In principle you can couple axes with each other statically without intervention by the PLC in the startup phase or dynamically with Module 9126 during program run. In both cases, however, it is necessary to configure the axis coupling beforehand in the machine parameters.

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgAxisCoupling	
<b>masterAxis</b>	402301
<b>mode</b>	402302
<b>type</b>	402303
<b>typeOfOffset</b>	402304
<b>posOffset</b>	402305
<b>offsetFeed</b>	402306
<b>maxPosDiff</b>	402307
<b>ultimatePosDiff</b>	402308
<b>scalingFactor</b>	402309
<b>accFilterTime</b>	402315

### Static activation of gantry axes

To activate a static axis position coupling, i.e. during startup of the MANUALplus 620 and without action by the PLC, proceed as follows:

- ▶ Assign a master axis to the slave axis. In **MP\_masterAxis**, enter the key name of the master axis from the list parameter **MP\_axisList** of the entity CfgAxes.



#### Note

The master and slave axes must be on the same drive-control main board, which means that both axes need to be controlled by the same DSP. In this way, you can flexibly assign the master and slave axes to the PWM outputs X51 to X56 of a CC 6106. On controller units with more than one drive control board (CC 6108, CC 6110), the master axis and the slave axis both need to be assigned to either the A connections or the B connections. Mixed connection is not permitted.

- ▶ In **MP\_mode**, define the type of coupling. Select a **position** for the position coupling.
- ▶ To keep a static coupling of the axes, enter in **MP\_type** the value **Static**. Both static and dynamic axis couplings can be closed and reopened at any time by the PLC with Module 9126.
- ▶ With **MP\_typeOfOffset** you configure the treatment of the position offset between the master and slave axes. The input values **None** and **Actual** cause the position offset at the time of coupling closing to remain as a static offset. In this case there is no compensating movement on stationary axes. Select **Parameter**, in order to transfer the value from **MP\_posOffset** as an absolute position offset. When the coupling is closed, a compensating movement is made immediately and the feed rate is enabled for the slave. The slave position is then calculated:

$$\text{SlavePos} = \text{MasterPos} * \text{scalingFactor} - \text{posOffset}$$

- ▶ If in **MP\_typeOfOffset** you have selected the input value **Parameter**, enter in **MP\_posOffset** the position offset that is moved to and held. After the reference run, this value is used as absolute position offset.
- ▶ In **MP\_offsetFeed** specify the speed at which the configured offset is to be attained.
- ▶ With closed coupling, except when moving to an offset, the difference between the actual positions of master and slave axes is monitored. In **MP\_maxPosDiff**, enter the value of the permissible position difference with closed coupling between the master and slave axes. If this difference exceeds the value entered here, the MANUALplus 620 issues a clearable emergency stop error message (monitoring only when **MP\_scalingFactor**= ±1 active).  
The position of the master is converted with the following factors for the comparison:

$$\text{ActlPosMaster} = \text{actual position of the master} * \text{scalingFactor} - \text{posOffset}$$

- ▶ In **MP\_ultimatePosDiff** enter a maximum position difference value up to which it will remain possible to close a coupling of master and slave. If you try to close a coupling in which the current position difference between master and slave axis is greater than this parameter value, an emergency stop message appears before the coupling is closed. This serves to monitor a mechanical coupling.  
Also if the coupling is closed, a non-clearable emergency stop error message appears if the position difference between master and slave exceed the value from **MP\_ultimatePosDiff**.  
The monitoring can be canceled by entering zero.



- ▶ With **MP\_scalingFactor** you can influence the target position of the slave axis depending on the master position. Enter any positive or negative value (on modulo axes only  $\pm 1$  is possible) in **MP\_scalingFactor** in order to specify the position of the slave axis according to the following equation:

$$\text{SlavePos} = \text{MasterPos} * \text{scalingFactor} - \text{posOffset}$$

The PLC can overwrite the factor when commanded. With a closed coupling this parameter can no longer be changed.



#### Note

The above equation always applies with respect to the reference system of both axes. Programmable shifts (e.g. preset) are not taken into account. However, the coupling is also influenced by shifting the reference point.

- ▶ If a coupling is closed while the master is moving, the slave axis is first accelerated to the velocity of the master at the slave axis's maximum possible acceleration from **MP\_maxAcceleration**. This is conducted by means of a linear, filtered ramp. In **MP\_accFilterTime** enter the time constant of the triangle filter used that helps to smooth the velocity values. Useful input values range from 30 ms to 100 ms.



#### Note

Several parameter sets can be used to define various couplings for a slave. When a coupling is closed, the data of the currently active parameter set are copied and kept for the duration of the coupling. When a parameter set is switched, it does not go into effect until the coupling is opened and closed again.

## Dynamic activation by the PLC

With Module 9126 you can couple axes dynamically, i.e. during program run. In this case, however, it is also necessary to configure the axis coupling beforehand in the machine parameters.

- ▶ Configure the axis coupling in the machine parameters with the exception of **MP\_type** as described in the previous section on the static activation of gantry axes.
- ▶ In **MP\_type**, enter the value **Dynamic** to make it possible to dynamically couple the axes.
- ▶ Close the coupling of a slave axis with a master axis by calling Module 9126.
- ▶ With Module 9126 you can also overwrite the values configured in **MP\_scalingFactor** and **MP\_posOffset** for the coupling factor and position offset.

The same process always occurs when the coupling closes and the feed rate enabling is given for the slave axis.

- The slave axis accelerates to the velocity of the master axis at the acceleration specified in **MP\_maxAcceleration**. During this, the slave axis evaluates its own software limit switches. If the position of the master axis cannot be reached, the MANUALplus 620 issues an emergency stop error message.
- If the velocity of the master axis is reached, the position offset is reached by the programmed or configured nominal offset at half the maximum acceleration. Here an acceleration or deceleration of the master axis is allowed.
- If the programmed offset is reached, the slave nominal position is calculated cyclically (see **MP\_scalingFactor**).

To prevent an immediate realization of any existing position offset, the PLC can revoke the axis release for the slave axis.



### Warning

Also when a coupling is closed, the feed rate enabling is effective for the slave. If the enabling is revoked for the slave during movement of the master and slave, the slave brakes at the configured acceleration (**MP\_maxAcceleration**) and stops. If enabled again, the slave accelerates to the velocity of the master and then compensates the position offset.

If a coupling is closed with **SYNC\_CALC** (interpreter stop) within a strobe, the geometry and the look-ahead are automatically informed about this coupling. You modify the software limit switch monitoring and the permissible dynamics under consideration of all axes involved in the gantry coupling. This ensures that the traverse range cannot be exceeded by any coupled axis.

However, if a coupling is closed without **SYNC\_CALC**, ensure that the slave axis has at least the same acceleration capability as the master axis. Software limit switch monitoring is then performed for the movements commanded by the PLC in the interpolator and under consideration of the master and slave. For movements commanded by the NC program, only the masters' software limit switch is monitored.

If you open an existing coupling without **SYNC\_CALC** while the master axis is in motion, the slave axis will be braked to a stop at the maximum possible axis deceleration from **MP\_maxAcceleration**.



## Opening a coupling of gantry axes

With Module 9126 you can also reopen axis couplings already existing. If an axis coupling is commanded open by the PLC with Module 9126, the following actions are taken:

- The coupling is opened
- The slave axis is braked to a stop at the velocity configured in `MP_maxAcceleration`
- The status bits of the slave axis are reset
- If the last slave axis of a master axis is decoupled, the status bits of the master axis are also reset

## Master-slave position deviation

The MANUALplus 620 monitors the synchronism of the coupled axes. If the position difference of the master and slave axes exceeds the maximum permissible value, the MANUALplus 620 issues an emergency stop error message.

- ▶ In **MP\_maxPosDifference** of the slave axis, enter the maximum permissible difference in positions between the master and slave.

If an offset is caused in the axes through an emergency stop, they will be synchronized after the emergency stop.

The current position difference between master and slave axis can be displayed in the oscilloscope by means of new channels for all axes.

## Homing of gantry axes

For gantry axes, the master axis must always be homed first when the MANUALplus 620 starts up. Then, all coupled slave axes are automatically homed. You configure the procedure for homing separately for all axes in **MP\_refType**. This makes it possible on gantry axes to use different encoder types for the master and slave.

Not until all coupled axes have been homed and come to a stop can the position control loop be closed.

### MP\_masterAxis

Assign a master axis to the slave axis.

Available from NCK software version: 597 110-04.

Format: Selection menu  
Selection: Key name of the master axis  
Default: 0  
Access: LEVEL3  
Reaction: RUN

### **MP\_mode**

Mode of the coupling  
Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **None**  
Axis has no coupling

**Position**  
Axis coupled via gantry (position coupling)

**Torque**  
Torque coupling

Default: None

Access: LEVEL3

Reaction: RUN

### **MP\_type**

Type of coupling  
Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **Static**  
Static coupling – is automatically closed in the start-up phase without PLC involvement.

**Dynamic**  
Dynamic coupling – is closed only by PLC command.

Default: Static

Access: LEVEL3

Reaction: RUN

### MP\_typeOfOffset

The parameter specifies how the position offset between master and slave axis is treated.

Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **None / Actual**

The offset when a coupling is closed is retained as static offset. There is no compensating movement on stationary axes.

#### **Parameter**

After the reference run, the value of the **MP\_posOffset** parameter is taken as the absolute position offset. When the coupling closes, there is an immediate compensating movement.

Default: None

Access: LEVEL3

Reaction: RUN

### MP\_posOffset

Value of the position offset with closed coupling

Available from NCK software version: 597 110-04.

Format: Numerical value

Input: Position offset in millimeters [mm] or degrees [°] that is compensated and maintained if **MP\_typeOfOffset = Parameter** is set

Default: 0

Access: LEVEL3

Reaction: RUN

### MP\_offsetFeed

The velocity with which an offset between the master axis and the slave axis is compensated for

Available from NCK software version: 597 110-04.

Format: Numerical value

Input: Velocity [mm/min] or [°/min]

Default: 999.996 [mm/min]

Access: LEVEL3

Reaction: RUN

### MP\_maxPosDiff

Synchronization monitoring – deletable emergency stop message

Available from NCK software version: 597 110-04.

Format: Numerical value

Input: Permissible offset [mm]

Default: 0

Access: LEVEL3

Reaction: RUN

**MP\_ultimatePosDiff**

Synchronization monitoring – non-deletable emergency stop message

Available from NCK software version: 597 110-04.

Format: Numerical value  
Input: Maximum permissible offset [mm]  
Default: 0  
Access: LEVEL3  
Reaction: RUN

**MP\_scalingFactor**

Scaling factor for calculating the slave position

Available from NCK software version: 597 110-04.

Format: Numerical value  
Input: Any values, even negative values (on modulo axes only  $\pm 1$  is  
can be entered)  
Default: 1  
Access: LEVEL3  
Reaction: RUN

**MP\_accFilterTime**

Time constant for filtering the acceleration curve

Available from NCK software version: 597 110-04.

Format: Numerical value  
Input: 0 to 200 [ms]  
Default: 30  
Access: LEVEL3  
Reaction: RUN





## Module 9126 Configure axis coupling

With this module you can close or open the coupling of a PLC axis as slave to another axis.

A dynamic coupling of a master axis must be configured in the parameters. If the coupling is not possible, the MANUALplus 620 will issue an error message.

When the coupling is activated the coupling factor can be specified. The coupling factor is calculated as a fraction of the transferred factors and must be unequal to zero.

With a coupling that is already closed, the coupling factor and the position offset cannot be changed.

Call:

PS B/W/D/K <>Number of the axis>  
PS B/W/D/K <>Numerator of the coupling factor>  
PS B/W/D/K <>Denominator of the coupling factor>  
PS B/W/D/K <>Position offset in 0.0001 mm or 0.0001°>  
PS B/W/D/K <>Mode>  
0: Open the coupling  
1: Close the coupling  
2: Close the position coupling and  
use the transferred coupling factor  
3: Close the position coupling and  
use the transferred position offset  
4: Close the position coupling and  
use the transferred coupling factor and position offset  
5: Close the position coupling and  
keep the position offset at the time of the coupling  
6: Close the position coupling and  
use the transferred coupling factor and  
keep the position offset at the time of the coupling

CM 9126

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Coupling is being opened or closed
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	The given number of the axis is invalid or the axis has been deactivated
	2	The given mode or coupling factor is invalid
	6	The coupling is already opened or closed
	9	Axis is being positioned or is assigned to an NC channel

### Module 9127 Status of the axis coupling

With this module you can interrogate the status of the coupling of an axis with another axis.

Call:

PS B/W/D/K <>Number of the axis>

PS B/W/D/K <>Mode>

0: Interrogate the condition of master / slave

1: Interrogate the type of coupling for the master

2: Interrogate the type of coupling for the slave

3: Interrogate the coupling factor

CM 9127

PL (B/W)/D <>Status>

<Mode 0>: (Bit-encoded. An axis cannot be both master and slave at the same time!)

Bit 0 = 1: Axis is master for coupling

Bit 1 = 1: Axis is slave for coupling

Bit 2 = 1: Coupling is closed (in addition to bit 1)

<Mode 1>: (Bit-encoded. An axis can be master to multiple slaves!)

Bit 0 = 1: Coupling is active through torque control

Bit 1 = 1: Coupling is active through position control

Bit 2 = 1: Coupling is active through spindle synchronization

<Mode 2>: (Bit-encoded)

Bit 0 = 1: Coupling is active through torque control

Bit 1 = 1: Coupling is active through position control

Bit 2 = 1: Coupling is active through spindle synchronization

<Mode 3>

Rounded coupling factor in 0.0001

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Status provided
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	The entered number of the axis is invalid
	2	The entered mode is invalid





### 6.14.2 Master-slave torque control

In master-slave torque control, two motors (master and slave) are mechanically coupled. Because of the coupling, only one position encoder is required. The motor to which the position encoder is assigned is the master.

Axes can be controlled in pairs in the torque-master-slave-control, whereby you must keep in mind that the master and slave axis must be on the same speed controller circuit board.


In principle there are two applications:

- Minimization of mechanical play through mutual tensioning
- Distribution of torque with a rigid coupling



## Method of function

Position control is deactivated in the slave axis. The nominal velocity of the master axis is at the same time the nominal velocity of the slave axis. The speed controllers of both axes remain independent. The manipulated variables coming from the speed controllers, i.e. the nominal torque current values, are weighted with the torque constants of the motors and compared with each other. In addition, a tensioning torque (**MP\_torqueBias**) can be introduced at this comparison point. To permit a distribution of drive torque, the nominal torque of the slave axis can be multiplied with a factor (**MP\_torqueDistrFactor**; not with the CC 61xx). The result at the comparison point is fed to a torque balancing controller that amplifies it proportionally (**MP\_propGain**). The manipulated variable of the balancing controller is a speed compensation value that is added to the current speed value.



## Conventions


The following applies for a master-slave combination:

- For a master-slave combination, no more than one common position encoder is required.
- Linear and nonlinear axis error compensation as well as temperature compensation is not possible for both axis.
- Nonlinear axis-error compensation cannot be entered separately for master and slave axes. Here the values of the master axis are always used.
- When operating with following error, the  $k_v$  factor for the master axis must be used.

## Gantry axes in master-slave torque control

It is possible to run gantry axes in master-slave torque control. The gantry master and gantry slave axes are at the same time torque master axes and have one torque slave axis each.

A gantry axis can also serve as a torque master axis at the same time, but a torque slave axis cannot at the same time be a gantry master axis.



## Activation of master-slave torque control

A torque coupling is supported at present only as a "static coupling." If you have configured a torque-master-slave coupling, it will be automatically activated after the control startup.

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgAxisCoupling	
<b>masterAxis</b>	402301
<b>mode</b>	402302
<b>type</b>	402303
<b>torqueBias</b>	402310
<b>propGain</b>	402311
<b>torqueDistrFactor</b>	402312
<b>speedCorrectRatio</b>	402313
<b>inverseVelocity</b>	402314

- ▶ Assign the appropriate master axis to the slave axis. In **MP\_masterAxis**, enter the key name of the master axis from the list parameter **MP\_axisList** of the entity **CfgAxes**. It must be noted that the master and slave axis must be on the same speed controller circuit board.

- ▶ In **MP\_mode**, define the type of coupling. Select the **Torque** entry for the torque coupling.
- ▶ At present, only a static coupling is possible for the torque coupling. Therefore, in **MP\_type**, enter the value **Static**.
- ▶ Therefore, in **MP\_posEncoderInput**, enter the value **None** for the slave.

Axes for which master-slave torque control is active cannot be switched by the PLC to single-axis operation during operation.

### Setting the master-slave torque control for minimizing mechanical play

- ▶ For the master and slave axes you must select in **MP\_inverseVelocity** the same or the opposite direction of rotation, depending on the application (**MP\_signCorrActualVal** has no effect on the slave).
- ▶ Adjust the current controller for the master and slave axes. see "Commissioning" on page 1072
- ▶ Not on the CC 61xx:  
Enter the following temporary values in the machine parameters for the slave axis:  
**MP\_torqueBias** = approx. 20% to 25% of the rated torque of the motor  
**MP\_propGain** = 3  
**MP\_speedCorrectRatio**: = 0
- ▶ Not on the CC 61xx:  
In **MP\_torqueDistrFactor**, enter the ratio of the mass moment of inertia of the master to the mass moment of inertia of the slave. For identical motors, therefore, the value to be entered is 1.
- ▶ If you use a position encoder, in **MP\_speedCorrectRatio** enter 100 for the slave axis; if you do not use a position encoder, enter the value 0 in **MP\_speedCorrectRatio** (not on the CC 61xx).
- ▶ Enter **MP\_vCtrlIntGain** (I factor of speed controller) = 50 or, if you have one, an empirical value for your motor.
- ▶ Adjust the P and I factor of the speed controller for the master and slave axes at the same time. See see "Commissioning" on page 1072. It is not permissible to commission the master and slave axes separately, since the motors must be tensioned during commissioning.
- ▶ If you do not reach the desired rise time (approx. 10 ms), you can increase the P factor with the aid of a filter. Here the band-rejection filter is preferable to the low-pass filter.
- ▶ To find the center frequency for the band-rejection filter, slowly increase the P factor to the oscillation limit and find the frequency with the integrated oscilloscope.



#### Note

For low-frequency oscillations (< approx. 200 Hz) you should not use a filter, because it may have a negative influence on the dynamics of the control. For the mid-range frequency (approx. 200 Hz to approx. 400 Hz) ensure that you do not excite any low-frequency oscillation. The higher the frequency of the oscillation (> approx. 400 Hz), the less negative will be the influence of high damping on the dynamics.




#### Note

For identical motors, the factors of the speed controller should be identical to ensure identical dynamic behavior.

Test the tensioning torque:

- ▶ With the integrated oscilloscope, record the nominal current ( $I_{\text{nominal}}$ ) of the master and the slave axes at standstill.
- ▶ Send a step to the speed controller and, with the integral oscilloscope, record the nominal current of the master and slave axes.
- ▶ If there is a discontinuity in the course of the nominal current, increase the tensioning torque for the slave axis in **MP\_torqueBias**.



#### Note

The lower the ratio of the total mass moment of inertia (transmission, machine table, etc.) to the motor mass moment of inertia, the smaller the required tensioning torque is (**MP\_torqueBias**).

## Setting the master-slave torque control for torque distribution in a rigid design

Test the P factor of the torque controller:

- ▶ With the integrated oscilloscope, record the actual speed value V (N ACTL)
- ▶ Increase the P factor in **MP\_propGain** for the slave axis up to the oscillation limit
- ▶ Enter in **MP\_propGain** for the slave axis 50% of the resulting value.
- ▶ For the master and slave axes you must select in **MP\_inverseVelocity** the same or the opposite direction of rotation, depending on the application (**MP\_signCorrActualVal** has no effect on the slave).
- ▶ Adjust the current controller for the master and slave axes. See see "Commissioning" on page 1072.
- ▶ Enter the following temporary values in the machine parameters for the slave axis:  
**MP\_torqueBias** = 0  
**MP\_propGain** = 3  
**MP\_speedCorrectRatio** = 0 (not on the CC 61xx)
- ▶ Not on the CC 61xx:  
In **MP\_torqueDistrFactor**, enter the ratio of the mass moment of inertia of the master to the mass moment of inertia of the slave. For identical motors, therefore, the value to be entered is 1.
- ▶ Not on the CC 61xx:  
If you use a position encoder, enter 100 for the slave axis in **MP\_speedCorrectRatio**; if you do not use a position encoder, enter the value 0 in **MP\_speedCorrectRatio**



### Note

The parameters **MP\_torqueDistrFactor** and **MP\_speedCorrectRatio** are not evaluated if the CC 61xx and UEC 11x are used!

With the CC 61xx and UEC 11x, the shaft speed compensation value is divided evenly between the master and slave axis.

- ▶ Enter **MP\_vCtrlIntGain** (I factor of speed controller) = 50 or, if you have one, an empirical value for your motor.
- ▶ Deactivate the slave axis in **MP\_axisMode**
- ▶ For the master axis, adjust the P and I factor of the speed controller. See see "Commissioning" on page 1072.
- ▶ If you do not reach the desired rise time (approx. 10 ms), you can increase the P factor with the aid of a filter. Here the band-rejection filter is preferable to the low-pass filter.
- ▶ To find the center frequency for the band-rejection filter, slowly increase the P factor to the oscillation limit and find the frequency with the integrated oscilloscope







#### Note

For low-frequency oscillations (< approx. 200 Hz) you should not use a filter, because it may have a negative influence on the dynamics of the control. For the mid-range frequency (approx. 200 Hz to approx. 400 Hz) ensure that you do not excite any low-frequency oscillation. The higher the frequency of the oscillation (> approx. 400 Hz), the less negative will be the influence of high damping on the dynamics.

- ▶ Deactivate the master axis in **MP\_axisMode**
- ▶ In **MP\_masterAxis** enter the value 0 and for **MP\_mode**, select the entry **None**
- ▶ Set the speed controller and the filter parameters for the slave axis in the same manner as for the master axis, see "Commissioning" on page 1072.



#### Note

For identical motors, the factors of the speed controller should be identical to ensure identical dynamic behavior.

Test the P factor of the torque controller:

- ▶ In **MP\_axisMode** reactivate the master and slave axes
- ▶ With the integrated oscilloscope, record the actual speed value V (N ACTL)
- ▶ Increase the P factor in **MP\_propGain** for the slave axis up to the oscillation limit
- ▶ Enter in **MP\_propGain** for the slave axis 50% of the resulting value.

### **MP\_torqueBias**

Tensioning torque between master and slave for master-slave torque control (entry for the slave axis)  
Available from NCK software version: 597 110-04.

Format: Numerical value  
Input: -1 000.00 to +1 000.00 [Nm]  
Default: 0  
Access: LEVEL3  
Reaction: RUN

### **MP\_propGain**

P factor of the torque controller for master-slave torque control (entry for the slave axis)  
Available from NCK software version: 597 110-04.

Format: Numerical value  
Input: 0 to 1666.666666667 [1/(Nm · min)]  
Default: 0  
Access: LEVEL3  
Reaction: RUN

### **MP\_torqueDistrFactor**

Factor for variable torque distribution for master-slave torque control (entry for the slave axis)  
Available from NCK software version: 597 110-04.

Format: Numerical value  
Input: 0 to 100.000000000  
1: Master and slave axes have identical motors  
Do not assign on CC 61xx – no evaluation.  
Default: 1  
Access: LEVEL3  
Reaction: RUN



### MP\_speedCorrectRatio

Speed compensation ratio for master-slave torque control (entry for the slave axis)

Available from NCK software version: 597 110-04.

Format: Numerical value

Input: -100.000000000 to +100.000000000 [%]

Do not assign on CC 61xx – no evaluation.

Default: 1

Access: LEVEL3

Reaction: RUN



#### Note

The parameters **MP\_torqueDistrFactor** and **MP\_speedCorrectRatio** are not evaluated if the CC 61xx and UEC 11x are used!

With the CC 61xx and UEC 11x, the shaft speed compensation value is automatically divided evenly between the master and slave axis.

### MP\_inverseVelocity

Reversal of the algebraic sign of the nominal speed value

Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **FALSE**

Algebraic sign reversal inactive

**TRUE**

Algebraic sign reversal active

Default: FALSE

Access: LEVEL3

Reaction: RUN

### 6.14.3 Brake test for synchronized axes

As a prerequisite for the brake test of a synchronized axis, all servo drives of the axis must be switched on and the brakes must be open. The test can only be performed if all relevant servo drives are switched on.



#### Note

Before performing the brake test, ensure via the PLC program that all servo drives of a synchronized axis are switched on and the holding brakes are open.

The brake test is activated ( $> 0$ ) or deactivated ( $= 0$  or parameter deleted) separately for each servo drive via **MP\_testBrakeCurrent**.

An additional test torque is applied to the servo drive during the brake test. You define this test torque via a multiplier for the motor stall current with **MP\_testBrakeCurrent**, see "Automatic test of the motor brake" on page 985. This test torque exerts additional load on the holding brake of the servo drive. The axis is prevented from moving during the brake test and the brake test is considered to have been passed only if the brake withstands this load.

#### HEIDENHAIN recommends:



#### Note

- Note the constraints for the brake test of synchronized axes and adapt your PLC program to the conditions.
- Test the behavior of the PLC program and the brake test on the machine.

The MANUALplus 620 runs the brake test for synchronized axes as follows:

#### Behavior during the brake test of synchronized axes:

The function reads the machine configuration to detect which servo drives are operated together as a synchronized axis and which must therefore be handled separately in the brake test. **CfgAxisCoupling** is used to configure servo drives to a synchronized axis. The brakes and drives of the synchronized axis are tested simultaneously. It is ensured, however, that the same algebraic sign is used for the test torque of all drives.

The sign is determined for all servo drives of the synchronized axis based on the entry for the holding torque of the master in **MP\_compCurrentOffset** (401405). If no value is entered in **MP\_compCurrentOffset**, the current holding torque of the master is used.



There are two possibilities for starting the brake test. In both cases the function described above is used to test the brakes of synchronized axes simultaneously:

■ **Automatic brake test:**

The brake test takes place automatically during the power-up test of the control, as soon as all servo drives of the respective synchronized axis have been switched on.

■ **Brake test via PLC module:**

The brake test can be activated axis-specifically by the PLC program with PLC module 9143. The slave drives of a synchronized axis are tested simultaneously with the master. As a prerequisite for the brake test of a synchronized axis, all servo drives of the axis must be switched on and the brakes must be open.

**Alternative behavior:**

**Testing the brakes of a synchronized axis successively**

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisCoupling <b>autoBrakeTest</b>	402316

Additionally, you can activate a changed brake test sequence with **MP\_autoBrakeTest**. The setting **MP\_autoBrakeTest = with Master** causes the brake test to be performed together with the master axis. If **MP\_autoBrakeTest = off**, the servo drives of a synchronized axis are tested successively rather than simultaneously. As a result, the brake test is performed individually for all servo drives of a synchronized axis.

All brakes and servo drives of the synchronized axis are tested successively, one after the other, at the specified test current. For the brakes and servo drives that are not part of the momentary test, but are configured as connected to the servo drive to be tested, the current is set during the test so that the servo drive is not moved. The brakes of these servo drives must be open for this purpose. This way, each time only the brake of an individual servo drive is tested, without the other servo drives or brakes of the synchronized axis having an effect on the test.

To be able to use this brake test sequence, the individual brakes of the synchronized axis must not be combined. It must be possible to control the brakes individually.



There are also two possibilities for starting the brake test. In both cases the function described above is used to test the brakes of synchronized axes sequentially:

■ **Automatic brake test:**

The brake test takes place automatically during the power-up test of the control, as soon as all servo drives of the respective synchronized axis have been switched on. Depending on the setting in **MP\_autoBrakeTest**, the brakes of the slave drives are tested either sequentially or together with the master.

■ **Brake test via PLC module:**

The brake test can be activated axis-specifically by the PLC program with PLC module 9143. Depending on the setting in **MP\_autoBrakeTest**, the brakes of the slave drives are tested either sequentially or together with the master. As a prerequisite for the brake test of a synchronized axis, all servo drives of the axis must be switched on and the brakes must be open.

**MP\_autoBrakeTest**

Motor brake test for synchronized axes.  
Available from NCK software version: 597 110-05.

Format: Selection menu

Selection: **off**

The brake is tested separately for this axis.

**with Master**

The brake for this axis is tested at the same time as the master axis.

Default: off

Access: LEVEL3

Reaction: RUN



### Constraints for the brake test:

As a prerequisite for the brake test of a synchronized axis, all servo drives of the axis must be switched on and the brakes must be open. The test can only be performed if all relevant servo drives are switched on.



#### Note

Before performing the brake test, ensure via the PLC program that all servo drives of a synchronized axis are switched on and the holding brakes are open.

For slave drives for which the brake test has been disabled via **MP\_testBrakeCurrent**, the current is adjusted so that the servo drive is not moved while the other servo drives of the synchronized axis are being tested.

Since the algebraic sign of the test torque cannot be determined until the drives are feedback-controlled and the brakes are open, an appropriate waiting time must be specified for the start of the brake test of synchronized axes. The time set in **MP\_vCtrlSwitchOnDelay** (400929) is used for this. The value for **MP\_vCtrlSwitchOnDelay** must equal the time that passes until the brake is really open after the controller has been switched on. The same time must be entered in **MP\_vCtrlSwitchOnDelay** for all servo drives of a synchronized axis. For the CC61xx controller unit the time in **MP\_vCtrlSwitchOnDelay** is taken into account each time the controller is switched on.

In general, the following applies to the brake control: If the brakes are controlled by the PLC, and not by the inverters, the PLC module 9159 (drive controllers are switched off) transmits the status message to the PLC program regarding the closing of the brakes during the brake test.



#### Note

HEIDENHAIN recommends the sequential brake test of synchronized axes for all machines on which a brake test for synchronized axes made (**MP\_autoBrakeTest = off**).

- Test the behavior of the PLC program and the brake test on the machine.





## 6.15 Reference Marks


### 6.15.1 Definition

The position value (the coordinates) of an axis position is defined with respect to a freely chosen datum. When the axes are moved, the ACTUAL position is calculated incrementally. An interruption in power causes the reference between the axis position and the position value to be lost.

HEIDENHAIN linear encoders are designed with one or more reference marks. The reference marks identify an axis position at a known distance from the machine datum. The position of the freely selectable datum is defined with respect to the machine datum.

The datum and the actual position can be reproduced as soon as the reference marks are traversed.

HEIDENHAIN recommends position encoders with distance-coded reference marks. With distance-coded reference marks, the position value can be reestablished after traverse of a short distance over any two reference marks.



## 6.15.2 Traversing the reference marks

The reference marks must be traversed after any interruption in power. Specify which axes are homed, and in which sequence, in **MP\_refAllAxes** or **MP\_refAxis**.

- ▶ Press the machine START button: The reference marks are automatically traversed (MP\_refAllAxes=True).

or:

- ▶ Press the machine axis-direction buttons: The user determines the sequence of the axes (MP\_refAllAxes=False).

After the reference marks have been traversed:

- The software limit switches are activated.
- The most recently set datum or workpiece datum and the machine datum are reproduced.

### Distance between the scale reference point and the machine datum

For position encoders with distance-coded reference marks, the machine datum is defined with respect to the scale reference point, which is at the first reference mark after the beginning of the measuring length. On angle encoders, the scale reference point is marked:

- ▶ In MP\_refPosition, enter the distance between the scale reference point and the machine datum.

For position encoders without distance-coded reference marks but with more than one reference mark, every reference mark to be traversed must be evaluated.

- ▶ For each reference mark to be traversed, create another parameter set, and enter in MP\_refPosition the distance between the scale reference point and the reference mark.
- ▶ Activate the parameter set that corresponds to the traversed reference mark.

### Assigning a reference value

In some cases it may be necessary to assign a new reference value to an axis, e.g. if an axis is mechanically fixed and the encoder is moved. A typical application is, for example, with (Hirth) clamped axes

Since due to the mechanical fixing the position of the axis cannot be changed, you can assign it a new reference value.

- ▶ Enter the new reference value in Module 9147.



#### Note

Please note the following restriction if you are using the **CC 422** controller unit:

If you are using Module 9147, the following settings in the **MP\_refType** parameter (functional sequence for traversing the reference marks) are not permissible when using the CC 422:

**MP\_refType = distance coded + on the fly**

**MP\_refType = without switch + on the fly**

### Module 9147 Assign a reference value to an axis

Module 9147 is used to enter a new reference value for an axis. New reference values can be entered for multiple axes in one scan with this module.

If a new reference value is assigned to an axis, the corresponding bit in NN\_AxReferenceAvailable (W1032) is reset.



#### Note

When calling the module for an NC axis during a strobe, the synchronization with the advance calculation (strobe with **MP\_sync** = SYNC\_CALC) must be configured for this strobe.

#### Constraints:

- The module functions only in the cyclic PLC program.
- The module can only be executed when the control is not active or if an M/S/T/T2/G strobe is pending.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

#### Call:

```
PS   B/W/D/K <>Axis number>  
      Index from CfgAxes/axisList  
PS   B/W/D/K <>New reference value in 0.1 µm>  
CM   9147
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModuleError (M4203)	0	No error
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModuleError Code (W1022)	2	Invalid axis number
	21	Missing strobe in M4176 = 1
	24	Module was called in a spawn or submit job

## Encoders with EnDat interface

Position encoders and speed encoders with EnDat interface can be connected to the MANUALplus 620. With these encoders there is no need to traverse the reference marks. The position value is only read when the MANUALplus 620 is switched on. It cannot be read again.

When connecting a position encoder with EnDat interface, or a speed encoder with EnDat interface as a position encoder:

► Enter **MP\_refType = Endat Encoder**



### Note

If use of multiturn encoders with EnDat interfaces results in overflows, the corresponding information is stored temporarily. If the control is exchanged, **MP\_refPosition** must be re-adjusted.



## Renewed traversing of the reference marks

### Module 9220 Traverse the reference mark

The module starts the reference mark traverse in an axis or servo-controlled spindle. If the reference mark has already been evaluated, it can be evaluated again by this module. The module can be called in all operating modes.

Constraints:

- Software limit switches are not effective.
- The sequence of functions is determined by **MP\_refType**.
- The velocity and the direction for traversing the reference marks are either taken from **MP\_refFeedHigh** and **MP\_refDirection** (CfgReferencing) or they are defined in the module.
- An axis cannot be started for referencing until all other axes are in position.
- If an axis is started for reference point traverse although the reference mark has already been traversed, NN\_AxReferenceAvailable is reset and the reference mark is evaluated again. The same constraints apply as when traversing the reference mark for the first time.
- If the spindle is started for reference point traverse, the marker NN\_SpiReferenceAvailable is set.
- The spindle must be started from a standstill to traverse the reference mark.



#### Note

The direction of traverse should be defined in the module only in exceptional cases. Since the reference end positions are not considered in this case, the limits of the traverse range may be violated.

Call:

- |    |         |  |
|----|---------|--|
| PS | B/W/D/K | <>Axis/spindle><br>Index from CfgAxes/axisList   |
| PS | B/W/D/K | <>Feed rate/shaft speed><br>0: Feed rate/shaft speed from CfgReferencing/refFeedHigh<br>>0: Feed rate in mm/min or shaft speed in 1/1000 min <sup>-1</sup>   |
| PS | B/W/D/K | <>Direction of traverse><br>-1: Negative direction<br>0: Direction from CfgReferencing/refDirection<br>1: Positive direction   |
| CM | 9220    |  |
| PL | B/W/D   | <>Error code><br>0: Reference mark traverse is commanded<br>1: Non-existent axis or open-loop spindle<br>2: Inadmissible values for the feed rate / direction<br>3: Incorrect operating mode<br>4: Reference traverse already started<br>5: Axis is already being positioned or the spindle is in motion<br>6: Other axis is already being positioned<br>8: Programmed axis not in closed loop |

### 6.15.3 Traversing the reference marks

The reference marks must be traversed after any interruption in power. Specify which axes are homed, and in which sequence, in **MP\_refAllAxes** or **MP\_refAxis**.

- ▶ After acknowledging the power interruption with the CE key or pressing the Control voltage On key, you can preselect individual axes to be homed or use the ALL soft key.
- ▶ After the NC start key has been pressed, the axes are homed one after the other in the sequence defined in parameter **MP\_refAxis**.

After the reference marks have been traversed:

- The software limit switches are activated.
- The most recently set datum or workpiece datum and the machine datum are reproduced.

#### Distance between the scale reference point and the machine datum

For position encoders with distance-coded reference marks, the machine datum is defined with respect to the scale reference point, which is at the first reference mark after the beginning of the measuring length. On angle encoders, the scale reference point is marked:

- ▶ In **MP\_refPosition**, enter the distance between the scale reference point and the machine datum.

For position encoders without distance-coded reference marks but with more than one reference mark, every reference mark to be traversed must be evaluated.

- ▶ For each reference mark to be traversed, create another parameter set, and enter in **MP\_refPosition** the distance between the scale reference point and the reference mark.
- ▶ Activate the parameter set that corresponds to the traversed reference mark.

#### Assigning a reference value

In some cases it may be necessary to assign a new reference value to an axis, e.g. if an axis is mechanically fixed and the encoder is moved. A typical application is, for example, with (Hirth) clamped axes

Since due to the mechanical fixing the position of the axis cannot be changed, you can assign it a new reference value.

- ▶ Enter the new reference value in Module 9147.



#### Note

Please note the following restriction if you are using the **CC 422** controller unit:

If you are using Module 9147, the following settings in the **MP\_refType** parameter (functional sequence for traversing the reference marks) are not permissible when using the CC 422:

**MP\_refType = distance coded + on the fly**

**MP\_refType = without switch + on the fly**

### Module 9147 Assign a reference value to an axis

If a new reference value is assigned to an axis, the corresponding bit in NN\_AxReferenceAvailable (W1032) is reset.



#### Note

When calling the module for an NC axis during a strobe, the synchronization with the advance calculation (strobe with **MP\_sync** = SYNC\_CALC) must be configured for this strobe.

Call:

PS B/W/D/K <>Axis number>  
0 to 8: Axes 1 to 9

PS B/W/D/K <>New reference value in 0.1 µm>

CM 9147

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModuleError (M4203)	0	No error
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModuleError Code (W1022)	2	Invalid axis number
	21	Missing strobe in M4176 = 1
	24	Module was called in a spawn or submit job

### Encoders with EnDat interface

Position encoders and speed encoders with EnDat interface can be connected to the MANUALplus 620. With these encoders there is no need to traverse the reference marks. The position value is only read when the MANUALplus 620 is switched on. It cannot be read again.

When connecting a position encoder with EnDat interface, or a speed encoder with EnDat interface as a position encoder:

- ▶ Enter **MP\_refType = Endat Encoder**



#### Note

If use of multiturn encoders with EnDat interfaces results in overflows, the corresponding information is stored temporarily. If the control is exchanged, **MP\_refPosition** must be re-adjusted.

## Renewed traversing of the reference marks

### Module 9220 Traverse the reference mark

The module starts the reference mark traverse in an axis or servo-controlled spindle. If the reference mark has already been evaluated, it can be evaluated again by this module. The module can be called in all operating modes.

Constraints:

- Software limit switches are not effective.
- The sequence of functions is determined by **MP\_refType**.
- The velocity and the direction for traversing the reference marks are either taken from **MP\_refFeedHigh** and **MP\_refDirection** (CfgReferencing) or they are defined in the module.
- An axis cannot be started for referencing until all other axes are in position.
- If an axis is started for reference point traverse although the reference mark has already been traversed, NN\_AxReferenceAvailable is reset and the reference mark is evaluated again. The same constraints apply as when traversing the reference mark for the first time.
- If the spindle is started for reference point traverse, the marker NN\_SpiReferenceAvailable is set.
- The spindle must be started from a standstill to traverse the reference mark.



#### Note

The direction of traverse should be defined in the module only in exceptional cases. Since the reference end positions are not considered in this case, the limits of the traverse range may be violated.

Call:

PS	B/W/D/K	<>Axis/spindle> Index from CfgAxes/axisList
PS	B/W/D/K	<>Feed rate/shaft speed> 0: Feed rate/shaft speed from CfgReferencing/refFeedHigh >0: Feed rate in mm/min or shaft speed in 1/1000 min <sup>-1</sup>
PS	B/W/D/K	<>Direction of traverse> -1: Negative direction 0: Direction from CfgReferencing/refDirection 1: Positive direction
CM	9220	
PL	B/W/D	<>Error code> 0: Reference mark traverse is commanded 1: Non-existent axis or open-loop spindle 2: Inadmissible values for the feed rate / direction 3: Incorrect operating mode 4: Reference traverse already started 5: Axis is already being positioned or the spindle is in motion 6: Other axis is already being positioned 8: Programmed axis not in closed loop





## 6.15.4 Defining the process of traversing the reference marks

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgReferencing	
<b>refType</b>	400401
<b>refSwitchActive</b>	400404
<b>refFeedLow</b>	400406
<b>refFeedHigh</b>	400407
<b>refDirection</b>	400408

The parameter object CfgReferencing is not required for:

- Virtual axes (MP\_axisMode = Virtual)

You define the process of traversing the reference marks in the following machine parameters:

- ▶ In **MP\_refDirection** and **MP\_refFeedHigh** (for rotary encoders also in MP\_refFeedLow) you define the direction and velocity for traversing the reference marks.
- ▶ In **MP\_refAxis**, define the sequence of axes for traversing the reference marks.
- ▶ In **MP\_refType** you select the functional sequence (type of reference marks) for each axis.

## MP\_refType

Sequence for finding the reference mark  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **None**

No traversing of the reference marks

If the reference run with the spindle is performed via a trip dog, this value must be set.

### **Switch, changing Dir**

For linear axes with speed encoder; reference run with NC start

### **Switch, no changing Dir**

For linear axes with speed encoder; reference run with NC start

### **without Switch**

For spindle, rotary table with angle encoder; reference run with NC start

### **distance coded**

For distance-coded linear encoders; reference run with NC start

### **distance coded + on the fly**

For distance-coded linear encoders; reference run with axis-direction keys or NC start

### **without switch + on the fly**

For spindle; reference run with M3, M4

### **Endat Encoder**

For axes with EnDat encoder; reference-mark traverse not necessary

Default: Switch, changing Dir

Access: LEVEL3

Reaction: REF



## Direction and velocity

In **MP\_refDirection** you specify the direction of traverse. If the axis traverses the reference-end-position trip dog, and **PP\_AxReferenceEndPosition** is set, the direction of traverse is reversed.

In **MP\_refFeedHigh** and **MP\_refFeedLow**, define the velocity for traversing the reference marks.

It depends on the entry in **MP\_refType** whether the low or high reference-run velocity is used.

### MP\_refDirection

Direction for traversing the reference marks  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: **positive**  
Positive traverse direction  
**negative**  
Negative traverse direction  
Default: negative  
Access: LEVEL3  
Reaction: REF

### MP\_refFeedLow

Low speed when finding the reference mark  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 10.000 000 000 to 36 000 000 [mm/min]  
Default: 600  
Access: LEVEL3  
Reaction: REF

### MP\_refFeedHigh

High velocity for traversing the reference mark  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 36 000 000 [mm/min]  
Default: 1200 [mm/min]  
Access: LEVEL3  
Reaction: REF


The parameter **MP\_refSwitchActive** defines the status of the trip dog for reference end position.

### MP\_refSwitchActive

Active level of the trip dog for reference end position  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: **high**  
Reference-end-position trip dog is active if  
PP\_AxReferenceEndPosition = 1  
**low**  
Reference-end-position trip dog is active if  
PP\_AxReferenceEndPosition = 0  
Default: high  
Access: LEVEL3  
Reaction: REF


**Position encoder  
with distance-  
coded reference  
marks**

Functional sequence if **MP\_refType=distance coded**



**Position encoder with one reference mark**


Functional sequence if **MP\_refType=Switch, no changing Dir**



## Linear measurement through rotary encoder

### Functional sequence if **MP\_refType=Switch, changing Dir**


For linear measurement using a rotary encoder, a reference pulse is produced at each revolution of the encoder. Ensure that after machine switch-on the same reference pulse is always evaluated. This can be realized with the trip dog for reference end position.



### Functional sequence if **MP\_refType=without Switch**

For linear measurement using a rotary encoder, a reference pulse is produced at each revolution of the encoder. During the reference run the first reference pulse traversed after the trip dog for reference end position is closed is evaluated. This ensures that the same reference pulse is always evaluated.

For linear measurement using a rotary encoder, HEIDENHAIN recommends using the **MP\_refType=Switch, changing dir** method.



## 6.15.5 "Traverse Reference Points" operating mode

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgReferencing	
<b>refPosition</b>	400403
<b>moveAfterRef</b>	400409
<b>moveAfterRefType</b>	400410
<b>moveAfterRefPos</b>	400411
<b>moveAfterRefFeed</b>	400412

The parameter object CfgReferencing is not required for:

- Virtual axes (MP\_axisMode=Virtual)

In **NN\_OmgReference**, the NC informs the PLC of the **Pass Over Reference Point** operating mode. In **NN\_AxReferenceAvailable**, the NC reports whether the reference marks of this axis were traversed.

If you switch the operating mode before all reference marks are traversed, the MANUALplus 620 identifies this state and prompts you to traverse the remaining reference marks.

### Reference end position

To prevent the axes from violating their traverse limits when traversing the reference marks, each axis requires a trip dog (at the reference end position). The trip dogs must be installed by the machine tool builder at the ends of the traverse range. The switch signals from the trip dogs are sent to free PLC inputs. The PLC program must gate these PLC inputs with **PP\_AxReferenceEndPosition** for "reference end position." Setting the reference end position causes a reversal of the traverse direction from **MP\_refDirection**.

PLC operand / Description	Type
NN_AxReferenceAvailable 0: Reference mark not traversed 1: Reference mark traversed	M
PP_AxReferenceEndPosition 0: Trip dog not triggered 1: Trip dog triggered	M





## Machine datum

**MP\_refPosition** defines the position of the machine datum relative to the reference point of the scale. For encoders with distance-coded reference marks, the position is relative to the scale reference point; for encoders with EnDat interface, relative to the absolute encoder datum.

### MP\_refPosition

Position of the machine datum

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: -100 000.000 000 000 to +100 000 [mm] or [°]

Default: 100

Access: LEVEL3

Reaction: REF

## Positioning after reference mark traverse

The axis can automatically be moved to a certain position after reference mark traverse is completed. This behavior is activated with **MP\_moveAfterRef**.

Define the following information for positioning after reference mark traverse:

- ▶ The type of movement after finding the reference mark: absolute, relative or positioning on the Hirth grid
- ▶ In **MP\_moveAfterRefPos** the end position.
- ▶ In **MP\_moveAfterRefFeed**, the feed rate.

### **MP\_moveAfterRef**

Activate movement after finding the reference mark  
Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **on**  
Positioning after reference-mark traverse is active  
**off**  
No positioning after reference-mark traverse

Default: off

Access: LEVEL3

Reaction: REF

### **MP\_moveAfterRefType**

Type of movement after finding the reference mark  
Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **absolute**  
Absolute positioning. This function is mainly intended for positioning rotary tables. Please ensure that no collision occurs as a result of this positioning. The software limit switches are already active.  
**relative**  
Incremental positioning

**HirthRasterPos**  
Approach next Hirth grid position in positive direction.

**HirthRasterNeg**  
Approach next Hirth grid position in negative direction.

Default: absolute

Access: LEVEL3

Reaction: REF

### **MP\_moveAfterRefPos**

Position for positioning after traversing the reference mark  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: -100 000.000 000 000 to +100 000 [mm] or [°]

Default: 0

Access: LEVEL3

Reaction: REF

### **MP\_moveAfterRefFeed**

Feed rate for positioning after traversing the reference mark  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 10.000 000 000 to 36 000 000 [mm/min] or [°/min]

Default: 6 000

Access: LEVEL3

Reaction: REF



## 6.16 The Control Loop


Machine tools normally function on the principle of cascade control. Here the position control loop is prior to the speed and current control loops.

Benefits of cascade control:

- Transparent structure of the individual control loops.
- Disturbances can be compensated through the subsequent controllers. This relieves the prior controller.
- The respective outer control loop protects the inner control loop by limiting the command variable.
- Individual commissioning of each control loop, starting with the innermost loop.

### 6.16.1 Block diagram of control loop

The position, speed, and current controllers are integrated in the MANUALplus 620. The power module is driven by the CC controller unit through PWM signals (PWM = pulse width modulation).



There is a separate time interval for each control loop:


- **Position controller cycle time:** Time interval during which the interpolation points on the path are calculated.
- **Speed controller cycle time:** Time interval in which the actual speed value is compared to the calculated nominal speed value.
- **Current controller cycle time:** Time interval in which the actual current value is compared to the calculated nominal current value.

The cycle times that apply vary depending on the CC used or the CC's settings.

## 6.16.2 Relation between jerk, acceleration, velocity and distance

### Acceleration and jerk

Taking into account the motor and the power module, the machine should be designed in such a way that acceleration during the acceleration phase is as constant as possible. This ensures maximum utilization of the drive current. On the other hand, the machine should also be designed to fulfill the dynamic requirements. The jerk should be kept to a minimum and the jerk phase should be maximized in order to prevent the machine from oscillating. This results in a bell-shaped acceleration curve (see figure).



Legend:


- v: Velocity
- a: Acceleration
- r: Jerk
- $v_{max}$ : Maximum velocity

## Distance

To attain the maximum velocity, a certain minimum distance must be traversed. This also applies to the braking phase.

If the traverse distance is greater than the distance covered during the acceleration and braking phases, a movement at constant (maximum) speed is inserted (see period of time from  $t_1$  to  $t_2$  in the figure below).

If the traverse distance is shorter, the maximum velocity is not attained.



### Legend:

- v: Velocity
- a: Acceleration
- r: Jerk
- s: Distance
- $v_{max}$ : Maximum velocity
- $S_w$ : Traverse distance
- $t_1$ : End of acceleration phase
- $t_2$ : Start of braking phase
- $t_3$ : End of traverse distance

### 6.16.3 Nominal position value filter

To attain a high machining velocity while maintaining a high surface quality, the workpiece contour can be adapted to the machine dynamics by means of a nominal position value filter.

Four types of low-pass filters are available for limiting the bandwidth of the dynamics of nominal position and speed values.

- Average (mean-value filter)
- HSC filter (not available on lathes)
  - HSC finishing filter
  - HSC roughing filter
- Advanced HSC filter (not available on lathes)
- Triangle filter

#### Mean-value and triangle filter

The mean-value and triangle filters are low-pass filters that always smooth a contour towards the inside at changes in direction. They can be used when a very high surface quality is required, or when a high machining speed is required and larger tolerances are permitted.

HEIDENHAIN recommends: Do not use the mean-value filter. This filter provides a reduced edge steepness and was originally developed for internal tests. Prefer the triangle filter.

#### HSC and advanced HSC filter (not available on lathes)

The speed advantage of both HSC filters is especially large for circular contours. However, you must consider slight overshoots at corners and curvature transitions that are within the given tolerances

**(MP\_pathTolerance).**

HEIDENHAIN recommends: Prefer the HSC filter when a high accuracy is required, and use the advanced HSC filter when you need a high surface quality. The advanced HSC filter has a more even effect on the speed and any possible overshoots.

#### Selection criteria for the nominal position value filters

The settings for the nominal position value filters mainly depend on the emphasis of the requirements for machining the workpiece. Speed and accuracy, in connection with clean and smooth surfaces, are the decisive criteria.

At the same time, the oscillation and resonance tendencies of the machining system (the machine tool) are to be considered, and taken into account in the settings for the nominal position value filters. The following recommendations can be made for the settings:

Clean surface

Definition of the term "surface":

- A clean and smooth surface has the highest priority
- Application: Finishing
- Oscillations in the axes must be damped, since following errors of 1 µm are still visible on the surface
- Tolerances are typically between 0.01 and 0.02 mm (may be slightly exceeded in order to achieve a better surface)

Settings guidelines for "surface":

- Low jerk values (**MP\_maxPathJerk**)
- Switch off consideration of the tolerance for curvature changes (**MP\_pathTolerance**)
- High jerk values for MP\_axJerk so that no limitations take effect (example: test up to a value of 1000)

Accuracy

Definition of the term "accuracy":

- Maintaining the tolerances has the highest priority
- Slight oscillations can be seen on the surface
- Tolerances are typically between 0.005 and 0.01 mm.

Settings guidelines for "accuracy":

- Lower jerk values than for "speed"
- Ideally, circular paths should be checked with a KGM grid encoder from HEIDENHAIN. However, in many cases the circular interpolation test with the integrated oscilloscope or TNCopt suffices.
- **MP\_pathTolerance** = 1 (consideration of tolerance limits at curvature changes)
- The adjustment should be tested with suitable NC programs. The **TNCopt** software from HEIDENHAIN features suitable NC programs for this. The advantage is that the speed and the contour deviations can be seen directly.

## Speed

Definition of the term "speed":

- Surface quality is secondary; short machining times have the highest priority
- Application: Roughing
- Tolerances typically between 0.1 and 0.2 mm

Settings guidelines for "speed":

- Filter selection
  - For large tolerances (greater than 50 µm), preferential use of triangle filters
- High jerk values
- The adjustment should be tested with suitable NC programs. The **TNCopt** software from HEIDENHAIN features suitable NC programs for this. The advantage is that the speed and the contour deviations can be seen directly.






- When setting the jerk and acceleration values, as well as selecting the suitable filters, take into account
  - the running noises of the machine
  - the mechanical load (wear)
  - the desired machining speed.

**Function of the nominal position value filters**

The function of the filters for rotary axes depends on TCPM (see figure):

- TCPM is not active:
  - The filters of the "cutter location" type are not active
  - The filters of the "position" type are active for all axes
- TCPM is active and **MP\_isAng** = TRUE (not available on lathes):
  - The filters of the "cutter location" type are automatically activated for all rotary axes
  - The filters of the "position" type are not active for rotary axes



This method provides the following advantage:

- Filtering by CLP filters (Cutter Location Point filters) changes the actual positions of the rotary axes. Based on the kinematics, these changed rotary axis positions result in changes in the nominal X, Y and Z positions before the position filter.

**Configuration of the nominal position value filters as of NCK software version 597 110-05**

Settings in the configuration editor	MP number
System	
CfgFilter	
defaultPosition	100405
<b>shape</b>	
<b>frequency</b>	
<b>hscMode</b>	
<b>defaultManualOrder</b>	100407
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgPositionFilter	
axisPosition	401606
<b>shape</b>	
<b>frequency</b>	
<b>hscMode</b>	
<b>manualFilterOrder</b>	401605
<b>handwheelFilterOrder</b>	401608

As of NCK software version 597 110-05 (milestone 5), the MANUALplus 620 provides new machine parameters for configuring the nominal position value filters:

**Global setting of the nominal position value filters via System / CfgFilter**

Two filters are located before the position control loop to prevent the machine from oscillating:

- **MP\_defaultPosition** is effective for **linear axes**, without TCPM also for rotary axes.
- **MP\_defaultManualOrder** defines the order of the mean-value filter for the Manual operating modes.

Use **MP\_shape** to specify the form of nominal position value filter and enter the filter's limit frequency in **MP\_frequency**. The MANUALplus 620 calculates the filter order automatically.

The **MP\_hscMode** parameter affects only HSC filters (not advanced HSC filters) and specifies the HSC mode (roughing or finishing).

The parameters are globally effective for all axes unless you overwrite the defined default value with the axis-specific filter parameter **MP\_axisPosition**:

**Axis-specific setting of the nominal position value filters:**

- **MP\_axisPosition** is effective for specific linear axes, and for rotary axes if TCPM is deactivated.
- **MP\_manualFilterOrder** defines the order of the mean-value filter for specific axes in the Manual operating modes.

When you define an axis-specific filter, the global setting from System / CfgFilter is overwritten for the specified axis.

The smoothing function of the nominal position value filters causes contour errors. The velocity profile is adjusted by the look-ahead function so that the contour error does not exceed the given tolerance (see "Look-ahead" on page 825).



Take the machine setup into account when you configure filters. It is decisive whether TCPM (Tool Center Point Management, not available on lathes) executes compensating movements for rotary axes.

**Configuration examples**

**Example 1:  
Machine with 3 axes (TCPM is not used)**

For a simple 3-axis configuration, the nominal position value filters are globally defined in **CfgFilter**: Remove the **CfgPositionFilter** configuration object from the parameter sets of the axes. In addition, remove the **MP\_defaultCutterLoc** parameter since there are no rotary axes and the Cutter Location filter is not needed.

Machine parameters in the configuration editor and recommended input value	Meaning
System CfgFilter defaultPosition <b>shape:</b> Triangle <b>frequency:</b> 24 <b>hscMode:</b> Smoothing <b>defaultManualOrder:</b> 11	Form of filter: Triangle filter Limit frequency: 24 Hz HSC mode: Finishing Filter order in Manual operating modes: 11



**Example 2:**  
**Machine with 3 axes, with slow infeed of the Z axis**

In this 3-axis configuration, all nominal position value filters are defined globally with the exception of the Z axis. Remove all CfgPositionFilter configuration objects, except in the parameter set for the Z axis. Since the filter settings will be reduced for the Z-axis to accommodate the slow infeed movements, this axis is configured separately:



**Warning**

Only define separate filter settings for an axis if the axis is not interpolated with the other axes!

Example:

On a boring mill (boring applications only) it may be useful to define softer filters for positioning movements in the Z axis at rapid traverse.

Machine parameters in the configuration editor and recommended input value	Meaning
System CfgFilter defaultPosition <b>shape:</b> HSC <b>frequency:</b> 40 <b>hscMode:</b> Smoothing <b>defaultManualOrder:</b> 11	Form of filter: HSC filter Limit frequency: 40 Hz HSC mode: Finishing Filter order in Manual operating modes: 11
Axes ParameterSets [Key name of the Z axis] CfgPositionFilter axisPosition <b>shape:</b> HSC <b>frequency:</b> 15 <b>hscMode:</b> Smoothing	Form of filter: HSC filter Limit frequency: 15 Hz HSC mode: Finishing



## Machine parameters as of NCK software version 597 110-05:

### System / CfgFilter:

Configuration of the globally effective nominal position value filters

#### ■ **defaultPosition:**

Defines the form and limit frequency of the nominal position value filter globally for all linear axes.

#### ■ **defaultManualOrder:**

Defines the filter order in the Manual operating modes globally for all axes.

### Parameter set of the axis / CfgPositionFilter:

Axis-specific configuration of the nominal position value filters. Overwrites the settings made in System / CfgFilter for the specified axis.

#### ■ **axisPosition:**

Defines the nominal position value filter for specific linear axes. Also effective for rotary axes with M129 (TCPM not active).

#### ■ **manualFilterOrder:**

Axis-specific order of the mean-value filter for the Manual operating modes. Overwrites the setting in **MP\_defaultManualOrder** (System / CfgFilter).

#### ■ **handwheelFiltOrder:**

Axis-specific order of the mean-value filter when using a handwheel. Overwrites the setting in **MP\_manualFilterOrder** or

**MP\_defaultManualOrder**.

### MP\_shape

Shape of the nominal position value filter

Available from NCK software version: 597 110-05.

Format: Selection menu

Selection: Off

Average

Triangle

HSC

AdvancedHSC

Default: Off

Access: LEVEL3

Reaction: RUN

### MP\_frequency

Limit frequency of the position value filter

Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0 to 1000 [Hz]

9 decimal places are permissible

Default: 20

Access: LEVEL3

Reaction: RUN

### **MP\_hscMode**

Only for HSC filters: HSC mode  
Available from NCK software version: 597 110-05.

Format: Selection menu

Selection: The HSC mode defined here is effective for HSC filters (not advanced HSC filters). The machine operator can use Cycle 32 or FN17: ID260 in the NC program to overwrite this setting.

**Smoothing**  
HSC mode: Finishing

**Roughing**  
HSC mode: Roughing

Default: Smoothing

Access: LEVEL3

Reaction: RUN

### **MP\_defaultManualOrder**

Globally effective order of the mean-value filter in the Manual operating modes  
Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 1 to 51  
Only odd integers are permitted input values! If you enter an odd number, the MANUALplus 620 displays an error message.

Default: 11

Access: LEVEL3

Reaction: RUN

### **MP\_manualFilterOrder**

Axis-specific order of the mean-value filter for the Manual operating modes. Overwrites the value in MP\_defaultManualOrder (CfgFilter).  
Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 1 to 251  
Only odd integers are permitted input values! If you enter an even number, the MANUALplus 620 displays an error message.

Default: 11

Access: LEVEL3

Reaction: RUN



## MP\_handwheelFilterOrder

Axis-specific order of the mean-value filter in the **E1 . Handwheel** operating mode

Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 1 to 251

Only odd integers are permitted input values! If you enter an even number, the MANUALplus 620 displays an error message.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

### Configuration of the nominal position value filters up to NCK software version 597 110-04

Settings in the configuration editor	MP number
System	
CfgFilter	
<b>typeFilter1</b>	100401
<b>orderFilter1</b>	100402
<b>typeFilter2</b>	100403
<b>orderFilter2</b>	100404
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgPositionFilter	
<b>filter1Shape</b>	401601
<b>filter2LimitFreq</b>	401602
<b>filter2Shape</b>	401603
<b>filter2LimitFreq</b>	401604

### Global settings of the nominal position value filters

Two filters are located before the position control loop to prevent the machine from oscillating.

■ **MP\_typeFilter1** only affects **rotary axes**. This filter is usually not required for lathes. In this case you can enter "off" for the parameter.

■ **MP\_typeFilter2** only affects **linear axes**.

With **MP\_orderFilter1** and **MP\_orderFilter2** you define the global order of the filter. Then you define for each axis whether a filter is used and which filter is used to optimize the axis. In addition, the frequency of the filter is defined axis-specifically.

The smoothing function of these filters causes contour errors. The velocity profile is adjusted by the look-ahead function so that the contour error does not exceed the given tolerance (see "Look-ahead" on page 825).



#### Note

Filters delay the processing time of NC blocks by the control, since multiple NC blocks must be considered for the filter functions.

Take the machine setup into account when you configure filters.

HEIDENHAIN recommends that you configure the filters of standard machines (TCPM is not used) as follows:

- ▶ Define **MP\_typeFilter1** = Off.
- ▶ Define **MP\_typeFilter2** = Position and specify the filter order in **MP\_orderFilter2**.
- ▶ For **rotary and linear axes** you define the triangle filter **MP\_filter2Shape** = Triangle. Enter in **MP\_filter2LimitFreq** the limit frequency of the machine.

### Recommended settings for filter limit frequency and filter order

On the MANUALplus 620 the filter limit frequency is set via the globally effective filter order. In the following you will find recommendations on how to set the filter order.

#### Triangle and mean-value filter:

The higher you set the filter order, the more "relaxed" the machine behaves—this always results in a degree of inaccuracy. In addition, the higher the filter order, the more the speed of the axes is reduced.

These settings must always be considered in relation to their results. The speed at corners and arcs is reduced because of the tolerance.

However, the behavior is exactly the opposite at contour transitions (straight line to arc, arc to arc): the "relaxed" filter settings make contour transitions at higher speeds possible.

You must perform tests to find the best compromise between high transition speeds and high curve speeds for each machine type.

### Settings of the nominal position value filters

Now that the basic global settings for the nominal position value filter have been made, the filter and look-ahead parameters can be specified.

- ▶ The control can distinguish between machining and rapid-traverse positioning movements. This makes it possible to optimize the path control for positioning movements at rapid traverse:  
Define the maximum machining feed rate in the **MP\_maxG1Feed** parameter. As with rapid traverse, the parameters **MP\_maxPathJerkHi** and **MP\_pathToleranceHi** apply as of this feed rate.
- ▶ Enter the permissible axis-specific jerk:  
**MP\_maxPathJerk**: Maximum jerk for acceleration processes.  
**MP\_axJerk**: Is effective for acceleration processes due to the workpiece geometry (at curvature changes, e.g. tangential transition from a line to an arc)
- ▶ Enter the permissible axis-specific jerk for rapid traverse in the parameter **MP\_maxPathJerkHi**. This value also applies to feed rates greater than the parameter **MP\_maxG1Feed**.
- ▶ In the **MP\_pathTolerance** parameter you must define the tolerance for contour transitions with motions at the machining feed rate. The control monitors the contour deviation to ensure that it does not exceed this maximum.
- ▶ In the parameter **MP\_pathToleranceHi** you define a tolerance for contour transitions with motions at rapid traverse. The value also applies to feed rates greater than the limit value in **MP\_maxG1Feed**. This tolerance can **not** be overwritten by the machine user with Cycle 32 "Tolerance."





- ▶ When selecting the limit frequencies (parameters **MP\_filter1LimitFreq** and **MP\_filter2LimitFreq**) for mean-value filters and triangle filters, take into account the lowest resonant frequency of your machine's axes and the desired damping at this frequency. If the limit frequency is set to 0, the filter is switched off.

**MP\_filter1LimitFreq** and **MP\_filter2LimitFreq** have no significance for the Triangle and Average filter types. You can switch off these filters only if you enter the value **0ff** in **MP\_filter1Shape** and **MP\_filter2Shape**.



#### Note

The tolerance (**MP\_pathTolerance**) always refers to the nominal value, meaning the servo lag also affects the contour accuracy. For example, if the servo lag  $S = 5 \mu\text{m}$  and the tolerance  $T = 10 \mu\text{m}$ , then the total deviation is  $15 \mu\text{m}$ .

- ▶ With the parameters **MP\_filter1Shape** and **MP\_filter2Shape**, select from the mean-value and triangle filters the nominal position value filters for the **Program Run, Single Block, Program Run, Full Sequence** and **Positioning with Manual Data Input** operating modes. The triangle filter (triangle) smoothes the contour towards the inside at changes in direction. This results in an excellent surface quality without overshoot. The mean-value filter (average) is a very smooth filter with low edge steepness, which should be used only for testing, and not for machining.
- ▶ With the parameter **MP\_manualFilterOrder**, select the order of the mean-value filter for the **Manual, Electronic Handwheel, Jog Increment** and **Pass Over Reference Point** operating modes.
- ▶ In order to achieve the optimum results for your machine or application, test the various filter settings with a test part consisting of short, straight paths.

## Machine parameters up to NCK software version 597 110-04:

### MP\_typeFilter1

Type of the first nominal position value filter  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **Off**  
Filter 1 is deactivated (recommended for lathes)  
**Position**  
Axis position (for linear and rotary axes)  
**CutterLocation**  
For rotary axes

Default: **Off**

Access: LEVEL3

Reaction: RESET

### MP\_orderFilter1

Order of first nominal position value filter  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 1 to 31

Default: 11

Access: LEVEL3

Reaction: RESET

### MP\_typeFilter2

Type of the second nominal position value filter  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **Off**  
Filter 2 is not active  
**Position**  
Axis position (for linear and rotary axes)  
(recommended for lathes)  
**CutterLocation**  
for rotary axes (do not use for lathes)

Default: Position

Access: LEVEL3

Reaction: RESET

### MP\_orderFilter2

Order of second nominal position value filter  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 1 to 31

Default: 11

Access: LEVEL3

Reaction: RESET



### **MP\_filter1Shape**

Form of the first nominal position value filter  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **Off**  
Switched off  
**Average**  
Mean-value filter  
**Triangle**  
Triangle filter  
**HSC**  
High-speed cutting filter (cannot be used for lathes)

Default: Off

Access: LEVEL3

Reaction: RUN

### **MP\_filter1LimitFreq**

Limit frequency of the first nominal position value filter  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 10.000 000 000 to 100 [Hz]

Default: 66 [Hz]

Access: LEVEL3

Reaction: RUN

### **MP\_filter2Shape**

Form of the second nominal position value filter  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **Off**  
Switched off  
**Average**  
Mean-value filter  
**Triangle**  
Triangle filter  
**HSC**  
High-speed cutting filter (cannot be used for lathes)

Default: Off

Access: LEVEL3

Reaction: RUN

### **MP\_filter2LimitFreq**

Limit frequency of the second nominal position value filter  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 10.000 000 000 to 100 [Hz]

Default: 40 [Hz]

Access: LEVEL3

Reaction: RUN



#### Note

- For filters of the "position" type, the cutoff frequencies of the axes should not differ significantly.
- Values between 20 Hz and 40 Hz are recommended for the cutoff frequencies of the second nominal position value filter.



#### 6.16.4 Look-ahead

Under consideration of certain limit values, **look-ahead** cyclically calculates the maximum possible contouring speed up to 5000 blocks in advance.

The calculated values are transferred to the **interpolator** in feed-rate profiles. The interpolator calculates axis-specific nominal values from the position polynomials and feed-rate profile.

The programmed contouring feed rate, maximum axis accelerations, permissible axis/path jerk, filter parameters and tolerances are taken into account in these feed-rate profiles. The feed-rate profiles are also influenced by changes to the override potentiometer, and by whether SINGLE BLOCK or FULL SEQUENCE is active.

Small variations in the feed rate, which appear during calculation of the feed-rate profile, are suppressed in order to achieve a smooth feed rate.

#### Contour smoothing

In order to achieve smooth machining surfaces with a minimum of machining time, the following must be kept in mind:

- Each jerk ( $da/dt$ ), which is caused by a change in direction on the contour, or by a change in the acceleration or in the feed rate, excites vibrations in the machine. Therefore, the jerk must be limited to a permissible size.
- For feed rates above the machining feed rate, an increased jerk and increased tolerance are both permissible, since they no longer have any effect on the machining quality.
- The tool may go to the limits of the adjustable path tolerance (deviation from the contour), but must not exceed the tolerance.
- Each machine axis is programmed for a certain maximum feed rate, and has a specified capability for acceleration. For interpolating axes, the acceleration of the slowest axis is decisive.
- Feed rates must not fall beneath the minimum value.

## Machine parameters for path-specific limit values

Settings in the configuration editor	MP number
Channels	
ChannelSettings	
[Key name of the machining channel]	
CfgLaPath	
<b>minPathFeed</b>	201501
<b>minCornerFeed</b>	201502
<b>maxG1Feed</b>	201503
<b>maxPathJerk</b>	201504
<b>maxPathJerkHi</b>	201505
<b>pathTolerance</b>	201506
<b>pathToleranceHi</b>	201507
<b>maxPathYank</b>	201508

► In **CfgLaPath**, define the path-specific limit values for feed rate, acceleration and jerk.

**MP\_minPathFeed** allows you to define the minimum feed rate in an NC block. The parameter is intended for technological purposes, in particular for preventing dwell marks in small radii. If the values are too large, feed-rate optimization becomes ineffective. This might lead to excessive dynamic load on the machine.



### Note

**MP\_minPathFeed** is always limited to the programmed feed rate; this means that look-ahead violates the defined minimum feed-rate value only if a lower value is programmed in the NC block or is set by the override potentiometer.

### MP\_minPathFeed

Minimum feed rate on the path  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 600 000 [mm/min]  
Default: 60 [mm/min]  
Access: LEVEL3  
Reaction: RUN



Use **MP\_minCornerFeed** to define the minimum feed rate at block transitions (corners and line-to-arc transitions). The parameter is intended for technological purposes, in particular for preventing dwell marks in corners. If the values are too large, feed-rate optimization becomes ineffective. This might lead to excessive dynamic load on the machine.

If a value greater than **MP\_minPathFeed** is defined in **MP\_minCornerFeed**, the value from **MP\_minPathFeed** is used as the minimum feed rate at block transitions.



#### Note

**MP\_minCornerFeed** is always limited to the programmed feed rate between two segments; this means that look-ahead violates the defined minimum feed-rate value only if a lower value is programmed in the NC block or is set by the override potentiometer.

#### **MP\_minCornerFeed**

Minimum feed rate at corners

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 600 000 [mm/min]

Default: 30 [mm/min]

Access: LEVEL3

Reaction: RUN

**MP\_pathTolerance** limits the feed rate at corners and curvatures. The parameter defines the radius of rounding of corners and the maximum deviation from the circle radius. This keeps the errors of nominal position value filter within certain limits. The MANUALplus 620 decreases the feed rate at corners, circles and curved paths in order to maintain the specified tolerance.

**MP\_pathTolerance** includes errors caused by the filter before the position control loop. The feed-rate override does not affect which jerk or tolerance is in effect.

The tolerance defined in **MP\_pathToleranceHi** is effective for feed rates exceeding those defined in **MP\_maxG1Feed**.

### MP\_pathTolerance

Path tolerance for contour transitions after the filter  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.0001 to 10.000 000 000 [mm]  
Default: 0.01 [mm]  
Access: LEVEL3  
Reaction: RUN

### MP\_pathToleranceHi

Path tolerance after the filter at rapid traverse  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.0001 to 10.000 000 000 [mm]  
Default: 0.01 [mm]  
Access: LEVEL3  
Reaction: RUN

All "-Hi" parameters (jerk and tolerance) go into effect from the feed rate defined in **MP\_maxG1Feed**.

Please note:

■ **Programmed feed rate  $\leq$  MP\_maxG1Feed:**

Tool in contact with workpiece, lower jerk values and tolerances are effective

■ **Programmed feed rate  $>$  MP\_maxG1Feed:**

Rapid traverse, greater jerk values and tolerances are effective



Note

**HEIDENHAIN recommends:**

Set **MP\_maxG1Feed** to a high value when optimizing the machine. This prevents inadvertent use of the "-Hi" values on the MANUALplus 620 while you are adjusting the axes.

### MP\_maxG1Feed

Maximum machining feed rate. If this value is exceeded, the "-Hi" parameters go into effect.

Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 99 999 [mm/min]  
Default: 99 999 [mm/min]  
Access: LEVEL3  
Reaction: RUN





The jerk defined in **MP\_maxPathJerk** is effective for machining feed rates in all channels that do not exceed the maximum machining feed rate from **MP\_maxG1Feed**. **MP\_maxPathJerk** has a higher priority than **MP\_axPathJerk** (CfgLaAxis). This means that **MP\_maxPathJerk** limits the vector sum of axis-specific path jerks.

### **MP\_maxPathJerk**

Maximum jerk on the path  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 to 1 000 000.000 [m/s<sup>3</sup>]  
Default: 40 [m/s<sup>3</sup>]  
Access: LEVEL3  
Reaction: RUN

The jerk defined in **MP\_maxPathJerkHi** is effective for feed rates greater than the feed rate defined in **MP\_maxG1Feed**. **MP\_maxPathJerkHi** has a higher priority than **MP\_axPathJerkHi** (CfgLaAxis). This means that **MP\_maxPathJerkHi** limits the vector sum of the axis-specific path jerks at rapid traverse.

### **MP\_maxPathJerkHi**

Maximum jerk on the path at rapid traverse  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 to 1 000 000.000 [m/s<sup>3</sup>]  
Default: 40 [m/s<sup>3</sup>]  
Access: LEVEL3  
Reaction: RUN

- Independent of the feed rate, define the maximum yank (dj/dt) in **MP\_maxPathYank**.

The maximum yank normally does not have to be limited in the path direction with **MP\_maxPathYank** (= change of the jerk per time). Therefore, you can usually set the parameter to its maximum value.

Under unfavorable conditions, very short jerk phases (in the range of the first natural frequency of the axis) may lead to oscillations in the workpiece. By reducing **MP\_maxPathYank**, you can prolong the jerk phases to a certain extent and thus reduce the oscillations in the workpiece.



#### Note

Limiting the yank is not suitable for smoothing successive acceleration and deceleration processes ("pumping" of feed rate). Reduce the path jerk (**MP\_axTransJerk**) instead. The use of a stretch filter (CfgStretchFilter) and feed-rate smoothing filter (**MP\_filterFeedTime**) might also be helpful.

Feed-rate "pumping" often occurs in poor-quality CAM-generated programs that carry noise. Therefore check whether the CAM program is the cause of the problem and read it out again if necessary.

#### **MP\_maxPathYank**

Maximum yank on the path (dj/dt)

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 1 000 000 [mm/s<sup>4</sup>]

Default: 4 000 [mm/s<sup>4</sup>]

Access: LEVEL3

Reaction: RUN



## Axis-specific limit values

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgFeedLimits	
<b>minFeed</b>	400301
<b>maxFeed</b>	400302
<b>rapidFeed</b>	400303
<b>manualFeed</b>	400304
<b>maxAcceleration</b>	400305
<b>maxAccSpeedCtrl</b>	400311
<b>maxDecSpeedCtrl</b>	400306
CfgLaAxis	
<b>axTransJerk</b>	401701
<b>axPathJerk</b>	401703
<b>axPathJerkHi</b>	401704

The parameter objects **CfgFeedLimits** and **CfgLaAxis** are not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)

► In **CfgFeedLimits** and **CfgLaAxis**, define the axis-specific limit values for feed rate, acceleration and jerk.

### MP\_minFeed

Applies only to the main spindle: minimum spindle speed  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 36 000 000 [°/min]

Default: 0

Access: LEVEL3

Reaction: RUN

### MP\_maxFeed

Maximum axis feed rate (rapid traverse) or maximum spindle speed

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 36 000 000 [mm/min] or [°/min]

Default: 16 000

Access: LEVEL3

Reaction: RUN

**MP\_rapidFeed** is used as the maximum axis feed rate in the **Manual Operation** and **E1. Handwheel** modes in conjunction with the rapid traverse key.

### **MP\_rapidFeed**

Rapid traverse in manual mode  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.0 to 36 000 000.0 [mm/min] or [°/min]  
Default: 4 999.98  
Access: LEVEL3  
Reaction: RUN

In the **E1. Handwheel** mode, the value entered in **MP\_manualFeed** is multiplied by the value entered in **CfgHandwheel/feedFactor**. For rotary axes and spindles, the velocity is specified in [°/min]:

### **MP\_manualFeed**

Maximum manual feed rate  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.0 to 36 000 000.0 [mm/min] or [°/min]  
Default: 4 999.98  
Access: LEVEL3  
Reaction: RUN

**MP\_maxAcceleration** defines the axis-specific acceleration. Use this parameter for all position-looped axes. The parameter is also effective for spindles operated with position control, such as while tapping or with M19. The value entered also applies to braking the axis. For rotary axes and spindles, the acceleration is specified in the unit [1000°/s<sup>2</sup>].

### **MP\_maxAcceleration**

Max. permissible axis acceleration during position control  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 1000 [m/s<sup>2</sup>] or [1000°/s<sup>2</sup>]  
Default: 3 [m/s<sup>2</sup>] or [1000°/s<sup>2</sup>]  
Access: LEVEL3  
Reaction: RUN

The two optional parameters **MP\_maxAccSpeedCtrl** and **MP\_maxDecSpeedCtrl** are only of interest if you want to use values for the acceleration and braking ramp of the spindle (M3, M4, M5) that differ from those for the axis acceleration (**MP\_maxAcceleration**). If this is the case, then enter the parameters. If the two parameters are not entered, then as a default the value from **MP\_maxAcceleration** is used.



### MP\_maxAccSpeedCtrl

Optional acceleration for the spindle with shaft speed control  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 0.000 000 000 to 1000 [1000°/s<sup>2</sup>]

This parameter is only effective for spindles. If 0 is entered or there is no parameter, the acceleration from **MP\_maxAcceleration** is used.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

### MP\_maxDecSpeedCtrl

Optional braking ramp for the spindle with shaft speed control  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 0.000 000 000 to 1000 [1000°/s<sup>2</sup>]

This parameter is only effective for spindles. If the value 0 is entered or the parameter is not available, the value from **MP\_maxAccSpeedCtrl** will be used for the brake acceleration. If **MP\_maxAccSpeedCtrl** is also 0 or not present, the value from **MP\_maxAcceleration** will be used.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

There are two ways to configure the maximum jerk on the path:

- **MP\_maxPathJerk(Hi)** (829) limits the jerk in the direction of traverse.
- **MP\_axTransJerk** limits the jerk for specific axes in the transverse path direction (transition jerk).

If the emphasis of commissioning is primarily on speed (with a sufficiently smooth surface), you can set the transition jerk to a value that is 2 to 3 times higher than the path jerk. Only if a smooth surface takes highest priority should you use the same setting for both the path jerk and the transition jerk.

### MP\_axTransJerk

Maximum axis jerk

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 1 000 000 [m/s<sup>3</sup>]

Default: 0.1 [m/s<sup>3</sup>]

Access: LEVEL3

Reaction: RUN

Two axis-specific jerk parameters are available for very high requirements on the surface quality. With the parameters **MP\_axPathJerk** and **MP\_axPathJerkHi** (rapid traverse) you limit the axis-specific jerk on path contours.

Regardless of the values of these two parameters, the values defined in **MP\_maxPathJerk** and **MP\_maxPathJerkHi** (829) are always the maximum limits for the jerk in traverse direction. You should therefore set **MP\_maxPathJerk** and **MP\_maxPathJerkHi** to a value that is at least 1.75 times greater than the greatest value in **MP\_axPathJerk** and **MP\_axPathJerkHi** to ensure maximum flexibility for jerk calculation, while taking all traverse components of the axes into account. This ensures that only the axis-specific jerk values go into effect.

**MP\_axPathJerk** and **MP\_axPathJerkHi** have a large influence on the running smoothness, surface quality and machining time.

The MANUALplus 620 ensures that the nominal values do not exceed the permissible axis jerk.

Adjusting **MP\_axPathJerk** and **MP\_axPathJerkHi**:

- ▶ A suitable NC program should be used for the adjustment. The NC programs "ff\_100\_[axis].nc" are already available on the control for feedforward adjustment. Record the following error **s-diff** and the jerk **j-nom** caused by a change in the feed rate ("ramp"), e.g. from 100 to 1000 mm/min.



#### Note

Recording the jerk is especially useful, because it allows you to check whether there is actually a change in the jerk of the axis after **MP\_axPathJerk** has been changed. If the change in feed rate is too great, it may happen that the maximum acceleration rather than the jerk limits the ramp.

- ▶ Modify the setting in **MP\_axPathJerk** until the resulting following error is just acceptable enough.
- ▶ The value set in **MP\_axPathJerkHi** is typically five times higher than that in **MP\_axPathJerk**.



#### Note

The following error **s-diff** should be no more than a few micrometers ( $\mu\text{m}$ ) to ensure smooth surfaces during acceleration and deceleration. If speed is required, the parameter can be increased until the machine gets loud, or the following error **s-diff** too large.



#### Note

In the above procedure, which uses feed rate changes instead of only positioning movements, disturbances from sliding friction and stiction transitions are avoided.



- ▶ The following formula can be used to calculate a proposed value for **MP\_axPathJerk**. The formula is conceived for the calculated jerk to be large enough that the acceleration of the axis is not impaired.

$$\text{MP\_axPathJerk} \geq \frac{\text{MP\_maxAcceleration}^2 \cdot 60000}{\text{MP\_rapidFeed}}$$



Note

HEIDENHAIN recommends entering the permissible jerk for each axis in **MP\_axPathJerk** and **MP\_axPathJerkHi**. This way the jerk is based on the weakest axis participating in a motion.



Note

Please also note the guideline on setting the nominal position value filters and the look-ahead starting on page XXX.

**MP\_axPathJerk**

Axis-specific maximum jerk on path contours  
Available from NCK software version: 597 110-04.

Format: Numerical value  
Input: 0 to 1 000 000 [m/s<sup>3</sup>]  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

**MP\_axPathJerkHi**

Axis-specific maximum jerk during rapid traverse

Format: Numerical value  
Input: 0 to 1 000 000 [m/s<sup>3</sup>]  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN



**Reduction of the  
contouring feed  
rate at the  
beginning of a  
contour element**

Settings in the configuration editor	MP number
Channels ChannelSettings [Key name of the machining channel] CfgLaPath <b>reduceCornerFeed</b>	201516

The new, optional parameter **MP\_reduceCornerFeed** was introduced with NCK software version 597 110-05 (MLST 5) With this parameter you can activate or deactivate a reduction of the contouring feed rate at the beginning of any contour element.

The setting **MP\_reduceCornerFeed = TRUE** reduces the contouring feed rate at the beginning of a contour element. This may improve the accuracy, but also results in a longer machining time.

If a short machining time is more important than high accuracy, you should set **MP\_reduceCornerFeed** to the value **FALSE**. This way the contouring feed rate at contouring elements is not reduced and the machining time is shorter.

**MP\_reduceCornerFeed**

Reduction of the contouring feed rate at the beginning of a contour element

Available from NCK software version: 597 110-05.

Format: Selection menu

Selection: **TRUE**

Reduction of contouring feed rate active  
(slower but more accurate if required)

**FALSE**

Reduction of contouring feed rate not active  
(fast, but can be a little less accurate)

Default: TRUE

Access: LEVEL3

Reaction: RUN





## Tolerance for rotary axes

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgLaAxis <b>axFilterErrWeight</b>	401702

The parameter object CfgLaAxis is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)

The filter error for a rotary axis with a large radius can be multiplied by a factor. Weighting the factor smoothes the feed-rate profile for the rotary axis.

By enlarging the value of the rotary axes, the tolerance of these axes has a more stringent effect and the error of the tool center point becomes smaller.

Reducing the value is also useful if the filter error of an axis has only a minor influence on the workpiece.

Enter **MP\_axFilterErrWeight** = 1 for linear axes.

**MP\_axFilterErrWeight** is evaluated for smoothing the contour.

### **MP\_axFilterErrWeight**

Factor for filter error (for rotary axes)

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.010 000 000 to 100

For linear axes: 1

Default: 1

Access: LEVEL3

Reaction: RUN

## 6.16.5 Interpolator

Settings in the configuration editor	MP number
System CfgCycleTimes <b>ipoCycle</b>	100301

The interpolator operates at the clock rate defined in **MP\_ipoCycle**. The axis-specific nominal position values are calculated at this clock rate from the feed rate profiles transferred by look-ahead.

### MP\_ipoCycle

Cycle time of position controller (interpolation clock pulse)

Format: Selection menu

Selection: 3 ms


At this time only a position controller cycle time of 3 ms is supported. Therefore no other values can be selected.

Default: 3 ms

Access: LEVEL3

Reaction: RESET

Schematic of the Interpolator:



## 6.16.6 Position controller

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPosControl <b>kvFactor</b> <b>feedForwardFactor</b> <b>controlOutputLimit</b>	    400801 400806 400807

The parameter object **CfgPosControl** is not required for:

- Virtual axes (**MP\_axisMode**=Virtual)
- Axes that are for display only (**MP\_axisMode**= Display)

The position controller uses the axis-specific nominal position values transferred by the interpolator. The nominal speed values are determined and transferred to the speed controller.

### Feedback control

The MANUALplus 620 operates with following error (servo lag) or with velocity feedforward. It is defined in **MP\_feedForwardFactor**.

- If **MP\_feedForwardFactor** = 0, operation with 100 % following error is in effect.
- **MP\_feedForwardFactor** = >0 activates velocity semifeedforward control (for analog axes).
- If **MP\_feedForwardFactor** = 1, machining will be carried out using 100 % velocity feedforward control (for digital axes).

With analog control, the shaft speed nominal value is calculated with the following formula:

$$U_{out} = (P_{err} \cdot kvFactor + \frac{V_{nom}}{60} \cdot feedForwardFactor + 1000 \cdot A_{nom} \cdot accForwardFactor) \cdot \frac{9V \cdot 60}{maxFeedAt9V}$$

Simplified:

$$U_{\text{out}} = \text{MP\_kvFactor} \cdot P_{\text{err}} + V_{\text{nom}} \cdot \text{MP\_feedForwardFactor}$$

Value, parameter	Unit	Description
$U_{\text{out}}$	Volt	Output voltage (analog nominal speed value)
$P_{\text{err}}$	mm	Following error (servo lag)
kvFactor	1/s	Kv factor (proportional component of position controller)
$V_{\text{nom}}$	mm/min	Nominal velocity
feedForwardFactor		Factor for velocity feedforward control
$A_{\text{nom}}$	$\text{m/s}^2$	Nominal acceleration
accForwardFactor	(s)	Factor for acceleration feedforward control
maxFeedAt9V	mm/min	Assumed velocity of the axis at 9 V

### MP\_feedForwardFactor

Factor for velocity feedforward control

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: **0**: Feedback control with following error

**>0,<1**: Feedback control with velocity semifeedforward

**1**: Feedback control with velocity feedforward

Default: 1

Access: LEVEL3

Reaction: RUN




#### Note

For axes that are interpolated with each other, the  $k_v$  factor and the factor for velocity feedforward control must be equal. In this case the smaller  $k_v$  factor determines the input value for all axes.

## Feedback control with following error

Following error (also known as servo lag) is a gap that remains between the nominal position commanded by the NC and the actual position of the axis.

Simplified representation:



The nominal position value  $s_{noml}$  for a given axis is compared with the actual position value  $s_{actl}$  and the resulting difference is the following error  $s_a$ :

$$s_a = s_{noml} - s_{actl}$$

$s_a$  = following error

$s_{noml}$  = nominal position value

$s_{actl}$  = actual position value

The following error is multiplied by the  $k_v$  factor and passed on as nominal velocity value:

$$v = k_v \cdot s_a$$

$v_{noml}$  = nominal velocity value

The control loop gain, known as the  $k_v$  factor, defines the amplification of the position control loop. You must find the optimum  $k_v$  factor by trial and error.

If you choose a  $k_v$  factor that is too large, the following error will become very small. However, this can lead to oscillations.

If you choose too small a  $k_v$  factor, the axis will move to a new position too slowly.

For axes that are interpolated with each other, the  $k_v$  factors must be equal to prevent contour deviations.

► Define the  $k_v$  factor in **MP\_kvFactor**.

## Interrelation of $k_v$ factor, feed rate, and following error

The following formula shows the interrelation of  $k_v$  factor, feed rate, and following error:

$$k_v = \frac{v_e}{s_a} \quad \text{or} \quad s_a = \frac{v_e}{k_v}$$

$k_v$  = kv factor [(mm/s)/mm]

$v_e$  = rapid traverse [mm/sec]

$s_a$  = following error [mm]



### Note

The unit for the  $k_v$  factor of the MANUALplus 620 differs from the one used for the other TNC contouring controls, such as the iTNC 530.

**Unit for the  $k_v$  factor of the MANUALplus 620: mm / (mm · s)**

**Unit for the  $k_v$  factor of the iTNC 530: m / (mm · min)**

Therefore:

**iTNC 530 kv factor · 1000 / 60 = MANUALplus 620 kv factor**

### MP\_kvFactor

kv factor (proportional component of the position controller)

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 1000 [1/s]

Default: 0

Access: LEVEL3

Reaction: RUN



## Controller output limit

The controller output limit **MP\_controlOutputLimit** is used only during switch-on of position control without actual-to-nominal value transfer. Example:

Clamped or hanging axes cause a following error when the position control loop is open. When closing the control loop without actual-to-nominal value transfer, this difference in the position is corrected by the MANUALplus 620. The deviation is corrected at the maximum feed rate entered in **MP\_controlOutputLimit**.



### Note

The axis parameters entered for jerk and acceleration have no effect. Enter only values that are non-critical to the axis.

HEIDENHAIN recommends:

In **MP\_controlOutputLimit**, enter a value that is approximately  $0.1 \cdot \text{MP\_manualFeed}$ .

If **MP\_controlOutputLimit** = 0, the resulting following error is not corrected until the next positioning block.

### MP\_controlOutputLimit

Controller output limit for the position controller  
Available from NCK software version: 597 110-01.


Format: Numerical value  
Input: 0.000 000 000 to 1666 [mm/min]  
Default: 0 [mm/min]  
Access: LEVEL3  
Reaction: RUN

## Feedback control with velocity feedforward

For feedback control with velocity feedforward, the nominal velocity value consists of an open-loop and a closed-loop component.


The machine-adjusted nominal velocity value is the open-loop controlled component. The closed-loop velocity component is calculated through the following error. The following error is small.

In most cases, machines are controlled with velocity feedforward, since it makes it possible to machine exact contours even at high speeds.



You can influence feedback control with velocity feedforward with the  $k_v$  factor:

- Enter a  $k_v$  factor in **MP\_kvFactor**.



#### Warning


If the  $k_v$  factor that you select is too large, the system will oscillate around the forward-fed nominal velocity value.

Unlike operation with following error, you must enter the optimum  $k_v$  factor for each axis when operating with interpolated axes (see "Interrelation of  $k_v$  factor, feed rate, and following error" on page 842).



## Rapid traverse and feed rate limitation

If more than one axis is moved simultaneously, the rapid traverse on the path  $v_{\text{path}}$  is formed from the appropriate axis components (see "Axis-specific limit values" on page 831).



- ▶ In **MP\_maxFeed**, define the maximum rapid traverse for this axis.

Feed rate and rapid traverse are significantly lower for **Manual Operation**:

- ▶ Define the feed rate for manual mode in **MP\_manualFeed**.
- ▶ Define the feed rate for rapid traverse in **MP\_rapidFeed**.

If the value in **PP\_ChnContourFeedMax** is greater than the value in **MP\_maxFeed**, the parameter value applies. After the MANUALplus 620 is switched on, or after an interruption of the PLC program, **PP\_ChnContourFeedMax** is assigned the value 300 000 so that the value in **MP\_maxFeed** automatically becomes effective.



### Note

The absolute maximum velocity of this axis is defined in **MP\_maxFeed**. This value is not exceeded.

The maximum possible feed rate depends on the encoder being used.

$$v_{\text{max}} [\text{mm}/\text{min}] = P [\text{mm}] \cdot f_i [\text{kHz}] \cdot 60$$

$v_{\text{max}}$  = Maximum traversing speed

$P$  = Signal period of the encoder

$f_i$  = Input frequency of the encoder input, see "Encoder Connections" on page 242.

### Digital axes:

For digital axes, the maximum feed rate also depends on the number of pole pairs in the drive motor and the pitch of the ball screw.

$$v_{\text{max}} [\text{mm}/\text{min}] = \frac{24\,000}{\text{number of pole pairs}} [1/\text{min}] \times \text{ball screw pitch} [\text{mm}]$$

### Analog axes:

The rapid traverse rate at an analog voltage of 9 V is defined in **MP\_maxFeedAt9V**.

## Feed rate values in PLC operands

The feed rate values are stored in PLC operands (see the following tables).

The PLC can influence the following values:

- ▶ **PP\_ChnContourFeedMax:** Maximum feed rate
- ▶ **PP\_AxManualFeedMax:** Maximum axis feed rate in all operating modes  
Only effective for specific axes if the optional machine parameter **MP\_axisFeedDisplay** (CfgDisplayData) is set to the value **at axis key**. If the parameter is not set, the feed-rate value is effective globally for all axes.

The following PLC operands contain channel-specific feed rate values.

PLC operand / Description	Type
NN_ChnProgFeedMinute Programmed feed rate per minute [mm/min]	D
NN_ChnProgFeedRevolution Programmed feed rate per revolution [mm/rev]	D
NN_ChnProgFeedThread Programmed feed rate per thread [mm/rev]	D
NN_ChnFeedMinuteActive Feed rate per minute active 0: Feed rate per minute is not active. 1: Per-minute feed rate is active	M
NN_ChnFeedRevolutionActive Feed per revolution is active 0: Per-revolution feed rate is not active 1: Per-revolution feed rate is active	M
NN_ChnFeedThreadActive Feed rate per thread active 0: Thread feed rate is not active 1: Thread feed rate is active	M
NN_ChnFeedRapidTraverseActive Rapid traverse active (FMAX) 0: Rapid traverse is not active 1: Rapid traverse active	M
NN_ChnContourFeed Current contouring feed rate [mm/min] In the manual operating modes, the highest axis feed of all axes is stored in this operand	D
PP_ChnContourFeedMax Max. feed rate from the PLC [mm/min]	D

The following PLC operands contain axis-specific feed rate values.

PLC operand / Description	Type
PP_AxManualFeedMax Maximum axis feed rate in all operating modes [mm/rev] (Only effective for specific axes if the machine parameter <b>MP_axisFeedDisplay</b> (CfgDisplayData) is set to the value <b>at axis key.</b> ) If the parameter is not set, the feed-rate value is effective globally for all axes.	D
PP_AxTraversePos Manual traverse in positive direction 0: Do not move axis 1: Move axis	M
PP_AxTraverseNeg Manual traverse in negative direction 0: Do not move axis 1: Move axis	M

**Position loop resolution for digital axes**

The encoder signals are interpolated 1024-fold.


$$\text{Position loop resolution } [\mu\text{m}] = \frac{\text{signal period } [\mu\text{m}]}{1024}$$



## 6.16.7 Activating and deactivating position control loops

### Opening the position control loop

The following figure shows the procedure for switching on the drive motor and activating the position control loop as well as the procedure for opening the position control loop and deactivating the drive.




PLC operand / Description	Type
<b>NN_AxDriveReady</b> Axis drive is ready 0: Drive not ready for operation 1: Drive ready for operation	M
<b>PP_AxDriveOnRequest</b> Switch axis drive on 0: Do not activate the drive 1: Activate the drive	M
<b>NN_AxDriveOn</b> Axis drive is switched on (and is at least speed-controlled) 0: Drive is off 1: Drive is on	M
<b>PP_AxPosControlRequest</b> Position-control the axis 0: No position feedback control for axis 1: Position feedback control for axis	M
<b>NN_AxPosControl</b> Axis in position feedback control 0: Axis not in position feedback control 1: Axis in position feedback control	M

## Clamping the axes

After running an NC block you can clamp the axes.

The MANUALplus 620 considers an axis to be clamped as soon as position control is switched off, i.e. as soon as **NN\_AxPosControl** decreases towards 0. The PLC uses the signal **NN\_AxInPosition** to determine whether an axis movement is pending.

The following figure shows the procedure for clamping the axes as well as for unclamping them.



If **NN\_AxInPosition** is set, no further movement of the respective axis is pending. The PLC must initiate a clamping operation if **PP\_AxClampModeRequest** is set.

As illustrated in the figure, first the axis is clamped, then position control is switched off, and finally the drive is switched off. The MANUALplus 620 resumes NC program run as soon as position control is switched off.

If **NN\_AxInPosition** decreases, the axis should be moved. The PLC initiates the unclamping operation for the respective axis. As illustrated in the figure, first the drive is switched on, then the clamping is released, and then position control is activated. The MANUALplus 620 resumes NC program run as soon as position control is switched on.

For clamped axes the PLC program must set the **PP\_AxClampModeRequest** signal shortly before unclamping at the latest, so that the MANUALplus 620 can distinguish the clamped axis from the normal axes and, at the end of the movement, waits for the axis to be clamped again.



Note

When switching an axis between clamped and unclamped mode, the following constraints apply:

The PLC program must ensure that **PP\_AxClampModeRequest** and **PP\_AxDriveOnRequest** are not switched during a movement. By removing **PP\_AxFeedEnable** of all NC axes, the PLC program can prevent motions, for example. Otherwise, the error message **Axes switched while in motion** can occur.

**Clamping mode with active handwheel**

If a handwheel is active for an axis in clamping mode, the axis may remain switched on even if no further programmed movement of this axis is pending, i.e. **NN\_AxInPosition** is set.

For axes in clamping mode, the handwheel should not be activated during a movement.

PLC operand / Description	Type
PP_AxClampModeRequest Axis in clamping mode. Indicates that the MANUALplus 620 must wait at the end of the axis motion until the axis is clamped. 0: No clamping mode Axis is to remain continuously in a closed loop 1: Clamping mode Axis is to be clamped as soon as it is no longer moved (NN_AxInPosition=1) Axis is to be unclamped when it is to be moved (NN_AxInPosition=0)	M
NN_AxInPosition Axis in position 0: Axis not in position 1: Axis in position	M



## Actual-to-nominal value transfer

During actual-to-nominal value transfer, the current position is saved as the nominal position value. This becomes necessary, for example, if the axis has been moved when the position control loop is open.

There are two ways to turn the actual position into the nominal position:

- ▶ Place the request for actual-to-nominal value transfer in the **Manual** and **Electronic Handwheel** operating modes in **PP\_AxValueActToNominal** and check the elimination of the following error in **NN\_AxCorrectingLagError**.
- ▶ To transfer the actual position in all operating modes, use Module 9145.

PLC operand / Description	Type
PP_AxValueActToNominal Actual-to-nominal value transfer (Request to eliminate following error) 0: Request to eliminate following error 1: No request to eliminate following error	M
NN_AxCorrectingLagError Following error eliminated 0: Following error is not eliminated 1: Following error is eliminated	M

### Module 9145 Actual-to-nominal value transfer

Module 9145 is used for an actual-to-nominal value transfer for the axes entered.

Constraints:

- The module functions only in the cyclic PLC program.
- An actual-to-nominal value transfer is possible only if the MANUALplus 620 is not active (NN\_ChnControlInOperation=0) or if an M/S/T/T2/G strobe is pending. Actual-to-nominal value transfer can always be performed for axes that are not in an interpolation context.

Call:

PS B/W/D/K <>Axes bit-encoded>  
(Bit 0 represents logic axis 0, etc.)

CM 9145

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Actual-to-nominal value transfer performed
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid axis number
	21	Missing M/S/T/T2/G strobe in NN_ChnControlInOperation=1
	24	Module was called in a spawn or submit job

## 6.16.8 Feed-rate enable

To move the axes, you must first enable the feed rate through the PLC. Until "feed-rate enable" is set, the nominal velocity value zero is output. The status display shows that the feed rate enable is set / not set.

You can set the feed rate enable for all axes of the NC channel or for specific axes. The PLC run-time system combines **PP\_ChnFeedEnable** and the corresponding axis-dependent feed rate enable **PP\_AxFeedEnable** with an OR gate.

Feed-rate enable for all axes of an NC channel:

- ▶ Set **PP\_ChnFeedEnable**

Axis-specific feed-rate enable:

- ▶ Reset **PP\_ChnFeedEnable**

- ▶ Set **PP\_AxFeedEnable**

Feed-rate enable for axes that are not assigned to any NC channel, e.g. PLC axes:

- ▶ Set **PP\_AxFeedEnable**

PLC operand / Description	Type
PP_ChnFeedEnable Feed-rate enable for all axes of the NC channel: 0: No feed-rate enable 1: Feed-rate enable	M
PP_AxFeedEnable Axis-specific feed-rate enable 0: No feed-rate enable 1: Feed-rate enable	M

The PLC sets **PP\_ChnWorkFeedEnable** if rapid traverse movements are allowed. This marker is set, for example during a tool change or turret actuation, in order to use the time for rapid-traverse movements. During the first PLC scan after the compilation of the PLC program, **PP\_ChnWorkFeedEnable** is set to the value 1. This ensures that contouring feed rates are also permitted if the PLC program does not activate the marker.

PLC operand / Description	Type
PP_ChnWorkFeedEnable Enables the contouring feed rate 0: Contouring feed rate not enabled, only G0 movements permitted (rapid traverse enable) 1: Contouring feed rate enabled	M





## 6.16.9 Speed controller


Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgSpeedControl <b>vCtrlPropGain</b> <b>vCtrlIntGain</b> <b>vCtrlDiffGain</b>	   400901 400902 400904

The parameter object CfgSpeedControl is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)
- Analog axes (MP\_axisHw=Analog)

The actual speed values are measured directly at the motors with HEIDENHAIN rotary encoders. The position controller provides the nominal speed value. The speed controller is driven by the difference between nominal and actual speed values. It provides the nominal current value as output.

Use Module 9164 to read the actual speed value of the motors.



Adjust the step response of the speed controller:

- ▶ With the position controller switched off (**PP\_AxPosControlRequest**), enter with **MP\_VCtrlPropGain** a proportional factor and with **MP\_VCtrlIntGain** an integral factor for the speed controller. Adjust the step response so that only one overshoot is visible and the settling time  $t_{off}$  is as small as possible.  
Realistic values for the settling time: 3 ms to 15 ms.

### **MP\_vCtrlPropGain**

Proportional factor of the speed controller  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 1 000 000 [As/rev.]  
Default: 1 [As/rev.]  
Access: LEVEL3  
Reaction: RUN

### **MP\_vCtrlIntGain**

Integral factor of the speed controller  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 10 000 000 [A/rev.]  
Default: 100 [A/rev.]  
Access: LEVEL3  
Reaction: RUN



### Module 9164 Read the actual speed value of the drive motor

The module provides the actual speed value of a motor controlled by an integral current controller in 1/1000 revolutions per minute.

The resolution of the actual speed value depends on the encoder being used:

$$\text{Resolution} = \frac{1}{\text{line count} \cdot 1024} \cdot 100\,000 \text{ [min}^{-1}\text{]}$$

Constraints:

- The value 0 is read for axes that are not connected.
- For motors in volts-per-hertz (U/f) control mode, the module returns the nominal speed value (vnnoml) since there is no actual-value encoder.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Call:


PS B/W/D/K <>Axis>  
Index from CfgAxes/axisList

CM 9164

PL B/W/D <>Actual speed value in the format 0.001 [min<sup>-1</sup>]>

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Actual speed value was read
Error (M4203)	1	Control has no integrated current controller



The step response illustrated above is idealized. In practice, interfering oscillations are superimposed on the step response.

You can reduce these interference oscillations with the differential factor, the  $PT_2$  second-order time-delay element, the band rejection filter and the low-pass filter of the speed controller.

### Differential factor

The differential factor reduces low-frequency oscillations. However, it increases the tendency to oscillate in the high frequency range.

► In **MP\_vCtrlDiffGain**, enter a differential factor.



#### Note

Ensure that the system is stable enough!

The differential factor is not recommended on machines with motors that have belt couplings. The influence of aging and temperature is too great.

Estimating the differential factor:

$$MP\_vCtrlDiffGain \approx \frac{T \cdot MP\_vCtrlPropGain}{8}$$

**MP\_vCtrlDiffGain:** Differential factor of the speed controller [As<sup>2</sup>]

**MP\_vCtrlPropGain:** Proportional factor of the speed controller

T: Period duration of the lowest disturbance frequency [s]

#### MP\_vCtrlDiffGain

Differential factor of the speed controller

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 1 [As<sup>2</sup>/rev.]

Default: 0 [As<sup>2</sup>/rev.]

Access: LEVEL3

Reaction: RUN





Note

The filters in the speed control loop of the CC 422 and CC 61xx/CC 424 differ in their organization. This chapter describes the filter functions available when using the CC 61xx and CC 424.

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgSpeedControl	
<b>vCtrlFiltLowPassT</b>	400905
<b>vCtrlEnclInputFilt</b>	400906
<b>vCtrlFiltLowPassT</b>	400905
<b>vCtrlFiltDamping1</b>	400910
<b>vCtrlFiltDamping2</b>	400914
<b>vCtrlFiltDamping3</b>	400918
<b>vCtrlFiltDamping4</b>	400922
<b>vCtrlFiltDamping5</b>	400926
<b>vCtrlFiltFreq1</b>	400908
<b>vCtrlFiltFreq2</b>	400912
<b>vCtrlFiltFreq3</b>	400916
<b>vCtrlFiltFreq4</b>	400920
<b>vCtrlFiltFreq5</b>	400924
<b>vCtrlFiltType1</b>	400907
<b>vCtrlFiltType2</b>	400911
<b>vCtrlFiltType3</b>	400915
<b>vCtrlFiltType4</b>	400919
<b>vCtrlFiltType5</b>	400923
<b>vCtrlFiltBandWidth1</b>	400909
<b>vCtrlFiltBandWidth2</b>	400913
<b>vCtrlFiltBandWidth3</b>	400917
<b>vCtrlFiltBandWidth4</b>	400921
<b>vCtrlFiltBandWidth5</b>	400925

The parameter objects CfgSpeedControl and CfgControllerComp are not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)
- Analog axes (MP\_axisHw=Analog)



## Multifunction filter

With the CC 61xx and CC 424, you can influence the manipulated variable of the speed controller (= nominal current) and the position controller (= nominal speed) by means of up to five freely definable filters per axis. These filters are multifunctional filters, which means that the filter type of each individual filter order can be selected as desired. They are also effective for the spindle(s).

## Objective of the filters

The first objective when adjusting a machine is the optimization of the control loop in the current and speed controller. The increase of the P component of the control loops in order to raise the dynamics of the machine is the main aspect of this. If a control loop is at the oscillation limit, these oscillations can be damped with filter functions, so that the P components can be increased again.

The second objective when adjusting a machine is the optimization of the position controller. Here it is attempted to increase the  $k_V$  factor in the position controller, in order to simultaneously increase the machine's performance (the acceleration behavior, for example). The procedure is always to increase the  $k_V$  factor to the oscillation limit, damp these oscillations with the filters, and then increase the  $k_V$  factor again.

## Types of filters

Three different types of filters per axis are available for selection:

### ■ PT2 low-pass

- Use:
  - Oscillations in the upper frequency range (typically: from 500 Hz)
  - High-frequency noises on axes (such as during switch-on)

### ■ Band-rejection filter

- Use:
  - Oscillations in the middle frequency range (typically: between 100 Hz and 2.5 Hz)
- Typical settings:
  - Damping from 6 dB to 9 dB
  - Bandwidth: equal to the center frequency, constant from 500 Hz
- Disadvantage:
  - These can strengthen oscillations in the lower frequency range

### ■ Phase increase

- Use:
  - Oscillations in the lower to middle frequency range, which occur because of an insufficient phase reserve
  - Oscillations in the lower frequency range, for which band rejection would excessively decrease the amplitude
- Typical settings:
  - Phase from 20° to 80°
  - Center frequency: Frequencies from 3 Hz to 400 Hz
  - Bandwidth: Equal to the center frequency (oscillation frequency)
- Disadvantage:
  - The control-loop gain above the center frequency is increased. The increased use of band-rejection filters can become necessary, or the P component might need to be reduced.
- Note: After the settings have been made, the stability of the control loop must be checked again (P and I component)

## Recommended types of filters

Experience has shown that the band rejection of the multifunction filters is to be used for damping oscillations in the **speed controller**.

On the other hand, the tendency of the **position controller** to oscillate should be counteracted with IPC (Integral Phase Compensation). Only if this adjustment does not lead to the desired result can the multifunction filters such as the phase increase (better, since it does not facilitate oscillations at lower frequencies as much) or the band-rejection filter be used.

Since the ambient conditions can be so different, the use of the filters must be checked separately in every case. The TNCopt PC software from HEIDENHAIN should always be used, so that the sequence of the adjustment matches the ideal case. This manual can only present recommended guidelines and procedures.

## Possible multifunction filter settings

	Filters 1 to 5
Selection of filter type: <b>0</b> = Filter not active <b>1</b> = PT2 low-pass filter (speed controller) <b>2</b> = Band-rejection (speed ctrl.) <b>3</b> = Phase increase (speed ctrl.) <b>11</b> = PT2 low-pass filter (position controller) <b>12</b> = Band-rejection (position ctrl.) <b>13</b> = Phase increase (position ctrl.)	<b>MP_vCtrlFiltType1...5</b>
<ul style="list-style-type: none"> <li>■ <b>PT2 low-pass filter:</b> No effect</li> <li>■ <b>Band rejection:</b> Damping [dB]</li> <li>■ <b>Phase increase:</b> Phase [0 - 90°]</li> </ul>	<b>MP_vCtrlFiltDamping1...5</b>
<ul style="list-style-type: none"> <li>■ <b>PT2 low-pass filter:</b> Corner frequency [Hz]</li> <li>■ <b>Band-rejection:</b> Center frequ. [Hz]</li> <li>■ <b>Phase increase:</b> Center frequency [Hz]</li> </ul>	<b>MP_vCtrlFiltFreq1...5</b>
<ul style="list-style-type: none"> <li>■ <b>PT2 low-pass filter:</b> No effect</li> <li>■ <b>Band-reject.:</b> Bandwidth [Hz]</li> <li>■ <b>Phase increase:</b> Bandwidth [Hz]</li> </ul>	<b>MP_vCtrlFiltBandWidth1...5</b>

The filters can be used in the position controller or speed controller as desired. For example, the second filter can be used although the first filter is not active.

- ▶ In **MP\_vCtrlFiltType1...5**, define the filter type and specify whether the filter is to take effect in the speed controller or in the position controller. The other parameters to be entered depend on the filter type:
- ▶ Enter **MP\_vCtrlFiltFreq1...5** to set a **PT2 second-order time-delay element**. Enter a cutoff frequency of 3 dB as parameter value.
- ▶ The parameters **MP\_vCtrlFiltFreq1...5**, **MP\_vCtrlFiltBandWidth1...5** and **MP\_vCtrlFiltDamping1...5** are required to set a **band-rejection filter**.

## Machine parameters

### MP\_vCtrlFiltType1...5

Filter type for filters 1 to 5  
Format: Numerical value  
Input: 0 to 3  
0: No filter  
1: PT<sub>2</sub> low-pass filter (speed controller)  
2: Band-rejection filter (speed ctrlr.)  
11: PT<sub>2</sub> low-pass filter (position controller)  
12: Band-rejection filter (position ctrl.)  
Default: 0  
Access: LEVEL3  
Reaction: RUN

### MP\_vCtrlFiltFreq1...5

Center frequency of band-rejection filter for filters 1 to 5  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 5000 [Hz]  
Default: 0 [Hz]  
Access: LEVEL3  
Reaction: RUN

### MP\_vCtrlFiltBandWidth1...5

Bandwidth of band-rejection filter for filters 1 to 5  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 5000 [Hz]  
Default: 0 [dB]  
Access: LEVEL3  
Reaction: RUN

### MP\_vCtrlFiltDamping1..5

Damping of band-rejection filter for filters 1 to 5  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 40 [dB]  
Default: 0 [dB]  
Access: LEVEL3  
Reaction: RUN





## 6.16.11 Filter order for separate low-pass filter in the speed controller on the CC 61xx and CC 424:

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgSpeedControl <b>vCtrlEnclInputFilt</b>	400906

### Application

If a low-pass filter is used with the CC 61xx or CC 424, the filter order of the low-pass filter can be set in **MP\_vCtrlEnclInputFilt**. Enter `MP_vCtrlEnclInputFilt=0` under standard conditions.

**Spindle:** High-frequency spindles often cause considerable current noise (shown by **I nom** or **Utilization** on the oscilloscope). The optimization goal is as little current noise as possible at high spindle speeds. `MP_vCtrlEnclInputFilt = 10 to 20` should be used as a starting value.

**Axes:** The low-pass filter should be used if the actual speed has "a lot of noise," for example `MP_vCtrlEnclInputFilt = 1 or 2`. If there is no improvement, set `MP_vCtrlEnclInputFilt = 0`.

For adjustment of the filters, see "Filters in the speed controller and position controller when using the CC 61xx and CC 424" on page 857.

### Machine parameters

#### MP\_vCtrlEnclInputFilt

Filter order of the FIR filter (low-pass filter)  
 Available from NCK software version: 597 110-01.

Format: Numerical value  
 Input: 0 to 20  
 0: No low-pass filter  
 1: 1st-order low-pass filter  
 . . .  
 20: 20th-order low-pass filter

Default: 0  
 Access: LEVEL3  
 Reaction: RUN

## 6.16.12 Peculiarities in weakened-field operation with CC 61xx and CC 424


### Reduction of the magnetization current

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgCurrentControl <b>iCtrlMotVRedFact</b>	401005

Some of the asynchronous spindle motors require a high magnetizing current at low speeds ( $n < n_{\text{field weakening}}$ ). This magnetizing current can, however, lead to thermal motor problems at the rpm for field weakening  $n_{\text{FW}}$  when there is no load.

The nominal voltage (and so also the nominal magnetization current) at the rpm for field weakening  $n_{\text{FW}}$  when there is no load can be reduced with **MP\_iCtrlMotVRedFact**. The entered reduction results in a nominal voltage curve as shown in the figure below. The maximum nominal voltage is reached when  $n = 3 \cdot n_{\text{field weakening}}$ . The nominal voltage can be reduced by max. 60 % (**MP\_iCtrlMotVRedFact** = 60).

If a load is placed on the drive, then the nominal voltage is increased again automatically in order to improve the dynamics.



### MP\_iCtrlMotVRedFact

Factor for the reduction of the magnetization current during idle running (only as of CC 61xx)

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0 to 60 [%]

0: Function inactive

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN



#### Note

Please note that the reduction of the magnetization current can lead to a limitation of the drive's dynamics. However, this depends on the drive, and must be judged separately in each case.

### Setting the reduction of the magnetization current

If thermal problems arise on an asynchronous spindle with no load during weakened-field operation, and these problems cannot be traced to an overload or other mechanical problems, then please reduce the magnetization current as follows:

- ▶ Reduce the nominal voltage in steps of 10% in MP\_iCtrlMotRedFact
- ▶ Reduce MP\_iCtrlMotRedFact until a stable temperature within the motor specifications is reached when there is no load.

### 6.16.13 Active damping of low-frequency oscillations



#### Note

This function is **not** available for a CC 61xx or UEC 11x!

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgControllerComp	
<b>compActDampFact</b>	401409
<b>compActDampTime</b>	401410

The active damping of low-frequency oscillations is suitable for damping noise oscillations of approx. 10 to 30 Hz. The damping factor is set in **MP\_compActDampFact**, and the damping time constant in **MP\_compActDampTime**. It can be calculated according to the following formula:

$$MP\_comActDampTime = \frac{k}{2 \cdot \pi \cdot f}$$

k: Factor from 0.8 to 1.0

f: Frequency to be damped (approx. 10 Hz < f < 30 Hz)



#### Note

The active damping should only be used if improvements actually occur, since the damping could also lead to lower and higher frequencies being fortified.

Activating the active damping:

- ▶ Ascertain the deepest resonant frequency (e.g. with the frequency diagram in TNCOpt when adjusting the IPC and  $k_V$  factor).
- ▶ Set **MP\_compActDampFact** = 1.5.
- ▶ Calculate the damping time constant according to the above formula with k = 0.9, and enter this value in MP\_compActDampTime.
- ▶ Record **I (n int)** or **s diff** with the integrated oscilloscope, and move the axis with the axis-direction buttons.
- ▶ Vary the value of k up and down somewhat (between 0.8 and 1.0), calculate **MP\_compActDampTime** and compare the oscilloscope recordings in order to find the correct value for **MP\_compActDampTime** (the value with the lowest amplitude).
- ▶ Vary **MP\_compActDampFact**, and compare with the recordings in the frequency diagram in TNCOpt for the adjustment of the IPC and  $k_V$  factor.
- ▶ Select the value for **MP\_compActDampFact** by evaluating the advantages and disadvantages of the active damping.



**MP\_compActDampFact**

Damping factor for active damping  
Available from NCK software version: 597 110-02.

Format: Numerical value  
Input: 0 to 30.000  
0: No damping  
1.5: Typical damping factor

Default: No value, parameter optional (= 0)  
Access: LEVEL3  
Reaction: RUN

**MP\_compActDampTime**

Damping time constant for active damping  
Available from NCK software version: 597 110-02.

Format: Numerical value  
Input: 0 to 0.9999 [s]  
0: No damping  
0.005 to 0.02: Typical damping time constant

Default: No value, parameter optional (= 0)  
Access: LEVEL3  
Reaction: RUN

### 6.16.14 Acceleration feedforward control

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgControllerComp <b>compAcc</b>	401406


The parameter object CfgControllerComp is not required for:


- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)
- Analog axes (MP\_axisHw=Analog)

Acceleration feedforward functions only in velocity feedforward control in parallel with the speed controller.

At every change in velocity, spikes of short duration appear in the following error. With acceleration feedforward control you can minimize these spikes:

- ▶ First adjust the friction compensation (see "Compensation of sliding friction" on page 724).
- ▶ From the integral-action component of the nominal current value I (N INT) calculate the input value for **MP\_compAcc**.
- ▶ Adjust the acceleration feedforward control with MP\_compAcc.





For calculation of the acceleration feedforward, the integral-action component of the nominal current value I (N INT) is recorded with the internal oscilloscope. The actual speed value V (ACT RPM) and nominal current value I (NOM) are also recorded for better illustration.

$$\text{MP\_compAcc} = \frac{I \text{ (N INT) [A]} \cdot t \text{ [s]} \cdot 60 \text{ [s/min]} \cdot \text{MP\_distPerMotorTurn [mm]}}{\Delta V \text{ (N IST) [mm/min]}}$$

I (N INT) = integral-action component of the nominal current value

t = acceleration time in which I (N INT) remains constant

$\Delta V$  (ACT RPM) = actual-speed-value change

**MP\_distPerMotorTurn** = traverse distance per motor revolution

### **MP\_compAcc**

Acceleration feedforward control

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 6 [As<sup>2</sup>]

Default: 0

Access: LEVEL3

Reaction: RUN

## Limiting the integral factor

In machines with a great deal of stiction, a high integral-action component can accumulate if there is a position error at standstill. This can result in a jump in position when the axis begins moving. In such cases you can limit the integral-action component of the speed controller:

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgSpeedControl <b>vCtrlIntTime</b>	400903

- ▶ Enter a limit in MP\_vCtrlIntTime.  
Realistic input values: 0.1 to 2.0

### MP\_vCtrlIntTime

Limit of integral factor of the speed controller  
Available from NCK software version: 597 110-02.

Format: Numerical value  
Input: 0.000 000 000 to 30 [s]  
Default: 0  
Access: LEVEL3  
Reaction: RUN





## 6.16.15 IPC, holding torque, following error in the jerk phase

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgControllerComp <b>compCurrentOffset</b> <b>complpcT1</b> <b>complpcT2</b> <b>complpcJerkFact</b>	    401405 401407 401408 401409

The parameter object **CfgControllerComp** is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)
- Analog axes (MP\_axisHw=Analog)

### Integral Phase Compensation (IPC)

Use the I factor **MP\_vCtrlIntGain** of the speed controller to attain a short settling time. However, the I factor has a negative influence on the position controller. The position controller is more likely to oscillate, which often makes it impossible to adjust the  $k_v$  factor **MP\_kvFactor** to the desired size.

The IPC compensates the negative influence of the I factor on the speed controller, and makes it **possible** to increase the  $k_v$  factor.

The IPC is beneficial on the following types of machines:

- Machine type 1: Machines with a dominant natural frequency between 15 Hz and 80 Hz, for which it is not possible to set a sufficiently high  $k_v$  factor.
- Machine type 2: Small-to-medium size machines that are driven directly.



#### Note

- The acceleration feedforward (**MP\_compAcc**) must already have been carefully adjusted for both types of machines.
- If after commissioning the IPC you wish to optimize the speed controller again, you must switch off the IPC beforehand, because the IPC influences the curve form.
- Use the same test program to commission the IPC as is used to measure the jerk and the  $k_v$  factor.

### Machine type 1:

- ▶ The machine is commissioned as usual until the  $k_V$  factor is to be determined.
- ▶ Enter **MP\_complpcT1** = 1 and **MP\_complpcT2** = 0.
- ▶ Increase the  $k_V$  factor (**MP\_kvFactor**) until you reach the oscillation limit.
- ▶ Starting value:  $MP\_complpcT2 = \frac{2}{3} \cdot \frac{MP\_compAcc}{MP\_vCtrlPropGain}$
- ▶ Change **MP\_complpcT2** until you have found the maximum  $k_V$  factor. If you cannot find a maximum  $k_V$  factor, use the default value.
- ▶ Starting value:  $MP\_complpcT1 = \frac{MP\_compAcc}{MP\_vCtrlPropGain}$
- ▶ Increase **MP\_complpcT1** until you have found the maximum  $k_V$  factor. If the value found is significantly greater than the starting value (> factor 2), you should adjust **MP\_complpcT2** again by enlarging and reducing it to find the optimum value.
- ▶  $MP\_kvFactor = 0.65 \cdot \text{determined } k_V$

### Machine type 2:

- ▶ The machine is commissioned as usual until the  $k_V$  factor is to be determined.
- ▶ Enter **MP\_complpcT1** = 1 and **MP\_complpcT2** = 0.
- ▶ Increase the  $k_V$  factor (**MP\_kvFactor**) until you reach the oscillation limit.
- ▶ Starting value:  $MP\_complpcT2 = \frac{2}{3} \cdot \frac{MP\_compAcc}{MP\_vCtrlPropGain}$
- ▶ Change **MP\_complpcT2**, normally by reducing it, until the following error is at its minimum.
- ▶  $MP\_kvFactor = 0.65 \cdot \text{determined } k_V$



### MP\_complpcT1

IPC time constant T1  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 100 000 to 1 [s]  
0: IPC inactive  
Default: 0  
Access: LEVEL3  
Reaction: RUN

### MP\_complpcT2

IPC time constant T2  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 100 000 to 1 [s]  
0: IPC inactive  
Default: 0  
Access: LEVEL3  
Reaction: RUN

## Optimizing the jerk feedforward control

In the same manner as the other feedforward controls in a control loop, the jerk feedforward control causes following errors to be reduced or compensated during a dynamic phase (in this case the phase of the change in acceleration).

When the feedforward control is initially configured, the necessary jerk feedforward control is calculated for the known control-loop factors, but the mechanical deformation of the transmission components (e.g. due to torsion of the ball screw or the slack sides and tight sides of belt drives) and the resulting following error are unknown. This can be minimized or compensated with the dimensionless multiplier **MP\_complpcJerkFact**, which affects the jerk feedforward control directly.

When optimizing the jerk feedforward control all other controller parameters must already have been adjusted.



#### Note

The **MP\_complpcJerkFact** parameter is not available on the CC 61xx or UEC 11x. Use the much more suitable parameter **MP\_compTorsionFact** instead (see "Torsion compensation" on page 944).

With the **CC 61xx or CC 424** you can also use this function without active IPC. A prerequisite for the activation of the possibility of compensation with the CC 422 is an active and already adjusted IPC (Integral Phase Compensation).

Commissioning:

- ▶ Enter the following test program:

```
BEARBEITUNG [MACHINING]  
[maximum traverse range]  
N1 G0 X400  
N2 G0 X0  
N3 M99  
END
```

- ▶ Run the program at high speed.
- ▶ Use the integrated oscilloscope to record the following error.
- ▶ **CC 424:** Adjust MP\_complpcJerkFact until a minimal following error occurs in the jerk phase. Here you can compensate the following error for the jerk phase.  
Typical input values: 0 to 0.5 (e.g. 0.01).



#### Note

Please note that values over 0.5 in MP\_complpcJerkFact do not make sense for the CC 424 controller unit, and are therefore not permissible. Therefore, an error message will be issued for values greater than 0.5.

- ▶ **CC 422:** Adjust MP\_complpcJerkFact until a minimal following error occurs in the jerk phase. Here you can compensate positive following errors (MP\_complpcJerkFact > 1) as well as rare negative following errors (MP\_complpcJerkFact < 1) for the jerk phase.  
Typical input values: 0.5 to 2.

#### **MP\_complpcJerkFact**

Following error in the jerk phase

Available from NCK software version: 597 110-02.

Format: Numerical value  
Input: 0.000 000 000 to 10  
Default: 0  
Access: LEVEL3  
Reaction: RUN



## Holding torque

The holding torque is the torque that is required to keep a vertical axis at a standstill.

The holding torque is given by the MANUALplus 620 through the integral-action component of the nominal current value. In most cases the holding torque is constant. The required holding current can therefore be fed forward through MP\_compCurrentOffset. This relieves the speed controller.

- ▶ To prevent the effect of stiction, measure the current at low speed in both directions (e.g. 10 min<sup>-1</sup>).
- ▶ Calculate the holding current from the mean of the measured current values and enter the result in MP\_compCurrentOffset.

Mean:

$$\text{MP\_compCurrentOffset} = \frac{I_{\text{SOLL}_1} + I_{\text{SOLL}_2}}{2}$$



### Note

If the ready signal (RDY) is missing from the speed encoder inputs of vertical axes, the DSP error message

**8B40 No drive release <axis>** appears.

A **vertical axis** is defined with an entry in **MP\_currentOffset**.

### MP\_compCurrentOffset

Holding current

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: -30.000 000 000 to +30 [A]

Default: 0

Access: LEVEL3

Reaction: RUN

## 6.16.16 HSCI: switching drives on and off, enabling the drive controller

Settings in the configuration editor	MP number
System CfgHardware <b>driveOffGroupInput</b>	100106
Axes ParameterSets [Key name of the parameter set] CfgAxisHardware <b>driveOffGroup</b>	400015
CfgPowerStage <b>ampReadyWaitTime</b>	401206

The parameter object

- CfgAxisHardware is not required for:
  - Virtual axes (MP\_axisMode=Virtual)
- CfgPowerStage is not required for:
  - Virtual axes (MP\_axisMode=Virtual)
  - Axes that are for display only (MP\_axisMode=Display)
  - Analog axes (MP\_axisHw=Analog)

The procedure recommended by HEIDENHAIN for switching the drives on and off, including the correct triggering of the brakes, can be configured with the PLC basic program. HEIDENHAIN recommends using the PLC basic program.

### Readiness of the drives

The drives can only be switched on once the drive system is ready. This includes

- the readiness of the supply unit (RDY.PS signal at X69 pin 17a – interrogation via Module 9066 bit 5), the inverters (RDY signal at X51..64 pin 10b of the PWM outputs) and of the motors.
- global drive enabling with EMERGENCY STOP via -ES.B.
- the conclusion of the motor orientation (determination of the field angle).
- for optional use of axis groups, these must be enabled via the PLC inputs specified in **MP\_driveOffGroupInput**.



### Basic settings:

- ▶ Ensure that the clamping or brakes activate when an emergency stop is effected.
- ▶ To enable drives use the input configured as -ES.B. on the PL 62xx or UEC 11x PLC system module.
- ▶ Ensure via Module 9159 (drive controllers are switched off) that the clamping or brakes activate before the drive controllers (current and speed controllers) are switched off.
- ▶ Before switching off the drives, save the positions of axes with common encoders.
- ▶ Ensure that all control components are wired correctly. (HEIDENHAIN recommends always wiring the system according to the basic circuit diagram of the MANUALplus 620.) Registered customers can download the current basic circuit diagram from the HESIS-Web Including Filebase on the Internet at <http://hesis.heidenhain.de>.
- ▶ If you are using axis groups, assign the axis to the axis group required for drive enabling in **MP\_driveOffGroup**.

### To switch on the drive controller:

- ▶ With **PP\_AxDriveOnRequest**, switch the drive motor on (see "Opening the position control loop" on page 848).
- ▶ Use **NN\_AxDriveOn** to check the status of the drive motor.

If drive enabling through X150/X151 is missing, the drive motor will **always** be switched off and the position controller will be informed accordingly.

If drive enabling of axis groups is used, the PLC program should perform a plausibility test to see if all axes used are defined in **MP\_driveOffGroup**.



#### Danger

If **MP\_driveOffGroup** is configured incorrectly, the drive motor might not be switched off correctly!



#### Note

- If drive enabling is missing, the error message **8B40 No drive release <axis>** appears.
- If you do **not** want to use drive enabling for axis groups, but rather just global drive enabling through -ES.B, remove the optional parameter **MP\_driveOffGroup** from the configuration of your machine.
- The MANUALplus 620 monitors the time between the switch-on of the drive controller (via Module 9161) and the READY signal of the power module (via the PWM cables). If the READY signal is missing after the waiting time has passed, the error message **8B40 No drive release <axis>** appears. In **MP\_ampReadyWaitTime** you preset the permissible waiting time.
- If the readiness signal is reset at the PWM outputs, the drive controllers (current and speed controllers) are switched off. Normally, the error message **MOVEMENT MONITORING IN <AXIS> B** is output through the position control loop. Subsequently, the PWM signal release is switched off by the reset signal.

The drive controller cannot be switched on until the control-is-ready signal of the inverter, the global drive enabling through -ES.B and the axis group enabling are available.




#### Note


If you do **not** want to use drive enabling for axis groups, but rather just global drive enabling through -ES.B, set **MP\_driveOffGroup=NONE** for all axes, or remove the parameter from your configuration.






## Procedure for "switching drives on and off"







## MP\_driveOffGroup

	Circuit of X150/X151 Available from NCK software version: 597 110-01.
Format:	Selection menu
Selection:	<b>None</b> Axis not assigned (disabling only through I32) <b>Group1</b> Axis is assigned to X150 pin 1 <b>Group2</b> Axis is assigned to X150 pin 2 <b>Group3</b> Axis is assigned to X150 pin 3 <b>Group4</b> Axis is assigned to X150 pin 4 <b>Group5</b> Axis is assigned to X151 pin 1 <b>Group6</b> Axis is assigned to X151 pin 2 <b>Group7</b> Axis is assigned to X151 pin 3 <b>Group8</b> Axis is assigned to X151 pin 4
Default:	No value, parameter optional
Access:	LEVEL3
Reaction:	RESET

The MANUALplus 620 monitors the time between the switch-on of the drive controller (by means of **PP\_AxDriveOnRequest**) and the RDY signal (via the PWM cable). If the READY signal is missing after the waiting time has passed, the error message **8B40 NO DRIVE ENABLE <axis>** appears.

► Enter in **MP\_AmpReadyWaitTime** the permissible waiting time.

## MP\_ampReadyWaitTime

	Waiting time between switch-on of the power module and the RDY signal Available from NCK software version: 597 110-01.
Format:	Numerical value
Input:	0.001 000 000 to 4999 [s] 0: Waiting time of 2 [s]
Default:	0 [s]
Access:	LEVEL3
Reaction:	RESET



### Note

If drive enabling is missing, the error message **8B40 No drive release <axis>** appears.

If you disconnect the voltage

- -ES.B, all drive controllers are switched off.
- on the PLC inputs for axis group enabling, the drive controllers of the corresponding axis group(s) are switched off.

You can determine by PLC which axes are switched off in 200 ms:

- Call Module 9159. The drive motors that are switched off are returned in bit code.




#### Note

The bit-encoded status signal supplied by Module 9159 is a request to lock the brake/clamping of the servo drive. Do not use the signal as a request to switch off the drive concerned.

The following logic diagram shows the status signals of the PLC modules 9159 and 9162 as well as the trigger signal for the brake from the HEIDENHAIN inverter.

A switch-on procedure with a test of the motor brake and a switch-off procedure with an overlap time of 200 ms are recorded:



The logic diagram shows that the trigger signal for the motor brake can be calculated from the status signals of the Modules 9159 and 9162:

Brake is not active = Status signal of Module 9162 AND NOT status signal of Module 9159

This enables you to use the PLC to apply the test of the motor brakes to non-HEIDENHAIN power modules, too.

The status of the drive controller is shown in **NN\_AxDriveOn**. Use Module 9157 to inquire whether the drive controller is ready to be switched on.

### Module 9157 Status request for drive hardware

The module provides information about the drive controller status.

Information about drive controller status: The drive is ready if

- the DSP processor board has been enabled.
- the drive was activated through external switching.
- the current controller and the speed controller have been activated.

Call:

PS    B/W/D/K   <>Selection of status information>  
0: Drive controller is ready  
    Result 0: Drive is not ready and cannot be switched on  
    Result 1: Drive is ready and can be switched on  
1: Drive controller status  
    Result: Bit-encoded (bit 0 corresponds to logical axis 0,  
    etc.)  
2: Axis enabled via axis group (bits 0 to 13 = 1) or axis not  
    enabled (bits 0 to 13 = 0)  
3: Signals available at X150/X151  
    (bits 0 to 7 = X150; bits 8 to 15 = X151)  
4: Reserved

CM    9157

PL    B/W/D    <>Axis status information bit-encoded>  
                  (Bit 0 represents logic axis 0, etc.)

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Status information was ascertained
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid status information was programmed
	24	Module was called in a spawn job or submit job



### Module 9159 Early warning for stopping the drives

The module provides an early warning indicating that the drives will be stopped. This early warning is made available approx. 200 ms before the drive readiness is canceled.

Constraints:

- When the API 3.0 symbolic memory interface is used, the number of the returned bits depends on the number of configured axes. Bit 0 corresponds to the axis with the index 0 in the parameter CfgAxes\axisList (100001). Spindles are not handled separately. The corresponding index from CfgAxes/axisList is returned.

Call:

CM 9159

PL W/D <>Drives, in bit code, that are switched off in 200 ms>  
When using the API 3.0 symbolic memory interface,  
Bit 0 corresponds to index 0 from CfgAxes/AxisList etc.  
When using the API 1.0 numerical memory interface:  
Sxxx xxx9 8765 4ZYX

### Module 9161 Enable the drive controller

With this module you can switch the drive controllers (speed and current controllers) on and off for specific axes. A nominal speed value is also output when the drive controller is not enabled.

Call:

PS W/D/K <>Enabled axes>  
Bit 0...13 -> axis 1...14, bit 15 -> spindle  
0: No drive controller enabling  
1: Drive controller enabling

CM 9161

### Error recognition:

Marker	Value	Meaning
M4203	0	No error
	1	Control has no current controller, or the call is in a spawn or submit job

### Module 9162 Status request of the drive controller

Call:

CM 9162

PL B/W/D <>Drive is ready>  
Bit 0...13 -> axis 1...14, bit 15 -> spindle  
0: Not ready  
1: Ready

### Module 9169 Axes for which I32 does not switch off the drives

Call:

PS B/W/D/K <>Axes bit-encoded>

Bit 0: Axis with index 0 from CfgAxes/axisList etc.

CM 9169





## 6.16.17 Current controller

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgCurrentControl <b>iCtrlPropGain</b> <b>iCtrlIntGain</b>	   401001 401002

The parameter object **CfgCurrentControl** is not required for:


- Virtual axes (**MP\_axisMode = Virtual**)
- Axes that are only for display (**MP\_axisMode = Display**)
- Analog axes (**MP\_axisHw = AnalogMC, AnalogCC**)

Several digital current controllers for the axes and spindle(s) are integrated in the MANUALplus 620.


The nominal values for magnetizing current  $I_{dnom}$  and torque current  $I_{qnom}$  are divided into the PWM signals  $U_1$ ,  $U_2$  and  $U_3$  through a PI controller and vector rotator VD+, and are transferred to the power module through X51 to X60 (via internal connections on the UEC 11x).

The actual current values  $I_{1act}$  and  $I_{2act}$  are determined by the power module and are transferred to vector rotator VD- through X51 to X60 (via internal connections on the UEC 11x). The vector rotator determines the actual values of magnetizing current  $I_{dAct}$  and torque current  $I_{qNom}$ .

Circuit diagram:



You adjust the current controller to attain the optimum result, with the position and speed controller switched off.



The step response is adjusted such that there is no overshoot and the rise time is as small as possible:

- ▶ In **MP\_iCtrlPropGain**, define the P factor of the current controller.
- ▶ In **MP\_iCtrlIntGain**, define the I factor of the current controller.

Automatic calculation of the P and I factor of the current controller for synchronous and asynchronous motors is also possible. However, automatic calculation is not to be used for linear synchronous and torque motors:

- ▶ Select the **MP\_iCtrlPropGain** or **MP\_iCtrlIntGain** parameter
- ▶ Press the ENT key to open the dialog window for the value input
- ▶ Press the CALCULATE soft key. An asterisk \* is prefixed to the parameters to identify the automatically calculated value.

### **MP\_iCtrlPropGain**

Proportional component for digital current controller  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 9 999.99 [V/A]  
Default: 0 [V/A]  
Access: LEVEL3  
Reaction: RUN

### **MP\_iCtrlIntGain**

Integral-action component for digital current controller  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 9 999 999.9 [V/As]  
Default: 0 [V/As]  
Access: LEVEL3  
Reaction: RUN

**Expanded current controller bandwidth (only CC 61xx)**

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgCurrentControl <b>iCtrlDiffFreqFF</b> <b>iCtrlAddInfo</b>	    401007 401008

For axes with rigidly connected mechanics it may make sense to adjust the current control loop using the maximum possible bandwidth to attain high gains in the superimposed velocity control loop. For the CC 61xx controller unit there are two procedures for increasing the bandwidth of the current control loop:

- Using machine parameter **MP\_iCtrlAddInfo** to increase the controller factors in the current control loop,
- Proportionally differentiating feedforward (D feedforward) to optimize the command action of the current control loop (**MP\_iCtrlDiffFreqFF** parameter).

**Increased controller factors in the current control loop:**

The dead time in the current control loop is the decisive factor for the attainable controller factors, and therefore for the attainable bandwidth. With parameter **MP\_iCtrlAddInfo**, you can activate compensation of this dead time. After activation, you have to repeat the current controller adjustment. Usually you can then set considerably higher current controller factors. The higher the controller factors, the larger the bandwidth of the current controller. The bandwidth of the current control loop can be evaluated with the Bode diagram function of the TNCopt commissioning and diagnostic software (see TNCopt User's Manual).

However, the noise in the current—and as a result, the loudness of the drive—increases when the current controller bandwidth is increased.

**D feedforward for optimization of the current controller command action:**

With parameter **MP\_iCtrlDiffFreqFF**, you activate feedforward with proportionally differentiating behavior for the torque-generating current. This way you achieve an optimized command action of the current controller.

The parameter **MP\_iCtrlDiffFreqFF** indicates the cutoff frequency in Hertz [Hz] up to which feedforward is active. When this cutoff frequency is reached, feedforward is deactivated by a low-pass element. It is therefore also referred to as  $PDT_1$  feedforward in the following.

The following table shows the maximum possible cutoff frequency depending on the PWM frequency of the drive. The higher the cutoff frequency, the larger the bandwidth of the current controller regarding its command action. At the same time, however, the noise in the current—and as a result, the loudness of the drive—increases. If you enter 0 Hz, feedforward is deactivated.



Maximum values for parameter **MP\_iCtrlDiffFreqFF** as a function of the PWM frequency:

PWM frequency	Maximum value for MP_iCtrlDiffFreqFF
3333 Hz	800 Hz
4000 Hz	960 Hz
5000 Hz	1200 Hz
6666 Hz	1600 Hz
8000 Hz	1920 Hz
10000 Hz	2400 Hz

**Adjustment of the current controller if increased current controller factors are active over MP\_iCtrlAddInfo:**



Note

For standard drives, it is usually not necessary to increase the current controller bandwidth. In general, the increase is only useful if the drives are connected directly without an interconnected gear.

If  $PDT_1$  feedforward or the increase of the current controller factors is activated, you must keep in mind that the noise in the current increases when the bandwidth is increased. You have to find a compromise between the

- increase of the current controller bandwidth and
- the development of noise in the drive.

To adjust the increased current controller factors, proceed as follows:

- ▶ In the corresponding parameter set of the axis **MP\_iCtrlAddInfo**, set bit 0 = 1 to activate the function.
- ▶ Readjust the current controller with TNCopt (Bode diagram function; see TNCopt User's Manual).



Note

If you activate the  $PDT_1$  feedforward by entering a value in the **MP\_iCtrlDiffFreqFF** parameter, it is not necessary to readjust the current controller. The  $PDT_1$  feedforward does not have a noticeable effect on the current control loop but rather only on the superimposed speed control loop. For axes with rigidly connected mechanics, you attain higher controller factors in the speed control loop if the  $PDT_1$  feedforward is activated.



### **MP\_iCtrlDiffFreqFF**

Cutoff frequency of the current controller feedforward in Hz  
(This function is only available when using the CC 61xx controller unit!)

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 0 Hz to  $f_g$

The cutoff frequency  $f_g$  depends on the PWM frequency (see table).

0: Current controller feedforward deactivated

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

### **MP\_iCtrlAddInfo**

Switching dead-time compensation on and off.  
(This function is only available when using the CC 61xx controller unit!)

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: Bit 0 = 0:

Compensation switched off

Bit 0 = 1:

Compensation switched on

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

## 6.16.18 Braking the drives for an emergency stop and a power failure

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgServoMotor <b>motEmergencyStopRamp</b> <b>motPbrMax</b> <b>motPbrMaxAcFail</b>	    401306 401307 401308

The parameter object CfgServoMotor is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)
- Analog axes (MP\_axisHw=Analog)

In an emergency stop and power failure the axes and the spindle must be braked as quickly as possible. If the braking energy cannot be drawn off quickly enough, the DC-link voltage increases sharply. If, in unfavorable cases, the maximum regenerative power of the inverter is exceeded, the inverter is switched off and the axes and spindle(s) coast to a stop. A powerful braking of the drives also puts a high strain on the mechanics of the machine. With gantry axes a mechanical offset can occur between the master and slave axes.

Problems with **non-regenerative** inverters (with braking resistors) during braking mostly arise if the inverter is switched off too early. The strain on the mechanics during braking is reduced, but can also be influenced with braking strategies.

**Regenerative** inverters usually do not develop problems if they are switched off. As a rule, the mechanics of the machine must be taken into account.

During a **power failure** ("powerfail"), the "SH1B" signal at X51 to X60 is maintained for 10 more seconds, in order to brake the spindle(s). At the same time, the control tries to reset the PLC outputs.



## Decelerating along the braking ramp

The steepness of the emergency braking ramp (ramp for deceleration) is defined in **MP\_motEmergencyStopRamp**. The greater the value entered in **MP\_motEmergencyStopRamp**, the steeper the emergency braking ramp.

The maximum value for **MP\_motEmergencyStopRamp** is limited by the output power of the inverter. The minimum value is determined by **MP\_maxAcceleration**. The permissible acceleration of the axis during normal machining operation is defined in **MP\_maxAcceleration**.



### Note

If the brake ramp defined in **MP\_motEmergencyStopRamp** has a smaller gradient than the one defined in **MP\_maxAcceleration**, the brake ramp from **MP\_maxAcceleration** is used for braking.

The greatest possible value must be entered in **MP\_motEmergencyStopRamp** in order for deceleration to take place at the limit of current.



### Note

#### If you are switching from the iTNC 530:

With regard to deceleration at the limit of current, the iTNC 530 (MP2590) differs from the MANUALplus 620:

#### ■ iTNC 530:

If 0 is entered in MP2590, this leads to deceleration at the limit of current.

#### ■ MANUALplus 620:

Entering the greatest possible value leads to deceleration at the limit of current.

Entering 0 in **MP\_motEmergencyStopRamp** on the MANUALplus 620 leads to a very flat braking ramp.

Define **MP\_motEmergencyStopRamp** (brake ramp in an emergency stop):

- ▶ Use the value in **MP\_maxAcceleration** as the minimum value
- ▶ Use the emergency stop to brake the axis from rapid traverse, or the spindle from high speed.
- ▶ Increase the value entered in **MP\_motEmergencyStopRamp** until the braking time is as short as possible and the mechanics of the axis or spindle are not overloaded.

## Limitation of the braking power

The use of energy recovery and/or a braking resistor must also be taken into account when braking the drives in an emergency stop or in the event of a power failure:

Inverter **without energy recovery** (with braking resistor):

- **MP\_motPbrMax**: Calculate the maximum braking power from the formula below.
- **MP\_motPbrMaxAcFail**: Calculate the maximum braking power from the formula below.

Inverter **with energy recovery** (without braking resistor):

- Enter **MP\_motPbrMax** = 0 so as not to limit the braking power.
- **MP\_motPbrMaxAcFail**: The braking power cannot be limited in a power failure. Axes and spindles will coast to a stop.

Inverter **with energy recovery and additional braking resistor**:

- Enter **MP\_motPbrMax** = 0 so as not to limit the braking power.
- **MP\_motPbrMaxAcFail**: Calculate the maximum braking power from the formula below.

Calculation of maximum braking power:

- ▶ For **inverters with braking resistor**, calculate the maximum braking power from the following formula:

$$\text{Max. braking power} = \frac{U_Z^2}{R \cdot 1000}$$

R = Braking resistance [Ω]

U<sub>Z</sub> = DC-link voltage [V]



### Note

- If the braking power defined in **MP\_motPbrMax** or **MP\_motPbrMaxAcFail** is smaller than the one defined in **MP\_maxAcceleration**, the braking power from **MP\_maxAcceleration** is used for braking.
- If after entry of a value in **MP\_motPbrMax** or **MP\_motPbrMaxAcFail**, the mechanics are overloaded by the braking process, reduce the value until you have found an optimum between braking time and mechanical load.





**Machine  
parameters**

**MP\_motEmergencyStopRamp**

Braking ramp in an emergency stop  
Available from NCK software version: 597 110-02.  
Format: Numerical value  
Input: 0.000 000 000 to 999.9 [m/s<sup>2</sup>] or [1000°/s<sup>2</sup>]  
0: Function inactive  
Default: 0  
Access: LEVEL3  
Reaction: RESET

**MP\_motPbrMax**

Maximum brake power for emergency stop  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.0 to 3200.0 [kW]  
0: Braking power is not limited  
Default: 0  
Access: LEVEL3  
Reaction: RESET

**MP\_motPbrMaxAcFail**

Maximum brake power for power failure  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 3200 [kW]  
0: Braking power is not limited  
Default: 0  
Access: LEVEL3  
Reaction: RESET

## 6.16.19 Power and torque limiting

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgServoMotor	
<b>motEncCheckOff – Bit2</b>	401303
<b>motPMax</b>	401308
<b>motMMax</b>	401310

The parameter object CfgServoMotor is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Analog axes (**MP\_axisHw** = Analog)

You can limit the power of your spindle motor to achieve wider gear ranges. Wide-range motors are characterized by a larger speed range with higher torque at low speed.

One solution for bringing about this behavior is to use an oversized motor, and to limit the maximum power. However, power limiting does not reduce the high torque to the speed at which power limiting becomes effective. This high torque (until power limiting takes effect) can be reduced with torque limiting, in order to keep the mechanics of the machine from becoming overloaded.

With torque limiting you can also limit the torque of the axis motors, in order to keep the mechanics of the machine from becoming overloaded. Power limiting is not useful for axis motors.

For **axes and spindles**, the torque is limited to the value taken from either the table of power modules or the motor table, whichever is lower.

On supply units where the  $\overline{\text{ERR.IZ.GR}}$  signal is available, the power is limited via MP\_motPMax in case of error.

HEIDENHAIN recommends activating this monitoring function (not with UE 2xx).

The torque can be calculated for any speed:

$$M = \frac{P \cdot 60}{n \cdot 2 \cdot \pi}$$

M: Torque [Nm]

P: Power [W]


n: Speed [ $\text{min}^{-1}$ ]



### Note

The power and torque limiting can have an effect on the braking of the spindle in an emergency stop.

- ▶ Enter the maximum power for the spindle in **MP\_motPMax**.
- ▶ Enter the maximum torque for the drive motor in **MP\_motMMax**.
- ▶ Activate the power limiting of the spindle at  $\overline{\text{ERR.IZ.GR}}$  via **MP\_motEncCheckOff – Bit 2 = 0** (not for UE 2xx)



**Machine  
parameters**

**MP\_motEncCheckOff**

Monitoring functions  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: **Bit 2** – Power limit of spindle with ERR.IZ.GR (only for HEIDENHAIN inverters, except UE 2xx)  
**0:** Power limit active  
**1:** Power limit inactive  
Default: 0  
Access: LEVEL3  
Reaction: RESET

**MP\_motPMax**

Power limiting of motor  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 3200 [kW]  
0: No power limiting  
Default: 0  
Access: LEVEL3  
Reaction: RESET

**MP\_motMMax**

Maximum torque  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0 to 30 000 [Nm]  
0: No torque limiting  
Default: 0  
Access: LEVEL3  
Reaction: RESET



**Module 9128 Torque limiting by the PLC**

Module 9128 can be used to program a maximum torque for the programmed axis. The torque of the drive is limited to the programmed value. The value -1 cancels the torque limitation and the value from the motor data becomes effective again. The torque can be limited in [mA] or in [0.1 %] of the rated current.

Conditions:

- The module is only executable in the cyclic PLC program.
- The programmed value for the maximum torque may not be higher than the value in the motor data. If the programmed value is higher than the value in the motor data, the value in the motor data is used as the limit.
- A torque value of 0 cannot be programmed.
- Programming a torque value of -1 cancels limitation. The original value from the motor data becomes effective again.
- The unit of the resulting torque is [mA].
- If a drive is switched off, the torque from the motor data becomes effective again when it is switched on.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Call:

```
PS    B/W/D/K  <>Mode>
        0: Current in [0.1 %] of the rated current
        1: Current in [mA] (like Module 9158)
PS    B/W/D/K  <>Axis number / spindle number>
PS    B/W/D/K  <>Torque>
        -1: Cancel the torque limiting
```

CM 9128

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error	0	Torque limiting programmed
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Invalid value for torque
	2	Invalid value for axis number or mode, axis is an open-loop axis or is temporarily not a closed-loop axis
	24	Module was called in a spawn or submit job



### Module 9129 Status of torque limiting by the PLC

Module 9129 is used to determine the current status of torque limiting for the programmed axis. The momentary maximum torque can be determined in [mA] or in [0.1 %] of the rated current.

Constraints:

- The module is only executable in the cyclic PLC program.
- The greatest possible return value is the value resulting from the motor data.
- If torque limiting is not active, the maximum current can be determined from the motor data.
- An axis that is not configured as "active", or an axis that is currently deactivated (e.g. with Module 9226 or 9418), is treated as if it were not present.

Call:

```
PS    B/W/D/K  <>Mode>
        0: Limiting active/inactive
        1: Current in [mA]
        2: Current in [0.1 %] of the rated current
        3: Limit reached / not reached

PS    B/W/D/K  <>Axis number / spindle number>
CM    9129
PL    B/W/D    <>Status>
        Mode 0: 0 = Limiting inactive / 1 = Limiting active
        Mode 1: Current in [mA]
        Mode 2: Current in [0.1 %] of the rated current
        Mode 3: 0 = Limit not reached / 1 = Limit reached (1)
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Status ascertained
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid value for axis number or mode, axis is an open-loop axis or is temporarily not a closed-loop axis
	24	Module was called in a spawn or submit job



### Module 9158 Maximum torque

With Module 9158 you can limit the torque of an axis or spindle. The maximum torque resulting from the data in the control's motor table cannot be exceeded. In this case the torque is limited to the value from the motor specifications. After the drive is switched off, the original torque becomes effective again.

If torque limiting is active, the standstill monitoring is inactive; only the motion monitoring remains active.

The torque-producing current required for the desired torque must be transferred to the module:

Synchronous motor	Asynchronous motor
$k_M = \frac{P_N}{I_N \cdot 2 \cdot \pi \cdot \frac{n_N}{60}}$ $I_q = \frac{M}{k_M}$ <p> <math>I_q</math>: Torque-producing current  <math>M</math>: Desired torque  <math>k_M</math>: Torque constant  <math>n_N</math>: Rated speed (from motor table)  <math>I_N</math>: Rated current (from motor table)  <math>P_N</math>: Rated power output (from motor table)                 </p>	<p>■ Armature control range (<math>n &lt; n_{FS}</math>)</p> $I_q = \frac{M \cdot n_N \cdot 2 \cdot \pi \cdot \sqrt{I_N^2 - I_0^2}}{P_N \cdot 60}$ <p>■ Field weakening range (<math>n &gt; n_{FS}</math>)</p> $I_q = \frac{M \cdot n_N \cdot n \cdot 2 \cdot \pi \cdot \sqrt{I_N^2 - I_0^2}}{P_N \cdot n_{FS} \cdot 60}$ <p> <math>I_q</math>: Torque-producing current  <math>M</math>: Desired torque  <math>n_N</math>: Rated speed (from motor table)  <math>n</math>: Current speed  <math>I_N</math>: Rated current (from motor table)  <math>I_0</math>: No-load current (from motor table)  <math>P_N</math>: Rated power output (from motor table)  <math>n_{FS}</math>: Threshold speed for field weakening (from motor table)                 </p>



#### Danger

If Module 9158 is used, then certain monitoring functions regarding the drives must be switched off. Please note the following error messages and their possible consequences (see DSP error messages)

- **C380 Motor <axis> not controllable**
- **C3B0 Motor <axis> does not rotate**



#### Warning

If you are using a CC 422 controller unit, then please note that the current values in the oscilloscope are all peak values (and not effective values as with the CC 424). Measured values then appear greater by a factor of the square root of 2 than the calculated values.

Call:

PS B/W/D/K/S<>Axis number / spindle number>

PS B/W/D/K/S<>Torque-producing current in mA>  
-1 = Torque given in motor specifications

CM 9158

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error	0	Torque preset active
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	0 Nm torque transferred
	2	Invalid value for axis number or mode, axis is an open-loop axis or is temporarily not a closed-loop axis
	24	Module was called in a spawn or submit job





## 6.16.20 Controller parameters for manual traverse

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPositionFilter <b>manualFilterOrder</b>	401605

### Filter before position control loop

The **MP\_manualFilterOrder** parameter differentiates between axes and spindles. In the **Manual Operation** and **E1. Handwheel** operating modes, or if axes are moved by PLC, a mean-value filter is used as a nominal position value filter for axes.

**MP\_manualFilterOrder** for spindles: see "Filtering the acceleration values" on page 1014

- ▶ Define the order of the mean-value filter for axes in **MP\_manualFilterOrder**.

#### **MP\_manualFilterOrder**

Order of mean-value filter in Manual mode  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 1 to 51  
Default: 11  
Access: LEVEL3  
Reaction: RUN

## 6.16.21 Controller parameters for analog axes

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPosControl <b>kvFactor</b> <b>feedForwardFactor</b>	400801 400806
Axes ParameterSets [Key name of the parameter set] CfgAxisAnalog <b>analogOffset</b> <b>kvFactor2</b> <b>kvSpeedLimit</b> <b>accForwardFactor</b> <b>compStrength</b> <b>compWidth</b> <b>compTimeOffset</b> <b>compFFAdjust</b> <b>compRefAcc</b> <b>compLimitFactor</b> <b>noOffsetAdjust</b> <b>unipolar</b>	400102 400103 400104 400106 400107 400108 400109 400110 400111 400114 400112 400113

### General information

Analog axis feedback control is based on the following formula:

$$U_{out} = (P_{err} \cdot kvFactor + V_{nom} \cdot feedForwardFactor + A_{nom} \cdot accForwardFactor) \cdot \frac{9V}{maxFeedAt9V}$$

Value, parameter	Unit	Description
U <sub>out</sub>	Volt	Output voltage (analog nominal speed value)
P <sub>err</sub>	mm	Following error (servo lag)
kvFactor	1/s	Kv factor (proportional component of position controller)
V <sub>nom</sub>	mm/min	Nominal velocity
feedForwardFactor		Factor for velocity feedforward control
A <sub>nom</sub>	m/s <sup>2</sup>	Nominal acceleration
accForwardFactor		Factor for acceleration feedforward control
maxFeedAt9V	mm/min	Assumed velocity of the axis at 9 V

The parameter object **CfgAxisAnalog** is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Digital axes **MP\_axisHW** = CC or None)

### Characteristic curve kink point (only for analog axes)


For machines with high rapid traverse, you can not increase the  $k_v$  factor enough for an optimum control response to result over the entire velocity range (from standstill to rapid traverse).

In this case, define a characteristic curve kink point, which has the following advantages:

- High  $k_v$  factor in the low range
- Low  $k_v$  factor in the upper range (beyond the machining velocity range)

► Define the position of the kink point in **MP\_kvSpeedLimit**.

► In **MP\_kvFactor2**, enter the  $k_v$  factor for the upper range.



sa: Following error

The characteristic curve kink point must lie above the tool feed rate!

### MP\_kvFactor2

Proportional component of position controller above

MP\_kvSpeedLimit

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 1000 [1/s]

Default: 0 [1/s]

Access: LEVEL3

Reaction: RUN

### MP\_kvSpeedLimit

Limit velocity for MP\_kvFactor2

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 36 000 000 [mm/min]

Default: 0.0 [mm/min]

Access: LEVEL3

Reaction: RUN


## Acceleration feedforward control for analog axes


**MP\_accForwardFactor** allows you to influence acceleration feedforward control for analog axes.

The following error (servo lag) should be as small as possible during the acceleration phase. The **MP\_accForwardFactor** parameter directly affects the following error.


The best method for ascertaining the appropriate value for the parameter is by carefully approaching the ideal value. Proceed as follows:

- ▶ Enter 0.005 as the preliminary starting value in the parameter **MP\_accForwardFactor**.
- ▶ Press the axis-direction key and record the following error with the integrated oscilloscope.
- ▶ Ascertain the correct setting by carefully increasing the preliminary starting value; i.e. use the value 0.01 for the next measurement.
- ▶ Determine the value just before an undershoot forms with the measured following error.





MP\_accForwardFactor adjusted too high



MP\_accForwardFactor correctly adjusted

### MP\_accForwardFactor

Factor for acceleration feedforward control  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.00 to 0.01  
Default: 0  
Access: LEVEL3  
Reaction: RUN

## Compensation of reversal spikes for analog axes

The compensation of the reversal peaks affects the nominal speed value, which is output at the analog nominal value output of the control (X8). If an axis reverses its direction of movement, a time-dependent compensation curve is superimposed on the nominal speed value.

### Machine parameters

#### MP\_compStrength

Strength of the compensation  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -999 999 999.999 999 999 to +999 999 999.999 999 999 [mm]  
0: No compensation  
Positive input value:  
Compensation works in the direction of acceleration.  
Negative input value:  
Compensation works against the acceleration.

Default: 0  
Access: LEVEL3  
Reaction: RUN

With the **MP\_compWidth** parameter you define the distance to the reversal peak. The distance given refers to the offset entered under **MP\_compTimeOffset**. Enter the traverse path in which the compensation curve is to be superimposed over the nominal speed value.

#### MP\_compWidth

Specify, with respect to MP\_compTimeOffset=0, the distance from the reversal point at which compensation is to begin.  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to +999 999 999.999 999 999 [mm], only positive values  
Default: 0.001  
Access: LEVEL3  
Reaction: RUN



The parameter **MP\_compTimeOffset** shifts the compensation curve along the time axis. The width is not changed. The velocity of the axis at which the compensation function is to reach its maximum is defined. This means the higher the acceleration at the reversal point, the closer the maximum will be to the reversal point at the time of direction reversal.

### **MP\_compTimeOffset**

Time offset of the compensation  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -999 999 999.999 999 999 to +999 999 999.999 999 999 [mm/min]

0: Compensation parabola reaches its maximum at the time of direction reversal  
Positive input value:  
The compensation curve is delayed, which means that the maximum will not be reached until after the direction reversal.  
Negative input value:  
The compensation curve is moved to an earlier position, which means that the maximum is reached before the direction reversal.

Default: 0  
Access: LEVEL3  
Reaction: RUN

Use machine parameter **MP\_compFFAdjust** to adjust the area below the compensation curve as a function of the velocity at the reversal point. The area entered in the machine parameter **MP\_compStrength** is valid for the acceleration entered in **MP\_compRefAcc**. The compensation strength is increased or decreased during accelerations that differ from the acceleration in **MP\_compRefAcc**.

### **MP\_compFFAdjust**

Additive correction of the compensation strength to the machine parameter MP\_compStrength  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -999 999 999.999 999 999 to +999 999 999.999 999 999 [mm]

0: The compensation strength is constant over all acceleration values and is equal to the value in MP\_compStrength.  
> 0: The area below the compensation curve becomes larger for low accelerations.  
< 0: The area below the compensation curve becomes smaller for low accelerations.

Default: 0  
Access: LEVEL3  
Reaction: RUN

### **MP\_compRefAcc**

For the acceleration given here, the area below to compensation curve is set equal to the value entered in MP\_compStrength.

Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to 999 999 999.999 999 999 [m/s<sup>2</sup>]  
Default: 0.03  
Access: LEVEL3  
Reaction: RUN

## **Limiting the compensation**

Parameter **MP\_compLimitFactor** (400114) is used to limit reversal-spike compensation. As a precaution, the effective internal software limit is 3 mm/s. You can use **MP\_compLimitFactor** to raise or lower the limit. To do this, add the optional parameter to the machine configuration.

### **MP\_compLimitFactor**

Limit of reversal-spike compensation

Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 0.5 to 5 with up to 9 decimal places  
Factor for raising or lowering the internal default software limit of 3 mm/s.  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN





## Compensation of reversal peaks

For adjusting the compensation of the reversal peaks, proceed as follows:

- ▶ Set machine parameters **MP\_compFFAdjust** = 0 and **MP\_compRefAcc** = 0 to ensure that the compensation strength is constant over all feed-rate values.

Now select a typical machining speed and adjust the **MP\_compStrength**, **MP\_compWidth** and **MP\_compTimeOffset** parameters for the selected speed.

**MP\_compWidth** specifies the duration of compensation and should contain values in the range of a few microns.

- ▶ In **MP\_compStrength** specify the distance (in [mm]) which the axis will travel if it ideally complies with the transferred nominal speed value. The reversal peak height resulting without compensation is a suitable starting value for the compensation.
- ▶ In **MP\_compWidth**, enter the duration of compensation. The value entered should lie in the range of a few microns.
- ▶ Set the parameter **MP\_compTimeOffset** = 0.
- ▶ Run a circular interpolation test.
- ▶ If the path traversed in the circular test deviates at the reversal point from the nominal path, first toward the inside and then toward the outside, the compensation is performed too early. In this case, you must increase the value in **MP\_compTimeOffset**.
- ▶ If the path traversed deviates at the reversal point from the nominal path, first toward the outside and then toward the inside, the compensation is performed too late. In this case, you must decrease the value in **MP\_compTimeOffset**.

With the following formula you can estimate the magnitude of useful values for the **MP\_compTimeOffset** parameter:

$$\mathit{compTimeOffset} = \sqrt{2} \cdot [\mathit{acceleration}] \cdot \mathit{compWidth} \cdot 6$$

It is easier to adjust the **MP\_compWidth** and **MP\_compTimeOffset** parameters at low feed rates. HEIDENHAIN recommends:

- ▶ First roughly adjust **MP\_compStrength**.
- ▶ Then select a low feed rate.
- ▶ Then set **MP\_compWidth** and **MP\_compTimeOffset**.
- ▶ Return to the original feed rate and optimize the value for **MP\_compStrength**.

You use these three parameters (**MP\_compStrength**, **MP\_compWidth**, **MP\_compTimeOffset**) to adjust the compensation of reversal peaks for a specific feed rate and radius. Under certain circumstances, however, it can be necessary to correct the compensation strength based on the feed rate. Proceed as follows:

- ▶ Switch to the **Oscilloscope** mode of operation.
- ▶ Set the following value in the oscilloscope by pressing the **SELECTION** soft key:  
**Display mode: YT**  
**Sampling time: IPO clock**  
**Channel 1: A nom**  
**Trigger: Free run**
- ▶ Press the **OSCI** soft key to switch to the curve representation.
- ▶ Now get the nominal acceleration for the axis (**A nom**) at the reversal point for the feed rate that you have selected for the adjustment up to now.
- ▶ Press the **START** soft key to start recording.
- ▶ Press the axis-direction key of each axis.
- ▶ Press the **STOP** soft key to stop recording.
- ▶ Enter the determined acceleration in the parameter **MP\_compRefAcc**.



#### Note

The oscilloscope shows  $\text{mm/s}^2$ , but the unit of the parameter is  $\text{m/s}^2$ . This means that you must divide the value by 1000.

- ▶ Now use the parameter **MP\_compFFAdjust** to correct the compensation strength for lower or higher feed rates.

## Analog offset

The offset voltage required for analog axes is stored in **MP\_analogOffset**. You either enter these values manually or determine them by using the **offset adjustment** function.

During the offset adjustment, the control receives the axis offset values determined by the IPO and enters them in the parameters **MP\_analogOffset**.

For the offset adjustment, the axes must be in position feedback control.

To adjust the offset:

▶ Switch to the **Organization** mode of operation.

▶ Press the MOD key.



▶ Press soft key and enter the key number 75368

▶ Press the MOD key.



▶ Press the **ADJUST OFFSET** soft key.

The control opens the **Adjustment of analog axis offset** dialog box and displays the values determined.

Axis	Value	Unit
Axis-X	-0.9	mV
Axis-Y	2.3	mV
Axis-Z	-3.6	mV
Axis-C	-1.5	mV
Axis-S	33.0	mV

▶ Press the **OK** button to transfer the offset values to the parameters **MP\_analogOffset**.

The maximum permissible offset voltage in the control is +/- 1 V. If this voltage is exceeded, the **offset adjustment** function limits the value.

### MP\_analogOffset

Offset on analog axis  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: -1.0 to +1.0 [V]  
Default: 0 [V]  
Access: LEVEL3  
Reaction: RUN

### MP\_noOffsetAdjust

Excludes the axis from automatic offset adjustment  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: **TRUE**  
Axis will be excluded from offset adjustment.  
**FALSE**  
Offset of the axis is adjusted.  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

### Position loop resolution for analog axes

The analog voltage is subdivided 65536-fold with a 16-bit D/A converter. This results in a smallest voltage step of 0.15 mV.

This results in the voltage DU per position error or following error  $s_a$ :

The control outputs one voltage per position error.

$$\Delta U = \frac{10\,000 \text{ [mV]}}{S_a \text{ [\mu m]}}$$

If DU is divided by the smallest possible voltage step (0.15 mV), the result is the number n of the possible voltage steps per position error.



**General  
information**

Analog axis feedback control is based on the following formula:

$$U_{out} = (P_{err} \cdot kvFactor + V_{nom} \cdot feedForwardFactor + A_{nom} \cdot accForwardFactor) \cdot \frac{9V}{maxFeedAt9V}$$

Value, parameter	Unit	Description
U <sub>out</sub>	Volt	Output voltage (analog nominal speed value)
P <sub>err</sub>	mm	Following error (servo lag)
kvFactor	1/s	Kv factor (proportional component of position controller)
V <sub>nom</sub>	mm/min	Nominal velocity
feedForwardFactor		Factor for velocity feedforward control
A <sub>nom</sub>	m/s <sup>2</sup>	Nominal acceleration
accForwardFactor		Factor for acceleration feedforward control
maxFeedAt9V	mm/min	Assumed velocity of the axis at 9 V



The parameter object **CfgAxisAnalog** is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Digital axes **MP\_axisHW** = CC or None)

### Characteristic curve kink point (only for analog axes)


For machines with high rapid traverse, you can not increase the  $k_v$  factor enough for an optimum control response to result over the entire velocity range (from standstill to rapid traverse).

In this case, define a characteristic curve kink point, which has the following advantages:

- High  $k_v$  factor in the low range
- Low  $k_v$  factor in the upper range (beyond the machining velocity range)

► Define the position of the kink point in **MP\_kvSpeedLimit**.

► In **MP\_kvFactor2**, enter the  $k_v$  factor for the upper range.



sa: Following error

The characteristic curve kink point must lie above the tool feed rate!

### MP\_kvFactor2

Proportional component of position controller above

MP\_kvSpeedLimit

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 1000 [1/s]

Default: 0 [1/s]

Access: LEVEL3

Reaction: RUN

### MP\_kvSpeedLimit

Limit velocity for MP\_kvFactor2

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 36 000 000 [mm/min]

Default: 0.0 [mm/min]

Access: LEVEL3

Reaction: RUN


## Acceleration feedforward control for analog axes

**MP\_accForwardFactor** allows you to influence acceleration feedforward control for analog axes.


The following error (servo lag) should be as small as possible during the acceleration phase. The **MP\_accForwardFactor** parameter directly affects the following error.

The best method for ascertaining the appropriate value for the parameter is by carefully approaching the ideal value. Proceed as follows:


- ▶ Enter 0.005 as the preliminary starting value in the parameter **MP\_accForwardFactor**.
- ▶ Press the axis-direction key and record the following error with the integrated oscilloscope.
- ▶ Ascertain the correct setting by carefully increasing the preliminary starting value; i.e. use the value 0.01 for the next measurement.
- ▶ Determine the value just before an undershoot forms with the measured following error.







MP\_accForwardFactor adjusted too high



MP\_accForwardFactor correctly adjusted

### MP\_accForwardFactor

Factor for acceleration feedforward control  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 0.01  
Default: 0  
Access: LEVEL3  
Reaction: RUN

## Compensation of reversal spikes for analog axes

The compensation of the reversal peaks affects the nominal speed value, which is output at the analog nominal value output of the control (X8). If an axis reverses its direction of movement, a time-dependent compensation curve is superimposed on the nominal speed value.

### Machine parameters

#### MP\_compStrength

Strength of the compensation  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -999 999 999.999 999 999 to +999 999 999.999 999 999 [mm]  
0: No compensation  
Positive input value:  
Compensation works in the direction of acceleration.  
Negative input value:  
Compensation works against the acceleration.

Default: 0  
Access: LEVEL3  
Reaction: RUN

With the **MP\_compWidth** parameter you define the distance to the reversal peak. The distance given refers to the offset entered under **MP\_compTimeOffset**. Enter the traverse path in which the compensation curve is to be superimposed over the nominal speed value.

#### MP\_compWidth

Specify, with respect to MP\_compTimeOffset=0, the distance from the reversal point at which compensation is to begin.  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to +999 999 999.999 999 999 [mm], only positive values  
Default: 0.001  
Access: LEVEL3  
Reaction: RUN



The parameter **MP\_compTimeOffset** shifts the compensation curve along the time axis. The width is not changed. The velocity of the axis at which the compensation function is to reach its maximum is defined. This means the higher the acceleration at the reversal point, the closer the maximum will be to the reversal point at the time of direction reversal.

### **MP\_compTimeOffset**

Time offset of the compensation  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -999 999 999.999 999 999 to +999 999 999.999 999 999 [mm/min]

0: Compensation parabola reaches its maximum at the time of direction reversal  
Positive input value:  
The compensation curve is delayed, which means that the maximum will not be reached until after the direction reversal.  
Negative input value:  
The compensation curve is moved to an earlier position, which means that the maximum is reached before the direction reversal.

Default: 0  
Access: LEVEL3  
Reaction: RUN

Use machine parameter **MP\_compFFAdjust** to adjust the area below the compensation curve as a function of the velocity at the reversal point. The area entered in the machine parameter **MP\_compStrength** is valid for the acceleration entered in **MP\_compRefAcc**. The compensation strength is increased or decreased during accelerations that differ from the acceleration in **MP\_compRefAcc**.

### **MP\_compFFAdjust**

Additive correction of the compensation strength to the machine parameter MP\_compStrength  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -999 999 999.999 999 999 to +999 999 999.999 999 999 [mm]

0: The compensation strength is constant over all acceleration values and is equal to the value in MP\_compStrength.  
> 0: The area below the compensation curve becomes larger for low accelerations.  
< 0: The area below the compensation curve becomes smaller for low accelerations.

Default: 0  
Access: LEVEL3  
Reaction: RUN

### MP\_compRefAcc

For the acceleration given here, the area below to compensation curve is set equal to the value entered in MP\_compStrength.

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: -999 999 999.999 999 999 to +999 999 999.999 999 999  
[m/s<sup>2</sup>]

Default: 0.03

Access: LEVEL3

Reaction: RUN

## Limiting the compensation

Parameter **MP\_compLimitFactor** (400114) is used to limit reversal-spike compensation. As a precaution, the effective internal software limit is 3 mm/s. You can use **MP\_compLimitFactor** to raise or lower the limit. To do this, add the optional parameter to the machine configuration.

### MP\_compLimitFactor

Limit of reversal-spike compensation

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 0.5 to 5 with up to 9 decimal places

Factor for raising or lowering the internal default software limit of 3 mm/s.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

## Compensation of reversal peaks

For adjusting the compensation of the reversal peaks, proceed as follows:

- ▶ Set machine parameters **MP\_compFFAdjust** = 0 and **MP\_compRefAcc** = 0 to ensure that the compensation strength is constant over all feed-rate values.

Now select a typical machining speed and adjust the **MP\_compStrength**, **MP\_compWidth** and **MP\_compTimeOffset** parameters for the selected speed.

**MP\_compWidth** specifies the duration of compensation and should contain values in the range of a few microns.

- ▶ In **MP\_compStrength** specify the distance (in [mm]) which the axis will travel if it ideally complies with the transferred nominal speed value. The reversal peak height resulting without compensation is a suitable starting value for the compensation.
- ▶ In **MP\_compWidth**, enter the duration of compensation. The value entered should lie in the range of a few microns.
- ▶ Set the parameter **MP\_compTimeOffset** = 0.
- ▶ Run a circular interpolation test.
- ▶ If the path traversed in the circular test deviates at the reversal point from the nominal path, first toward the inside and then toward the outside, the compensation is performed too early. In this case, you must increase the value in **MP\_compTimeOffset**.

- ▶ If the path traversed deviates at the reversal point from the nominal path, first toward the outside and then toward the inside, the compensation is performed too late. In this case, you must decrease the value in **MP\_compTimeOffset**.

With the following formula you can estimate the magnitude of useful values for the **MP\_compTimeOffset** parameter:

$$\mathit{compTimeOffset} = \sqrt{2} \cdot [\text{acceleration}] \cdot \mathit{compWidth} \cdot 6$$

It is easier to adjust the **MP\_compWidth** and **MP\_compTimeOffset** parameters at low feed rates. HEIDENHAIN recommends:

- ▶ First roughly adjust **MP\_compStrength**.
- ▶ Then select a low feed rate.
- ▶ Then set **MP\_compWidth** and **MP\_compTimeOffset**.
- ▶ Return to the original feed rate and optimize the value for **MP\_compStrength**.

You use these three parameters (**MP\_compStrength**, **MP\_compWidth**, **MP\_compTimeOffset**) to adjust the compensation of reversal peaks for a specific feed rate and radius. Under certain circumstances, however, it can be necessary to correct the compensation strength based on the feed rate. Proceed as follows:

- ▶ Switch to the **Oscilloscope** mode of operation.
- ▶ Set the following value in the oscilloscope by pressing the **SELECTION** soft key:  
**Display mode: YT**  
**Sampling time: IPO clock**  
**Channel 1: A nom**  
**Trigger: Free run**
- ▶ Press the **OSCI** soft key to switch to the curve representation.
- ▶ Now get the nominal acceleration for the axis (**A nom**) at the reversal point for the feed rate that you have selected for the adjustment up to now.
- ▶ Press the **START** soft key to start recording.
- ▶ Press the axis-direction key of each axis.
- ▶ Press the **STOP** soft key to stop recording.
- ▶ Enter the determined acceleration in the parameter **MP\_compRefAcc**.



#### Note

The oscilloscope shows mm/s<sup>2</sup>, but the unit of the parameter is m/s<sup>2</sup>. This means that you must divide the value by 1000.

- ▶ Now use the parameter **MP\_compFFAdjust** to correct the compensation strength for lower or higher feed rates.

## Analog offset

The offset voltage required for analog axes is stored in **MP\_analogOffset**. You either enter these values manually or determine them by using the **offset adjustment** function.

During the offset adjustment, the control receives the axis offset values determined by the IPO and enters them in the parameters **MP\_analogOffset**.

For the offset adjustment, the axes must be in position feedback control.

To adjust the offset:

- ▶ Switch to the **Organization** mode of operation.



- ▶ Press soft key and enter the key number 75368



- ▶ Press the **ADJUST OFFSET** soft key.

The control opens the **Adjustment of analog axis offset** dialog box and displays the values determined.

Adjustmt. of analog axis offs.

Axis-X	<input type="text" value="-0.9"/>	mV
Axis-Y	<input type="text" value="2.3"/>	mV
Axis-Z	<input type="text" value="-3.6"/>	mV
Axis-C	<input type="text" value="-1.5"/>	mV
Axis-S	<input type="text" value="33.0"/>	mV

- ▶ Press the **OK** button to transfer the offset values to the parameters **MP\_analogOffset**.

The maximum permissible offset voltage in the control is +/- 1 V. If this voltage is exceeded, the **offset adjustment** function limits the value.

### MP\_analogOffset

Offset on analog axis  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: -1 to +1 [V]  
Default: 0 [V]  
Access: LEVEL3  
Reaction: RUN

### MP\_noOffsetAdjust

Excludes the axis from automatic offset adjustment  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: **TRUE**  
Axis will be excluded from offset adjustment.  
**FALSE**  
Offset of the axis is adjusted.  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

### Position loop resolution for analog axes

The analog voltage is subdivided 65536-fold with a 16-bit D/A converter. This results in a smallest voltage step of 0.15 mV.  
This results in the voltage delta U per position error or following error  $s_a$ :  
The control outputs one voltage per position error.

$$\Delta U = \frac{10\,000 \text{ [mV]}}{s_a [\mu\text{m}]}$$

If delta U is divided by the smallest possible voltage step (0.15 mV), the result is the number n of the possible voltage steps per position error.

## 6.16.23 Weakened field operation

### General Information

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPowerStage <b>ampVoltProtection</b>	401205

The parameter object CfgPowerStage is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Analog axes (**MP\_axisHw** = Analog)

Asynchronous motors are usually operated with a weakened field. This operating mode can become necessary for synchronous motors if the present inverter voltage does not suffice for the required rotational speed. Typical applications for this operating mode are high-speed synchronous spindle motors and "high-speed" torque motors.

For synchronous drives the operation with a weakened field is automatically activated if the value **installed – mode 2** has been entered in **MP\_ampVoltProtection**, and the desired speed makes it necessary. Under certain conditions a voltage protection module must be used.

Because of their design, the HEIDENHAIN EcoDyn motors are treated as a special case. They must always be operated with a weakened field, but no voltage protection module is necessary.

For HEIDENHAIN EcoDyn motors, enter **not installed – mode 3** in **MP\_ampVoltProtection**.

The speed-torque characteristics from the drive manufacturer indicate whether weakened-field operation is necessary. Among other information, they show the possible speeds in combination with the necessary inverter voltage.



#### Note

Please note that there are other possible settings for weakened-field operation with the CC 61xx, see "Peculiarities in weakened-field operation with CC 61xx and CC 424" on page 862.



## Using the voltage protection module

If the power supply fails during weakened-field operation, and the synchronous drive is running at a high speed at the same time, then the DC-link voltage can rise rapidly (generator effect of the drive). If this voltage rises to over 850 V, then inverters and possibly the motor itself can become damaged. Reliable protection against this is offered by a voltage protection module, which short-circuits the motor phases when the trigger threshold of 850 V is exceeded. (for example SM 110 or SM 130; see the "Inverter Systems and Motors" Technical Manual).

Whether a voltage protection module is necessary for a drive depends on the desired speed, the nominal speed **N-N** and the no-load voltage **U0** of the drive. See the motor table for these values.

The following formula calculates the motor speed at which a voltage greater than 850 V would be induced by the generator effect. If the desired motor speed is greater than the one calculated, then the voltage protection module (SM 110 or SM 130) **must** be used!

$$N_{max} = \frac{850 \text{ V} \times N_{noml}}{U_0 \times \sqrt{2}}$$

Please refer to the "Inverter Systems and Motors" Technical Manual to see which voltage protection module is needed for which motor types (depending on the maximum phase current of the SM 110 or SM 130).




### Warning

A braking resistor, such as PW xxx or UP 110, does not offer sufficient protection.

## Setting the weakened-field operation

When setting **MP\_ampVoltProtection** and **MP\_ampBusVoltage** for synchronous motors (SM), proceed as shown in the diagrams for commissioning.

### Default setting of MP\_ampVoltProtection:




- ▶ Mode 1:  
Enter **MP\_ampVoltProtection = not installed – mode 1** if you want to operate synchronous motors **without** a weakened field. **((1))** in the commissioning flow chart)  
Field weakening for synchronous motors is deactivated, i.e. the field weakening current is always 0, regardless of the speed and load. Use this entry also for all asynchronous motors. MP2160 is without effect on them.
- ▶ Mode 2:  
Enter **MP\_ampVoltProtection = installed – mode 2** if you want to operate the synchronous motor with a weakened field (check whether a voltage protection module must be used. **((2))** in the commissioning flow chart).  
This entry is intended for synchronous spindles and torque motors in turning mode. Here, field weakening is active in a wide speed range, i.e. the maximum speed  $n_{max}$  is much higher than the rated speed  $n_{rated}$  ( $n_{max} \gg n_{rated}$ ). The internal voltage  $U_{emk}$  at maximum speed in the motor leads to a considerable rise of the DC-link voltage if the power supply fails, so that the connected inverters and also the motor can get damaged. It is therefore necessary to install a voltage protection module (e.g. SM 110, see the "Inverter Systems and Motors" Technical Manual) as a protective measure.

The EcoDyn synchronous motors from HEIDENHAIN are operated with limited field weakening. No voltage protection module is necessary here.

- ▶ Select from the motor table the motors with the designation **QSY1xxx EcoDyn** or **QSY1xxx EcoDyn EnDat** for **MP\_motName**
- ▶ Enter **MP\_ampVoltProtection = not installed – mode 3** if you use HEIDENHAIN EcoDyn synchronous motors. **((3))** in the commissioning flow chart).  
This entry is intended for axis motors in EcoDyn operation. Here, field weakening is only active in a relatively small speed range, i.e. the maximum speed  $n_{max}$  is not significantly higher than the rated speed  $n_{rated}$  ( $n_{max} > n_{rated}$ ). The MANUALplus 620 calculates a voltage-dependent, maximum speed  $n_{maxUz}$ . This speed ensures that the internal voltage  $U_{emk}$  in the motor only leads to a limited rise of the DC-link voltage if the power supply fails. Using a voltage protection module is therefore not necessary. Please note that the voltage-dependent, maximum speed  $n_{maxUz}$  can be lower than the maximum speed in the motor table. Please take this into consideration during project planning.  
 $U_0$  = entry  $U_0$  (no-load voltage) of the motor from the motor table  
 $n_{rated}$  = entry N-N (rated speed) of the motor from the motor table  
 $U_Z$  = 800 V (maximum DC-link voltage if the power supply fails)

$$n_{maxUz} = \frac{800V \cdot n_{rated}}{\sqrt{2} \cdot U_0}$$

## Setting of MP\_ampBusVoltage:



### Regenerative module ((4) in commissioning flow chart)

The DC-link voltage for regenerative power modules are independent of the line voltage  $U_{Netz}$ . On regenerative HEIDENHAIN power modules it is 650 V (**MP\_ampBusVoltage** = 650) and on the regenerative Siemens modules 600 V or 625 V (**MP\_ampBusVoltage** = 600 / 625).

**Actual DC-line voltage on non-regenerative power modules** (in the commissioning flow chart = (5))

Entering the DC-link voltage in **MP\_ampBusVoltage** is also used by the control to ascertain the magnetizing current. At a line voltage of 400 V (interlinked), the rectified DC-link voltage is 565 V. If the fluctuation range of the line voltage is known (e.g. +/- 10 %), use the minimum value  $U_{Netz,Min}$  of the line voltage to calculate the DC-link voltage according to the following equation:

$$U_z = \sqrt{2} \cdot U_{NetzMin}$$

If in addition you use a series reactor—for example to comply with EMC standard—then remember that the DC-link voltage can be reduced. So enter, if possible, the measured value of the DC-link voltage. If a measurement is not possible, then reduce the value calculated on the basis of the line voltage by approx. 3 %.

Example: Line voltage  $U_{Netz} = 380 \text{ V} \Rightarrow$

$$\mathbf{MP\_ampBusVoltage} = 0.97 \cdot 537 = 521.$$

If the line voltage in the machine's work area is less than the line voltage during commissioning, enter the value of the DC-link voltage at its later location during commissioning.


**Stationary line voltage stable? ((6))** in the commissioning flow chart)

Any stationary fluctuating line voltage is to be accounted for by using the smallest occurring value for calculating the entry in **MP\_ampBusVoltage**, insofar as it has not already been accounted for through minimum line voltage. This ensures that the required magnetizing current is available, in particular during the acceleration phase. An excessively large DC-link voltage could lead to increased following error during acceleration and at high speeds.

**Line voltage stable under load? ((7))** in the commissioning flow chart)

If you use an unstable power network on the machine, it can reduce the line voltage under load (when the axes are accelerated) and therefore also reduce the DC-link voltage. So it might be necessary to adjust the entry in **MP\_ampBusVoltage** for the load. Compare the behavior of one axis during acceleration of only that axis (light load) with its behavior during acceleration of all axes, perhaps including the spindle (maximum load). If there are no differences in the following error or nominal current, the entry in **MP\_ampBusVoltage** can remain unchanged. If these signals show anything unusual (surge in current or following error), reduce the entry in **MP\_ampBusVoltage** accordingly.

### Feed axis (EcoDyn operation):



### **Feed axis in EcoDyn operation – medium utilization**

**MP\_ampVoltProtection = not installed – mode 3**

**((8))** in the commissioning flow chart)

After you have found the desired acceleration and jerk for the axis concerned, check the axis load during motion. To do so, reverse the axis up to maximum feed rate and record the torque current *InomI* on the internal oscilloscope. If the amount of torque current never exceeds approx. 70 % of the maximum current, there are enough reserves for the magnetizing components—the setting of MP2160 (=2) is completed. Please note: The maximum current is the lesser of maximum motor current and maximum power stage current.

### **Feed axis in EcoDyn operation – high utilization**

**MP\_ampVoltProtection = not installed – mode 3**

**((9))** in the commissioning flow chart)

However, if the torque current is greater than 70 % of the maximum current, record the actual current *IactI* on the internal oscilloscope to check whether it approaches the maximum current. The actual current contains both the torque current component as well as the magnetizing current component. If the amount of actual current never exceeds approx. 90 % of the maximum current, there are still enough reserves for the magnetizing components—the setting of MP2160 (=2) is completed here, too.

### **Feed axis in EcoDyn operation – high utilization**

**MP\_ampVoltProtection = not installed – mode 5**

**((10))** in the commissioning flow chart)

With the entry **MP\_ampVoltProtection = not installed – mode 5** you can activate an alternative algorithm for determining magnetizing current. This can lower the magnetizing current. The total actual current in the field weakening range falls with it.

### **Feed axis in EcoDyn operation – high utilization**

**MP\_ampVoltProtection = not installed – mode 5**

**((11))** in the commissioning flow chart)

If you succeed with **MP\_ampVoltProtection = not installed – mode 5** in limiting the actual current to less than 90 % of the maximum current at any time, there are enough reserves again for the magnetizing component—the setting of MP\_ampVoltProtection (**=not installed – mode 5**) is completed here.


### **Feed axis in EcoDyn operation – high utilization**

**MP2160 = not installed – mode 5**

**((12))** in the commissioning flow chart)

If the actual current stays over 90 % of the maximum current, the load on the drive can be reduced through a reduction of the acceleration and/or jerk.

**Synchronous spindle/torque motor:**





### **Synchronous spindle/torque motor**

**MP\_ampVoltProtection = installed – mode 2**

((13) in the commissioning flow chart)

When you have set the desired acceleration (and rounding, if required) for the respective drive, test if the motor accelerates to the required final speed with a steady increase in acceleration. "Steady increase in acceleration" means that there are no drops in the acceleration curve. The actual acceleration usually declines with increasing speed, however.

### **Synchronous spindle/torque motor**

**MP\_ampVoltProtection = installed – mode 2**

((14) in the commissioning flow chart)

Drops in the acceleration curve indicate an excessive magnetizing-current consumption. You can see this if it exceeds 90 % of the maximum current of the drive. You can display the magnetizing current on the internal oscilloscope of the control.

### **Synchronous spindle/torque motor**

**MP\_ampVoltProtection = installed – mode 4**

((15) in the commissioning flow chart)

If the maximum current is limited by the power module ( $I_{max}$  of power module  $\ll$   $I_{max}$  of motor) it can make sense to use a more powerful power module. As an alternative you can use the entry **MP\_ampVoltProtection = installed – mode 4** to activate an algorithm to reduce the magnetizing current.

### **Synchronous spindle/torque motor**

**MP\_ampVoltProtection = installed – mode 4**

((16) in the commissioning flow chart)

If you can attain a steady actual acceleration to the final speed with **MP\_ampVoltProtection = installed – mode 4** (or by installing a larger power module), there are enough reserves again for the magnetizing component—the setting of **MP\_ampVoltProtection (=installed – mode 4)** is completed here.

## MP\_ampVoltProtection

	Field weakening for synchronous motors Available from NCK software version: 597 110-05.
Format:	Selection menu
Selection:	<b>not installed – mode 1</b> (cf. iTNC 530: MP2160.x = 0) Mode 1: There is no voltage-protection module (SM). No field weakening possible. <b>installed – mode 2</b> (cf. iTNC 530: MP2160.x = 1) Mode 2: Voltage-protection module (SM) exists. Field weakening without speed limitation is possible. Use this mode for synchronous spindles and torque motors, for example. <b>not installed – mode 3</b> (cf. iTNC 530: MP2160.x = 2) Mode 3: There is no voltage-protection module (SM). Field weakening with speed limitation is possible. Use this mode for EcoDyn motors, for example. <b>installed – mode 4</b> (cf. iTNC 530: MP2160.x = 9) Mode 4: Like mode 2, but with minimized total current. <b>not installed – mode 5</b> (cf. iTNC 530: MP2160.x = 10) Mode 5: Like mode 3 but with minimized total current.
Default:	Not installed
Access:	LEVEL3
Reaction:	RESET





## 6.16.24 Motor with wye/delta switchover

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgServoMotor <b>starDelta</b>	401302

The parameter object CfgServoMotor is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Analog axes (**MP\_axisMode** = Analog)

Define different parameter sets if a wye/delta connection switchover is carried out for an asynchronous motor. Use the Modules 9434 and 9435 to activate the parameter set for operation with wye connection or operation with delta connection (see "Switching Parameter Sets" on page 398).

For the two operating modes, you can use different machine parameters for the current and speed controllers:

The switchover can be carried out during standstill or with a revolving spindle.



### Danger

The contactor for the wye/delta switchover must not be switched under load!

With Module 9173, a monitoring function dependent on the speed can be realized for the wye/delta switchover of the spindle. You can interrogate the current spindle status with reference to the wye/delta switchover with Module 9174.

Performing a wye/delta connection switchover:

- ▶ Switch the drive controller off by using **PP\_AxDriveOnRequest**.
- ▶ Use Module 9434 to select the corresponding parameter set.
- ▶ Use Module 9435 to check if this parameter set is active.
- ▶ Switch the drive controller back on by using **PP\_AxDriveOnRequest**.

### MP\_starDelta

Motor with wye/delta switchover  
 Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **star-connection**

Wye connection

**delta-connection**

Delta connection

Default: star-connection

Access: LEVEL3

Reaction: RESET



### Module 9173 Speed-dependent monitoring of the wye/delta switchover

Module 9173 is used to realize a monitoring function dependent on the speed for the wye/delta switchover of the spindle.

You can use Module 9174 to determine a requirement for switching. Module 9174 supplies the current status for wye/delta operation.

Do not call the module cyclically. A single call is enough for activation, deactivation or changing the setting.

Call:

```
PS    B/W/D/K  <>Mode>
        Bit 0 = 0: Monitoring off
        Bit 0 = 1: Monitoring on
        Useful values for <Mode> include:
        xx0 = Deactivate monitoring
        001 = Monitoring on, Switchover compatible
PS    B/W/D/K  <>Switchover speed from wye to delta operation>
PS    B/W/D/K  <>Switchover speed from delta to wye operation>
CM    9173
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Speed-dependent monitoring activated
	1	Faulty call parameters, see error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode (W1022)	1	Invalid shaft speeds were given (e.g. wye switchover speed >= delta switchover speed, or shaft speed negative)

### Module 9174 Read current spindle status

With Module 9174 you read the current spindle status in reference to wye/delta operation.

In order to receive one of the two "Request switchover" status values, you must activate the speed-dependent wye/delta switchover via Module 9173.

Call:

CM 9174

```
PL    B/W/D    <>Status>
        0: Spindle in wye operation
        1: Request for wye/delta switchover
        2: Spindle in delta operation
        3: Request for delta/wye switchover
```

## 6.16.25 Speed-dependent switching of the PWM frequency



### Note

This function is only available when using the CC 61xx, UEC 11x or CC 424 controller unit!

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgServoMotor	
<b>motSpeedSwitchOver</b>	401318
<b>motSpeedSwitchBack</b>	401319

This function is used with high-speed spindle drives. This switchover is only possible for double-speed control loops. (Software option)

In **MP\_motSpeedSwitchOver** and **MP\_motSpeedSwitchBack**, a speed-dependent hysteresis for switching the PWM frequency is specified. It only takes effect if the value in **MP\_motSpeedSwitchBack** is less than the value in **MP\_motSpeedSwitchOver**.

This function is associated with **MP\_iCtrlPwmType** and **MP\_iCtrlPwmInfo**. Only if **MP\_iCtrlPwmType** = 2, and **MP\_ampPwmFreq** ≤ 5 kHz, does the switching of the PWM frequency take effect. Please note that the adjustment of the current controller (**MP\_iCtrlPropGain**, **MP\_iCtrlIntGain**) is based on the lower PWM frequency ≤ 5 kHz. Adaptation of the current-controller parameters and consideration of the power-module derating are performed automatically.

Using this function provides several benefits:

- At lower speeds and therefore a lower PWM frequency, the power module provides a comparatively high current. This results in a relatively high maximum motor torque.
- On the one hand, losses due to harmonics in the motor become more important as the speed increases, and on the other hand, the relationship between the electrical frequency and the PWM frequency worsens. These two disadvantages can be counteracted by increasing the PWM frequency. The resulting reduction of the current normally is insignificant, since in part due to motor characteristics, very high motor currents are mostly no longer possible or needed at higher speeds.



### Note

The speed-dependent switching of the PWM frequency is only permitted with power modules from HEIDENHAIN.




### Danger

Speed-dependent switching of the PWM frequency with non-HEIDENHAIN power modules can lead to malfunctions, and possibly to damage of the power modules. Therefore, only use this function with power modules from HEIDENHAIN.

When determining the optimum switching speed for the PWM frequency, you should consider that the maximum motor current decreases as the speed rises, due to the finite DC-link voltage.

The current for the drive depends on the maximum permissible motor current and power-module current. The smaller of the two values limits the current for the drive. The value of the maximum power-module current is reduced by approx. 30 % because of the derating when doubling the PWM frequency.

The optimum switching speed results from the intersection of the maximum current curve of the motor with the maximum current curve of the power module for the high PWM frequency. You can determine the maximum current curve of the spindle motor by using the TNCscopeNT software. Record the current  $I_{nom}/S$  in dependency of the speed. The spindle must be accelerated to the maximum speed so that the derating behavior can be seen in the curve. The figure shows the behavior when the values entered for the switching speed (**MP\_motSpeedSwitchOver** and **MP\_motSpeedSwitchBack**) are too low. This then results in a speed range where the current for the motor is less than the permitted and maximum current, resulting in inconsistencies in the motor's torque behavior.



- 1: Red line: Maximum current for the drive, resulting from the entries in **MP\_motSpeedSwitchOver** and **MP\_motSpeedSwitchBack**.
- 1: Broken line: Maximum possible current for the drive ( $I_{max}$  of motor)
- 2: Switching point for the PWM frequency set too low
- 3: Optimum switching point for the PWM frequency
- 4: Maximum power-module current at low PWM frequency
- 5: Maximum power-module current at high PWM frequency ( $I_{max}$  of power module)

Summary:

- The speed is switched at the intersection of the two current curves (I<sub>max</sub> of motor, I<sub>max</sub> of power module) so that no inconsistencies in the torque behavior of the motor occur.
- For better controllability (no harmonics at higher PWM frequencies), it might already make sense to switch at lower speeds.
- The best speed to switch at must be determined by experimenting. The value above should serve as an initial value.

## Overcurrent switch-off

The momentary current is monitored by the CC, and the following errors now lead to an immediate cutoff:

- Excessive actual current: If the actual current exceeds the maximum permissible current (depending on the power module and motor), it triggers the error 0xC3C0 (Motor current too high).
- Excessive current offset: If the offset current exceeds the permissible threshold (50 % of the maximum current), the error 0xC600 (Current offset too high) is triggered. One possible reason could be a phase to ground fault.

### MP\_motSpeedSwitchOver

Shaft speed for PWM switchover  
Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 0 to 100 000 [rpm]  
Specifies the shaft speed at which the PWM frequency is switched to twice the PWM frequency. Use only in combination with HEIDENHAIN power modules!  
Function only available in combination with CC 6106 or CC 424.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### MP\_motSpeedSwitchBack

Shaft speed for PWM switchover  
Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 0 to 100 000 [rpm]  
Specifies the shaft speed at which the factor 2 PWM frequency is switched to a factor 1. Use only in combination with HEIDENHAIN power modules!  
Function only available in combination with CC 6106 or CC 424.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET





## 6.16.26 TRC – Torque Ripple Compensation

### General Information



#### Note

This function is only available when using the CC 61xx, UEC 11x or CC 424 controller unit!


Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgControllerComp <b>compTorqueRipple</b> <b>compSwitchOff</b>	     401412 401414

Certain motors with permanent magnets (linear, torque and some synchronous motors) have an increased, position-dependent variation of the motor torque (not QSY motors from HEIDENHAIN). This can be the result of two things:

- During idle running, the cogging due to attractive forces of the permanent magnets
- When under load, the torque ripple from higher harmonics, resulting from the opposing electromotive forces (generator effect)

In practice, both causes always occur together, i.e. the torque of the motor is subject to periodic oscillations. This can have a negative effect on the controllability of the motor, which can result in a greater following error, and under circumstances, lower surface quality of the workpiece.

To compensate for the **cogging**, a compensation current ascertained specifically for each motor can now be added.



## Activating TRC

TRC can only be activated via a special compensation file. The settings in this file can only be made with the TNCopt commissioning software from HEIDENHAIN (as of version 2.3). Please refer to the documentation for the TNCopt software. The compensation current is determined with a special method for measurement, and the parameters for calculating this compensation are stored in a compensation file on the control. The MANUALplus 620 then takes these parameters into account when calculating the controller parameters.

- Directory: The MANUALplus 620 saves the compensation files in the directory configured under Paths / CfgOemPath / **MP\_oemTable**.  
Default: %OEM%\table
- File name: **xx\_<Motor\_name>.TRC**
  - **xx**: Index of the axis (e.g. 00 = 1st axis, X axis)
  - **<Motor\_name>**: Name of the motor from the motor table (max. 29 characters)
  - **.TRC**: File extension for "Torque Ripple Compensation"

An entry in **MP\_compTorqueRipple** specifies whether torque ripple compensation is to be performed for an axis. If the optional parameter **MP\_compTorqueRipple** is not part of the configuration, no compensation current is calculated for the axis concerned.

### Example:

**MP\_compTorqueRipple:**      **00\_MotNameAusMotTab**



#### Note

- The TRC function can only be used with PWM frequencies up to 5 kHz.
- A TRC file can only be used on the control on which the adjustment has been made.
- A TRC file must be re-created if the motor or even the encoder is exchanged.
- A TRC file can only be generated for synchronous motors or for linear or torque motors.



## Switching off TRC

The TRC can be switched off by setting the machine parameter **MP\_compSwitchOff**, bit 0.

### MP\_compTorqueRipple

Name of the file for "torque ripple compensation" (TRC)  
Available from NCK software version: 597 110-03.  
Format: String  
Input: xx\_<MotorNamefromMotorTable>.TRC (generated in TNCopt)  
No entry: No compensation  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

### MP\_compSwitchOff

Switch-off of compensation in speed controller or current controller  
Format: String  
Input: Binary value  
Bit 0: Torque ripple compensation  
0: Torque ripple compensation is switched on  
1: Torque ripple compensation is switched off  
Default: %00000000000000000000000000000000  
Access: LEVEL3  
Reaction: RUN

## 6.16.27 Torsion compensation



### Note


This function is only available when using the CC 61xx, UEC 11x or CC 424 controller unit!

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgControllerComp <b>compTorsionFact</b>	401413

With **MP\_compTorsionFact** you can perform a torsion compensation between the position and speed measuring systems.

The torsion compensation regulates the difference in position that results from the elasticity between the motor (rotary encoder) and the position measuring system. An additional torsion motion is added to the speed controller.

Enter a specific drive elasticity factor in **MP\_compTorsionFact**. The block diagram shows how the torsion compensation works.



- 1: Torsion compensation
- 2: Position controller
- 3: Speed controller
- 4: Current controller – power module
- 5: Motor
- 6: Elastic coupling
- 7: Machine
- 8: Linear encoder



Adjusting **MP\_compTorsionFact** only makes sense when all other feedforward-control parameters under **CfgControllerComp** have been adjusted. Moreover, torsion compensation via **MP\_compTorsionFact** should not be used if stick-slip friction is only compensated via **MP\_compFrictionT1** (**MP\_compFrictionT2** = 0).

#### **MP\_compTorsionFact**

Torsion compensation between position encoder and speed encoder  
Available from NCK software version: 597 110-03.  
Format: Numerical value  
Input: 0.001 to 100.000 [ $\mu\text{m}/\text{A}$ ]  
0: Not active  
Default: No value, parameter optional (= 0)  
Access: LEVEL3  
Reaction: RUN

## 6.17 Monitoring Functions

### 6.17.1 Monitoring the drives

Settings in the configuration editor	MP number
System CfgHardware <b>I32stopsMonitoring</b>	100102

The NC monitors the dynamic response of the machine by using the following monitoring functions:

- Position monitoring
- Standstill monitoring
- Movement monitoring

If the specified values are exceeded, it displays an error message and stops the machine.

You can switch off the monitoring functions for individual axes or for all axes (globally) if drive enabling is canceled ( $I32 = 0$ ).



#### Warning

Safe machine operation is not possible if the monitoring functions are switched off. Uncontrolled axis movements are not detected.

#### Switching off monitoring functions globally

The monitoring functions for all drives are switched off if  $I32 = 0$  and **MP\_I32stopsMonitoring** = On:

#### **MP\_I32stopsMonitoring**

Behavior of input I32 (drive enabling)  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **on**  
If  $I32 = 0$ , all monitoring functions that can be influenced by the PLC are switched off.  
**off**  
Input I32 has no effect on the monitoring functions.

Default: off

Access: LEVEL3

Reaction: RESET



**Switching off monitoring functions for individual axes**

Set **PP\_AxDeactivateMonitoring** to switch off monitoring for individual axes.

PLC operand / Description	Type
PP_AxDeactivateMonitoring Deactivate monitoring functions 0: Monitoring functions active 1: Monitoring functions inactive	M

The following table shows the status of monitoring as a function of the axis-specific PLC operand **PP\_AxDeactivateMonitoring** and drive enabling (I32) if **MP\_I32stopsMonitoring** = On.

Monitoring functions for		PP_AxDeactivate Monitoring =	MP_I32stopsMonitoring = On; I32=
Individual drive motor	All drive motors		
Inactive	Inactive	0	0
Active	Active	0	1
Active	Inactive	1	0
Inactive	Active	1	1

## 6.17.2 Position monitoring

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgPosControl	
<b>servoLagMin1</b>	400802
<b>servoLagMax1</b>	400803
<b>servoLagMin2</b>	400804
<b>servoLagMax2</b>	400805
CfgControllerAuxil	
<b>driveOffLagMonitor</b>	400601
<b>maxPosDiff</b>	400605
<b>posDiffCountDir</b>	400604
CfgReferencing	
<b>endatDiff</b>	400405



### Note

The parameters **MP\_maxPosDiff** and **MP\_posDiffCountDir** are available only with digital drive control.

The parameter object

- CfgControllerAuxil is not required for:
  - Virtual axes (**MP\_axisMode = Virtual**)
  - Axes that are only for display (**MP\_axisMode = Display**)
- CfgReferencing is not required for:
  - Virtual axes (**MP\_axisMode = Virtual**)

The axis positions are monitored by the MANUALplus 620 as long as the control loop is closed.

The input values for position monitoring depend on the maximum possible following error (servo lag). Therefore the input ranges for operation with following error and velocity feedforward are separate.

For both modes of operation there are two range limits for position monitoring.

If the first limit (**MP\_servoLagMin1, MP\_servoLagMax1**) is exceeded, the warning **Excessive servo lag in [axis]** appears. The machine stops.

This message can be cleared. An actual-to-nominal value transfer is then executed for the respective axes.


If the second limit (**MP\_servoLagMin2, MP\_servoLagMax2**) is exceeded, the emergency-stop error message "Excessive servo lag in [axis]" appears.





The control-is-ready signal output is reset. The machine stops. You cannot clear this message. You must restart the control to correct the error.

- ▶ In the machine parameters given below, define two range limits for position monitoring.
- ▶ Adjust the input values to the machine dynamics.



**MP\_servoLagMin1** and  $\text{MP\_servoLagMin2}$  apply at a constant feed rate, whereas **MP\_servoLagMax1** and  $\text{MP\_servoLagMax2}$  apply to changes in the feed rate.

#### **MP\_servoLagMin1**

Minimum for following-error monitoring (clearable)  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.0000 to 100.0000 [mm] or [°]  
Default: 1 [mm] or [°]  
Access: LEVEL3  
Reaction: RUN

#### **MP\_servoLagMax1**

Maximum for following-error monitoring (clearable)  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 100 [mm] or [°]  
Default: 5 [mm] or [°]  
Access: LEVEL3  
Reaction: RUN

### MP\_servoLagMin2

Minimum for following-error monitoring (emergency stop)  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 100 [mm] or [°]  
Default: 1 [mm] or [°]  
Access: LEVEL3  
Reaction: RUN

### MP\_servoLagMax2

Maximum for following-error monitoring (emergency stop)  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 100 [mm] or [°]  
Default: 5 [mm] or [°]  
Access: LEVEL3  
Reaction: RUN

## Clamped axes, hanging axes

Clamped axes or hanging axes are monitored when the drive motor is switched off if **MP\_driveOffLagMonitor** is activated. The value from **MP\_servoLagMax2** is monitored.

### MP\_driveOffLagMonitor

Following-error monitoring with drive switched off  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: **on**  
Monitoring of hanging axes is active  
**off**  
Monitoring of hanging axes is not active  
Default: off  
Access: LEVEL3  
Reaction: RUN



#### Note

The monitoring functions for hanging axes can **not** be switched off by using **MP\_I32stopsMonitoring**.

## Difference between position at switch-on and shutdown

When the MANUALplus 620 is switched off, the actual position of the axes is saved with an absolute encoder. During switch-on it is compared with the position values read by the encoder.

If the positions differ by more than the difference defined in MP\_endatDiff, a pop-up window appears with both positions. The new position must be confirmed with a soft key. If it is not confirmed, the error message **Check the position encoder <axis>** appears.

The pop-up window may appear, stating that the positions at switch-on and shutdown differ by more than **MP\_endatDiff**. If the motor is located at the correct position, you can confirm the message.



### Note

The cause for one of the above listed messages can also be a defect in the encoder or control.

### MP\_endatDiff

Permissible difference of EnDat encoders during switch-on  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -100 000.000 000 000 to +100 000 [mm] or [°]  
0: Monitoring is switched off  
Default: 0  
Access: LEVEL3  
Reaction: REF

## Determining the difference between speed and position encoder

If shaft-speed and position measuring systems are connected to a machine, then the MANUALplus 620 can ascertain and monitor deviations between the two systems. These differences can be displayed in the oscilloscope (**PosDiff** oscilloscope signal).

- ▶ Specify in **MP\_maxPosDiff** the maximum permissible position difference in [mm] between the position and shaft-speed measuring systems.
- ▶ The **MP\_maxPosDiff** parameter is optional. Deactivate the parameter in order to switch monitoring off.

### MP\_maxPosDiff

Maximum position difference between position and shaft-speed measuring system  
Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 0.000 to 100 000.000 [mm]  
(max. 9 decimal places are permissible)  
0: Monitoring is switched off

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

In some situations it may occur that the interpolator cannot clearly recognize if the position or shaft-speed measuring system is counting in the opposite direction. That is why you can configure the counting direction of the motor encoder in the **MP\_posDiffCountDir** parameter.

- ▶ Use the integrated oscilloscope (**PosDiff** signal) to inspect the position deviation between the shaft-speed and position measuring system.

If you determine via the oscilloscope that the actual position of the axis "wanders," then you must invert the parameter **MP\_posDiffCountDir**.

### MP\_posDiffCountDir

Counting direction of the motor encoder  
Available from NCK software version: 597 110-03.

Format: Selection menu  
Selection: **positive**  
Motor encoder counts in positive direction  
**negative**  
Motor encoder counts in negative direction

Default: positive  
Access: LEVEL3  
Reaction: REF

### 6.17.3 Movement monitoring

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgEncoderMonitor <b>movementThreshold</b> <b>thresholdDistance</b>	    400705 400706

Movement monitoring is possible during operation both with velocity feedforward and with following error. This requires, however, that position control occurs in the interpolator of the MC, and not in the CC.

If the **MP\_movementThreshold** parameter is set to a value greater than 0, the manipulated value of the position controller is totaled in the IPO clock as soon as the threshold configured in the parameter is exceeded. In **MP\_thresholdDistance** you enter the distance at which the comparison is to be performed, and so define the monitoring cycle.

The MANUALplus 620 now calculates a nominal path and compares it with the actual path traversed, based on the distance defined in the optional parameter **MP\_thresholdDistance**. If **MP\_thresholdDistance** is not defined, the default distance of 5 mm is effective.

An error message is output if the actual path traversed is...

- less than a quarter of the nominal path  
or
- four times greater than the nominal path.

If the encoder is defective, the axis moves no more than the distance defined in **MP\_thresholdDistance**.

Intentional movements smaller than indicated in **MP\_movementThreshold** are ignored.

- ▶ In **MP\_movementThreshold**, enter the distance over time at which movement monitoring is to start.
- ▶ Enter in **MP\_thresholdDistance** the distance at which the nominal and actual paths are to be checked.



#### Warning

- If **MP\_movementThreshold = 0**, movement monitoring is not active.
- If you are using drive motors with digital interface, set **MP\_movementThreshold** to 0 and use **MP\_vCtrlFiltLowPassT** of the speed controller.

### **MP\_movementThreshold**

Threshold above which the movement monitoring functions  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 36 000 000 [mm/min] or [°/min]  
0: Monitoring switched off  
Default: 199.98 [mm/min] or [°/min]  
Access: LEVEL3  
Reaction: RUN

### **MP\_thresholdDistance**

Tolerance at and above which the following error is included  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 36 000 000 [mm] or [°]  
Default: 5 [mm] or [°]  
Access: LEVEL3  
Reaction: RUN



## 6.17.4 Standstill monitoring

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgControllerAuxil <b>checkPosStandstill</b>	400602

Standstill monitoring is effective during operation both with velocity feedforward and with following error, as soon as the axes have reached the positioning window.

If the position difference is greater than the value defined in **MP\_checkPosStandstill**, the error message **Standstill monitoring in [axis]** appears. The message also appears if, while moving to a position, an overshoot occurs that is larger than the value entered in **MP\_checkPosStandstill**, or if the axis moves in the opposite direction when beginning a positioning movement.

Manually moving a spindle while the control loop is open (e.g. during a manual tool change) causes following error to build up. This following error could trigger activation of the standstill monitoring. Therefore, monitoring is only active in the following situations:

- If the axis is not a spindle and the parameter **MP\_checkPosStandstill** > 0. Here it is not relevant whether the axis is in a control loop or not.
- If the affected axis is a spindle and the parameter **MP\_checkPosStandstill** > 0, then the axis must be in a closed loop for standstill monitoring to be effective.
- ▶ Enter in **MP\_checkPosStandstill** the threshold from which the standstill monitoring should go into effect:

### **MP\_checkPosStandstill**

Standstill monitoring  
 Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0: Monitoring switched off  
 0.001 000 000 to 10 000 [mm]

Default: 10 000 [mm]

Access: LEVEL3

Reaction: RUN

## 6.17.5 Positioning window

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgControllerTol <b>posTolerance</b> <b>timePosOK</b>	    401101 401102

The parameter object CfgControllerTol is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)

If the axes have reached the positioning window after a movement, the status is shown in **NN\_AxInPosition**. This also applies to the status after the machine control voltage is switched on.

The NC resets **NN\_AxInPosition** as soon as you start a positioning movement or traverse the reference marks.

In the **Electronic Handwheel** mode of operation, **NN\_AxInPosition** for the current handwheel axis is reset.

**NN\_AxInPosition** is not set for contours that can be machined with constant surface speed.

### Axes in position

The MANUALplus 620 reports "axis in position" (**NN\_AxInPosition**), if

- the axis is stationary for the time **MP\_timePosOK** within the positioning window **MP\_posTolerance**
- no axis direction key for the axis is pressed.

After the position has been reached, the control begins running the next block. The position controller can correct a disturbance inside this window without activating the "Return to the Contour" function. **NN\_AxInPosition** is reset as soon as there is a request to move an axis (**NN\_AxMotionRequest** = 1).

- ▶ Specify in **MP\_posTolerance** the size of the positioning window.
- ▶ Specify in **MP\_timePosOK** how long the axis is to remain within the positioning window.

The control window is monitored during positioning as concerns various parameters. A following error is calculated from the control parameters, and compared with the actual following error. If the deviation is greater than the calculated value as well as the parameter value in **MP\_posTolerance**, then the error message **[Axis] does not attain the control window** is output after 20 seconds.





This error message can be cleared, and traverse can continue.

### MP\_posTolerance

Positioning window  
 Available from NCK software version: 597 110-01.  
 Format: Numerical value  
 Input: 0.001 to 100.000 [mm]  
 Default: 0.005  
 Access: LEVEL3  
 Reaction: RUN

### MP\_timePosOK

Hysteresis time for "positioning window reached"  
 Available from NCK software version: 597 110-01.  
 Format: Numerical value  
 Input: 0.000 to 20.000 [s]  
 Default: 0.010 [s]  
 Access: LEVEL3  
 Reaction: RUN

PLC operand / Description	Type
NN_AxInPosition Axis in position 0: Axis not in positioning window 1: Axis in positioning window	M

### Axis movement by interpolator

If the interpolator wants to move the axes, the markers **NN\_AxMotionRequest** or **NN\_SpiMotionRequest** are set. The PLC then switches on the drive, activates the control loop, releases the brake, and enables the feed rate or spindle.


If a spindle is moved by the NC and not by the PLC program, the **NN\_SpiMotionRequest** marker is set. This allows the PLC program to decide when the spindle drive is to be switched on.

PLC operand / Description	Type
NN_AxMotionRequest Axis movement by interpolator 0: No axis movement by interpolator 1: Axis movement by interpolator	M
NN_SpiMotionRequest Spindle movement by interpolator 0: No spindle movement by interpolator 1: Spindle movement by interpolator	M

## Axes in motion

During an axis movement, the NC sets NN\_AxInMotion.

PLC operand / Description	Type
NN_AxInMotion Axes in motion 0: Axis not in motion 1: Axis in motion	M



## 6.17.6 Monitoring of the power supply unit

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPowerStage <b>ampAcFailSelection</b>	401207

The parameter object CfgPowerStage is not required for:

- Virtual axes (MP\_axisMode=Virtual)
- Axes that are for display only (MP\_axisMode=Display)
- Analog axes (MP\_axisHw=Analog)

The rectified supply voltage of the power supply unit is monitored. The supply voltage must lie within a defined range (400 V +/- 10 %). If this is not the case the power supply unit reports an AC fail (PF.PS.AC).

At the same time, the DC-link voltage is monitored:

- If approx. 760 V– (UV 120, UV 140, UV 150, UR 2xx: approx. 800 V) is exceeded, the NC revokes the pulse release (reset) for the IGBT of the power module. The motors coast out of loop to a stop. No energy is returned to the dc link.
- If the DC-link voltage falls below approx. 385 V– (UV 120, UV 140, UV 150, UR 2xx: approx. 410 V), the power supply unit reports a powerfail (PF.PS.ZK signal)
- If the DC-link voltage falls below approx. 155 V– (UV 120, UV 140, UV 150, UR 2xx, UV 105: approx. 200 V), the control is reset (signal RES.PS).
- Below approx. 135 V– (UV 120, UV 140, UV 150, UR 2xx, UV 105: approx. 180 V), the power supply unit switches off.

The UV 105 power supply unit reports a powerfail if the DC-link voltage is < approx. 385 V and the supply voltage is < approx. 330 V.

- ▶ Define in **MP\_ampAcFailSelection** which inverter signal is to trigger the **Powerfail** on the control.

Inverter signal	Meaning
AC fail (PF.PS.AC)	Failure of supply voltage for inverter
Powerfail (PF.PS.ZK)	DC-link voltage failure

Since the AC-fail signal is reported to the control before the powerfail, the MANUALplus 620 has more time to react to the subsequent DC-link voltage failure.



#### Note

Only certain HEIDENHAIN power supply units provide the AC-fail signal (see the Technical Manual for "Inverter Systems and Motors"). If you are using power supply units that do not provide this signal, you must not select the AC-fail signal in **MP\_ampAcFailSelection**.

If a power fail is triggered on the control, all drives are brought to a controlled stop. The PLC outputs are switched off and the control freezes to ensure that the hard disk can no longer be accessed.

The MANUALplus 620 must be turned off and on again.

- ▶ Define in **MP\_ampAcFailSelection** whether the powerfail in the control is generated via the AC-fail and/or the powerfail signal of the power module.

#### **MP\_ampAcFailSelection**

Signal for powerfail  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **AC fail only generated**  
Only AC-fail signal  
**power fail and AC fail generated**  
Powerfail and AC-fail signals  
**AC fail / power fail inactive**  
AC fail and powerfail deactivated  
**power fail only generated**  
Only powerfail signal

Default: AC fail only generated

Access: LEVEL3

Reaction: RESET



### Module 9167 Monitoring of DC-link voltage

With this module you can switch the DC-link voltage monitoring for powerfail ( $U_z < \text{approx. } 385 \text{ V or } 410 \text{ V}$ ) on and off.

If you don't call the module during the first PLC cycle, the supply voltage monitoring is automatically started after the first PLC cycle.

Call:

PS    B/W/D/K   <>Command code>  
                  0: DC-link voltage monitoring for >385 V– off  
                  1: DC-link voltage monitoring for >385 V– on  
  
CM    9167  
PL    B/W/D    <>Error code>  
                  0: Command executed  
                  -1: Transferred parameter invalid

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	DC-link voltage monitoring on or off
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Transferred parameter invalid

## 6.17.7 Temperature monitoring

### Temperature of the MC

The internal temperature of the MC is continuously monitored. At about 55 °C the early warning **Temperature warning** appears. If the temperature does not fall below 55 °C, the warning is reactivated after two minutes. Beginning at about 60 °C the error message **Temperature too high <temperature> °C** appears and an emergency stop is triggered. If the temperature does not fall below 60 °C when the machine is switched on again, the error message reappears after 10 to 20 seconds.

### Interrogate the values of the internal ADCs

Module 9133 allows you to interrogate the internal values of the analog-to-digital converter of the MC.

#### Module 9133 Interrogate the values of the internal ADC

Call:

```
PS    B/W/D/K  <>Code>
        0: Internal temperature sensor in [°C]
        1: Temperature CPU1 (basic PCB) in [°C]
        2: Temperature CPU2 (additional PCB) in [°C]
        3: Voltage of buffer battery in [mV]
```

```
CM    9133
```

```
PL    B/W/D    <>Value>
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Value ascertained
	1	Value could not be determined; error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid code programmed
	8	No second processor present (for code 2)

## Motor temperature

To measure the motor temperature, a KTY 84 must be connected at pins 13 and 25 of X15 to X20, X80 to X83. The temperature value is ascertained at least once per second. The maximum permissible motor temperature is taken from the motor table.

As soon as the given temperature is exceeded, the blinking error message **MOTOR TEMPERATURE <AXIS> TOO HIGH** appears and the drives are automatically switched off.

Appropriate measures can be taken before the motor reaches the maximum temperature.

### Module 9165 Read the temperature of the drive motor

The module provides the temperature of a drive motor controlled by the integral current controller in degrees Celsius.

Constraints:

- The measuring range is 0 to 255 °C.
- For non-existing axes the value 0 °C is read.
- The temperature value is measured every 5 seconds.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Call:

PS B/W/D/K <>Axis>  
Index from CfgAxes/axisList

CM 9165

PL B/W/D <>Temperature>  
Range: 0 to 255 °C

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	No error
	1	Control has no current controller

## Temperature of the power module's heat sink

At X51 to X60 the temperature warning signal is available at pin 10a.

If the permissible temperature of the heat sink on the power module is exceeded, this signal is reset.



### Warning

To avoid destroying the power module, the drives must be brought to a standstill immediately after a temperature warning.

Data on maximum permissible temperatures are available from the manufacturer of your power supply unit.

The temperature warning signal is not evaluated in the NC.

- Use Module 9160 (recommended, see "Module 9160 Status request of temperature monitoring and I2t monitoring" on page 971) or Module 9360 to interrogate the temperature warning, and take appropriate measures.

### Module 9360 Monitor the temperature of the power modules

This module provides the temperature of the power modules. If the temperature is exceeded (ERR\_TEMP signal at X51 to X60), the axis-specific bits are reset.

Call:

CM 9360

PL D <>Temperature monitoring in bit code>

Bit 15876543210

Axis:Sxxxxx987654321

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	No error
	1	Control has no current controller





## 6.17.8 I<sup>2</sup>t monitoring

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgServoMotor <b>motFactorI2t</b>	401304
CfgPowerStage <b>ampFactorI2t</b>	401208

The parameter objects CfgServoMotor and CfgPowerStage are not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Analog axes (**MP\_axisHw** = Analog)

### General Information


HEIDENHAIN inverter systems feature individual I<sup>2</sup>t monitors, one for each power module and motor.

### Function

An I<sup>2</sup>t monitor calculates and supervises the temperature pattern in a thermal motor or power-stage model during operation, even if temperature measurement is also provided by the hardware.

The basis for calculation are the active current, the rated or stall current, (multiplied by MP\_motFactorI2t for motors and by MP\_ampFactorI2t for power modules) and a device-specific temperature model. A first-order temperature module is available for monitoring power modules, first and second-order modules are available for motors. These models make it possible to permanently calculate the temperature of the stator winding in the motor or the semiconductor in the power module.

## Temperature model in an example comparison (motor)



The  $I^2t$  monitor responds if this calculated temperature exceeds a certain limit.

Because temperature increase and heat dissipation are uneven when the motor is stationary or moving slowly, the  $I^2t$  monitor distinguishes between standstill and traversing mode.

This limit range is defined in a motor table or power module table. The following entries are important:

- F-AC (**transition frequency in traversing mode [Hz]**)
- F-DC (**transition frequency at standstill [Hz]; only CC 424**)


## Fundamentals

The following graphics illustrate these parameters in relation to the reference voltage. Remember here that the parameters of the CC 422 may differ from those of the CC 61xx or CC 424.


With the CC 61xx and CC 424 it is possible to use an interpolated current range for the transition from standstill to traverse. This allows a more exact calculation of the temperature model.

For the CC 422, no difference is made between F-DC and F-AC. Instead, F-AC is used as a rigid limit frequency for the transition between standstill and traversing mode.

If there is no stall torque value given in the motor table, the following model of current (with respect to the rated current) is used to calculate the temperature in the motor. The factors for  $MP\_motFactor12t$  and  $MP\_ampFactor12t$  are not yet taken into account.



If the stall current value is given in the motor table, the following model of current (with respect to the stall current) is used to calculate the temperature in the motor. This is only used for synchronous motors, however. For asynchronous motors the above model of current applies, which is used if no stall current is given. For synchronous motors, the factors from MP\_motFactorI2t and MP\_ampFactorI2t are not yet taken into account in the following description.



### Commissioning and evaluation

- ▶ Enter in **MP\_motFactorI2t** the factor for the  $I^2t$  monitoring of the motor. The input value is a factor for the reference current (1 = 100% of the motor's standstill current or rated current). If you enter zero, the  $I^2t$  monitoring for the motor (not for the power module) is switched off.
- ▶ Enter in **MP\_ampFactorI2t** the factor for the  $I^2t$  monitoring of the power module. The input value is a factor of the power module's rated current (1 = 100%). If you enter zero, the  $I^2t$  monitoring for the power module (not for the motor) is switched off.
- ▶ All required entries for calculation of a temperature model have to be available in the motor table or power module table (see "Temperature models" on page 973).
- ▶ Use Module 9160 (recommended) or Module 9367 to interrogate the  $I^2t$  monitoring (see "Module 9160 Status request of temperature monitoring and I2t monitoring" on page 971).

## Limit values

The limit values for the  $I^2t$  value (dimension for the permissible temperature in the device [%]) are handled by the NC side of the control and are composed of the following:


- Value exceeds 100%: An axis-specific  $I^2t$  early warning is sent to the PLC (for evaluation and possible countermeasures such as reduction of the feed rate with error message by PLC program with the aid of PLC Module 9367). If the value does not exceed 110% and falls below 90%, the axis-specific early warning is reset.
- 110%: An NC stop is triggered and the drives are switched off.



### Note

In the oscilloscope you can display the current value of the  $I^2t$  monitoring of the motor and power module, as well as the current load of the drive.

### Motor overload with $I^2t$ monitoring



**Machine  
parameters**

**MP\_motFactorI2t**

Reference value for I<sup>2</sup>t monitoring of motor  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 1000 [· rated or stall current of the motor]  
Default: 0  
Access: LEVEL3  
Reaction: RESET

**MP\_ampFactorI2t**

Reference value for I<sup>2</sup>t monitoring of the power module  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 1000 [· rated current of power module]  
0: I<sup>2</sup>t monitoring of the power module switched off  
1: Rated current of power module is reference value  
Default: 0  
Access: LEVEL3  
Reaction: RESET



**Module 9160 Status request of temperature monitoring and I<sup>2</sup>t monitoring**

The I<sup>2</sup>t monitoring reported by the module is given with respect to the first I<sup>2</sup>t monitor response (power module or motor) if both I<sup>2</sup>t monitors are activated (MP\_motFactorI2t and MP\_ampFactorI2t). This early warning is withdrawn as soon as the limit for reset is reached. For the response behavior, see "Limit values" on page 969.

Constraints:

- Unconnected axes respond with all error bits as 0.
- The I<sup>2</sup>t monitoring responds when the current value exceeds 110% of the rated current.
- After an e-function, the current is limited to 110 % of I<sub>noml</sub>. The time constant for this is approx. 2.56 seconds.
- The response time for the I<sup>2</sup>t monitoring at 2 · I<sub>noml</sub> without preload is approx. 2.1 seconds. With a nominal load hysteresis every 10 seconds the monitoring responds after approx. 200 ms.
- The message "I<sup>2</sup>t early warning" is set approx. 200 ms before limitation starts. The message "I<sup>2</sup>t monitoring" appears when limitation is activated.
- Only the I<sup>2</sup>t early warning is possible for the spindle axis.

Call:

CM 9160

PL D <>Temperature monitoring>  
Bit 15876543210  
Axis:Sxxxxx987654321

PL D <> I<sup>2</sup>t monitoring I<sup>2</sup>t early warning>  
Bit 15876543210 15 876543210  
Axis Sxxxxx987654321 Sxxxxx987654321

**Error recognition:**

Marker	Value	Meaning
M4203	0	No error
	1	Control has no current controller



## Module 9367 I<sup>2</sup>t monitoring

The module reports

- an I<sup>2</sup>t early warning
- an I<sup>2</sup>t error (temperature exceeded)

The I<sup>2</sup>t monitoring reported by the module is given with respect to the first I<sup>2</sup>t monitor response (power module or motor), if both I<sup>2</sup>t monitors are activated (MP\_motFactorI2t, MP\_ampFactorI2t).

The I<sup>2</sup>t early warning is withdrawn as soon as the limit for reset is reached. For the response behavior, see "Limit values" on page 969.

Constraints:

- Unconnected axes respond with all error bits as 0.
- The I<sup>2</sup>t monitor responds if the current value exceeds 110 % of the rated current.
- The "I<sup>2</sup>t early warning" is set approx. 200 ms before the limit takes effect. The "I<sup>2</sup>t monitoring" is set when the limit is reached.
- For the spindle axis, only the I<sup>2</sup>t early warning is possible.

Call:

CM 9367

PL D <>I<sup>2</sup>t early warning, bit-encoded  
(Bit 0 represents logic axis 0, etc.)

PL D <>I<sup>2</sup>t error, bit-encoded  
(Bit 0 represents logic axis 0, etc.)

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	No error
	1	Control has no current controller





## Temperature models

The temperature model of the motor or power module is defined by the entries in the motor table or power module table, respectively (motor.mot, motor.amp). Remember that calculation of which temperature model to use depends exclusively on the availability or nonavailability of the parameters. In addition, the parameters for motors and power modules are to be evaluated separately.


These parameters are explained below using the respective temperature model for the calculation.

## Temperature model, first order

The following values (entries in the motor table or power module table) are required for the first-order temperature model to calculate the temperature.

- F-DC [Hz]:  
This parameter is not evaluated for the CC 422.  
Lower limit frequency for the transition of traverse to standstill with the CC 61xx and CC 424.  
F-DC = 0 – Default value (0) is active  
F-DC > 0 – Input value in Hz is active
- T-DC [s]:  
Thermal time constant for operation at standstill (not evaluated at present)
- F-AC [Hz]:  
Upper limit frequency for the transition from standstill to traverse.  
F-AC = 0 – Default value (0) is active  
F-AC > 0 – Input value in Hz is active
- T-AC [s]:  
Thermal time constant for the motor or power stage. Identifies the point in the temperature curve at which 63 % of the maximum temperature is reached.  
T-AC = 0 – Default value: 10 s for axes, 150 s for ball screw  
T-AC > 0 – Input value [s] for power modules. For motors, this input value is active if  $Tth_2 = 0$ .
- Only for motors  $Tth_2$  [s]:  
Thermal time constant for the motor. Identifies the point in the temperature curve at which 63 % of the maximum temperature is reached.  
 $Tth_2 = 0$  – Default value: 10 s for axes, 150 s for ball screw  
 $Tth_2 > 0$  – Input value in [s] for motors

## First-order temperature model of the motor



- P: Heat output of the three phases
- KTY: KTY temperature sensor in the winding
- $C_{th2}$ : Thermal capacity of the motor housing
- $R_{th2}$ : Thermal resistance on the motor housing
- $T_{th2}$ : Thermal time constant  $R_{th2} \cdot C_{th2}$

## Temperature model, second order

The following values (entries in the motor table) are required for the second-order temperature model to calculate the temperature (default values [axis/spindle] are valid for the entry "0"):


- F-DC [Hz]:  
This parameter is not evaluated for the CC 422.  
Lower limit frequency for the transition of traverse to standstill with the CC 61xx and CC 424.  
F-DC = 0 – Default value (0 Hz) is active  
F-DC > 0 – Input value in Hz is active
- T-DC [s]:  
Thermal time constant for operation at standstill (not evaluated at present)
- F-AC [Hz]:  
Upper limit frequency for the transition from standstill to traverse.  
F-AC = 0 – Default value (0 Hz) is active  
F-AC > 0 – Input value in Hz is active
- Tth<sub>1</sub> [s]:  
Thermal time constant for the transition from winding to housing  
Tth<sub>1</sub> = 0 – Default value (0 s) is active  
Tth<sub>1</sub> > 0 – Input value in [s] is active
- Rth<sub>1</sub> [K/W]  
Thermal resistance for the transition from winding to housing.  
Rth<sub>1</sub> = 0 – Default value: 0 K/W  
Rth<sub>1</sub> > 0 – Input value in [K/W] is active
- Tth<sub>2</sub> [s]:  
Thermal time constant for the transition from housing to coolant  
Tth<sub>2</sub> = 0 – Default value: 10 s for axes, 150 s for ball screw  
Tth<sub>2</sub> > 0 – Input value in [s] is active
- Rth<sub>2</sub> [K/W]:  
Thermal resistance for the transition from winding to coolant  
Rth<sub>2</sub> = 0 – Default value: 0 K/W  
Rth<sub>2</sub> > 0 – Input value in [K/W] is active
- When the CC starts up, the current motor temperature (KTY sensor) is taken into the calculation model in order, for example, to compensate any excessive temperatures.



### Note

- All parameters have to be entered for the model to become active. If a parameter is missing, the first-order temperature model becomes active, either with the thermal time constant "Tth2" or with "T-AC."

## Second-order temperature model of the motor



- P: Heat output of the three phases
- KTY: KTY temperature sensor in the winding
- $C_{th1}$ : Thermal capacity of the winding
- $C_{th2}$ : Thermal capacity of the housing
- $R_{th1}$ : Thermal resistance winding/housing
- $R_{th2}$ : Thermal resistance housing/coolant
- $T_{th1} = R_{th1} \cdot C_{th1}$
- $T_{th2} = R_{th2} \cdot C_{th2}$

### Compatibility

Old motor tables are also usable in newer software versions. If the columns/parameters in the temperature models are missing, however, it is of course impossible to calculate a second-order temperature model.

In such a case the entries **F-DC**, **T-DC**, **F-AC**, **T-AC** are used for a first-order temperature model. If this model, too, has no entries (entries "0"), the default values of the above temperature models apply.

### 6.17.9 Momentary utilization of drive motors

Module 9166 provides the momentary utilization of the given drive motor as a percentage value.

Utilization means:

Speed range	$n_{actl} < \text{rated speed}$	$n_{actl} \geq \text{rated speed}$
Asynchronous motor	$\frac{ M }{ M_{Mean} }$	$\frac{ P }{ P_{Mean} }$
Synchronous motor	$\frac{ M }{ M_{Mean} }$	–

Instead of the drive torque, one uses the effective component  $I_q$  of the current, which is proportional to the torque.

$I_{qMean}$  is formed as mean value of the individual current values  $I_{qx}$  of the last 20 ms:

$$I_{qMean} = \frac{\sum(I_{q1} \cdot I_{qn})}{n}$$

$$\text{Utilization} = 1000 \cdot \frac{I_{qMean}}{I_{qRated}}$$

**For asynchronous motors:**

$$I_{qRated} = \sqrt{I_N^2 - I_{mag}^2}$$

$I_N$ : Rated current of motor

$I_{mag}$ : Magnetizing current

**For synchronous motors:**

$$I_{qRated} = \langle \text{Rated current of motor} \rangle$$

The utilization display of synchronous motors is with respect to the rated torque ( $M/M_{rated}$ ).

### Module 9166 Read momentary utilization of drive motor

The module provides the momentary utilization of a drive motor controlled by the integral current controller in percent (%) of the rated utilization. The momentary utilization is ascertained by the current controller, under consideration of the equivalent circuit data of the motor.

In the speed range  $(n_{act}) < (n_{nom})$  utilization refers to the quotient  $|M/M_{limit}|$ , in the range  $(n_{act}) \geq (n_{nom})$  utilization refers to the quotient  $|P/P_{limit}|$ .

Constraints:

- The value 0 is read for axes that are not connected.
- The spindle must be coded as axis 15.
- An axis that is not configured as "active", or an axis that was set to the "deactivated axis" activation status (e.g. with Module 9226 or 9418), is treated as if it were not present.

Possible errors:

- The control is not equipped with a current controller.

Call:

PS B/W/D/K <>Axis>  
Index from CfgAxes/axisList

CM 9166

PL B/W/D <>Utilization of the drive in %>

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Utilization read
Error (M4203)	1	Control has no current controller



### 6.17.10 Status of HEIDENHAIN hardware and software

Module 9066 is used to determine the status information of the HEIDENHAIN components. Module 9067 is used to interrogate the status of software settings—at present with code 0 of the set SIK options.

#### Module 9066 Status of HEIDENHAIN hardware

Module 9066 interrogates the status information of HEIDENHAIN hardware components and the SIK component.

Constraints:

- The module can only be called in the cyclic PLC program.

Call:

```
PS    B/W/D/K  <>Code for hardware component>
        0: HEIDENHAIN inverter (only with digital control)
        1: SIK ID
           If you are switching from the iTNC 530:
           iTNC: SIK ID as BCD number
           NCK: SIK ID as decimal number
        2: I2t early warning (only with digital control)
        3: I2t monitoring (only with digital control)
        4: Error of analog part (only with digital control)
```

```
CM    9066
PL    B/W/D    <>Status information>
        Bit 0: Reserved
        Bit 1: DC-link voltage too high
        Bit 2: Heat sink temperature too high
        Bit 3: Reserved
        Bit 4: DC-link current too high
        Bit 5: Power supply unit not ready
        Bit 6: Leakage current too high
        Code 1: SIK ID
        Codes 2 to 4: Axis masks
```

#### Error recognition:

Marker	Value	Meaning
M4203 or NN_GenApiModule	0	Status ascertained
Error	1	Error code in W1022 or NN_GenApiModuleErrorCode
W1022 or NN_GenApiModule	2	Invalid code for HEIDENHAIN hardware
ErrorCode	24	Module was called in a spawn or submit job

### Module 9067 Status of software settings

Module 9067 enables you to request status information about software settings. Module 9067 can currently be used to interrogate the software options set in the SIK.

Call:

```
PS   B/W/D/K <>Mode>
      0: Interrogate whether SW option is set in the SIK
PS   B/W/D/K <>Number>
      If mode is 0: Number of SIK option
CM   9067
PL   B/W/D   <>Status>
      Status of SIK option (if mode is 0)
      0: Not set
      1: Set
```

### Error recognition:

Marker	Value	Meaning
M4203 or NN_GenApiModule Error	0	Function performed successfully
	1	Error code in W1022 or NN_GenApiModuleErrorCode
W1022 or NN_GenApiModule ErrorCode	1	Invalid value for number
	2	Invalid value for mode

Example:

Query if option 10 is set in the SIK:

```
PS   K0
PS   K10
CM   9067
PL   DL_statusinfo_9067
M_display_module_error(KG_error_module_9067)
```





## Suppressing the status signals of the HEIDENHAIN supply unit

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPowerStage <b>powStatusCheckOff</b>	401209

The parameter object CfgPowerStage is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Analog axes (**MP\_axisHw** = Analog)

The HEIDENHAIN power supply units have several status signals which lead to error messages on the control. **MP\_powStatusCheckOff** is used to suppress the error message for each status signal.

HEIDENHAIN does not recommend suppressing the error messages from the power supply units. If you are using a UE 2xx, the signals must be suppressed because the UE 2xx compact inverter does not provide these signals.

The handling of status signals from HEIDENHAIN power supply units, which are already inactive during control start-up, varies depending on **MP\_ampStatusCheckOff** – bit 0.

### MP\_powStatusCheckOff

- **Bit 0 = 0:** Missing signals do not result in an error message when the drive is switched on.
- **Bit 0 = 1:** Missing signals result in an error message when the drive is switched on. Signals that are not provided by the power supply unit must be suppressed with MP\_powStatusCheckOff (bit 1 to bit 6), because non-existent signals are always identified as errors.



#### Note

Signals that change their status during operation are always identified as errors.

## MP\_powStatusCheckOff

Suppress error messages of the HEIDENHAIN supply units  
Available from NCK software version: 597 110-01.

Format:

Numerical value

Input:

**Bit 0** – Status signals that are already active during control power-up.

0: Missing signals are ignored

1: Missing signals are evaluated

**Bit 1** –  $\overline{\text{ERR.UZ.GR}}$  signal

0: Error message is not suppressed

1: Error message is suppressed

**Bit 2** –  $\overline{\text{ERR.TMP}}$  signal

0: Error message is not suppressed

1: Error message is suppressed

**Bit 3** – Reserved

**Bit 4** –  $\overline{\text{ERR.IZ.GR}}$  signal

0: Error message is not suppressed

1: Error message is suppressed

**Bit 5** –  $\overline{\text{RDY.PS}}$  signal

0: Error message is not suppressed

1: Error message is suppressed

**Bit 6** –  $\overline{\text{ERR.ILEAK}}$  signal

0: Error message is not suppressed

1: Error message is suppressed

**Bit 7** –  $\overline{\text{PF.PS.AC}}$  signal

(only on CC 61xx / UEC 11x)

0: Error message is not suppressed

1: Error message is suppressed

**Bit 8** –  $\overline{\text{PF.PS.DC}}$  signal

(only on CC 61xx / UEC 11x)

0: Error message is not suppressed

1: Error message is suppressed

**Bit 9** – Monitoring of DC-link voltage Uz or LIFTOFF function

(only on CC 61xx / UEC 11x)

0: Uz monitoring and LIFTOFF function are active

1: Uz monitoring and LIFTOFF function are not active

Default:

0

Access:

LEVEL3

Reaction:

RESET

## 6.17.11 Motor brake

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgSpeedControl <b>vCtrlSwitchOffDelay</b> <b>vCtrlSwitchOnDelay</b> CfgServoMotor <b>motEncCheckOff – Bit3</b>	    400927 400929  401303

The parameter objects CfgSpeedControl and CfgServoMotor are not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Analog axes (**MP\_axisHw** = Analog)

### Controlling the motor brakes

The motor brakes are controlled with the  $\overline{\text{BRK}}$  braking signal, which is transmitted to the **HEIDENHAIN inverters** via the PWM interface (X51 to X62). The corresponding outputs are activated there. See the basic circuit diagrams. Registered customers can download the current basic circuit diagram from the "HESIS-Web Including Filebase" on the Internet (<http://hesis.heidenhain.de>).

Control of the motor brakes via the PWM interface must be deactivated for non-HEIDENHAIN inverters that do not support this function.

The motor brakes are opened no later than 50 ms after the speed controller is switched on. For safety reasons, the controller is not switched off until the braking signal has been output:

- ▶ Enter in **MP\_vCtrlSwitchOffDelay** the time (overlap time) after which the controller is to be switched off (after the braking signal has been output).

If the inverter sends the  $\overline{\text{RES.PS}}$  reset signal, then the  $\overline{\text{BRK}}$  braking signals are output immediately upon switch-off of the controllers, i.e. without any overlap time.

Activated brakes cause a change in the controlled system. The motor with the changed controlled system is controlled during the overlap time. This can lead to oscillations when the controller is switched off. These oscillations are suppressed by the NC software. **MP\_motEncCheckOff** bit 3 can be used to deactivate the suppression of the oscillations. HEIDENHAIN does not recommend switching off the suppression of the oscillations.

In **MP\_vCtrlSwitchOnDelay** you can define a time period in which the speed and position controller parameters are adjusted to values for controlling a closed brake when the drive is switched on. This parameter can be used to avoid oscillations in the drive during switch-on when the brake is still closed and the controller is already active.

### **MP\_motEncCheckOff**

Monitoring functions  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: **Bit 3** – Switching off the controller when the motor brakes are activated  
0: Suppress oscillations  
1: Oscillations are allowed  
(cf. iTNC 530: MP2220 Bit 3)

Default: 0

Access: LEVEL3

Reaction: RESET

### **MP\_vCtrlSwitchOffDelay**

Dwell time of speed controller during feedback control switch-off  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 5 [s]  
(max. 9 decimal places are permissible)  
Time between output of the braking signal BRK and switching off of the controller (overlap time)  
(cf. iTNC 530: MP2308.x)

Default: 0 [s]

Access: LEVEL3

Reaction: RUN

### **MP\_vCtrlSwitchOnDelay**

Controller parameters adjusted to closed brake  
Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0 to 5 [s]  
(max. 9 decimal places are permissible)  
0: Function not active  
The time [in seconds] after switch on in which the controller parameters are adapted for a locked brake. For the defined time, the parameters of the control loop are reduced after the motor switch-on in order to prevent oscillations.  
(cf. iTNC 530: MP2309.x)

Default: No value, parameter optional (= 0)

Access: LEVEL3

Reaction: RUN



## Automatic test of the motor brake

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgServoMotor <b>testBrakeCurrent</b> <b>testBrakeTolerance</b>	    401323 401324

You can carry out an automated functional test of the motor brake after switching on the drive, either before traversing the reference mark or through activation by PLC Module 9143.

This brake test only functions in combination with HEIDENHAIN inverter systems and only when using the brake output on X392/X393/X394 if it is wired according to the basic circuit diagram from HEIDENHAIN.

For the period of one second, a torque (current) is applied while the brake is active. The path that the axis has moved is then measured. If the permissible path is exceeded, the error message **8130 Motor brake defective <axis>** appears, and the axis remains controlled. The test is carried out simultaneously for all affected axes.



### Warning

In case of an error, the axis must be moved to a safe position, and physically supported, if necessary. Only then may the machine be switched off so that the defect can be corrected.

The brake test is activated (insert optional parameter) or deactivated (delete optional parameter) separately for each servo drive via **MP\_testBrakeCurrent**. An additional test torque is applied to the servo drive during the brake test. This test torque is defined via a multiplier for the motor stall current **I0**. **MP\_testBrakeCurrent** defines the multiplier. This test torque exerts additional load on the holding brake of the servo drive. The axis is prevented from moving during the brake test and the brake test is considered to have been passed only if the brake withstands this load.

The control determines the algebraic sign of the test torque individually for each servo drive depending on the holding torque.

If no motor current flows while testing the motor brakes, the error message **8140 No current for brake test <axis>** appears.

- ▶ Enter in **MP\_testBrakeCurrent** a factor for the motor stall current with which the motor brake test is to be carried out. If the test is not to be carried out, or for motors without brakes, delete the parameter from the configuration.

The reference value for the factor from **MP\_testBrakeCurrent** is the stall current **I0** entered in the motor table. If **I0** in the motor table equals 0, then the rated current **I-N** from the motor table is used.

Recommended input value for **MP\_testBrakeCurrent**:

$$\mathbf{MP\_testBrakeCurrent} \geq 1,3 \cdot \frac{M_L}{M_0}$$

**M<sub>L</sub>**: Maximum load torque of the axis. In a standard case the holding torque of a vertical axis is used here. It is to be ensured via activation of the brake that a vertical axis does not fall down when the drive controllers are switched off.

**M<sub>0</sub>**: Stall torque of motor

Always keep in mind:

- Torque for motor test  $\geq 1.3 \cdot$  maximum load torque of the axis
- Stall torque of the motor  $\geq$  maximum load torque of the axis
- Holding torque of the motor brake  $\geq$  torque for the motor test



#### Note

- Please note that when reading the current via the internal oscilloscope on the CC 61xx or UEC 11x you are seeing the effective value of the current.
- Please note that the test torque can only be generated with a certain factor of uncertainty. Factors of influence here are the accuracy of the current sensors and the torque constant of the motor.

- ▶ Enter in **MP\_testBrakeTolerance** the permissible path that the motor is allowed to move against the brake.

To prevent standstill monitoring from responding, the following is required:

**MP\_testBrakeTolerance** < **MP\_checkPosStandstill!**

Recommended input value for **MP\_testBrakeTolerance**:

$$\mathbf{MP\_testBrakeTolerance} = 2 \cdot \alpha \cdot \frac{\mathbf{MP\_distPerMotorTurn}}{360^\circ}$$

$\alpha$ : Permissible braking angle: Backlash of the motor brake as per the manufacturer specifications (for HEIDENHAIN motors,  $\alpha \leq 1^\circ$ )

#### Example:

QSY 155B-EcoDyn:  $M_0 = 13 \text{ Nm}$ ,  $M_{Br} = 40 \text{ Nm}$

$M_L = 11 \text{ Nm}$

$$\mathbf{MP\_testBrakeCurrent} \geq 1,3 \cdot \frac{11 \text{ Nm}}{13 \text{ Nm}} = 1,1$$

MP1054.x (distance per motor revolution) = 20 [mm]

$\alpha = 1^\circ$

$$\mathbf{MP\_testBrakeTolerance} = 2 \cdot 1^\circ \cdot \frac{20 \text{ mm}}{360^\circ} = 0,111 \text{ mm}$$



### **MP\_testBrakeCurrent**

Multiplier for motor current during test of motor brake  
Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0.1 to 30 [ $\cdot$  motor stall current]  
Max. 9 decimal places are permissible.  
Recommended:  $1.3 \cdot M_L / M_0$   
If the optional attribute is missing, do not perform the brake test.  
(cf. iTNC 530: MP2230.x)

Default: No value, parameter optional (= brake test is inactive)

Access: LEVEL3

Reaction: RUN

### **MP\_testBrakeTolerance**

Maximum permissible path during test of motor brakes  
Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0 to 10 [mm] or [°]  
Max. 9 decimal places are permissible.  
(cf. iTNC 530: MP2232.x)

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

### **Module 9143 Activate the brake test**

This module can start an axis-specific brake test with the configuration from the machine parameters or with other values for the **MP\_testBrakeCurrent** and **MP\_testBrakeTolerance** machine parameters.

Constraints:

- Programming it in a submit job blocks other submit jobs until the test is completed.
- The PLC module automatically passes the processing time to other spawn and submit processes.

Call:

PS K/B/W/D <>Axis number>  
0 = 1st axis, 2 = 2nd axis, etc.

PS K/B/W/D <>Multiplier for rated current>  
Value in 1/1000 or  
0: Default MP2230 (factor of nominal current)

PS K/B/W/D <>Permissible traverse path>  
Value in 0.1 [um] or  
0: Default MP2232

CM 9143

PL B/W/D <>Status/Error>  
0: Brake OK  
1: Brake defective  
2: Invalid axis or negative values for rated current or traverse path  
3: Call during running NC program or during other PLC jobs  
4: Call was made from a cyclic PLC program  
5: Error during data exchange  
6: Not allowed for safe control  
7: Drive not ready  
8: Brake test was aborted (e.g. by emergency stop)

**Error recognition:**

Marker	Value	Meaning
M4203 or NN_GenApiModule Error	0	No error
	1	Error code in W1022
W1022 or NN_GenApiModule ErrorCode	2	Invalid axis programmed (invalid axis number, not a closed-loop axis, axis currently open-loop axis or slave axis) or negative values for the traverse path or current are programmed
	8	Module is not allowed for control with functional safety
	20	Module was not called in a spawn job or submit job
	21	Call during program run or during other active PLC jobs for the programmed axis
	40	Drive not ready
	45	Canceled due to error during data exchange or due to external influences (e.g. emergency stop)





## 6.17.12 Emergency stop monitoring

### Internal EMERGENCY STOP

If an **internal EMERGENCY STOP** is triggered (e.g. due to standstill monitoring), the MANUALplus 620 switches

- the control-is-ready output off (STO.A.G; responsible watchdog reacts after 10 ms at the latest)
- the inverter enablings off (STO.B.X; responsible watchdog reacts after the time set in **MP\_watchdogTime** of 1 to 6 s), and the inverters are now without power.

An error message appears and the PLC program is stopped. Depending on the error class, it might be possible that it **cannot** be cleared with the CE key:

- ▶ Correct the error and restart the switch-on routine.

### MP\_watchdogTime

Delay for the SH1B signal (inverter enable)

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 1 to 6 [s]

Default: 3 [s]

Access: LEVEL3

Reaction: RESET

### Testing an internal EMERGENCY STOP

For test purposes, an internal EMERGENCY STOP can be simulated in order to inspect the correct wiring of the machine. The control-is-ready output is reset, and the NC and PLC are no longer operable.



#### Warning

It is essential that you support hanging axes before the test in order to prevent damage to the machine in case of error.

- ▶ Under MOD, enter the code number **6871232**.
- ▶ Press the ENT key and the test will start.

After the test has been completed, you must restart MANUALplus 620.

## External emergency stop -ES.A and -ES.B

For triggering an emergency stop, controls with HSCI have the emergency-stop inputs –ES.A and –ES.B (e.g. –ES.A (X9/7a) and –ES.B (e.g. X9/7b) on the PL). A "0" signal at –ES.A or –ES.B triggers an emergency stop reaction with the error message **external emergency stop**. The familiar PLC inputs I3 and I32 are being replaced by –ES.A and –ES.B in HSCI systems.

Both emergency stop inputs –ES.A and –ES.B must be wired. Both inputs must carry the same signal. This signal is a safety-related signal and must be generated by the appropriate devices (e.g. dual-channel emergency stop button, safety contactor combinations).

If an **external emergency stop** is triggered,

- the nominal speed value "null" is transmitted, braking the drives on the intended braking ramp (usually at the limit of current)
- the **External emergency stop** error message is displayed, and
- the **NN\_GenNcEmergencyStop** marker is set by the NC.

You can clear the error message with CE after switching the machine control voltage back on.

However, an external emergency stop (–ES.A, –ES.B) does not disconnect the output –STO.A.G.

PLC operand / Description	Type
NN_GenNcEmergencyStop Control in external emergency stop state 0: Control is not in external EMERGENCY STOP state 1: Control is in external EMERGENCY STOP state	M

## Axis enabling

HEIDENHAIN recommends using the axis-specific "axis releases" of the CC via the configuration in **MP\_driveOffGoupInput** and **MP\_driveOffGroup** in addition to –ES.A and –ES.B, see page 218.

On controls with HSCI but without functional safety (FS), a pure axis enable, which up to now has been realized over I32, can only be realized through the function of the former X150. However, a CC 61xx and the UEC 11x do not have an X150 connector for axis-specific or axis-group-specific drive controller enabling.

Instead, you can now enter in the **MP\_driveOffGroupInput** machine parameter (100106) eight numbers of those PLC inputs that simulate the inputs of X150. If one of these PLC inputs is switched off, the corresponding drives are decelerated on the provided braking ramp (usually at the limit of current). Over PLC module 9161 you have to switch off the axes of the affected axis groups. To do so, you can use PLC module 9157 to scan the corresponding PLC inputs.

The axes are assigned to individual axis groups through the axis-specific parameter **MP\_driveOffGroup** (400015).



If the corresponding PLC inputs are switched off, the NC

- transmits the nominal speed value "null", braking the drives on the intended braking ramp (usually at the limit of current)
- detects the standstill of the drives after braking and switches off the pulses of the power stage over the PWM interface (-STO.B.x).

Machine parameter **MP\_vCtrlTimeSwitchOff** serves to monitor the braking of the drives. The monitoring time for the braking process is defined in **MP\_vCtrlTimeSwitchOff**. After the monitoring time has expired, the control checks whether the servo drive is at a standstill. If this is not the case, the control assumes that a serious error has occurred and switches off the pulses of the power stages via -STO.B.x (signal to PWM cable).

This ensures that, after a request to switch off the servo drives (e.g. emergency stop, X150, PLC or alarm), the pulses are safely switched off (via -STO.B.x) at the latest after the time specified in **MP\_vCtrlTimeSwitchOff** expires. If the standstill is detected right before expiration of the time defined in **MP\_vCtrlTimeSwitchOff**, the active braking process is continued and the pulses are not switched off until after the overlap time.

The time for switching off the pulses (entry in **MP\_vCtrlTimeSwitchOff**) must be greater than the maximum possible braking time of the axis/spindle that can occur through electrical braking. Especially for axes/spindles without mechanical braking, you must ensure that the pulses are not switched off until after the maximum possible braking time for the axis/spindle that can occur through electrical braking. Non-decelerated axes/spindles coast to a stop after pulse switch-off. In the worst case, this can cause damage to the machine. Specific operating conditions of the machine, such as maximum feed rate, overload on the axes, etc., must also be taken into account.



#### Warning

The time for switching off the pulses via -STO.B.x, (entry in **MP\_vCtrlTimeSwitchOff**) must always be greater than the maximum possible braking time of the axis/spindle that can occur through electrical braking. However, do not set too large a value in **MP\_vCtrlTimeSwitchOff**. Otherwise the safety function of the machine parameter cannot be ensured.

#### **MP\_vCtrlTimeSwitchOff**

Pulse switch-off of the power stages (STO.B.x)  
Available from NCK software version: 597 110-05.

Format: Numerical value  
Input: 0.100 000 000 to 100 [s]  
0 = 3 seconds (default value)

Default: 3 [s]  
Access: LEVEL3  
Reaction: RUN

## Emergency stop test

After the emergency stop test or a self-test is started, internal signals of the HSCI participants are tested for proper function in a first phase. In a further, second phase the emergency stop test and brake test are conducted with external signals (-ES.A, -ES.B, -STO.A.G).

In the event of an error, a drop-off of the control-is-ready output (MC.RDY or -STO.A.G) always triggers an emergency stop.




### Note

The circuitry recommended by HEIDENHAIN is illustrated in the Basic Circuit Diagram of the MANUALplus 620. Registered customers can download the current basic circuit diagram from the HESIS-Web Including Filebase on the Internet at <http://hesis.heidenhain.de>. It is also available from HEIDENHAIN upon request.

With **NN\_GenSafetySelftest** you can find out via the PLC program whether the emergency-stop test is running:

PLC operand / Description	Type
<b>NN_GenSafetySelftest</b> 0: Self-test of control is not performed 1: Self-test of the control (emergency stop test) is being performed	M

Time diagram of essential signals after the MANUALplus 620 is booted and during the emergency-stop test:



<b>Step</b>	<b>Function</b>	<b>Screen display</b>
1	Start of the self test, immediately after compiling of the PLC program	
2	Phase 1 of the self-test: Triggering and detection of essential internal signals are tested. In this phase of the self-test, the signals STO.A.G (X9/3a) and STOS.A.G (X9/2a) are set and deleted several times.	
3	Waiting for machine control voltage	<b>RELAY EXT. DC VOLTAGE MISSING</b>
4	Detection of the control voltage and cut-off of the STO.A.G/STOS.A.G signal by the NC software. ES.A/ES.B must switch to zero within one second.	<b>EMERGENCY STOP test</b>
5	Switch-on of the STO.A.G/STOS.A.G signal by the NC software.	
6	Phase 2 of the self-test: Release and detection of the emergency stop signals ES.A and ES.B are tested internally. No hardware terminals are switched!	
7	Normal control operation Control voltage is on, STO.A.G/STOS.A.G output and ES.A/ES.B are at "1".	<b>TRAVERSE REFERENCE POINTS</b>

The following error messages can occur during the test:

■ **Timeout during self-test**

At least one HSCI participant has not answered a request or has not correctly detected a signal condition to be tested. Possible causes:

- HSCI participant/device is defective
- HSCI cabling is faulty
- The hardware components used and/or software are not compatible with each other.

■ **Error during self-test**

The sequence of the individual test steps and processes in the self-test do not fulfill the requirements. A signal condition to be tested is not in the required initial condition. Possible causes:

- HSCI participant/device is defective
- HSCI cabling is faulty
- The hardware components used and/or software are not compatible with each other.

■ **Error in self-test**

Has same causes as **Error during self-test**. However, after the cause of error is corrected (e.g. by closing the guard door), the test can be continued without the MANUALplus 620 having to restart.

**Module 9144 Configuration of the EMERGENCY STOP test**

PLC module 9144 is used to activate special functions regarding the safety self-test or emergency-stop test, as well as the functional safety (FS) of a HEIDENHAIN control system. The test can be started directly through the PLC module. Also, a PLC soft key can be made available through the PLC program if all minimum requirements are fulfilled so that the user can start the self test directly by soft key.

With PLC Module 9144 you can specify whether a repeated self-test should be started immediately (mode 0) or by the user via soft key (mode 1).

It must be ensured by the PLC program that the following minimum requirements are met before the self-test is started:

- All guard doors must be closed and, if possible, locked.
- No active machining operation is allowed.



If a MANUALplus 620 with functional safety (FS) is used, there are further constraints:

- Defining an NC operating mode for functional safety in NCK-based controls  
The PLC program must select an NC operating mode for systems without operating-mode group (PNC 610). After booting the system, you must set parameter 1 to 2 in mode 10 to initiate the homing and testing of the axes. Then you must use the PLC to switch to one of the two NC operating modes (e.g. operation through machine operating panel). The system with Functional Safety is not ready for operation until both of the two above-mentioned actions have taken place.
- Testing the axis positions for functional safety in NCK-based controls  
In systems without operating-mode group (PNC 610), the PLC program must request that the axis positions be tested so that functional safety can be realized. The user must confirm the test with the permissive button.

Call:

```

PS    B/W/D/K  <>Mode>
          0: Start self test immediately
          1: Prompt the user to start the self-test
          10: Define the operating mode for functional safety
          11: Request for testing the axis position

PS    B/W/D/K  <>Parameter1>
          0: No evaluation, but must be programmed
          1: No evaluation, but must be programmed

PS    B/W/D/K  <>Parameter2>
          Mode 0:
            No evaluation, but must be programmed
          Mode 1:
            No evaluation, but must be programmed
          Modus 10:
            0: Operation through machine operating panel
            1: Operation via electr. handwheel
            2: Homing and testing of axes
          Mode 11:
            0: No evaluation, but must be programmed
            1: No evaluation, but must be programmed
            10: No evaluation, but must be programmed
            11: No evaluation, but must be programmed

CM    9144
PL    B/W/D    <>Error/Result>
          Mode 0:0 = Function is being run
          1 = Error in NN_GenApiModuleErrorCode
  
```

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error	0	Function is being run
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid value for mode
	43	Control is not an HSCI system



### 6.17.13 Monitoring functions when using the CC 61xx and CC 424

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgServoMotor <b>motEncCheckOff – Bit4...8</b>	401303

The parameter object CfgServoMotor is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Analog axes (**MP\_axisHw** = Analog)

The following monitoring functions are only available when you are using the CC 61xx and CC 424. Use **MP\_motEncCheckOff** to activate/deactivate these functions:

- **Bits 4, 5:** The KTY temperature sensor of the motors is monitored by the MANUALplus 620 for excessive and insufficient temperatures. If the KTY is not to be evaluated (e.g. because the temperature sensor is not doubly isolated), this function must be deactivated.
- **Bit 7:** The CC 61xx or CC 424 monitors the input frequency of the speed encoders. If this leads to problems (e.g. unjustified responses), the monitoring function can be deactivated. The following error messages can appear:
  - Speed encoder: **8860 Input frequency from speed encoder <axis>**
  - Position encoder: **8870 Input frequency from position encoder <axis>**
- **Bit 8:** Position encoders are not used with linear or torque motors. If such an axis is removed from the closed-loop control and later reintroduced, a mechanical offset can occur. This offset is not fixed "in one blow," but instead is adjusted by gradually raising the  $k_V$  factor from 0 to the original value.





## MP\_motEncCheckOff

Monitoring functions

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: **Bit 4** – Monitoring for excessive motor temperature

0: Monitoring active

1: Monitoring inactive

**Bit 5** – Monitoring for too low a motor temperature

0: Monitoring active

1: Monitoring inactive

**Bit 7** – Monitoring the input frequency of the speed encoder

0: Monitoring active

1: Monitoring inactive

**Bit 8** – Adjust mechanical offset by gradually increasing the  $k_v$  factor

0: Function active

1: Function inactive

Default: 0

Access: LEVEL3

Reaction: RESET

## 6.18 Spindles

The spindle is controlled via the PLC. The PLC can transfer the control of the spindle to the NC.

The programmed speed can be output as

- Digital nominal speed value for a digital spindle
- Analog nominal speed command signal for an analog spindle
- Coded control of the PLC outputs

### 6.18.1 Configuring spindles

Settings in the configuration editor	MP number
System CfgAxes <b>spindleIndices</b>	100002

The MANUALplus 620 basically treats spindles like axes, i.e. just like the axes in the system, also a spindle has a logical axis number. The spindle key names and axis key names must therefore be entered in **CfgAxes/axisList**.

The logical spindle number is additionally specified with **MP\_spindleIndices**. The spindle key name's place in the list in **MP\_spindleIndices** defines the programmable spindle number used by the PLC to identify the spindle. Spindles are indicated by sequential numbering starting from the index [0].

The key names shown in the selection menu of the **MP\_spindleIndices** parameter are automatically taken from the **MP\_CfgAxes/axisList** parameter. Select the key name(s) of the spindle(s) from the menu.

#### **MP\_spindleIndices**

	Key names of all spindles on the machine Available from NCK software version: 597 110-02.
Format:	Selection menu
Selection:	The key names from CfgAxes/axisList are automatically presented as a selection menu. Select the key name of the spindle. The index number determines the logical spindle number.
Default:	–
Access:	LEVEL3
Reaction:	RESET

The PLC indicates the number of configured spindles and the logical spindle number in the following PLC operands.

<b>PLC operand / Description</b>	<b>Type</b>
NN_GenSpiCount Number of configured spindles	D
NN_SpiLogNumber Logical axis number of the spindle. Equals the index of the spindle from CfgAxes > <b>MP_axisList</b> 0...n: Logical axis number -1: Spindle does not exist -2: Spindle deactivated (example: alternation between C axis and spindle)	D

## 6.18.2 Spindle in position feedback control

### Position encoder of the spindle

Analog and digital spindles can be driven in a closed position control loop. In this case the spindle needs its own position encoder, or you use the speed encoder to measure the position of a digital spindle.

Due to the higher required accuracy, the position encoder should be mounted directly on the spindle.

- ▶ Enter the encoder model for position measurement in **MP\_posEncoderType**.
- ▶ Enter the value **360** in **MP\_posEncoderDist**.
- ▶ Enter the line count of the encoder being used in **MP\_posEncoderIncr**.  
1  $V_{PP}$  signals undergo 1024-fold subdivision.
- ▶ Enter the value **360** in **MP\_distPerMotorTurn**.

If the position encoder cannot be mounted to the spindle because of its design, the encoder will output several reference pulses per revolution. For example, with a transmission of 4:1 (motor to spindle), you will receive four reference pulses (every 90°) per spindle revolution.

- ▶ Define the position encoder-to-spindle transmission ratio in **MP\_distPerMotorTurn**, for example:

$$\text{MP\_distPerMotorTurn} = \frac{360}{4} = 90$$

Set **MP\_externRefPulse = spindleRef** to use an external reference pulse input (X30 or –REF.SP) as reference signal. The reference mark of the position encoder will not be evaluated in this case, see page 1008.

- ▶ Evaluate the reference mark with Module 9220 (see "Renewed traversing of the reference marks" on page 793).

The individual gear ranges are realized via one spindle parameter set each, see "Gear shifting" on page 1567.

In **NN\_SpiReferenceAvailable**, the NC reports whether the reference position of the spindle has been determined.

PLC operand / Description	Type
NN_SpiReferenceAvailable Reference position found 0: Reference position not found 1: Reference position found	M
PP_SpiReferenceMarkSignal Trip dog 0: Trip dog not triggered 1: Trip dog triggered	M

**Spindle  
Oriented spindle  
stop (spindle point  
stop)**

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgFeedLimits <b>M19MaxSpeed</b> <b>M19NcSpeed</b> CfgSpindle <b>kvFactorM19</b>	    400307 400310




Note

The spindle position must be measured by an encoder before an oriented spindle stop can be executed. If the parameter CfgAxisHardware/posEncoderType is set to **no encoder**, an oriented spindle stop is not possible.


**Spindle  
Oriented spindle  
stop with rotating  
spindle**

An oriented spindle stop (spindle point stop) with **rotating spindle** and at high speeds is executed in two steps if you set **MP\_M19MaxSpeed** accordingly:

- Rotational speed > 120 % of **MP\_M19MaxSpeed** (phase 1):  
The spindle is braked at the limit of current until the speed limit is reached (speed control with  $V_{nom} = 0$ ).
- Rotational speed < 120 % of **MP\_M19MaxSpeed** (phase 2):  
The position controller is switched on at the rotational speed limit. The actual position, actual speed and actual acceleration at the time of the transition of phase 1 to 2 are the initial values for positioning under position feedback control. This results in a continuous movement, speed and acceleration until the target position is reached. The jerk is limited during deceleration and positioning, whereby the maximum jerk can be set.



The oriented spindle stop with **rotating spindle** and at a speed < 120 % of **MP\_M19MaxSpeed** is executed under position feedback control.





#### Note

Make sure that the rotational speed limit is not set too low. Otherwise, due to the position-controller cycle time it will be impossible to generate jerk-limited positioning commands.

HEIDENHAIN recommends the following for the setting of **MP\_M19MaxSpeed**:

- Set a minimum of 3000 rpm for dynamic milling spindles.
- For slower milling spindles set a minimum of 1000 rpm.

The absolute minimum for the input value of **MP\_M19MaxSpeed** is 100 rpm.

#### **MP\_M19MaxSpeed**

Maximum rotational speed limit for M19

Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 100 to 20 000 [1/min]  
Default: 1 000 [1/min]  
Access: LEVEL3  
Reaction: RUN

For a spindle orientation requested by the NC (tapping, measuring) the parameter **MP\_M19NcSpeed** (400310) can now be used to specify the speed for it.

#### **MP\_M19NcSpeed**

Nominal speed for an oriented spindle stop commanded by the NC

Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: Shaft speed [rpm]  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

## Specific kv factor for spindle orientation

As the position control of the spindle is based on other internal algorithms than the position control of the axes, it can be useful to set the control behavior of the spindle so that it differs from that of the axes. The position control of the spindle is calculated on the MC—this results in time offsets that can, under certain circumstances, necessitate a reduction of the spindle's kv factor.

With the **MP\_kvFactorM19** parameter you can define a specific kv factor for the oriented spindle stop. If M19 is active, the value defined in **CfgPosControl/kvFactor** is replaced.

### MP\_kvFactorM19

kv factor for oriented spindle stop

Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0.000 to 1 000.000 [1/s]

Only effective with active spindle orientation (M19); replaces the value in **CfgPosControl/kvFactor**.

If the parameter is not defined or 0, the value in **CfgPosControl/kvFactor** is used.

Default: No value, parameter optional


Access: LEVEL3

Reaction: RUN

## Spindle Oriented spindle stop with stationary spindle

A ramp algorithm determines the acceleration with a **stationary spindle**.

**MP\_maxAcceleration** determines the steepness of the ramp during acceleration, **MP\_maxAcceleration** determines the steepness of the ramp during braking. The **MP\_maxFeed** parameter or the speed from Module 9414 limits the ramp.



Legend:

- **P0**: Initial position
- **P1**: Target position
- **st-max**: MP\_maxFeed or the rotational speed from 9414
- **A**: **MP\_maxAcceleration**
- **B**: **MP\_maxAcceleration**



**Spindle  
Oriented spindle  
stop through PLC  
module**

See "Spindle control by PLC" on page 1017.

**Stopping/  
referencing the  
spindle at trip dog  
position**

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgSpindle	
<b>fastInputType</b>	401501
<b>fastInput</b>	401502
<b>zeroPosEdge</b>	401503
<b>stopOnSwitchSpeed</b>	401504
CfgFeedLimits	
<b>maxDecSpeedCtrl</b>	400312
CfgReferencing	
<b>externRefPulse</b>	400413

The parameter object CfgSpindle is not required for:

- Axes that are **not** defined as spindles (not entered in **MP\_spindleIndices**)
- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)

A spindle that is not driven in a position control loop can also be stopped at a defined position (trip dog position). It is a prerequisite that this position be reported to a fast PLC input. A fast PLC input is not read in PLC cycle time but in the IPO clock.

On HSCI controls, a vacant PLC input on the PL 62xx PLC system module or a vacant PLC input of the UEC 11x is used as the input for the spindle reference signal. Use one of the first two slots from the left on the PL 62xx. Use the IOconfig PC software to determine a vacant PLC input and identify its input number.

During a spindle stop, the PLC transfers the rotational speed for "waiting for the input signal" (see "Module 9414 Position the spindle" on page 1027) in Module 9414.

The spindle is stopped in three steps.

- 1** The spindle is decelerated until the defined rotational speed is reached.
- 2** The spindle continues rotating at the defined rotational speed.
- 3** The spindle is stopped immediately (without ramp) as soon as the input signal of the spindle trip dog is detected.

Use the **MP\_fastInputType** parameter to define how the control is to handle the signal of the trip dog for reference end position. Select **forStopping** to stop the spindle at trip dog position with M19 upon receiving this input signal.

Select **forReferencing** to use the input signal as spindle reference pulse.



#### Note

If you use the **forReferencing** function, you have to set the parameter **MP\_refType = None** in the **CfgReferencing** configuration object.

Reference run process:

■ **With M3 or M4:**

The spindle accelerates to the programmed speed and picks up the reference point during this process.

■ **With M19:**

If the spindle was not referenced before, it rotates at 10 rpm in positive direction until the reference pulse has been recognized. Then the spindle stops and orients.

## Referencing with external reference signal

Set the value **spindleRef** in **MP\_externRefPulse** if you want to use an external reference signal instead of the reference signal of the connected motor encoder or position encoder (e.g. when gear ranges are used). Only one axis in the entire system can be homed with an external reference signal.

### MP\_fastInputType

Treatment of the fast input for the spindle

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **none**

Spindle does not have any trip dog for reference end position (no signal) or the signal is not evaluated.

#### **forStopping**

For M19 without rotary encoder, the spindle is positioned at the trip dog upon receiving this input signal.

#### **forReferencing**

The input signal is used as spindle reference signal. The control handles the signal of the trip dog for reference end position as reference pulse of the encoder.

Default: None

Access: LEVEL3

Reaction: RUN

### MP\_fastInput

Number of the fast PLC input for the spindle reference run

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0 to 32767

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN



**MP\_zeroPosEdge** defines the trip dog edge, which defines the spindle stop position in positive direction of rotation.

### **MP\_zeroPosEdge**

Evaluation of the edge  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: zeroOne  
Zero-one transition is evaluated.  
oneZero  
One-zero transition is evaluated.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

**MP\_stopOnSwitchSpeed** defines the speed for positioning at the trip dog. If you defined the value **forStopping** in the **MP\_fastInputType** parameter, you have to enter the positioning speed here.

### **MP\_stopOnSwitchSpeed**

Shaft speed for positioning to the trip dog  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: RPM [1/min] with up to 9 decimal places

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

### **MP\_maxDecSpeedCtrl**

Brake ramp for the spindle  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 000 to 1000 [m/s<sup>2</sup>] or [1000°/s<sup>2</sup>]  
Define a brake ramp for the spindle different from the acceleration ramp. You usually enter the same value as in **MP\_maxAcceleration**.

Default: 3 [m/s<sup>2</sup>] or [1000°/s<sup>2</sup>]  
Access: LEVEL3  
Reaction: RUN

### **MP\_externRefPulse**

Referencing with external reference signal  
Available from NCK software version: 597 110-04.

Format: Selection menu  
Selection: **Off**  
The reference signal of the connected motor encoder or the position encoder is used.  
**spindleRef (X30)**  
On systems with HSCI, the reference signal at -SP.REF+ and -SP.REF- of the external PL is evaluated; on systems with MC 320T or MC 420 the reference signal at input X30 is evaluated.

Default: Off  
Access: LEVEL3  
Reaction: RUN



## 6.18.3 Spindle in speed control

### Speed encoder of the spindle

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgServoMotor	
<b>motEncCheckOff – Bit0, 1</b>	401303
CfgEncoderMonitor	
<b>checkRefDistance</b>	400704

The parameter object

- CfgServoMotor is not required for:
  - Virtual axes (**MP\_axisMode** = Virtual)
  - Axes that are for display only (**MP\_axisMode** = Display)
  - Analog axes (**MP\_axisHw** = Analog)
- CfgEncoderMonitor is not required for:
  - Virtual axes (**MP\_axisMode** = Virtual)

Digital speed control requires a speed encoder.

The MANUALplus 620 monitors the reference mark of the speed encoder. The monitor checks whether the line count for one revolution from reference mark to reference mark is equal to the line-count entry in the motor table. If differences occur, the DSP error message **C3A0 Incorrect reference position S** appears. If this happens, check the speed encoder, encoder cable, and whether you have selected the correct motor.

With a gear wheel encoder, even if it is properly installed, monitoring can result in this error message due to its inherent inaccuracy:

- ▶ In this case, switch the monitoring off with **MP\_motEncCheckOff – Bit 0 = 1**

The MANUALplus 620 monitors the direction of rotation. If the nominal value of current exceeds the limit value for a certain time, the DSP error message **C380 motor <spindle n, axis> not controllable** appears.

At lower speeds, high-frequency spindles only have a low amount of torque. If such a spindle is having its speed controlled, the tool changer may slightly twist the spindle, causing the limit of current to be exceeded. This leads to the above error message:

- ▶ In this case, switch the monitoring off with **MP\_motEncCheckOff – Bit 1 = 1**

## MP\_motEncCheckOff

Monitoring functions  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: **Bit 0** – Monitoring the reference mark  
0: Monitoring active  
1: Monitoring inactive  
**Bit 1** – Monitoring the direction of rotation  
0: Monitoring active  
1: Monitoring inactive

Default: 0

Access: LEVEL3

Reaction: RESET



### Warning

For axes, monitoring of the rotational direction (**MP\_motEncCheckOff** – Bit 1) must **not** be deactivated. An error (e.g. one motor phase interchanged with another or incorrect entry in the **DIR** column of the motor table) might cause uncontrolled acceleration of the motor in one direction if the monitoring function for the rotational direction is deactivated. This also applies to spindles. For spindles, however, an incorrect acceleration in one direction is less dangerous than for axes.

Monitoring of the direction of rotation (**MP\_motEncCheckOff** – Bit 1) for synchronous motors (entry **SM** in the column **TYPE** in the motor table) cannot be switched off.

- ▶ In **MP\_checkRefDistance**, define the monitoring of the datum-to-datum distance of the spindle.

## MP\_checkRefDistance

Monitoring the reference mark of the spindle speed encoder  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **on**  
Monitor the reference mark of the speed encoder  
**off**  
No monitoring

Default: off

Access: LEVEL3

Reaction: RESET



## Spindle acceleration

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgFeedLimits <b>maxAccSpeedCtrl</b> <b>maxDecSpeedCtrl</b> <b>limitSpeedAcc</b> <b>limitSpeedDec</b> <b>limitAccSpeedCtrl</b> <b>limitDecSpeedCtrl</b>	    400311 400312 400313 400314 400315 400316


The MANUALplus 620 permits you to define adapted acceleration values for the speed-controlled spindle with M3/M4/M5 and for the position-controlled spindle with M19.

In **MP\_maxAccSpeedCtrl** and **MP\_maxDecSpeedCtrl** you define the acceleration and braking ramp values for the spindle in speed control (M3/M4/M5). If the two optional parameters are not part of the configuration, the value from **MP\_maxAcceleration** is effective.

The additional parameters **MP\_limitSpeedAcc**, **MP\_limitSpeedDec**, **MP\_limitAccSpeedCtrl** and **MP\_limitDecSpeedCtrl** were introduced to be able to adapt the acceleration behavior of large, speed-controlled main spindles better to the actual situation.

Machine parameters	Effective in mode	Description
<b>MP_maxAccSpeedCtrl:</b>	M3/M4/M5	Acceleration for the spindle with shaft speed control. Also effective for the braking ramp if <b>MP_maxDecSpeedCtrl</b> is not defined.
<b>MP_maxDecSpeedCtrl</b>	M3/M4/M5	Braking ramp for the spindle with shaft speed control
<b>MP_maxAcceleration</b>	M19	Acceleration of spindle in position control. Also effective for the spindle in the speed control loop if <b>MP_maxAccSpeedCtrl</b> and/or <b>MP_maxDecSpeedCtrl</b> are not defined.
<b>MP_limitSpeedAcc</b>	M3/M4/M5	Limit speed for reduction of the acceleration
<b>MP_limitSpeedDec</b>	M3/M4/M5	Limit speed for reduction of the braking deceleration
<b>MP_limitAccSpeedCtrl</b>	M3/M4/M5	Absolute acceleration. Effective above <b>MP_limitSpeedAcc</b>
<b>MP_limitDecSpeedCtrl</b>	M3/M4/M5	Absolute deceleration during braking. Effective above <b>MP_limitSpeedDec</b> .

The parameters **MP\_limitSpeedAcc**, **MP\_limitSpeedDec**, **MP\_limitAccSpeedCtrl** and **MP\_limitDecSpeedCtrl** are only effective for spindles in speed control. If the parameters do not exist or the value 0 has been entered, a "kink-free" ramp with the values from **MP\_maxAcceleration** or **MP\_maxAccSpeedCtrl** and **MP\_maxDecSpeedCtrl** is output.



### MP\_maxAccSpeedCtrl

Optional acceleration for the spindle with shaft speed control  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: Value in [1000°/sec<sup>2</sup>] with up to 9 decimal places

This parameter is only effective for spindles. If 0 is entered or there is no parameter, the acceleration from **MP\_maxAcceleration** is used.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

### MP\_maxDecSpeedCtrl

Optional braking ramp for the spindle with shaft speed control  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: Value in [1000°/sec<sup>2</sup>] with up to 9 decimal places

This parameter is only effective for spindles. If the value 0 is entered or the parameter is not available, the value from **MP\_maxAccSpeedCtrl** will be used for the brake acceleration. If **MP\_maxAccSpeedCtrl** is also 0 or not present, the value from **MP\_maxAcceleration** will be used.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN



### **MP\_limitSpeedAcc**

Limit speed for reduction of the acceleration  
Available from NCK software version: 597 110-05.

Format: Numerical value  
Input: Value in [°/min] or [mm/min] with up to 9 decimal places  
Acceleration of the spindle with "broken" acceleration curve:  
The parameter sets the absolute limit speed above which the acceleration is reduced.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

### **MP\_limitSpeedDec**

Limit speed for reduction of the braking deceleration  
Available from NCK software version: 597 110-05.

Format: Numerical value  
Input: Value in [°/min] or [mm/min] with up to 9 decimal places  
Braking of the spindle with "broken" deceleration curve:  
The parameter sets the absolute limit speed above which the braking deceleration is reduced.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

### **MP\_limitAccSpeedCtrl**

Absolute acceleration. Effective above MP\_limitSpeedAcc  
Available from NCK software version: 597 110-05.

Format: Numerical value  
Input: Value in [m/s<sup>2</sup>] with up to 9 decimal places  
Acceleration of the spindle with "broken" acceleration curve:  
Specifies the absolute acceleration of the spindle, which becomes effective above the speed defined with **MP\_limitSpeedAcc**.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

### **MP\_limitDecSpeedCtrl**

Absolute deceleration during braking. Effective above MP\_limitSpeedDec  
Available from NCK software version: 597 110-05.

Format: Numerical value  
Input: Value in [m/s<sup>2</sup>] with up to 9 decimal places  
Braking of the spindle with "broken" deceleration curve:  
Specifies the absolute deceleration during braking, which becomes effective above the speed defined with **MP\_limitSpeedDec**.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

## 6.18.4 Filtering the acceleration values

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPositionFilter <b>manualFilterOrder</b>	401605

The parameter object CfgPositionFilter is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)

The **MP\_manualFilterOrder** parameter differentiates between axes and spindles. Linear acceleration is used for the operation of spindles.

**MP\_manualFilterOrder** allows you to filter the acceleration values.

**MP\_manualFilterOrder** for axes: see "Filter before position control loop" on page 901

- ▶ Define the order of the mean-value filter for spindles in **MP\_manualFilterOrder**.

### **MP\_manualFilterOrder**

Order of mean-value filter in Manual mode  
 Available from NCK software version: 597 110-01.

Format: Numerical value  
 Input: 1 to 51  
 Default: 11  
 Access: LEVEL3  
 Reaction: RUN



## 6.18.5 Controlling the spindle

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgControllerTol <b>speedTolerance</b> <b>timeSpeedOK</b>	401103 401104


The parameter object **CfgControllerTol** is only required for spindles.

Also, the parameter object is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)

### Switch on / switch off spindle drive

The following figure shows the procedure for switching the spindle drive on/off.



The NC or PLC store the information on controlling the spindle in the following PLC operands.

PLC operand / Description	Type
NN_SpiDriveReady Spindle drive is ready 0: Drive not ready for operation 1: Drive ready for operation	M
PP_SpiDriveOnRequest Switch spindle drive on. This operand is used to switch closed-loop control of the spindle on or off. It can be switched on only in the ready condition ( <b>NN_SpiDriveReady</b> = 1). 0: Do not activate the drive 1: Activate the drive	M
NN_SpiDriveOn Spindle drive is switched on (and is at least speed-controlled) 0: Drive is off 1: Drive is on	M

PLC operand / Description	Type
PP_SpiSpeedMax Maximum spindle speed	D
PP_SpiEnable Spindle enabling 0: Spindle not enabled 1: Spindle enabled	M
NN_SpiInMotion Spindle in motion 0: Spindle not in motion 1: Spindle in motion The operand is set if the nominal velocity of a spindle is not equal to 0, e.g. when - The spindle is controlled by the NC (tapping) - It is controlled by the PLC (9000 modules for M3/M4) The operand is not set (not even if the above conditions are fulfilled): - With spindle override = 0 - PLC has withdrawn the spindle enabling (PP_SpiEnable = 0)	M



#### Note

The PLC program offers the following ways to detect a real movement of the spindle:

- Find the actual speed of the spindle through Module 9411 (<desired spindle information> : 10)
- Connect "NN\_SpiInMotion = 0" and "NN\_SpiSpeedOK = 1". This attains the information that the spindle speed is less than 5 rpm.

## Spindle control by PLC

The PLC controls the spindle by using the following modules:

- Module 9412: Stop the spindle, see page 1018
- Module 9413: Rotate the spindle, see page 1019
- Module 9414: Position the spindle (M19), see page 1027
- Module 9416 Select gear range and assigned settings for spindle, see page 1568.
- Module 9417: Set shaft speed for spindle
- Module 9418: Set status for spindle, see page 684

The status is queried by

- Module 9410: Read spindle status



### Note

**PP\_SpiEnable = 1** must be set for a spindle movement to be executed.

In order to remain compatible with old PLC programs that use the numerical programming interface API 1.0, PLC Module 9171 is available as an alternative (see "Module 9171 Start of a spindle orientation with adjustable parameters" on page 1021).

### Module 9410 Read spindle status

The module reads the status of the specified spindle.

This module is only supported by the new symbolic memory interface. If the iTNC-compatible programming interface is used (API 1.0), the module returns an error.

Call:

```
PS   B/W/D/K  <>Spindle index>
CM   9410
PL   D        <>Spindle status>
                1: No job active – Last job was OK
                2: No job active – Last job was faulty
                3: Job is being executed
PL   D        <>Spindle mode>
                1: Spindle at standstill
                2: Spindle turning clockwise
                3: Spindle turning counterclockwise
                4: Spindle is position-looped (M19)
```

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Status ascertained
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid spindle number
	99	Module is not supported (control does not operate with symbolic memory interface)



### Module 9412 Stop the spindle

Use Module 9412 to stop the specified spindle (M5 status).

This module is only supported by the new symbolic memory interface. If the iTNC-compatible interface (API 1.0) is used, the module returns an error.

Call:

PS B/W/D/K <>Spindle index>

CM 9412

PL D <>Error code>

0: Module successfully executed

1: Incorrect module call

2: No permission for module call (example: NC is cutting a thread at the time it is instructed to execute a command)

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Spindle is stopped
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid spindle number
	9	Module call not possible at this time
	99	Module is not supported (control does not operate with symbolic memory interface)

### Module 9413 Move the spindle

The module rotates the specified spindle in CW/CCW direction (M3/M4) at a constant rotational speed or at a constant cutting speed.

Constraints:

- This module is only supported by the new symbolic memory interface. If the iTNC-compatible interface is used (API 1.0), the module returns an error.
- With an analog spindle the voltage to be output for a reciprocation movement is read from the configuration data, and the shaft speed given is ignored. With a digitally controlled spindle the given shaft speed is interpreted as the motor shaft speed for the reciprocation movement.

Call:

PS B/W/D/K <>Spindle index>

PS B/W/D/K <>Mode>

Bit 0 and bit 1: Direction of rotation

01 = Rotation CW (M3)

10 = Rotation CCW (M4)

Bits 2 to 4: Type of rotation

001 = Constant surface speed

010 = Constant shaft speed

100 = Constant motor shaft speed for reciprocation movement

PS D/K <>Rotational speed or cutting speed>

Constant cutting speed in [m/min]

Constant rotational speed in [rpm]

CM 9413

PL D <>Error code>

0: Module successfully executed

1: Incorrect module call

2: No permission for module call

3: Rotational speed not allowed

4: Mode not allowed

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Status ascertained
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid spindle number
	9	Module call not possible at this time
	99	Module is not supported (control does not operate with symbolic memory interface)

### Module 9417 Set default shaft speed for spindle

You use Module 9417 to enter a default shaft speed for the spindle for the display. It can also set a shaft speed for the monitoring when switching between wye to delta operation.

Constraints:

- The default shaft speed for the display is not offset by the spindle override, i.e. any value set with the override potentiometer must be included via the PLC program.
- The maximum actual shaft speed is shown, as well as the shaft speed entered via the module.
- The shaft speed for calculations in the NC program may only be set if no NC program is being executed or if a strobe with synchronization of the advance calculation is pending. The value SYNC\_CALC must be set for **MP\_sync** when configuring the strobe.
- The shaft speed must not be negative.
- Modes 2 to 4 of this module are only supported by the new symbolic memory interface. If you are using the iTNC-compatible memory interface (API 1.0), the module returns an error. Use Module 9173 if you are using the iTNC-compatible memory interface.

Call:

```
PS   B/W/D/K  <>Spindle index>
PS   B/W/D/K  <>Mode>
                1: Shaft speed for display
                2: Shaft speed for NC program
                3: Switchover speed from wye to delta operation
                4: Switchover speed from delta to wye operation
PS   B/W/D/K  <>Speed in 1/1000 rpm>
CM   9417
PL   B/W/D    <>Error number>
                0: Module successfully executed
                1: Invalid spindle number given
                2: Invalid mode given
                3: Negative shaft speed given
                4: Shaft speed for NC program was changed during program
                    run
```

### Error recognition:

Marker	Value	Meaning
M4203 or NN_GenApiModuleError	0	No error; shaft speed set
	1	Error code in W1022 or NN_GenApiModuleErrorCode(a) or see error code above
W1022 or NN_GenApiModuleError Code	2	Invalid task data transferred (see error number in returned value)
	21	Shaft speed for NC program was changed during program run
	99	Function is not supported (control does not operate with symbolic memory interface)





## Module 9171 Start of a spindle orientation with adjustable parameters

Module 9171 can be used to start an orientation of the spindle. The orientation speed, orientation angle and the direction of rotation can be set. The module sets M4130, which displays that the positioning is running and for how long.



### Note

This PLC module was introduced in order to remain compatible with older PLC programs (with API version 1.0) of older HEIDENHAIN contouring controls. This module is **not** supported if the symbolic programming interface is used. Use Module 9414 instead.

### Constraints:

- If no speed output has occurred for the spindle, the call will have no effect.
- If the marker M4130 is set in the same PLC scan and Module 9171 is called, the spindle is oriented with the parameters from the module call.
- If the module is called several times in the same scan, the spindle will be oriented with the parameters of the last call.
- If the module is called although an orientation from an earlier PLC scan is not yet finished, the call will have no effect.
- The module functions only in the cyclic PLC program.
- If the module is called while the spindle is turning, the direction of orientation that was transferred will be ignored. The spindle is always oriented in the direction of spindle rotation.
- If the values +2 to +4 are transferred as direction of rotation, the spindle can be oriented to the angle last defined in CYCL DEF 13. The transferred angle of orientation is added to the value from CYCL DEF 13. Therefore the PLC can transfer an additional spindle preset.
- If 0 is transferred as the speed, the speed from MP3520.1 is used.
- The module is only supported for PLC programs that use API version 1.0.

### Call:

```
PS   B/W/D/K  <>Orientation angle [1/10000 degrees]>
      or additional preset if there is a value from CYCLE DEF 13
PS   B/W/D/K  <>Speed [1/1000 rpm]>
PS   B/W/D/K  <>Direction of rotation>
      -1: Negative direction (M04)
      0: Direction of the shorter path
      1: Positive direction (M03)
      2: Same as -1, but angle from CYCLE DEF 13
      3: Same as 0, but angle from CYCLE DEF 13
      4: Same as +1, but angle from CYCLE DEF 13
```

CM 9171

**Error recognition:**

<b>Marker</b>	<b>Value</b>	<b>Meaning</b>
M4203	0	Spindle is oriented, M2712/M4130=1
	1	Error code in NN_GenApiModuleErrorCode
W1022	1	The value for direction of rotation or rotational angle is invalid
	2	The spindle number or speed is incorrect, or there has been no speed output
	19	Spindle is not a closed-loop spindle
	24	Module was called from a spawn/submit job
	27	A spindle orientation is already running.



## Tolerances for "rotational speed reached"


The MANUALplus 620 reports "Rotational speed reached" (**NN\_SpiSpeedOK** = 1), if

- the actual speed has reached the tolerance band specified under **MP\_speedTolerance** for the time from **MP\_timeSpeedOK**,
- the nominal speed does not lie below the minimum speed of the current parameter set as specified in **MP\_minFeed**,
- the spindle is no longer in the acceleration/braking ramp.

The programmed speed serves for comparison.

Special characteristics:

- If the programmed speed is not equal to 0 and **MP\_speedTolerance** = 100 %, the MANUALplus 620 sets **NN\_SpiSpeedOK** = 1.
- If the spindle movement is to be stopped (programmed speed = 0), the MANUALplus 620 monitors the spindle for a speed  $n < 5$  rpm.
- ▶ In **MP\_speedTolerance**, define the size of the control window.
- ▶ In **MP\_timeSpeedOK**, define the period of time which the rotational speed (feed rate) is to remain within the control window.
- ▶ In **MP\_minFeed** of the respective spindle parameter set, define the minimum permissible speed for the spindle.



**MP\_speedTolerance**

Rotational speed (feed rate) window

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 01 to 100 [%]

Default: 10 [%]

Access: LEVEL3

Reaction: RUN

**MP\_timeSpeedOK**

Hysteresis time for monitoring the speed deviation

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.006 to 10 [s]

Default: 0.01 [s]

Access: LEVEL3

Reaction: RUN

**MP\_minFeed**

Applies only to spindles: minimum spindle speed

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0.000 000 000 to 36 000 000 [mm/min] or [°/min]

Default: 0

Access: LEVEL3

Reaction: RUN

The NC provides the information "rotational speed reached" in

**NN\_SpiSpeedOK.**

PLC operand / Description	Type
NN_SpiSpeedOK Spindle speed reached 0: Spindle speed not reached 1: Spindle speed reached	M

## Monitoring the spindle speed

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgSpeedControl <b>vCtrlSpinSpeedTol</b> <b>vCtrlSpinMinSpeed</b> <b>delayEmStopSpin</b>	    400930 400931 400933

A percentage value for the permissible shortfall of the nominal spindle speed can be entered in **MP\_vCtrlSpinSpeedTol**. You can thus use this machine parameter for monitoring whether the spindle speeds falls below a specific spindle speed limit.

Example:

Nominal speed = 500 rpm, **MP\_vCtrlSpinSpeedTol** = 20 %

If the speed falls below 400 rpm, monitoring is activated.

Monitoring is useful for power milling where the workpiece is to be machined at a high feed rate and a low constant spindle speed. If the monitoring function responds, an EMERGENCY STOP reaction is triggered in order to protect the machine from possible damage, for example if the spindle comes to a standstill while still engaged in the material. The error message **8BF0 Actual speed value too small** is displayed.

Monitoring for falling below the lower spindle speed limit (defined in **MP\_vCtrlSpinSpeedTol**) does not become active until the actual spindle speed exceeds the value defined in **MP\_vCtrlSpinMinSpeed**. This threshold is required in order to avoid activating the monitoring function before a reasonable shaft speed is reached. A reasonable shaft speed has been reached if the noise of encoders at the actual value of the spindle speed is of subordinate importance. **MP\_vCtrlSpinMinSpeed** also prevents monitoring from becoming active when the tool plunges into the material.

In an EMERGENCY STOP, braking of the spindle is delayed compared to braking of the axes by the time in **MP\_delayEmStopSpin**. This avoids tool breakage during power milling, because low spindle speeds might result in the spindle coming to a standstill before the axes do. However, the spindle braking is delayed by no more than half a spindle revolution.

### **MP\_vCtrlSpinSpeedTol**

Permissible spindle speed shortfall  
Available from NCK software version: 597 110-05.

Format: Numerical value  
Input: 0 to 100 [%]  
cf. iTNC 530: MP3540  
Permissible lower limit of the actual spindle speed multiplied by a percentage of the nominal speed. If the current spindle speed falls below the defined value, the MANUALplus 620 outputs an error message.

Default: No value, parameter optional (= monitoring off)  
Access: LEVEL3  
Reaction: RUN

### **MP\_vCtrlSpinMinSpeed**

Minimum spindle speed as of which the monitoring in MP\_vCtrlSpinSpeedTol becomes active  
Available from NCK software version: 597 110-05.

Format: Numerical value  
Input: 0 to 16 666.666 666 667 [rpm]  
cf. iTNC 530: MP3542

Default: No value, parameter optional (= monitoring off)  
Access: LEVEL3  
Reaction: RUN

### **MP\_delayEmStopSpin**

Delay of emergency-stop reaction of spindles  
Available from NCK software version: 597 110-05.

Format: Numerical value  
Input: 0.001 to 0.1 [s]  
cf. iTNC 530: MP3550

Default: No value, parameter optional (= delay not active)  
Access: LEVEL3  
Reaction: RUN



## Positioning the spindle (M19/trip dog position)

The PLC command defined in

- Module 9414 instructs the NC to activate spindle positioning.
- Module 9412 instructs the NC to deactivate spindle positioning.

Use Module 9414 to switch on position feedback control. Position feedback control is effective until it is switched off by Module 9412.

### Module 9414 Position the spindle

The module is used for the following functions:

- Position the spindle (M19): The spindle is stopped at the specified position. The mode defines the direction of rotation.
- Stop the spindle at the trip dog position (mode bit 3 = 1): The spindle is positioned to the trip dog at the specified rotational speed (see "Stopping/referencing the spindle at trip dog position" on page 1005).

This module is only supported by the new symbolic memory interface. If the iTNC-compatible interface (API 1.0) is used, the module returns an error.

Call:

PS B/W/D/K <>Spindle index>

PS B/W/D/K <>Mode>

Bits 0 to 2: Direction of rotation

000 = Shortest direction of rotation, absolute position entry

001 = Rotation CW, absolute position entry

010 = Rotation CCW, absolute position entry

100 = Relative position entry, rotational direction from algebraic sign of position entry

Bit 3: Select the function

0 = "Position the spindle (M19)" function

1 = "Stop spindle at trip dog position" function

PS D/K <>Absolute or relative position in [0.0001°]>

PS D/K <>Rotational speed in [0.0001 rpm]>

CM 9414

PL D <>Error code>

0: Module successfully executed

1: Incorrect module call

2: No permission for module call

3: Rotational speed not allowed

4: Mode not allowed

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Status ascertained
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid spindle number
	9	Module call not possible at this time
	99	Module is not supported (control does not operate with symbolic memory interface)

The NC stores the status information on spindle positioning in the following PLC operands.

PLC operand / Description	Type
NN_SpiControl Spindle in position control loop 0: Spindle is not in position control loop 1: Spindle is in position control loop	M
NN_SpiControlInPos Spindle in position 0: Spindle is not in position 1: Spindle is in position	M

## Tapping

The NC puts the spindle in the position control loop during tapping and thread cutting (Cycle 18 for TNC controls). Please be aware that the spindle is position-looped (NN\_SpiControl = 1) even for tapping with a floating tap holder (Cycle 2). The job is not transmitted by the PLC.

The NC shows in the following PLC operands that a tapping operation is currently being executed (both markers are set simultaneously).

PLC operand / Description	Type
NN_SpiTapping Tapping active 0: Tapping not active 1: Tapping active	M
NN_SpiRigidTapping Tapping with spindle interpolated with Z axis active 0: Tapping not active 1: Tapping active	M



## 6.18.6 Switching the operating modes

As soon as the operating mode is switched with Module 9163, the NC switches the drive controller of the spindle off and activates the parameter set from the motor table and the machine parameters. You can check this with Module 9162. After the operating mode has been switched, you must reactivate the drive controller of the spindle with Module 9161.

For a spindle motor, two parameter sets with the same name can be saved in the motor table. This may be necessary if

- Another parameter set applies to a spindle motor at the higher speed range.
- A wye/delta connection switchover is carried out for a motor.

With Module 9163 you can switch between the drive parameters for wye and delta connections of the spindle. The switchover can be carried out during standstill or with a revolving spindle.



### Danger

The contactor for the wye/delta switchover must not be switched under load!

To use the operating-mode switchover:

- ▶ Enter the two parameter blocks of your spindle motor with the same name in the motor table. Identify parameter block 1 by entering 0 in the **MODE** column, and parameter block 2 by entering 1.
- ▶ Switch between the two operating modes with Module 9163.
- ▶ With Module 9161, reactivate the drive controller.

For the two operating modes, you can use different machine parameters for the spindle (e. g. current and speed controller):

Settings in the configuration editor	MP number
System	
PLC	
CfgPlcSStrobe	
[Key name of S strobe]	
<b>gearSpeed0</b>	104008
<b>gearSpeed1</b>	104009

- ▶ Enter the key names of spindle parameter sets either in the **MP\_gearSpeed0** parameter (wye connection) or **MP\_gearSpeed1** (delta connection). These parameter sets define the gear ranges for operating modes 0 or 1, if they are selected with PLC Module 9163. Then create the parameter sets with the desired parameters in the configuration editor.



### Note

Use the KeySynonym function to create a new parameter set, see "The KeySynonym Function" on page 377

The configuration object **CfgFeedLimits** of the respective parameter set defines the minimum and maximum spindle shaft speed for each gear range. The list must be sorted in ascending order, with the smallest shaft speed at the top. Gear ranges are not supported if the list is missing or empty.

Module 9163 reports an error if it is called from a PLC program using the numerical TNC API version 1.0.

### **MP\_gearSpeed0**

Key names of parameter sets for gear ranges (operating mode 0)  
Available from NCK software version: 597 110-02.  
Format: Array [0...99]  
Input: List with key names for spindle parameter sets for operating mode 0.  
Default: –  
Access: LEVEL3  
Reaction: RESET

### **MP\_gearSpeed1**

Key names of parameter sets for gear ranges (operating mode 1)  
Available from NCK software version: 597 110-02.  
Format: Array  
Input: List with key names for spindle parameter sets for operating mode 1.  
Default: –  
Access: LEVEL3  
Reaction: RESET



### Module 9163 Switch the drive parameters for delta and wye connection

The module cancels the pulse release of the designated axis, and activates the given parameter set for the drive. When 0 is transferred the parameter set for wye connection is activated, and when 1 is transferred the set for delta connection is activated. Define in **MP\_gearSpeed0** the parameters for wye connection, and in **MP\_gearSpeed1** the parameters for delta connection.

Constraints:

- The axis must be configured as a spindle. It may neither be assigned to an NC channel, nor may it be controlled by one.
- The position control loop for the axis must not be a closed position loop, not even if the motor is switched off.
- A parameter set must be configured for the combination of selected operating mode and active gear range.
- Do not call the module again with the already active operating mode.
- Do not call the module again during a switchover.

Call:

```
PS    B/W/D/K  <>Axis>
PS    B/W/D/K  <>Type of connection>
                0: Wye connection
                1: Delta connection
```

CM 9163

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Parameters were switched
	1	Faulty call parameters, see error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	An axis that is not configured or not configured as a spindle was transferred.
	2	Incorrect type of connection transferred
	3	No parameter set was defined for the combination of switching type and gear range
	9	The entered switching type is already active
	21	The transferred axis is currently being controlled by an NC channel
	27	The position control loop of the transferred axis is currently closed
	28	A switchover is already active



## 6.18.7 Analog spindle with unipolar motor

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgAxisAnalog <b>unipolar</b>	400113



### Note

This function is only available if the spindle is controlled via an analog nominal-value output!

The same polarity of the nominal voltage value is output for both directions of rotation (M3 and M4) for "unipolar" spindles. (For example, for a speed of 9 V, or 1000 rpm, a voltage of +4.5 V is output for S500 for both M3 and M4.) The motor is then switched over by means of a contactor controlled by a PLC output.

You configure a unipolar spindle as follows:

- ▶ Open the parameter set of the spindle concerned and move the cursor to the **CfgAxisAnalog** config object.
- ▶ Add the optional parameter **MP\_unipolar** (400113) to the configuration.
- ▶ Configure the parameter according to your needs (see the parameter description below)

### MP\_unipolar

Algebraic sign with analog unipolar drives  
 Available from NCK software version: 597 110-03.

Format: Selection menu

Selection: **off**  
 Not a unipolar drive.  
**always positive**  
 A positive voltage is output for each direction of rotation (M3, M4).  
**always negative**  
 A negative voltage is output for each direction of rotation (M3, M4).

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN



## 6.18.8 Spindle synchronism

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgSpindle <b>kvFactorSync</b>	401512
CfgControllerTol <b>syncTolerance</b>	401105
<b>timeSyncOK</b>	401106

The parameter object CfgControllerTol is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)

### Separate kv factor for spindle synchronism

With **MP\_kvFactorSync** you can define a separate kv factor for the spindle synchronism, which is then effective instead of the value from **MP\_kvFactor**. If you enter nothing or the value 0 in **MP\_kvFactorSync**, the control automatically uses the value from **MP\_kvFactor** in CfgPosControl for the spindle synchronism, as well.

#### MP\_kvFactorSync

kv factor for spindle synchronism

Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0.000 000 000 to 999 999 999 [1/s]

Default: 0

Access: LEVEL3

Reaction: RUN

## Tolerances for synchronism

The control reports that the synchronism of two spindles is reached if the spindle remains within the control window of **MP\_syncTolerance** for the period of time defined in **MP\_timeSyncOK**.

- ▶ In **MP\_syncTolerance**, define the size of the control window.
- ▶ In **MP\_timeSyncOK**, define the period of time which the spindle is to remain within the control window.

### MP\_syncTolerance

Angle tolerance for spindle synchronism  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.001 000 000 to 2 [°]  
Default: 0.01  
Access: LEVEL3  
Reaction: RUN

### MP\_timeSyncOK

Hysteresis time for spindle synchronism  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 20 [s]  
Default: 0.01 [s]  
Access: LEVEL3  
Reaction: RUN

## Spindle synchronism

The NC stores the spindle synchronism in the following operands.

PLC operand / Description	Type
NN_SpiSyncSpeed Rotational speed synchronism active 0: Rotational speed synchronism not active 1: Rotational speed synchronism active	M
NN_SpiSyncAngle Angle synchronism active 0: Angle synchronism not active 1: Angle synchronism active	M
NN_SpiSyncReached Synchronism attained 0: Synchronism not reached 1: Synchronism reached	M



## Module 9415 Synchronize spindles

The module synchronizes the specified master spindle and slave spindle.

This module is only supported by the new symbolic memory interface. If the iTNC-compatible interface is used, the module returns an error.

**Rotational speed:** The rotational speed of the master spindle is programmed. The speed factors then determine the speed of the slave spindle.

Remember that:

$$\text{Master speed} * \text{FM} = \text{Slave speed} * \text{FS}$$

- FM: Speed factor of master
- FS: Speed factor of slave

The angle offset is set as default.

Call:

```
PS   B/W/D/K  <>Logic number of master spindle>
PS   B/W/D/K  <>Logic number of slave spindle>
PS   B/W/D/K  <>Mode>
      0: Switch off all synchronism functions (the spindle
          numbers have no meaning)
      1: Switch off synchronization of master spindle and slave
          spindle
      2: Switch on synchronization of master spindle and slave
          spindle
PS   D/K      <>Speed factor of master>
PS   D/K      <>Speed factor of slave>
PS   D/K      <>Angle offset in [0.0001°]>
CM   9415
PL   D        <>Error code>
      0: Module successfully executed
      1: Incorrect module call
      2: No permission for module call
      3: Invalid mode
      4: Invalid speed factor
```

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Status ascertained
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid spindle number
	9	Module call not possible at this time
	99	Module is not supported (control does not operate with symbolic memory interface)

## 6.18.9 Spindle of the kinematics model (as of NC software 548 328-03)

Settings in the configuration editor	MP number
Channels Kinematics CfgKinComposModel [Key name of the kinematic model] <b>activeSpindle</b>	202902

In **MP\_activeSpindle** you specify the spindle used in the kinematic model. This assignment is required for different calculations (for example: calculate feed per revolution, determine tool life, etc.)

### **MP\_activeSpindle**

Key of the active spindle of this kinematic model  
Available from NCK software version: 597 110-01.

Format: String

Input: The key name of the spindle is read from CfgAxes/  
spindleIndices, e.g. "S", "Spindle1", etc.

Default: –

Access: LEVEL3

Reaction: RUN

For more information on the configuration of the machine kinematics of your control, see "Machine Kinematics (As of NC Software 548328-03)" on page 727





## 6.18.10 Spindle of the kinematics model (until NC software 548 328-02)

Settings in the configuration editor	MP number
Channels Kinematics CfgKinModel [Key name of the kinematic model] <b>activeSpindle</b>	200011

In **MP\_activeSpindle** you specify the spindle used in the kinematic model. This assignment is required for different calculations (for example: calculate feed per revolution, determine tool life, etc.)

### **MP\_activeSpindle**

Key of the active spindle of this kinematic model  
Available from NCK software version: 597 110-01.

Format: String

Input: The key name of the spindle is read from CfgAxes/spindleIndices, e.g. "S", "Spindle1", etc.

Default: –

Access: LEVEL3

Reaction: RUN

For more information on the configuration of the machine kinematics of your control, see "Machine Kinematics (Up to NC Software 548 328-02)" on page 747

### 6.18.11 Gear shifting

The PLC is responsible for gear shifting. The PLC also manages the parameters that are required for gear shifting. Please refer to "Gear shifting" on page 1567 in the PLC section of this documentation.

A separate parameter set can be created for every gear range.

The PLC is instructed by M function (M40 to M44) to switch on a certain gear range.



## 6.18.12 Tapping

Tapping is executed with position feedback control. The spindle and the tool axis interpolate with each other. A floating tap holder is not required.

An oriented spindle stop is performed before tapping.

I.e., a certain spindle position is assigned to each axis position. This synchronization makes it possible to cut the same thread more than once. The NC orients the spindle.

The feed-rate can be changed during tapping. In **MP\_sourceOverride** you define the override source (feed-rate override or spindle speed override) for tapping, see page 1356. The MANUALplus 620 automatically adapts the spindle speed if the feed rate is changed.

- ▶ Define another parameter set and switch to this parameter set if you want to achieve a specific control response for tapping.

Under certain circumstances it can make sense to define a separate kv factor for the spindle during tapping. Example:

Reduce the kv factor during tapping to optimize the control response of the spindle.

- ▶ You can define a specific kv factor for the spindle during tapping in **MP\_kvFactorTapping**. This parameter overwrites the value in the **CfgPosControl/kvFactor** parameter.

### **MP\_kvFactorTapping**

	kv factor for tapping
	Available from NCK software version: 597 110-05.
Format:	Numerical value
Input:	Only effective during tapping; replaces the value in CfgPosControl/kvFactor. If the parameter is not defined or 0, the value in CfgPosControl/kvFactor is used.
Default:	No value, parameter optional
Access:	LEVEL3
Reaction:	RUN

### 6.18.13 C-axis operation

In C-axis operation, an axis and a spindle are driven by the same motor.

The MANUALplus 620 supports the following configurations for C-axis operation:

- The C axis and spindle use the same servo drive. Because the speed encoder is built into the motor, it measures both the C axis and the spindle.
- The C axis and spindle each use their own servo drive. Because the speed encoder is built into the motor, there are separate speed encoders for the C-axis and the spindle.
- The C axis and spindle use one position encoder.
- The C axis and spindle each use their own position encoder.
- The axis and spindle can be operated as an analog or digital axis or spindle.

Separate parameter sets for the spindle and C axis are required in all configurations. In these parameter sets, you define the servo drive, the position encoder and speed encoder as well as the other details separately for the spindle and C axis.

- ▶ Define separate parameter sets for spindle and C-axis operation.
- ▶ The commissioning must be performed for spindle operation as well as for C-axis operation.



#### Note

The C-axis position controller should be commissioned in the gear range that is actually used for positioning. If possible, use the lowest gear range to ensure optimum controllability.

If you use only one position encoder for both the spindle and the axis, the axis display keeps running while the spindle is in operation:

- ▶ Before switching from the axis to the spindle, save the actual position value of the axis with Module 9146. This ensures that the axis display remains at the last value, even when the spindle is rotating.
- ▶ Before switching from the spindle to the axis, recover the actual position value of the axis with Module 9146.

If you save the actual position value with Module 9146 and then close the position control loop, or if the position control loop is closed and the actual position value is then saved with Module 9146, the error message **Actual position value saved <Axis>** appears. The error message triggers an emergency stop.

Switching from **spindle to C axis**: (example):

- ▶ Stop the spindle
- ▶ Change the axis by switching the parameter set
- ▶ Start C-axis operation

Switching from **C-axis to spindle** (example):

- ▶ Stop C-axis operation
- ▶ Change the axis by switching the parameter set
- ▶ Start spindle operation

### **Module 9146 Save and reestablish actual position values**

Module 9146 saves and later reestablishes the actual position values of axes. If the actual position values were saved, the last value displayed remains until they are reestablished.

Call:

PS B/W/D/K <>Axes bit-encoded>

PS B/W/D/K <>Mode>

0: Save actual position values

1: Reestablish actual position values

### **Error recognition:**

<b>Marker</b>	<b>Value</b>	<b>Meaning</b>
NN_GenApiModule Error (M4203)	0	Actual position values saved or reestablished
	1	Error code in NN_GenApiModuleError (M4203)
NN_GenApiModule ErrorCode (W1022)	1	Invalid mode
	2	Invalid axes
	24	Module was called in a spawn job or submit job

### 6.18.14 Volts-per-hertz control mode

In volts-per-hertz control mode (U/f control mode), the motor is speed-controlled in an open loop. The motor is digitally controlled using HEIDENHAIN or non-HEIDENHAIN inverter systems.

You can use the following HEIDENHAIN inverters to set up the volts-per-hertz control mode:

- UM 1xx
- UE 2xx
- UR 2xx
- UEC 1xx

You need a control loop to use a motor in volts-per-hertz control mode, and the appropriate axis or spindle has to be enabled in the SIK. Connect the PWM output of the CC with the inverter (not required for UEC 11x)—the encoder inputs remain unconnected.




#### Note

The volts-per-Hertz control mode is a type of digital motor control that does not return the rotational speed. This control mode cannot be used for axes controlled through the analog nominal shaft-speed interface ( $\pm 10$  V signals).

The motor voltage increases in proportion to frequency up to the break (= threshold rpm for field weakening). Then the motor voltage remains constant (= rated voltage of motor); only the frequency continues to increase.

If the spindle reaches the maximum current due to excessive load, the error message **C380 Motor <Spindle 1/2> not controllable** appears. For the maximum current, the value from either the motor table or the power-module table of the drive (whichever is lower) applies.



The maximum speed in the volts-per-hertz control mode corresponds to the maximum speed in closed loop operation.



Settings to drive a motor with a U/f component:

### Settings in the configuration editor:

- ▶ **MP\_posEncoderType = NO\_ENCODER**
- ▶ Set a small value for **MP\_maxAccSpeedCtrl** (permissible axis acceleration).  
As a general rule:  
Select a suitable acceleration and braking ramp to ensure that the maximum drive current (the lesser of maximum motor current and maximum power stage current) is not exceeded. If the maximum current is exceeded, the drives shut down. Controlled braking is not possible in this case.

### Entries in the motor table:

Column	Input	Explanation
<b>TYPE</b>	UASM	Motor model
<b>STR</b>	0	Line count of rotary encoder
<b>SYS</b>	0	Type of encoder
<b>T-MAX</b>	255	Maximum winding temperature in °C
<b>R1</b>	Increase the value until the utilization at standstill or at low shaft speeds is about 40 %.	Stator resistance cold



#### Note

If you enter a value of 0 into the **STR** column of the motor table, the motor is speed-controlled in an open loop. The machine parameters for current controller and speed controller have no effect.



#### Note

Because of the non-linear characteristic of the inverters the spindle should be operated with a utilization of approx. 40 %. You can attain this value by adjusting the **R1** column in the motor table:

The voltage that is output at standstill results from the product of **IO** and **R1** in the motor table. **R1** should be modified depending on the inverter being used.

- If the utilization at standstill is insufficient, the motor lacks power at standstill and at low shaft speeds.
- If the utilization is too high, the motor overheats.

During volts-per-hertz (U/f) control mode, no speed encoder is used.  
Therefore: Actual speed value = Nominal speed value

- ▶ Use Module 9164 to determine the speed while the spindle is running, but not during the acceleration and braking phases.



#### Note

The oscilloscope shows the actual current instead of the nominal current (I NOML), since there is no nominal current with U/f components.

## 6.19 Configuring the Controller Unit and Drive Motors

### 6.19.1 Specifications of CC 61xx / UEC 1xx

Machine interfacing	MANUALplus 620														
<b>Regulation with CC 6xxx / UEC 1xx</b>															
Position control resolution	$\frac{\text{Signal period}}{4096}$ <ul style="list-style-type: none"> <li>- Repeat the measurement</li> <li>- Inform your service agency if the error continues to occur or encoder resolution (EnDat 2.2 interpol.)</li> </ul>														
Path interpolation	3 ms														
Fine interpolation	Cycle time for fine interpolation = Cycle time of position controller														
Cycle time of current controller	<table style="border: none;"> <tr> <td>PWM frequency</td> <td>Cycle time if <b>MP_iCtrlPwmType</b> = 0:</td> </tr> <tr> <td>3333 Hz</td> <td>150 μs</td> </tr> <tr> <td>4000 Hz</td> <td>120 μs</td> </tr> <tr> <td>5000 Hz</td> <td>100 μs</td> </tr> <tr> <td>6666 Hz</td> <td>75 μs (option 49)</td> </tr> <tr> <td>8000 Hz</td> <td>60 μs (option 49)</td> </tr> <tr> <td>10000 Hz</td> <td>50 μs (option 49)</td> </tr> </table>	PWM frequency	Cycle time if <b>MP_iCtrlPwmType</b> = 0:	3333 Hz	150 μs	4000 Hz	120 μs	5000 Hz	100 μs	6666 Hz	75 μs (option 49)	8000 Hz	60 μs (option 49)	10000 Hz	50 μs (option 49)
PWM frequency	Cycle time if <b>MP_iCtrlPwmType</b> = 0:														
3333 Hz	150 μs														
4000 Hz	120 μs														
5000 Hz	100 μs														
6666 Hz	75 μs (option 49)														
8000 Hz	60 μs (option 49)														
10000 Hz	50 μs (option 49)														
Cycle time of speed controller	<ul style="list-style-type: none"> <li>■ Speed controller cycle time = 2 · current controller cycle time</li> <li>■ Unless PWM frequency ≤ 5 kHz and double-speed performance, then: Speed controller cycle time = Current controller cycle time</li> </ul>														
Cycle time of position controller	Position controller cycle time = Speed controller cycle time														





Machine interfacing	MANUALplus 620
<p>Maximum motor speed</p> <p>or by way of:</p>	$n_{\max} = \frac{f_{\text{PWM}} \cdot 60000 \text{ min}^{-1}}{p \cdot 5000 \text{ Hz}}$ <p><math>n_{\max}</math>: Maximum motor speed [<math>\text{min}^{-1}</math>]  <math>f_{\text{PWM}}</math>: PWM frequency [Hz]  <math>p</math>: Number of pole pairs</p> <p>The following PWM frequencies are available:  3333 Hz, 4000 Hz, 5000 Hz  With option 49: 6666 Hz, 8000 Hz, 10 000 Hz</p> <hr/> <p>Maximum signal frequency of motor encoder = 400 kHz or 800 kHz (depending on <b>MP_vCtrlEnclInputFunc</b> bit 0)</p> <p>Calculation of maximum motor speed:</p> $n_{\max} = \frac{f_{\max} \cdot 60000 \text{ [s/min]}}{\text{STR}}$ <p><math>n_{\max}</math>: Maximum motor speed [<math>\text{min}^{-1}</math>]  <math>f_{\max}</math>: Maximum signal frequency of motor encoder [kHz]  STR: Encoder line count</p> <p>Example 1:</p> $n_{\max} = \frac{400 \text{ kHz} \cdot 60000 \text{ [s/min]}}{2048}$ <p><math>n_{\max} = 11718.75 \text{ min}^{-1}</math></p> <p>Example 2:</p> $n_{\max} = \frac{800 \text{ kHz} \cdot 60000 \text{ [s/min]}}{2048}$ <p><math>n_{\max} = 23437.5 \text{ min}^{-1}</math></p>
<p>Maximum feed rate by way of:</p>	<p>Maximum signal frequency of the position encoder:</p> <ul style="list-style-type: none"> <li>■ At 1 Vpp: 27 kHz or 400 kHz</li> <li>■ At 11 <math>\mu\text{A}_{\text{pp}}</math>: 27 kHz or 140 kHz</li> </ul> <p>Calculation of the maximum feed rate <math>F_{\max}</math>:</p> $F_{\max} = \text{SP} \cdot f_{\max} \cdot 60^{-3} \left[ \frac{\text{m} \cdot \text{s}}{\mu\text{m} \cdot \text{min}} \right]$ <p><math>F_{\max}</math>: Maximum feed rate [m/min]  <math>f_{\max}</math>: Maximum signal frequency of position encoder [kHz]  SP: Signal period of the position encoder [kHz]</p> <p>Example:</p> $F_{\max} = 20 \mu\text{m} \cdot 400 \text{ kHz} \cdot 60^{-3} \left[ \frac{\text{m} \cdot \text{s}}{\mu\text{m} \cdot \text{min}} \right]$ <p><math>F_{\max} = 480 \text{ m/min}</math></p>

## 6.19.2 Structure of the CC 61xx and UEC 11x controller units

There is no backplane between the CC and MC for the CC 61xx and MC 6xxx. The CCs continue to be supplied via X69. The MCs of the new generation are supplied with +24 V NC voltage via X101, independently of the CCs.

A new DSP processor is used on the CC 61xx and the UEC 11x. A single one of these DSPs can regulate up to six control loops, with the same controller performance as the CC 424.

The CC 61xx family has a modular structure. The addressed DSP is on the motherboard of the controller. These drive-control motherboards have two control loops, and can therefore control two axes. The same applies to each drive-control expansion board, which does not have its own DSP, however. A drive-control expansion board has two control loops, but can only be used in combination with a drive-control motherboard (with DSP).

Up to two controller expansion boards can be connected to a drive-control motherboard (with DSP). This configuration results in a maximum of six axes that a single DSP can control. If more than six axes are to be controlled, then another drive-control motherboard is necessary, providing another DSP.

If two drive-control motherboards (two DSPs) are housed in one CC, then the inputs and outputs of the CC are uniquely assigned to one of the two DSPs via the letters A and B.

Index A means that these inputs and outputs are controlled by the first DSP (first drive-control motherboard). Index B means that these inputs and outputs are controlled by the second DSP (second drive-control motherboard).

For configuring the controller units via machine parameters, the HSCI address of the respective drive-control motherboard must be entered in **MP\_hsciCIndex**. The HSCI address is obtained from the position of the drive-control motherboard in the HSCI system. The first drive-control motherboard after X500 of the MC is given the address 0, etc. However, the HSCI address to be entered only depends on the drive-control motherboards in the system. I/O units (PLs) and machine operating panels (MBs) are not taken into account. This means that for the first drive-control motherboard, you have to enter the address 0 in MP108, regardless of whether PLs or MBs are located before the CC in the HSCI chain.

There is one LED on each drive-control motherboard indicating its HSCI address relevant for **MP\_hsciCclIndex** by a blink code.



Also, on the CC 61xx the inputs and outputs have permanent assignments to each other. Switching of the inputs and outputs, as with the CC 424, is not possible here.

Example:

X51, X15, X201 are permanently assigned to each other.

X53A, X17A, X203A are permanently assigned to each other.

etc.

See the table for the assignments. The assignment within each row is permanent. Switching between the rows is not possible with the CC 61xx.

Speed output: PWM output	Input: Speed encoder	Input: Position encoder
X51 (A/B)	X15(A/B)	X201 (A/B)
X52(A/B)	X16(A/B)	X202(A/B)
X53(A/B)	X17(A/B)	X203(A/B)
X54(A/B)	X18(A/B)	X204(A/B)
X55(A/B)	X19(A/B)	X205(A/B)
X56(A/B)	X20(A/B)	X206(A/B)

### PWM frequencies of the CC 61xx

The same PWM frequency must be set for both PWM outputs of a controller group in MP2180.x.

- Controller group 1: X51, X52
- Controller group 2: X53, X54
- Controller group 3: X55, X56

### 6.19.3 PWM frequencies with the CC 61xx

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPowerStage <b>ampPwmFreq</b>	401204
CfgCurrentControl <b>iCtrlPwmType</b>	401003

In **MP\_ampPwmFreq**, you assign different PWM frequencies to the CC 61xx controller groups.

There are three fundamental PWM frequencies: 3.333 kHz, 4 kHz and 5 kHz. A control loop is operated at the fundamental PWM frequency or at double the fundamental PWM frequency (6.666 kHz, 8 kHz, 10 kHz).

The same PWM frequency must be assigned to both PWM outputs of a controller group with **MP\_ampPwmFreq**. Otherwise, the DSP error message **C440 PWM frequency <axis> incorrect** will appear.

- Controller group 1: X51, X52
- Controller group 2: X53, X54
- Controller group 3: X55, X56

► In **MP\_ampPwmFreq**, enter the PWM frequency.

#### **MP\_ampPwmFreq**

PWM frequency  
 Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **0**  
 5 kHz (for HEIDENHAIN inverters)  
**3.333 kHz**  
**4.166 kHz**  
**5 kHz**  
**6.666 kHz**  
**8.333 kHz**  
**10 kHz**

Default: 0

Access: LEVEL3

Reaction: RESET



The cycle time of the current controller depends on the PWM frequency:

$$T_I = \frac{1}{2 \cdot f_{PWM}}$$

If a control loop is operated at double the fundamental PWM frequency, the current controller cycle time is halved. However, this is possible only with double-speed control loops.

If you want to operate single-speed control loops at double the fundamental PWM frequency,

- ▶ Set **MP\_iCtrlPwmType** = 1 in order to calculate the current controller cycle time from the fundamental PWM frequency although the control loop will be operated at double the fundamental PWM frequency.

If you operate a single-speed control loop at double the fundamental PWM frequency and half the current controller cycle time (**MP\_iCtrlPwmType** = 0), the error message **C017 PWM frequency too high** will appear. Current controller cycle time depending on the PWM frequency:

PWM frequency	Single-speed control loop MP_iCtrlPwmType		Double-speed control loop MP_iCtrlPwmType	
	=0	=1	=0	=1
3.333 kHz	150 µs	Error C013!	150 µs	Error C013!
4 kHz	125 µs	Error C013!	125 µs	Error C013!
5 kHz	100 µs	Error C013!	100 µs	Error C013!
6.666 kHz	Error C017!	150 µs <sup>a</sup>	75 µs	150 µs <sup>a</sup>
8 kHz	Error C017!	125 µs <sup>b</sup>	62.5 µs	125 µs <sup>b</sup>
10 kHz	Error C017!	100 µs <sup>c</sup>	50 µs	100 µs <sup>c</sup>

- Fundamental PWM frequency of 3333 Hz
- Fundamental PWM frequency of 4000 Hz
- Fundamental PWM frequency of 5000 Hz

### MP\_iCtrlPwmType

Current controller cycle time

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 0: Cycle time =  $1 / (2 \cdot f_{PWM})$

1: Cycle time =  $1 / f_{PWM}$

2: Reserved

The value from CfgPowerStage/ampPwmFreq is used as the PWM frequency  $f_{PWM}$ .

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

#### 6.19.4 PWM frequency with INDRAMAT "POWER DRIVE" inverters

- ▶ In **MP\_ampPwmFreq**, enter the PWM frequency 4.166 kHz.

#### 6.19.5 PWM frequency with SIEMENS "SIMODRIVE" inverters

The MANUALplus 620 operates with a PWM frequency of 5 kHz. SIEMENS power modules are normally driven with a PWM frequency of 3.2 kHz (spindle) and 4 kHz (axes).

The rated current values  $I_N$  are defined for these frequencies. If power modules are operated with a higher PWM frequency (e.g. 5 kHz), high temperatures can be caused in these modules in some cases.

This applies particularly to these SIEMENS power modules:

- 6SN1123-1AA00-0CA0 (as axis module)
- 6SN1123-1AB00-0CA0 (as axis module)

Machines that are not under full load do not exceed the maximum permissible temperature.

There are two ways to prevent the undesired heating:

- ▶ In **MP\_ampPwmFreq**, enter the required PWM frequency (3.333 kHz or 4.166 kHz).  
or
- ▶ Reduce the factor for  $I^2t$  monitoring  
or
- ▶ Reduce rated current  $I_N$  in the table of power modules.



#### Note

A reduction of the PWM frequency has no effect on the maximum rotational speed, but it means that the axes and the spindle(s) must be commissioned again.

When a new machine is put into service, HEIDENHAIN recommends the PWM frequency fitting for the axis modules (normally 4 kHz, see the SIEMENS documentation). If the power module of the spindle gets too warm in spite of a reduction of the PWM frequency from 5 kHz to 4 kHz, then the reference value for the  $I^2t$  monitoring or the rated current  $I_N$  must be reduced in the table of power modules.

### Reduction of the reference value for $I^2t$ monitoring or rated current $I_N$ in the table of power modules

The reduction of the rated current  $I_N$  of the power modules, as well as the reference value for  $I^2t$  monitoring can be calculated from two values ( $X1$ ,  $X2$ ) that are given in the SIEMENS documentation.

The percent reduction of the rated current can be calculated with the following formula:

$$X_R[\%] = 100 - \left( \frac{(100 - X1) \cdot (8 \text{ kHz} - f_{PWM})}{8 \text{ kHz} - X2} + X1 \right)$$

- $X1$  = Reduction factor of the current in % at a PWM frequency of 8 kHz
- $X2$  = PWM threshold frequency in kHz at which the electrical power reduction begins
- $f_{PWM}$  = PWM frequency in kHz set in MP\_ampPwmFreq

This results in the reference value for  $I^2t$  monitoring:

$$X_B = 1 - \frac{X_R[\%]}{100}$$

- ▶ Reduce the rated current values  $I_N$  of your power modules in the power module table.

$$I_{N_{new}} = I_N \cdot (100 \% - X_R[\%])$$

or

- ▶ Reduce the reference value (CfgServoMotor/motFactorI2t) for the  $I^2t$  monitoring.

$$\text{Reference value} = X_B$$



#### Note

A reduction of the rated current of the power module can cause a reduction of the rated torque and, as a consequence, the rated power of the motor, if equal values for rated current of the power module and the rated current of the motor were chosen.

**Example of a 50 A power module:**

- Axis power module with 50 A, PWM frequency of 5 kHz, X1 = 40 %, X2 = 4 kHz

$$X_R[\%] = 100 - \left( \frac{(100 - 40) \cdot (8 \text{ kHz} - 5 \text{ kHz})}{8 \text{ kHz} - 4 \text{ kHz}} + 40 \right) = 15 \%$$

$$X_B = 1 - \frac{15}{100} = 0.85$$

- Spindle power module with 50 A, PWM frequency of 5 kHz, X1 = 40 %, X2 = 3.2 kHz

$$X_R[\%] = 100 - \left( \frac{(100 - 40) \cdot (8 \text{ kHz} - 5 \text{ kHz})}{8 \text{ kHz} - 3.2 \text{ kHz}} + 40 \right) = 22.5 \%$$

$$X_B = 1 - \frac{22.5}{100} = 0.78$$

- Axis power module with 50 A, PWM frequency of 4 kHz, X1 = 40 %, X2 = 4 kHz

$$X_R[\%] = 100 - \left( \frac{(100 - 40) \cdot (8 \text{ kHz} - 4 \text{ kHz})}{8 \text{ kHz} - 4 \text{ kHz}} + 40 \right) = 0 \%$$

$$X_B = 1 - \frac{0}{100} = 1.0$$

- Spindle power module with 50 A, PWM frequency of 4 kHz, X1 = 40 %, X2 = 3.2 kHz

$$X_R[\%] = 100 - \left( \frac{(100 - 40) \cdot (8 \text{ kHz} - 4 \text{ kHz})}{8 \text{ kHz} - 3.2 \text{ kHz}} + 40 \right) = 10 \%$$

$$X_B = 1 - \frac{10}{100} = 0.90$$



## 6.19.6 Comparison of the CC 61xx and CC 424 controller units

Function	CC 61xx	CC 424
Hardware	Position encoder inputs X201(A) to X206(A) and X201B to X206B on the CC 61xx	Position encoder inputs X201 to X206 and X207 to X210 on the CC 424
Assignment of speed encoder inputs to the PWM outputs	Permanent assignment, position encoder inputs are also permanently assigned. Always in one row, e.g. X16A, X51A and X202A are permanently assigned to each other.	Fixed assignment, MP_speedEncoderInput not required
MP_hsciCcindex	Assignment of axes and spindles to drive-control motherboards	Not present
MP_pwmSignalOutput	Assignment of axes and spindles to the speed outputs (X15 to X18, X15 to X20)	Assignment of axes and spindles to speed outputs
MP_posEncoderType	New possible choice "CC_EXTERN_ENDAT_2_2" for CC 61xx.	The choice "CC_EXTERN_ENDAT_2_2" has no function
Encoders with EnDat 2.2 interface	Encoders with EnDat 2.2 interface can be operated without analog encoder signals. The position is evaluated purely digitally via a serial data protocol. The parameter MP_posEncoderSignal has no effect. EnDat 2.2 encoders can be selected as motor encoders in parameter MP_motEncType.	Encoders can only be operated via analog encoder signals.
PWM frequency	Same as CC 424, only the controller groups for which the same PWM frequency must be set have changed, see page 1046.	Can be set via MP_ampPwmFreq (switchable during operation); the calculation of the current-controller cycle time must be adapted via MP_iCtrlPwmType
Control loops can be switched from single speed to double speed for higher controller performance	Option 49 "Double speed" is not available on lathes.	
Control-loop cycle times (at 5000 Hz PWM frequency) (position/speed/current)	Single-speed: 200 µs/200 µs/100 µs Double-speed: 100 µs/100 µs/100 µs (with position encoder) 100 µs/100 µs/100 µs (without position encoder)	Single-speed: 200 µs/200 µs/100 µs Double-speed: 200 µs/100 µs/100 µs (with position encoder) 100 µs/100 µs/100 µs (without position encoder)
Following error in the jerk phase (MP_complpcJerkFact)	Same as CC 424	Typical input values: 0.001 to 0.005

Function	CC 61xx	CC 424
Stick-slip friction compensation (MP_compFriction0, MP_compFrictionT1, MP_compFrictionT2)	Same as CC 424	Feed-rate independent; MP_compFriction0 same meaning as previously (effective values, readjustment necessary), MP_compFrictionT1 new meaning MP_compFrictionT2 new
Filter in the speed control loop	Same as CC 424	MP_vCtrlFiltLowPassT omitted, new machine parameters: MP_vCtrlFiltDamping1 to MP_vCtrlFiltDamping5 MP_vCtrlFiltFreq1 to MP_vCtrlFiltFreq5 MP_vCtrlFiltType1 to MP_vCtrlFiltType5 MP_vCtrlFiltBandWidth1 to MP_vCtrlFiltBandWidth5 MP_vCtrlEnclInputFilt new meaning
Master-slave torque control	The PWM outputs of the master and slave axes must always be operated on the same DSP (meaning the same controller basic board for the CC 61xx), i.e. the master and slave axes must be operated with the same power. More slave axes are possible for the CC 61xx than before, e.g. up to five slave axes are possible for a CC for six axes.	The PWM outputs of the master and slave axes must always be operated on the same DSP ("single-speed" setting)
Reading the absolute value of encoders with EnDat interface	Same as CC 424	The absolute value can be read out again via the <b>PASS OVER REFERENCE</b> soft key or via Module 9220 (i.e. after the exchange of milling heads).
MP_motEncCheckOff	Same as CC 424	Bit 4: Monitoring for excessive temperature Bit 5: Monitoring for insufficient temperature Bit 6: Reserved Bit 7: Monitoring of encoder input frequency Bit 8: Adjust mechanical offset by gradually increasing the $k_V$ factor
MP_motTypeOfFieldAdjust	Same as CC 424	Determining the field angle for unaligned encoders
MP_plcCount	Same as CC 424	PLC cycle time [ms]

Function	CC 61xx	CC 424
MP_ipoCycle	Same as CC 424	MP_ipoCycle omitted, path interpolation fixed at 3 ms (does not influence the position controller cycle)
Display in internal oscilloscope and in TNCopt	Same as CC 424	Effective values

### 6.19.7 Configuring the drive motor

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgServoMotor <b>motName</b> <b>motEncType</b> <b>motDir</b> <b>motStr</b>	   401301 401311 401312 401313
System Paths CfgTablePath MOTOR_OEM <b>path</b>	   MOTOR_OEM.102501

The parameter object CfgServoMotor is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Analog axes (**MP\_axisHw** = Analog)

Configure the servo motor in the CfgServoMotor parameter object. You can use the entries in the motor table for the parameters **MP\_motEncType**, **MP\_motDir** and **MP\_motStr**, or use the three parameters to overwrite the values in the motor table.

The motor table currently active for the MANUALplus 620 is opened when making an entry in **MP\_motName**. Select the name of the motor.

Along with the motor table supplied by HEIDENHAIN, the OEM has the possibility of saving his own motor table on the MANUALplus 620 as well. The soft keys OEM and SYS are used to open the respective tables in the table editor. The SYS motor table is write-protected.

In the dialog window for selecting a motor, all entries from the OEM motor table have an asterisk (\*) in the OEM column to identify them as entries made by the OEM.

You must configure the path to the OEM motor table. In the "Settings in the configuration editor" table at the top of the page you will find the **MP\_path** parameter.

- ▶ Specify the path to the OEM motor table under the key name "MOTOR\_OEM" in the **MP\_path** parameter.

### MP\_motName

Name of the motor  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: Name of the motor  
Choose the name from the motor table.  
Default: –  
Access: LEVEL3  
Reaction: RESET

Enter the type of encoder in **MP\_motEncType**. If "off" is entered, then the type of encoder entered in the motor table is used.

### MP\_motEncType

Type of speed encoder  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: **off**  
The encoder type entered in the motor table is valid.  
**ROTATING\_WITH\_Z1**  
Incremental rotary encoder with Z1 track  
**ROTATING\_ENDAT\_ADJUSTED**  
Aligned absolute rotary encoder  
**LINEAR\_ENDAT**  
Absolute linear encoder  
**LINEAR\_INCREMENTAL**  
Incremental linear encoder  
**ROTATING\_ENDAT\_NOT\_ADJUSTED**  
Unaligned absolute rotary encoder  
**ROTATING\_WITHOUT\_Z1**  
Incremental rotary encoder without Z1 track  
**ROT\_DIST\_CODED\_NOT\_ADJUSTED**  
Unaligned incremental rotary encoder with distance-coded reference marks  
**LIN\_DIST\_CODED\_NOT\_ADJUSTED**  
Unaligned linear encoder with distance-coded reference marks  
**DIG\_ENDAT\_2\_2\_ADJUSTED**  
Purely digital and aligned EnDat 2.2 rotary encoder  
**DIG\_ENDAT\_2\_2\_NOT\_ADJUSTED**  
Purely digital and unaligned EnDat 2.2 rotary encoder  
**LIN\_ENDAT\_2\_2**  
Purely digital EnDat 2.2 linear encoder  
Default: off  
Access: LEVEL3  
Reaction: RESET



You define the counting direction of the encoder in **MP\_motDir**. If "off" is entered, then the counting direction entered in the motor table is used.

### **MP\_motDir**

Counting direction of the motor encoder

Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **Off**

The counting direction entered in the motor table is valid.

**Positive**

Positive counting direction.

**Negative**

Negative counting direction.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

Use the parameter **MP\_motStr** to define the line count of the motor encoder. If "0" is entered, then the line count entered in the motor table is used.

### **MP\_motStr**

Line count of the motor encoder

Available from NCK software version: 597 110-02.

Format: Numerical value

Input: **0**: The line count entered in the motor table is used.

**> 0**: Line count of the motor encoder

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

## 6.19.8 Field orientation

### General Information

If a linear, torque or synchronous motor is used with an incremental encoder without a Z1 track or an unaligned encoder with EnDat interface, there is no assignment between the encoder and the rotor magnets. The field angle must be determined before this motor can be moved.

The MANUALplus 620 uses the "field orientation" function to determine the field angle for the motors listed above. The assignment between the encoder and the rotor magnet (field angle) is determined and stored.



#### Note

The "field orientation" function can be performed only if the current controller is already adjusted!

Regarding the **motor.mot** motor table, the field orientation must be performed for the following drives:

- Linear motor with absolute encoder with EnDat interface (**SYS = 3**)
- Synchronous or torque motor with unaligned rotary encoder with EnDat interface (**SYS = 5**)
- Synchronous or torque motor with incremental rotary encoder without Z1 track (**SYS = 6**); one reference mark per revolution
- Synchronous or torque motor with incremental rotary encoder with distance-coded reference marks (**SYS = 7**)
- Linear motor with incremental linear encoder with distance-coded reference marks (**SYS = 8**)
- Synchronous or torque motor with unaligned rotary encoder with EnDat 2.2 interface (**SYS = 10**)

Absolute encoder with EnDat interface	Incremental encoders
As soon as the absolute position of the encoder has been read, the absolute position and determined field angle are assigned to each other. The field angle is assigned to the zero position of the encoder.	After switching on the drive, the motor orients itself (rough orientation; the message <b>Finding the field angle</b> appears). The drive is ready for operation after this procedure. The field angle is determined and assigned as soon as the reference mark/s is/are traversed during the first motor motion.



#### Danger

If the speed encoder is exchanged, the Field Orientation function must be rerun.



## General information about encoders for direct drives

- An absolute encoder with EnDat interface should be used, since the absolute position value is available directly after switch-on, and the field angle can be assigned immediately. This means that the motor can be controlled immediately.
- The encoder should have a high line count. This leads to better controllability.
- With incremental encoders the motor must first be moved a "minimum" distance in order to determine a field angle with which the motor can be moved until the reference mark. Only after the reference mark has been traversed can the field angle determined during commissioning be assigned.
- If excessive clamping of the axis prevents the "minimum" motion for determining the field angle, then no field angle can be determined and the axis cannot be controlled. In this case the clamping must be undone for the field angle to be determined. If this is not possible, because the axis would fall down, then an absolute encoder with EnDat interface must be used.

## Field orientation with absolute encoder (EnDat)

As soon as the absolute position of the encoder has been read, the absolute position and determined field angle are assigned to each other. The field angle is assigned to the zero position of the encoder.

## Field orientation via encoder with Z1 track

After switching on the MANUALplus 620, the motor orients itself (rough orientation) via the Z1 track of the encoder. The drive is ready for operation after this procedure. The field angle is determined and assigned as soon as the reference mark is traversed during the first motor motion.

## Field orientation via the MANUALplus 620

There are various possibilities for determining the field angle:

- The field angle is determined automatically when the drive is switched on, without any motion of the motor. This method is set via **MP\_motTypeOfFieldAdjust**. The field angle is stored after it has been determined. This field angle is used when the motor is switched on again. An adjustment of the field angle via the special operating mode **Current Controller and Field Angle Adjustment** (code number 94655) is not necessary.
- By adjusting the field angle once via the special operating mode **Current Controller and Field Angle Adjustment** (code number 94655) during commissioning of the motor. The motor moves during the adjustment, and the field angle is determined and stored during this motion. This field angle is used when the motor is switched on again. A plausibility test is run during the field angle determination.



### Warning

This method **cannot** be used for hanging axes (with 100 % weight compensation), since the brakes are not applied and the monitoring functions are deactivated!



### Note

The "field orientation" function can be performed only if the current controller is already adjusted!



#### Note

For synchronous spindles, the field angle should be determined via the code number, since this is a more exact determination.



#### Danger

- An encoder with absolute values or an encoder with a Z1 track must be used when determining the field angles for hanging axes (or braked axes that could move on their own).
- If the speed encoder is exchanged, the Field Orientation function must be rerun.





## 6.19.9 Determining the field angle with the CC 61xx und CC 424

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgServoMotor	
<b>motTypeOfFieldAdjust</b>	401314
<b>motFieldAdjustMove</b>	401315
<b>motPhiRef</b>	401316
<b>motEncSerialNumber</b>	401317
CfgAxisHardware	
<b>checkPhiFieldRef</b>	400016

The parameter object CfgServoMotor is not required for:

- Virtual axes (**MP\_axisMode** = Virtual)
- Axes that are for display only (**MP\_axisMode** = Display)
- Analog axes (**MP\_axisHw** = Analog)

- ▶ Select the method for field angle determination in **MP\_motFieldAdjustMove**.

HEIDENHAIN recommends using **MP\_motFieldAdjustMove = mode 2** when commissioning new drive systems (such as machine prototypes), because the plausibility tests will be run. After successful commissioning, **MP\_motFieldAdjustMove = mode 0** can be used to save time (such as for series production of the machine).

In certain cases it can be of advantage to determine the field angle via **MP\_motFieldAdjustMove = mode 3**. This mode can be used if

- there are no brakes,
- in the **Commissioning Current Controller** mode of operation, where the brakes are always open,
- the user ensures that the brakes can be opened manually or with the PLC.

## MP\_motFieldAdjustMove

	Feed-angle adjustment mode Available from NCK software version: 597 110-05.
Format:	Selection menu
Selection:	Possibilities of field angle adjustment: <b>mode 0</b> Rough determination of the field angle during operation (An adjustment of the field angle via the special operating mode <b>Current Controller and Field Angle Adjustment</b> (MOD code number 94655) is not necessary.) Field angle is determined for a motor at standstill. No plausibility tests. Use parameter "MP_motTypeOfFieldAdjust" to specify the method for rough determination of the field angle. <b>mode 1</b> Only on CC 422. Precise determination of the field angle via soft key. Use only for spindles or motors without limit switches! Do not use for hanging axes! Drive is moved during field angle determination. <b>mode 2</b> Only with CC 424, CC 61xx. Precise determination of the field angle via MOD code number 94655. The field angle is determined for a motor during motion. Caution: No position monitoring (following error or software limit switch)! Recommended for horizontal axes or hanging axes with full weight compensation. <b>mode 3</b> Like mode 2. However, the drive does not have to be enabled via the PLC. Caution: Note the safety precautions on the following pages!
Default:	No value, parameter optional (initial value: mode 0)
Access:	LEVEL3
Reaction:	RUN



### Note

For synchronous spindles the field angle should be determined via the MOD code number 94655 (**MP\_motFieldAdjustMove = mode 2**) because this method of determination is more precise.

## Plausibility test

During plausibility testing, some machine parameters and part of the wiring are checked.

- Encoder line count
- Number of pole pairs
- Rotational direction of the electrical field
- Traverse distance per electrical revolution




### Note

Determination of the field angle with plausibility testing is recommended for initial setup, new designs, and other similar situations.

The following messages can appear during the plausibility test:

- **8630 Field orient. successful**  
Indicates that the field angle was successfully determined and stored in **MP\_motPhiRef**.
- **8B10 Wrong traverse direction**  
Indicates that the rotational direction of the electrical field does not match the counting direction of the encoder.  
Error fix: Change the entry in the machine parameter **MP\_motDir**.
- **8B20 Error field orientation**  
Indicates that no usable measurement results could be determined. One common reason for this is that the parameters for the encoder are incorrect. A further cause could be that the motor is moving against a resistance (e.g. brake is still active, bellows, limit stop) or that the mechanics are too stiff.

## Overview of the field orientation



## Determining the field angle without motor motion

A distinction must be made if you intend to determine the field angle without motor motion (**MP\_motFieldAdjustfMove = mode 0**):

- Commissioning: No field angle has been determined yet (**MP\_motPhiRef = 0**)
- A field angle has already been determined (**MP\_motPhiRef ≠ 0**).

The field angle is determined automatically after switching on the drive. This process lasts approximately 4 to 6 seconds (the PLC program must not rescind the drive enabling during this time).

If the power module is not active before the determination of the field angle begins, the error message **8B40 No drive release <axis>** appears. If the power module switches off during the determination, **8B50 Axis module <axis> not ready** appears.

### Field angle not yet determined (**MP\_motPhiRef = 0**):

If the field angle on this machine was not yet determined after the control was started (**MP\_motPhiRef = 0**), the determination starts automatically. The method used to determine the field angle is set in

**MP\_motTypeOfFieldAdjust**. The determined field angle is stored in **MP\_motPhiRef**.

### Field angle already determined (**MP\_motPhiRef ≠ 0**):

If the field angle on this machine was already determined after the control was started (**MP\_motPhiRef ≠ 0**), a distinction must be made:

- If an absolute encoder with EnDat interface is being used:  
The absolute position of the encoder is read immediately after the control has been started. The field angle from **MP\_motPhiRef** is assigned to this position. Therefore, the first motor motion already occurs with the determined field angle.
- If an incremental encoder is being used:  
Immediately after the control has been started and the control voltage has been switched on, then depending on **MP\_motTypeOfFieldAdjust** a field angle is determined with which the motor can be traversed over the reference mark. After traversing the reference mark, the field angle from **MP\_motPhiRef** is assigned. The subsequent motor motions utilize the field angle from **MP\_motPhiRef**.
- Initial operation, field angle has not been determined yet (**MP\_motPhiRef = 0**): Determination of the field angle is started automatically when the MANUALplus 620 is switched on. The method for determining the field angle is set in **MP\_motTypeOfFieldAdjust**. The determined angle is stored in **MP\_motPhiRef**.

## Methods for determining the field angle

There are three methods for determining the field angle without motor motion (rough determination):

■ **Method 2: (MP\_motFieldAdjustMove = mode 2)**

Current pulses are output with the brakes applied, and the absolute rotor position is determined from the reaction. A "minimum" movement of the motor must be possible when the brakes are applied.

■ **Method 3: (MP\_motFieldAdjustMove = mode 3)**

Functions in the same manner as Method 2, but with the difference that the motor brakes are not applied. Therefore, this method is not suitable for hanging axes. However, this method can lead to more exact results than Method 2, so it should be used for synchronous spindles. Minimal spindle movements can occur during field angle determination.

■ **Method 4: (MP\_motFieldAdjustMove = mode 4)**

This new method was introduced for determining the field angle so that the relationship between the position of the incremental encoder and the position of the rotor magnets can be established even if there is considerable noise in the encoder signals.

Use this method only in consultation with HEIDENHAIN!

- In **MP\_motTypeOfFieldAdjust** select the method to be used for determining the absolute rotor position.

### MP\_motTypeOfFieldAdjust

	Rough determination of the field angle without motor motion Available from NCK software version: 597 110-02.
Format:	Selection menu
Selection:	If a precise value is available for the field-angle orientation, the rough value is used until the axis has been referenced. Methods of rough determination of the field angle: <b>mode 0</b> Recommended for all motors. Do not use for hanging axes! <b>mode 1</b> Reserved, do not use! <b>mode 2</b> Field angle determination with brake applied. A "minimum" movement of the motor must be possible when the brakes are applied. <b>mode 3</b> Like "mode 2" with the difference that the brake is opened. Not suitable for hanging axes! <b>mode 4</b> Reserved. Use only in consultation with HEIDENHAIN. (For very noisy encoder signals.)
Default:	No value, parameter optional (initial value: mode 0)
Access:	LEVEL3
Reaction:	RESET



#### Note

Standstill monitoring is active while determining the field angle. If it responds for motors without motor brakes, increase the threshold in **MP\_checkPosStandstill**. Afterwards, reset **MP\_checkPosStandstill** to the original value.

## Determining the field angle with motor motion

With this field angle determination method (**MP\_motFieldAdjustMove = mode 2** or **mode 3**), the motor moves in a certain direction. It should be approximately halfway in the distance traversed before the field angle is determined.

Axes with linear/torque motors can be slid "by hand" if the brakes are not applied.

While the field angle is being found, the speed controller and position controller are open and the drive controller is active. This means that the motor is moved (approx. 2 pole pairs) and the brake must be open until the field angle is determined.



### Danger

**Hanging axes need 100 % weight compensation.  
Please contact HEIDENHAIN if this is not the case.**



### Warning

Limit switches are ignored!  
If axes move into an illegal area, press the emergency stop button!



### Note

When using incremental encoders with distance-coded reference marks, **MP\_posEncoderRefDist** (nominal increment between two fixed reference marks) must be set correctly.

### **MP\_motFieldAdjustMove = mode 2:**

The PLC commissioning program, whose name and path are entered in the parameter **MP\_pwmPgm**, must ensure that the inverters are ready after "Switch on external dc voltage," but that the motor brakes are opened only while the field angle is being determined. Alternately, the motor brakes can be opened manually for the duration of the field angle determination.

### **MP\_motFieldAdjustMove = mode 3:**

Under certain conditions, determination of a field angle with the help of the PLC is not necessary or desired. Here the motor is moved immediately after the **FIELD ORIENT**. key is pressed, and the field angle is determined. This mode can be used if

- there are no brakes,
- in the **Current Controller and Field Angle Adjustment** special mode of operation (code number 94655), the brakes are always open,
- the user ensures that the brakes can be opened manually or with the PLC.

Before determining the field angle (code number 94655 not entered yet) the inverter must be in the following mode of operation:

- Green "READY" LED on
- Red "SH1" LED off
- Red "SH2" LED on (drive controller not ready, brakes closed)

As soon as the drive enable comes from the PLC, the **Finding field angle** message appears, otherwise **8B40 No drive release** appears.

The motor moves and the field angle is determined. Limit switches are not taken into account.

In order to avoid the possible error message resulting from standstill monitoring, enter an appropriately high value in **MP\_checkPosStandstill**.

- ▶ Switch on the MANUALplus 620.
- ▶ Do **not** acknowledge the **Power interrupted** message. Enter the code number **94655**.
- ▶ The PLC must
  - switch the drive on/off
  - release and lock the brakes

The motor moves back and forth. The field angle is determined for the reference mark or datum, and is stored automatically. The **Finding field angle** progress bar appears. Then one of the following messages appears:

- **8630 Field orient. successful** indicates that the field angle was successfully determined and stored in **MP\_motPhiRef**.
- **8B10 Wrong traverse direction** indicates that the rotational direction of the electrical field does not match the counting direction of the encoder.  
Error fix: Change the entry in the machine parameter **MP\_motDir**.
- **8B20 Error field orientation** indicates that no usable measuring results could be determined. One common reason for this is that the parameters for the encoder are incorrect. A further cause could be that the motor is moving against a resistance (e.g. brake is still active, bellows, limit stop) or that the mechanics are too stiff.

The MANUALplus 620 carries out a reset. If the message **8630 Field orient. successful** appears, then the field angle was associated and is available.





### Module 9065 Status of the commissioning function

Module 9065 is used to interrogate status information of commissioning functions dealing with the determination of the field angle, and with the commissioning of the current controller of an axis.

Conditions for the determination of the field angle:

- Synchronous, linear and torque motors determine the field angle each time the control is started if no EnDat or Z1-track encoders are used. For the duration of determining the field angle (about 5 to 7 seconds), <Mode> 1 returns bit-encoded the axes for which field-angle determination is active.
- Module 9162 reports that the speed controller is not ready while the field angle is being determined. A PLC error message can be suppressed if determining is active.

Conditions for commissioning the current controller:

- If no commissioning function is active, the value -1 is returned.

Call:

PS B/W/D/K <>Mode>

Determining the field angle:

0: Axes for which the field angle is being determined with a commissioning aid

1: Axes for which automatic determination of the field angle is active

Commissioning the current controller:

2: Axes for which the commissioning of the current controller is active

3: Interrogation whether the spindle is in delta operation during the commissioning of the current controller (bit 0 = 1)

CM 9065

PL B/W/D <>Axes bit-encoded>

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Axes have been determined
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Invalid value for mode

## Saving the determined field angle

The determined field angle is automatically entered in **MP\_motPhiRef**.

For purposes of reliability and redundancy, either the serial number of the encoder (only for EnDat interface) or a unique control ID is entered as identification in **MP\_motEncSerialNumber**.

An error message appears if the current identification does not match the entry in **MP\_motEncSerialNumber**:

- When using an encoder with EnDat interface, the error message **8830 EnDat: no field angle <axis>** appears. In any case the field angle must be determined anew, since the encoder does not match the field angle from MP\_motPhiRef.
- When using an incremental encoder, the error message **MP2257.<index> incorrect (ID=\$<identification>)** appears. The field angle from **MP\_motPhiRef** and the new identification (**ID=\$<identification>**) for **MP\_motEncSerialNumber** can only be assumed after determining that the same drive is meant (e.g. after changing controls).



### Danger

In all other cases the field angle must be determined anew, since otherwise uncontrolled drive motions could occur!



### Note

You can force a new field angle determination by entering MP\_motPhiRef = 0 (for example, after exchanging a motor or encoder).

## MP\_motPhiRef

	Determined field angle
	Available from NCK software version: 597 110-01.
Format:	Numerical value
Input:	Automatic determination and entry by interpolator in the operating mode for determining the field angle. 0: Field angle does not need to be determined, or has not been determined
Default:	0
Access:	LEVEL3
Reaction:	RESET

## MP\_motEncSerialNumber

	Control or encoder identification for the field angle from MP_motPhiRef
	Available from NCK software version: 597 110-01.
Format:	Numerical value
Input:	0: Field angle does not need to be determined, or has not been determined
Default:	No value, parameter optional
Access:	LEVEL3
Reaction:	RESET

## Definition of the field angle

The following applies to the determined field angle, which is entered in **MP\_motPhiRef**:

The motor is moved with external power in the positive direction (when viewing the shaft, the shaft rotates clockwise). The voltages  $U_{1-Y}$  (phase 1 to star point) and  $U_{2-Y}$  (phase 2 to star point) are measured. The positive peak value of  $U_{1-Y}$  corresponds to a field angle of  $90^\circ$ .

The field angle at the reference mark is saved in increments in **MP\_motPhiRef**. An increment is formed from  $\langle \text{line count} \rangle \cdot \langle \text{interpolation factor} \rangle$ .


Therefore:

$$\mathbf{MP\_motPhiRef} = (\langle \text{field angle at reference mark} \rangle \cdot \langle \text{line count} \rangle \cdot 1024) / 360^\circ$$

In the example below, the reference mark is at the field angle  $90^\circ$ , i.e.

$$\mathbf{MP\_motPhiRef} = (90^\circ \cdot 2048 \cdot 1024) / 360^\circ = 524288.$$

On a "standard" synchronous motor (with aligned speed encoder), the reference mark is at the field angle  $0^\circ$ . If the field angle were to be determined for this motor, the result would be **MP\_motPhiRef** = approx. 2097152.



- $U_{1-Y}$ : Motor voltage between phase 1 and star point
- $U_{2-Y}$ : Motor voltage between phase 2 and star point
- FA: Field angle in degrees
- $FA_{2048}$ : Field angle in increments for an encoder with 2048 lines and 1024-fold interpolation ( $2048 \cdot 1024 = 2\,097\,152$ )

## 6.20 Commissioning











### 6.20.1 Tables for power modules, supply modules and motors

In the configuration editor you select the installed power modules and the motors:

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPowerStage <b>ampName</b> <b>ampAdditionalInfo</b> CfgServoMotor <b>motName</b> <b>motEncType</b> <b>motDir</b> <b>motStr</b> <b>motSupply</b>	   401201 401210  401301 401311 401312 401313 401321
System CfgSupplyModule [Key name of the supply module] <b>name</b>	117200

- ▶ Open the parameter set of the desired axis, and move the cursor to the **MP\_ampName** (power stage) or **MP\_motName** (motor) parameter.
- ▶ Press the ENT key. The MANUALplus 620 opens the list of power modules or motors.
- ▶ Add the configuration object **CfgSupplyModule** to the machine configuration.
- ▶ Enter a freely chosen key name for the supply module and select the storage file \*.cfg.
- ▶ Move the cursor to the **MP\_name** parameter and press ENT. The MANUALplus 620 opens the list of supply modules. Select your power supply module from the table.
- ▶ Open the parameter set of the desired axis, and move the cursor to the **MP\_motSupply** (CfgServoMotor) parameter.
- ▶ In **MP\_motSupply**, enter the key name of the power supply module that drives this motor. All key names from **CfgSupplyModule** are available for selection.



Meaning of the soft keys	
	Scroll back one page in the list
	Scroll forward one page in the list
	Confirm selection
	Cancellation, do not confirm value
	Open OEM motor table in the table editor
	Open HEIDENHAIN motor table in the table editor (write-protected)
	Open power module table ( <b>inverter.inv</b> ) in the table editor (write-protected)
	Open power supply module table ( <b>supply.spy</b> ) in the table editor (write-protected)
	Copy selected value to clipboard
	Paste value from clipboard

In the list of motors, the memory location (OEM or HEIDENHAIN motor table), the type of motor (synchronous, asynchronous, or linear motor), the operating mode (wye/delta) and the maximum current are displayed in addition to the motor designation.

Once you have selected the motor and power module, and have confirmed this with the ENT key or the OK soft key, the selected models are automatically entered in **MP\_motName** and **MP\_ampName** for the respectively open parameter set.

If you use motors or power modules that are not listed in the menus, please contact HEIDENHAIN.

You can overwrite standard data or add other models to the OEM motor table. The OEM motor table is stored in the PLC partition:

■ **PLC:\table\MOTOR\_OEM.MOT**

To open the OEM motor table, press the OEM soft key in the table editor. In the list view, the MANUALplus 620 marks all motors from the OEM table with an "\*" in the **OEM** column.

The data in the HEIDENHAIN motor table and in the **inverter.inv** power module table on the SYS partition is write-protected. You can open the tables, but you cannot edit them.



#### Note

The power module table of older HEIDENHAIN contouring controls, **MOTOR.AMP**, is no longer supported by the MANUALplus 620!

If you use a motor that appears in the motor table, but only the data for the speed encoders differs, you can overwrite this data in the motor table with **MP\_motStr**, **MP\_motDir** and **MP\_motEncType**. The motor table is not actually changed. The changes only take place in the working memory.



#### Note

The original entry from the motor table is only used if **MP\_motStr**, **MP\_motDir** and **MP\_motEncType** are not in the configuration.

### MP\_name

Type of power supply module  
Available from NCK software version: 597 110-05.  
Format: Selection menu  
Selection: Name of the power supply module from the "supply.spy" power supply module table (entered automatically by the MANUALplus 620)  
Default: –  
Access: LEVEL3  
Reaction: RESET

### MP\_motSupply

Key name of the motor's power supply module  
Available from NCK software version: 597 110-05.  
Format: Selection menu  
Selection: Enter the key name of the power supply module that drives this motor. All power-supply-module key names defined under CfgSupplyModule are available for selection.  
Default: –  
Access: LEVEL3  
Reaction: RUN

### MP\_ampName

Type of axis/spindle power module  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: Name of the power module from the inverter.inv power module table (entered by the MANUALplus 620)  
Default: –  
Access: LEVEL3  
Reaction: RESET



### MP\_ampAdditionalInfo

Configure the switch position of the current sensor (column "S" of the inverter.inv power module table). Is required for the D series of HEIDENHAIN inverters (UM 1xx D) in order to use the higher currents at the lower PWM frequencies.  
Available from NCK software version: 597 110-04.

Format: Numerical value (32 bits)  
Input: Bit 0 – Configure the switch position of the current sensor in HEIDENHAIN inverters of the "D" series (UM 1xx D).  
Bit 0 = 0: "S" in inverter.inv table = 0  
Bit 0 = 1: "S" in inverter.inv table = 1  
Bit 1- Reserved  
Bit 2- Reserved  
Bit 3 – Inverter manufacturer  
Bit 3 = 0: Non-HEIDENHAIN inverter  
Bit 3 = 1: HEIDENHAIN inverter  
Default: -  
Access: LEVEL3  
Reaction: RUN

### MP\_motName

Motor model  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: Name of the selected motor from the motor table (entered by the MANUALplus 620)  
Default: -  
Access: LEVEL3  
Reaction: RESET

### MP\_motDir

Overwrite the "counting direction" of the motor encoder from the motor table  
Available from NCK software version: 597 110-03.

Format: Selection menu  
Selection: **Off**  
Value from the motor table active  
**Positive**  
Positive counting direction  
**Negative**  
Negative counting direction  
Default: No value, parameter optional (value from motor table in effect)  
Access: LEVEL3  
Reaction: RESET

### MP\_motStr

Overwrite "Line count" of the motor encoder from the motor table  
Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 0: No speed encoder (volts-per-hertz control mode)  
1 to 999 999

Default: No value, parameter optional (value from motor table in effect)  
Access: LEVEL3  
Reaction: RESET

### MP\_motEncType

Overwrite "Type of encoder" from the motor table  
Available from NCK software version: 597 110-03.

Format: Selection menu  
Selection: **off**  
Entry from the motor table active

**ROTATING\_WITH\_Z1**  
Incremental rotary encoder with Z1 track

**ROTATING\_ENDAT\_ADJUSTED**  
Absolute rotary encoder with EnDat interface (aligned)

**LINEAR\_ENDAT**  
Absolute linear encoder with EnDat interface

**LINEAR\_INCREMENTAL**  
Incremental linear encoder

**ROTATING\_ENDAT\_NOT\_ADJUSTED**  
Absolute rotary encoder with EnDat interface (nonaligned)

**ROTATING\_WITHOUT\_Z1**  
Incremental rotary encoder without Z1 track

**ROT\_DIST\_CODED\_NOT\_ADJUSTED**  
Incremental rotary encoder with distance-coded reference marks (not aligned)

**LIN\_DIST\_CODED\_NOT\_ADJUSTED**  
Incremental linear encoder with distance-coded reference marks (unaligned)

**DIG\_ENDAT\_2\_2\_ADJUSTED**  
Absolute rotary encoder with EnDat 2.2 interface (aligned)

**DIG\_ENDAT\_2\_2\_NOT\_ADJUSTED**  
Absolute rotary encoder with EnDat 2.2 interface (unaligned)

**LIN\_ENDAT\_2\_2**  
Absolute linear encoder with EnDat 2.2 interface

Default: off (value from the motor table active)  
Access: LEVEL3  
Reaction: RESET





**Entries in the power supply module table: (supply.spy)**

- **NAME:** Designation of the power supply module
- **E-R:** Type of power supply module
  - 0: No regenerative module
  - 1: Regenerative module
- **P-N:** Rated power in W
- **P-S6-40:** Peak power (S6-40) in W
- **P-MAX02:** Peak power for (0.2 s) in W
- **UZ:** DC-link voltage in V
- **UZ-AN:** Ratio of measuring voltage / UZ in V/V
- **IZ-AN:** Ratio of measuring voltage / IZ in V/A
- **STATUS-SIG:** Status signals
  - Bit#0: AC-FAIL
  - Bit#1: POWERFAIL
  - Bit#2: TEMP
  - Bit#3: READY
  - Bit#4: Reserved
  - Bit#5: Reserved
  - Bit#6: Reserved
  - Bit#7: Reserved
- **T1:**
- **P-D:** Proportional factor of D controller
- **I-D:** Integral factor of D controller
- **P-Q:** Proportional factor of Q controller
- **I-Q:** Integral factor of Q controller
- **FREQ:** PWM frequency in HZ

## Entries in the power module table (inverter.inv)

- **NAME:** Designation of the power module
- **PWM:** PWM frequency in [Hz] at which the power module is driven
- **S:** Switch position of the current sensor. Is required for the D series of HEIDENHAIN inverters (UM 1xx D) in order to use the higher currents named above at the lower PWM frequencies.  
Input 0 or 1
- **I-MAX:** Maximum current of the inverter output in [A]
- **I-N:** Rated current of the inverter output in [A]
- **U-IMAX:** Current sensor voltage in [V] at I-MAX
- **I-N-DC:** Permissible continuous current in stationary rotating field or until F-DC is reached in [A]
- **T-DC:** Time constant, how long maximum current can be applied to a stationary synchronous motor in [s]
- **F-DC:** Lower motor cutoff frequency down to which the motor can be loaded with I-N-DC in Hz
- **T-AC:** Cycle duration for the duty cycle S6-40% s
- **F-AC:** Motor frequency from which I-MAX is permissible in s
- **T-IGBT:** Protection time of the IGBTs in [s]
- **R-SENSOR:** Resistance of the current sensor. The entries in this column are maintained by HEIDENHAIN and need not be changed by the machine tool builder.
- **F-Limit:** Lower frequency limit
- **D-I-MEAS:** Method of measured value acquisition by the current sensor
  - 0: No digital measured value acquisition
  - 1: Measured value of the current sensor in the power module is transferred via a digital interface to the CC.

## Entries in the motor table (motor.mot)

- **TYPE:** Motor model
  - UASM = uncontrolled asynchronous motor (volts-per-hertz control mode)
  - SM = synchronous motor
  - ASM = asynchronous motor
  - LSM = linear motor
- **NAME:** Designation of the motor
- **MODE:** Operating mode
- **I-N:** Rated current in A
- **U-N:** Rated voltage in V
- **N-N:** Rated speed in  $\text{min}^{-1}$
- **F-N:** Rated frequency in Hz
- **U0:** No-load voltage in V
- **I0:** No-load current in A
- **R1:** Stator resistance cold in  $\text{m}\Omega$
- **R2:** Rotor resistance cold in  $\text{m}\Omega$
- **XStr1:** Stator leakage reactance in  $\text{m}\Omega$
- **XStr2:** Rotor leakage reactance in  $\text{m}\Omega$
- **XH:** Magnetizing reactance in  $\text{m}\Omega$
- **N-XH:** Upper speed X-H characteristic in  $\text{min}^{-1}$
- **N-FS:** Threshold rpm for field weakening in  $\text{min}^{-1}$
- **N-MAX:** Maximum speed in  $\text{min}^{-1}$



- **%-XH**: Factor for X-H characteristic
- **%-K**: Factor for stalling torque reduction
- **PZ**: Number of pole pairs
- **TK**: Temperature coefficient in  $\Omega/K$
- **STR**: Line count of the motor encoder
- **SYS**: Encoder being used
  - 0 = No speed encoder (volts-per-hertz control mode)
  - 1 = Incremental rotary encoder with Z1 track
  - 2 = Absolute rotary encoder with EnDat interface (aligned)
  - 3 = Absolute linear encoder with EnDat interface
  - 4 = Incremental linear encoder
  - 5 = Absolute rotary encoder with EnDat interface (not aligned)
  - 6 = Incremental rotary encoder without Z1 track (one reference mark)
  - Only CC 424 and CC 61xx:
    - 7 = Incremental rotary encoder with distance-coded reference marks (not aligned)
  - Only CC 424 and CC 61xx:
    - 8 = Incremental linear encoder with distance-coded reference marks (not aligned)
- **DIRECT**: Counting direction of the motor encoder
- **T-MAX**: Maximum temperature in  $^{\circ}C$
- **I-MAX**: Maximum current in A
- **P-N**: Rated power in W
- **J**: Motor mass moment of inertia in  $kgm^2$
- **L**: Inductance of the series reactor in  $\mu H$
- **T-DC**: Thermal time constant for direct current in seconds
- **F-DC**: Lower thermal limit frequency in Hz
- **T-AC**: Thermal time constant for alternating current in seconds
- **F-AC**: Upper thermal limit frequency in Hz; above this frequency, the maximum current I-MAX applies
- **Tth1**: Thermal time constant for winding in s
- **Rth1**: Thermal resistance between winding and lamination in K/W
- **Tth2**: Thermal time constant for lamination in s
- **Rth2**: Thermal resistance between lamination and cooling system in K/W
- **M0**: Stall torque in Nm
- **Mmax**: Torque at I<sub>max</sub> in Nm
- **Fpwm**: Minimum PWM frequency recommended for the motor (recommendation; currently not used by the CC software). The current controller values in the K<sub>p</sub> and K<sub>i</sub> columns are calculated values and are based on the entered PWM frequency.
- **Kp**: Calculated current controller P factor (recommendation; currently not used by the CC software)
- **Ki**: Calculated current controller I factor (recommendation; currently not used by the CC software)
- **Ld**: Series inductance in mH
- **Lq**: Shunt inductance in mH
- **TempSens**: In preparation: type of temperature sensor. Enter 0.
- **Rfe**: In preparation: Resistance of iron of the laminated core. Enter 0.

## Series reactor

The inductance of the series reactor is calculated depending on the no-load current  $I_0$ :

$I_0 < 26$  A:

$$L = \frac{700 \mu\text{H} \cdot 5000 \text{ Hz} \cdot U_Z}{f_{\text{PWM}} \cdot 600} - \frac{(X_1 + X_2) \cdot 1000}{2 \cdot \pi \cdot f_N}$$

$I_0 \geq 26$  A:

$$L = \frac{700 \mu\text{H} \cdot 5000 \text{ Hz} \cdot U_Z}{23,1 \cdot I_0 \cdot f_{\text{PWM}}} - \frac{(X_1 + X_2) \cdot 1000}{2 \cdot \pi \cdot f_N}$$

- L: Inductance of the series reactor in  $\mu\text{H}$
- $f_{\text{PWM}}$ : PWM frequency [Hz]
- $X_1$ : Stator leakage reactance [ $\text{m}\Omega$ ]
- $X_2$ : Rotor leakage reactance [ $\text{m}\Omega$ ]
- $f_N$ : Rated frequency [Hz]
- $U_Z$ : DC-link voltage [V]
- $I_0$ : No-load current [A]

A negative result means that there is no series reactor.



### Note

If a series reactor is installed later, the current controller must be readjusted.

The series reactor must fulfill the following specifications:

- The required inductance (per phase)
- Load capacity with the maximum spindle current
- The inductance even with the maximum spindle speed (operating frequency)

## Determining data for synchronous motors

The motor data for synchronous motors are entered in the motor table after some conversions using the values from the motor data sheet of the respective manufacturer (here using the example of a SIEMENS motor).

Values in the HEIDENHAIN motor table	Values from the motor data sheet
TYPE: SM	Permanently excited synchronous motor
NAME: 1FT6044-4AF7	1FT6044-4AF7
MODE: 0	
Rated current I-N in [A <sub>eff</sub> ] winding I-N: 2.9	Data sheet value I <sub>rated</sub> (100 K) I <sub>N</sub> = 2.9 A
Rated voltage U-N in [V <sub>eff</sub> ] interlinked U-N: 340	Calculation from data sheet values n <sub>noml</sub> , k <sub>E</sub> , R <sub>Str</sub> , I <sub>noml</sub> (100 K), L <sub>D</sub> : $U-N = \sqrt{3} \cdot \sqrt{(U_e + U_r)^2 + U_x^2}$ $U_e = (n_{noml} / 1000) \cdot (k_E / \sqrt{3})$ $U_e = (3000 / 1000) \cdot (108 / \sqrt{3})$ $U_e = 187.06 V_{eff L,N}$ $U_r = R_{Str} \cdot I_{noml} (100 K)$ $U_r = 3.05 \cdot 2.9$ $U_r = 8.85 V_{eff L,N}$ $U_x = 2 \cdot \pi \cdot (n_{noml} / 60) \cdot PZ \cdot (LD / 1.5) \cdot I_{noml} (100 K)$ $U_x = 2 \cdot \pi \cdot (3000 / 60) \cdot 2 \cdot (0.016 / 1.5) \cdot 2.9$ $U_x = 19.44 V_{eff L,N}$ $U-N = \sqrt{3} \cdot \sqrt{(187,06 + 8,85)^2 + 19,44^2}$ U-N = 341 V <sub>eff L,L</sub>
Rated speed N-N in [min <sup>-1</sup> ] N-N: 3000	Data sheet value n <sub>noml</sub> N-N = 3000 min <sup>-1</sup>
Rated frequency F-N in [Hz] F-N: 100	Calculation from data sheet value n <sub>noml</sub> F-N = (n / 60) · PZ F-N = (3000 / 60) · 2 F-N = 100 Hz
No-load voltage at rated speed U0 in [V <sub>eff</sub> ] interlinked U0: 324	Calculation from data sheet value n <sub>noml</sub> and k <sub>E</sub> U0 = (n <sub>noml</sub> / 1000) · k <sub>E</sub> U0 = (3000 / 1000) · 108 U0 = 324 V <sub>eff L,L</sub>
No-load current I0 in [A <sub>eff</sub> ] winding I0: 3	Data sheet value I <sub>0</sub> (100 K) I0 = 3 A <sub>eff</sub>
Stator resistance at 20 °C R1 in [mΩ] at 20 °C R1: 3050	Data sheet value R <sub>Str</sub> R1 = 3050 mΩ
Rotor resistance at 20 °C R2 in [mΩ] at 20 °C R2: 0	

Values in the HEIDENHAIN motor table	Values from the motor data sheet
Stator leakage reactance at F-N Xstr1 in [mΩ] Xstr1: 0	If nothing given, then zero.
Rotor leakage reactance at F-N Xstr2 in [mΩ] Xstr2: 0	
Magnetizing reactance XH for F-N at rated conditions XH in [mΩ] XH: 10052	Calculation from data sheet value $L_D$ , $n_{noml}$ $XH = 2 \cdot \pi \cdot (n_{noml} / 60) \cdot PZ \cdot (L_D / 1.5)$ $XH = 2 \cdot \pi \cdot (3000 / 60) \cdot 2 \cdot (0.016 / 1.5)$ $XH = 6702 \text{ m}\Omega$
Desaturation speed N-XH in [min <sup>-1</sup> ] N-XH: 0	
Rotational speed of beginning field weakening range N-FS [min <sup>-1</sup> ] N-FS: 0	
Maximum speed (mechanical) N-MAX in [min <sup>-1</sup> ] N-MAX: 7700	Data sheet value n N-MAX = 7700 min <sup>-1</sup>
Saturation factor %-XH in % %XH: 100	
Stalling torque reduction factor %-K in % %-K: 100	
No. of pole pairs (half pole no. of motor) PZ PZ: 2	From data sheet value or model designation
Temperature coefficient of the stator winding TK in 1/K TK: 0.004	
Line count of the speed encoder: STR STR: 2048	From the mounted speed encoder
Type of encoder SYS: 1	Incremental rotary encoder with Z1 track
Counting direction DIRECT. DIRECT.: +	
Max. temperature of motor at temperature sensor T-MAX in [°C] T-MAX: 150	
Maximum motor current I-MAX in [A <sub>eff</sub> ] winding I-MAX: 7.5	Data sheet value $I_{max}$ I-MAX = 11 A <sub>eff</sub>
Rated power P-N in [W] P-N: 1350	Calculation from data sheet value $n_{rated}$ and $M_{rated}$ (100 K) $P-N = 2 \cdot \pi \cdot (n_{rated} / 60) \cdot M_{rated}$ $P-N = 2 \cdot \pi \cdot (3000 / 60) \cdot 4.3$ $P-N = 1351 \text{ W}$

Values in the HEIDENHAIN motor table	Values from the motor data sheet
Motor mass moment of inertia J in [kgm <sup>2</sup> ] J: 0.0006	Data sheet value J <sub>mot</sub> J = 0.00051 kgm <sup>2</sup>
Inductance of the series reactor L in [mH] L: 0	
Thermal time constant for direct current T-DC in [s] T-DC: 2400	Calculation from data sheet value T <sub>th</sub> T-DC = T <sub>th</sub> · 60 T-DC = 40 · 60 T-DC = 2400
Lower thermal cutoff frequency F-DC in [Hz] F-DC: 0	
Thermal time constant for alternating current T-AC in [s] T-AC: 2400	Calculation from data sheet value T <sub>th</sub> T-AC = T <sub>th</sub> · 60 T-AC = 40 · 60 T-AC = 2400
Upper thermal cutoff frequency F-AC in [Hz] F-AC: 0	

## 6.20.2 Field orientation

### Methods of the MANUALplus 620 for determining the field angle

For a description of field-angle orientation by the MANUALplus 620, see "Field orientation" on page 1058.

## 6.20.3 Preparation

Proceed as follows:

- ▶ Check the wiring against the grounding diagram.
- ▶ Acknowledgment of control-is-ready signal (see "Emergency stop monitoring" on page 989).
- ▶ Check the EMERGENCY STOP circuit by pressing the EMERGENCY STOP buttons and the EMERGENCY STOP limit switches.
- ▶ Determine the machine configuration using the documentation on hand. A basic configuration of the machine kinematics should exist before you start commissioning. Please refer to "Machine Kinematics (As of NC Software 548328-03)" on page 727 in this manual. The machine configuration must contain a parameter set for every axis. The machine parameters should be preassigned with initial values before commissioning.
- ▶ Create a PLC program for interfacing the control to the machine (use the PLC development software **PLCdesignNT**). A PLC basic program is available for the MANUALplus 620. Registered customers can download the current version of the PLC basic program from the "HESIS-Web Including Filebase" on the Internet (<http://hesis.heidenhain.de>). HEIDENHAIN recommends using the PLC basic program.
- ▶ Ensure that all axis drives are enabled by the PLC. Use the OLM, for example, (see "Actual status 1 of the axes (lpo Act State 1)" on page 1179) to check this before putting the machine into service.
- ▶ Before putting the machine into service, get familiar with the machine and the mechanical data of the individual axes.
- ▶ Ensure that the axes are located at noncritical positions and that they can be moved safely during adjustment.



## DC-link voltage

The MANUALplus 620 uses the DC-link voltage to calculate the maximum motor voltage.

- ▶ Define a power supply module from the **SUPPLY.SPY** table via **CfgSupplyModule** and **MP\_motSupply**. The MANUALplus 620 reads the value of the DC-link voltage from the table. See "Tables for power modules, supply modules and motors" on page 1072.
- ▶ If **CfgSupplyModule** and **MP\_motSupply** are not configured:  
Enter in **MP\_ampBusVoltage** the DC-link voltage at the power module.

### MP\_ampBusVoltage

DC-link voltage  $U_z$   
Available from NCK software version: 597 110-03.  
Format: Numerical value  
Input: DC-link voltage  $U_z$  in [V]  
Regenerative inverter: 650 [V]  
Non-regenerative inverter: 565 [V]  
Default: 650 [V]  
Access: LEVEL3  
Reaction: RESET

## Power stage model

- ▶ Define a power supply module from the **SUPPLY.SPY** table via **CfgSupplyModule** and **MP\_motSupply**. The MANUALplus 620 reads the power stage model from the table. See "Tables for power modules, supply modules and motors" on page 1072..
- ▶ If **CfgSupplyModule** and **MP\_motSupply** are not configured:  
Define with the **MP\_ampPowerSupplyType** parameter whether you are using a power supply module with or without power recovery:

### MP\_ampPowerSupplyType

Power module with or without energy recovery  
Available from NCK software version: 597 110-03.  
Format: Selection menu  
Selection: **without energy recovery**  
Power module without energy recovery  
**with energy recovery**  
Power module with energy recovery  
Default: without energy recovery  
Access: LEVEL3  
Reaction: RESET

**Preliminary  
input values**

► Enter the following temporary input values when you begin commissioning:

Machine parameters in the configuration editor and preliminary input value	Meaning
System CfgFilter defaultPosition <b>shape:</b> Triangle <b>frequency:</b> 40 <b>defaultCutterLoc:</b> Deactivated	Type of nominal position value filter Frequency of the position filter CLP filter: Deactivated (delete from configuration)
Channels ChannelSettings CH_NC CfgLaPath <b>minPathFeed:</b> 0 <b>minCornerFeed:</b> 0 <b>maxPathJerk:</b> 5 <b>maxG1Feed:</b> 99,999 <b>pathTolerance:</b> 0.01 <b>maxPathYank:</b> 1000000	Minimum feed rate on the path Minimum feed rate at corners Maximum jerk on the path Max. machining feed rate Tolerance for contour transitions Maximum yank on the path




Machine parameters in the configuration editor and preliminary input value	Meaning
Axes	
ParameterSets	
[Key name of the parameter set]	Parameter set of axis
CfgAxisHardware	
<b>signCorrActualVal:</b>	off Reverse counting dir. of act. value
<b>signCorrNominalVal:</b>	off Reverse counting dir. of nom. value
CfgPosControl	
<b>kvFactor:</b>	15 $k_v$ factor
<b>servoLagMin1:</b>	20 Following error limit
<b>servoLagMax1:</b>	20 Following error limit
<b>servoLagMin2:</b>	20 Following error limit
<b>servoLagMax2:</b>	20 Following error limit
<b>feedForwardFactor:</b>	1 100 % feedforward
<b>controlOutputLimit:</b>	1000 Control variable limit for pos. ctrl.
CfgFeedLimits	
<b>maxAcceleration:</b>	0.5 Max. permissible acceleration
CfgReferencing	
<b>refType:</b>	None No reference mark evaluation
CfgControllerAuxil	
<b>driveOffLagMonitor:</b>	off Following-error monitoring
<b>checkPosStandstill:</b>	2 Standstill monitoring
CfgEncoderMonitor	
<b>checkAbsolutPos:</b>	off Monitoring of distance code
<b>checkSignalLevel:</b>	on Monitoring the encoder amplitude
<b>movementThreshold:</b>	0 Movement monitoring threshold
CfgControllerTol	
<b>posTolerance:</b>	0.01 Positioning window
CfgPositionFilter	
<b>axisPosition:</b>	deactivated Axis-specific position filter
<b>axisCutterLoc:</b>	Deactivated Axis-specific CLP filter (Delete the parameters from the configuration)

Machine parameters in the configuration editor and preliminary input value	Meaning
Axes ParameterSets [Key name of the parameter set] CfgSpeedControl <b>vCtrlPropGain:</b> 0.5 <b>vCtrlIntGain:</b> 20 <b>vCtrlIntTime:</b> 0 <b>vCtrlDiffGain:</b> 0 <b>vCtrlFiltLowPassT:</b> 0 <b>vCtrlFiltDamping[1...5]:</b> 0 <b>vCtrlFiltFreq[1...5]:</b> 0 <b>vCtrlFiltType[1...5]:</b> 0 CfgCurrentControl <b>iCtrlPropGain:</b> 0 <b>iCtrlIntGain:</b> 0 CfgControllerComp <b>compFriction0:</b> 0 <b>compFrictionT1:</b> 0 <b>compFrictionT2:</b> 0 <b>compFrictionNS:</b> 0 <b>compCurrentOffset:</b> 0 <b>compAcc:</b> 0 <b>complpcT1:</b> 0 <b>complpcT2:</b> 0 <b>complpcJerkFact:</b> 0	Parameter set of axis  Proportional factor of speed controller Integral factor of speed controller Limitation of integral factor Derivative factor of speed controller PT <sub>2</sub> element of speed controller Band-rejection for attenuation, filters 1 to 5 Band-rejection for center frequency, filters 1-5 Type of filter Proportional factor of current controller Integral factor of current controller Friction compensation, low speed Delay of friction compensation Delay of stick-slip friction compensation Friction compensation at rated speed Holding current Acceleration feedforward control IPC time constant T <sub>1</sub> IPC time constant T <sub>2</sub> Following error in the jerk phase



## 6.20.4 Commissioning of digital axes

### Overview: Commissioning



## TNCopt

Commissioning the digital control loops should be performed with the TNCopt commissioning and optimization software. Refer to the detailed information in the TNCopt User's Manual. It is available as a PDF document via the HESIS-Web Including Filebase on the Internet (<http://hesis.heidenhain.de>) and is also provided as online help with TNCopt.

## Current controller

The current controller **must** be adjusted with TNCopt. The speed and position control loops are opened when you adjust the current controller. You must therefore activate a special PLC commissioning program:

- ▶ Open the machine configuration.
- ▶ Enter the path to the PLC commissioning program in the **MP\_pwmPgm** parameter of the System/Path/CfgPlcPath configuration object.
- ▶ Save the changes to the machine configuration.
- ▶ Restart the MANUALplus 620.

It suffices to program an **EM** (end module) in the PLC commissioning program.

The drive must be enabled externally and the MANUALplus 620 needs the "ready" signal.

Adjusting the current controller:

- ▶ Do not acknowledge the **Power Interrupted** message. In the **Organization** mode of operation, use the MOD key to enter the code number **94655**. The MANUALplus 620 will start the **Current Controller and Field Angle Adjustment** special mode of operation in the background.
- ▶ Switch to the **Machine** mode of operation.
- ▶ Press the CE key, wait until the PLC program has been compiled and switch the "control voltage" on.
- ▶ A selection window will be displayed on the screen. Select a combination of axis and parameter set for the adjustment and press the **Current Control** soft key.
- ▶ Open TNCopt and connect to the MANUALplus 620.
- ▶ Load the machine parameters from the control.
- ▶ Adjust the current controller as described in the TNCopt User's Manual.
- ▶ When the adjustment has been completed, select the next axis in the selection dialog etc.
- ▶ On completion of the adjustment, transfer the current controller parameters determined by TNCopt to the MANUALplus 620.



### Note

If you use the CC 61xx or UEC 11x controller unit, always adjust all control loops (axes and spindle) **without** overshoot.



## Commissioning speed and position controllers

- ▶ Save the changes to the configuration data and restart the MANUALplus 620 by turning the main switch off/on. Do not reboot the control, because rebooting would cause the general system error 320-0010.
- ▶ Activate a PLC program that is adapted to the machine.
- ▶ Acknowledge power interruption with the CE key and switch on the drives.



### Note

It is possible that the MANUALplus 620 generates an error message regarding standstill monitoring. In this case, either change the **MP\_signCorrActualVal** or the **MP\_signCorrNominalVal** parameter.

More information and a block diagram on the subject of defining the traverse direction is provided at "Defining the traverse direction" on page 663.

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgAxisHardware	
<b>signCorrActualVal</b>	400001
<b>signCorrNominalVal</b>	400002

Commission the speed controller by following the steps described below:



## Speed controller stability measurement

- ▶ Establish a connection between TNCopt and the control.
- ▶ In TNCopt, select the "speed-controller pulse" function.
- ▶ Load the machine parameters from the control.
- ▶ Disable all filters in the speed controller.
- ▶ Enter for PropGain (proportional factor of the speed controller) the value "1" and for IntGain (integral factor of the speed controller) the value "0".  
You may need to increase the starting value for IntGain (e.g. for hanging axes).
- ▶ Click the AUTO button and then the START button to start the measurement.
- ▶ Continue as described in the TNCopt User's Manual.



### Note

If TNCopt reduces the P factor continually without finding a stable value, there might not be sufficient energy available for the speed controller's pulse output. In this case, modify the basic settings in TNCopt in such a way that a higher amplitude and a higher pulse width are achieved:

#### **Settings/General/Speed Controller/Stability Measurement:**

- Increase gain and/or
- Pulse width.

Example:

Increase the gain from 0.5 to 0.99 and the pulse width from 600  $\mu$ s to 1800  $\mu$ s.

#### **Filter optimization:**

During AUTO adjustment, a dominant resonance frequency might occur. If this is the case, you should abort the AUTO adjustment, and dampen this specific resonant frequency with a filter (band-rejection filter with 3 to 9 dB of damping).

- ▶ Repeat the AUTO adjustment and continue optimizing the filter until the AUTO adjustment has been successfully completed.
- ▶ Only repeat the filter optimization for as long as Kp clearly increases and the rise time is approx. 3 ms.
- ▶ Set as few filters as necessary.



### Note

The rise time is machine-dependent. The 3 ms indicated above are not a standard value! On some types of machine, the best results might be achieved with a rise time of 10 ms and higher.

- ▶ Transfer the determined filter parameters to the control.



## Speed controller step adjustment


- ▶ In TNCopt, select the "speed-controller step adjustment" function.
- ▶ The P factor and the filter parameters are transferred from the speed controller stability measurement performed previously.
- ▶ Set the I factor (IntGain) to a small value:  
Value 0 for horizontal axes  
Value 100 for vertical axes, e.g. Z axis
- ▶ Now check the P factor of the speed controller, which you determined previously. This factor might be too high and need to be reduced. Carry out a measurement and continue reducing the P factor until you:
  - obtain a low oscillation tendency
  - there is (almost) no overshoot
  - obtain a rise time of approx. 3 ms (incl. I factor)
  - obtain a "smooth" step response.
- ▶ Click the START button (AUTO is disabled)

Example of a P factor adjusted too high



- ▶ Reduce the P factor and disable the filters you do not need (filters for a very high P factor)
- ▶ Repeat the measurement to check the P factor.

Example of a correctly adjusted P factor of a speed controller:




When checking and correcting the P factor is complete, continue with the speed controller step adjustment:

- ▶ Click the AUTO button.
- ▶ Click the START button.
- ▶ TNCopt now performs several measurements and automatically determines the value for the I factor of the speed controller.

As an alternative, you can also determine the I factor manually:

- ▶ Disable the AUTO button.
- ▶ Increase the I factor until a step response with just a minimal overshoot results. Example:



- ▶ Transfer the determined machine parameters to the control.



The CC 61xx and UEC 11x controller units offer the possibility to use a powerful multifunction filter for the resonance frequencies. For more information on the multifunction filter, see "Filters in the speed controller and position controller when using the CC 61xx and CC 424" on page 857

**Sequence for  
traversing the  
reference marks**

Commission the speed controller by following the steps described below:


**Check the counting and traversing direction**

More information and a block diagram on the subject of defining the traverse direction is provided at "Encoder monitoring" on page 665.

Settings in the configuration editor	MP number
Channels ChannelSettings CH_NC CfgChannelAxes <b>refAxis</b> <b>refAllAxes</b>	     200303 200304
Axes ParameterSets [Key name of the parameter set] CfgAxisHardware <b>signCorrActualVal</b> <b>signCorrNominalVal</b>	     400001 400002



- Specify via the channel-dependent configuration object **CfgChannelAxes** the sequence in which the reference marks are to be traversed. In **MP\_refAllAxis**, you specify whether all axes are to be referenced in the sequence defined in **MP\_refAxis**, or whether the reference point in these axes is to be traversed by pressing the axis-direction keys.
- Use the following flow chart to check the traversing direction:



## Adjustment of feedforward parameters

The feedforward parameters are adjusted with TNCopt. Please refer to the detailed information in the TNCopt User's Manual.

### Generate NC Programs:

- ▶ Establish a connection between TNCopt and the control.
- ▶ Select the TNCopt function "Feedforward, sliding friction and holding torque (FF)"
- ▶ Select the "Create NC Programs" function on the "Extras" menu.
- ▶ TNCopt automatically creates the adjustment programs and stores them in the folder TNC:\TNCopt\ in the control.



#### Note

The Generate NC Programs function must not be used on lathes, because this function transfers milling programs to the control. The ff\_100\_[axis].nc programs required for adjusting the feedforward parameters are already contained in the ncps program folder of the lathe.

### Default settings in the configuration editor of the MANUALplus 620:

Machine parameters in the configuration editor and input value:	Meaning:
Axes ParameterSets [Key name of the parameter set] CfgFeedLimits <b>maxAcceleration:</b>	0.5 Acceleration [m/s <sup>2</sup> ]
Channels ChannelSettings CH_NC CfgLaPath <b>maxPathJerk:</b>	5 Maximum jerk on the path

- ▶ Enter the default values according to the table above and save the changes to the machine configuration.
- ▶ Switch to the **Program Run** mode of operation
- ▶ Depending on the axis you want to optimize, open the NC program **TNC:\nc\_prog\ncps\ff\_100\_[axis].nc**  
e.g. for the X axis: **ff\_100\_x.nc**
- ▶ Click the AUTO and START buttons in TNCopt.
- ▶ Press the NC START button on the machine to start the NC program.

- ▶ TNCopt now determines the feedforward parameters automatically:
  - Friction (low speed)
  - Friction (high speed)
  - Acceleration
  - Holding current for vertical axes by minimizing the integral current
- ▶ The integral current should now be almost 0:




- ▶ Transfer the determined machine parameters to the control.

## IPC / Kv factor


A prerequisite for the correct adjustment of the IPC is that the acceleration feedforward (**MP\_compAcc** parameter) has realistic values. It is therefore essential that you adjust the acceleration feedforward control with TNCopt, as described above, before adjusting the IPC and kv factor.

The IPC and the kv factor are adjusted with TNCopt. Continue as described in the TNCopt User's Manual to set the IPC and determine the kv factor.

- ▶ TNCopt automatically increases the kv factor until a sustained oscillation results:



- ▶ The values for  $I_{pcT1}$  and  $I_{pcT2}$  are automatically determined by TNCopt.
- ▶ Correctly adjusted kv factor:



#### Note

If the measurement cannot be successfully completed, the trigger threshold might be too high. In this case, change the settings in TNCopt under:

#### **Settings/Optimize/IPC=> Trigger CC**

In "Trigger threshold," enter a lower value, e.g. 5.

For more information on the IPC, see "IPC, holding torque, following error in the jerk phase" on page 869.


## Determining the acceleration

### Temporary machine parameters in the configuration editor and input value:

Axes	
ParameterSets	[Key name of the parameter set]
CfgFeedLimits	<b>maxAcceleration:</b> 0.5
CfgLaAxis	<b>axJerk:</b> 500
Channels	
CH_NC	
CfgLaPath	<b>maxPathJerk:</b> 999999
	<b>maxPathJerkHi:</b> 999999

The following machine parameters influence whether the maximum possible acceleration can be reached:


- Maximum permissible axis acceleration (**MP\_maxAcceleration**)
- Maximum jerk on the path (**MP\_maxPathJerk**)
- Maximum jerk on the path during rapid traverse (**MP\_maxPathJerkHi**)
- ▶ Clamp an object of maximum permissible weight on the machine table.
- ▶ Increase the acceleration (**MP\_maxAcceleration** parameter) step by step by a value of 0.5.
- ▶ The maximum possible acceleration is achieved at the point where the current I (nom) reaches the limitation. In the example below: 15 A motor current at an acceleration of 16 m/s<sup>2</sup>




- ▶ Limit the maximum acceleration to approx. 80% of the maximum current of the motor or power stage, e.g.:  
 $15 \text{ A} \cdot 80 \% = 12 \text{ A}$



- ▶ Reduce the acceleration and check the result with the oscilloscope until a maximum motor or power-stage current of  $I = 80\% \cdot I_{max}$  is obtained. In the example below, an acceleration of  $12 \text{ m/s}^3$  results:




**Example: Selected acceleration =  $16 \text{ m/s}^2$**



Result: The acceleration actually achieved is only  $4.5 \text{ m/s}^2$ .

Possible causes:

- Speed too low
- Traverse range too short
- ▶ Use the integrated oscilloscope to check whether the configured axis jerk (e.g. **MP\_axJerk** = 500 m/s<sup>3</sup>) is actually reached.



Result: The jerk actually achieved is only 364 m/s<sup>3</sup>.

Possible reasons

- Speed too low
- Traverse range too short

### Setting the traverse range

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgPositionLimits <b>swLimitSwitchPos</b> <b>swLimitSwitchNeg</b>	    400501 400502

To define the software limit switches, proceed as follows:

- ▶ Traverse the reference points, e.g. by pressing the **Machine reference** soft key.
- ▶ Enter **NominalValue** in the **Axis display** user parameter to display the nominal position with respect to the machine zero point.
- ▶ The position displays now show the distance to the machine zero point, without taking the tool lengths or zero point shifts into account.
- ▶ With the axis direction buttons or handwheel, move all axes in positive and negative direction until they almost reach the EMERGENCY STOP limit switch. Write down the displayed positions with the algebraic signs.
- ▶ Enter the noted values in the machine parameters **MP\_swLimitSwitchPos** or **MP\_swLimitSwitchNeg**.



- ▶ Enter **Default** in the **Axis display** user parameter to return the position displays to the display of the tool tip position with respect to the workpiece zero point.



#### Note

You can enter different traverse ranges. You must define a separate parameter set per axis and traverse range. The individual traverse ranges are activated by switching the parameter sets (e.g. by PLC).

## Activating monitoring functions

The monitoring functions of the MANUALplus 620 must be activated now.



#### Note

To ensure that the monitoring functions of the MANUALplus 620 become effective at the right moment, you must enter meaningful values.

- ▶ Activate the position monitoring (see "Position monitoring" on page 948). You define two limits in the machine parameters for the position monitoring: one for operation with following error, and one for operation with velocity feedforward control.
- ▶ Configure the movement monitoring (see "Movement monitoring" on page 953).
- ▶ Configure the standstill monitoring (see "Standstill monitoring" on page 955).



#### Note


Adjust the input values to the machine dynamics.

## 6.20.5 Commissioning of analog axes

### General information

The MANUALplus 620 features a Commissioning Wizard for analog axes.

The Wizard guides you step by step through the commissioning of any axis parameter set. Press the **ANALOG AXIS** soft key on the opening screen of the internal oscilloscope to start the Commissioning Wizard. The soft key is grayed out as a default. You must enable the commissioning aid with the code number **13852**. The parameter set to be optimized must exist in the system, and is selected from a dialog window.







Soft key	Function
	Grayed out as a default; selectable after the code number 13852 has been entered. Starts the Commissioning Wizard for analog axes.



#### Warning

Default values are automatically assigned to the axis parameters before commissioning. The control reports this in a message window. The axis is not operated with position control as long as these temporary initial parameter values are in effect. The following error that results is not eliminated. **Hanging axes require a 100 % compensation for weight. Ensure that hanging axes are adequately supported.**

You can set the following machine parameters with the aid of the Commissioning Wizard:

Soft key	Function
	Ascertain the algebraic sign of the axis ( <b>MP_signCorrActualVal</b> or <b>MP_signCorrNominalVal</b> )
	Ascertain the axis traverse direction ( <b>MP_signCorrActualVal</b> or <b>MP_signCorrNominalVal</b> )
	Ascertain the velocity at an analog voltage of 9 V ( <b>MP_maxFeedAt9V</b> )
	Ascertain the maximum acceleration of the axis ( <b>MP_maxAcceleration</b> )
	Ascertain the $k_v$ factor of the axis ( <b>MP_kvFactor</b> )
	Ascertain the acceleration feedforward of the axis ( <b>MP_accForwardFactor</b> )

Press the **CANCEL** or **LEVEL BACK** soft key to leave the commissioning tool at any point. The temporary parameter values or ascertained values are then discarded, and the previous values are restored.



#### Note

The last step of the commissioning wizard for determining acceleration feedforward cannot be performed on the MANUALplus 620 because there is no HSC filter. The commissioning wizard must therefore be canceled after determining the kv factor. As a result, all values determined through the adjustment are discarded by the control.

It is therefore necessary to write down all values determined through the adjustment, to enter them manually in the corresponding machine parameters and to save them.

## Preparation

Proceed as follows:

- ▶ Check the wiring against the grounding diagram.
- ▶ Acknowledgment of control-is-ready signal (see "Emergency stop monitoring" on page 989).
- ▶ Check the EMERGENCY STOP circuit by pressing the EMERGENCY STOP buttons and the EMERGENCY STOP limit switches.
- ▶ Determine the machine configuration using the documentation on hand. The machine configuration must contain a parameter set for every axis. The machine parameters should be preassigned with initial values before commissioning.
- ▶ Create a PLC program for interfacing the control to the machine (use the PLC development software **PLCdesignNT**). A PLC basic program is available for the control. It is already installed on the control when the control is shipped. In addition, registered customers can download the current version of the PLC basic program from the HESIS-Web Including Filebase on the Internet ([hesis.heidenhain.de](http://hesis.heidenhain.de)). HEIDENHAIN recommends using the PLC basic program.
- ▶ Ensure that all axis drives are enabled by the PLC. Use the OLM, for example, (see "Actual status 1 of the axes (lpo Act State 1)" on page 1179) to check this before putting the machine into service.
- ▶ Before putting the machine into service, get familiar with the machine and the mechanical data of the individual axes.
- ▶ Ensure that the axes are located at noncritical positions and that they can be moved safely during adjustment.

**Temporary input values**

▶ Enter the following temporary input values when you begin commissioning:

Machine parameters in the configuration editor and preliminary input value	Meaning
Channels ChannelSettings CH_NC CfgLaPath <b>maxPathJerk:</b> 1 <b>maxG1Feed:</b> 99,999 <b>pathTolerance:</b> 0.01	Maximum jerk on the path Max. machining feed rate Tolerance for contour transitions
Axes ParameterSets [Key name of the parameter set] CfgAxisHardware <b>signCorrActualVal:</b> off <b>signCorrNominalVal:</b> off CfgPosControl <b>kvFactor:</b> 0 <b>servoLagMin1:</b> 20 <b>servoLagMax1:</b> 20 <b>servoLagMin2:</b> 20 <b>servoLagMax2:</b> 20 <b>feedForwardFactor:</b> 1 <b>controlOutputLimit:</b> 1000 CfgFeedLimits <b>maxAcceleration:</b> 0.5 CfgControllerAuxil <b>driveOffLagMonitor:</b> off <b>checkPosStandstill:</b> 2 CfgEncoderMonitor <b>checkAbsolutPos:</b> off <b>checkSignalLevel:</b> on <b>movementThreshold:</b> 0 CfgControllerTol <b>posTolerance:</b> 0.01 CfgPositionFilter defaultPosition <b>shape:</b> Triangle <b>frequency:</b> 40 <b>defaultCutterLoc:</b> Deactivated <b>manualFilterOrder:</b> 11	Parameter set of axis Reverse counting dir. of act. value Reverse counting dir. of nom. value $k_v$ factor Following error limit Following error limit Following error limit Following error limit Following error limit 100 % feedforward Control variable limit for pos. ctrl. Max. permissible acceleration Following-error monitoring Standstill monitoring Monitoring of distance code Monitoring the encoder amplitude Movement monitoring threshold Positioning window Shape of the position filter Cutoff frequency of the filter CLP filter: Deactivated



## Adjusting the servo amplifier

Please note:



### Note

Adjust the servo amplifier before optimizing the position controller. For instructions on adjustment, refer to the information given by the manufacturer of your servo amplifier.

- ▶ Adjust the offset according to the information given by the drive manufacturer.
- ▶ Adjust the proportional (P) component and the integral-action (I) component of the speed controller at the servo amplifier.
- ▶ Check the polarity of the tachometer signal of the drive by using a battery box, for example.

HEIDENHAIN recommends:

Use a voltage of 9 V for rapid traverse to ensure optimum utilization of the voltage range of +/- 10 V and to attain optimum control loop performance for the axis. The axis velocity to be expected (in [mm/min]) is defined in machine parameter **MP\_maxFeedAt9V**. Enter the rapid traverse rate in the machine parameter.



### Note

A servo amplifier that has been adjusted according to the information given by the manufacturer is the basic prerequisite for putting the machine into service.

## Commissioning the analog axes

### General information

Analog axis feedback control is based on the following formula:

$$U_{out} = (P_{err} \cdot kvFactor + \frac{V_{nom}}{60} \cdot feedForwardFactor + 1000 \cdot A_{nom} \cdot accForwardFactor) \cdot \frac{9V \cdot 60}{maxFeedAt9V}$$

Value, parameter	Unit	Description
$U_{out}$	Volt	Output voltage (analog nominal speed value)
$P_{err}$	mm	Following error (servo lag)
kvFactor	1/s	Kv factor (proportional component of position controller)
$V_{nom}$	mm/min	Nominal velocity
feedForwardFactor		Factor for velocity feedforward control
$A_{nom}$	$m/s^2$	Nominal acceleration
accForwardFactor	(s)	Factor for acceleration feedforward control
maxFeedAt9V	mm/min	Assumed velocity of the axis at 9 V

The temporary input values result in the following reduced formula for the output voltage:

$$U_{out} = (P_{err} \cdot 0 + V_{nom} \cdot 1 + A_{nom} \cdot 0) \cdot \frac{9V}{maxFeedAt9V}$$

Therefore:

$$U_{out} = V_{nom} \cdot \frac{9V}{maxFeedAt9V}$$



#### Note

Due to the temporary input values the axis is only in a speed control loop, but not in a position control loop, during operation. The resulting following error is not eliminated. For this reason, higher values were defined with the temporary input values in the **MP\_servoLagMin1**, **MP\_servoLagMin2**, **MP\_servoLagMax1** and **MP\_servoLagMax2** parameters.



#### Danger

Due to the temporary machine parameters, the position control loop is open at the beginning of commissioning!

**Hanging axes need 100 % weight compensation.**

Ensure that hanging axes are adequately supported.





## 1. Checking the counting direction

Settings in the configuration editor:	
Axes	
ParameterSets	
[Key for parameter set]	
CfgAxisHardware	
<b>signCorrActualVal</b>	
<b>signCorrNominalVal</b>	

To check the counting direction of the position measuring system, proceed as follows:

- ▶ Switch on the machine.
- ▶ Select the following operating mode without crossing over the reference marks:  
**Manual Operation**
- ▶ Switch to the **Oscilloscope** mode of operation.
- ▶ Set the following values in the oscilloscope by pressing the **SELECTION** soft key:
  - Display mode: YT**
  - Sampling time: IPO clock**
  - Channel 1: Analog**
  - Channel 2: v nom**
  - Channel 3: v act**
  - Trigger: Free run**
- ▶ Press the **OSCI** soft key to switch to the curve representation.
- ▶ Press the **START** soft key to start recording.
- ▶ Press the axis-direction key of each axis to be checked.
- ▶ Press the **STOP** soft key to stop recording.





- ▶ If  $v_{nom}$  and  $v_{act}$  do not lie in the same direction on the oscilloscope, you must change either **MP\_signCorrActualVal** or **MP\_signCorrNominalVal**.

### Reversal of traverse direction

If the axis does not move in the expected direction after you have pressed the respective axis-direction key (e.g. X axis moves in negative direction although you have pressed the X+ key), you can reverse the traversing direction.

- ▶ Invert the two values entered in the parameters **MP\_signCorrActualVal** and **MP\_signCorrNominalVal**.

## 2. Speed adjustment

Settings in the configuration editor:	
Axes	
ParameterSets	
[Key for parameter set]	
CfgAxisAnalog	
<b>maxFeedAt9V</b>	

The aim of speed adjustment is to achieve that the output nominal speed value is equal to the really measured actual speed value ( $V_{nom} = V_{act}$ ).

Determine whether the nominal speed value ( $V_{nom}$ ) differs from the actual value ( $V_{act}$ ) on the machine. Proceed as follows:

- ▶ Switch on the machine.
- ▶ Select the following operating mode without crossing over the reference marks:  
**Manual Operation**
- ▶ Switch to the **Oscilloscope** mode of operation (code number **688379**).
- ▶ Set the following values in the oscilloscope by pressing the **SELECTION** soft key:


**Display mode: YT**  
**Sampling time: IPO clock**  
**Channel 1: Analog**  
**Channel 2: V nom**  
**Channel 3: V act**  
**Trigger: Free run**




### Note

In the internal oscilloscope, the **analog** signal corresponds to the output voltage  $U_{out}$  (= analog speed command signal) at connector X8.

- ▶ Press the **OSCI** soft key to switch to the curve representation.
- ▶ Press the **START** soft key to start recording.
- ▶ Press the axis-direction key of each axis to be checked.
- ▶ Press the **STOP** soft key to stop recording.
- ▶ Compare the values measured for  $V_{nom}$  and  $V_{act}$  with each other.
- ▶ Ideally, your oscilloscope measurement should look similar to this:



However, it may occur that the nominal value differs from the actual value:



In this case, you should at first try to eliminate the difference by using the possible settings of the servo amplifier (please note the information given by the manufacturer). If this fails, refer to the information given below on how to adjust the value in **MP\_maxFeedAt9V**.

Due to the temporary input values, the following formula applies to the nominal output voltage at connection X8:

$$U_{out} = V_{nom} \cdot \frac{9V}{\mathbf{maxFeedAt9V}}$$

Therefore, **MP\_maxFeedAt9V** is determined as follows:

$$\mathbf{maxFeedAt9V} = V_{act} \cdot \frac{9V}{U_{out}}$$

Perform a measurement with the internal oscilloscope to determine the current difference between **MP\_maxFeedAt9V** and the connected drive. Use the parameter formula described above to determine the correct value.

Proceed as follows:

- ▶ Switch to the **Oscilloscope** mode of operation.
- ▶ Set the following values in the oscilloscope by pressing the **SELECTION** soft key:
  - Display mode: YT**
  - Sampling time: IP0 clock**
  - Channel 1: Analog**
  - Channel 2: v nom**
  - Channel 3: v act**
  - Trigger: Free run**
- ▶ Press the **OSCI** soft key to switch to the curve representation.
- ▶ Press the **START** soft key to start recording.
- ▶ Press the axis-direction key of each axis to be checked.
- ▶ Press the **STOP** soft key to stop recording.
- ▶ Select the values **v nom** and **Analog** by using the arrow keys and write down the measured values, which are displayed at the left side of the oscilloscope (**Cu1:**).
- ▶ Enter the two values in the formula for determining the parameter **MP\_maxFeedAt9V**.

**Example:**

The internal oscilloscope measured the following values on the machine:

- **Analog** = 1.21 V
- **v act** = 1517 mm/min
- **v nom** = 1008 mm/min

This measurement makes clear that the actual speed value **v act** differs from the nominal speed value **nom**. The difference can be eliminated by using the formula mentioned above:

$$\mathbf{maxFeedAt9V} = 1517 \frac{mm}{min} \cdot \frac{9V}{1.21V} = 11283 \frac{mm}{min}$$

- ▶ Enter the calculated value in the parameter **MP\_maxFeedAt9V** and check the calculated value by performing a measurement with the internal oscilloscope.



### 3. Determining the acceleration

- ▶ Clamp an object of maximum permissible weight on the machine table.



#### Note

Write down the current input values set in **CfgPositionFilter**. You will need to enter these values again after the acceleration has been optimized.

- ▶ Now enter the temporary machine parameters listed in the table.

Goal of the temporary input values: A jump in the nominal value is output to the axis.

Machine parameters in the configuration editor	Temporary input value	Meaning
Axes ParameterSets [Key for parameter set] CfgPosControl <b>kvFactor</b> CfgFeedLimits <b>maxAcceleration</b> CfgPositionFilter <b>filter2Shape</b> <b>manualFilterOrder</b>	   0  999999  Off 1	   $k_v$ factor  Maximum acceleration  Shape of 2nd nom. pos. value filter Order of mean-value filter in manual mode



#### Warning

Ensure that the transmitted nominal-value step does not cause any damage to the machine mechanics. It may be necessary to determine the acceleration by careful approximation.


- ▶ Switch to the **Oscilloscope** mode of operation.
- ▶ Set the following values in the oscilloscope by pressing the **SELECTION** soft key:
  - Display mode: YT**
  - Sampling time: IPO clock**
  - Channel 1: Analog**
  - Channel 2: v nom**
  - Channel 3: v act**
  - Trigger: Free run**
- ▶ Press the **OSCI** soft key.
- ▶ Press the **START** soft key to start recording.
- ▶ Press the rapid traverse key together with the axis-direction key to output the maximum possible feed rate.
- ▶ Press the **STOP** soft key to stop recording.



- From the step response of the actual velocity (**v act**) you determine the maximum possible acceleration (incl. 10 % safety margin).

$$a = \frac{V_{nom}}{t_{an} \cdot 66\,000}$$

Value, parameter	Unit	Description
a	m/s <sup>2</sup>	Acceleration
<b>Vnom</b>	mm/min	Nominal velocity
t <sub>on</sub>	s	Rise time



### Example:

The internal oscilloscope measured the following rise-time value on the machine:

$$t_{an} = 0.125 \text{ s}$$

The nominal speed **v nom** (can be read from the oscilloscope) is a machine specific parameter, and was determined to be 5000 mm/min in this example.

Calculation of acceleration:

$$a = \frac{5000 \frac{mm}{min}}{0.125 \text{ s} \cdot 66\,000} = 0.61 \frac{m}{s^2}$$

- ▶ Enter the calculated value in the parameter **MP\_maxAcceleration** and check the calculated value by performing a measurement with the internal oscilloscope.



#### Warning

Every transmitted nominal value step causes high stress to the machine mechanics. Now reset the temporary input values in **CfgPositionFilter** to the initial values before continuing commissioning.

## 4. Determining the $k_v$ factor

Machine parameters in the configuration editor	Temporary starting value	Meaning
Axes ParameterSets [Key for parameter set] CfgPosControl <b>kvFactor</b>	15	$k_v$ factor



#### Note

If the starting value entered causes the control loop to oscillate, the value must be reduced.

- ▶ Enter the following test program:

```

BEARBEITUNG [MACHINING]
N 1 G94 F2000
N 2 G1 X100
N 3 G1 X0
N 4 M99
END
  
```


The test program should be structured so that the axis reaches the nominal velocity.

- ▶ Run the program at high speed (feed-rate override = 100 %).
- ▶ With the integrated oscilloscope, record the nominal feed rate (**v nom**), the actual feed rate (**v act**), and if desired, the servo lag (**s diff**) as well.
- ▶ Perform the first measurement with the temporary  $k_v$  factor (15).
- ▶ Increase the  $k_v$  factor until the oscillation limit is reached.
- ▶ Calculate the starting value of the **MP\_kvFactor** with the following formula:  


$$\mathbf{MP\_kvFactor} = \langle \text{determined value of the oscillation limit} \rangle \cdot 0.5$$







kv factor too high, axis oscillates



Axis has reached the oscillation limit



## 5. Determining the jerk

The following machine parameter will be optimized now:

Settings in the configuration editor:	
NCchannel ChannelSettings CH_NC CfgLaPath <b>maxPathJerk</b>	

- ▶ Run the test program described previously in "Determining the  $k_v$  factor."



### Note



Depending on the position of the axis slide on the ball screw, the axis can have different mechanical properties. Therefore you should repeatedly perform the following measurement several times in a row at different positions within the traverse range.

- ▶ Run the program at high speed (feed-rate override = 100 %).
- ▶ With the integrated oscilloscope, record the actual feed rate (**v act**) and if desired, the servo lag (**s diff**) as well.
- ▶ Increase the parameter **MP\_maxPathJerk** until the overshoot disappears.



### Note

The **MP\_maxPathJerk** parameter is globally effective for all axes. Therefore, sequentially determine the jerk for each axis individually. In the parameter you then enter the jerk of the interpolating axis with the smallest determined jerk value. The specific jerk values determined for each axis are then entered in **MP\_axJerk**.




## 6. Determining acceleration feedforward control



Goal: The following error (servo lag) is to be set as small as possible during the acceleration phase.

Machine parameters in the configuration editor	Temporary starting value	Meaning
Axes ParameterSets [Key for parameter set] CfgAxisAnalog <b>accForwardFactor</b>	0.005	$k_v$ factor

This parameter is determined via step-by-step approximation to the ideal value:

- ▶ Carefully increase the temporary starting value to determine the optimum setting for **MP\_accForwardFactor**. Use the value 0.001 as a starting value in the next step.
- ▶ Determine the value just before an **undershoot** forms with the measured following error (**P err**).





## 7. Setting the traverse range

Settings in the configuration editor:	
Axes ParameterSets [Key for parameter set] CfgPositionLimits <b>swLimitSwitchPos</b> <b>swLimitSwitchNeg</b>	

To define the software limit switches, proceed as follows:

- ▶ Traverse the reference points
- ▶ Select **NominalValue** for the **Axis display** user parameter to display the nominal position with respect to the machine zero point.
- ▶ The position displays now show the distance to the machine zero point, without taking the tool lengths or zero point shifts into account.
- ▶ With the axis direction buttons or handwheel, move all axes in positive and negative direction until they almost reach the EMERGENCY STOP limit switch. Write down the displayed positions with the algebraic signs.
- ▶ Enter the noted values in the machine parameters **MP\_swLimitSwitchPos** or **MP\_swLimitSwitchNeg**.
- ▶ Enter **Default** in the **Axis display** user parameter to return the position displays to the display of the tool tip position with respect to the workpiece zero point.



### Note

You can enter different traverse ranges. You must define a separate parameter set per axis and traverse range. The individual traverse ranges are activated by switching the parameter sets (e.g. by PLC).

## 8. Activating monitoring functions

The monitoring functions of the control must be activated now.



### Note

To ensure that the monitoring functions of the control become effective at the right moment, you must enter meaningful values.

- ▶ Activate the position monitoring (see "Position monitoring" on page 948).
- ▶ You define two limits in the machine parameters for the position monitoring: one for operation with following error, and one for operation with velocity feedforward control.
- ▶ Configure the movement monitoring (see "Movement monitoring" on page 953).
- ▶ Configure the standstill monitoring (see "Standstill monitoring" on page 955).



### Note

Adjust the input values to the machine dynamics.

## 9. Hysteresis / static friction

For configuring the reversal-peak compensation, see "Compensation of reversal spikes for analog axes" on page 906.

## 6.20.6 Configuring the nominal position value filter and look-ahead parameters



### Note

The following description of the configuration of the nominal position value filters and the look-ahead is valid as of NCK software version 597 110-05 (milestone 5).

The nominal position value filters smooth the NC path so that a higher traversing speed is possible and oscillations are dampened. This path smoothing leads to a deviation from the programmed positions. By reducing the feed rate at corners and curvatures, the MANUALplus 620 always keeps this deviation within the specified tolerance.

You can display the filter effects in the integrated oscilloscope:

**Values before filtering:** Signal **IpoDbg** with:  
**ch** = 36  
**idx** = [axis index from MP\_axisList]  
**bit** = 0

**Values after filtering:** Signal **s-nom**

### Types of filters

Four filters are available for limiting the bandwidth of the dynamics of nominal position and speed values.

- Average (mean-value) filter<sup>1</sup>
- Triangle filter (also: single filter)
- HSC filter
- Advanced HSC filter

### Default filter and axis-specific filters

As of NCK software version 597 110-05, all filters are set system-wide via the **CfgFilter** config object (default filter). If you want to activate another filter for a specific axis, you can overwrite the default configuration axis-specifically via the **CfgPositionFilter** configuration object.



### Note

For axes that are interpolated together, you should define different filters only in exceptional cases. It leads to distortions of the nominal path!

---

1. The average filter is (almost) never used in practice. You should also consider that the shape of the filter causes, for example at corners, a relatively strong jerk on the axes.





**Overview:  
Machine  
parameters**

Critical points for filtering on contour paths are corners, circles and curvature changes. To optimize the contour accuracy and surface quality at those points, the following machine parameters are essential.

The individual parameters are described in detail on the page indicated in the "Page" column. There you will also find further tips for parameter setting.

A guideline on how to set the nominal position value filters and the look-ahead parameters is provided after the table under "Selection criteria for setting the mode of operation" on page 1133.



Note

Sometimes different values apply to axis movements at rapid traverse (= programmed feed rate exceeds the value in **MP\_maxG1Feed**) than to movements when the tool is engaged. This permits higher dynamics during rapid-traverse movements.

**Parameters that apply to movements at rapid traverse are identified by the extension "Hi".**

Config object	Machine parameters	NCK number	iTNC MP number	Brief description	Page
<b>CfgLaPath</b>					
Channel-specific jerk and tolerance parameters in the Channels folder					
	<b>minPathFeed</b>	201501	–	Minimum feed rate in the segment	826
	<b>minCornerFeed</b>	201502	–	Minimum transition feed rate	827
	<b>maxG1Feed</b>	201503	MP1092	Starting with this feed rate, "Hi" values apply	828
	<b>maxPathJerk</b>	201504	MP1090	Maximum jerk on the path	829
	<b>maxPathJerkHi</b>	201505	MP1090	Maximum jerk on the path at rapid traverse	829
	<b>pathTolerance</b>	201506	MP1202	Path tolerance for contours (and transitions) after the filter	828
	<b>pathToleranceHi</b>	201507	MP1202	Path tolerance for contours (and transitions) after the filter at rapid traverse	828
	<b>maxPathYank</b>	201508	–	Maximum yank (time change of the jerk) on the path	830
	<b>reduceCornerFeed</b>	201516	MP1205	Reduction of the contouring feed rate at the beginning of a contour element	836



Config object	Machine parameters	NCK number	iTNC MP number	Brief description	Page
<b>CfgLaAxis</b>					
Axis-specific jerk and tolerance parameters in the axis parameter set					
	<b>axTransJerk</b>	401701	MP1222 to MP1250	Maximum axis jerk at segment transitions	833
	<b>axPathJerk</b>	401703	MP1085 MP1097 MP1098	Axis-specific maximum jerk in traverse direction (software option 2)	835
	<b>axPathJerkHi</b>	401704	MP1086 MP1097 MP1098	Axis-specific maximum jerk in traverse direction at rapid traverse (software option 2)	835
	<b>axFilterErrWeight</b>	401702	–	Factor for filter error	837
<b>CfgFilter</b>					
(up to NCK software version 597 110-05)					
Global (system-wide) machining parameters for configuring the nominal position value filters:					
■ <b>defaultPosition</b> subfolder for global filter settings of the linear axes					
■ <b>defaultCutterLoc</b> subfolder for global filter settings of the tilting axes (M128)					
	<b>shape</b>	100405 100406	MP1200	Shape of the global nominal position value filter	817
	<b>frequency</b>	100405 100406	MP1210 MP1211 MP1212 MP1213	Limit frequency of the filter	817
	<b>hscMode</b>	100405 100406	–	Mode (only relevant with HSC filter)	818
	<b>defaultManualOrder</b>	100407	–	Global order of the mean-value filter for the Manual Operation mode	818

Config object	Machine parameters	NCK number	iTNC MP number	Brief description	Page
<b>CfgPositionFilter</b> (up to NCK software version 597 110-05) Axis-specific machining parameters for configuring the nominal position value filters. Overwrite the global settings under System / CfgFilter.					
<ul style="list-style-type: none"> <li>■ "axisPosition" subfolder for axis-specific filter settings on linear axes.</li> <li>■ "axisCutterLoc" subfolder for axis-specific filter settings on tilting axes (M128).</li> </ul>					
	<b>shape</b>	401606 401608	MP1200	Shape of the nominal position value filter	817
	<b>frequency</b>	401606 401608	MP1210 MP1211 MP1212 MP1213	Limit frequency of the filter	817
	<b>hscMode</b>	401606 401608	–	Mode (only relevant with HSC filter)	818
	<b>manualFilterOrder</b>	401605	–	Axis-specific order of the mean-value filter for the Manual Operation mode. Overwrites the setting in MP_defaultManualOrder for the respective axis.	818
	<b>typeFilter1</b> <b>typeFilter2</b>	100401 100403	MP1200	Type of the nominal position value filter	822 822
	<b>orderFilter1</b> <b>orderFilter2</b>	100402 100404	–	Order (= run length) of second nominal position value filter	822 822
<b>CfgPositionFilter</b> (up to NCK software version 597 110-04) Axis-specific machine parameters for configuring the nominal position value filters					
	<b>filter1Shape</b>	401601	MP1200	Shape of the first nominal position value filter from CfgFilter	823
	<b>filter1LimitFreq</b>	401602	MP1212 MP1213	Limit frequency of the first filter	823
	<b>filter2Shape</b>	401603	MP1200	Shape of the second nominal position value filter from CfgFilter	823
	<b>filter2LimitFreq</b>	401604	MP1212 MP1213	Limit frequency of the second filter	823
	<b>manualFilterOrder</b>	401605	–	Axis-specific order of the mean-value filter for the Manual Operation mode.	818

## Ascertaining the initial values (standard setting)

### 1. Ascertain the machine frequency

With the nominal position value filters you limit the bandwidth of the given nominal value. To do so, you have to enter the cutoff frequency of the machine in **MP\_frequency**. The following guideline explains how to determine the machine frequency.

Prepare measurement:

- ▶ Preferably select the advanced HSC filter for the measurement:  
**MP\_shape** = AdvancedHSC
- ▶ Define a start value for the tolerance:  
**MP\_pathTolerance** = 0.02
- ▶ Define a start value for the filter cutoff frequency:  
**MP\_frequency** = 50  
If required, limit the cutoff frequency step by step (this increases the filter damping) until the oscillation is reduced.
- ▶ Carry out the adjustment with a suitable NC program. The **TNCopt** software from HEIDENHAIN features the "FF\_100\_[axis].h" NC programs for feedforward adjustment.
- ▶ With the integrated oscilloscope, record the signals **v nom**, **v act** and the following error (servo lag) **s-diff**.

Proceed as follows to ascertain the resonance frequency of the machine:

- ▶ Increase the jerk for the measurement to achieve a more intensive machine excitation.  
**MP\_axTransJerk**: Set a very high value




#### Note

Reset the parameters to the original values at the end of the measurement!

- ▶ Observe the oscillation of the following error in the constant speed range.
- ▶ Determine the amplitude duration of the oscillation and calculate the resonance frequency of the axis from it.
- ▶ Compare the frequencies of the individual axes.
- ▶ Select the lowest frequency of all linear axes for the default setting of the position filter (defaultPosition).

- ▶ Select the lowest frequency of all rotary axes for the default setting of the CLP filter (defaultCutterLoc).



## 2. Set the jerk

While the path jerk (**MP\_axPathJerk**) is determined via the following error (servo lag) at the transition from acceleration to constant feed rate, you set the transition jerk (**MP\_axTransJerk**) at the reversal point of the axis.


Step 1: Set the axis-specific path jerk (**MP\_axPathJerk**)

### Basic settings:

- Set a very high value for the maximum path jerk (so that there is no limitation):  
**CfgLaPath: MP\_maxPathJerk** and **MP\_maxPathJerkHi**  
(Hi values apply to rapid traverse in general)
- Use the advanced HSC or triangle filter:  
**MP\_shape** = AdvancedHSC or  
**MP\_shape** = Triangle
- Enter the machine frequency in **MP\_frequency**
- Deactivate feed-rate smoothing:  
**MP\_filterFeedTime** = 0 (software option 2)
- Set a very low transition jerk value for the measurement because the path jerk and transition jerk overlap:  
**MP\_axTransJerk** = 1

### Perform an adjustment:

- Use suitable NC program.  
The **TNCopt** software from HEIDENHAIN features the "FF\_100\_[axis].h" NC programs for feedforward adjustment.
- Modify **MP\_axPathJerk** until the following error **s-diff** is reduced to a few  $\mu\text{m}$  (usually about  $5\ \mu\text{m}$ ).



Step 2: Set the transition jerk (**MP\_axTransJerk**)


### Basic settings:

- Use the advanced HSC filter:  
**MP\_shape** = AdvancedHSC
- Define HSC mode (Cycle 32):  
**MP\_hscMode** = Smoothing
- Set a very low path jerk value for the measurement because the path jerk and transition jerk overlap:  
**MP\_axPathJerk** = 5
- Set a high value for the contour tolerance:  
**MP\_pathTolerance(Hi)** = 3
- Apply the other basic settings from Step 1

### Perform an adjustment:


- Observe the following error **s-diff** during the direction reversal

- Modify **MP\_axTransJerk** until the following error during the direction reversal of the axis is reduced to a few  $\mu\text{m}$ .



#### **Additional inspection of the transition from straight line to circle:**

With the integrated oscilloscope you can determine the following error when traversing a transition from a straight line to a circle. To exclude the influences of frictional moment and reversal error, you should select a transition with a  $45^\circ$  movement of the axis pair involved:



Set the following parameter values to check the transition from straight line to circle:



Note

Reset the parameters to the original values when the check is finished!

Machine parameters	Recommended values
CfgLaPath: MP_minCornerFeed	0
CfgLaPath: MP_minPathFeed	Very high
CfgLaAxis: MP_axTransJerk	Very high

- ▶ Record the following error **s-diff** and the jerk **j-nom** of the respective axes with the integrated oscilloscope.
- ▶ Turn the feed-rate potentiometer completely down.
- ▶ Start the test program and turn the feed-rate potentiometer slowly and carefully up until an acceptable following error (< few  $\mu\text{m}$ ) is attained.
- ▶ On the integrated oscilloscope, read the jerk **j-nom** at the transition from straight line to circle of the respective axis.
- ▶ Enter this jerk value in **MP\_axTransJerk**.

For the adjustment of **MP\_axTransJerk** described here it is essential to consider only the geometric influences of the path (corner, transition from straight line to circle etc.) The development of the feed rate is without effect. In the table above, **MP\_minPathFeed** is therefore set to a high value. A reduction of the feed rate due to other criteria is thus prevented; the feed rate stays constant during the measurement.



Note

HEIDENHAIN recommends:

Always record the feed rate during the measurements to check whether it remains constant.

During roughing the jerk value can increase until the machine gets loud or the following error **s-diff** becomes too large. For smooth surfaces during roughing the corner jerk should barely limit the feed rate.




Note

For more information on the **MP\_axTransJerk** and **MP\_axPathJerk** parameters, please also refer to "Axis-specific limit values" on page 831.





## Selection criteria for setting the mode of operation



The settings for the nominal position value filters and look-ahead parameters mainly depend on the emphasis of the requirements for machining the workpiece. Speed and accuracy, in connection with clean and smooth surfaces, are the decisive criteria.

At the same time, the oscillation and resonance tendencies of the machining system (the machine tool) are to be considered, and taken into account in the settings for the nominal position value filters.

### **Criterion: Clean surface**

Definition of the term "surface":

- A clean and smooth surface has the highest priority – The given nominal value is additionally smoothed by reducing the path jerk and the limit frequency.
- Application: Finishing
- Oscillations in the axes must be damped, since following errors of 1  $\mu\text{m}$  are still visible on the surface
- Tolerance (Cycle 32) typically between 0.01 and 0.02 mm (may also be exceeded in order to achieve a better surface)

### **Criterion: Speed (tolerances above 50 $\mu\text{m}$ )**

Definition of the term "speed":

- Surface quality is secondary; short machining times have the highest priority
- Application: Roughing
- Tolerances (Cycle 32) typically between 0.1 and 0.2 mm

### **Criterion: High accuracy**

Definition of the term "accuracy":

- Maintaining the tolerances has the highest priority
- Application: Very fine and small parts
- Slight oscillations can be seen on the surface
- Tolerances typically between 0.005 and 0.01 mm
- Compensation of reversal peaks must be performed beforehand

## Recommended settings

In the following recommendations it is assumed that the nominal position value filters are not configured individually for each axis, but globally in **CfgFilter**.



### Note

Configuring different filters for axes with joint interpolation is only permitted in special cases!

## Recommended settings guidelines for "surface":

### Basic settings:

- Set small path jerk values:  
**CfgLaPath: MP\_maxPathJerk**  
Optional:  
**CfgLaAxis: MP\_axPathJerk**, see "Axis-specific limit values" on page 831.  
(On milling controls: Software option 2 is required!)



### Note

The rapid-traverse values **MP\_maxPatzJerkHi** and **MP\_axPathJerkHi** are set to high values regardless of the desired criterion. They depend on the wear of the machine elements rather than on the path quality.

- Use the advanced HSC or triangle filter
- **Important for uniform machining:**  
(= feed rate as constant as possible)  
Set high transition jerk values:  
**CfgLaAxis: MP\_axTransJerk**

### Perform an adjustment:

- **Goal:**  
Minimum following error (servo lag)
- Use suitable NC program.  
The **TNCopt** software from HEIDENHAIN features the "FF\_100\_[axis].h" NC programs for feedforward adjustment.
- Evaluate the following error **s-diff** – it should largely be less than 1 µm at a constant feed rate.
- Minimize the following error **s-diff**



### Note


Relationship between cutoff frequency (**MP\_frequency**) and the effect of the filters:

**MP\_frequency** = small value:  
(recommended for "surface" criterion)

Strong damping—the contour is milled more slowly and is smoothed more

**MP\_frequency** = large value:  
Weak damping—the contour is milled faster and is smoothed less

- Perform the adjustment according to the following flow chart:



**Clean surface – Example values of a medium-sized machine:**

Machine parameters	Recommended values	Remark
axPathJerk	25	Software option 2 is required!
axPathJerkHi	150	
maxPathJerk	25	Without software option 2
maxPathJerk	40	With software option 2
maxPathJerkHi	300	
defaultPosition/shape	Triangle or AdvancedHSC	
defaultPosition/frequency	20	
pathTolerance	0.02	
pathToleranceHi	0.5	
filter2LimitFreq	20	
axTransJerk	200	
curveJerkFactor	10	

**Recommended settings guidelines for "speed":**

**Basic settings:**

- Set high jerk values in traverse direction:  
**CfgLaPath: MP\_maxPathJerk.** You can nearly set rapid-traverse values for the jerk.  
 Optional:  
**CfgLaAxis: MP\_axPathJerk**  
 (Software option 2 is required!)  
 => a bigger following error **s-diff** is possible
- The triangle filter is recommended for tolerances > 50 µm (Cycle 32):  
**MP\_shape = Triangle**
- HSC filter is recommended at tolerances < 30 µm (Cycle 32)  
**MP\_shape = HSC**



Note

With the triangle filter and slightly increased jerk values, you can often attain the same speed, but with a lower machine excitation than with HSC filters.

- Define HSC mode (Cycle 32):  
**MP\_hscMode = Roughing**
- Set a high cutoff frequency:  
**MP\_frequency = high value; recommendation: 50 Hz, if possible**
- Set higher values for the transition jerk:  
**CfgLaAxis: MP\_axTransJerk**  
 You can nearly set rapid-traverse values.



### Perform an adjustment:


■ **Goal:**

Maximum speed while maintaining the programmed contour tolerance (Cycle 32).

■ Use suitable NC program.

The **TNCopt** software from HEIDENHAIN features the "Contour-Single.h" NC program within the "contour measurement" function. The advantage is that the speed and the contour deviations can be seen directly.

■ Perform the adjustment according to the flow chart below:



**Speed – Example values of a medium-sized machine:**

Machine parameters	Recommended values	Remark
axPathJerk	75	Software option 2 is required!
maxPathJerk	75	Without software option 2
maxPathJerk	100	With software option 2
defaultPosition/shape	Triangle	
defaultPosition/frequency	50	
pathTolerance	0.05	
axTransJerk	200	
curveJerkFactor	10	

**Recommended settings guidelines for "accuracy":**

**Basic settings:**

- Use the HSC filter whenever possible (with limit frequencies greater than 30 Hz)  
MP\_shape = HSC
- Define HSC mode (Cycle 32):  
**MP\_hscMode** = Smoothing
- Use lower jerk values than in the default setting  
**CfgLaAxis: MP\_axTransJerk**  
**CfgLaPath: MP\_maxPathJerk**  
Optional:  
**CfgLaAxis: MP\_axPathJerk**  
(Software option 2 is required!)
- Use limit frequencies above 30 Hz

**Perform an adjustment:**

- **Goal:**  
The programmed contour tolerance (Cycle 32) must be maintained while the following error is kept at a minimum
- Use suitable NC program.  
The **TNCopt** software from HEIDENHAIN features the "Contour-Single.h" NC program within the "contour measurement" function. The advantage is that the speed and the contour deviations can be seen directly.



Note

Possibility of further adjustment:

Ideally, circular paths should be checked with a KGM grid encoder from HEIDENHAIN. However, in many cases the circular interpolation test with the integrated oscilloscope or TNCopt suffices.




Note

To reduce deformations of the machine elements under increased centrifugal forces (radial acceleration) the acceleration values set in **MP\_maxAcceleration** may have to be reduced to 1.5 m/s<sup>2</sup>.



- Perform the adjustment according to the flow chart below:



#### Accuracy – Example values of a medium-sized machine:

Machine parameters	Recommended values	Remark
axPathJerk	30	Software option 2 is required!
maxPathJerk	30	Without software option 2
maxPathJerk	50	With software option 2
defaultPosition/shape	HSC	
defaultPosition/frequency	38	
defaultPosition/hscMode	Smoothing	
pathTolerance	0.005	
axTransJerk	25	
curveJerkFactor	1	

## 6.20.7 Commissioning the digital spindle


**Current controller** The current controller is adjusted in the same manner as a digital axis, see "Current controller" on page 1090.

**Speed controller** To activate the jump function, enter the following machine parameters:

Settings in the configuration editor	
Axes	
ParameterSets	
[Key name of the spindle parameter set]	
CfgFeedLimits	
<b>maxAcceleration:</b>	High value
<b>maxAccSpeedCtrl:</b>	High value
CfgPositionFilter	
<b>manualFilterOrder:</b>	1

Use **MP\_manualFilterOrder** = 1 to activate the lowest filter order for the Manual Operation mode. As a result, the nominal speed value is no longer "averaged."


- ▶ Start the step output by Spindle On.
- ▶ Activate a spindle speed from the highest gear range.
- ▶ Use the integrated oscilloscope to record the nominal feed rate (**v nom**), the actual feed rate (**v act**), and the actual current value **I (nom)**.
- ▶ Output a step with the Spindle On function (M03/M04).
- ▶ Choose the height of the step function for a very low speed so as not to overload the speed controller, i.e. so that **I (nom)** is not limited.
- ▶ Increase the P factor of the speed controller (**MP\_vCtrlPropGain**) until the system oscillates or no change is visible. To change machine parameters, press the END key in the oscilloscope and then the CONFIG EDIT soft key.



- ▶ Calculate the input value for **MP\_vCtrlPropGain**:  
**MP\_vCtrlPropGain = MP\_vCtrlPropGain · 0.6**





- Increase the I factor (**MP\_vCtrlIntGain**) until the nominal value is reached and there is no overshoot.



- Output the step with maximum shaft speed. **I (nom)** is within the limitation during acceleration. **I (nom)** must not oscillate after reaching the maximum speed. If **I (nom)** oscillates:

Reduce **MP\_vCtrlPropGain** and **MP\_vCtrlIntGain** evenly until the overshoots are minimized.





### Optimize the acceleration for M3/M4/M5 with the parameters **MP\_maxAcceleration**, **MP\_maxAccSpeedCtrl** and **MP\_maxDecSpeedCtrl**

The MANUALplus 620 permits you to define adapted acceleration values for the speed-controlled spindle with M3/M4/M5 and for the position-controlled spindle with M19. You can also define different values for the acceleration and braking ramp for the spindle in speed control:

Machine parameters	Effective in mode	Description
<b>MP_maxAccSpeedCtrl</b> :	M3/M4/M5	Acceleration ramp of the spindle. Also effective for the braking ramp if <b>MP_maxDecSpeedCtrl</b> is not defined.
<b>MP_maxDecSpeedCtrl</b>	M3/M4/M5	Braking ramp of the spindle.
<b>MP_maxAcceleration</b>	M19	Acceleration of spindle in position control. Also effective for the spindle in the speed control loop if <b>MP_maxAccSpeedCtrl</b> and/or <b>MP_maxDecSpeedCtrl</b> are not defined.

To adjust the acceleration of the spindle, proceed as follows:

► Optimize the acceleration individually for each gear range.


► **M3/M4:**

The spindle is in speed control with M3 and M4. Define the acceleration ramp of the spindle with **MP\_maxAccSpeedCtrl**. If the value of **MP\_maxAccSpeedCtrl** is 0, then the value entered in **MP\_maxAcceleration** is used.




Note

For motor spindles with direct drives you can usually choose an acceleration and braking ramp gradient at which the motor reaches the electrical current limit during starting and braking. Pay attention to the manufacturer's mechanical limit values for spindle drives with gear unit or belts and set ramps that are suitable for the mechanics.



► **M5:**

Braking is usually performed at the current limit. You define the braking ramp of the spindle with **MP\_maxDecSpeedCtrl**. If the value of the parameter is 0, then the value entered in **MP\_maxAccSpeedCtrl** is used. If the value of **MP\_maxAccSpeedCtrl** is also 0, the MANUALplus 620 uses the value entered in **MP\_maxAcceleration**.



### M19:

For tapping and oriented spindle stop, **I (nom)** must not be within the limit during acceleration:

- ▶ In **MP\_maxAcceleration**, enter a lower value for these operations with closed-loop position control.
- ▶ Use the **MP\_manualFilterOrder** parameter to influence the transient response of the spindle. Large values result in considerable signal rounding, small values in minor signal rounding.  
Adapt the nominal value curve to the actual value curve.

### Check the direction of rotation:

You can check the direction of rotation of the spindle when M03 is output. If the spindle does not rotate in clockwise direction:

- ▶ Change **MP\_signCorrNominalVal**

### Position controller

The position control loop of the main spindle is closed only during the spindle orientation:

- ▶ Close the position control loop of the main spindle, see "Spindle Oriented spindle stop (spindle point stop)" on page 1001.
- ▶ If the error message **Nominal speed value too high** appears, you must modify **MP\_signCorrActualVal**.
- ▶ Optimize the  $k_v$  factor (**MP\_kvFactor**) for each gear range. A TOOL CALL must be run to transfer the modified gear-specific parameters.

## 6.21 Integrated Oscilloscope

### 6.21.1 Fundamentals

The MANUALplus 620 features an integrated oscilloscope. This oscilloscope features 6 channels for recording analog signals and 16 channels for recording digital signals (see the following tables).

The recording of CC signals is limited to four signals.

#### Overview of signals

Analog signals	Meaning	CC signal
SAVED	The signal last recorded on this channel is "frozen."	–
a act	Actual axis acceleration value [m/s <sup>2</sup> ] or [°/s <sup>2</sup> ]. Calculated from position encoder.	–
a nom	Nominal axis acceleration value [m/s <sup>2</sup> ] or [°/s <sup>2</sup> ]	–
v act	Actual value of the axis feed rate [mm/min] or [°/min]. Calculated from position encoder.	–
v nom	Nominal value of the axis feed rate [mm/min] or [°/min]. Axis feed rate calculated from the difference from the nominal position values. The following error is not included.	–
Feed rate F	Contouring feed rate [mm/min] or [°/min]	–
Block no.	Block number of the NC program for triggering	–
s act	Actual position [mm] or [°]	–
s nom	Nominal position [mm] or [°]	–
s diff	Following error of the position controller [mm] or [°]	–
PosDiff	Difference between position and speed encoder [mm] or [°]	–
Position: A	Signal A of the position encoder	–
Position: B	Signal B of the position encoder	–
j act	Actual jerk value [m/s <sup>3</sup> ]. Calculated from position encoder.	–
j nom	Nominal jerk value [m/s <sup>3</sup> ]	–
v (N act)	Shaft speed actual value [mm/min]. Calculated from speed encoder (= From the number of motor revolutions). For drive motors with transmission, this value differs from <b>v act</b> . <b>(v act = v (N act) · MP_distPerMotorTurn)</b>	CC
v (N nom)	Nominal velocity value [mm/min]. Output quantity of the position controller	CC
I (N int)	Integral-action component of the nominal current value [A]; CC 422: peak value, CC 61xx/CC 424: effective value	CC
I (nom)	Nominal current value [A] that determines torque; CC 422: peak value, CC 61xx/CC 424: effective value	CC
I2-t (mot.)	Current value of the I <sup>2</sup> t monitoring of the motor [%]	CC

Analog signals	Meaning	CC signal
I2-t (pow. module)	Current value of the I <sup>2</sup> t monitoring of the power module [%]	CC
PLCPrePgm	The PLC operands (B, W, D, I, O, T, C) are recorded <b>before</b> the PLC program run. This means that the values of the operands are read at the beginning of the PLC program cycle. For types B, W and D the contents are recorded, and for the other types the logical state of the operands are recorded.	–
PLCPostPgm	The PLC operands (B, W, D, I, O, T, C) are recorded <b>after</b> the PLC program run. This means that the values of the operands are read at the end of the PLC program cycle. For types B, W and D the contents are recorded, and for the other types the logical state of the operands are recorded.	–
Analog	Analog axis/spindle: Analog voltage = nominal velocity value [mV]	–
SPLC-MC	SPLC operands of the SPLC program of the MC (reserved)	–
SPLC-CC	SPLC operands of the SPLC program of the CC (reserved)	CC
IpoDbg	Diagnostic information for internal purposes	–
CCDbg	Diagnostic information for internal purposes	CC
Contour deviat.	Circular interpolation test, contour deviation in mm	–
Off	No recording for this channel	–

Digital signals	Meaning
M	PLC marker
I	Input
O	Output
T	Timer
C	Counter
X	Reserved



#### Note

The PLC operands are addressed with numbers in the oscilloscope. You get the numerical addresses from the PLC diagnostic function **Watch List**.

### Sampling rate

The resolution of the internal oscilloscope is at most 600 µs.

This means that even for CC signals, the signal is only recorded every 600 µs. However, since the CC 61xx and CC 424 operate with control-loop cycle times < 600 µs, undersampling results at higher frequencies. This can result in misinterpretation of the oscilloscope image.


For the CC 61xx and CC 424, the internal oscilloscope displays effective values, as opposed to the peak values of the CC 422.

## 6.21.2 Preparing a recording

### Starting the oscilloscope



- ▶ Switch to the Organization mode of operation.
- ▶ Press the soft key
- ▶ Enter the code number **688379** for the control to activate the setup menu.




### Setup for analog signals



Call the "Selection" dialog box:

- ▶ Press the **SELECT** soft key.

In the dialog box, set:



▶ **Type of display:** Set the time interval for recording the signals.

- YT: Chronological depiction of the channels
- YX: Graph of two channels
- Circle: Circular interpolation test, see page 1158

▶ **Sampling time:** Set the time interval for recording the signals.

- CC clock: Time interval = 0.6 ms
- IPO clock: Time interval = IPO clock  
(from MP\_System/CfgCycleTimes/ipoCycle)
- PLC clock: Time interval = PLC clock  
(results from MP\_System/CfgCycleTimes/plcCount \* Ipo clock)

3000 grid points (events) are stored. The time grid determines the duration of recording.

Examples:

- $0.6 \text{ ms} \cdot 3000 = 1.8 \text{ s}$
- $3 \text{ ms} \cdot 3000 = 9 \text{ s}$
- $21 \text{ ms} \cdot 3000 = 63 \text{ s}$

### **Channel 1 to channel 6**

Specify the signals to be recorded:

- ▶ Assign the channels of the analog signals to be recorded to the respective axes.
- ▶ Specify the operand type (B,W,D,I,O,T,C) and the address for the recording of PLC operands.
- ▶ Use the **SAVED** setting to "freeze" the signal last recorded for this channel. This means that the recorded values remain available on the display. For example, you can use them to record a reference curve for use in future measurements.





### Trigger conditions:

Specify the trigger conditions in the following input fields:

- ▶ **Trigger:** Set the trigger condition.
  - **Single shot:** After pressing the soft key, the next 3000 events are stored.
  - **Free run:** The recording is started and ended by soft key. If you press the STOP soft key, the last 3000 events (at most) are stored.
  - **Channels 1 to 6:** Recording begins when the trigger condition of the selected channel is fulfilled.
  - **Channel 1 + L to channel 6 + L:** Recording begins when the trigger condition of the channel selected here as well as the trigger conditions of the digital signals (trigger condition "logic") are fulfilled. The trigger conditions are AND-gated.
  - **Logic:** Recording begins when the trigger condition of the digital signals is fulfilled (trigger condition "logic").
- ▶ **Edge:** Set when triggering is to occur:
  - +: Trigger at rising edge
  - -: Trigger at falling edge
- ▶ **Trigger threshold:** Enter the trigger threshold (you will find the appropriate units in the signals table on 1145).
- ▶ **Pre-Trigger:** Select a value from the selection box.  
Recording begins at a time preceding the trigger time point by the value entered here

The **Output** and **Feed rate F** fields are reserved.

## Setup for digital signals



Call the "M, I, O, T, C selection" dialog box:

- ▶ Press the **SELECT MIOTC** soft key.

Unname	Operand	Trigger	Select
1	M 4711 9999	0	X
2	M 4712 9999	1	X
3	I 345 999	*	X
4	O 57 999	*	X
5	T 27 999	*	X
6	C 120 143	*	X
7		*	
8		*	
9		*	
10		*	
11		*	
12		*	
13		*	
14		*	
15		*	
16		*	

Set:

- ▶ **Operand:** Type and number of the PLC operand's symbolic name
  - M: Marker
  - I: Input
  - O: Output
  - T: Timer
  - C: Counter
  - X: Diagnostic information for internal purposes
  - s: Symbolic API operand  
After selection, the symbolic API operand can be selected over the SYMBOL LIST soft key.
- ▶ **Trigger:**
  - X: No trigger
  - 0: Trigger at 0-level
  - 1: Trigger at 1-level

The trigger is only taken into consideration if **Selection=X** is set.

- ▶ **Selection:**
  - X: Signal is displayed and considered as trigger
  - Empty field: Signal is not displayed and not considered as trigger



### Note

- You define the general trigger conditions ("Trigger" input field) and the pre-trigger in the setup for analog signals.
- The trigger condition "logic" is fulfilled when all triggers set in "M I O T C selection" are fulfilled (AND-gating).




### 6.21.3 Recording signals



Change to the Recording operating mode:

- ▶ Press the **OSCI** soft key.



For every channel, the type and resolution of the analog signal are shown in the left status field. The operand type and address are listed for digital signals.

### Starting and stopping the recording



To start recording:

- ▶ Press the **START** soft key.



To stop recording:

- ▶ Press the **STOP** soft key.



To stop the display:

- ▶ Press the **DISPLAY STOP** soft key.

## Starting signal recording before the first PLC scan

To start the signal recording in the oscilloscope before the first PLC scan, proceed as follows:

- ▶ Start the control.
- ▶ Do **not** acknowledge the Power interrupted message with the CE key; instead, enter the code number 807667 to switch to the PLC programming mode of operation.
- ▶ Press the **COMPILE** soft key.
- ▶ Press the **SELECT + COMPILE PLC PGM** soft key and press the **SELECT** soft key to compile the **MAIN\_PGM.SRC** PLC main program manually. The "PLC program could not be started" error message can be ignored.
- ▶ Select the desired data in the oscilloscope and press the **START** soft key to start recording.
- ▶ Acknowledge the power interruption with the CE key.



**Trigger conditions:** Trigger and pre-trigger conditions:

- Trigger=Single shot: 3000 events beginning from the start are recorded.
- Trigger=Free run: At most the last 3000 events before the STOP soft key is pressed are recorded.
- Trigger condition defined: The time when recording ends depends on the setting of the pre-trigger.
  - Pre-trigger=0 %: 3000 events beginning from the fulfilled trigger condition are recorded.
  - Pre-trigger=25 % (or 50 %, or 75 %): 75 % (or 50 % or 25 %) of the 3000 events beginning from the fulfilled trigger condition are recorded.
  - Pre-trigger=100 %: Recording is stopped. The last 3000 events before the fulfilled trigger condition are recorded.



Note

If the trigger condition is fulfilled **before** the corresponding number of events have been stored when the pre-trigger is set to 25 %, 50 %, 75 % or 100 %, then correspondingly fewer events are recorded.

During recording, the selected signals are continuously displayed. You can freeze the display of the signals with the DISPLAY STOP soft key. This does not affect the recording of the signals.

The recorded data remain stored until you start recording again or activate another graphic function.

A fulfilled trigger condition is indicated with a "T" in the status field at right below the display area.


Hide/show **gridlines**:



▶ Press the **GRID** soft key.



## 6.21.4 Analyzing the recording




### Recording completed

After recording has been completed, the oscilloscope shows the memory contents. The information in the status field below the display area refers to the displayed events. It has the following meanings (see figure below):

- Left number: Time the "leftmost" event was recorded
- Right number: Time the "rightmost" event was recorded
- The bar symbolizes the displayed range relative to the memory content.

The fulfillment of the trigger condition is designated as "t0" (t=0). Events that were recorded before the trigger condition was fulfilled are given a negative time. If no trigger condition was defined, the beginning of the recording is designated as "t0."



## Changing the display

The following soft keys influence the entire display range (all signals):



▶ Shift the display range to the left.



▶ Shift the display range to the right.



▶ Decrease horizontal resolution.



▶ Increase horizontal resolution.

## Increment

The increment used when shifting the display or shifting the cursor is shown in the status field at bottom left, with the code "sk: ....." (see the "cursor information" illustration).



▶ The **Page Up** key increases the increment, and the **Page Down** key decreases it.

## Analyzing an individual analog signal



▶ Use the **arrow up** and **arrow down** keys to select the channel to be analyzed.

The selected channel is indicated with an asterisk (\*). At the same time, the cursor is activated and placed on the selected channel.

Shown in the status field (bottom left) are (see "cursor information" figure):

- Code "t1: .....": Cursor position in [s], referenced to t0
- Code "Cu1: .....": Signal size at the cursor position

### Shifting the cursor:



▶ Shift the cursor with the **right arrow** and **left arrow** keys.

## Influencing the signal display

Soft keys that influence the signal display:



- ▶ Shift the signal downward.



- ▶ Shift the signal upward.



- ▶ Decrease the vertical resolution.



- ▶ Increase the vertical resolution.



- ▶ Optimum vertical resolution; The signal is centered on the zero line and always remains in the display area.



- ▶ Undo vertical shifts.



- ▶ Invert the signal (multiply by  $-1$ ).

## Second cursor



- ▶ Activate/deactivate second cursor.

The information for the second cursor is **relative to the first cursor**. It is shown in the status field (see "Cursor information" figure):

- Code "t2: .....": Cursor position in [s], referenced to the first cursor
- Code "Cu2: .....": Signal referenced to the first cursor position

Cursor information:

```
t1: 1.660
Cu1: 266.0000
t2: 0.970
Cu2: 97.0000
sk: 0.050
```



## 6.21.5 Saving and loading recordings

You can save the recorded signals and all settings in one file. The file must have the extension SCO (oscilloscope trace file).

You can load and evaluate saved SCO files in the oscilloscope. HEIDENHAIN also makes the PC program **TNCscopeNT** available for evaluating SCO files.

Saving and loading oscilloscope recordings:



Switch to the Saving and Loading mode:

- ▶ Press the soft key

To save the oscilloscope trace file:



- ▶ Press the **SAVE** soft key.
- ▶ Enter the path in the "Save As" dialog box.
- ▶ Press the **OK** soft key or button.



To load the oscilloscope trace file:



- ▶ Press the **LOAD** soft key.
- ▶ Enter the path in the "Open" dialog box.
- ▶ Press the **OK** soft key or button.



## 6.21.6 Circular interpolation test with the integrated oscilloscope

A circular interpolation test can now be conducted with the integral oscilloscope.

- ▶ Start the oscilloscope and press the SELECTION soft key
- ▶ Under **display mode**, select the setting **Circle**
- ▶ At the desired channels, select as the signal type the setting **Contour deviat.**
- ▶ Start recording. Press the soft keys OSCI and then START.
- ▶ Start an NC program in which a circle is programmed. The circle center point must be at the origin of both axes.
- ▶ For lathe controls, the programs cir\_xz\_r10\_f2000\_f.nc and cir\_xz\_r10\_f2000\_r.nc prepared for the circular interpolation test are contained in the folder NCPS.  
The starting points are X0 and Z0.

### Example of a circular interpolation test with the integrated oscilloscope:


Actual position:

X +30

Y +0

NC program (example of milling control):

```
0 BEGIN PGM Circular interpolation test MM
1 CC X+0 Y+0
2 CP IPA+360 DR+ F1000
3 M30
4 END PGM Circular interpolation test MM
```



## 6.21.7 Configuring the colors of the oscilloscope display

Settings in the configuration editor	MP number
System	
DisplaySettings	
CfgOsciColor	
<b>background</b>	101401
<b>channel1</b>	101402
<b>channel2</b>	101403
<b>channel3</b>	101404
<b>channel4</b>	101405
<b>channel5</b>	101406
<b>channel6</b>	101407
<b>logicTrace</b>	101408
<b>select</b>	101409
<b>grid</b>	101410
<b>cursorText</b>	101411

► In the parameter object CfgOsciColor, define the colors for the oscilloscope.

### MP\_background

Background color

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **black**  
**blue**  
**light\_gray**  
**red**  
**dark\_gray**  
**light\_green**  
**really\_light\_gray**  
**really\_dark\_gray**  
**light\_violet**  
**light\_blue**  
**light\_red**  
**medium\_gray**  
**yellow**  
**white**

Default: black

Access: LEVEL3

Reaction: NOTHING

The colors defined in MP\_channels 1 to 6 are used for display of the status information of this channel and the path of the curve. As soon as a channel is selected, the color defined in **MP\_select** is switched to.

### **MP\_channel1**

Color for channel 1  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See MP\_background  
Default: light\_green  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_channel2**

Color for channel 2  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See MP\_background  
Default: light\_violet  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_channel3**

Color for channel 3  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See MP\_background  
Default: light\_blue  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_channel4**

Color for channel 4  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See MP\_background  
Default: light\_red  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_channel5**

Color for channel 5  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See MP\_background  
Default: light\_blue  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_channel6**

Color for channel 6  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See MP\_background  
Default: light\_red  
Access: LEVEL3  
Reaction: NOTHING



The color defined in **MP\_logicTrace** is used for the display of the digital signals.

### **MP\_logicTrace**

Color for logic-trace channels  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See MP\_background  
Default: yellow  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_select**

Color for selected channel  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See MP\_background  
Default: white  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_grid**

Color for gridlines  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See MP\_background  
Default: light\_gray  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_cursorText**

Color for gridlines  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See MP\_background  
Default: dark\_gray  
Access: LEVEL3  
Reaction: NOTHING

## 6.22 Diagnosis with the Online Monitor (OLM)


### 6.22.1 Introduction

The Online Monitor (OLM) assists you in commissioning and provides diagnostic functions to check control components:

- Display of IPO internal variables for axes and channels
- Display of CC internal variables (if a CC is present)
- Display of hardware signal states
- Various trace functions
- Activation of spindle commands
- Enabling IPO internal debug outputs


The OLM is included in the control software.

#### Software structure



## 6.22.2 Using the OLM

### Overview of the menus



## END and NEXT soft keys

The NEXT soft key indicates that additional soft keys are available for this menu level. The END soft key switches one level back.



▶ Press the **NEXT** soft key. The OLM switches to the next soft-key row of this level.



▶ Press the **END** soft key. The OLM switches one level back. If you press the END soft key on the main level, the OLM is exited.

## Keyboard and display

The OLM is operated using the soft keys of the control keyboard. The control screen is used for display.

The OLM distinguishes the following software and function areas:

- IPO
- Simulation IPO (SimIPO)
- PLC
- Trace

The software area or function area is selected by soft key on the "main level."

For hardware reasons, only a subgroup of the IPO functions is available for the SimIpo. The available SimIpo functions work in the same way as the IPO functions.

## Starting and exiting the OLM

### To start the OLM:



- ▶ Press the soft key
- ▶ Enter the code number 654321 for the control to activate the main menu.

### To exit the OLM:

- ▶ Change to the main level of the OLM.



- ▶ Press the **END** soft key.



## 6.2.2.3 Screen layout

### Display of variables

Example of screen layout when variables are displayed:

Axis-Key	X1	Z1	Axis-Key	X1	Z1
axisState1	0x300010de	0x300210de	targetPos	0.000	0.000
axisState2	0x02000114	0x02000114	totalDistance	0.000	0.000
driveCmdFord	0x00000000	0x00000000	motorTemperature	+0	+0
relNomPos	0.000	0.000	utilization	+0	+0
absNomPos	10.000000	0.000000	rpmOffset	-10.000000	-0.000000
absActPos	10.000000	0.000000	spindleTurns	0.000	0.000
absNomFeed	0.000	0.000	modCounter	+0	+0
absActFeed	0.000	0.000	modCounterAct	+0	+0
absNomAcc	0.000	0.000	absNomPosOffset1	10.000000	0.000000
absActAcc	0.000	0.000	absNomPosOffset2	10.000000	0.000000
actParSet	0	0	absNomPosBase	10.000000	0.000000
ipoCtrlWord	0x00000011	0x00000011	lastIpoPos	0.000000	0.000000
compensPos	0.000	0.000	syncPosDiff	0.000000	0.000000
masterId	+0	+0	absTouchPos	0.000000	0.000000
lag	0.000000	0.000000	virtStartPos	0.000000	0.000000
lagPeak	0.000000	0.000000	requestedPos	0.000000	0.000000

Connected    IPO    IpoCounter    4764    Ax/Chn-Number    +0 - +1

Use Cursor Up/Down (with or without Ctrl or Alt) to change Ax/Channel-Number

Plc Nom Data    Ipo Act Data    Plc Ipo Data    Spindle    Offset Data    CC Data    END    NEXT

The OLM lists the variable designations, status designations, etc. in the **dark-highlighted boxes** of the "main window."

The **white-highlighted boxes** contain the variable values. The OLM displays the values of two axes or channels.

The axis designation or channel designation defined in the parameters is shown in the **column heading**.

- Parameter for axis designation:  
MP\_System/CfgAxes/axisList(axisId)
- Parameter for channel designation for IPO:  
MP\_ChannelGroup/CfgChannelGroup/Machining/ChannelList
- Parameter for channel designation for SimIpo:  
MP\_ChannelGroup/CfgChannelGroup/Simulation/ChannelList

The term **Index n** in the column heading means that no axis or no channel is defined for this index.

The following general data is displayed in the bottom display line:

- **Connected:** Indicates the software or function area to which the OLM is connected
  - Ipo
  - SimIpo
  - PLC6
  - none: No connection
- **IpoCounter:** Counts the IPO clock pulses  
Note: The contents of the IpoCounter are also stored for trace information and error messages.
- **Ax/Chn-Number:** Logical axis number or channel number (depends on the selected function)
  - Number at left: Left column
  - Number at right: Right column

If the number of variables displayed exceeds the capacity of the main window, use PageDown/PageUp to scroll to the next/previous group of variables. One group consists of eight displayed variables.

## Units

The OLM displays data in the following units:

- **Linear axes**
  - For position, length, etc: in [mm]
  - For speed: in [mm/s]
  - For acceleration: in [mm/s<sup>2</sup>]
- **Rotary axes (spindles)**
  - For position, etc: in [°]
  - For speed: in [°/s]
  - For acceleration: in [°/s<sup>2</sup>]

## Selecting axes and channels

To select axes or channels, proceed as follows:

- Press **CTRL** + UP ARROW / DOWN ARROW to influence the **left column**.
  - CTRL + UP ARROW: Display the next axis/channel.
  - CTRL + DOWN ARROW: Display the previous axis/channel.
- Press **ALT** + UP ARROW / DOWN ARROW to influence the **right column**.
  - ALT + UP ARROW: Display the next axis/channel.
  - ALT + DOWN ARROW: Display the previous axis/channel.
- Press UP ARROW / DOWN ARROW (without CTRL or ALT) to influence **both columns**.
  - UP ARROW: Display the next axes/channels.
  - DOWN ARROW: Display the previous axes/channels.



## Status display

Example of screen layout for status display:

Axis-Key	X1	Z1	Axis-Key	X1	Z1
CHD_ACTIVE	F	F	SCHLEPP_AUSF_REQ	F	F
IM_FENSTER	T	T	REQU_POS_REACHED	F	T
SPEED_OK	T	T	KEITNE_UEBERNM	F	F
V_OK	T	T	MOVING_VNOM	F	F
LGR_AKTIV	T	T	SVE_POS	F	F
reserve	F	F	SVE_NEG	F	F
ANTRIEB_EIN	T	T	RELEASE_CONNECTOR	F	F
ANTRIEB_FREI	T	T	BREAK_ON	F	F
MOVING	F	F	POS_ERROR	F	F
DIRECTION	F	F	I2T_WAFIN	F	F
SCHLEPP_OK	F	F	I2T_ERROR	F	F
REF_OK	T	T	TEMP_ERROR	F	F
VORSCHUB_FREI	T	T	SG_REFERENCED	T	T
NULLPULS	F	F	SG_POS_TESTED	T	T
LATCH_GUELTIG	F	F	SG_PREPARED	F	F
ISTV_UEBERNOMMEN	F	F	SG_SAVE	F	F

Connected    IPO    IpoCounter    24755    Ax/Chn-Number    +0 - +1

Use Cursor Up/Down (with or without Ctrl or Alt) to change Ax/Channel-Number

Plc Nom State    Ipo Act State 1    Ipo Act State 2    Diag State    Diag Counter    NEXT

In the main window, the status of the binary variables is displayed. The status is identified by the background color and the code letter.

- Green or "T": true
- Red or "F": false
- Yellow: The status is not defined yet

The information given about the display of variables also applies to the column headings and the bottom display line.

## 6.22.4 Group of NC axes

### Nominal commands of the PLC (Plc Nom Data)

To select the **PLC Nom Data** function:



▶ Press the **Login Ipo** soft key.



▶ Press the **Axes** soft key.



▶ Press the **PlcNomData** soft key.




The function displays the nominal commands of the PLC for each axis in the following variables:

Variable	Display
PlcSollStatus	Axis status of the PLC as a bit line (listed in PLC-Nom_State)
MaxAchsVorschub	Maximum permissible axis feed rate in mm/s
AchsOverride	Override value for each axis (1 = 100%)
TempKorr	Temperature compensation in mm




## IPO-internal variables (Ipo Act Data or Spindle)

The OLM displays the current IPO-internal variables of the selected axes (also spindle axes).

To select the **Ipo Act Data** function:

-  ▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.
-  ▶ Press the **Axes** soft key.
-  ▶ Press the **Ipo Act Data** soft key.

The display of the current IPO-internal variables is also activated when you select the **Spindle** function.

-  ▶ Press the **Login Ipo** soft key.
-  ▶ Press the **Axes** soft key.
-  ▶ Press the **Spindle** soft key.

The function displays the following variables:

Variable	Display
axisState1	Bit line (listed in IpoActState 1)
axisState2	Bit line (listed in IpoActState 2)
driveCmdWord	Command for universal controller
relNomPos	Relative nominal position
absNomPos	Absolute nominal position
absActPos	Absolute actual position
absNomFeed	Absolute nominal velocity
absActFeed	Absolute actual velocity
absNomAcc	Absolute nominal acceleration
absActAcc	Absolute actual acceleration
actParSet	Current parameter set index
ipoCtrlWord	Internal control bit line of nominal commands in the IPO chain
compensPos	Compensation value
masterId	Active master during synchronism
lag	Current following error

Variable	Display
lagPeak	Peak of current following error. The maximum peak of the following error is determined and displayed here. Use CLEARPEAKLAG to delete it.
targetPos	Absolute target position of the axis
totalDistance	Total travel of the axis
motorTemperature	Motor temperature in degrees Celsius
utilization	Utilization of axis in %
rpfOffset	Coordinate system offset between switch-on position and reference point
spindleTurns.	Spindle revolutions – the value of the active spindle is calculated.
ModCounter	Only available for modulo axes. The counter is updated with each zero crossover of the current nominal position value of a modulo axis. All positions leaving the IPO (display, PLC, etc.) are calculated from the current position (0 to 359.9999 degrees) + moduloCounter * 360. The counter can be set, cleared, stopped and restarted from the geometry module. The modulo counter is saved cyclically in SRAM and restored during control startup.
ModCounterAct	Only available for modulo axes. The counter is updated with each zero crossover of the current actual position value of a modulo axis. All positions leaving the IPO (display, PLC, etc.) are calculated from the current position (0 to 359.9999 degrees) + moduloCounter * 360. The counter can be set, cleared, stopped and restarted from the geometry module.
absNomPosOfFilt1	Absolute nominal position before the nominal position value filter (see configuration data <b>System/CfgFilter</b> )
absNomPosOfFilt2	Absolute nominal position before the nominal position value filter (see configuration data <b>System/CfgFilter</b> )
absNomPosBase	Nominal position without compensation of virtual axes
lastIpoPos	Last interpolated nominal value of interpolator
syncPosDiff	Position difference during spindle synchronism (for slave spindle)
absTouchPos	Absolute actual position provided by measuring system
virtStartPos	Starting position of virtual axis (reference position). Basis for determining the relative virtual offset.
requestedPos	Position commanded by HMI for returning to the contour
absProgFeed	Currently programmed speed

<b>Variable</b>	<b>Display</b>
PosWithChainTime	The value is "pre-calculated" in the spindle module and then processed in the internal path calculation. This value considers the runtime of the interpolator.
realAxisIdent	Number of the real axis to which a virtual axis is connected.
relActPos	Relative actual position per IPO clock
xNom	Nominal position value in the CC interface (in interpolation steps).
absActPosNonMod	Absolute actual position without any modulo calculation (for non-modulo axes: absActPosNonModulo == absActPos).
acceptableLag1	Permissible following error for warning.
acceptableLag2	Permissible following error for emergency stop error.
axisCommand	Internal axis commands (e.g. freeze override, from interpolator to spindle during thread cutting)
driveCmdWord	Command for universal controller
virtOffsetOn	Feedforward of virtual offset is active.
rpfActiv	Reference run for this axis is active.
measureLatch Active	Touch probe latch is active.
counterAbs PosCheck	Encoder monitoring is active.
checkPosStandstill	Standstill monitoring is active.
toolCorrDelta	Asynchronous tool compensation per IPO clock.
toolCorrNom	Nominal value for asynchronous tool compensation.
toolCorrAkt	Asynchronous tool compensation path executed until now.
wpCorrDelta	Asynchronous position compensation per IPO clock.
wpCorrNom	Nominal value for asynchronous position compensation.
wpCorrAkt	Asynchronous position compensation path executed until now.

## Internal working data of PLC-IPO (Plc Ipo Data)

To select the **Plc Ipo Data** function:



▶ Press the **Login Ipo** soft key.



▶ Press the **Axes** soft key.



▶ Press the **Plc Ipo Data** soft key.

The function displays the following variables:

- **act-Cmd** (currently active command)
- **last-Cmd** (last assigned command)

Variable	Display
state	<p>Possible states:</p> <ul style="list-style-type: none"> <li>■ Finished: Command acknowledged.</li> <li>■ Idle: Axis does not work and can be assigned a command.</li> <li>■ MovingByHand: Manual direction key or PLC positioning is active.</li> <li>■ StoppingByHand: Deceleration until standstill</li> <li>■ WaitForPlcPosQuit: Waiting until the last nominal position value has been received by the axis (runtimes in the IPO chain)</li> <li>■ RpfStart: Status during reference run</li> <li>■ RpfFastToSwitchPreo: Status during reference run</li> <li>■ RpfFastToSwitch: Status during reference run</li> <li>■ RpfFastFromSwitchPrep: Status during reference run</li> <li>■ RpfFastFromSwitch: Status during reference run</li> <li>■ RpfSlowToSwitchPrep: Status during reference run</li> <li>■ RpfSlowToSwitch: Status during reference run</li> <li>■ RpfAktivatePulse: Status during reference run</li> <li>■ RpfWaitForPulse: Status during reference run</li> <li>■ RpfWaitForStop: Status during reference run</li> <li>■ RpfLatchPos: Status during reference run</li> <li>■ RpfFinish: Status during reference run</li> <li>■ WaitForSpindlemoveQuit: Waiting for acknowledgment of spindle (e.g. speed reached or synchronism switched on, etc.)</li> <li>■ Spindlemove: Spindle rotates at programmed speed.</li> </ul>





Variable	Display
typeOfMove	Possible states: <ul style="list-style-type: none"> <li>■ NONE = 0: Axis is in IDLE state</li> <li>■ AXKEY: Manual direction key</li> <li>■ PLCPOS: PLC positioning</li> <li>■ LIFTOFF: Lift off at Cycle stop</li> <li>■ RESTORE_POS: Return to contour (block scan)</li> <li>■ SYNCHRON: Synchronism (only for spindles)</li> <li>■ PLCMEASURE: Measuring with PLC axes</li> <li>■ SG_POS: Positioning with safety-related (SG) package</li> <li>■ REVOL_FEED: Feed per revolution</li> <li>■ SPINDLE: Command to spindle (M3, M4, M19 etc.)</li> </ul>
noLimitSw	During PLC positioning, software limit-switch monitoring can be switched off (T = switched off).
error	The following errors can occur: <ul style="list-style-type: none"> <li>■ AxisAlreadyActive = 1: Axis is already working and cannot be given a new command.</li> <li>■ PlcposAlreadyActive: Axis is already working and cannot be given a new command.</li> <li>■ KeyposAlreadyActive: Axis is already working and cannot be given a new command.</li> <li>■ OnlyOneAxWithKinem: When the kinematic model is switched on, the PLC-IPO can assign commands to only one axis at a time.</li> <li>■ SweAlreadyActive: Axis is located at software limit switch.</li> <li>■ MovementCanceled: Movement was canceled.</li> <li>■ TsSwitched: Touch probe has triggered</li> <li>■ ErrorPending: Touch probe error must be cleared first (in the error window).</li> <li>■ NoToolAx: No tool axis.</li> <li>■ MinFeed: Too small a feed rate is programmed.</li> <li>■ M19_ACTIVE: M19 is active; axis cannot be moved.</li> <li>■ NoChannel: Feed-per-revolution command was sent to an axis without NC channel.</li> <li>■ M19WithoutRef: Not used.</li> <li>■ ReconfigActive: Do not move any axis while changing parameters.</li> <li>■ AlreadyMaster: This axis is a master and cannot be a slave at the same time (synchronism).</li> <li>■ AlreadySlave: Only the SYNCHRON_OFF command is allowed for a slave spindle.</li> <li>■ NoSlave: The SYNCHRON_OFF command was sent to a non-slave spindle.</li> </ul>



<b>Variable</b>	<b>Display</b>
Vb-Prog	Programmed feed rate (mm/s)
Vb-Act	Active feed rate
Source	Type of handwheel (serial, e.g. HR410, etc., or encoder)
Dist/Revol	Traverse per handwheel revolution
DistMax	Maximum traverse range (+/-) of handwheel
Factor	Internal conversion factor (dist./rev. / incr./rev.)
Impulse	Handwheel pulses at current IPO clock
ImpulseLast	Handwheel pulses at previous IPO clock
Position	Handwheel position
PosRaster	Handwheel position (for handwheel with detent).
InputsToPLC	Handwheel keys are sent to the PLC as bit line C
OutputsFromPLC	e.g. LEDs on the HR 410.



## Data from the IpoOffset module (Offset Data)

The data of the interpolator and the PLC-IPO are collected in the module IpoOffset.

To select the **Offset Data** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Axes** soft key.



▶ Press the **Offset Data** soft key.

The function displays the following variables:

Variable	Display
offsetIpoSteuer	Internal control bit line
IpoSteuer	Internal control bit line
IpoSteuerErlaubt	Internal control bit line
handValid	Nominal values from the PLC-IPO are available.
offsetPosition	Nominal position (relative) from PLC interpolator and/or kinematics.
kinematikOffset	Incremental offset of kinematics.
autoValid	Nominal values from the interpolator are available.
sollPosition	(Absolute) nominal position from the interpolator.
sollPosBase	Absolute position (sum of SollPosition and OffsetPosition)
lastPosition	Absolute position (sum of sollPosBase and virtual offset)
lastPosWithoutG	Position of the axis without grinding offset. The axis has reached this position by executing the movement in the standard interpolator.
grindingValid	Validity of the value in <b>grindingOffset</b> . True: The content of <b>grindingOffset</b> is added to the nominal axis value.
grindingOffset	Offset value generated by the grinding interpolator.
channelNr	Current channel number

Variable	Display
The following variables coordinate the movements of the real and virtual axes. The nominal position value of the virtual axes is added to the nominal position value of the real axis (feedforward of nominal value). This applies only to the relative movements of the virtual axis.	
virtOffsValid	Validity of the value in <b>virtOffset</b> . True: <b>virtOffset</b> is effective.
virtOffset	Value of the relative movement of the virtual axis. (Only important for real axes.)
virtOffsActive = true	The feedforward of the nominal position value is configured and effective. (Only important for virtual axes.)
virtStartPos	Starting position of the virtual axis before feedforward of nominal position value is activated. (Only important for virtual axes.)
realAxisNr	Number of the real axis to which the virtual axis was connected. (Only important for virtual axes.)
virtOffsetOn	Feedforward of position value of virtual axis is active. (Only important for real axes.)
channelNr	Assignment of the axis to the channel.

Example of coordinated movements of real and virtual axes:

- Absolute position of virtual axis = 5.0
- The virtual axis is moved to position 8.0.
- Resulting virtual offset (virtOffset) at the end of movement = 3.0.

## Data of the active CC (CC Data)

To select the **CC Data** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Axes** soft key.



▶ Press the **CC Data** soft key.

The function displays the following variables:

Variable	Display
cclIndex	Current position of the axis (on CC0 or CC1).
axIndex	Index of this axis on the current CC.
N_SOLL_IN	Nominal velocity transferred to the CC (internal units in the CC).
V_VORST	Nominal feedforward velocity transferred to the CC (internal units in the CC).
N_SOLL_IN_DELTA	Nominal acceleration transferred to the CC (internal units in the CC).
N_SOLL_IN_CHK	Handshake bit
DriveCmdWord	Command word
boDREG_FREI	Controller enable
S_IST	Actual position in the CC interface.
S_IST_CHK	Handshake bit
N_IST	Actual velocity
S_REF	Reference position
S_REF_CHK	Handshake bit
S_3D	Measurement result (position)
S_3D_CHK	Handshake bit
S_IST_ROT_ENC	Position of the motor encoder
S_IST_CHK_ROT_ENC	Handshake bit
Utilization	Utilization of drive
MotTemp	Motor temperature
Dummy01	

## Nominal status of the axes (Plc Nom State)

The nominal status of the axes is requested by the PLC.

To select the **PLC Nom State** function:



▶ Press the **Login Ipo** soft key.



▶ Press the **Axes** soft key.



▶ Press the **Plc Nom state** soft key.

The function displays the status of the following binary variables (the descriptions refer to the status "true"):

Variable	Display
RefSwitch	Trip dog
ActualToNom	Transfer the current values as nominal values.
ClampRequest	Request for clamping this axis.
PosCtrlRequest	Request for position feedback control for this axis
NoMonitoring	No monitoring of following error or standstill
NoFeedhold	Feed rate stop is not set
DriveOnReq	Request to switch the drive on
ActToNomStrb	Not used
CurrentOff	Switch off the current for wye/delta connection
SpiChangeDir	Change the direction of spindle rotation
ResetRefOk	Reset the Ref OK flag when changing from 0 to 1
NoPosDiffCheck	Suppress the position difference check



**Actual status 1 of the axes (Ipo Act State 1)**

To select the **Ipo Act State 1** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Axes** soft key.



▶ Press the **Ipo Act State 1** soft key.

The function displays the status of the following binary variables (the descriptions refer to the status "true"):

Variable	Display
CMD_ACTIVE	Command is active for this axis
IM_FENSTER	Following error is within the positioning tolerance
SPEED_OK	Feed rate is OK
V_OK	No acceleration active
LGR_AKTIV	Position feedback control is active
ANTRIEB_EIN	Drive is on
ANTRIEB_FREI	Drive ready for operation
MOVING	Axis is in motion (feed rate > 0)
DIRECTION	Direction of motion (true: negative direction or standstill)
SCHLEPP_OK	Not used
REF_OK	Axis was homed
VORSCHUB_FREI	Feed rate has been enabled (no feed stop)
NULLPULS	Reference pulse in one IPO cycle
LATCH_GUELTIG	Probe value is valid
ISTW_UEBERNOMMEN	The current value was transferred instead of the nominal value.
SCHLEPP_AUSF_REQ	If position feedback control is activated, the "old" position is approached (no compensation of following error)
REQU_POS_REACHED	Requested position is reached
KEINE_UEBERW	Request from PLC: No servo lag and standstill monitoring
MOVING_VNOM	Axis is in motion (nominal feed rate > 0)
SWE_POS	Positive software limit switch is reached
SWE_NEG	Negative software limit switch is reached



<b>Variable</b>	<b>Display</b>
RELEASE_CONNECTOR	Status of axis-specific enabling (X150/X151)
BREAK_ON	Request to PLC for activating the brake within 100 ms
POS_ERROR	Positioning error
I2T_WARN	Warning during I <sup>2</sup> t monitoring
I2T_ERROR	Error during I <sup>2</sup> t monitoring
TEMP_ERROR	Error during temperature monitoring
SG_REFERENCED	Axis was homed (SG: safety-oriented control)
SG_POS_TESTED	Axis was "tested" by the user (SG: safety-oriented control)
SG_PREPARED	Axis was homed and "tested" by the user (SG: safety-related control)
SG_SAVE	Safe axis (SG: safety-oriented control)





## Actual status 2 of the axes (Ipo Act State 2)

To select the **Ipo Act State 2** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Axes** soft key.



▶ Press the **Ipo Act State 2** soft key.

The function displays the status of the following binary variables (the descriptions refer to the status "true"):

Variable	Display
NO_CONTROL	Axis is not controlled (internal IPO status)
SPEED_CONTROL	Speed control is active (internal IPO status)
POS_CONTROL	Position control is active (internal IPO status)
INTERNAL_ERROR	Error has occurred (internal IPO status)
CHANNEL_AXIS	Axis belongs to a channel
CHANNEL_SPINDLE	Axis is a spindle of a channel
PLC_AXIS	Axis received a command from the PLC
PLC_SPINDLE	Axis is used as spindle
IS_ACTIVE	Axis is physically available and can be given a command
IS_MANUAL	Axis is a noncontrolled counter axis
IS_VIRTUAL	Virtual axis whose nominal position values can be added to those of other axes. (Axis does not have its own servo drive.)
IS_DISPLAY	Axis is only displayed. (Axis does not have its own servo drive.)
NORMAL_FEED	Feed rate in "travel/minute."
REVOL_FEED_MANUAL	Feed rate in "travel per revolution" in the manual control mode.
REVOL_FEED_PROGR	Feed rate in "travel per revolution" in the automatic mode.
VCONST_FEED	Only for spindles – Feed rate at constant cutting speed
NC_CMD_ACTIVE	Command from the NC is active
PLC_CMD_ACTIVE	Command from the PLC is active
HR_ACTIVE	Handwheel is active
NC_STOP_ACTIVE	NC stop is active in the channel

<b>Variable</b>	<b>Display</b>
SP_SPEED_ REACHED	Only for spindles – last spindle speed reached
SP_MASTER	Axis is master spindle (for spindle synchronism)
SP_SLAVE	Axis is slave spindle (for spindle synchronism)
SP_SYNC_ REACHED	Last spindle speed reached (for spindle synchronism)
LGR_REQUEST	Only for spindles – IPO-internal request for position feedback control
TAKE_CYC_DATA	Use the nominal values from the cyclic message
IS_NOT_ACTIVE	Axis was configured but is not available physically
IS_ENDAT	Axis with EnDat encoder



## Status of the axes (Diag State)

To select the **Diag State** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Axes** soft key.



▶ Press the **Diag State** soft key.

The function displays the status of the following binary variables (the descriptions refer to the status "true"):

Variable	Display
OwnFeedhold	No feed-rate enable from the PLC for this axis
OtherFeedhold	No feed-rate enable from the PLC for an axis of the kinematics
NewSlope	Internal use
NoAntriebFrei	No drive enable by the PLC
OwnPosCtrl	Position feedback control not active
OtherPosCtrl	Position feedback control not active in an axis of the kinematics
Override=0	Override at 0%
OffsetCtrl	Internal use
TakeCycData	Internal use
PlcMaxFeed=0	MaxFeed from the PLC is 0
TsMaxFeed=0	MaxFeed from the touch-probe table and/or from parameter "maxTouchFeed" is 0
WorkingOutLag	Following error is corrected

## Counters for axis commands (Diag Counter)

To select the **Diag Counter** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Axes** soft key.



▶ Press the **Diag Counter** soft key.

All counters are reset to 0 when the control is started. The function displays the following counters:

Variable	Display
cntrActToNom	Number of nominal/actual position captures
cntrFeedHold	Number of changes of the feed-rate enable
cntrM3	Number of M3 commands
cntrM4	Number of M4 commands
cntrM5	Number of M5 commands
cntrHwheel	Number of handwheel commands











## Group of axis commands

The OLM transfers the axis commands directly to the axis. The current IPO internal variables are displayed in the display boxes.

The commands apply to the **axis selected in the left column**.

To select the **axis commands**:

-  ▶ Press the **Login Ipo** soft key.
-  ▶ Press the **Axes** soft key.
-  ▶ Press the **Plc Ipo Data** soft key.
-  ▶ Press the **ActPos=0** soft key or a soft key for another command.

Axis commands	
	Set axis to position 0.
	Set axis to position 1000.
	Set axis to position -50.
	Restore original axis data.

## Switching the parameter set of an axis (Change ParSet)

The active parameter set of an axis can be switched for test purposes.

To select the **Change ParSet** function:



- ▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



- ▶ Press the **Axes** soft key.



- ▶ Press the **Change ParSet** soft key for the OLM to open the "Change ParSet" dialog box.
- ▶ Enter the required data in the dialog box (see below).
  
- ▶ Confirm with **OK**—the OLM switches to the defined parameter set.

"Change ParSet" dialog box:

Change ParSet

Axis-Index 0

ParSet-Index 0

OK ABRUCH

Dialog box entries:

- **Axis-Index:** Logical axis number
- **ParSet-Index:** Index of parameter set

### Deleting the following error (Clear PeakLag)

The IPO saves the greatest following error (PeakLag) that occurred. The Clear PeakLag function deletes this variable for all axes.

To select the **Clear PeakLag** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Axes** soft key.



▶ Press the **Clear PeakLag** soft key.

### Deleting the reference point (Clear RefOk)

Deleting the reference point is necessary for being able to assign a new reference-run command. The function is effective for all axes.

To select the **Clear RefOK** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Axes** soft key.



▶ Press the **Clear RefOK** soft key.

## 6.22.5 Group of spindle commands

The OLM transfers the spindle commands directly to the spindle. The current IPO internal variables are displayed in the display boxes.

- The standard spindle commands apply to the **spindle selected in the left column.**
- If you want to use commands for **spindle synchronism**, remember the following assignment:
  - Spindle in left column: Master spindle
  - Spindle in right column: Slave spindle

To select the **spindle commands**:

Login Ipo	▶ Press the <b>Login Ipo</b> soft key.
Axes	▶ Press the <b>Axes</b> soft key.
Plc Ipo Data	▶ Press the <b>Plc Ipo Data</b> soft key.
Spindle	▶ Press the <b>Spindle</b> soft key.
M3	▶ Press the <b>M3</b> soft key or a soft key for another spindle command.

Specify the direction of rotation (M3 or M4) in the commands for spindle synchronism.

Spindle commands	
M3	Spindle rotates (at 123 rpm) in M3 direction
M4	Spindle rotates (at 234 rpm) in M4 direction
M5	Spindle is stopped
V-Const	The spindle rotates at constant cutting speed (2000 m/sec in M3 direction)
M19 0 Grad	Spindle point stop at 0°
M19 179 Grad	Spindle point stop at 179°





<b>Spindle synchronism commands</b>	
Synchron +1*	Spindle synchronism <ul style="list-style-type: none"> <li>■ Same direction of rotation</li> <li>■ Speed ratio master/slave: 1/1</li> </ul>
Synchron +2*	Spindle synchronism <ul style="list-style-type: none"> <li>■ Same direction of rotation</li> <li>■ Speed ratio master/slave: 1/2</li> </ul>
Synchron -1*	Spindle synchronism <ul style="list-style-type: none"> <li>■ Reversed direction of rotation</li> <li>■ Speed ratio master/slave: 1/1</li> </ul>
Synchron +1* (+42°)	Spindle synchronism <ul style="list-style-type: none"> <li>■ Same direction of rotation</li> <li>■ Speed ratio master/slave: 1/1</li> <li>■ Angle offset: 42°</li> </ul>
Synchron -1/2 (-25°)	Spindle synchronism <ul style="list-style-type: none"> <li>■ Reversed direction of rotation</li> <li>■ Speed ratio master/slave: 2/1</li> <li>■ Angle offset: -25°</li> </ul>
Synchron OFF	Switch off spindle synchronism

## 6.22.6 Group of NC channels

### Data of the interpolator module (Ipo Data)

To select the **Ipo Data** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Channels** soft key.



▶ Press the **Ipo Data** soft key.

The function displays the following variables:

Variable	Display
State	<p>Possible IPO states:</p> <ul style="list-style-type: none"> <li>■ Idle: IPO is idle (start-up)</li> <li>■ RdNextMsg: IPO is waiting for job—reads from its input queue</li> <li>■ Running: IPO is working (traverses the axes)</li> <li>■ Waiting: Waiting during synchronism between IPO, PLC and channel object</li> <li>■ WaitingForLr: Waiting to ensure that the nominal value last generated was received by axes (IPO chain)</li> <li>■ WaitingForCancel: Waiting for GmCanceled from the input queue</li> <li>■ WaitingForAxes: Waiting until all axes are in the control window</li> <li>■ WaitingForLiftOff: Waiting for lift off movement after NcStop</li> <li>■ WaitingForLA: Waiting for Look-Ahead</li> <li>■ WaitingForSpindle: Waiting for spindle command to be executed (internal M19 during drilling)</li> <li>■ ShapeReset: <ul style="list-style-type: none"> <li>■ StartThreadCutting: Thread cutting</li> <li>■ WaitingForPLCPos: Waiting for PLC positioning</li> <li>■ WaitingForTime: Waiting times for tapping with BCD spindles</li> <li>■ WaitingForPlcQuit: Waiting for acknowledgment from the PLC during tapping with BCD-encoded spindles (M3, M4, M5)</li> </ul> </li> </ul>
kanalStatus	Possible channel states, represented as bit codes (See page 1194)



Variable	Display
chainState	Status of the IPO chain: <ul style="list-style-type: none"> <li>■ IPO chain is "full."</li> <li>■ IPO chain is "empty."</li> <li>■ IPO chain is "almost empty" (waiting for the last acknowledgment message)</li> </ul>
chainCount	Number of acknowledgment messages in the IPO chain
satzCount	Number of blocks in this NC program.
blockId	ID of the current block
blockNumber	Number of the current block (from NC program)
fileName	Current NC program
syncActState	<ul style="list-style-type: none"> <li>■ Running: Synchronization not active</li> <li>■ Wait SS: Waiting in Single Block mode</li> <li>■ Wait Sync: Waiting during the synchronization of IPO and PLC</li> </ul>
syncWaitFor	Is only relevant if syncActState is <b>not</b> SyncRunning. <ul style="list-style-type: none"> <li>■ Channel object</li> <li>■ PLC-Sync</li> <li>■ Step-Contrl</li> </ul>
syncWaitId	Number of the current synchronization
CH-synclWait	Waiting ID for M97, G62, G63 (channel synchronization), not relevant for the MANUALplus 620
CH-syncl	Start ID for M97, G62, G63 (channel synchronization), not relevant for the MANUALplus 620
eomStopId	ID of the End of Move (eom) from the geometry chain
laStopId	ID of the End of Move (EOM) from the real-time LookAhead
startPath	Absolute starting position of current traverse on the path
endPath	Absolute end position of current traverse on the path
pathLength	Current path length
S(t)	(Absolute) position on the path

<b>Variable</b>	<b>Display</b>
P(s)[0]	Position of the first axis to be interpolated
P(s)[1]	Position of the second axis to be interpolated
P(s)[2]	Position of the third axis to be interpolated
P(s)[3]	Position of the fourth axis to be interpolated
P(s)[4]	Position of the fifth axis to be interpolated
P(s)[5]	Position of the sixth axis to be interpolated
RevolFeedProg	Programmed feed rate per revolution in automatic mode
RevolFeedMan	Programmed feed rate per revolution in manual mode
ProgFeed	Programmed contour speed
Fmax	(If true:) Rapid traverse was programmed
toolCorrId	ID of the current asynchronous tool compensation
wpCorrId	ID of the current asynchronous workpiece compensation



## Internal data of the offset interface (Offset Data)

To select the **Offset Data** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Channels** soft key.



▶ Press the **Offset Data** soft key.

The function displays the following variables from the IpoOffset:

Variable	Display
kindOfKinComp	Type of current kinematics
kindOfKinCompSave	Type of current kinematics
useFrozenAxVal	The "frozen position" is used for rotary axes
v_bahn	Current contour speed
mySpindleNr	Spindle number belonging to this channel
achsAnz	Number of axes of this channel to be interpolated
logAchsNr[0]	First logical axis number of the channel
...	...
logAchsNr[8]	Ninth logical axis number of the channel

## Current status of the channel (Act State)

To select the **Act State** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Channels** soft key.



▶ Press the **Act State** soft key.

The function displays the following binary variables:

Variable	Display
rapidFeed	Rapid traverse is active for this channel
ncStopTaster	PLC request for NcStop at triggering of touch probe
override100	The override is frozen at 100 %
singleStep	Single Block is active
ncStart	NC start is active
internStart	Internal NC start is active
systemCycle	A system cycle is active
ncStop	NC stop is active
programStop	Program stop (M00/M01) is active
cancel	Cancellation is active
threadCycle	Thread cycle is active
tProbeCycle	Touch probe cycle is active
threadRevFeed	Feed rate per revolution during thread cutting
tasterMonitorGeo	NC request for monitoring of touch probe
tasterMonitorPlc	PLC request for monitoring of touch probe
measure	The touch probe has triggered.
revolFProgRun	Feed rate per revolution in automatic mode is programmed for this channel.
revolFManualMode	Feed rate per revolution in manual mode is programmed for this channel.

## Diagnosis of the channel status (Diag State)

To select the **Diag State** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Channels** soft key.



▶ Press the **Diag State** soft key.

The function displays the following binary variables:

Variable	Display
WaitingForAxes	Waiting until all axes are in the control window after the program is started
noSFromT	No new nominal values from the look-ahead
SameSFromT	Cyclically identical nominal values from the look-ahead

## Look-Ahead information

To select the **Look-Ahead information**:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Channels** soft key.



▶ Press the **Look Ahead** soft key.



▶ Press the **Pathes** or **States I** or **States II** or **States III** soft key.

The functions display the states and variables of the look-ahead function. Analyzing this data is reserved for look-ahead specialists.

## 6.22.7 Hardware group

### Hardware information of the CC (CC HW Info)

To select the **CC HW Info** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **HW** soft key.



▶ Press the **CC HW Info** soft key.



#### Note

The hardware information displayed for the CC is only valid if a CC with a parallel interface is used (no HSCI).

On the **left side of the screen** the OLM shows the variables as they are provided by the CC (first CC in the left column, and second CC in the right column):

Variable	Display
CC-Type	
ActiveAxes	Displays the available axes in bit-encoded representation.
CtrlType	Provides information on hardware and software versions, etc.
TestVersion	Information on the DSP software. Indicates either the letter of a test version or the number of a DSP software service pack. The MC must take this additional information into account.
LinkDate	Contains the software generation in 32 bits (Unix format)
SoftIdent	Contains the software ID and the version code.
ReadyInc	After processing the remaining identification cells, the variable is incremented by the controller program or boot program to allow an "activity check."





The data provided by the CC are explained in the **right half of the screen** (first CC in the left column, and second CC in the right column):

Variable	Display
BootHost	Boot software from the host
BootEprom	Boot software from the EEPROM
Type	Controller model: <ul style="list-style-type: none"> <li>■ TMS320C31</li> <li>■ TMS320C32</li> <li>■ TMS320C32 – spindle board</li> <li>■ Universal controller</li> </ul>
HW-Info	Information on the hardware version
PS-Modul	Module for safety-related controls (SG: safety-oriented controls)
Version	Test version or release version (delivery version)
TestVers.	Is the software a test version?
LinkDate	Contains the software generation in 32 bits (Unix format)
SW-Info	Information on the software version

**Transfer of commands between IPO and CC (CC Data)**

To select the **CC Data** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **HW** soft key.



▶ Press the **CC Data** soft key.



**Note**

The hardware information displayed for the CC is only valid if a CC with a parallel interface is used (no HSCI).



The function displays the following variables (first CC in left column – second CC in right column):

Variable	Display
CmdFrmHost	Current command to the CC
AxInfoFrHost	Associated axis information
MsgInfoFrmHost0 .. 3	Additional information on the command
CmdToHost	Current command from the CC
AxInfoToHst	Associated axis information
MsgInfoToHost0 .. 3	Additional information on the command
WatchDogFrHst	Watchdog to the CC
WatchDogToHst	Watchdog from the CC
Irq_Cycle	Synchronization between CC0 and CC1
UnixTime	Not used
DriveOffMask	Not used
ExtDrvRelMask	Not used
LtRdyState	<p>The 8-bit word (oooo oooo) contains the following information ("x" indicates the bit(s) containing the information):</p> <ul style="list-style-type: none"> <li>■ oooo ooxo (x=1): DC-link voltage too high (Port input: "-ERR.UZ.GR" = low level)</li> <li>■ oooo oxoo (x=1): Temperature of heat sink too high (Port input: "-ERR.TEMP" = low level)</li> <li>■ ooxo oooo (x=1): DC-link current too high (Port input: "-ERR.IZ.GR" = low level)</li> <li>■ ooxo oooo (x=1): Power supply unit not ready (Port input: "RDY.PS" = low level)</li> <li>■ oxoo oooo (x=1): Leakage current too high (Port input: "-ERR.ILEAK" = low level)</li> </ul>
DriveStatus	<p>Shows the status of the drives in bit-encoded representation. The bit position of a drive depends on the index in the CC. This index is shown in the <b>axIndex</b> field (OLM function: IPO/Axes/CC Data).</p> <ul style="list-style-type: none"> <li>■ Bit = 0: Drive is switched off or does not exist</li> <li>■ Bit = 1: Drive is on</li> </ul>



Variable	Display
AxRelConnect	<ul style="list-style-type: none"> <li>■ Bits 0 to 7: Indicate the status at connection X150 (axis-specific enabling)</li> <li>■ Bits 8 to 15: Indicate the enabling status of the axes of the first CC</li> </ul>
AxRelConnectSI	<ul style="list-style-type: none"> <li>■ Bits 0 to 7: Indicate the status at connection X151 (axis-specific enabling)</li> <li>■ Bits 8 to 15: Indicate the enabling status of the axes of the second CC</li> </ul>



## Command to the CC (CC Command)

This function transfers commands directly to the CC.



### Danger

Please note that commands transferred to the CC with this function are not checked by the system.

Do **not** use these functions to switch drives on or off, since the brakes will not be activated or deactivated.

To select the **CC Command** function:



- ▶ Press the **Login Ipo** soft key.



- ▶ Press the **HW** soft key.



- ▶ Press the **CC Command** soft key for the OLM to open the "CC Command" dialog box.
- ▶ Enter the required data in the dialog box (see below).
  
- ▶ Enter the required data in the dialog box (see below).
  
- ▶ Confirm with **OK**—the OLM sends the defined command to the CC.

**CC\_Command** dialog box:

Dialog box entries:

- **Function:** Command sent to the CC
  - AxMpUebern
  - MotTemp
  - DriveOnReq
  - AntriebAus
  - Status
  - CHK\_PHIFELDREF
  - SHOW\_HW\_CO...
- **Info:** Not used
- **Axis no:** Logical axis number



## Data of the static RAM (S-RAM)

This function displays the data stored in the static RAM of the IPO.

To select the **S-RAM** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **HW** soft key.



▶ Press the **S-RAM** soft key.

The function displays the following variables:

Variable	Display
kennung1	Internal code
kennung2	Internal code
absActPos	Switch-off position of the individual axes
absActPosNonMod	Switch-off position of the individual axes
refPosition	Reference position of the individual axes
modCntrEndat	Overflow of multiturn EnDat encoder
checkSum	Checksum of current machine parameters
valid	Validity code

## Data of the analog outputs (Analog Output)

Use **AnalogOutput** to display the nominal commands. – The values of the outputs are not returned.

To select the **Analog Output** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **HW** soft key.



▶ Press the **Analog Output** soft key.

The function displays the values of the analog outputs in [V]:

- Output1
- Output2
- ...
- Output16

## Counter function blocks of the MC (GAL Data)

GAL Data allows you to display the internal registers of the counter function blocks of the MC.

To select the **GAL Data** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **HW** soft key.



▶ Press the **GAL Data** soft key.

The GAL Data variables have only an IPO-internal meaning:

Variable	Display
reg0_low	
reg0_mid	
reg0_hig	
reg1_low	
reg1_mid	
reg1_hig	
init_reg_1	
cntrl_reg_1	
RI_reg	
latch_reg	
irq_reg	
offset00_reg	
offset90_reg	
timer_reg	
cntrl_reg_2	
cntrl_reg_3	



## Hardware port states (HW-Ports)

The **HW-Ports** function displays the current status of some hardware ports. For the meaning of the displays, please refer to the description of the MC hardware. To make orientation easier, the relative addresses of the ports are indicated below. To obtain the actual port address, add the base address of the hardware to the relative address.

To select the **HW-Ports** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **HW** soft key.



▶ Press the **HW-Ports I** or **HW-Ports II** or **HW-Ports III** soft key.

The functions display the status of the following hardware signals:

Variable	Display
HW-Ports I	<ul style="list-style-type: none"> <li>■ WD (IPO)</li> <li>■ _SH2_p(CCU): Base address + 0x330c</li> <li>■ _NE1_p (I3): Base address + 0x330e</li> <li>■ _NE2_p (I32): Base address + 0x3304</li> <li>■ _24V_plc2on:</li> <li>■ _24V_plc3on:</li> <li>■ _SH1AB_1_p: Base address + 0x3208</li> <li>■ _SHS1AB_1_p: Base address + 0x3204</li> <li>■ EN_SH2:Base address + 0x6000</li> <li>■ EN_NE1:Base address + 0x6004</li> <li>■ EN_PL:Base address + 0x6004</li> <li>■ EN_REG:Base address + 0x6006</li> <li>■ EN_MS:Base address + 0x6008</li> <li>■ EN_AT:Base address + 0x600a</li> <li>■ EN_ACFAIL:Base address + 0x600c</li> <li>■ IRQ_SH2:Base address + 0x6010</li> <li>■ IRQ_NE1:Base address + 0x6012</li> <li>■ IRQ_PL</li> <li>■ IRQ_REG:Base address + 0x6016</li> <li>■ IRQ_MS:Base address + 0x6018</li> <li>■ IRQ_AT:Base address + 0x601a</li> <li>■ IRQ_ACFAIL:Base address + 0x601c</li> <li>■ IRQ_SYNCPWM:Base address + 0x601e</li> </ul>

Variable	Display
HW-Ports II	<ul style="list-style-type: none"> <li>■ 3D-Signal (low active)</li> <li>■ 3D-Bereit (low active)</li> <li>■ 3d-Warng.</li> <li>■ TT-Signal (low active)</li> <li>■ TT-Bereit (low active)</li> <li>■ X30-SpRef</li> <li>■ WD-Reset</li> <li>■ PLC-2*5V</li> <li>■ iport1[0]: Base address + 0x3100</li> <li>■ iport1[1]: Base address + 0x3102</li> <li>■ iport1[2]: Base address + 0x3104</li> <li>■ iport1[3]: Base address + 0x3106</li> <li>■ iport1[4]: Base address + 0x3108</li> <li>■ iport1[5]: Base address + 0x310A</li> <li>■ iport1[6]: Base address + 0x310C</li> <li>■ iport1[7]: Base address + 0x310E</li> <li>■ oport1[0]: Base address + 0x3302</li> <li>■ oport1[1]: Base address + 0x3102</li> <li>■ oport1[2]: Base address + 0x3104</li> <li>■ oport1[3]: Base address + 0x3106</li> <li>■ oport1[4]: Base address + 0x3108</li> <li>■ oport1[5]: Base address + 0x310A</li> <li>■ oport1[6]: Base address + 0x310C</li> <li>■ oport1[7]: Base address + 0x310E</li> <li>■ _sg_inst_</li> </ul>





Variable	Display
HW-Ports II	<ul style="list-style-type: none"> <li>■ IRQ SH2</li> <li>■ IRQ MNE1</li> <li>■ IRQ PLC</li> <li>■ IRQ Reg/Spi1</li> <li>■ IRQ MS</li> <li>■ IRQ Mitsu/Spi2</li> <li>■ IRQ AF</li> <li>■ IRQ SyncPWM</li> <li>■ IRQ busTimeout</li> <li>■ IRQ VART1</li> <li>■ IRQ Vart2</li> <li>■ IRQ PF</li> <li>■ IRQ HWM</li> <li>■ IRQ WD</li> <li>■ IRQ</li> <li>■ IRQ</li> <li>■ MSK SH2</li> <li>■ MSK MNE1</li> <li>■ MSK PLC</li> <li>■ MSK Reg/Spi1</li> <li>■ MSK MS</li> <li>■ MSK Mitsu/Spi2</li> <li>■ AMK AF</li> <li>■ MSK SyncPWM</li> <li>■ MSK busTimeout</li> <li>■ MSK VART1</li> <li>■ MSK VART2</li> <li>■ MSK PF</li> <li>■ MSK HWM</li> <li>■ MSK WD</li> <li>■ MSK</li> <li>■ MSK enable all</li> </ul>



## Encoder data

With Encoder Data, you display the information on the encoder.

To select the **Encoder Data** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **HW** soft key.



▶ Press the **Encoder Data** soft key.

The **index** is structured as follows:

- 0 to 9: Position encoders of the MC
- 10: Speed encoder (index 0; CC 0)
- 11: Position encoder (index 0; CC 0)
- 12: Speed encoder (index 1; CC 0)
- 13: Position encoder (index 1; CC 0)
- . . .
- 32: Speed encoder (index 5; CC 1)
- 33: Position encoder (index 5; CC 1)

The OLM displays the following data of the encoder:

Variable	Display
type	<input type="checkbox"/> NotConnected <input type="checkbox"/> McPosEncoder <input type="checkbox"/> CcMotorEncoder <input type="checkbox"/> CcPosEncoder
inUse	The encoder is configured in the system (handwheel, position encoder or speed encoder).
usedFor	<input type="checkbox"/> Nothing <input type="checkbox"/> Position <input type="checkbox"/> Speed <input type="checkbox"/> Handwheel
axisIdent	Index of the axis from axisList
axisKey	Key of the axis from axisList
ipoFactor	Fine interpolation factor
cclIndex	Index of the CC
dplIndex	Index on the CC
latch1Ok	
latch1	Counter increments of latch 1, including fine interpolation
latch2Ok	
latch2	Counter increments of latch 2, including fine interpolation (reference pulse or measuring pulse).
EndatInfo	(Heading of the subsequent displays)
resolution	Resolution of the absolute track
absValue	Value of the absolute track
error	Error code
iresolution	Resolution of the incremental track
serialNumber	Serial number
multiturn	Maximum number of multiturn revolutions
mstype	Encoder code
incValue	Value of the incremental track during power-on

## Data of the "Fast Inputs"

This function displays information on the fast inputs.

To select the **Fast Inputs** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **HW** soft key.



▶ Press the **Fast Inputs** soft key.

The **index** is structured as follows:

- 0 to 4: Fast inputs of the PLC
- 5 to 9: Trip dogs of the spindles

The OLM displays the following data of the fast inputs:

Variable	Display
inUse	Fast input is configured
usedFor	<ul style="list-style-type: none"><li>■ Nothing</li><li>■ Plc</li><li>■ Axis (spindle)</li></ul>
axisIdent	Index of the axis from axisList
axisKey	Key of the axis from axisList
number	Number of the input: <ul style="list-style-type: none"><li>■ No HSCI: I0 to I31</li><li>■ HSCI: All inputs are permitted</li></ul>
set	Status of the input (0/1)



## 6.22.8 Group of drive commands

To select the **Drive Command** function:

- ▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.
- ▶ Press the **HW** soft key.
- ▶ Press the **CC HW Info** soft key.

The screenshot shows the DINplus Editor interface with the 'Maschine' tab selected. The main display area contains a table of drive command data. Below the table, there are several status fields: 'Connected' (IPO), 'IpoCounter' (364988), and 'Ax/Chn-Number' (+0 - +1). A note below these fields reads: 'Use Cursor Up/Down (with or without Ctrl or Alt) to change Ax/Channel-Number'. At the bottom of the interface, there is a 'DrvCmd Data' button and an 'END' button.

MyName	DrvCmdCC422		MyName	DrvCmdCC422	
valid	+1	+0	FromHost[0]	0x0012	0x0000
maxAchszAnz	+4	+0	FromHost[-1]	0x0012	0x0000
			FromHost[-2]	0x0012	0x0000
iAnBusy	+0	+0	FromHost[-3]	0x0012	0x0000
errNumber	0x0000	0x0000	FromHost[-4]	0x001e	0x0000
			FromHost[-5]	0x000a	0x0000
Sender-Id	+0	+0	FromHost[-6]	0x0010	0x0000
cmdState	EMPTY	EMPTY	FromHost[-7]	0x000f	0x0000
			ToHost[0]	0x0012	0x0000
cmdFromHost	0x0012	0x0000	ToHost[-1]	0x0000	0x0000
achsInfoFromHost	0x0004	0x0000	ToHost[-2]	0x0012	0x0000
cmdToHost	0x0012	0x0000	ToHost[-3]	0x0000	0x0000
achsInfoToHost	0x0004	0x0000	ToHost[-4]	0x0012	0x0000
ccuIndexMask	0x0001	0x0000	ToHost[-5]	0x0000	0x0000
axisIdent	+3	+0	ToHost[-6]	0x0012	0x0000
channelNo	+0	+0	ToHost[-7]	0x0000	0x0000

Connected: IPO    IpoCounter: 364988    Ax/Chn-Number: +0 - +1

Use Cursor Up/Down (with or without Ctrl or Alt) to change Ax/Channel-Number


DrvCmd Data    END

## 6.22.9 Auxiliary group

### Enabling debug outputs (Get/Set DebugPrint)

With **Get/Set DebugPrint**, you define the data to be logged and saved in the file r:\runtime\\_Xprint.txt. Data you identify by a "T" will be saved.

Example of a **selection**:



To select the **Get/Set DebugPrint** function:

- ▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.
- ▶ Press the **Auxil** soft key.
- ▶ Press the **Get/Set DebugPrint** soft key for the OLM to open (Get...) the selection list (see figure below).
- ▶ Use the arrow keys to select the data whose identifiers you want to change.
- ▶ Use the **ENT** key to change the identifier (T or F).

The OLM uses the selected data to generate a bit line. The bit line is displayed in the bottom screen line at right. You can also use the bit line in the start batch of the IPO to start the IPO with the Debug Print function.

Meaning of the data:

Variable	Display
parameter	Output of information during parameter assignment. In addition, the parameters for every axis that are sent to the CC are written to the file r:\runtime\_HelpTrace.txt.
referencing	Output of information during reference run
monitoring	Output of information during standstill monitoring and during monitoring of the absolute position (from zero pulse to zero pulse for distance-coded encoders)
axisCommands	Output of internal axis commands
axisValues	Output of information during actual-value transfer
measuring	Output of information on measuring process (probe on/off, monitoring, etc.)
tracePlcIpoMsg	All messages that are sent to the PLC-IPO are written to r:\runtime\_HelpTrace.txt.
initIpoChain	Output during the initialization of the IPO chain
tracelpoMsg	All messages that are sent to the IpoInterpolator are written to r:\runtime\_HelpTrace.txt.
handwheel	Output of information during the configuration and selection of the handwheel
ipoFilter	Output of information during the configuration and selection of two filters in the IPO chain
singleStep	Output of information during graphic simulation in the SingleStep mode of operation
sg	Output of additional information from the safety-oriented package (SG: safety-oriented control)
sglo	Output of additional information from the safety-oriented package
sgPos	Output of additional information from the safety-oriented package
sgCyclic	Output of additional information from the safety-oriented package
spindleCmds	All spindle commands and their acknowledgments are recorded.
EmStopTest	Outputs during the emergency stop test
lpolpoAchse	Output during the configuration of the axes of a channel (exchanging axes in and removing axes from the interpolation context)

Variable	Display
M97-G62-G162	Outputs during the synchronization of several NC channels (not relevant for MANUALplus 620)
AxesRegState	Outputs at status change of axes in the controller
ServerLogin	Log in to / log out of the IpoData server
Graphics	Request of workpiece positions for the on-line graphics and graphic simulation
CC Watchdog	Not used
Threading	Outputs during thread cutting
GAL	Not used
LiftOff	Lift off of tool during cycle stop
AxisPolys	Trace of the distance polynomials (result in file _HelpTrace.txt)
HirthAxis	Outputs during Hirth axis commands
DrvCmdData	Reserved
EthernetAll	Reserved
PathNames	Output of the names of all selected programs and cycles, including the paths
Watchdog	Output of watchdog states (only output once)
EthNet OnOff	Reserved
Terminal	Enable output to serial terminal
GetValues	Output when capturing positions with internal path calculation
Encoder	Reserved
RequestedPos	Output when approaching the restore position

## Reload of trace information

The configuration data for the IPO trace is loaded from the configuration file O:\service\traceInfo.cfg.

To select the **Check AxPar** function:



- ▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



- ▶ Press the **Auxil** soft key.



- ▶ Press the **Reload TraceInfo** soft key for the OLM to load the configuration data.



## Generating error messages (Set Error)

The **Set Error** function generates error messages. You define the error number and the error class.

To select the **Check AxPar** function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



▶ Press the **Auxil** soft key.




▶ Press the **Set Error** soft key for the OLM to open the "Send Error" dialog box (see figure below).

▶ Enter the required data in the dialog box (see below).

▶ Confirm with **OK**—the OLM generates an error message.

"Send Error" dialog box:



The "Send Error" dialog box is a rectangular window with a blue title bar containing the text "Send Error". Inside the window, there are two input fields. The first is labeled "Error-No" and contains the hexadecimal value "99". The second is labeled "Event-Class" and contains the value "9". At the bottom of the dialog box, there are two buttons: "OK" on the left and "ABBRUCH" on the right.

Dialog box entries:

- **Error-No:** Error number (hexadecimal)
- **Event-Class:** Error class

## Generating an asynchronous position compensation (Set PosCorr)

The **Set PosCorr** function generates an asynchronous position compensation (additive compensation). You define the number of the compensation and the compensation values.

To select the **Set PosCorr** function:



- ▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.



- ▶ Press the **Auxil** soft key.



- ▶ Press the **Set PosCorr** soft key for the OLM to open the "Send asynchron Pos-Corr" dialog box (see figure below).
- ▶ Enter the required data in the dialog box (see below).
- ▶ Confirm with **OK**—the OLM generates the compensation.

"Send asynchron Pos-Corr" dialog box:

Send asynchron Pos-Corr	
ID	99
dX	0
dY	0
dZ	0
OK      ABRUCH	

Dialog box entries:

- **ID**: Compensation number
- **dX, dY, dZ**: Compensation values

## Interface test

Interface for DNC mode and WinCast.

To select the function:



▶ Press the **Login Ipo** (or **Login SimIpo**) soft key.




▶ Press the **Auxil** soft key.



▶ Press the **Interface Test** soft key for the OLM to open the dialog box (see figure below).

▶ Set and check the required interface.



## 6.22.10 PLC group

### Displaying the values of the analog-to-digital converter



#### Note

The displayed information is specific to the control and the machine. Refer to the technical documentation to find out which analog values are assigned on your control and the meaning they have.

A/D-converter	Value	Constraint			
Override 1 [0..1]	0.6667				
Override 2 [0..1]	0.6667				
U battery [V]	3.0000	> 2.6000			
U gold-cap [V]	5.0000				
U ref [V]	2.5000				
Temp. HD [°C]	44.9980	< 60.0000			
Temp. CPU 1 [°C]	55.0003	< 70.0000			
Temp. CPU 2 [°C]	65.0026	< 70.0000			
PT100/1 [°C]	0.0000				
PT100/2 [°C]	0.0000				
PT100/3 [°C]	0.0000				
U ana/1 [V]	5.0000				
U ana/2 [V]	5.0000				
U ana/3 [V]	3.3002				
U core 3.3V [V]	3.3000				
Fan speed [rpm]	4300.0000	> 2000.0000			50

Connected IPO IpoCounter 371071 Ax/Chn-Number

AD-WERTE Plc-Trace On-Off Plc-Trace Save END

To select the **AD values** function:



▶ Press the **Login Plc** soft key.



▶ Press the **AD VALUES** soft key.



The function displays the values measured by the analog inputs as well as the permissible limits of some temperature and voltage values:

- **Value** column: Measured values, converted to units used internally by the PLC
- **Raw value** column: Values from the encoder, standardized to 16-bit format
- **Constraint** column: Limit values
- **Sample interval** column: PLC interval during which the value was read (0=simulated value)

Displays:

Variable	Display
ovr1 ovr2	Values of the override potentiometer (* 10000)
battery	Battery voltage (* 1000)
goldCap	"Gold-cap" voltage (* 1000)
caseTemp	Temperature of the control (* 10)
supply5V	5 V supply voltage at the main board (* 1000 / 2)
supply3V	3.3 V supply voltage at the main board (* 1000)
pt100_1 .. pt100_3	Temperature inputs (X48) of the MC (* 10)
u_1 .. u_3	Voltage of the analog inputs (X48) of the MC (* 1000)
tempCpu1	Temperature of CPU 1 (* 10)
tempCpu2	Temperature of CPU 2 (* 10)
caseFan	Fan speed [rpm]



## PLC trace

The PLC trace function saves the PLC modules called and the errors that have occurred during the module call. Depending on the setting of the PLC-TRACE ON-OFF soft key, the following modules are saved:

- **Plc Trace On:** The PLC trace saves all module calls of the real-time thread and the submit/spawn thread.
- **Plc-Trace Off:** The PLC trace saves only module calls that generate an error.

The PLC trace saves the following information for each module call:

- IPO counter
- Module called
- Error number

Press the PLC-TRACE SAVE soft key for the OLM to save the PLC trace data in the file r:\runtime\=APIModCall.txt.

## PLC trace on/off

To define **Plc-Trace On-Off**:



- ▶ Press the **Login Plc** soft key.



- ▶ Press the **Plc-Trace On-Off** soft key for the PLC-trace status to be changed.

## Plc-Trace Save

To select the **Plc-Trace Save** function:



- ▶ Press the **Login Plc** soft key.



- ▶ Press the **Plc-Trace Save** soft key for the PLC trace data to be saved.

## 6.22.11 Queue trace

The Q trace records the messages of the selected queues and saves them in a file.



After the trace function has been selected, the OLM displays the data of the queue at the top of the screen (see figure).



- ▶ Press the **Trace** soft key for the OLM to display the data of a queue.
- ▶ **Cursor Up**: Displays the next queue.
- ▶ **Cursor Down**: Displays the previous queue.
- ▶ **CTRL + Cursor Up**: Scrolls forward in increments of 10.
- ▶ **ALT + Cursor Up**: Scrolls forward in increments of 100.
- ▶ **CTRL + Cursor Down**: Scrolls backward in increments of 10.
- ▶ **ALT + Cursor Down**: Scrolls backward in increments of 100.


## Activating a Q trace

The OLM saves the queues to be traced in a file. Define the entries in this file as follows:



- ▶ Press the **Q-Trace On-Off** soft key for the OLM to open the "trace onoff" dialog box.
- ▶ Enter the required data in the dialog box (see below).
- ▶ Conclude with **OK**.

"trace onoff" dialog box:



Dialog box entries:

- TraceDefNo: Enter the number of the queue (after selecting Trace, you can view details of the queue—see above).
- On/Off: Enter 0 or 1.

## Deleting trace information

When the trace is activated, the data is "appended" to the existing trace file. You can delete the file as follows:



- ▶ Press the **Clear Saved Q** soft key for the OLM to delete the existing trace file.

All entries made after that will be entered into a new file.

## Saving trace information

Select how the Q trace is to save the trace information:



- ▶ Press the **Saved Q On Compact** soft key for the OLM to save the trace information in compact form (single-line).



- ▶ Press the **Saved Q On Pretty** soft key for the OLM to save the trace information in structured form.

## Stopping a Q trace



- ▶ Press the **Saved Q Off** soft key for the OLM to stop the trace.

## "Tipo Command" soft key

The "Tipo Command" function is provided for internal tests.



## 6.22.12 Frequent causes of error

### Servo drive cannot be switched on

The servo drive cannot be switched on or does not move:

- 1 Check whether the drive was enabled by the CC.  
Selection: Login Ipo/Axes/Ipo Act State 1: **ANTRIEB\_FREI** ()  
  
ANTRIEB\_FREI=false: Presumably an error on the CC or a hardware problem
- 2 Check whether "Drive on" was requested by the PLC.  
Selection: Login Ipo/Axes/Plc Nom State: **DriveOnReq** ()  
  
AntriebEin=false: probably error in the PLC program
- 3 Check whether the drive was switched on.  
  
Selection: Login Ipo/Axes/Ipo Act State 1: **ANTRIEB\_EIN** ()  
  
ANTRIEB\_EIN=false: probably IPO internal error
- 4 Check whether position feedback control was requested by the PLC.  
Selection: Login Ipo/Axes/Plc Nom State: **PosCtrlRequest** (does not apply to spindles)  
  
PosCtrlRequest=false: probably error in the PLC program
- 5 Check whether position feedback control is active.  
Selection: Login Ipo/Axes/Ipo Act State 1: **LGR\_AKTIV**
- 6 Check whether "feed rate enable" was set by the PLC.  
Selection: Login Ipo/Axes/Plc Nom State: **VorschubFreigabe**

### Servo drive does not move

The servo drive cannot be switched on or does not move although all enabling commands are available—check the following variables:

- 1 The maximum permissible axis feed rate must be > 0.  
Selection: Login Ipo/Axes/Plc Nom Data: **MaxAchsVorschub**  
  
MaxAchsVorschub = 0: probably an error in the PLC program
- 2 The axis override must be > 0.  
Selection: Login Ipo/Axes/Plc Nom State: **AchsOverride**  
  
AchsOverride = 0: probably error in the PLC program
- 3 The IPO nominal speed must not be equal to 0.  
Selection: Login Ipo/Axes/Ipo Act Data: **absSollV**  
  
absSollV = 0: probably IPO internal error
- 4 The IPO actual speed must not be equal to 0.  
Selection: Login Ipo/Axes/Ipo Act Data: **absIstV**  
  
absIstV = 0: probably IPO internal error



# 7 Machine Interfacing

## 7.1 Display and Operation

The display screen of the MANUALplus 620 is divided into separate windows. The user can select the operating functions by soft key. Please also refer to the User's Manual.

### 7.1.1 Unit of measurement for display and operation

Settings in the configuration editor	MP number
System DisplaySettings CfgUnitOfMeasure <b>unitOfMeasure</b>	101101

**MP\_unitOfMeasure** is evaluated by the following functions or modes of operation:

- Machine display
- Entries in the **Manual Operation, E1. Handwheel** and **Positioning with MDI** operating modes
- Entries in the configuration editor

NC programs have a specific code for the unit of measurement.

- ▶ In **MP\_unitOfMeasure**, you define whether display and operation are in metric or inch mode.

Input or display	metric	inch
Coordinates, linear dimensions, compensation values, etc.	mm	inch
Feed rate (feed rate per minute, feed rate per revolution)	mm/min; mm/rev	inch/min; in./rev
Cutting speed	mm/min	ft/min

Number of decimal places	metric	inch
Coordinates, linear dimensions, etc.	3	4
Compensation values	3	5

### **MP\_unitOfMeasure**

Unit of measure for display and user interface  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **metric**  
Metric measurement system

**inch**

Inches

Default: metric

Access: LEVEL3

Reaction: RUN



## 7.1.2 Conversational language

Settings in the configuration editor	MP number
System	
DisplaySettings	
CfgDisplayLanguage	
<b>ncLanguage</b>	101301
<b>plcDialogLanguage</b>	101302
<b>plcErrorLanguage</b>	101303
<b>helpLanguage</b>	101304

The MANUALplus 620 distinguishes between conversational languages for the following areas:

- NC operation
- PLC operation
- PLC error messages
- Online help

The **path** for the dialog text files is permanently defined. The language abbreviation is at the end of the path. You define the language abbreviation in the parameters of the **CfgDisplayLanguage** object.

- ▶ In the parameter object **CfgDisplayLanguage**, you define the languages you want to use.

These directories are:

%OEM%\PLCLANGUAGE\cs	(Czech)
da	(Danish)
nl	(Dutch)
en	(English)
fi	(Finnish)
fr	(French)
de	(German)
it	(Italian)
pl	(Polish)
pt	(Portuguese)
es	(Spanish)
sv	(Swedish)
hu	(Hungarian)
ru	(Russian)
zh	(Chinese simplified)
zh-tw	(Chinese traditional)

Additional conversational languages (option #41):

sl	(Slovenian)
sk	(Slovak)
lv	(Latvian)
no	(Norwegian)
ko	(Korean)
et	(Estonian)
tr	(Turkish)
ro	(Romanian)
lt	(Lithuanian)

If the dialog text files for the selected language are not on the PLC partition, the error message **LANGUAGE LOAD ERROR** appears. The MANUALplus 620 will then try to open the dialog text file in the directory ".\en" (English).

The **file names** of the dialog text file are the same for all languages. The file names are usually defined in parameters.

- Store the dialog texts you created under the same file name in permanently defined directories.

In **MP\_ncLanguage** you define the end of the path indicating the NC conversational language (language abbreviation).

### **MP\_ncLanguage**

NC conversational language  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **ENGLISH**  
**GERMAN**  
**CZECH**  
**FRENCH**  
**ITALIAN**  
**SPANISH**  
**PORTUGUESE**  
**SWEDISH**  
**DANISH**  
**FINNISH**  
**DUTCH**  
**POLISH**  
**HUNGARIAN**  
**RUSSIAN**  
**CHINESE**  
**CHINESE\_TRAD**  
**SLOVENIAN** (software option #41)  
**SLOVAK** (software option #41)  
**LATVIAN** (software option #41)  
**NORWEGIAN** (software option #41)  
**KOREAN** (software option #41)  
**ESTONIAN** (software option #41)  
**TURKISH** (software option #41)  
**ROMANIAN** (software option #41)  
**LITHUANIAN** (software option #41)

Default: ENGLISH

Access: LEVEL1

Reaction: RUN

In **MP\_plcDialogLanguage** you define the end of the path indicating the PLC conversational language (language abbreviation).



### **MP\_plcDialogLanguage**

PLC conversational language

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: See **MP\_ncLanguage**

Default: ENGLISH

Access: LEVEL1

Reaction: RUN

In **MP\_plcErrorLanguage** you define the end of the path indicating the PLC error messages (language abbreviation).

### **MP\_plcErrorLanguage**

PLC error message language

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: See **MP\_ncLanguage**

Default: ENGLISH

Access: LEVEL1

Reaction: RUN

**MP\_helpLanguage** is used to define the end of the path of the help texts (language abbreviation).

### **MP\_helpLanguage**

Language for online help

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: See **MP\_ncLanguage**

Default: ENGLISH


Access: LEVEL1

Reaction: RUN


### 7.1.3 Expanded menu structure

Settings in the configuration editor	MP number
System DisplaySettings CfgMMISettings <b>extManualMode</b> <b>extProgramMode</b>	604901 604902

Machine parameter **MP\_extManualMode** can be used to expand the menu guidance of the user interface (3x3 menu) in the **Machine** operating mode. The manual cycles are consolidated to the submode MDI, which vacates menu items so that new functions can be assigned to them.



With **MP\_extProgramMode** a horizontal menu is inserted beneath the dashboard in the **Program Run** operating mode in order to enable new functions to be selected. The new functions are described in the User's Manual of the control.





### **MP\_extManualMode**

Enhanced Machine operating mode  
Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **TRUE**  
Enhanced menu guidance in the user interface is active  
**FALSE**  
Enhanced menu guidance in the user interface is inactive

Default: -

Access: LEVEL3

Reaction: NOTHING

### **MP\_extProgramMode**

Enhanced Program Run operating mode  
Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **TRUE**  
Horizontal menu shown in Program Run  
**FALSE**  
Horizontal menu not shown in Program Run

Default: -

Access: LEVEL3

Reaction: NOTHING



## 7.1.4 Access rights to NC files

You can assign access rights to NC programs (\*.nc) and NC subprograms (\*.ncs). If you add an underscore as prefix before the file name (\_\*.nc, \_\*.ncs), then the respective file will not become visible in the **TNC:\nc\_prog\ncps\** directory until the code number 95148 has been entered.

## 7.1.5 Code numbers

### General information

Press the soft key with the key symbol in the **Organization** operating mode in order to enter code numbers. With these code numbers you can activate certain functions.

### Overview

The following code numbers have a fixed meaning:

Code number	Function
0	After access, deletion of the soft keys for the <b>Machine Parameter Programming, Oscilloscope</b> and <b>PLC Programming</b> operating modes.
123	Calls machine parameters that are accessible to the user. Additional enabling of the special function for deleting all tools ("Delete all" soft key) in the tool editor.
1234	PLC user parameters
5555	PLC Parameters
95148	Selects the <b>Machine parameter programming</b> mode of operation. Additional enabling of the input fields "Set axis values" in the menu window for the X and Y axes.
231019	Software update
049866931	Performing software updates during control start-up through the operating system, see "NC software exchange on the MANUALplus 620" on page 137.
531210	Deletes nonvolatile PLC operands, permanently saved data of the PLC run-time system (e.g. feed rate limits) and stops control operation. Then you must restart the control.
654321	OnLine Monitor (OLM)
688379	Oscilloscope
13852	Enables the commissioning tool for analog axes (The soft key for accessing the tool is provided in the startup screen of the internal oscilloscope.)
75368	Adjustment of analog axis offsets
807667	Selects the <b>PLC Programming</b> mode of operation
6871232	Tests the internal EMERGENCY STOP (as of SW02)
857282	Resets the operating times
94655	Selects the special operating mode <b>Current Controller and Field Angle Adjustment</b>
NET123	Ethernet settings
SIK	Opens the menu for enabling software options



## PLC operand

The code of the entered code number is entered in **NP\_GenModCode**. You can evaluate this code and define your own functions for code numbers, or disable fixed code numbers.

PLC operand / Description	Type
NP_GenModCode Code of the code number last entered	D

## Changing HEIDENHAIN code numbers

Settings in the configuration editor	MP number
System Key code CfgChangePassword [Key name = HEIDENHAIN code number] <b>replaceWith</b> <b>hideOriginal</b>	120501 120502

With **CfgChangePassword** you can replace existing HEIDENHAIN code numbers with your own code numbers or passwords.

Proceed as follows if you want to change existing HEIDENHAIN code numbers:

- ▶ Open the configuration editor.
- ▶ Add the optional configuration object **CfgChangePassword** to the machine configuration and confirm with the soft key INSERT
- ▶ As key name, enter the previous HEIDENHAIN code number, e.g. **807667**
- ▶ Indicate a storage file **\*.CFG** for the new parameters.
- ▶ In **MP\_replaceWith**, enter a new code number with which you want to replace the existing HEIDENHAIN code number. The new password can consist of numbers and/or capital letters.



### Note

In the MOD dialog for code number input, any small letters entered are automatically converted to capital letters.

The letters in **MP\_replaceWith** must therefore be entered as capitals.

- ▶ With **MP\_hideOriginal**, define whether the previous HEIDENHAIN code number remains effective or is deactivated



#### Warning

If you set **MP\_hideOriginal** = TRUE, then if the new code number is lost, only HEIDENHAIN service personnel can restore the previous HEIDENHAIN code number.

Protect the new code number from loss!

- ▶ Save your changes with the SAVE soft key.
- ▶ The new code number is immediately effective.

#### **MP\_replaceWith**

New OEM password or code number  
Available from NCK software version: 597 110-05.

Format: String  
Input: Max. 18 characters  
Numerals and/or capital letters  
The HEIDENHAIN password indicated in the key name is replaced by the new OEM password defined here.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

#### **MP\_hideOriginal**

Lock previous HEIDENHAIN code number  
Available from NCK software version: 597 110-05.

Format: Selection menu  
Selection: **TRUE**  
The previous HEIDENHAIN code number is disabled.  
**FALSE**  
The previous HEIDENHAIN code number remains in effect.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING



## 7.1.6 Programming station mode

Settings in the configuration editor	MP number
System	
CfgMachineSimul	
<b>simMode</b>	100201
<b>skipReferencing</b>	100202
<b>skipEmStopTest</b>	100203
<b>simHardwareType</b>	100204

You can switch the MANUALplus 620 into a programming station mode with **MP\_simMode**. This way the control can be used as a simple programming station. No drives are enabled. You can create and test NC programs. The operation of the machine is simulated in the programming station mode. As OEM, you have access to the machine configuration in the programming station mode. This enables you to adapt the MANUALplus 620 to the machine before actual commissioning.

The **MP\_simMode** parameter offers four different setting possibilities for the programming station mode:

If **FullOperation** is set, the MANUALplus 620 starts in normal operation. The programming station mode is deactivated. All drives and the PLC are active.

Choose the **CcOnly** setting in order to simulate the CC controller unit while the PLC is active. In this case all PLC inputs and outputs, as well as the emergency-stop loop (X41/34 and X42/4), must already be connected correctly in order to switch the MANUALplus 620 on correctly. As of NCK software level 597 110-04, analog values are only simulated and are no longer output if axes are moving.



### Danger

With the **CcOnly** setting, all axes are automatically switched to test mode. Hanging axes are not braked in test mode.

#### **Hanging axes need 100 % weight compensation.**

Ensure that hanging axes are adequately supported.

Choose **CcAndExt** in order to simulate the CC controller unit and all PLC inputs and outputs. The PLC runs in simulation mode, and the emergency-stop loop and PLC inputs and outputs are not interrogated.

If **Delivery** is set, all axes are set to the test mode during startup of the MANUALplus 620, and a switch-on of the axes is prevented. The user should then be able to start the control, even with an incomplete or faulty axis configuration in order to put the axes into operation. After the configuration of all axes has been completed, the control can be switched to full operation (FullOperation).

The MANUALplus 620 must be restarted after changes in **MP\_simMode** in order for the new settings to become active.

## MP\_simMode

Specify the type of programming station mode  
Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **FullOperation**

Programming station mode is switched off, the emergency-stop loop (X41/34 and X42/4) must be complete. The drives are moved.

### **CcOnly**

Simulation of the CC controller unit. All PLC inputs and outputs, as well as the emergency-stop circuit, must be connected correctly in order to switch the control on correctly.

### **CcAndExt**

Simulation of the CC controller unit and all PLC inputs and outputs. The emergency-stop loop does not need to be complete. The PLC runs in simulation mode.

### **Delivery**

Mode for commissioning.

During power-up, all axes are automatically put into the test mode. The drives cannot be switched on. In this way, the control can be started even with an incomplete or faulty axis configuration.

Default: FullOperation

Access: LEVEL3

Reaction: RESET

Traversing the reference position of the axes can be skipped in programming station mode.

Set the **MP\_skipReferencing** parameter to the value TRUE in order to set the axes directly on the reference position when the control is started.

## MP\_skipReferencing

Fast reference run

Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **FALSE**

The axes are not set on the reference position.

### **TRUE**

The axes are set directly on the reference position when the control is started.

Default: FALSE

Access: LEVEL3

Reaction: RESET

You can suppress the emergency-stop test with the **MP\_skipEmStopTest** parameter.

### **MP\_skipEmStopTest**

No emergency-stop test is performed  
Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **TRUE**  
Emergency-stop test is not performed  
**FALSE**  
Emergency-stop test is performed

Default: FALSE

Access: LEVEL3

Reaction: RESET

On the MANUALplus 620, transferring configuration data from a machine with a CC 61xx (HSCI) to a programming station can lead to errors concerning Ipo/Simulation (e.g. position encoder / speed encoder / PWM assignment does not match the simulated default setting of the CC 422). In the **MP\_simHardwareType** parameter, you can therefore specify the CC type to be simulated in Programming Station mode. If this machine parameter is defined, it has priority over **MP\_hardwareType** in CfgHardware.

### **MP\_simHardwareType**

Controller unit to be simulated in Programming Station mode  
Available from NCK software version: 597 110-05.

Format: Selection menu

Selection: **automatic**  
Automatic identification of controller unit  
**CC 422**  
CC 422 controller unit for conventional axes  
**CC 424**  
CC 424 controller unit for direct drives with high control loop requirements (very short cycle times)  
**CC 61xx**  
CC 61xx or UEC 11x controller unit with HSCI interfaces  
**NoCC**  
No controller unit

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

## 7.1.7 Operating modes / control operation in the operating mode group

### Operating modes



#### Note

All machining channels of an operating mode group have the same operating mode.

The symbolic PLC operands available depend on the control model. Under certain circumstances not all operands listed in the following table may be available on your control.

In the following PLC operands, the NC informs the PLC of the current operating mode of an operating mode group:

PLC operand / Description	Type
NN_OmgManual Manual Operation operating mode 0: Operating mode not active 1: Operating mode active	M
NN_OmgHandwheel Electronic Handwheel operating mode 0: Operating mode not active 1: Operating mode active	M
NN_OmgMdi Positioning with Manual Data Input operating mode 0: Operating mode not active 1: Operating mode active	M
NN_OmgProgramSingle Program Run, Single Block operating mode 0: Operating mode not active 1: Operating mode active	M
NN_OmgProgramRun Program Run, Full Sequence operating mode 0: Operating mode not active 1: Operating mode active	M
NN_OmgReference Reference operating mode 0: Operating mode not active 1: Operating mode active	M
NN_OmgJogIncrement Incremental Jog operating mode 0: Operating mode not active 1: Operating mode active	M





PLC operand / Description	Type
<p>NN_OmgAuxiliaryMode</p> <p>Product-specific code for special modes and submodes</p> <p>101: Cycle in preparation If a program was selected but not yet started with Cycle ON (e.g. an M function is run in manual control)</p> <p>102: Reference in preparation If the axis to be referenced is selected but the reference run has not yet been started</p> <p>103: Single block in preparation If a program was selected and SINGLE BLOCK is active but has not yet been started with Cycle ON</p> <p>104: Continuous mode in preparation If a program was selected and CONTINUOUS is active but has not yet been started with Cycle ON</p> <p>105: Single block, continuous in preparation If a program was selected and SINGLE BLOCK and CONTINUOUS are active, but has not yet been started with Cycle ON</p> <p>106: Measuring in preparation If in the "Measure the tool" overview the "Touch probe" soft key was pressed but the measuring cycle was not yet started</p> <p>201: Teach-in Teach-In operating mode and cycle is started</p> <p>202: Single cycle If, for example, in manual control mode an M function is run.</p> <p>203: Single program If a single cycle is started</p> <p>204: Program cycle ON and continuous mode If a single cycle is started and CONTINUOUS is set</p>	D

## Disabling operating modes

PLC Module 9285 "Set the access level" can be used to disable operating modes and write-access to files.

### Module 9285 Set the access level

PLC Module 9285 locks/enables the following predefined functions. If the bit is set in the mask, the function is locked. If the bit is set to 0, the function is enabled:

Group 0: Disabling operating modes	Bit mask	MANUALplus 620
Manual Operation operating mode	0x01	Machine operating mode Disabling function in the main menu (9-item menu): - Setup - TSF menu
Electronic Handwheel operating mode	0x02	Function not available
Positioning with Manual Data Input operating mode	0x04	Machine operating mode Disabling function in the main menu (9-item menu): - Single paths - MDI cycles - Manual programs - DIN macros - M functions
Program Run, Single Block operating mode	0x08	Machine operating mode Disable the Program Run soft key
Program Run, Full Sequence operating mode	0x10	Machine operating mode Disable the Program Run soft key
smarT.NC operating mode	0x20	smart.Turn / Teach-In operating mode Disable editing



<b>Group 1: Disabling write-access to files</b>	<b>Bit mask</b>	<b>MANUALplus 620</b>
NC programs (* .H, * .I, * .HU, * .HP, * .HC, * .DXF)	0x01	Disable write-access rights smart.Turn: * .nc, * .ncs Teach-In: * .gmz ICP: * .gm*
Tool table	0x02	Tool Editor operating mode Disable editing
Pocket table	0x04	Machine operating mode Disable editing
Preset table	0x08	Machine operating mode Disable setting up datums
Pallet table	0x10	Function not available

<b>Group 2: Disabling other functions</b>	<b>Bit mask</b>	<b>MANUALplus 620</b>
Manual probing	0x01	Machine operating mode Disable the "Tool measurement" soft key
Code numbers	0x02	Organization operating mode Disable the code number input

Call:

PS B/W/D/K <Group number>  
0: Disable operating modes  
1: Disable write-access to tables  
2: Disable other functions

PS B/W/D/K/S<Bit mask>

CM 9285

PL B/W/D <Status>

0: Function performed  
1: Illegal group number  
2: Incorrect parameterization via bit mask  
20: Module was not called in a spawn job or submit job

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Function performed
	1	Error code in W1022
NN_GenApiModule ErrorCode (W1022)	1	Invalid group number
	2	Invalid value for bit mask
	20	Module was not called in a spawn job or submit job

**Start/stop of the  
machining channels**

With the following PLC operands, the PLC informs the NC of the start or stop status:

PLC operand / Description	Type
PP_OmgNcStart NC start for all machining channels of this operating mode group 0: NC start not active 1: NC start active	M
PP_OmgNcStop NC stop for all machining channels of this operating mode group 0: NC stop not active 1: NC stop active	M

## 7.1.8 Control operation in the machining channel

### NC program run

Settings in the configuration editor	MP number
Channels ChannelSettings [Key name of the machining channel] CfgChannelFile <b>geolNiProgram</b> <b>geoCycleEnd</b> <b>geoCancelCycle</b>	   200402 200405 200406
System Paths CfgSystemCycle [Key name of the OEM system cycle] <b>path</b>	   102601



#### Note

The machine parameters described below (**MP\_geolNiProgram**, **MP\_geoCycleEnd**, etc.) of the **CfgChannelFile** config object are not evaluated by the TNC 620.

### Starting an NC program

The PLC executes an NC start with **PP\_ChnNcStart**.

PLC operand / Description	Type
PP_ChnNcStart NC start or cycle on 0: NC start not active 1: NC start active	M

With **NN\_ChnNcStartExternRequest**, the NC asks the PLC to initiate an NC start. The PLC then uses **PP\_ChnNcStart** to activate the NC start.

PLC operand / Description	Type
NN_ChnNcStartExternRequest External request for an NC start 0: External NC start not requested 1: External NC start requested	M



Before running the actual NC program, the NC first starts the program defined in **MP\_geolniProgram**, and then the OEM program defined in **MP\_Path**.

The NC program is executed immediately after the lead programs.

**MP\_geolniProgram**

Path and name of the lead program  
 Available from NCK software version: 597 110-01.  
 Format: String  
 Input: Path and name of the lead program  
 No entry: No lead program is executed.  
 Default: **%SYS%\jhcyc\sys\nc\iniprogram.h**  
 Access: LEVEL3  
 Reaction: RESET

**MP\_path**

Path and name of the OEM lead program  
 Available from NCK software version: 597 110-01.  
 Format: String  
 Input: Path and name of the OEM lead program  
 No entry: No OEM lead program is executed.  
 Default: –  
 Access: LEVEL3  
 Reaction: RUN

**Terminating the NC program**

In **NN\_ChnProgEnd** the NC informs the PLC that an NC stop was executed because the program end has been reached.

PLC operand / Description	Type
NN_ChnProgEnd End of NC program reached A "program end" command was executed (END PGM, M02 or M30). 0: End of NC program not reached 1: End of NC program reached	M

After the NC program has been run, the NC starts the program defined in **MP\_geoCycleEnd**. The trailer program is executed immediately after the NC program.

**MP\_geoCycleEnd**

Path/name of the trailer program for program end  
 Available from NCK software version: 597 110-01.  
 Format: String  
 Input: Path and name of the trailer program  
 No entry: No trailer program is executed.  
 Default: **%SYS%\jhcyc\sys\nc\progend.h**  
 Access: LEVEL3  
 Reaction: RESET



## Interrupting an NC program

The PLC or NC can stop execution of the NC program. After interruption, the NC program is continued.

During program interruption, the axes can be traversed manually.

### PLC stops NC program run:

The PLC executes an NC stop with **PP\_ChnNcStop**.

PLC operand / Description	Type
PP_ChnNCStop NC stop or cycle off 0: NC stop not active 1: NC stop active	M

### NC stops NC program run:

The NC uses the following markers to inform the PLC of NC program interruption and the reason for the interruption:

- **NN\_ChNStopExtern:** The program was interrupted because of an external request (e.g. Stop key).
- **NN\_ChNProgStopped:** The program was interrupted because of a program stop (M0), the end of a block in Single block mode, etc.
- **NN\_ChNProgStoppedAsync:** The program interruption was caused by an error, etc.

PLC operand / Description	Type
NN_ChNcStopExtern NC stop or Cycle off NC stop is executed by the NC. 0: NC stop not executed 1: NC stop was executed by the NC	M
NN_ChNProgStopped NC program interruption The NC reports an asynchronous program interruption, such as at the end of a block in Single Block mode, M0, etc. 0: No NC program interruption 1: NC program interruption	M
NN_ChNProgStoppedAsync Asynchronous NC program interruption The NC reports an asynchronous program interruption, for example because of an error, etc. 0: No asynchronous NC program interruption 1: Asynchronous NC program interruption	M

## Moving the axes during program interruption

During program interruption, the NC distinguishes between "manual traverse of the axes" and "returning to the contour." The NC indicates the status in the following markers:

PLC operand / Description	Type
NN_ChNProgManTraverse Manual traverse of the axes active (for lathes: inspection operation) 0: Manual traverse not active 1: Manual traverse active	M
NN_ChNProgReturnContour Return to contour active (after manual traverse or block scan) 0: Return to contour is not active 1: Manual traverse active	M

## Canceling an NC program

In **NN\_ChNProgCancel**, the NC informs the PLC of a program cancelation.

PLC operand / Description	Type
NN_ChNProgCancel NC program cancelation NC program canceled because of an internal stop 0: No NC program cancelation 1: NC program cancelation	M

After the NC program has been canceled, the NC starts the program defined in **MP\_geoCancelCycle**. The trailer program is executed immediately after the NC program has been canceled.

### MP\_geoCancelCycle

Path/name of the trailer program for program cancelation  
 Available from NCK software version: 597 110-01.

Format: String

Input: Path and name of the trailer program  
 No entry: No trailer program is executed.

Default: **%SYS%\jhcyc\sys\nc\cancelcyc.h**

Access: LEVEL3

Reaction: RESET





**Block scan  
(mid-program  
startup)**

<b>PLC operand / Description</b>	<b>Type</b>
NN_ChnBlockScan Mid-program startup (or block scan) active 0: Block scan not active 1: Block scan active	M
NN_ChnBlockScanStrobeTransfer Restore status at block scan (M/S/T/Q transfer) 0: Status not restored 1: Status restored	M

The PLC operand **NN\_ChnBlockScan** is set when a start block is selected and the Cycle Start key is pressed. After the start block has been reached, the signal is reset.

If the Cycle Start key is pressed again, the signal **NN\_ChnBlockScanStrobeTransfer** is set and all strobes collected during the block scan are executed by the control.

After the last strobe signal has been acknowledged, **NN\_ChnBlockScanStrobeTransfer** is also reset to zero. This falling edge indicates to the PLC that the control is in a state that corresponds to the start block status.

All data relevant to the PLC has been processed, and therefore the NC program can be started.

## Finding the NC program and block number

### Module 9321 Find the current block number

Prefer Module 9322 to evaluate the NC program!

Module 9321 finds the current block number of the active NC program.

Constraints:

- Before an NC program is run for the first time, -1 is set as block number. For all traverse blocks that are not generated from an NC program, a cycle or an NC macro (e.g. PLC positioning, return-to-contour logic), -1 is set as block number.
- After the NC program is canceled or after the end of the NC program, the last block number executed is returned.

Call:

PS B/W/D/K <String number>

CM 9321

PL B/W/D <Current block number>

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Block number has been found
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid string number

### Module 9322 Information of the current NC program

The module supplies information about the execution of the current NC program.

When called in the cyclic program part, only the current block number is read. When called from a spawn or submit job, the current block number and the name of the current NC program, subprogram or cycle (depending on the setting) are determined.

Constraints:

- Because of the geometry look-ahead, the call from the cyclic PLC program only supplies the block number in real time, but no information about the NC program.
- Call from the cyclic PLC program:  
For all traverse blocks that are not generated from an NC program, a cycle or an NC macro, block number -1 is read.
- Call from the cyclic PLC program:  
After the NC program is canceled or after the end of the NC program, the last block number executed is returned.



Call:

PS B/W/D/K <Mode>

When called from a cyclic PLC program, the <Mode> setting is omitted. The block number of the active NC program is always returned.

When called from a spawn job or submit job:

0: String / block number and path refer only to the active NC (sub)program. Block number from block scan.

1: String / block number and path refer only to the active NC (sub)program or cycle. Block number from block scan.

2: Only the name of the NC main program without information about the block number; block number is set to 0 when executed correctly.

PS B/W/D/K <String number for path of the NC program or cycle>

Call from a cyclic PLC program: Without effect.

CM 9322

PL B/W/D <Block number>

-1: Error if error marker is set

-1: Block number in certain cases, if call was from a cyclic PLC program

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Successful execution of module
	1	Error. See NN_GenApiModuleError
NN_GenApiModule ErrorCode	1	Invalid mode programmed
	2	Invalid string number programmed
	12	Path name is longer than PLC string
	13	Internal error
	20	Module was not started from a spawn or submit job

## Interrogating the status of the NC program

### Module 9429 Interrogate the status of the executed NC program

Use Module 9429 to interrogate the status of an NC program executed in an NC channel.

Possible errors:

- The entered channel number is invalid
- The entered mode is invalid
- The entered string number is invalid

Call:

```
PS   B/W/D/K <Number of the NC channel>
PS   B/W/D   <String number: Path name>
PS   B/W/D/K <Mode>
      0: Do not return a path name
      1: Return the path name of the main program
      2: Return the path name of the displayed program
      3: Return the path name of the executed program

CM   9429
PL   B/W/D   <Status>
      0: NC program is being run
      1: NC program run is interrupted
      2: NC program run has completed

PL   B/W/D   <Substatus>
      < of status 0: NC program is being run >
        0: Program not started yet
        1: Program with external start is being run
        2: Program with internal start is being run
        3: System cycle is being run

      < of status 1: NC program run is interrupted >
        0: Interruption due to external stop, silent emergency
          stop, error with "Stop" reaction
        1: Interruption due to programmed stop
        2 : Interruption at block end in the "Program Run, Single
          Block" operating mode
        3: Interruption at end of the dry run
      < of status 2: NC program run has completed >
        0 : NC program run completed normally (M02 or
          END_PGM)
        1: NC program run completely canceled by operator
        2: NC program run canceled by operator
        3: NC program run canceled by error with reaction
          "Cancel"
        4: NC program run canceled by emergency stop
        5: NC program run canceled by programmed error
        6: NC program run canceled due to program error

PL   B/W/D   <Block number of the displayed NC program>
PL   B/W/D   <Help number, not yet supported>
```



### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Information provided
	1	No information available; for error, see NN_GenApiModuleError
NN_GenApiModule ErrorCode	1	The entered channel number is invalid
	2	The entered mode is invalid
	3	The entered string number is invalid

### Control in operation

In the **Positioning with Manual Data Input, Program Run, Single Block** and **Program Run, Full Sequence** operating modes, the NC uses **NN\_ChnControllnOperation** to inform the PLC that the control is in operation. The status "control in operation" applies when the NC is executing a program, an M function or an axis movement.

**NN\_ChnControllnOperation** is also set if the NC is processing a macro (cycle) in the background.

This applies to the following situations:

- Program selection
- Leaving the **Positioning with Manual Data Input** operating mode
- Control start-up (execution of the start-up cycle)
- When running cycles in the **Positioning with Manual Data Input** operating mode (the control-in-operation symbol is shown on the screen), e.g. while entering M functions or setting a datum.

PLC operand / Description	Type
NN_ChnControllnOperation Control is in operation 0: Control not in operation 1: Control in operation	M

**M, S or T function in parallel with traverse motion**

The PLC can execute M, S or T functions in parallel with the movement programmed in the same NC block.

**Module 9404 Start movement while there is an NC strobe**

The module starts the movement programmed in an NC block when a strobe that is effective at the beginning of the same NC block is still present.

- Do not execute the module in a submit job or spawn process.

Call:

PS B/W/D/K <Channel number>

CM 9404

PL B/W/D <Error number>

0: Successful

1: Invalid channel number

15: Module was called in a submit job or spawn process

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error	0	Movement successfully started
	1	Process not possible
NN_GenApiModule ErrorCode	1	An invalid channel number was transferred
	2	Processing of NC part program is not synchronized
	24	The module was called in a submit job or spawn process



**Error status**

The NC informs the PLC of errors occurring in this machining channel. The PLC operands are used to distinguish between the reactions to errors (see "PET table (PLC error table)" on page 1268).

<b>PLC operand / Description</b>	<b>Type</b>
NN_ChnErrorWarning Error or warning occurred 0: No error or warning occurred 1: NC error or warning occurred	M
NN_ChnErrorFStop Feed rate stopped because of an error 0: No feed stop triggered 1: Feed stop triggered	M
NN_ChnErrorNCStop NC stop because of an error 0: No NC stop triggered 1: NC stop triggered	M
NN_ChnErrorCancel Program canceled because of an error 0: No program cancelation 1: Program cancelation triggered	M
NN_ChnErrorEmergencyStop Emergency stop triggered because of an error 0: No emergency stop triggered 1: Emergency stop triggered	M
NN_ChnErrorReset Reset because of an error 0: No reset 1: Reset triggered	M

**NN\_ChnErrorReset** is not used at present because the PLC program stops when a reset error occurs.

## Assignments in Manual modes of operation

In the manual operating modes, the peripheral user devices, such as the monitor or keyboard unit, are assigned to a machining channel and a spindle. The machining channel is specified in the PLC operands **NN\_GenOmgManual** and **NN\_GenChnManual**, and the spindle in **NN\_GenSpiManual**.

The machining channel and the spindle are selected specifically for each control.

PLC operand / Description	Type
NN_GenOmgManual Selected operating mode group in manual operation	D
NN_GenChnManual Selected machining channel in manual operation	D
NN_GenSpiManual Selected spindle in manual operation	D

## Asynchronous position compensation (additive compensation)

Settings in the configuration editor	MP number
System CfgPosCorrection <b>enable</b> <b>feed</b>	100501 100502

The control supports asynchronous compensation. Asynchronous means that compensation values are entered during machining.

The control supports:

- Asynchronous tool compensation: This compensation is assigned to a tool, and corrects the tool lengths. The asynchronous tool compensation is cleared during a tool change.
- Asynchronous position compensation: This type of compensation, also known as additive compensation, is managed independently of channels in tables, and is activated and deactivated via G command (G914). An asynchronous position compensation is in effect until it is deactivated or until the end of the program.

For compensation value tables for asynchronous position compensation, see MP\_System/Paths/CfgTablePath/Add\_Cor\*/path (\*=1: machining channel 1; \*=2: machining channel 2; etc.)

If an asynchronous compensation is activated, deactivated or changed, then it is "corrected" with the velocity defined in MP\_feed.



MP\_enable is used to specify whether asynchronous compensations are calculated in the interpolator or already before the interpolator. If **MP\_enable** = Off, the compensations are taken into account during interpretation of the NC program. Due to the large block scan required, it takes a certain amount of time for the compensations to take effect. As an alternative you can define **MP\_enable** = On. The interpolator then takes the compensations into account. This speeds up the reaction time, but the processing effort necessary by the interpolator is increased considerably.

- ▶ Define **MP\_enable** = On if you require a quick reaction time for asynchronous compensations. If this is not required, or if there is no asynchronous compensation, then the **MP\_enable** = Off setting is recommended.
- ▶ In **MP\_feed**, define the velocity at which asynchronous compensations are corrected.

### **MP\_enable**

Asynchronous position compensation on/off  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: **On**  
Switch asynchronous position compensation on  
**Off**  
Switch asynchronous position compensation off  
Default: Off  
Access: LEVEL3  
Reaction: RUN

### **MP\_feed**

Velocity for asynchronous position compensation  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 000 000 to 99 960 [mm/min]  
Default: 960  
Access: LEVEL3  
Reaction: RUN

## 7.1.9 Error messages and log files

The control displays errors in the header of the screen. Long error messages or error messages extending over more than one line are abbreviated. The complete information on all pending error messages is given in the error window.

Errors and system information (system start, system end, etc.) are entered in the error log file. The control saves every keystroke and the mouse events in the keystroke log file.

### Error window




► Press the ERR key to call the error window

The error window contains the details of all errors that have occurred (see figure below, framed area).

To obtain information on the cause of error and the corrective action, proceed as follows (see figure):




► Press the **Info** soft key



For further details regarding the software's internal error data, such as date, time, event class, line of the NC program, control program reporting the error, etc., proceed as follows (see figure):

DETAILS

► Press the **Details** soft key



## Deleting errors

To delete an individual error:

► Position the cursor on the entry to be deleted

DELETE

► Press the **Delete** soft key.

To delete all errors contained in the error window:

DELETE ALL

► Press the **Delete all** soft key.

Information provided by the **error message**:

- Error number: Assigned by HEIDENHAIN or the machine tool builder
- Error class: Defines the control's reaction to this error (see table)
- Error text: Describes the error (in one or more lines). If the error occurs while an NC program is running, the line of the NC program will also be indicated.

Overview of error handling in the control:

<b>Error class</b>	<b>Reaction</b>	<b>Display</b>	<b>Log file entry</b>	<b>Acknowledgment</b>	<b>Error group</b>
Ev_class_2	None	x			Warning
Ev_class_3	None		x		Warning
Ev_class_4	None	x	x		Warning
Ev_class_5	None	x	x	x	Errors
Ev_class_6	Feed stop	x	x	x	Errors
Ev_class_7	Program abortion	x	x	x	Errors
Ev_class_8	Program aborts at stable position	x	x	x	Errors
Ev_class_9	Emergency stop	x	x	x	Errors
Ev_class_10	Reset	x	x	x	System error
Ev_class_11	NC stop	x	x		Errors
Ev_class_12	NC stop	x	x	x	Errors
Ev_class_13	Program abortion	x	x		Errors
Ev_class_14	Reset – without output of error text ("Processor check error")	x	x	x	System error
Ev_class_15	Feed stop	x	x		Errors
Ev_class_16	Emergency stop	x	x		Errors
Ev_class_17	Display informational text	x	x		Info
Ev_class_18	None	x	x		Warning
Ev_class_19	Program abortion	x	x	x	Errors

Ev\_class\_18 is used to report that service files were saved.



## Error log file

The control saves all errors that occurred and the error information, including all details, in the error log file (see figure).


To call the error log file:



▶ Press the **Log** soft key



▶ Press the **Error log** soft key.



The screenshot shows a software interface for viewing error logs. At the top, there are tabs for "Machine", "smart.Turn", "Tool editor", and "Machine par.". Below the tabs, the text "Invalid text source" is displayed. The main area contains a log window with the following text:

```
//***** SYSTEM START  Date: 26.02.2008  Time: 9:54:35,851  *****//  
Event: 140-0032  Class: 3  Client: Server/cfgserver.CfgServerQueue  
Date: 26.02.2008  Time: 9:54:40,757  < 3.635537s >  
Text: Incorrect software version  
additional text: Test version for HEIDENHAIN internal uses only  
SourceFile: .\server\cfgaccessprotection.cpp  Line: 1246  
ThreadName: Server/cfgserver.cfgserver  
Channel:  OMG:  
  
//***** PRODUCT:  MANUALplus  C_MANPLUS_HSCI_435  *****//  
//***** KERNEL:  NC-KERNEL  C_NCK_HSCI_435  *****//  
  
Event: 320-0012  Class: 3  Client: Nc/plc.Q_PLC_FRONTSTAGE  
Date: 26.02.2008  Time: 9:55:12,460  < 35.328924s >  
Text: Konfigurationsdatum CfgPlcOverrideF - CH_SIM1  
enthält Fehler  
additional text: CfgPlcOverrideF, CH_SIM1,  
CfgPlcOverrideF(key="CH_SIM1",minimal:=0,maximal:=1.5,source="PotentiometerF")  
SourceFile: .\FunctionalControl\PlcConfiguration.cpp  Line: 221  
ThreadName: Nc/plc.plc  
Channel:  OMG:
```

On the right side of the log window, there are several control buttons: a green square with a white arrow, a red square with a white exclamation mark, "END PGM OFF" with a red circle and arrow, "M07 OFF" with a yellow pencil icon, "M08 OFF" with a yellow faucet icon, and a yellow bar with a blue arrow. At the bottom of the interface, there is a navigation bar with buttons: "Beginning" (up arrow), "End" (down arrow), "FIND", "Previous file", "Current file" (highlighted in blue), "Filter on/off", "Filter definition", and "Back".

### Moving within the log file:



To the oldest entry:

- ▶ Press the **BEGIN** soft key.



To the most recent entry:

- ▶ Press the **END** soft key.

To view other log file entries:

- ▶ Move using the arrow keys (up arrow, down arrow, page up, page down)

### To find a log file entry:



To call the "Find" dialog box:

- ▶ Press the **FIND** soft key.



- ▶ Enter the search string
- ▶ Define the search direction

## Current and previous error log file

The error log file uses two files, the **current file** and the **previous file**.

If the current file is full, the control switches the files. After converting the current file to the previous file, the control creates a new current file.

To switch between the current and the previous error log file:



▶ Press the **PREVIOUS FILE** soft key.



▶ Press the **CURRENT FILE** soft key.

## Filter

Use a filter to limit the log file display to the following error groups:

- Information
- Warnings
- Errors
- System errors

In addition, you can select the following information:

- Date and time from which you want the log file contents to be displayed.
- Clients whose errors and error information are to be considered in the log file display.

Whether the **filter is taken into account** depends upon the setting of the **FILTER ON/OFF** soft key:



▶ Soft key active: Filter is taken into account

▶ Soft key not active: Filter is not taken into account

## To set the filter:

Filter  
definition

- ▶ Press the **Filter Definition** soft key

INFOS

To display information:

- ▶ Press the **INFOS** soft key

WARNINGS

To display warnings:

- ▶ Press the **WARNINGS** soft key

ERRORS

To display errors:

- ▶ Press the **ERRORS** soft key.

SYSTEM  
ERRORS

To display system errors:


- ▶ Press the **SYSTEM ERRORS** soft key.

To set the client and/or date and time:

FURTHER  
FILTER  
FUNCTIONS

Call the "Filter functions" dialog box

- ▶ Press the **FURTHER FILTER FUNCTIONS** soft key



- ▶ Enter the client and/or date and time
- ▶ Conclude with **OK**.

To **display** the **log file** under consideration of the new filter settings (prerequisite: the **Filter on/off** soft key is on):

UPDATE

- ▶ Press the **ACTIVATE FILTER** soft key.




## Keystroke log file

The control saves all keystrokes and mouse events that occurred in the keystroke log file (see figure).


To call the keystroke log file from within the error system:



- ▶ Press the **LOG FILE** soft key.
- ▶ Press the **KEYSTROKE LOG FILE** soft key.



### Moving within the log file:



- To move to the oldest entry:
  - ▶ Press the **BEGINNING** soft key.
- To move to the most recent entry:
  - ▶ Press the **END** soft key.

To view other log file entries:

- ▶ Move using the arrow keys (up arrow, down arrow, page up, page down)




### To find a log file entry:



To call the "Find" dialog box:

- ▶ Press the **FIND** soft key.



- ▶ Enter the search string
- ▶ Define the search direction

### Current and previous keystroke log file

The keystroke log file uses two files, the **current file** and the **previous file**:

If the current file is full, the control switches the files. The current file is converted to the previous file and the previous file to the current file. The contents of the previous file are deleted before new entries are made.

To switch between the current and the previous error log file:



- ▶ Press the **PREVIOUS FILE** soft key.



- ▶ Press the **CURRENT FILE** soft key.

## Log

The accumulated keystrokes are now stored simultaneously with the control events in the log and are displayed in table view (see figure).

In order to be able to track machine operation or machine conditions systematically, detailed additional information is entered and stored simultaneously with all important log entries, such as keystrokes, errors, system errors or warnings.

At least 4 weeks of control operation can be recorded with the log. The data is saved on the SYS partition and therefore cannot be changed by the user or OEM.

The log can be read with the programs TeleService or TNCremoNT and is part of the service files.


To call the log from within the error system:

Logfile

▶ Press the **Log** soft key

LOGBUCH

▶ Press the **LOG** soft key.



The screenshot shows the TNCremoNT log viewer interface. At the top, there are tabs for 'Machine', 'smart.Turn', and 'Tool editor'. The main area displays a table of log entries with columns for 'Type', 'Description', 'Source', and 'Time'. The table contains various entries, including system start messages, product and kernel information, and error/warning messages such as '206 Machine guard is open!', 'Relay ext. dc voltage missing', and '207 Door test'. A 'Filter on/off' button is visible at the bottom right of the table area. On the right side of the interface, there are several control buttons, including 'END PGM', 'OFF', and 'ON'.

Type	Description	Source	Time
1875	***** PRODUCT: MANUALplus 5...		
1876	***** KERNEL: NC-Kernel 597...		
1877	206 Machine guard is open !	Nc/plc.QPlc...	08:56:19 2010...
1878	Relay ext. dc voltage missing	Nc/IPO.QDri...	08:56:19 2010...
1879	207 Door test	Nc/plc.QPlc...	08:56:19 2010...
1880	Ipo-Trace stopped	Nc/IPO.QKan...	08:59:09 2010...
1881	Ipo-Trace stopped	Nc/IPO.QKan...	09:52:08 2010...
1882	External emergency stop	Nc/IPO.QKan...	11:07:23 2010...
1883	206 Machine guard is open !	Nc/plc.QPlc...	11:07:23 2010...
1884	207 Door test	Nc/plc.QPlc...	11:07:23 2010...
1885	***** SYSTEM START Date: 14.10...		10:52:54 2010...
1886	***** PRODUCT: MANUALplus 5...		
1887	***** KERNEL: NC-Kernel 597...		
1888	Relay ext. dc voltage missing	Nc/IPO.QDri...	10:53:29 2010...
1889	206 Machine guard is open !	Nc/plc.QPlc...	10:53:29 2010...
1890	207 Door test	Nc/plc.QPlc...	10:53:29 2010...
1891	External emergency stop	Nc/IPO.QKan...	11:29:38 2010...
1892	206 Machine guard is open !	Nc/plc.QPlc...	11:29:38 2010...
1893	207 Door test	Nc/plc.QPlc...	11:29:38 2010...
1894	***** SYSTEM START Date: 21.10...		11:22:37 2010...
1895	***** PRODUCT: MANUALplus 5...		
1896	***** KERNEL: NC-Kernel 597...		

### Moving within the log file:



To move to the oldest entry:

- ▶ Press the **BEGINNING** soft key.



To move to the most recent entry:

- ▶ Press the **END** soft key.

To view other log file entries:


- ▶ Navigate in vertical direction by simply using the navigation keys

### To find a log entry:



To call the "Find" dialog box:

- ▶ Press the **FIND** soft key.



- ▶ Enter the search string
- ▶ Define the search direction

## Filter

Use a filter to limit the log display to the following error groups:

- Information
- Warnings
- Errors
- System errors

In addition, you can select the following information:

- Date and time from which you want the log contents to be displayed.
- Clients whose errors and error information are to be considered in the log display.

Whether the **filter is taken into account** depends upon the setting of the **FILTER ON/OFF** soft key:

Filter  
ein/aus

- ▶ Soft key active: Filter is taken into account
- ▶ Soft key not active: Filter is not taken into account

### To set the filter:

Filter  
definition

- ▶ Press the **Filter Definition** soft key

INFOS

To display information:

- ▶ Press the **INFOS** soft key

WARNINGS

To display warnings:

- ▶ Press the **WARNINGS** soft key

ERRORS

To display errors:

- ▶ Press the **ERRORS** soft key.

SYSTEM  
ERRORS

To display system errors:

- ▶ Press the **SYSTEM ERRORS** soft key.

To set the client and/or date and time:

FURTHER  
FILTER  
FUNCTIONS

Call the "Filter functions" dialog box

- ▶ Press the **FURTHER FILTER FUNCTIONS** soft key

Filter functions

Displayed clients

As of date (DD.MM.VVVV)

and time (HRS:MIN:SEC)

OK CANCEL

- ▶ Enter the client and/or date and time
- ▶ Conclude with **OK**.

To **display the log** under consideration of the new filter settings (prerequisite: the **Filter on/off** soft key is on):

UPDATE

- ▶ Press the **ACTIVATE FILTER** soft key.



Note

Writing to OEM logs must only take place in worthwhile intervals, since under circumstances the processing time could be affected negatively, and the hard disk written to unnecessarily.

**Module 9277 Write data into the OEM log**

With Module 9277 the PLC can write data into a specific OEM log. Up to eight OEM logs can be used at the same time. The module can be called from a cyclic PLC program or from a spawn job or submit job. The string for the log entry may contain two wildcards (data1 and data2). Only wildcards that occur are replaced. The output format is controlled through the entry %d for integers or the entry %f for floating point numbers with three decimal places. Alternatively, you can define the number of decimal places with %.1f to %.6f.

Example of a string for the log entry:

**S"data1: %.2f data2: %d"**

If the maximum log size of 1 MB is exceeded, the log is copied to <name>.LOG.OLD and a new log with the same name is created. Once the logs have been called, they remain open until the control is shut down.

Call:

```
PS B/W/D/K/S<Path with file name (without .LOG extension)>
PS B/W/D/K/S<String with placeholder for log entry>
PS B/W/D/K <Value for data1>
PS B/W/D/K <Value for data2>
PS B/W/D/K <Switch for additional entries>
    Bit 0 = 0/1: Entry without/with time stamp
    Bit 1 = 0/1: Entry without/with PLC cycle counter
```

CM 9277

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Data written into OEM log
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	2	Invalid string number or invalid string
	22	Message cannot be transmitted



## Saving log files (service files)

Data relevant for service purposes can be saved in a .zip file. Creating a service file is generally recommended should an error occur with the MANUALplus 620. This file contains useful information, especially for the HEIDENHAIN Service department during troubleshooting.

The following data (and other information) is saved in the service file:

- Error log file
- Keystroke log file
- Log files of the IPOs and the PLC
- Information on hardware setup and firmware versions
- Machine parameters
- Information and log files of the operating system (can be partially activated via HE Logging settings)
- Contents of PLC memory
- Error outputs and configuration files of the PLC compiler
- Current Feature Content Level (FCL) and active software options, including the option designations through the file PLC:\service\SIK.INFO

The control automatically packs the data into a \*.ZIP file. You can choose any name for the ZIP file. The MANUALplus 620 proposes the standard name **SERVICE [number] .ZIP**. With any other number, as well, the MANUALplus 620 automatically appends a serial number to the file name.

Path: **TNC:\[name] [number] .zip**

To save log files:



- ▶ Call the error window by pressing the **ERR** key.



- ▶ Press the **LOG FILES** soft key



- ▶ Press the **SAVE SERVICE FILES** soft key

- ▶ Enter a file name for the service file
- ▶ The control automatically creates the \*.ZIP file **TNC:\[name] [1] .zip**  
If more than one service \*.ZIP file is contained on the control, the files are numbered in increasing order. The file with the number 1 is always the file just generated.

## PLC error messages

Settings in the configuration editor	MP number
System	
Paths	
CfgPlcPath	
<b>errorTable</b>	102303
<b>errorText</b>	102304

PLC error messages are defined in the PET table (PLC Error Table). If the PLC detects an error, it is transferred to the error system by Module 9084, Module 9085 or by activating a marker defined in the PET table. The error system ensures that the error is displayed and processed. The PLC error messages are now displayed with the prefix PLC followed by the line number from the PET table (e.g. **PLC00239**).

With Module 9086 you can delete PLC error messages, and with Module 9087 you can interrogate the current status of the error message.

### PET table (PLC error table)

- ▶ Enter the path and file name of the PET table in **MP\_errorTable**.
- ▶ Enter the file name of the text file for PLC error messages in **MP\_errorText**.



#### Note

A \*.PET table is absolutely mandatory, since without it the PLC program cannot be compiled or activated.

Use the program "PLC-Text" to enter data in the PET table.

If a \*.PET table contains more than 999 error messages, the excessive messages are ignored and the error message **PET table: Too many lines** appears.

#### MP\_errorTable

PLC error message table

Available from NCK software version: 597 110-01.

Format: String

Input: Path and file name of the PET table, for example:  
%OEM%\table\

Default: -

Access: LEVEL2

Reaction: NOTHING





## Priority of PLC error messages

You can enter a priority between 0 and 2 for the PLC error messages defined in the PET table. Priority 0 (error) is the highest priority, followed by priority 1 (warning) and priority 2 (info). PLC error messages triggering an EMERGENCY STOP receive the highest priority (independent of the priority from the PET table). Therefore, these error messages always appear at the first position in the error list. The error message **External EMERGENCY STOP** has a lower priority, but still a higher priority than the top PLC priority. This means that PLC error messages triggering an emergency stop always appear at the first position in the error list. They are followed by **External EMERGENCY STOP** and then by further PLC error messages, depending on their priority.

## Error text file

Error texts are defined directly in the PET table (max. 32 characters; not language-sensitive) or in the error text file. In the error text file, you define the error text to be displayed as well as the information on the cause of error and corrective action.

Error text files are language-sensitive. The path for the error text file is permanently defined: %OEM%\plc\language\en (or another language abbreviation).

In MP\_System/DisplaySettings/CfgDisplayLanguage/plcErrorLanguage, you define the language to be used.

You define the name of the error text files in MP\_errorText.

### MP\_errorText

	Text file for PLC error messages
	Available from NCK software version: 597 110-01.
Format:	String
Input:	Example: <b>PLCErrorText.csv</b> The path %OEM%\plc\language\ is permanently defined. The last subdirectory is the language abbreviation for the respective conversational language, e.g. <b>en</b> for English.
Default:	–
Access:	LEVEL2
Reaction:	NOTHING

## Structure of the PET table

The PLC error message table (\*.PET) consists of the following columns, to which you can assign special attributes:

### ■ NR

Line number in the table. The modules select the PLC error message by assigning the line number.

### ■ ERROR

The error texts can be specified in the following manners:

- Direct entry of the error text (max. 32 characters)
- Line number of the PLC error text file (# <line no.>) defined in MP\_errorText.

### ■ MARKER

The PLC error message can be activated without module call by setting the marker defined here. The marker is also set if the error message was activated through Module 9085. Enter the symbolic name of the marker to be set.

Entry 0: No error marker

- **Error class:** The error class is defined in the following columns (see "Error status" on page 1251). If none of these error classes is set in the PET table, NN\_ChnErrorWarning is set.
  - **RESET**
    - 0: No NC reset upon activation of the error message (no system error).
    - 1: NC reset upon activation of the error message (system error). The PLC program stops.
  - **NC\_STOP**
    - 0: No NC stop upon activation of the error message
    - 1: NC stop upon activation of the error message (NN\_ChnErrorNcStop is set).
  - **NC\_CANCEL**
    - 0: No NC stop with subsequent INTERNAL STOP upon activation of the error message
    - 1: NC stop with subsequent INTERNAL STOP upon activation of the error message (NN\_ChnErrorCancel is set)
  - **F\_STOP**
    - 0: Feed-rate enable is not influenced
    - 1: Feed-rate enable is reset upon activation of the error message (NN\_ChnErrorFStop is set)
  - **EMER\_STOP**
    - 0: No EMERGENCY STOP upon activation of the error message
    - 1: EMERGENCY STOP upon activation of the error message (NN\_ChnErrorEmergencyStop is set)
- **CE**
  - 0: Error message can be deleted by the user.
  - 1: Error message cannot be deleted by the user.
- **PRI0**

A priority of 0 to 2 can be entered for the error message, with priority 0 being the highest priority. If the PLC triggers more than one error at the same time, the errors with the highest priority are the first to be sent to the event server (error system).
- **MTYPE**

Message type of the PLC error message

  - E: Error
  - W: Warning
  - I: Information
- **WARN\_LVL:** Not evaluated.
- **ONL\_NAME:** Name of a help file (\*.CHM), see "Enhanced error notification" on page 1284.
- **ONL\_NR:** Help number within this help file (\*.CHM), see "Enhanced error notification" on page 1284.

## Structure of the error text file

In the error text file, there are four columns with the following meanings:

- **Reference number:** This reference is used in the PET table ("Error" column).
- **Error text:** Displayed error text.
- **Cause of error:** Text that the error system displays under "Cause" after you have pressed the **Info** soft key.
- **Corrective action:** Text that the error system displays under "Action" after you have pressed the **Info** soft key.

### Module 9084 Display PLC error messages with additional data

The module displays PLC error messages with additional data. You can insert placeholders (%s, %d, %f) at any position of the error texts. The placeholders are assigned the data from the module at run time. Only those placeholders that are defined in the PLC error message will be replaced. %s is replaced by the string or the string content. The first occurrence of %d or %f in the PLC error message is replaced by the content of variable 1, and the second occurrence of %d or %f is replaced by the content of variable 2. %d is an integer, %f is a floating point number with three decimal places. Alternatively, you can define the number of decimal places with %.1f to %.6f.

If the module is called several times with the same line number of the \*.PET table, the error message is entered only once in the queue. A maximum of 32 PLC error messages can be entered in the queue.

If an error marker is assigned in the PET table, it is set.

If the \*.PET table or the line number is not found, the error message **PLC ERROR <line number>** appears.

Call:

```
PS    B/W/D/K <Line number of the *.PET table>
        0 to 999: Line number
PS    B/W/D/K/S<Data for %s>
PS    B/W/D/K <Data for %d or %f; variable 1>
PS    B/W/D/K <Data for %d or %f; variable 2>
CM    9084
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	PLC error message with additional data displayed
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Line number missing
	8	Incorrect operating mode, compatibility error marker set
	23	Overflow of PLC error message queue

### Module 9085 Display PLC error message

The module transfers PLC error messages to the error system. The error message texts come directly from the compiled error table (.PET) or from the selected text file for PLC error messages. PLC error messages (except reset errors) can be deleted by Module 9086 or by the user. However, deletion can be disabled in the error table ("CE" column).

Up to 32 error messages can be placed in the queue.

If an error marker is assigned to the error, it is set.

System error: Is displayed without entry in the queue.

Error number -1: System error message **EMERGENCY STOP PLC** is displayed. This error message also occurs if no \*.PET table was defined.

Error number not equal to -1 and no \*.PET table selected:

System error message **PLC: ERROR TABLE MISSING**

Call:

PS B/W/D/K <Line number of the \*.PET table>

0 to 999: Line number

-1: System error message **EMERGENCY STOP PLC**

CM 9085

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Error message displayed or in queue
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Line number missing
	8	Incorrect operating mode, compatibility error marker set
	23	Overflow of PLC error message queue, or too many error messages from string memory



### Module 9086 Clear PLC error message

Use this module to erase all set PLC error messages or a specific error message. System errors cannot be deleted.

Call:

PS B/W/D/K <Line number of the \*.PET table>  
0 to 999: Line number  
-1: Clear all PLC error messages

CM 9086

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Error message displayed or in queue
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Line number missing
	8	Incorrect operating mode, compatibility error marker set

### Module 9087 Status of PLC error message

The module interrogates the status of a specific PLC error message, or the PLC error status in general. In addition, the number of the error message active on the screen and the total number of PLC error messages in the error list can be interrogated.

Call:

PS B/W/D/K <Line number of the \*.PET table, status code>  
0 to 999: Line number  
-1: PLC error message, general  
-2: Number of the active PLC error message  
-3: Number of error messages in the \*.PET table

CM 9087

PL B/W/D <Status/error code>  
For code 0 to 999:  
0: No error message with the number, or message cleared  
-1: Line number does not exist  
Bit 0 – PLC error message is displayed  
Bit 1 – PLC error message in queue  
  
For code -1:  
0: No PLC error message  
2: PLC error message in queue  
  
For code -2:  
≥ 0: Number of the displayed error  
-1: No error in the \*.PET table  
For code -3:  
≥ 0: Number of errors in the \*.PET table

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Status information was read
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Invalid line number or status code



## Entering data in log files

The error log file can be used by the PLC for diagnostic purposes.

Entering data **from the PLC** into the error log file:

- ▶ Use Module 9275 to write ASCII data into the error log file
- ▶ Use Module 9276 to write the contents of operands into the error log file



### Note

Do not use Modules 9275 and 9276 in the PLC program as shipped. Instead, use them only for debugging. Otherwise the processing times could be increased and the hard disk could be written to unnecessarily.

### Module 9275 Write ASCII data into the log

The module writes a character string from a PLC string or an immediate string into the error log file. The entry can be given a special identifier for fast finding or later editing.

A buffer of approx. 210 bytes is available for the data to be written (including the entry identification).

Call:

```
PS   B/W/D/K/S<Log entry>
      -1: No entry
PS   B/W/D/K/S<Log identifier>
      -1: No entry
PS   B/W/D/K <Priority>
      0: Information
      1: Warning
      2: Error
```

CM 9275

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Entry was written
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Invalid priority
	2	Invalid string number or invalid immediate string
	12	No string end identifier
	20	Module was not called in a spawn or submit job

### Module 9276 Write operand contents into the log

The module writes the contents of PLC operands into the error log file. The entry can be given a special identifier for fast finding or later editing.

A buffer of approx. 210 bytes is available for the data to be written (including the entry identification).

The operands M/I/O/C/T are stored in binary format (e.g.110101), the operands B/W/D in hexadecimal format.

Call:

PS B/W/D/K <Identifier for operand name>

0: M (marker)

1: I (input)

2: O (output)

3: C (counter)

4: T (timer)

5: B (byte)

6: W (word)

7: D (double word)

PS B/W/D/K <Address of the first operand>

PS B/W/D/K <Number of operands>

PS B/W/D/K/S<Log identifier>

-1: No entry

PS B/W/D/K <Priority>

0: Information

1: Warning

2: Error

CM 9276

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Entry was written
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Invalid priority
	2	Invalid identifier for operand name
	3	Invalid first operand address
	4	Sum of first operand address and number of operands invalid
	5	Address is not a word/double-word address
	12	No string end identifier
	20	Module was not called in a spawn or submit job
	36	Entry in the log was truncated after 210 characters





## Suppressing the "Key non-functional" message

Settings in the configuration editor	MP number
System CfgConfigSettings <b>suppressUserMsg</b>	106502

The parameter **MP\_suppressUserMsg** is used to suppress the green "Key non-functional" warning message. This warning is not recorded in the error log and is always issued when a key is pressed on the control that is not assigned to a function in the current operating situation.

### **MP\_suppressUserMsg**

Do not display the **Key non-functional** error message  
Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **TRUE**

The control does not output the "Key non-functional" error message.

**FALSE**

The control displays all error messages.

Default: No value, parameter optional (= FALSE)

Access: LEVEL3

Reaction: NOTHING

### 7.1.10 TURNguide – context-sensitive help system (user documentation)

The TURNguide help system is based on the familiar Windows format for help, CHM. The CHM format was introduced by Microsoft in 1997 together with the HTML help system, and is now used by many Windows programs. It is a collection of individual HTML files that are collected in a single compressed file.

Mozilla Firefox is used as the browser on the single-processor MC. The programming station uses Internet Explorer or the standard browser configured for your PC.

In principle, the control with TURNguide is able to open and display any CHM files, including those prepared by the OEM. HEIDENHAIN provides the following documentation in the form of CHM files:

- TNC 620 User's Manual
- TNC 620 User's Manual for smart.Turn and DINprogramming
- Collection of all NC error messages

The User's Manual for the programming station is also supplied with the programming station.

The individual CHM files can be downloaded as ZIP archive from the HEIDENHAIN homepage on the Internet:

"Services and Documentation" > "Software" > "TURNguide Help"

Context-sensitive entry points were defined in the above CHM documentation. After the Info key is pressed, the control displays the relevant place within the documentation. If no context-sensitive entry point is available, the control opens the parent **main.chm** book file, in which all CHM files in the respective (language dependent) help directory are shown. The user navigates to the desired entry with the mouse or the arrow keys.

He can also jump to an entry point in TURNguide by mouse click:

- ▶ Click the help symbol that is shown at the right of the screen over the soft-key row.
- ▶ The mouse pointer changes into a question mark.
- ▶ Click the soft key
- ▶ The control starts the help system and—if an entry point is defined for the soft key—shows the help text pertaining to the soft key's function. If no context-sensitive entry point is available, the control opens the parent book file **main.chm**, as described above.



## Basic conditions for the OEM

So that CHM files created by OEMs can be shown in the **main.chm** book file, the conditions listed below must be followed:

- The OEMx.CHM files must be stored in the **TNC:\tncguide\de** directory, or in **TNC:\tncguide\en**, etc. When the dialog language is switched (CfgDisplayLanguage/helpLanguage), the control searches the corresponding language subdirectory when the help system is called. HEIDENHAIN recommends placing an OEMx.CHM file in English in each language subdirectory if you do not translate your documentation into every language. This ensures that online help is available for all topics, regardless of the language settings on the control. If no OEMx.CHM file exists in the language subdirectory, no OEM-specific help is shown when the online help is called.
- HEIDENHAIN has already defined the names for the CHM files created by the OEM, so that these files can be displayed as books (if they exist) within the parent **main.chm** book file:

Name of CHM file	Help-number range from	to
OEM1.chm	10 000 000	10 999 999
OEM2.chm	11 000 000	11 999 999
OEM3.chm	12 000 000	12 999 999
OEM4.chm	13 000 000	13 999 999
OEM5.chm	14 000 000	14 999 999
OEM6.chm	15 000 000	15 999 999
OEM7.chm	16 000 000	16 999 999
OEM8.chm	17 000 000	17 999 999
OEM9.chm	18 000 000	18 999 999
OEM10.chm	19 000 000	19 999 999

- The help-number range shows the context-sensitive entry points that are permanently defined for each file in order to simplify entry via the parent **main.chm** book file.
- The following links contain useful information about HTML help as well as software for downloading:  
<http://msdn.microsoft.com/library/en-us/htmlhelp/html/vsconHH1Start.asp>  
<http://www.helpware.net/>
- HEIDENHAIN recommends using Mozilla Firefox 1.0.x to check how the HTML pages are displayed, since it is used on the control. The view differs somewhat from the view in Internet Explorer, especially regarding the page layout. However, this does not replace a thorough test of the CHM file on the control.

Using PLC modules to call CHM files created by the OEM:

- PLC Module 9391 is available, with which a PLC error message is displayed, and in addition an offset is added to the value of the error number (= ONL Number) in the .PET table in order to generate the actual help number. This way a group error number can be defined for an (OEM) device in the .PET table, and the error number (used as an offset) supplied by the device in case of error then leads to the appropriate help text. This requires an OEM-specific \*.CHM file, which must be indicated in the .PET table (= ONL Name).
- Additionally, with PLC Module 9390, a help window can be opened directly by the PLC.

Every possible way of calling your OEM help file offers you the possibility of showing the entire directory (including HEIDENHAIN help files) in the directory tree, or just the directory of your OEM help file. This selection is made when calling the help file. If you enter **main.chm** as the help file in the call (via PLC module, \*.PET file, soft key or NC error), then the entire directory is shown. If you enter your OEM help file OEMx.CHM as help file in the call, then only the directory of your help file is shown.

## Files and structure of the help system

All online help available on a control can be called separately as well as within the online help system. In order for the call within the entire system to function, the conditions described below must be followed:

The help system is structured as follows:

- main.chm – Welcome page of the help system
  - jh1.chm
  - jh2.chm
  - ...
  - oem1.chm
  - oem2.chm
  - oem3.chm
  - ...



The HTML pages of the individual online help topics exist completely independently of each other. Special entries combine the tables of contents and collate the index entries (see below).

### Table of contents

The table of contents of main.chm contains "merge" objects:

```
<OBJECT type="text/sitemap">  
  <param name="Merge" value="oem1.chm:/merged.hhc">  
</OBJECT>
```

HEIDENHAIN has specified here the name of the CHM file and the file name **merged.hhc** of the table of contents contained therein.

When the welcome page of the help system (main.chm) is called, all existing help files linked with merge commands are included. Each table of contents is only displayed if it exists in a file named **merged.hhc**. This is why it is essential that you include the directory structure of your help as **merged.hhc** when you generate your **OEMx.CHM** files.

The first level of this table of contents should have exactly one entry: the title of the help file. This title then appears as a "book" in the entire table of contents, and can be opened by the user in order to show the subordinate headings.

Along with the actual HTML pages, the following files must be included when generating the OEMx.CHM files:

- \*.hhc file  
In this file you describe the structure and format of your help system. If you call your help file via main.chm, then this file must be named **merged.hhc**. If your help file is to be called directly, without **main.chm**, then the directory tree in the \*.hhc file that you indicated as content file when you created the CHM file is used.
- \*.hhk file  
In this file you list all entries that are to be shown in the index later, and create the links to the corresponding HTML pages. At least one entry is necessary here in order for your help file to be displayed.
- \*.hhp file  
This file is the project file that is necessary for generating an OEMx.CHM file.
- \*.h file (only necessary for context-sensitive help)  
In this file you use the **#define** command to establish connections between error numbers, from the respectively valid ranges of error numbers, and any variables.  
Example:  

```
#define IDH_OEM1_CHAP1          1000000  
#define IDH_OEM1_Page1_1      10000100
```
- \*.txt file (only necessary for context-sensitive help)  
In this file you establish the connection between the variables and the corresponding HTML pages, which are then called.  
Example:  

```
IDH_OEM1_CHAP1=chapter1.html  
IDH_OEM1_Page1_1=page11.html
```



### Note

"Merging" of the indexes only functions if each file involved contains at least one index entry, meaning at least one index entry is also necessary for the OEM help file. In addition, the entry "Binary Index=Yes" must be set in the project file (\*.hhp).

The project file of main.chm contains the following entries:

■ [MERGE FILES]

- jh1.chm
- jh2.chm
- ...
- oem1.chm
- oem2.chm
- oem3.chm
- ...

This collates and displays the index entries of all present and named help files when the index of main.chm is called.

### Context-sensitive call

In a context-sensitive call of the OEM help, the index display starts from the OEM help, and here the index entries can only be collated if all other help files \*except\* the current OEM file itself are entered in the project file of the OEM help.

HEIDENHAIN makes a complete list of the file names available.

Summary for OEM help

- Project file: Binary Index=Yes
- Project file: [MERGE FILES] with current list \*except\* its own file name!
- Table of contents: "merged.hhc" – Title of the help, can be opened as a "book."
- Index: At least one index entry.



## Designing soft keys for context- sensitive help

In order to establish context sensitivity in combination with soft keys, the additional HELPID and HELPFILE soft keys must be entered in the descriptions of the soft keys. Use HELPID to assign to a soft key an ID (= error number) from the respectively valid range of error numbers. With the HELPFILE attribute you indicate in which \*.chm file the error number can be found (e.g. OEM1.chm) or via which file the error number is to be searched for (e.g. main.chm). The assigned error number, in combination with the \*.txt and \*.h files, is used to call the appropriate HTML page when the help is called. If you enter main.chm as the HELPFILE, the entire directory structure with the HEIDENHAIN help files is shown. If you enter only one file (e.g. OEM1.CHM), then only the directory of this file is shown. The OEMx.CHM files must be stored in the **TNC:\tncguide\de** directory, or in **TNC:\tncguide\en**, etc. When the dialog language is switched, the TNC 620 searches the corresponding language subdirectory when the help system is called. You can enter HELPFILE for each soft key, or once for all soft keys.

Example:

**PLC SOFTKEY Project File - Version 1.0**

```
; Path for the soft-key help file  
HELPFILE 'TNC:\tncguide\de\oem1.chm'
```

...

```
; here the assignment of a HELPID to the soft keys  
;without indication of a *.chm file. This automatically links to  
; the help file indicated above.
```

```
ACTION Action2_Softkey HELPID:10000000
```

```
PULSE Pulse1_Softkey HELPID:10000100
```

```
BLANK  
ENDSKMENU
```

or:

**PLC SOFTKEY Project File - Version 1.0**

...

```
; here the assignment of a HELPID and a HELPFILE to  
; the soft keys. This automatically links to the  
; indicated help file.
```

```
ACTION Action2_Softkey HELPID:10000000  
HELPFILE:TNC:\tncguide\de\oem1.chm
```

```
PULSE Pulse1_Softkey HELPID:10000100  
HELPFILE:TNC:\tncguide\de\oem1.chm
```

```
BLANK  
ENDSKMENU
```

## Enhanced error notification

### ■ PLC error messages

For each entry (i.e. error message) in the PET file, the machine manufacturer can enter the name of a help file (\*.CHM) and a help number within this \*.CHM file. This is done with the two new columns in the PET table, ONL Name and ONL Number. The called help files must—as mentioned earlier—be present and language-sensitive in the TNC:\tncguide\de, TNC:\tncguide\en, etc. directories. When a PLC error message is current and the user then presses the ERR key and the HEIDENHAIN TURNguide soft key, the appropriate chapter from this file is shown (context-sensitive call). If a help number but no \*.CHM file is indicated, the main.chm file is automatically shown. If the OEM has adhered to the permanently defined help-number ranges for the respective files (see above for the help-number ranges), then the correct, context-sensitive help page is shown in this case as well.

## Including an OEM-specific online help file

Once you have created a valid \*.chm file, proceed as follows in order to display your own OEM-specific help file in the HEIDENHAIN TURNguide:

- ▶ You may need to rename your \*.chm file. You must use one of the names reserved by HEIDENHAIN for OEM help files.  
e.g. **OEM1.CHM**
- ▶ Use TNCremoNT to transfer the help file to the control.
- ▶ Store your help file in the appropriate language directory: **TNC:\tncguide\de**, **TNC:\tncguide\en**, etc. If you have created only an English help file, HEIDENHAIN recommends placing it in the other language directories as well.
- ▶ Press the Info key to call the TURNguide. Your help file should now automatically be included in the TURNguide directory tree.

## National languages

CHM files will not be available for all possible NC dialog languages at the time the new NC software levels are released. However, HEIDENHAIN offers at least the CHM files in English and German as a download over the FileBase. The CHM files in other languages will be made available for free downloading (also, of course for unregistered users) from our FileBase. The user then simply downloads the appropriate file(s) for the respective language(s), and stores them in the directory provided on the user partition: **TNC:\tncguide\de** or the appropriate language subdirectory.

## Online help files and TNCremoNT

As of TNCremoNT version 2.5 (released in November 2006), special functions, optimized for online help files are available:

### ■ Transfer of \*.chm files:

Online help files are binary files. If TNCremoNT is updated at least to version 2.5, the file extension .chm is automatically added to the list of binary file types. Otherwise the list of binary file types must be amended manually under Extras > Configuration on the Mode tab in order to transfer them correctly.

### ■ Performing a backup of the TNC via TNCremoNT:

Online help files are automatically untagged during creation of the scan list used for the backup. This also applies to CHM files that the machine manufacturer has saved on the control.

Reason:

The \*.chm files saved on the control require a large amount of memory, and do not need to be backed up, since they are freely available from the HEIDENHAIN homepage.

Please note that only online help files from HEIDENHAIN are available here. This setting can be applied to other file types as well in TNCbackup under Edit > Settings, if necessary.





**Module 9392 Display PLC error messages**

With Module 9392, you can display a PLC error message with an additional help offset and further parameters. The error message must be defined in the .PET table.

The behavior of the module corresponds to the behavior of PLC Module 9084 used in conjunction with Module 9391.

The wild cards %s, %d and %f can be defined at the appropriate places in the error texts. The individual module parameters are assigned to the wild cards (as described in the module interface), and are entered in the error texts at run time. Only the wild cards that occur in an error text are replaced. The wild cards %.1f ... %.6f can be used in order to show the places after the decimal point. If %f is entered, three decimal places are used.

The module can be called from a cyclic PLC program or from a spawn or submit job.

An offset is added to the value for the help number in the .PET file in order to generate the actual help number. This way a group error number can be defined for an (OEM) device in the .PET table. The error number (used as an offset) supplied by the device in case of error then leads to the appropriate help text.

Condition:

- The .CHM help file must be stored language-sensitive in the TNC:\tncguide\de directory, or in TNC:\tncguide\en etc.
- An OEM-specific OEMx.CHM file is necessary.
- If no OEMx.CHM file is indicated, the online help is not called. All other reactions that are saved for this error in the .PET table are performed.

Call:

```
PS    K/B/W/D <Line number in the .PET error table>>
PS    K/B/W/D <Additional text from S0 ... S99 or constant string>
PS    K/B/W/D <Variable 1>
PS    K/B/W/D <Variable 2>
PS    K/B/W/D <Offset for the help number in .PET>
CM    9392
```

**Error recognition:**

Marker	Value	Meaning
M4203 or NN_GenApiModule Error	0	No error
	1	Error code in NN_GenApiModuleErrorCode (W1022)
W1022 or NN_GenApiModule ErrorCode	1	Transferred parameter outside of value range or error number is not in .PET table
	2	Invalid parameter
	3	String address outside of value range
	8	Incorrect operating mode, compatibility error marker set
	3	Overflow of PLC error message queue



Example:

```
PS    K10                ; Error 10 from .PET
PS    S"ERROR-ERROR"    ; %s
PS    K9000              ; %d
PS    W100               ; %.1f
PS    K2                 ; Offset for the help number in .PET
CM    9392
```


Assumption: Text in .PET "%s error in module %d, W100 = %.1f" and  
W100 = 1234

Therefore, the following output text results:

"ERROR-ERROR error in module 9000, W100 = 123.4"



## 7.2 Machine Display in the Dashboard



The configurable machine display is referred to as the **dashboard** (see figure). The dashboard features 16 fields whose contents can be specified via machine parameters. You can create one or more dashboard for each operating mode of a machining channel. The corresponding dashboard is displayed when an operating mode is switched to. If more than one dashboard is defined for an operating mode, then there must be a user function in place for switching between dashboards.

The details of the displays, such as axis designations, number of decimal places, etc. are specified in the selection or configuration of the dashboard element. You specify in **MP\_unitOfMeasure** (CfgUnitOfMeasure) whether the units are displayed in the inch or metric system.


Sequence of the dashboard elements:

[0]	[1]	[2]	[3]
[4]	[5]	[6]	[7]
[8]	[9]	[10]	[11]
[12]	[13]	[14]	[15]

The dashboards are configured in the following steps:

- In the channel-dependent parameter object **CfgChannDashboard** you specify for each operating mode one or more key names for dashboard configurations.
- Configure the dashboard in the **CfgDashboard** parameter object. Under this key name you assign up to 16 dashboard elements for the layout of the dashboard. You do so by assigning the key names for the dashboard elements.
- Specify the dashboard elements in the **CfgDashboardElemnt** parameter object. You assign an "image" to each key name of a dashboard element. Depending on the type of element, you gate the element to one or more axes or one or more machining channels.

The overview below shows the connections between the dashboard parameters.




## 7.2.1 Assigning dashboards to the operating modes

Settings in the configuration editor	MP number
Channels	
ChannelSettings	
[Key name of the machining channel]	
CfgChannDashboard	
<b>defaultDashboard</b>	203401
<b>opmodeStartup</b>	203402
<b>opmodeReference</b>	203403
<b>opmodeManual</b>	203404
<b>opmodeManualLarge</b>	203408
<b>opmodeMDI</b>	203405
<b>opmodeAutomatic</b>	203406
<b>opmodeAutomaticLarge</b>	203409
<b>opmodeSGTest</b>	203407

The control displays the dashboard for the active operating mode. If no dashboard is defined for an operating mode, the default dashboard is displayed.

- ▶ Specify the **default dashboard** with the **MP\_defaultDashboard** parameter
- ▶ If desired, assign one or more dashboards to an operating mode

### Dashboard switchover

The  soft key can be used to switch between the dashboards entered in **MP\_opmodeManual** and **MP\_opmodeAutomatic** depending on the operating mode. Up to 40 dashboards can be configured for the Manual and Automatic operating modes. If the last dashboard in the list is active, the first dashboard is jumped to. The prerequisite is that all dashboards entered in the list are also configured under **CfgDashboard**.

#### MP\_defaultDashboard

Default dashboard  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: Key name of a dashboard configured under System/DisplaySettings/CfgDashboard

Default: DB\_DEFAULT

Access: LEVEL3

Reaction: RUN

### **MP\_opmodeStartUp**

Dashboard for start-up phase  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: Key name of a dashboard configured under System/  
DisplaySettings/CfgDashboard  
Default: DB\_STARTUP1  
Access: LEVEL3  
Reaction: RUN

### **MP\_opmodeReference**

Dashboard for the Reference operating mode  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: Key name of a dashboard configured under System/  
DisplaySettings/CfgDashboard  
Default: DB\_REFER1  
Access: LEVEL3  
Reaction: RUN

### **MP\_opmodeManual**

Dashboard for the Manual operating mode  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: Key name of a dashboard configured under System/  
DisplaySettings/CfgDashboard  
Default: DB\_MANUAL1  
Access: LEVEL3  
Reaction: RUN

### **MP\_opmodeMDI**

Dashboard for the MDI operating mode  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: Key name of a dashboard configured under System/  
DisplaySettings/CfgDashboard  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN



### **MP\_opmodeAutomatic**

Dashboard for the Automatic operating mode  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: Key name of a dashboard configured under System/  
DisplaySettings/CfgDashboard  
Default: DB\_AUTO1  
Access: LEVEL3  
Reaction: RUN

### **MP\_opmodeSGTest**

Dashboard for the SGTest mode  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: Key name of a dashboard configured under System/  
DisplaySettings/CfgDashboard  
Default: DB\_SGTEST1  
Access: LEVEL3  
Reaction: RUN



## 7.2.2 Configuring dashboards

Settings in the configuration editor	MP number
System	
DisplaySettings	
CfgDashboard	
[Key name of dashboard]	
<b>elementList</b>	113201
CfgDashboardElemnt	
[Key name of the dashboard element]	
<b>dashboardpicType</b>	113101
<b>attribut</b>	113102
<b>entityList</b>	113103
CfgOemWindow	
[Dashboard_1...4]	
<b>upperLeft</b>	605201
<b>bottomRight</b>	605202
CfgGlbDispSettings	
<b>axesDisplayMode</b>	604803

### Configuring the dashboard

- ▶ In the **CfgDashboard** parameter object, specify the configuration for each defined dashboard. For each dashboard you enter the key names of up to 16 dashboard elements in the list **MP\_elementList**.

#### MP\_elementList

List of dashboard elements, filled from the CfgDashboardElemnt pool.  
Available from NCK software version: 597 110-01.

Format: Array [0...40]  
Input: List of key names of dashboard elements configured under **CfgDashboardElemnt** in the sequence of arrangement.  
Default: –  
Access: LEVEL3  
Reaction: RUN

The dashboard elements are aligned from left to right and from top to bottom. The index 0 defines the element at top left in the display.





## Configuring a dashboard element

In the **CfgDashboardElemnt** parameter object you specify for each defined dashboard element the image, the attribute and the key names of the "associated" axis/axes or machining channel(s). "Associated" means that this display element shows values of this axis or machining channel (examples: position value of the axis, feed rate of the machining channel, speed of the spindle, etc.).

The following table shows the available dashboard elements.

- ▶ Select in **MP\_dashboardpicType** the name of the dashboard element from the list.
- ▶ If desired, use **MP\_attribut** to assign an attribute to the dashboard element.
- ▶ In **MP\_entityList** you associate the axis/axes or the machining channel to be displayed in this dashboard element.

## Configuring the OEM window

The OEM can define up to four OEM-specific areas of different sizes in the dashboard. These can be used to display Python applications.

With **MP\_upperLeft** you define the dashboard element number that represents the upper left corner of the OEM window. In **MP\_bottomRight** you enter the number of the corresponding dashboard element to limit the OEM window in the lower right. You can configure up to four different OEM windows in CfgOemWindow.

## Configuring the axis display

**MP\_axesDisplayMode** can be used to set the type of axis display. If the **Default** value is entered in **MP\_axesDisplayMode**, the axis is displayed as defined in the attribute of the dashboard element. The **ActualValue**, **NominalValue**, **Lag** (following error) and **Distance** fields show the corresponding values.

### **MP\_dashboardpicType**

Image type of a dashboard element  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: See table below  
Default: ActualValue  
Access: LEVEL3  
Reaction: RUN

### **MP\_attribut**

Attribute of the dashboard element  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: See table below  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

### **MP\_entityList**

Axis/Axes or channel associated with the dashboard element  
Available from NCK software version: 597 110-01.  
Format: Array [0...39]  
Input: Key names from **MP\_axisList** or **MP\_channelList**  
Default: –  
Access: LEVEL3  
Reaction: RUN

### **MP\_upperLeft**

Dashboard element number of upper left corner of OEM window  
Available from NCK software version: 597 110-05.  
Format: Numerical value  
Input: 0 to 19  
The dashboard elements are counted from the upper left to the lower right.  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_bottomRight**

Dashboard element number of lower right corner of OEM window  
Available from NCK software version: 597 110-05.  
Format: Numerical value  
Input: 0 to 19  
The dashboard elements are counted from the upper left to the lower right.  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING



## MP\_axesDisplayMode

Configuring the type of axis display

Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **Default**

Display defined as in the attribute

**ActualValue**

Display of the actual value

**NominalValue**

Display of the nominal value

**Lag**

Display of the following error (lag)

**Distance**

Display of the distance yet to go

Default: Default

Access: LEVEL3

Reaction: NOTHING

**Overview of the available dashboard elements**

The following table lists the available dashboard elements and the associated attributes.









Image	Name	Display/Attribute
	ActualValue	<b>Display:</b> Current position of an axis (actual-value display), handwheel and clamping are active
	[DB_X1_POS, DB_Y1_POS, DB_Z1_POS, DB_W1_POS]	<ul style="list-style-type: none"> <li>■ Letter designating the axis appears in black: Axis enabled by controller</li> <li>■ Letter designating the axis appears in white: Axis disabled by controller</li> </ul>
		<b>Attributes:</b> <ul style="list-style-type: none"> <li>■ Bit 0=0: Display the position of the tool tip</li> <li>■ Bit 0=1: Display the IPO axis value—identified by "I" after the letter designating the axis. Tool lengths and datum shifts are not considered.</li> <li>■ Bit 1=0: Display only if reference run has occurred</li> <li>■ Bit 1=1: Display even if no reference run has occurred</li> <li>■ Bit 2=1: Following error is displayed (code L)</li> </ul>
		
		
		<p>With the <b>General display settings -&gt; Axis display</b> or <b>MP_axesDisplayMode</b> user parameter, the position display can be adapted, whereby the attribute settings are then without effect.</p>
		<b>Selection:</b> <ul style="list-style-type: none"> <li>■ Default: No effect, attribute settings are without effect</li> <li>■ ActualValue: Actual position (REF ACTL) with respect to the machine datum (code A)</li> <li>■ NominalValue: Nominal position (REF NOML) with respect to the machine datum (code N). This value corresponds to the interpolator axis value (code I) if bit 0=1</li> <li>■ Lag: Following error (code L)</li> <li>■ Distance: Distance to go (code D)</li> </ul>
		










Image	Name	Display/Attribute
	ActualCAxisValue	<p><b>Display:</b> Current position of the C axis, handwheel and clamping are active</p> <ul style="list-style-type: none"> <li>■ Letter designating the axis appears in black: Axis enabled by controller</li> <li>■ Letter designating the axis appears in white: Axis disabled by controller</li> </ul>
	[DB_C1]	<p><b>Attributes:</b></p> <ul style="list-style-type: none"> <li>■ Bit 0=0: Display the position</li> <li>■ Bit 0=1: Display the IPO axis value—identified by "I" after the letter designating the axis. Tool lengths and datum shifts are not considered.</li> <li>■ Bit 1=0: Display only if reference run has occurred</li> <li>■ Bit 1=1: Display even if no reference run has occurred</li> <li>■ Bit 2=1: Following error is displayed (code L)</li> </ul>
		<p>With the <b>General display settings -&gt; Axis display</b> or <b>MP_axesDisplayMode</b> user parameter, the position display can be adapted, whereby the attribute settings are then without effect.</p>
		<p><b>Selection:</b></p> <ul style="list-style-type: none"> <li>■ Default: No effect, attribute settings are without effect</li> <li>■ ActualValue: Actual position (REF ACTL) with respect to the machine datum (code A)</li> <li>■ NominalValue: Nominal position (REF NOML) with respect to the machine datum (code N). This value corresponds to the interpolator axis value (code I) if bit 0=1</li> <li>■ Lag: Following error (code L)</li> <li>■ Distance: Distance to go (code D)</li> </ul>
		
		
		<p>If more than one C axis is configured, the assigned C axis number is displayed.</p>











Image	Name	Display/Attribute
   Protection zone monitoring active  Protection zone monitoring inactive	<p>ActualValueAnd DistanceToGo</p> <p>[DB_C1_DELTA, DB_X1_DELTA, DB_Z1_DELTA, DB_Y1_DELTA, DB_W1_DELTA]</p>	<p><b>Display:</b> Distance-to-go in an axis and status of protection zone</p> <p><b>Attributes:</b></p> <ul style="list-style-type: none"> <li>■ Bit 0=0: Display the programmed distance-to-go</li> <li>■ Bit 0=1: Display the distance-to-go in the physical axis</li> <li>■ Bit 1=0: Display only if reference run has occurred</li> <li>■ Bit 1=1: Display even if no reference run has occurred</li> <li>■ Bit 2=0: Do not display the status of the protection zone</li> <li>■ Bit 2=1: Display the status of the protection zone (protection-zone monitoring is active/inactive)</li> </ul>
     	<p>AllAxes</p> <p>[DB_ALL_AXES1]</p>	<p><b>Display:</b> Position values of up to four axes</p> <p><b>Attributes:</b></p> <ul style="list-style-type: none"> <li>■ Bit 0=0: Display the position of the tool tip</li> <li>■ Bit 0=1: Display IPO axis value—Letter designating the axis is highlighted in blue</li> <li>■ Bit 1=0: Display only if reference run has occurred</li> <li>■ Bit 1=1: Display even if no reference run has occurred</li> </ul> <p>The arrangement of the position values is determined by the sequence of the entityList entries.</p> <ul style="list-style-type: none"> <li>■ [0]—Top left</li> <li>■ [1]—Top right</li> <li>■ [2]—Bottom left</li> <li>■ [3]—Bottom right</li> </ul>










Image	Name	Display/Attribute
<p></p> <p> Code (blue) for driven tool</p> <p> Code (blue) for mirrored tool holder</p> <p> Code (blue) for displaying the special compensation DS</p>	<p>ToolDisplayWithCompValues</p> <p>[DB_TOOL1]</p>	<p><b>Display:</b> Tool pocket number and tool compensation values</p>
<p></p> <p> Code (blue) for driven tool</p> <p> Identification (blue) of mirrored tool holder</p> <p> Increase the display size of the tool ID number</p> <p> Attribute = 2: Increase the display size of the tool number with "ID" instead of "T"</p>	<p>ToolDisplayWithIdentification number</p> <p>[DB_TOOL_ID]</p>	<p><b>Display:</b> Tool ID number and tool compensation values</p> <p><b>Attributes:</b></p> <ul style="list-style-type: none"> <li>■ Bit 0=0: Display the tool ID number and tool compensation values</li> <li>■ Bit 0=1: Increase the display size of the tool ID number—<b>No</b> display of tool compensation values!</li> <li>■ Bit 1=1: Same as Bit 0=1, but with display of "ID" instead of "T"</li> </ul>



Image	Name	Display/Attribute
	AdditiveCompensation  [DB_ADD_CORR1]	<p><b>Display:</b> Additive workpiece compensation for X, Z and Y</p> <p>If no workpiece compensation is active, D=900 and the compensation values=0.0000 are displayed in gray.</p> <p>If workpiece compensation is active, D=901 to 916 and the active compensation values are displayed in black.</p>
	ActualToolData  [DB_TOOL_CORR1]	<p><b>Display:</b> Tool compensation for X, Z, Y and, if required, special compensation S</p> <p>If a special compensation that is not active (G148 O=0) is assigned to a tool, the compensation value is displayed in gray.</p> <p>If special compensation S is activated with G148 O=1 (DX-&gt;DS) or O=2 (DZ-&gt;DS), the S value is displayed and the assigned axis letter is highlighted in blue.</p>









Image	Name	Display/Attribute
 <p>Global tool life switch OFF (MP_lifeTime=Off): The letter T is displayed in white.</p>	<p>ToolDisplay- WithToolLife- Information</p> <p>[DB_TOOL_ LIFE1]</p>	<p><b>Display:</b> Tool and tool life information</p> <ul style="list-style-type: none"> <li>■ MT: Maximum tool life</li> <li>■ RT: Current tool life</li> <li>■ MZ: Maximum quantity</li> <li>■ RZ: Current quantity</li> <li>■ %: [current/maximum] · 100</li> </ul>
 <p>Global tool life switch ON (MP_lifeTime=On): The letter T is displayed in black (tool without tool life monitoring)</p>		<p>The display is updated cyclically about every 30 seconds, as well as after tool change, program end or program cancelation.</p>
 <p>Tool life monitoring <b>according to time</b></p>		
 <p>Tool life monitoring <b>according to part quantity</b></p>		


















Image	Name	Display/Attribute
 <p>Attribute=0 (bit 0=0)</p>	SpindleAnd SpeedInformatio n  [DB_S1, DB_S2]	<p><b>Display:</b> Spindle number, gear range, status (M3/M4/M5/M19/C axis), override, and rotational speed or stopping angle.</p> <ul style="list-style-type: none"> <li>■ Spindle symbol displayed in black: Spindle enabling</li> <li>■ Spindle symbol displayed in white: No spindle enabling</li> </ul>
 <p>Attribute=1 (bit 0=1)</p>		<p><b>Attributes:</b></p> <ul style="list-style-type: none"> <li>■ Bit 0=0: Display the actual rotational speed + override</li> <li>■ Bit 0=1: Display the actual rotational speed [1/min] and the programmed value ([m/min] at Vconst, or [1/min] at Nconst)</li> </ul>
 <p>Attribute=2 (bit 1=1)</p>		<ul style="list-style-type: none"> <li>■ Bit 1=1: Display the actual rotational speed, the programmed value and the override value</li> </ul>
 <p>Attribute=4 (bit 2=1)</p>		<ul style="list-style-type: none"> <li>■ Bit 2=1: The current spindle position in [°] is displayed as actual value when the spindle is stopped (M5)</li> </ul>
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		<ul style="list-style-type: none"> <li>■ Bit 3 = 1: The selected spindle is displayed.</li> </ul>
 <p>Attribute=4 (bit 2=1)</p>		<p>If the value <b>TRUE</b> is entered in <b>MP_plcSpindleSelect</b>, the number of the selected spindle is given a blue background.</p>
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		<p>For a C axis with external spindle drive (e.g. S4 drives the main spindle S1 through a transmission), the spindle speed of S4 can now be displayed in the S1 element in the C-axis mode. For this purpose the spindle (S1), which is also the spindle to be displayed, must be assigned in the external C axis in <b>MP_relatedWpSpindle</b> under CfgCAxisProperties [C<sub>n</sub>]. In addition, the physical axis of the external drive (S4) must be entered under CfgProgAxis [C<sub>n</sub>] in <b>MP_relatedAxis</b>. Then the bit AktAchsStatus2::CHANNEL_AXIS (spindle in C-axis mode) is monitored in the spindle interface. In this case, the axis velocity of the external drive (S4) is shown in the spindle display (S1) as long as the C-axis mode is active.</p>
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		<p>During spindle synchronism, the programmed value is shown only for the master spindle, not for the slave spindle. Depending on the status of the master spindle, the actual value is displayed in [1/min] or [°].</p>
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		
 <p>Attribute=5 (bit 0=1, bit 2=1)</p>		













Image	Name	Display/Attribute
 <p>Attribute=0 (bit 0=0)</p>  <p>Attribute=1 (bit 0=1)</p>  <p>Attribute=2 (bit 1=1)</p>  <p>Cycle OFF</p>  	<p>SlideAndFeed RateInformation</p> <p>[DB_CH1_ STATE]</p>	<p><b>Display:</b> Slide number, slide status (cycle ON/OFF), feed rate and override. If the slide is idle, the programmed feed rate is displayed in gray.</p> <p><b>Attributes:</b></p> <ul style="list-style-type: none"> <li>■ Bit 0=0: Display the actual feed rate and the override value</li> <li>■ Bit 0=1: Display the programmed feed rate and the actual feed rate</li> <li>■ Bit 1=1: Display the programmed feed rate, the actual feed rate and the override value</li> </ul> <p>The ballscrew being used to calculate the contouring feed rate is displayed above the slide symbol.</p> <p>If rear-face machining is enabled, the slide number is highlighted in blue.</p>
 <p>Attribute=0 (bit 0=0)</p>  <p>Attribute=2 (bit 1=1)</p>  <p>Attribute=4 (bit 2=1)</p>  <p>Displayed as of SW04</p>	<p>ChannelDisplay</p> <p>[DB_OVERRIDE]</p>	<p><b>Display:</b> Override for F, S and R</p> <p><b>Attributes:</b></p> <ul style="list-style-type: none"> <li>■ Bit 0=0: S at left, F or R at right</li> <li>■ Bit 0=1: F or R at left, S at right</li> <li>■ Bit 1=0: Display of feed override F</li> <li>■ Bit 1=1: Display of rapid traverse override R</li> <li>■ Bit 2=0: Display of feed override F</li> <li>■ Bit 2=1: Display of rapid traverse override R + feed override F</li> <li>■ Bit 3= 1: Display of the selected spindle</li> </ul> <p>As of NC software version 04, the channel number and the configured spindle name are displayed in addition.</p>










Image	Name	Display/Attribute
 <p>Utilization display of the spindle</p>  <p>Utilization display of an axis</p>  <p>Attribute=2 (bit 1=1) Utilization display showing the rotational speed limiting (only for spindles). The configured spindle name is displayed, as well.</p>	<p>LoadDisplay</p> <p>[DB_LD_C1, DB_LD_S1, DB_LD_X1, DB_LD_Z1]</p>	<p><b>Display:</b> Utilization of the drive of an axis (spindle, X, Z and C axes)</p> <p><b>Attributes:</b></p> <ul style="list-style-type: none"> <li>■ Bit 0=0: Digital drive; display data is supplied by the CC</li> <li>■ Bit 0=1: Analog drive; display data is supplied by the user PLC</li> <li>■ Bit 1=0: Without display of rotational speed limiting</li> <li>■ Bit 1=1: With display of the rotational speed limiting (only for spindles)</li> <li>■ Bit 3= 1: Display of the selected spindle</li> </ul>
 <p>Display of unit quantities and time per unit</p>  <p>Display of unit quantities</p>	<p>QuantityInformationAndTimePerUnit [DB_WPCT1]</p> <p>QuantityInformation [DB_WPC1]</p>	<p><b>Display:</b> Unit quantities and time per unit MP: Default unit quantity P: Number of finished parts t: Time in current program St: Total time</p> <p><b>Display:</b> Unit quantity MP: Default unit quantity P: Number of finished parts</p> <p>The quantity is incremented after each M30, M99 or M18 programmed counter pulse.</p>


Image	Name	Display/Attribute
 <p>RSM inactive, current datum shift = 0.000</p>  <p>RSM active, current datum shift = 1000.000</p>  <p>No RSM kinematics configured, current datum shift = 81.110</p>	<p>OperationInformation</p> <p>[DB_CH1_RSM]</p>	<p><b>Display:</b> Rear-face machining <b>(RearSideMachining)</b></p> <ul style="list-style-type: none"> <li>■ RSM status of the configured channel</li> <li>■ Active datum shift of the configured mirrored axis</li> </ul> <p>Configuration notes:</p> <p>The RSM channel to be displayed (e.g. CH_NC1) is configured in the element as default. The value of the associated "mirrored axis" (MP_mirAxis [605804]) is displayed as the current datum shift. If no RSM kinematics is configured, then instead of the RSM channel, an arbitrary axis (e.g. Z1) must be defined in the dashboard element under MP_entityList (DB_CH1_RSM.113103) because otherwise this element cannot be displayed in the dashboard. Then the datum shift for this axis is shown. The RSM status of the channel pertaining to the axis is also displayed. The mirror symbol on the right is missing, however, if no RSM kinematics has been configured for this channel. This configuration is useful on machines without RSM kinematics on which the current datum shift is to be displayed nevertheless.</p>
	<p>BlankField</p> <p>[DB_EMPTY]</p>	<p><b>Display:</b> Empty box</p>



## 7.3 PLC Soft Keys

In the vertical soft-key row, you can display your own soft keys through the PLC in all operating modes. Use the PLCdesignNT TNC soft key editor as of version 2.3 to create soft keys. The menu structure of the vertical soft-key row can be defined using the MenuDesign software (included in the PLCdesignNT package as of version 2.3). PLCdesignNT integrates the project file of MenuDesign in your PLC project. For more detailed information, please refer to the respective online help of the programs.

When a PLC soft key is pressed the NC enters the soft-key number in the PLC operand **NP\_GenSoftkeyVert**. On the rising edge of the keystroke it enters the soft-key number; on the falling edge it enters -1. The PLC can enter -1 itself after recognizing the soft-key number.



### 7.3.1 Soft-key resource file

Settings in the configuration editor	MP number
System Paths CfgPlcPath <b>softkeyProject</b>	102306

The PLC soft-key structure is defined with MenuDesign in an **\*.MDF** soft-key project file. Moreover, with MenuDesign you generate an **\*.XRS** soft-key resource file in which the structure and functionality of the soft-key menu is entered. The soft-key resource file has a structured XML format.

In the machine parameter **MP\_softkeyProject**, enter the path to the **\*.XRS** soft-key resource file. After acknowledgement of **Power interrupted**, the **\*.XRS** soft-key resource file is evaluated and the PLC soft-key structure is displayed.

For the soft-key graphics, use .bmx files, which you can create with the BMXdesign program. As an alternative, you can also use .bmp file for graphic soft keys. Note the online help of the programs for more detailed information.

#### Example of a soft-key resource file

```
<?xml version="1.0" encoding="ISO-8859-1" standalone = "yes"?>
<resource>
<imagelist id="1" >
  <image id="0" transparentColor="#c6c6c6" file="%OEM%\SK\Softkey1.bmx" variant="01"/>
  <image id="1" transparentColor="#c6c6c6" file="%OEM%\SK\Softkey2.bmx"/>
  <image id="2" transparentColor="#c6c6c6" file="%OEM%\SK\Softkey3.bmx"/>
  ...
</imagelist>
<!-- PLC root menuPLC Softkey Menu -->
<menu id="1" m304="W304" ImageListId="1" attributes="PLC | ROOT | VERTICAL | MANUAL |
AUTO | MULTI_LINE">
  <item id="100" ImageId="0" ItemType="TYPE_NODE" SubMenuId="2" />
  <item id="101" ImageId="1" ItemType="TYPE_NODE" SubMenuId="3" />
  <item id="102" ImageId="2" AltImageId="102" ItemType="TYPE_CHECKABLE"
status="MG_Softkey_1" />
  ...
</menu>
...
</resource>
```



Entries in the *.xrs file	Meaning
<?xml version="1.0" encoding="ISO-8859-1" standalone = "yes"?>	Basic structure of the XRS file (XML format); start entry of the file
<imagelist id="1" >	Beginning of the list with the soft-key graphics
<image id="0" transparentColor="#c6c6c6" file="%0EM%\SK\Softkey1.bmx" variant="01"/>	Definition of a soft-key graphic: Unique ID, color properties and path of the soft-key graphic file.
</imagelist>	End of the list with the soft-key graphics
<!-- PLC root menuPLC Softkey Menu -->	Comment
<pre> menu id="1" ImageListId="1" attributes="PLC   ROOT   VERTICAL   MANUAL   AUTO   MULTI_LINE" </pre>	<p>Defines a soft-key menu with soft-key graphics from the list with the ID "1". The following attributes are possible and can be combined using " ":</p> <p><b>PLC:</b> PLC soft-key row  <b>VERTICAL:</b> Vertical menu  <b>HORIZONTAL:</b> Horizontal menu  <b>ROOT:</b> Highest menu level  <b>MANUAL:</b> Menu for Manual operating mode  <b>AUTO:</b> Menu for Program Run operating mode  <b>EDIT:</b> Menu for Programming operating mode  <b>MULTI_LINE:</b> Menu with further levels  <b>ACTION_ON_PRESS:</b> Action is run when the soft key is pressed, not when it is released</p>
<pre> item id="100" ImageId="0" ItemType="TYPE_NODE" SubMenuId="2" </pre>	<p>Soft-key definition. The ID of the soft-key graphic file and the type of the soft key must be specified. The following types of soft keys are supported:</p> <p><b>TYPE_NODE:</b> Soft key jumps to a submenu. The name of the submenu must be entered under <b>SubMenuID=</b>.</p> <p><b>TYPE_RETURN:</b> Soft key returns from a submenu.</p> <p><b>TYPE_DUMMY:</b> Empty soft key</p> <p><b>TYPE_CONTINUOUS:</b> Function soft key</p> <p><b>TYPE_CHECKABLE:</b> A coupled marker is set the first time it is pressed, and is reset the next time.</p> <p><b>TYPE_RADIO:</b> From any group of these soft-key types, no more than one soft key can be pressed.</p>
</menu>	End of the soft-key menu
</resource>	End of the soft-key resource file



## Pop-up menu

A pop-up menu is called through an OEM soft key in the vertical soft-key row and covers the horizontal soft-key row with OEM soft-keys. This function is interesting, for example, when you need additional space for soft keys for more comprehensive tasks in the PLC (e.g. tool changer, pallet changer).

You can make pop-up menus with the MenuDesign program (provided in the PLCdesignNT package).

In the \*.XRS soft-key resource file, a pop-up menu is defined through the **PopupMenu=[name of the horizontal menu]** entry.

The **ClosePopup="„** entry marks the end of the pop-up menu.

Constraints:

- Only horizontal pop-up menus can be made.
- No more than one pop-up menu can be active at one time.
- A pop-up menu can be ended either with a vertical soft key (**ClosePopup="„**) or with the END soft key.
- A pop-up menu is always assigned to the operating mode from which the menu was called.



## Module 9203 Activate PLC soft-key menu

Module 9203 activates a soft-key menu that is indicated in the current soft-key resource file \*.XRS (machine parameter **MP\_softkeyProject**).

The PLC soft-key project can be defined in such a way that it is effective only for specific modes of operation. This might be useful, for example, if you want to use different PLC soft-key projects for the machine and programming modes of operation.

Call:

PS D <Resource handle>  
0 when it is called for the first time, otherwise  
Resource handle from Module 9203

PS B/W/D/K/S <Reserved>  
Transfer 0 or ""

PS B/W/D/K <Number of PLC soft-key menu>  
Number of the soft-key menu

PS B/W/D/K <Mode>  
Bit 0 = 0: Not allowed  
Bit 0 = 1: Vertical soft-key row  
Bit 1 = 0: A new soft-key menu is set up  
Bit 1 = 1: Return to the previous menu level.  
The value <number of PLC soft-key menu> is not  
evaluated.

PS B/W/D/K <Mode of operation>  
0: Programming modes of operation  
1: Machine modes of operation  
2: Programming and machine modes of operation  
3: Manual operating mode  
4: Automatic operating mode  
5: Editing operating mode  
6: Control operating mode

CM 9203

PL D <Resource handle>  
0: Error code in NN\_GenApiModuleErrorCode

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	No error
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Resource-handle overflow, incorrect resource handle, incorrect mode, incorrect operating mode or number of PLC soft-key root menu negative.
	20	Module was not called in a spawn or submit job
	44	Error in the resource file

### Module 9204 Update the PLC soft keys

If you want to restructure the PLC soft keys, you must call Module 9204. This is necessary each time you have called Module 9203.

Call:

PS D <Resource handle>  
Resource handle from Module 9203

CM 9204

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	No error
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Incorrect resource handle
	20	Module was not called in a spawn or submit job

### Module 9208 Status information of the PLC soft keys

Call:

PS D <Resource handle>  
Resource handle from Module 9203

PS B/W/D/K <Function>  
0: Number of the current soft-key menu

PS B/W/D/K <Reserved>  
0 transferred

CM 9208

PL D <Status information>

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	No error
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Incorrect resource handle or incorrect function
	20	Module was not called in a spawn or submit job
	44	Error finding the status information



## 7.4 Switching the Control On/Off

### 7.4.1 Powering up the control

**Start-up sequence** The control start-up comprises several phases, which are briefly described below. The points where OEMs can influence the start-up directly through entries or macros are described in detail.

Start-up sequence of the control:

■ **Step 1: BIOS loading process**

The BIOS stored in the EPROM of the MC main computer is loaded. BIOS stands for Basic Input Output System. The BIOS also checks the installed main memory and the individual peripherals.

■ **Step 2: HeROS boot process**

After the BIOS is loaded the control starts the HEIDENHAIN HeROS operating system (HEIDENHAIN Real-time Operating System).

■ **Step 3: Start the NC software**

HeROS starts the NC software. The start-up screen appears on the control monitor as well as a dialog box showing the number of the currently loaded process. During start-up the control reads the config data from the \*.cfg files. If the configuration contains errors or, for example, new and therefore yet uninitialized parameters from a software update, the boot process is interrupted. The code number dialog box appears. Enter the MP code number **95148** to open the configuration editor. All new or changed parameters are indicated by a red exclamation mark in the editor. Press the **SAVE** soft key to save the changed configuration and exit the configuration editor. The control then resumes the start-up sequence of the NC software.

■ **Step 4: Acknowledge the power interruption**

If so configured with **MP\_powerInterruptMsg**, see page 1314, the control waits until you confirm the **Power interrupted** message by pressing the CE key. If the machine configuration is incorrect, the power interruption can only be acknowledged after you have corrected the configuration.

■ **Step 5: Compile the PLC program**

After you press the CE key, the control compiles the PLC program and displays the **Compiling the PLC program** message. If the PLC program cannot be successfully compiled, you can view the errors in the PLC compiler's status window, contained in the editor of the PLC Programming operating mode.

■ **Step 6: Configure the CC controller unit (only digital control)**

The interpolator configures the CC controller unit and starts the DSPs. If errors occur, they are displayed in the error window (ERR key).

■ **Step 7: Test the EMERGENCY STOP**

Once the CC controller unit reports its readiness, the control starts the EMERGENCY STOP test. For more information on the process, see "Emergency stop monitoring" on page 989.

■ **Step 8: Run the start-up cycle**

The start-up cycle is run three times in total—once for the Program Run operating modes, once for the **Test Run** mode, and once for the **Programming and Editing** mode. During execution the control displays the message **Control is being initialized**. After the control start-up, the start-up cycle establishes a defined control condition.

■ **Step 9: Traverse the reference marks (if configured)**

In the last step, the control displays the **Traverse reference points** message prompting the operator to scan the reference marks in the axes. Then the start-up of the control is complete. The **Traverse Reference Marks** mode cannot be exited until all axes have been successfully referenced.

## Power interrupted message

Settings in the configuration editor	MP number
System DisplaySettings CfgStartupData <b>powerInterruptMsg</b>	101501

In **MP\_powerInterruptMsg**, you define the behavior during control start-up. You can choose between the following start-up procedures.

- The **Power interrupted** message is displayed during control start-up. Start-up is only continued after the message has been acknowledged.
- Start-up is not interrupted. The **Power interrupted** message does not appear.

### MP\_powerInterruptMsg

Acknowledge the **Power interrupted** message  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**  
Start-up is only continued after the message has been acknowledged.

**FALSE**  
The **Power interrupted** message does not appear.

Default: FALSE

Access: LEVEL3

Reaction: NOTHING

PLC operand / Description	Type
NN_GenCycleAfterPowerOn 1st PLC scan after power on	M
NN_GenCycleAfterPlcStop 1st PLC scan after interruption of the PLC program	M
NN_GenCycleAfterReConfig 1st PLC scan after changing of the configuration data	M
NN_GenNcInitialized Control is being initialized (after start-up cycles)	M



## Customer-specific logo

While the control is starting, a customer-specific company logo can be displayed instead of the HEIDENHAIN logo. The logo must be a bitmap file (\*.BMP) with a picture size of 1024 x 768 pixels.

Path and file name of bitmap file:

- PLC:\resource\startup\_1024x768.bmp




## Starting the control with empty PLC partition

During start-up, machine parameters are automatically transferred from the PLC partition. If the PLC partition does not contain any data, however (e.g. loss of data, partition inadvertently erased or initial operation), the control cannot be started.

If this occurs, you can access the control via TNCremoNT. This enables you to restore a PLC partition that has been backed up before.

Example:

During start-up, the control detects that the required machine parameter files are not available on the PLC partition. The start-up process is interrupted. The following dialog box appears:



(The machine parameters for configuring the conversational language are also stored on the PLC partition. Since these parameters are not available at present, English is set as the default language.)

- ▶ Use TNCremoNT to establish a connection to the control (the last valid Ethernet configuration is effective)
- ▶ Copy the data you saved before, with TNCbackup for example, back to the PLC partition
- ▶ Shut down the control by pressing the **OFF** soft key.
- ▶ Restart the control.

The system should work properly again.

### **Control start-up with faulty configuration**

If configuration errors occur during control start-up, the **Error during start-up** message appears instead of **Power interrupted**.

Also, the error messages for the incorrect configuration data, which are triggered by the applications, are displayed individually.



## 7.4.2 Shutting down the control

Settings in the configuration editor	MP number
System	
DisplaySettings	
CfgShutDown	
<b>shutdownOnConfig</b>	101601
<b>shutdownOnError</b>	101602
<b>shutdownOnUser</b>	101603
<b>shutdownOnOem</b>	101604
<b>maxTermTime</b>	101605
<b>powerOffDevice</b>	101608
<b>powerOffSlot</b>	101609
<b>powerOffPort</b>	101606
<b>powerOffDelay</b>	101607

The control must be shut down before it can be switched off. During shutdown the ready signal of the servo drives is removed and the memory card (or hard disk) is put into sleep mode. The shutdown can be delayed.

There are various causes for shutdown. In the parameter object **CfgShutDown** you define the behavior when the control is shut down, depending on the cause. A distinction is made between the following causes:

- **shutdownOnConfig:**  
Configuration data that cause a reset were changed.
- **shutdownOnError:**  
A severe error occurred.
- **shutdownOnUser:**  
The machine operator terminates control operation (by soft key).
- **shutdownOnOem:**  
The PLC program terminates control operation with Module 9279 or 9189.

**MP\_maxTermTime** specifies the maximum permissible time for all processes to be concluded. Use this parameter to define a time window within which shutdown has to be completed.

After shutting down the control, you can set a PLC output (to switch off the machine, for example). Systems with HSCI interface require other settings than systems without HSCI interface.

### Systems without HSCI interface:

- Use the **POWEROFF** setting for shutdown, or use Module 9279 – mode 2 to shut down the control.
- **MP\_powerOffPort** defines whether a PLC output is to be set after shutdown.  
Define a PLC output (O0 to O31) in **MP\_powerOffPort**.
- The setting of the PLC output can be delayed. If required, enter in **MP\_powerOffDelay** the time by which the setting of the PLC output is to be delayed.

## Systems with HSCI interface:




### Note

The following PLC outputs can be set automatically after shutdown:

- Freely available PLC outputs at X9 of a PL 62xx (system PL)
- PLC outputs at X6 of a UEC 11x

The output terminals that can be used are listed in the tables on the following pages.

- Use the **POWEROFF** setting for shutdown, or use Module 9279 – mode 2 to shut down the control.
- Set the parameter **MP\_powerOffDevice**:  
Every external PL in the HSCI system has a unique bus address. To define the PLC output to be set, you must specify the bus address of the affected system PL or the UEC 11x in parameter **MP\_powerOffDevice**. The bus address can be determined with the BUS DIAGNOSIS, for example:



- Set the parameter **MP\_powerOffSlot** = 0.
- Use **MP\_powerOffPort** to define the desired output terminal.  
Use the tables on the next page to determine the value for parameter **MP\_powerOffPort**.



**PL 62xx without functional safety, connection X9:**

<b>Terminal of the PLC output</b>	<b>Setting in MP_powerOffPort</b>
X9.3b	3
X9.4a	0
X9.4b	4
X9.5a	1
X9.5b	5
X9.6a	2
X9.6b	6

**UEC 11x without functional safety, connection X6:**

<b>Terminal of the PLC output</b>	<b>Setting in MP_powerOffPort</b>
X6.1a	4
X6.1b	0
X6.2a	5
X6.2b	1
X6.3a	6
X6.3b	2
X6.4a	7
X6.4b	3
X6.5a	12
X6.5b	8
X6.6a	13
X6.6b	9
X6.7a	14
X6.7b	10
X6.8a	15
X6.8b	11
X6.9a	20
X6.9b	16
X6.10a	21
X6.10b	17
X6.11a	22
X6.11b	18
X6.12b	19

- The setting of the PLC output can be delayed. If required, enter in **MP\_powerOffDelay** the time by which the setting of the PLC output is to be delayed.



## Machine parameters

### MP\_shutdownOnConfig

Behavior when RESET configuration data is changed  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **RESTART**

The control is shut down and then restarted.

#### **TERMINATE**

The control is shut down, but the operating system remains active.

#### **SHUTDOWN**

The control and the operating system are shut down.

#### **POWEROFF**

The control and the operating system are shut down. If a PLC output is entered in **MP\_powerOffPort**, it will be set after shutdown.

Default: RESTART

Access: LEVEL3

Reaction: NOTHING

### MP\_shutdownOnError

Behavior when RESET errors are acknowledged  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **RESTART**

The control is shut down and then restarted.

#### **TERMINATE**

The control is shut down, but the operating system remains active.

#### **SHUTDOWN**

The control and the operating system are shut down.

#### **POWEROFF**

The control and the operating system are shut down. If a PLC output is entered in **MP\_powerOffPort**, it will be set after shutdown.

Default: RESTART

Access: LEVEL3

Reaction: NOTHING



### MP\_shutdownOnUser

Behavior during switch-off by soft key  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **RESTART**

The control is shut down and then restarted.

**TERMINATE**

The control is shut down, but the operating system remains active.

**SHUTDOWN**

The control and the operating system are shut down.

**POWEROFF**

The control and the operating system are shut down. If a PLC output is entered in MP\_powerOffPort, it will be set after shutdown.

Default: TERMINATE

Access: LEVEL3

Reaction: NOTHING

### MP\_shutdownOnOem

Behavior when PLC module 9279 is called  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **RESTART**

The control is shut down and then restarted.

**TERMINATE**

The control is shut down, but the operating system remains active.

**SHUTDOWN**

The control and the operating system are shut down.

**POWEROFF**

The control and the operating system are shut down. If a PLC output is entered in MP\_powerOffPort, it will be set after shutdown.

Default: TERMINATE

Access: LEVEL3

Reaction: NOTHING

After shutdown has been initiated, the control waits for the time defined in **MP\_maxTermTime** before starting the shutdown.

### **MP\_maxTermTime**

Delay time until control is shut down  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0 to 1000 [s]  
Default: 0  
Access: LEVEL3  
Reaction: NOTHING

Both optional parameters **MP\_powerOffDevice** and **MP\_powerOffSlot** are relevant only for HSCI systems (e.g. TNC 620). No values are to be entered for controls without HSCI.

For an HSCI system, enter the bus address of the HSCI PL in the parameter **MP\_powerOffDevice**, e.g. the bus address of a PL 62xx or UEC 11x at which the control is to set a PLC output after shutting down.

### **MP\_powerOffDevice**

Bus address of the HSCI device  
Available from NCK software version: 597 110-04.  
Format: Numerical value  
Input: 0 to 20  
Default: No value, parameter optional  
Access: LEVEL1  
Reaction: NOTHING

For an HSCI system, enter in parameter **MP\_powerOffSlot** the number of a slot of the HSCI device defined under **MP\_powerOffDevice** at which a PLC output is to be set after shutdown. The system module of a PL 62xx or a UEC 11x has the number 0.

### **MP\_powerOffSlot**

Number of the slot on the HSCI device (PL or UEC)  
Available from NCK software version: 597 110-04.  
Format: Numerical value  
Input: 0 to 8  
Default: No value, parameter optional  
Access: LEVEL1  
Reaction: NOTHING



The entry in **MP\_powerOffPort** has the following meaning:

- The corresponding PLC output is set if the requirements described above are fulfilled (shutdown with **POWEROFF** setting or shutdown with Module 9279 – mode 2).
- No entry: No PLC output is set.

### **MP\_powerOffPort**

PLC output to be set after shutdown  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to 31: Corresponds to PLC outputs I0 to I31 for systems without HSCI  
For systems with HSCI, please see the device-specific table.  
No entry: Do not set PLC output.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

After shutdown, the control waits for the time defined in **MP\_powerOffDelay** before setting the PLC output.

### **MP\_powerOffDelay**

Delay time until PLC output is set  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to 1000 [s]  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

### **Module 9189 Shut down the control**

Module 9189 shuts down the control. The PLC is not executable after shutdown. The message windows, which appear during shutdown via soft key, do not appear.

Call:  
CM 9189

### **Error recognition:**

<b>Marker</b>	<b>Value</b>	<b>Meaning</b>
NN_GenApiModule Error	0	Control was shut down
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	20	Module was not called in a spawn job or submit job

### Module 9279 Shut down control (configurable)

The module terminates control operation. The behavior during shutdown of the control is defined in a transfer parameter.

Constraints:

- After the module has been called, the file system updates the data on the memory card (or hard disk) and closes all files.
- The module cannot be called in the cyclic PLC program since all accesses to the hard disk by the PLC must be implemented in a submit or spawn job.
- The PLC is not executable after shutdown.
- If mode 1 is active, a control reset is triggered immediately after shutdown.
- The module call does not result in any outputs on the screen.

Call:

PS     B/W/D/K   <Mode>  
                  0: Shut down the control  
                  1: Shut down and restart the control  
                  2: Shut down the control; then set the PLC output from  
                      MP\_powerOffPort (if defined).

CM     9279

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Control reset was carried out
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	20	Module was not called in a spawn job or submit job





## 7.5 Keystroke Simulation

The MANUALplus 620 features two control panels:

- Control keyboard
- MB 620T machine operating panel (from HEIDENHAIN) or a machine operating panel from the OEM

The machine operating panel is connected over an HSCI cable to the MC 6110T.

The key code of the control keyboard is evaluated directly by the NC.

The machine operating panel has PLC inputs and outputs which you must evaluate in the PLC.

### 7.5.1 Control keyboard

The key code is displayed in **NP\_GenKeyCode** while a key of the control keyboard is being pressed, see see "Codes for keystroke simulation" on page 1329.

PLC operand / Description	Type
NP_GenKeyCode Code of the depressed key	D



#### Note

The code of the key actually pressed is always saved in **NP\_GenKeyCode**. Characters entered using the "cell-phone-style keypad" are not stored in this PLC operand. Instead, the code of the numeric key you pressed is displayed n times.

The following modules can influence keys and soft keys:

- Module 9180: Simulate NC keys
- Module 9181: Disable individual NC keys
- Module 9182: Re-enable individual NC keys
- Module 9183: Disable groups of NC keys
- Module 9184: Re-enable groups of NC keys

### Module 9180 Keystroke simulation

The module simulates NC keys and soft keys. You transfer the code of the desired key.

If you transfer the code value zero, the number of occupied elements in the keystroke queue is returned. In this case there is no keystroke simulation.

Call:

PS B/W/D/K <Key code>

CM 9180

PL B/W/D <Number of occupied elements / error status>

0: Key code was transferred, key queue is empty

1 to 16 : Key code was not yet simulated, max. 16 entries in the keystroke queue are possible

-1: For error see NN\_GenApiModuleErrorCode

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	NC key was simulated
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Transferred parameter > maximum value
	2	Transferred parameter invalid
	22	Keystroke queue overflow

### Module 9181 Disable NC key by PLC

The module disables individual NC keys.

Call:

PS B/W/D/K <Key code>

CM 9181

PL B/W/D <Error status>

0: NC key disabled

-1: For error see NN\_GenApiModuleErrorCode

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	NC key was disabled
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Transferred parameter > maximum value
	2	Transferred parameter invalid



### Module 9182 Re-enable NC key by PLC

The module cancels the effect of Module 9181.

Call:

PS B/W/D/K <Key code>

CM 9182

PL B/W/D <Error status>

0: NC key enabled

-1: For error see NN\_GenApiModuleErrorCode

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Disabling was canceled
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Transferred parameter > maximum value
	2	Transferred parameter invalid

### Module 9183 Disable NC key groups by PLC

The module disables the specified key group. The table at the end of this section contains the assignment of the keys to the key groups.

The key-group codes are:

- 0: All keys
- 1: ASCII
- 2: Soft keys, Page Up/Down
- 3: Cursor, ENT, NOENT, DEL, END, GOTO
- 4: Numbers, algebraic signs, decimal point, actual position capture
- 5: Operating modes
- 6: Block opening keys

Call:

PS B/W/D/K <Key-group code>

CM 9183

PL B/W/D <Error status>

0: Group of NC keys disabled

-1: Transferred parameter > maximum value

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	The group of NC keys was disabled
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Transferred parameter invalid

### Module 9184 Re-enable locked NC key groups by PLC

The module cancels the effect of Module 9183 for the given key group. The table at the end of this section contains the assignment of the keys to the key groups.

The key-group codes are:

- 0: All keys
- 1: ASCII
- 2: Soft keys, Page Up/Down
- 3: Cursor, ENT, NOENT, DEL, END, GOTO
- 4: Numbers, algebraic signs, decimal point, actual position capture
- 5: Operating modes
- 6: Block opening keys

Call:

PS B/W/D/K <Key-group code>

CM 9184

PL B/W/D <Error status>

0: Group of NC keys enabled

-1: Transferred parameter > maximum value

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Disabling was canceled
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Transferred parameter invalid



**Codes for keystroke simulation**

The following table takes into account all keys used on the MANUALplus 620. Please note, however, that not all the keys listed in the table must necessarily be available on your keyboard.

Code	Key	Group
\$08	BACKSPACE	ASCII
\$0A	ENT (Return)	ASCII
\$1B	ESC	ASCII
\$20	SPACE	ASCII
\$21	!	ASCII
\$22	„	ASCII
\$23	#	ASCII
\$24	\$	ASCII
\$25	%	ASCII
\$26	&	ASCII
\$28	(	ASCII
\$29	)	ASCII
\$2A	*	ASCII
\$2B	+	ASCII
\$2C	,	ASCII
\$2D	–	ASCII
\$2E	. (ASCII DOT)	ASCII
\$2F	/	ASCII
\$30	0	Numbers
\$31	1	Numbers
\$32	2	Numbers
\$33	3	Numbers
\$34	4	Numbers
\$35	5	Numbers
\$36	6	Numbers
\$37	7	Numbers
\$38	8	Numbers
\$39	9	Numbers
\$3A	:	ASCII
\$3B	;	ASCII
\$3C	<	ASCII
\$3D	=	ASCII
\$3E	>	ASCII
\$3F	?	ASCII
\$41	A	ASCII
\$42	B	ASCII
\$43	C	ASCII
\$44	D	ASCII
\$45	E	ASCII

Code	Key	Group
\$160	Soft key 0	Vertical soft key
\$161	Soft key 1	Vertical soft key
\$162	Soft key 2	Vertical soft key
\$163	Soft key 3	Vertical soft key
\$164	Soft key 4	Vertical soft key
\$165	Soft key 5	Vertical soft key
\$17D	FNEXT (vertical)	Vertical soft key
\$180	Soft key 0	Horiz. soft key
\$181	Soft key 1	Horiz. soft key
\$182	Soft key 2	Horiz. soft key
\$183	Soft key 3	Horiz. soft key
\$184	Soft key 4	Horiz. soft key
\$185	Soft key 5	Horiz. soft key
\$186	Soft key 6	Horiz. soft key
\$187	Soft key 7	Horiz. soft key
\$19C	FBACK	Horiz. soft key
\$19D	FNEXT (horizontal)	Horiz. soft key
\$19E	FNEXT-UP	Horiz. soft key
\$1A0	C-UP	Cursor
\$1A1	C-DOWN	Cursor
\$1A2	C-LEFT	Cursor
\$1A3	C-RIGHT	Cursor
\$1A8	ENTER	Cursor
\$1A9	NO-ENTER	Cursor
\$1AB	DEL	Cursor
\$1AC	END BLOCK	Cursor
\$1AD	GOTO	Cursor
\$1AE	CE	
\$1BC	+/-	Numbers
\$1BD	.	Numbers
\$1C0	Machine	Operating mode
\$1C4	DINplus	Operating mode
\$1C5	Tool editor	Operating mode
\$1C7	Machine para.	Operating mode
\$1E9	Err	
\$1EF	Calc	
Empty key = no code		
\$1EE	I (Info)	
\$1EB	Circle with three arrows	





## 7.5.2 Machine operating panel

The machine operating panel provides PLC inputs and PLC outputs for evaluating its keys. Use the IOconfig PC software to link the inputs and outputs of the machine operating panel with the PLC operands.

PLC operand / Description	Type
PP_AxTraversePos Manual traverse in positive direction 0: Do not move axis 1: Move axis	M
PP_AxTraverseNeg Manual traverse in negative direction 0: Do not move axis 1: Move axis	M
PP_ChnRapidTraverseKey Rapid-traverse key 0: Rapid-traverse key not pressed 1: Rapid-traverse key pressed	M





## 7.6 Electronic Handwheel

The control supports:

- Handwheels that are connected to the serial handwheel input X23 of the MC or, for controls, with HSCI to X23 of the machine operating panel.
- Handwheels with position encoders, which are connected to the position encoder inputs of the MC.

For information about mounting and electrical connection, see "Handwheel Input" on page 287.

You can connect the following handwheels to the handwheel input (X23) of your control:

- One panel-mounted HR 130 or HR 330 handwheel, or
- One HR 410 portable handwheel
- Up to three HR 150 handwheels via HRA 110 handwheel adapter

For information about mounting and electrical connection, see "HRA 110 handwheel adapter" on page 290.

As an alternative, or additionally, you can connect the HR 180 handwheel to the position encoder inputs of the MC.

- ▶ Define the type of handwheel, or the connection of the handwheel to the control, in **MP\_type**. If the handwheel is connected to a position encoder input, the handwheel connection is described in the configuration object **CfgAxisHandwheel**.
- ▶ If an HRA 110 is used, the axis-specific description of the counting direction and the traverse per handwheel revolution is in the **CfgAxisHandwheel** configuration object.

### 7.6.1 Serial handwheel

Settings in the configuration editor	MP number
System	
CfgHandwheel	
<b>type</b>	100601
<b>initValues</b>	100602
<b>incrPerRevol</b>	100603
<b>rasterPerRevol</b>	100604
<b>countDir</b>	100605
<b>sensitivity</b>	100606
<b>speedFactor</b>	100607
<b>feedFactor</b>	100608
<b>crossShortSafety</b>	100609
<b>selectAxes</b>	

## Type of handwheel

### MP\_type

Handwheel  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **NONE**  
No handwheel connected  
**HRMAX**  
HRA 110 handwheel adapter connected to X23  
**HR410**  
HR 410 connected to X23  
**HR332**  
HR 332 connected to X23  
**HR330**  
HR 330 connected to X23  
**HR130**  
HR 130 connected to X23

Default: NONE

Access: LEVEL3

Reaction: RUN

## Handwheel initialization

You enter initialization values for serial handwheels in **MP\_initValues**. During startup, the control transfers the initialization values to the handwheel.

Information about the initialization values:

- HR 410: see "HR 410 portable handwheel" on page 1348
- HR 130: No initialization values are necessary for this model
- HRA 110 with HR 150: see "HR 150 panel-mounted handwheels with HRA 110 handwheel adapter" on page 1350

### MP\_initValues

Initialization values for handwheel  
Available from NCK software version: 597 110-01.

Format: Array [7]

Input: 0 to 255

Default: 0

Access: LEVEL3

Reaction: RUN



## Evaluation of handwheel pulses

Define the evaluation of the handwheel pulses in the following parameters:

- ▶ **MP\_incrPerRevol**: Number of increments per handwheel revolution
- ▶ **MP\_rasterPerRevol**: Detent steps per handwheel revolution (only for handwheels with detent)
- ▶ **MP\_countDir**: Direction for handwheel input

### MP\_incrPerRevol

Increments per handwheel revolution  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0 to max. value  
0: Standard value for HEIDENHAIN handwheel (20 000 increments)  
Default: 0  
Access: LEVEL3  
Reaction: RUN

### MP\_rasterPerRevol

Detent steps per handwheel revolution  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0 to max. value  
0: Handwheel without detent  
Default: 0  
Access: LEVEL3  
Reaction: RUN

### MP\_countDir

Counting direction for handwheel  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: **positive**  
Positive counting direction  
**negative**  
Negative counting direction  
Default: positive  
Access: LEVEL3  
Reaction: RUN

## Threshold sensitivity

Shock or vibrations can cause a slight motion at the handwheel and produce an unintentional axis movement.

- ▶ In **MP\_sensitivity**, enter a threshold sensitivity, in order to avoid unintentional movements.

### MP\_sensitivity

Sensitivity for electronic handwheel  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to 10 000 [pulses]  
Default: 10 [pulses]  
Access: LEVEL3  
Reaction: RUN

## Handwheel with manual direction keys

For handwheels with manual axis-direction keys (e.g. HR 410), you define three feed rates in **MP\_feedFactor**. These entries refer to the feed rate entered in **MP\_manualFeed** (CfgFeedLimits). In the parameter **MP\_speedFactor** you define three transmission ratios for the distance traversed per handwheel revolution configured in **MP\_distPerRevol**.

### MP\_speedFactor

Handwheel transmission ratio  
Available from NCK software version: 597 110-02.

Format: Array [0...2]  
Input: [0] = First transmission ratio in [%]  
[2] = Second transmission ratio in [%]  
[3] = Third transmission ratio in [%]  
Distance per handwheel revolution:  
Transmission ratio · **CfgAxisHandwheel/distPerRevol**

Default: [0] = 1  
[1] = 10  
[2] = 100

Access: LEVEL3  
Reaction: RUN

### MP\_feedFactor

Manual feed rates in the Electronic Handwheel mode  
Available from NCK software version: 597 110-01.

Format: Array [0...2]  
Input: 0 to 100 [%]  
[0] = First feed rate in [%]  
[1] = Second feed rate in [%]  
[2] = Third feed rate in [%]

Default: 1, 10 and 100 [%]  
Access: LEVEL3  
Reaction: RUN



#### Note

**MP\_feedFactor** is only valid in the **Electronic Handwheel** operating mode, but then for all manual axis-direction keys including the manual axis-direction keys of the operating panel.

In **MP\_crossShortSafety** you define whether a short-circuit test is to be performed on the permissive buttons.

### **MP\_crossShortSafety**

Cross-circuit-proof handwheel  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: **on**  
Cross-circuit test on  
**off**  
Cross-circuit test off  
Default: off  
Access: LEVEL3  
Reaction: RUN

With **MP\_selectAxes** you specify which axes are to be controlled with the handwheel configured under **MP\_type**. If, with a handwheel with axis keys (e.g. HR 410), you evaluate the key through the NC, then use **MP\_selectAxes** to assign an axis key to an axis.



#### Note

**MP\_selectAxes** only works for handwheels with axis keys (e.g. HR 410) and the HR 150 panel-mounted handwheel (with the HRA 110 handwheel adapter). The parameter has no function for panel-mounted handwheels of the model HR 130—use the PLC Module 9036 for the axis assignment.

## MP\_selectAxes

Selection of axes for the handwheel  
Available from NCK software version: 597 110-05.

Format: Array

Input: Selection of axes that can be moved with the handwheel.

### **On portable handwheels with axis keys, e.g. HR 410:**

(with evaluation of the keys by NC)

Make a list entry for each axis key on the handwheel. The sequence of the list sets the assignment to the axis keys X, Y, Z, IV, V on the handwheel.

### **With HR 150 panel-mounted handwheels through HRA 110:**

Handwheel on X1 of HRA 110: 1st list entry

Handwheel on X2 of HRA 110: 2nd list entry

Handwheel on X3 of HRA 110: The initialization parameters and the position of the selection switch set which list entry is to be used.

### **With HR 130 panel-mounted handwheel:**

Do not define parameter. The axes are assigned via the PLC program (e.g. Module 9036).

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN



### Note

**MP\_selectAxes** is evaluated while the control starts up. If the axis assignment of the handwheel is changed via Module 9036 while the control is running, the PLC program has priority and temporarily overwrites the setting of **MP\_selectAxes**.

## Disabling the handwheel

Disable handwheel pulses for specific axes with **PP\_AxHandwheelLocked**.  
Disable the handwheel pulses for all axes with **PP\_GenHandwheelLocked**. If **PP\_GenHandwheelLocked** is reset, axis-specific disabling of **PP\_AxHandwheelLocked** is effective again.

PLC operand / Description	Type
PP_GenHandwheelLocked Disable handwheel motion 0: Enable handwheel motions for all axes 1: Handwheel motions for all axes disabled	M
PP_AxHandwheelLocked Disable handwheel motion for specific axes 0: Enable handwheel motions for this axis 1: Handwheel motions for this axis disabled	M



## 7.6.2 Handwheel at position encoder input

Settings in the configuration editor	MP number
Axes	
ParameterSets	
[Key name of the parameter set]	
CfgAxisHandwheel	
<b>input</b>	400201
<b>hsciCclIndex</b>	400210
<b>countDir</b>	400202
<b>distPerRevol</b>	400203
<b>incrPerRevol</b>	400204
<b>rasterPerRevol</b>	400205
<b>encoderSignal</b>	400206
<b>encoderFreq</b>	400207
<b>encoderResistor</b>	400208
<b>decToSoftLimit</b>	400209

### Handwheel connection



#### Note

You define the handwheel parameters within the parameter set of an axis. This permanently assigns the handwheel to **this axis**. You can assign the handwheel to a different axis, for example, by changing to a different parameter set.

Define the handwheel connection in the following parameters:

- ▶ **MP\_input**: Assignment of handwheel to position encoder input
- ▶ **MP\_hsciCclIndex**: Index of the CC controller unit to which the handwheel is connected
- ▶ **MP\_EncoderSignal**: 1 V<sub>pp</sub> or 11 μA<sub>pp</sub> signal
- ▶ **MP\_EncoderFreq**: Maximum input frequency
- ▶ **MP\_EncoderResistor**: Terminating resistor

### MP\_input

Connection of the encoder handwheel  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **none**  
No handwheel connected to position encoder input  
**X01 to X06**  
Handwheel connected to X01 to X06 of the MC  
**X35 to X38**  
Handwheel connected to X35 to X38 of the MC  
**X201 to X210**  
Handwheel connected to X201 to X210 of the CC

Default: none

Access: LEVEL3

Reaction: NOTHING

### MP\_hsciCIndex

Index of the CC controller unit on the HSCI chain  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: If more than one CC controller unit is used on the HSCI chain, enter the CC index for the position encoder input to which the handwheel is connected. Only the CCs are counted, further HSCI devices (e.g. PLs) are not relevant.  
If only one CC is used (TNC 620), enter the value 0.

Default: 0

Access: LEVEL3

Reaction: NOTHING

### MP\_encoderSignal

Signal amplitude at position encoder input for handwheel  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **1 Vpp**  
Input signal of encoder is 1 Vpp signal.

**11 uA**

The input signal of the encoder is an 11  $\mu$ A signal.  
This setting is not supported by the CC 61xx controller unit! If the value is set nevertheless, the control outputs the **0400: 11 uA not supported** error message.

**TTL**

The input signal of the encoder is a TTL signal.

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING





### MP\_encoderFreq

Input frequency of position encoder input for handwheel  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **fast**  
Input frequency is 350 kHz  
**slow**  
Input frequency is 50 kHz

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING

### MP\_encoderResistor

Terminating resistor of position-encoder input for handwheel  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **without**  
Without terminating resistor  
**120 ohms**  
With terminating resistor

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING

## Evaluation of handwheel pulses

Define the evaluation of the handwheel pulses in the following parameters:

- ▶ **MP\_countDir**: Counting direction of the handwheel for this axis. If a serial handwheel or an HRA 110 is connected to X23, the counting direction can be specified for each axis.
- ▶ **MP\_distPerRevol**: Path of the axis per handwheel revolution. The value applies to all connected handwheels, including serial handwheels at X23. With this parameter a traverse per handwheel revolution for each axis can be entered for HR 150 handwheels connected to HR 110. The value is multiplied by the entry in **MP\_speedFactor** (CfgHandwheel).
- ▶ **MP\_incrPerRevol**: Number of increments per handwheel revolution
- ▶ **MP\_rasterPerRevol**: Detent steps per handwheel revolution (only for handwheels with detent)

### **MP\_distPerRevol**

Axis traverse per handwheel revolution  
Available from NCK software version: 597 110-02.

Format: Numerical value  
Input: Distance in [mm] with up to 9 decimal places  
Applies for **all** connected handwheels (handwheel at position input and at X23).  
The value is multiplied by **MP\_speedFactor** (CfgHandwheel).

Default: 1 [mm]  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_incrPerRevol**

Increments per revolution of handwheel at encoder input  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to max. value  
Default: 1024  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_rasterPerRevol**

Detent steps per revolution of handwheel at encoder input  
Available from NCK software version: 597 110-01.

Format: Array  
Input: 0 to max. value  
0: Handwheel without detent  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING



## Handwheel positioning up to software limit switch

The optional parameter **MP\_decToSoftLimit** is used to specify a braking ramp for handwheel-positioning of the axis to the software limit switch. Limit the maximum axis speed with **MP\_decToSoftLimit** such that no overshoot of the axis occurs when the software limit switch is reached.

Proceed as follows to determine the value to be set for the **MP\_decToSoftLimit** parameter:

- ▶ Record the current speed of the axis **v (N act)** with the integrated oscilloscope.
- ▶ During measurement with the oscilloscope, quickly move the axis to the software limit switch with the axis handwheel.

The control uses the following formula for limiting the maximum possible speed on reaching the software limit switch:

$$V_{max} = \sqrt{2 \cdot \text{distance to software limit switch} \cdot \text{MP\_decToSoftLimit}}$$

- ▶ Experiment with various values for the parameter **MP\_decToSoftLimit** and compare the different oscilloscope results with each other.

### MP\_decToSoftLimit

Brake ramp for handwheel motions to the software limit switch (MP\_swLimitSwitchPos and MP\_swLimitSwitchNeg)  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 0.000 000 000 to max. value [m/s<sup>2</sup>]

For rotary axes, the brake ramp is specified in [1000°/s<sup>2</sup>].

0: Value from **MP\_maxAcceleration** is used

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING

### 7.6.3 Traverse per handwheel revolution

Settings in the configuration editor	MP number
System CfgHandwheel <b>speedFactor</b>	100607
Axes ParameterSets [Key name of the parameter set] CfgAxisHandwheel <b>distPerRevol</b>	400203

The distance covered by an axis per handwheel revolution depends on the traverse per handwheel revolution and the handwheel transmission ratio.

- ▶ In **MP\_distPerRevol**, define the distance traversed per handwheel revolution for each axis moved by handwheel.
- ▶ In **MP\_speedFactor**, define the handwheel transmission for three transmission ratios.

#### **MP\_distPerRevol**

Traverse per handwheel revolution  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 000 001 to max. value [mm]  
Default: 1 [mm]  
Access: LEVEL3  
Reaction: NOTHING

#### **MP\_speedFactor**

Handwheel transmission ratio  
Available from NCK software version: 597 110-01.

Format: Array [0...2]  
Input: 0 to 100 [%]  
[0] = First ratio in [%]  
[1] = Second ratio in [%]  
[2] = Third ratio in [%]  
Default: 1, 10 and 100 [%]  
Access: LEVEL3  
Reaction: RUN

The transmission ratio is set either at the control panel or directly on the handwheel.



## 7.6.4 Assigning a handwheel to an axis

Module 9036 allows you to assign a handwheel connected to connection X23 to an axis (NC or PLC axis). The module also defines the transmission ratio.

As an alternative, you can define the axis assignment for an HR 410 (with evaluation of the keys by the NC) or for three HR 150s via HRA 110 through **MP\_selectAxes**; see "MP\_selectAxes" on page 1338.

Use Module 9035 to find the axis to which the handwheel is assigned.

### Module 9036 Write NC status information

The module modifies status information from the NC. The status information to be modified is transferred by function number.

- **Select the handwheel axis** function: The handwheel connected to connector X23 of the MC is assigned to an axis.
- **Set the handwheel transmission ratio:** The handwheel transmission ratio is defined.

You can change the following status information:

Number of the function	Function	Value
0	Handwheel subdivision X	0 to 10: Subdivision factors
1	Handwheel subdivision Y	0 to 10: Subdivision factors
2	Handwheel subdivision Z	0 to 10: Subdivision factors
3	Handwheel subdivision IV	0 to 10: Subdivision factors
4	Handwheel subdivision V	0 to 10: Subdivision factors
5	Handwheel subdivision for all axes	0 to 10: Subdivision factors
6	Select the handwheel axis	Index from MP_axisList or -1: Deselect all axes
7	Set the handwheel transmission ratio	■ 0: Slow ■ 1: Normal ■ 2: Fast
8	Reserved	–
9	Reserved	–
10	Limit value for jog increment	0.0001 mm to 50 mm or -1: Cancel the limiting 2: New jog increment = minimum (programmed jog increment, previous limit value) and cancel limitation
11..19	Handwheel subdivision of axes 1 to 9	0 to 10: Subdivision factors



#### Note

On the MANUALplus 620, only function 6 "Select the handwheel axis" from the table above is used.

Constraints:

- Handwheel subdivision factors are limited to the smallest possible value in accordance with the rapid traverse of the corresponding axis. This does not result in an error message, however.
- Call codes 0 to 4 refer to the 5 axes assigned to the axis keys X/Y/Z/IV/V. Call codes 11 to 19 refer to the internal axis numeration.
- The value for the jog increment limitation is transferred in [1/10000 mm].
- If a jog limitation is entered in the inch mode, the limitation value [degrees] for rotary axes is calculated from the limitation value [mm] / 24.5.

Possible errors:

- The input parameter <Number of the function> does not refer to any overwriteable status information in this software version.
- The transferred value is outside of the range valid for this status information.
- Entry of this status information is disabled, e.g. via the machine configuration.

Call:

PS B/W/D/K <Number of the function>  
PS B/W/D/K <Value to be written>  
CM 9036  
PL B/W/D <Error code>  
0: Status written  
1: Incorrect status code  
2: Transferred value is out of range  
3: Input disabled

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Status information was written
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Transferred value is out of range
	2	Incorrect number of the status information
	3	Transferred value is out of range
	6	Input disabled

#### Module 9035 Read NC status information

The module reads status information from the NC. The status information to be read is transferred by function number.



The following handwheel information can be read:

Transferred number		Return code
9	Handwheel axis	Finds the axis which is assigned to the handwheel connected to connection X23 of the MC.  -1: None or more than one 0: X axis 1: Y axis 2: Z axis 3: IV axis 4: V axis 5: VI axis 6: VII axis etc.
10	Handwheel axis, bit-encoded	Bit 0: X axis Bit 1: Y axis Bit 2: Z axis Bit 3: IV axis Bits 4 to 13: Axes 4 to 14 (only available for PLC programs that work with API 1.0)
	Handwheel subdivision factor	
11	X key	0 to 10
12	Y key	
13	Z key	
14	IV key	
15	V key	
20	HR 410 speed	0: Slow 1: Medium 2: Fast
	Handwheel subdivision factor	
31	Axis 1	0 to 10
32	Axis 2	
33	Axis 3	
34	Axis 4	
35	Axis 5	
36	Axis 6	
37	Axis 7	
38	Axis 8	
39	Axis 9	

Call:

PS B/W/D/K <Number of the function>

CM 9035

PL B/W/D <Status information>

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	No error
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Status information invalid
	20	Call was not in a submit or spawn job

## 7.6.5 HR 410 portable handwheel

- ▶ In **MP\_type**, select HR 410.
- ▶ In **MP\_initValues**, define whether the keys on the handwheel are evaluated by the NC or PLC.

### Initialization values for HR 410 handwheel:

- **MP\_initValues** [0]:
  - 0: Evaluation of the keys by NC, including LEDs, except for three function keys
  - 1: Evaluation of the keys by PLC
- Entry in **MP\_initValues** [1 to 7]: Reserved

Keys evaluated by the NC: <b>MP_initValues [0] = 0</b>			Keys evaluated by the PLC: <b>MP_initValues [0] = 1</b>		
X		IV	O96 I160		O97 I161
Y		V	O98 I162		O99 I163
Z		ISTWERT- ÜBER- NAHME	O100 I164		O103 I167
VORSCHUB KLEIN	VORSCHUB MITTEL	VORSCHUB GROB	O104 I168	O105 I169	O106 I170
-		+	I171		I172
O109 I173	O110 I174	O111 I175	O109 I173	O110 I174	O111 I175



The function keys I173 to I175 are always evaluated by the PLC.

Assignment of axis keys:

- When the keys are evaluated by the NC, use **MP\_selectAxes** to define the assignment of axis keys (the key designations refer to the figure on the previous page):
  - X key: **MP\_selectAxes** [0]
  - Y key: **MP\_selectAxes** [1]
  - Z key: **MP\_selectAxes** [2]
  - IV key: **MP\_selectAxes** [3]
  - V key: **MP\_selectAxes** [4]
- When the keys are evaluated by the PLC, the handwheel axis is selected with Module 9036. This is the only case in which a PLC axis can be assigned to the handwheel with Module 9036.

Use the three feed rates from **MP\_feedFactor** to influence the feed rate when you press an axis-direction key. You set the feed rate on the HR 410 (keys for low feed rate, medium feed rate, and high feed rate).

## 7.6.6 HR 150 panel-mounted handwheels with HRA 110 handwheel adapter

- ▶ In **MP\_type**, select HRNAX.
- ▶ With **MP\_selectAxes [0,1]**, define the assignment of the first and second handwheel (connections X1 and X2 on the HRA 110)
- ▶ With **MP\_selectAxes [2]** and the initialization values in **MP\_initValues**, define the assignment of the third handwheel (connection X3 on the HRA 110). The handwheel can be set either permanently to one axis or variably through the step switch S2 on the HRA 110.
  - Settings for a fixed assignment of the third handwheel:
    - **MP\_selectAxes [2]**: Enter axis
    - **MP\_initValues [0]**: No entry
    - **MP\_initValues [1]** = 4
    - **MP\_initValues [2]** = 1
  - Settings for a variable assignment of the third handwheel:
    - **MP\_selectAxes [2..4]**: Enter axes for the third handwheel
    - **MP\_initValues [0]**: Define assignment of switch positions. See below.
    - **MP\_initValues [1]**: No entry
    - **MP\_initValues [2]** = 0



### Note

- Through the config object **CfgAxisHandwheel** you can specify for each axis the counting direction and the distance per handwheel revolution. To do so, open the config object **CfgAxisHandwheel** in the parameter set of the desired axis. Enter the values in **MP\_countDir** and **MP\_distPerRevol**.
- The parameters **MP\_incrPerRevol**, **MP\_rasterPerRevol** and **MP\_countDir** (from System/CfgHandwheel) apply globally for all handwheels connected to the HRA 110. The values in CfgAxisHandwheel overwrite these global values.

### Initialization of the handwheel adapter

#### Initialization values for HRA 110 handwheel adapter:

- **MP\_initValues[0]** – Assignment of the third handwheel:
  - 0: Switch position 1 – axis in MP\_selectAxes [2]  
Switch position 2 – axis in MP\_selectAxes [3]  
Switch position 3 – axis in MP\_selectAxes [4]
  - 1: Switch position 1 – axis in MP\_selectAxes [0]  
Switch position 2 – axis in MP\_selectAxes [1]  
Switch position 3 – axis in MP\_selectAxes [2]  
Switch position 4 – axis in MP\_selectAxes [3]  
Switch position 5 – axis in MP\_selectAxes [4]
  - 2: Switch position 3 – axis in MP\_selectAxes [2]  
Switch position 4 – axis in MP\_selectAxes [3]  
Switch position 5 – axis in MP\_selectAxes [4]



- **MP\_initValues [1]** – for permanent assignment of the third handwheel, the following applies:
  - 1: Axis in MP\_selectAxes [0]
  - 2: Axis in MP\_selectAxes [1]
  - 4: Axis in MP\_selectAxes [2]
  - 8: Axis in MP\_selectAxes [3]
  - 16: Axis in MP\_selectAxes [4]
- **MP\_initValues [2]** – assignment of the third handwheel:
  - 0: Axis selection switch as defined in MP\_initValues[0]
  - 1: Permanently as defined in **MP\_initValues[1]**
- **Entry in MP\_initValues [3 to 7]:** Reserved

Switch position 1 on the HRA 110 corresponds to the left stop.

### Assignment of switch positions to PLC inputs

The tables below list the assignments of switch positions of S1 and S2 to the PLC inputs I160 to I175.

The two switches work with a 0 V logic circuit.

Example: If switch S1 is in position 3, input I162 is logically 0, and the inputs I160, I161, I163 to I167 are logically 1.

Step switch 1

Switch position	PLC input
1 (at the left stop)	I160
2	I161
3	I162
4	I163
5	I164
6	I165
7	I166
8 (at the right stop)	I167

Step switch 2: Axis selection switch

Switch position	PLC input
1 (at the left stop)	I168
2	I169
3	I170
4	I171
5	I172
6	I173
7	I174
8 (at the right stop)	I175

## 7.7 Override

### 7.7.1 Override devices

Settings in the configuration editor	MP number
System PLC CfgPlcOverrideDev [Key name of override device]	
<b>source</b>	104301
<b>mop</b>	104304
<b>mode</b>	104302
<b>values</b>	104303

The control supports the following override devices:

- Up to three potentiometers
- Group of keys (you can use two machine operating keys for setting the override value).

The input values of the override devices (potentiometer setting or key input) are evaluated as follows:

■ **DISCRETE:**

The control converts the input values into a maximum of 64 discrete override values.

■ **LINEAR:**

The control interpolates the input values linearly between the minimum and maximum override value.

■ **CURVE:**

The control uses a curve to convert the lower input values into override values. In this way you can achieve a finer resolution of the lower override values. Higher input values are again interpolated linearly.

Define the override devices as follows:

- ▶ For each override device, insert a data record under **CfgPlcOverrideDev** and assign a key name.
- ▶ Define the source for the override device in **MP\_source**:
  - OVR1:** Feed-rate override input **F** on the rear side of the TE.
  - OVR2:** Spindle-speed override input **S** on the rear side of the TE.
  - OVR3:** Rapid-traverse override input **E** on the rear side of the TE.
- ▶ In **MP\_mop**, enter the key name of the machine operating panel on which the override source is located.  
(This is only required for future software versions that support the connection of more than one machine operating panel.)
- ▶ In **MP\_mode**, define the evaluation of the override input
- ▶ In **MP\_values**, define the discrete override values or the interpolation points of the curve

### MP\_source

Selection of configurable source for override values  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **OVR1**

Potentiometer 1.

Feed-rate override input **F** on the rear side of the TE.

**OVR2**

Potentiometer 2.

Spindle-override input **S** on the rear side of the TE.

**OVR3**

Potentiometer 3.

Rapid-traverse override input **E** on the rear side of the TE.

**KEY**

Group of keys

Default: OVR1

Access: LEVEL3

Reaction: RESET

### MP\_mop

Enter the key name of the machine operating panel on which the override source is located

Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: Defines the operating panel on which the override source is located.

Enter a key name from **CfgPlcMop**

Default: –

Access: LEVEL3

Reaction: RESET

### MP\_mode

Evaluation of override values

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **DISCRETE**

The key inputs or potentiometer settings are converted in up to 25 discrete override values from MP\_values.

**LINEAR**

The input from the override device is interpolated linearly between the minimum and maximum override value.

**CURVE**

The input values of the override device are converted using the curve defined in MP\_values.

You define the curve with up to 64 interpolation points in MP\_values. The input values of the override device are again interpolated linearly above the last interpolation point specified. If no curve is defined in MP\_values, the control uses a standard curve.

Default: DISCRETE

Access: LEVEL3

Reaction: RESET

## MP\_values

Discrete values or interpolation points for curve  
Available from NCK software version: 597 110-01.

Format: Array [0..63]  
Input: 0.000 to 200.000 [%]

The meaning of the parameter depends on MP\_mode:

**MP\_mode = DISCRETE:** Enter override values for a maximum of 64 key inputs or potentiometer settings.

**MP\_mode = LINEAR:**  
MP\_values has no function.

**MP\_mode = CURVE:**  
Define a curve with up to 64 interpolation points. The override values are taken from the curve. Linear interpolation is again effective above the last interpolation point specified.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### 7.7.2 Override functions

Settings in the configuration editor	MP number
System PLC CfgPlcOverrideS [Key name of spindle] <b>minimal</b> <b>maximal</b> <b>source</b>	    104401 104402 104402
Channels ChannelSettings [Key name of machining channel] CfgThreadSpindle <b>sourceOverride</b>	



## Speed override

- ▶ In the parameter object **CfgPlcOverrideS**, create a parameter set for each spindle to which a spindle speed override is to apply.
- ▶ With **MP\_sourceOverride** define which potentiometer is to be effective during thread cutting for speed and feed rate

### MP\_minimal

Minimum value for override  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 to 100.000 [%]  
Default: 0  
Access: LEVEL3  
Reaction: RESET

### MP\_maximal

Maximum value for override  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 to 200.000 [%]  
Default: 150  
Access: LEVEL3  
Reaction: RESET

### MP\_source

Source for override values  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: Key name for override device from CfgPlcOverrideDev  
Default: –  
Access: LEVEL3  
Reaction: RESET

## Override potentiometer during thread cutting

The potentiometer adjusted with **MP\_sourceOverride** is effective during thread cutting for shaft speed and feed rate.



### Note

#### **If you are switching from the iTNC 530:**

With **MP\_sourceOverride = Spindle Potentiometer** you define the iTNC 530-compatible setting for the override during thread cutting. In milling, the feed rate during thread cutting is usually controlled with the spindle speed override.

### MP\_sourceOverride

Effective override potentiometer for feed rate during thread cutting

Available from NCK software version: 597 110-05.

Format: Selection menu

Selection: **Spindle Potentiometer**

(iTNC 530-compatible setting)

During thread cutting, the potentiometer is effective for the spindle speed knob. The potentiometer for the feed rate override is disabled.

#### **Feed potentiometer**

(previous behavior of the MANUALplus 620)

During thread cutting, the potentiometer is effective for the feed rate knob. The potentiometer for the spindle speed override is disabled.

Default: Feed potentiometer

Access: LEVEL3

Reaction: RUN

## PLC operands

The percentage adjusted with the speed override is entered by the NC in **NN\_SpiOverrideInput** and **PP\_SpiOverride**.

You can change the percentage through the PLC:

- ▶ Enter the desired percentage in **PP\_SpiOverride**. The NC immediately takes over the new value.

PLC operand / Description	Type
NN_SpiOverrideInput Speed override set [%]	D
PP_SpiOverride Speed override entered by the PLC [%]	D



## Feed rate override

Settings in the configuration editor	MP number
Channels	
ChannelSettings	
[Key name of the machining channel]	
CfgPlcOverrideF	
<b>minimal</b>	201901
<b>maximal</b>	201902
<b>source</b>	201903

- ▶ In the channel-sensitive parameter object **CfgPlcOverrideF**, create a parameter set for each machining channel (slide) to which a feed rate override is to apply.

### MP\_minimal

Minimum value for override

Available from NCK software version: 597 110-01.

Format: Numerical value  
 Input: 0.00 to 100.00 [%]  
 Default: 0  
 Access: LEVEL3  
 Reaction: RESET

### MP\_maximal

Maximum value for override

Available from NCK software version: 597 110-01.

Format: Numerical value  
 Input: 0.00 to 200.00 [%]  
 Default: 150  
 Access: LEVEL3  
 Reaction: RESET

### MP\_source

Source for override values

Available from NCK software version: 597 110-01.

Format: Selection menu  
 Selection: Key name for override device from CfgPlcOverrideDev  
 Default: PotentiometerF  
 Access: LEVEL3  
 Reaction: RESET



#### Note

The feed rate override also applies to rapid traverse if the rapid traverse override is not active.

## PLC operands

The percentage adjusted with the feed rate override is entered by the NC in **NN\_ChnFeedOverrideInput** and **PP\_ChnFeedOverride**.

You can change the percentage through the PLC:

- ▶ Enter the desired percentage in **PP\_ChnFeedOverride**. The NC immediately takes over the new value.

PLC operand / Description	Type
NN_ChnFeedOverrideInput Feed-rate override set [%]	D
PP_ChnFeedOverride Feed-rate override entered by the PLC [%]	D



## Rapid traverse override

Settings in the configuration editor	MP number
Channels	
ChannelSettings	
[Key name of the machining channel]	
CfgPlcOverrideR	
<b>minimal</b>	202001
<b>maximal</b>	202002
<b>source</b>	202003

- ▶ In the channel-sensitive parameter object **CfgPlcOverrideR**, create a parameter set for each machining channel (slide) to which a rapid traverse override is to apply.

### MP\_minimal

Minimum value for override  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.00 to 100.00 [%]  
Default: 0  
Access: LEVEL3  
Reaction: RESET

### MP\_maximal

Maximum value for override  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.00 to 200.00 [%]  
Default: 150  
Access: LEVEL3  
Reaction: RESET

### MP\_source

Source for override values  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: Key name for override device from CfgPlcOverrideDev  
Default: PotentiometerF  
Access: LEVEL3  
Reaction: RESET

You can change the percentage through the PLC:

- ▶ Enter the desired percentage in PP\_ChnRapidFeedOverride. The NC immediately takes over the new value.

PLC operand / Description	Type
NN_ChnRapidFeedOverrideInput Rapid traverse override set [%]	D
PP_ChnRapidFeedOverride Rapid traverse override entered by the PLC [%]	D

### 7.7.3 Compensation for potentiometers

Settings in the configuration editor	MP number
System	
PLC	
CfgPlcPeriphery	
<b>overrideFullRatio</b>	103406
<b>overrideDelta</b>	103407
<b>overrideIntegDelta</b>	103408

**MP\_overrideFullRatio** allows you to compensate voltage losses.

#### **MP\_overrideFullRatio**

Compensation for cable losses of the override potentiometer  
 Available from NCK software version: 597 110-01.  
 Format: Numerical value  
 Input: 0.5000 to 1.0000  
 Default: 0.5 (optional parameter)  
 Access: LEVEL2  
 Reaction: NOTHING

Use **MP\_overrideDelta** and **MP\_overrideIntegDelta** to influence the sensitivity of the override potentiometers. **MP\_overrideDelta** suppresses short-term fluctuations and **MP\_overrideIntegDelta** compensates the signal drift.

#### **MP\_overrideDelta**

Compensation for thermal noise in override potentiometers  
 Available from NCK software version: 597 110-01.  
 Format: Numerical value  
 Input: 0.00010 to 0.10000  
 Default: 0.0001 (optional parameter)  
 Access: LEVEL2  
 Reaction: NOTHING

#### **MP\_overrideIntegDelta**

Compensation for thermal noise in override potentiometers  
 Available from NCK software version: 597 110-01.  
 Format: Numerical value  
 Input: 0.00010 to 1.00000  
 Default: 0.0001 (optional parameter)  
 Access: LEVEL2  
 Reaction: NOTHING



## 7.8 PLC Inputs/Outputs

### 7.8.1 Diagnosis of the external PL

#### Module 9007 Read the diagnostic information of a PLC input/output unit

The module provides diagnostic information about the PL 510. To save computing time, refrain from continuously calling this module.

Call:

PS B/W/D/K <Number of the PLB 510 basic module (0 to 3)>

PS B/W/D/K <Number of the information>

0: Reserved

1: Reserved

2: Reserved

3: Total number of PL 510 on this MC

4: Reserved

5: Reserved

CM 9007

PL B/W/D/K <Diagnostic information>

0 to 4: Number of PL 510

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Diagnostic information was read
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Invalid code
	2	Invalid PL module
	24	Module was called in a spawn job or submit job
	51	Diagnostic function cannot be read because PL 510 system is running in modular mode.

### Module 9137 Read diagnostic information of the PL 510

The module provides diagnostic information about the PL 510. To save computing time, refrain from continuously calling this module.

Call:

PS B/W/D/K <Number of the PLB 510 basic module (0 to 3)>  
PS B/W/D/K <Number of the slot (0 to 3)>  
PS B/W/D/K <Number of the information>  
0: Possible mode of operation (PL modular mode)  
1: Active mode of operation  
2: Reserved  
3: Reserved  
4: Basic module code  
5: Status of the basic module  
6: Module type in the slot  
7: Reserved  
8: Reserved  
9: Status of the module in the slot  
10: Logical status of the outputs of a PLD 16-8  
11: Short-circuit of the outputs of a PLD 16-8  
12: Number of connected PL 510

CM 9137  
PL W/D <Diagnosis information>  
Information no. 0:  
0: "PL 510" operating mode not possible (only "PL 4xxB"  
operating mode, without new functions of the PL 510)  
1: "PL 510" operating mode possible  
Information no. 1:  
0: "PL 4xxB" operating mode active (without new  
functions of the PL 510)  
1: "PL 510" operating mode active  
Information no. 2:  
0: No PLB 510  
1: PLB 510  
Information no. 3:  
0..15: Hardware version  
Information no. 4:  
0..15: Hardware code  
Information no. 5:  
Bit 0 = 1: Power supply of the PLB 510 is OK  
Bits 1 to 15: Reserved  
Information no. 6:  
0: No module in slot  
1: Reserved  
2: PLD 16-8  
3: PLA 4-4 in slot  
Information no. 7:  
0..15: Hardware version (identifies the function status of  
the module)  
Information no. 8:  
0..15: Hardware code (identifies a hardware change  
state)  
Information no. 9:  
PLD 16-8 (module type 2):  
Bit 0 = 1: Power supply outputs 0 to 3 are OK  
Bit 1 = 1: Power supply outputs 4 to 7 are OK



Bit 2 = 1: Short circuit at an output  
 Bit 3 = 1: At least one output idle (< 300 mA)  
 Bits 4 to 6: No meaning  
 Bit 7 = 1: Output 7 is a programmable output (otherwise "control is ready")  
 Bits 8 to 31: No meaning  
 PLA 4-4 (module type 3):  
 Bit 0 = 1: Power supply of the inputs is OK  
 Bits 1 to 31: No meaning  
 Information no. 10:  
 Bit 0: Status of output 0 (PLD 16-8)  
 to  
 Bit 7: Status of output 7 (PLD 16-8)  
 Information no. 11:  
 Bit 0: Short circuit at output 0 (PLD 16-8)  
 to  
 Bit 7: Short circuit at output 7 (PLD 16-8)  
 Bit 8: Idle (< 300 mA) Out0 (PLD 16-8)  
 to  
 Bit 15: Idle (< 300 mA) Out7 (PLD 16-8)

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error	0	Diagnostic information was read
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Invalid code
	2	Invalid basic module number or slot number
	24	Module was called in a spawn job or submit job
	51	Function not possible since no PL 510 system is connected or the I/O module type is incorrect for the desired type of information.

**Explanations:**

- **Hardware version** – identifies the function status of the module. When a function that affects the software is changed, the code number identifying the version is increased by one. Modules with low version numbers cannot be replaced by modules with higher version numbers.
- **Hardware code** – identifies the hardware change state. The hardware changes do not affect the functions. It is not necessary to take the hardware code into account when a module is replaced.
- **Short circuit:** Short circuit codes (both the group signal as well as the output-specific messages) are modal. They are indicated by the error LED on the I/O module. In the event of a short circuit, the affected output is automatically reset. With Module 9139 you can withdraw the short-circuit code and then drive the output again.
- **No load:** The limit values for no-load code are minimum 20 mA and maximum 300 mA.



### Module 9139 Monitoring functions for the PL 510 PLC input/output units

The short circuit of an output of the PLD 16-8 is indicated by an LED, and the output is reset. Short-circuit monitoring remains in place, and must therefore be reset with Module 9139.

To save computing time, refrain from repeatedly calling this module.

Call:

PS    B/W/D/K <Function>  
         0: Reserved  
         1: Reserved  
         2: Reset short-circuit monitoring

CM    9139

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Short-circuit monitoring was reset
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Invalid code
	2	Invalid basic module number or slot number
	24	Module was called in a spawn job or submit job
	51	Function not possible or not a PL 510





## 7.8.2 24 V– switching input/outputs

In PLC addresses you can find the current states of the switching inputs and outputs.

For the current states of the inputs/outputs of the external PL:

- ▶ Read all inputs with Module 9002
- ▶ Update all outputs with Module 9005

With Module 9004 you can evaluate the rising or falling edge of the PLC inputs.



### Note

Before the PLC program is converted, the PLC outputs are reset. In addition, the memory of the PLC outputs is reset.

During a loss of power (power fail), the control tries to reset the PLC outputs.

Settings in the configuration editor	MP number
System PLC CfgPlcDeferCutoff [Key name of the output] <b>port</b> <b>time</b>	103601 103602

If all PLC outputs are switched off (e.g., during PLC program compilation or due to a PLC run-time error), the outputs defined via the configuration object **CfgPlcDeferCutoff** can be switched off delayed by a time between 0 and 5 seconds. The delay only affects outputs that cannot be switched off by an emergency stop, since for the outputs that can be shut off by an emergency stop, the 24 V supply is shut off immediately.

### MP\_port

Number of the physical output port on the PL  
Available from NCK software version: 597 110-02.

Format: Numerical value  
Input: 0 to 31  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

### MP\_time

Delay time during switch-off  
Available from NCK software version: 597 110-02.

Format: Numerical value  
Input: 0.1 to 5.0 [s]  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

### Module 9002 Read the inputs of a PLC input/output unit

The module downloads the current states of the PLC input/output unit. These states can be read in the PLC addresses (process image). The contents of the PLC addresses remain unchanged until you call this module again.

For PL 510, inputs of empty slots are not read.

The program can be called only in the cyclic PLC program.

Call:

PS B/W/D/K <Number of the PLB 510 basic module (0 to 3)>

CM 9002

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Inputs were read
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid PL number
	24	Module was called in a spawn job or submit job

### Module 9004 Build the edges of PLC inputs

The module sets, upon falling or rising edges of the PLC inputs, specified edge markers or bits in the specified byte range. Changes in the inputs are recognized only if a change also occurs in the PLC addresses (see Module 9002).

Ensure that the specified edge markers or edge bytes are in an unoccupied area. The edge bytes are written beginning with the least significant bit. Superfluous bits are erased.

Call:

PS B/W/D/K <Number of the first PLC input>

PS B/W/D/K <Number of the first edge marker or edge byte>

PS B/W/D/K <Number of PLC inputs>

PS B/W/D/K <Edge evaluation>

0: Rising edge. Entry in edge marker

1: Falling edge. Entry in edge marker

2: Rising edge. Entry in edge byte

3: Falling edge. Entry in edge byte

CM 9004

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Outputs were set
	1	Invalid transfer parameter

### Module 9005 Set the outputs of a PLC input/output unit

The module overwrites the outputs of the PLC input/output unit with the values from the PLC addresses. The outputs are set or reset immediately at the time of module execution and remain in their condition until they are set or reset again by this module.

For the PL 510, the outputs of empty slots are not overwritten with values from the PLC addresses.

The program can be called only in the cyclic PLC program.

Call:

PS B/W/D/K <Number of the PLB 510 basic module (0 to 3)>

CM 9005

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Outputs were set
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid PL number
	24	Module was called in a spawn job or submit job

### 7.8.3 Analog inputs

Settings in the configuration editor	MP number
System PLC CfgPlcPeriphery <b>pt100Discrete</b>	103404

#### Transferring the analog inputs of the MC

±10 V– analog inputs and inputs for Pt 100 thermistors are available either on the MC unit or on the external PL (see Chapter 3, Mounting and Electrical Installation). Use Module 9003 to load the current temperatures of the Pt 100 thermistors or the values of the analog inputs.

To transfer the analog inputs and temperature inputs of the external PL, use Module 9138.

#### Module 9003 Transfer the analog input of the MC

This module reads the current value of the specified analog input, regardless of whether it is actually connected.

Value range ±10 V input: –10 V to +10 V, at a resolution of 10 mV

Value range Pt 100 input: 0 to 100 °C, at a resolution of 0.1 °C

The module can be called only in the cyclic PLC program.

Call:

PS B/W/D/K <Number of analog input>  
0 to 63: Reserved  
64 to 66: ±10 V input on connection X48  
67 to 69: Pt 100 input on connection X48

CM 9003

PL W/D <Analog value>  
No. 64 to 69: Natural number with the unit 0.01 V or 0.1 °C

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Input was read
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid PL number or invalid analog input number
	24	Module was called in a spawn job or submit job



In **MP\_pt100Discrete** you define whether the values of the Pt 100 inputs are transferred immediately or with a change rate of 1 K/s. The disadvantage of transfer with a change rate of 1 K/s is that at high change rates it may take some time until the correct temperature has been transferred. For example, it would take 30 seconds to correctly read a temperature change of 30 K. An advantage of this, however, is a low sensitivity to disturbance: the temperature display will not jump back and forth between two values:

- ▶ If you wish to transfer the values of the Pt 100 inputs immediately, set **MP\_pt100Discrete** = True
- ▶ If you wish to work with a change rate of 1 K/s, set **MP\_pt100Discrete** = False.

### **MP\_pt100Discrete**

	Transfer of PT100 values
	Available from NCK software version: 597 110-01.
Format:	Selection menu
Selection:	<b>TRUE</b> Transfer value immediately
	<b>FALSE</b> Transfer value at 1 K/s
Default:	TRUE
Access:	LEVEL2
Reaction:	NOTHING

**Transferring the analog inputs of the PL 510**

**Module 9138 Read analog input of the PL 510**

The module transfers the current value of the given analog input of the PL 510.

Value range  $\pm 10$  V input:  $-10$  V to  $+10$  V, at a resolution of  $0.01$  V

Value range Pt 100 input:  $0$  to  $100$  °C, at a resolution of  $0.01$  °C

To save computing time, refrain from repeatedly calling this module. The module can be called only in the cyclic PLC program.

Call:

PS B/W/D/K <Number of the PLB 510 basic module (0 to 3)>

PS B/W/D/K <Number of the slot (0 to 3)>

PS B/W/D/K <Number of the analog input (0 to 7)>

CM 9138

PL B/W <Analog value>

Analog inputs 0 to 3: Natural number ( $-1000$  to  $+1000$ ) in steps of  $0.01$  V

Analog inputs 4 to 7: Natural number ( $0$  to  $10\ 000$ ) in steps of  $0.01$  °C

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error	0	Input was read
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	2	Invalid basic module number or slot number
	24	Module was called in a spawn job or submit job
	51	Function not possible or not a PL 510 or PLA 4-4 analog module



## 7.8.4 Analog outputs

You can select the analog outputs 1 to 6 at connection X8.



### Note

Every analog axis or analog spindle needs an analog output. These outputs are no longer available to the PLC.

### Module 9130 Output analog voltage

The module places an analog voltage on an analog output. The voltage is output with a slight delay after the end of the PLC scan.

Call the module only once for each output per PLC scan!

Format: 1 mV

Voltages greater than +10 V or less than -10 V are limited to the respective maximum value.

Call:

```
PS    B/W/D/K <Number of the analog output>
        1 to 6: Analog outputs 1 to 6 (X8)
        7 to 13: Analog outputs 7 to 13 (X9)
```

```
PS    B/W/D/K <Analog voltage in mV>
```

```
CM    9130
```

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Analog voltage was output
	1	Error code in NN_GenApiModuleErrorCode
NN_GenApiModule ErrorCode	1	Invalid analog output
	2	Disabled analog output





## 7.9 Operating Times and System Times

### 7.9.1 Measuring operating times

Settings in the configuration editor	MP number
System	
CfgPlcOperTimes	
<b>displayPlcTimes</b>	105001
<b>resetPlcTimes</b>	105002
<b>resetNcTimes</b>	105003
<b>textNumber</b>	105004

The control can measure up to 11 operating times (operating hours counter) and store them in a file:

Operating time	Meaning
TNCTIME	Control on
MACHINETIME	Machine on (NC operating time)
PROGTIME	Program run (NC operating time)
PLCTIME0 to PLCTIME7	Freely definable PLC operating time

- ▶ In **MP\_resetPlcTimes**, specify the PLC operating times you can reset with the code number **857282**
- ▶ In **MP\_resetNcTimes**, specify the NC operating times you can reset with the code number **857282**
- ▶ In **MP\_displayPlcTimes**, define the operating times you want to display
- ▶ In **MP\_textNumber**, define the dialog messages to be displayed for the individual PLC operating times

The time is measured in seconds and is updated every minute during the run time. When the control is switched off, no more than one minute is lost.

The NC starts and stops the NC operating hours counter (**Control on**, **Machine on** and **Program run**).

PLC operating hours counters 1 to 8:

- ▶ Start with Module 9190.
- ▶ Stop with Module 9191.

All operating times are saved during a hard-disk backup.

Use the following modules to evaluate or change the operating times:

- Module 9190: Start the PLC operating hours counter
- Module 9191: Stop the PLC operating hours counter
- Module 9192: Transfer the operating hours counter
- Module 9193: Set the operating hours counter
- Module 9194: Alarm when operating times are exceeded



#### Note

When measuring the operating time in the Program Run mode, the different operating mode groups are currently not distinguished.

#### **MP\_displayPlcTimes**

Display PLC operating times  
Available from NCK software version: 597 110-01.

Format: String  
Input: Binary value  
Bits 0 to 7 represent PLC operating times 1 to 8  
0: Do not display  
1: Display

Default: %11111111  
Access: LEVEL2  
Reaction: NOTHING

#### **MP\_resetPlcTimes**

Reset PLC operating times with the code number  
Available from NCK software version: 597 110-01.

Format: String  
Input: Binary value  
Bits 0 to 7 represent PLC operating times 1 to 8  
0: Do not reset  
1: Reset

Default: %00000000  
Access: LEVEL2  
Reaction: NOTHING

#### **MP\_resetNcTimes**

Reset NC operating times with the code number  
Available from NCK software version: 597 110-01.

Format: String  
Input: Binary value  
Bit 0: "Control on" operating time  
Bit 1: "Machine on" operating time  
Bit 2: "Program run" operating time  
0: Do not reset  
1: Reset

Default: %000  
Access: LEVEL2  
Reaction: NOTHING



The dialog texts for the PLC operating hours counter are defined in the text file %OEM%\plc\language\en (or languages other than English).

### **MP\_textNumber**

Dialogs for PLC operating times  
Available from NCK software version: 597 110-01.

Format: Array [0...7]  
Input: [0] corresponds to the text for PLC time 1, etc.  
In the text file for PLC dialogs, indicate the line number of the dialog text (%OEM%\plc\language\en (or language other than English)).

Default: [0]: 16  
[1]: 17  
[2]: 18  
[3]: 19  
[4]: 20  
[5]: 21  
[6]: 22  
[7]: 23

Access: LEVEL2  
Reaction: NOTHING



### Module 9190 Start the PLC operating hours counter

The module activates one or more PLC operating hours counters. The control measures the time that elapses until activation is completed. Use Module 9191 to cancel activation. Bits 0 to 7 of the transfer value represent the PLC operating hours counters 1 to 8. For every bit set, the associated counter is started.

Call:

PS B/W/D/K <PLC operating time>  
Bits 0 to 7 represent PLC operating times 1 to 8

CM 9190

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	PLC operating time started
	1	Incorrect parameter

### Module 9191 Stop the PLC operating hours counter

The module stops one or more PLC operating hours counters. The time measured by the control is saved. Bits 0 to 7 of the transfer value represent the PLC operating hours counters 1 to 8. For every bit set, the associated counter is stopped.

Call:

PS B/W/D/K <PLC operating time>  
Bits 0 to 7 represent PLC operating times 1 to 8

CM 9191

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	PLC operating time stopped
	1	Incorrect parameter



### Module 9192 Transfer the operating hours counter

The module reads the given PLC or NC operating hours counter.

The current value is transferred in seconds. If the value is greater than 2 147 483 648 (approx. 69 years), a negative number will be transferred.

Call:

PS B/W/D/K <Number of the operating time>  
-3: **Control on**  
-2: **Machine on**  
-1: **Program run**  
0 to 7: PLC operating time counter 1 to 8

CM 9192

PL B/W/D <Current time [s]>  
-1: Error

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	PLC operating time was read
	1	Incorrect transfer value, or module was not called in a spawn or submit job

### Module 9193 Set the operating hours counter

The module overwrites the given PLC or NC operating hours counter. The old value is lost irretrievably.

The value of the NC operating hours counters may only be changed in exceptional cases (e.g. when the control is exchanged).

The time for **Control on** cannot be overwritten.

Transfer all values greater than 2 147 483 648 (approx. 69 years) as negative numbers.

Call:

PS B/W/D/K <Number of the operating time>  
-3: **Control on**  
-2: **Machine on**  
-1: **Program run**  
0 to 7: PLC operating times 1 to 8

PS B/W/D/K <New time [s]>  
CM 9193

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Operating time was overwritten
	1	Incorrect transfer value, or module was not called in a spawn or submit job

### Module 9194 Alarm when operating time exceeded

The module activates a monitoring function in the NC, which sets a PLC marker when the given maximum time for a PLC or NC operating hours counter is exceeded. The marker is set the first time the maximum time is exceeded, and then cyclically once per minute.

The marker can be delayed by max. 59 s the first time it is set. All values greater than 2 147 483 648 (approx. 69 years) must be transferred as negative numbers.

If you enter the value zero as the alarm threshold, the function is deactivated.

Call only in a submit job or spawn job.

Call:

PS B/W/D/K <Number of the operating time>  
-3: **Control on**  
-2: **Machine on**  
-1: **Program run**  
0 to 7: PLC operating times 1 to 8  
PS B/W/D/K <Alarm threshold [s]>  
PS B/W/D/K <Number of the alarm markers>  
CM 9194

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Alarm function activated
	1	Incorrect transfer value, or module was not called in a spawn or submit job



## 7.9.2 System time

Settings in the configuration editor	MP number
System CfgSystemTime <b>offsetToUTC</b>	105201

System time management varies depending on the control system:

- Single-processor systems internally operate with UNIX system time. This is the number of seconds since 0:00 hours on January 1, 1970. The parameter **MP\_offsetToUTC** defines the time difference between Universal Time (Greenwich time, UTC "Universal Time Coordinated") and local time. It is the user's task to adjust between Daylight Saving Time and Standard Time. Daylight Saving Time or Standard Time can be set in **MP\_offsetToUTC**.
- For dual-processor systems, the Windows operating system provides the system time. Windows automatically adjusts for Daylight Saving Time or Standard Time.

Use the following modules to transfer the system time:

- Module 9195: Transfer the real-time clock (UNIX system time)
- Module 9055: Convert time (binary) to formatted string (and consider **MP\_offsetToUTC**)

▶ **Single-processor systems:** In **MP\_offsetToUTC**, define the time difference between Universal Time and local time, taking into account Daylight Saving Time or Standard Time

▶ **Dual-processor systems:** Set **MP\_offsetToUTC** = 0

### MP\_offsetToUTC

Time difference to universal time

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: Enter the time shift to UTC, e.g. UTC+1h for Central European Time (CET)

UTC-10h, UTC-9h, UTC-8h,

UTC-7h, UTC-6h, UTC-5h,

UTC-4h 30min, UTC-4h,

UTC-3h, UTC-2h, UTC-1h,

#### UTC

UTC+1h, UTC+2h, UTC+3h,

UTC+4h, UTC+5h,

UTC+5h 30min,

UTC+6h, UTC+7h, UTC+8h,

UTC+9h, UTC+9h 30min,

UTC+10h, UTC+11h, UTC+12h

Default: 1

Access: LEVEL1

Reaction: RESET

### Module 9195 Transfer the real-time clock

The module reads the time of the real-time clock. A double word is returned, which contains the number of seconds accumulated since 0:00 hours on January 1, 1970 (UNIX system time).

Call:

CM 9195

PL D <System time>

Number of seconds since 0:00 hours on January 1, 1970.

### Module 9055 Convert time (binary) to formatted string

The module provides the date and time (local time) as an ASCII string with configurable format.

The module converts the binary UNIX system time (number of seconds since 0:00 hours on January 1, 1970) into an ASCII string, taking into account the time difference between local time and Universal Time (Greenwich time) defined in MP\_offsetToUTC.

Call:

PS B/W/D/K <System time>

Number of seconds since 0:00 hours on January 1, 1970.

PS B/W/D/K <String number for the result>

PS B/W/D/K <Format>

0: DD.MM.YYYY hh:mm:ss

1: D.MM.YYYY h:mm:ss

2: D.MM.YYYY h:mm

3: D.MM.YY h:mm

4: YYYY-MM-DD- hh:mm:ss

5: YYYY-MM-DD- hh:mm

6: YYYY-MM-DD h:mm

7: YY-MM-DD- h:mm

8: DD.MM.YYYY

9: D.MM.YYYY

10: D.MM.YY

11: YYYY-MM-DD

12: YY-MM-DD

13: hh:mm:ss

14: h:mm:ss

15: h:mm

CM 9055

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	String was created
Error	1	Incorrect transfer value





## 7.10 Touch Probe

The following touch probes can be connected for workpiece measurement:

- TS 220: Touch-trigger probe with cable connection for workpiece setup and measuring during machining
- TS 440, TS 444, TS 640 and TS 740: Touch trigger probe with infrared transmission for workpiece setup and measurement during machining
- ▶ Specify in the tool editor which touch probe is connected.
- ▶ Make sure that the spindle is locked during the measuring process.

### Touch-probe table

In the touch-probe table, you configure the touch probe data. You can reach the touch-probe table through the file manager under

**TNC:\table\tchprobe.tp.**

Enter the touch-probe data in the touch-probe table. All HEIDENHAIN touch probes are already preconfigured.

Machine smart.Turn Tool editor Table

Selection of the touch probe?

File: v:\table\tchprobe.tp Line: 2 >>

NO	TYPE	CAL_OF1	CAL_OF2	CAL_ANG	F	FMAX	DIST	SET_UP
1	TS120	+0	+0	0	500	-2000	10	2
2	TS220	+0	+0	0	500	-2000	10	2
3	TS440	+0	+0	0	500	-2000	10	2
4	TS444	+0	+0	0	500	-2000	10	2
5	TS630	+0	+0	0	500	-2000	10	2
6	TS632	+0	+0	0	500	-2000	10	2
7	TS640	+0	+0	0	500	-2000	10	2
8	TS740	+0	+0	0	500	-2000	10	2

BEGIN END PAGE PAGE INSERT LINE DELETE LINE FIND END

To make it possible to cover the widest possible range of applications, the touch-probe table offers numerous settings to enable you to determine the behavior common to all touch probe cycles:

Column	Description
T	Number of the touch probe: Enter this number in the tool table (column: <b>TP_NO</b> ) under the appropriate tool number
TYPE	Selection of the touch probe used
CAL_OF1	Offset of the touch probe axis to the spindle axis for the reference axis
CAL_OF2	Offset of the touch probe axis to the spindle axis for the minor axis
F	Feed rate at which the control is to probe the workpiece
FMAX	Feed rate at which the touch probe pre-positions, or is positioned between the measuring points
DIST	Maximum measuring range. If the stylus is not deflected within the defined path, the control outputs an error message.
SET_UP	Set-up clearance for pre-positioning during probing cycles
F_PREPOS	Pre-positioning with speed from the column FMAX: FMAX_PROBE Pre-positioning at the machine's rapid traverse: FMAX_MACHINE
TRACK	Spindle orientation (the touch probe is oriented so that it is always probed by the same point on the touch-probe stylus tip)



#### Note

At this time, the lathe control evaluates only columns T, TYPE and F of the touch probe table.

For more detailed information about tool measurement, please refer to the chapter "In-Process Measurement" of the User's Manual for your control.

## Maximum probing feed rate

Settings in the configuration editor	MP number
System CfgHardware <b>maxTouchFeed</b>	100104

Use machine parameter **MP\_maxTouchFeed** to limit the feed rate during probing. The parameter is effective if a touch probe was inserted or the touch probe was switched on by the NC.

The machine operator can additionally define the maximum possible probing feed rate in the touch-probe table (F and FMAX columns). The control limits the probing feed rate to the minimum value from **MP\_maxTouchFeed** or the touch probe table.

### **MP\_maxTouchFeed**

Absolute maximum probing feed rate

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 0.000 000 000 to 99960 [mm/min]

With this parameter, you limit the values defined in the touch-probe table.

Default: 960

Access: LEVEL3

Reaction: RESET

## 7.10.1 Tool measurement

Settings in the configuration editor	MP number
System	
ProbeSettings	
CfgToolMeasuring	
<b>measuringType</b>	604601
<b>feed</b>	604602
<b>distance</b>	604603
Axes	
Settings	
LinearAxis	
[Key name of the axis]	
CfgProbePosition	
<b>positionProbePos</b>	604701
<b>positionProbeNeg</b>	604702
<b>maxMeasuringFeed</b>	604703

There are two types of measurement available for measuring tools:

- Measurement with an optical gauge
- Measurement with a touch probe

Tools can only be measured in the **Machine** mode of operation. In the main menu, select the **Set T, S, F** dialog box and press the **Measure tool** soft key.

### Measurement with an optical gauge

If you want to use an optical gauge for tool measurement, set **MP\_measuringType** to **Optic**. Appropriate help graphics and soft keys for tool measurement by means of an optical gauge will then be displayed in the **Machine** mode of operation. Since the tool tip must be moved manually by the user to the cross hairs of the optical gauge, you do not need to enter any further settings in the machine parameters.

## Measurement with a touch probe

If you want to use a touch probe for tool measurement, set **MP\_measuringType** to **Probe**.

To measure a tool, position the tool in front of the touch probe and press the **NC start** key. The control then moves the tool automatically towards the touch probe and returns it to its initial position after measurement. A separate measurement is required for every axis direction. For more detailed information about tool measurement, please refer to the User's Manual of the control.

The expert program **\_Measure.ncs**, which was tested in conjunction with a TT 140 tool touch probe from HEIDENHAIN, is available as a probing cycle. If touch probes other than the TT 140 are used, the expert program **\_Measure.ncs** might need to be adapted by the OEM.

You configure the values for the measuring feed rate, the measuring range and the position of the touch probe as follows:

- ▶ In **MP\_feed**, enter the value for the feed rate at which the tool is to approach the touch probe.
- ▶ In **MP\_distance**, enter a value for the measuring range. The tool stops when it has traversed the measuring range without reaching the touch probe.
- ▶ Enter the position of the touch probe in **CfgProbePosition** for each individual axis. In **MP\_positionProbePos**, define the position of the touch probe in the positive axis direction with respect to the machine datum, and in **MP\_positionProbeNeg** in the negative axis direction.
- ▶ In addition, you can enter in **MP\_maxMeasuringFeed** an axis-specific maximum feed rate for approaching the touch probe.

### **MP\_measuringType**

Type of tool measurement (optical gauge, touch probe)  
Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **None**  
No tool measurement possible  
**Probe**  
Tool measurement with touch probe  
**Optic**  
Tool measurement with optical gauge

Default: -

Access: LEVEL3

Reaction: NOTHING

### **MP\_feed**

Feed rate for approaching the touch probe  
Available from NCK software version: 597 110-04.

Format: Numerical value

Input: [mm/min]

Default: 0

Access: LEVEL1

Reaction: NOTHING

### **MP\_distance**

Measuring path  
Available from NCK software version: 597 110-04.

Format: Numerical value

Input: [mm]

Default: 0

Access: LEVEL1

Reaction: NOTHING

### **MP\_positionProbePos**

Position of the touch probe in positive axis direction with respect to the machine datum  
Available from NCK software version: 597 110-04.

Format: Numerical value

Input: [mm]

Default: 0

Access: LEVEL3

Reaction: RUN

### **MP\_positionProbeNeg**

Position of the touch probe in negative axis direction with respect to the machine datum  
Available from NCK software version: 597 110-04.

Format: Numerical value

Input: [mm]

Default: 0

Access: LEVEL3

Reaction: RUN



**MP\_maxMeasuringFeed**

Maximum permissible feed rate for approaching the touch probe

Available from NCK software version: 597 110-04.

Format: Numerical value  
Input: [mm]  
Default: 0  
Access: LEVEL3  
Reaction: RUN



## 7.11 Additional Parameters for Lathes

### 7.11.1 Coordinate system of the lathe

Settings in the configuration editor	MP number
System DisplaySettings CfgCoordSystem <b>coordSystem</b>	114901

Specify in **MP\_coordSystem** the coordinate system of the lathe. The support graphics and the position of the axes in the simulation are among the items influenced by the coordinate system.

#### **MP\_coordSystem**

Definition of the coordinate system

Available from NCK software version: 597 110-01.

Format: Selection menu





Selection: See table below

Default: +X, +Z

Access: LEVEL3

Reaction: NOTHING

Meaning of the selection elements (the arrows point in the positive direction):

Selection	Coordinate system	
<b>+X, +Z</b>		Horizontal lathe; turning behind the center
<b>-X, +Z</b>		Horizontal lathe; turning in front of center
<b>+Z, +X</b>		Vertical lathe (vertical boring and turning mill); turning to the right of center
<b>+Z, -X</b>		Vertical lathe (vertical boring and turning mill); turning to the left of center



## 7.11.2 Linear axes

Settings in the configuration editor	MP number
Axes Settings LinearAxis [Key name of the linear axis] CfgAxisProperties <b>threadSafetyDist</b>	300902
CfgProtectionZone <b>limitPositive</b>	301001
<b>limitNegative</b>	301002

If a G33 thread block is programmed without approach path, the control uses **MP\_threadSafetyDist** as approach path. The approach path must suffice in order to attain the programmed feed rate.

### MP\_threadSafetyDist

Approach path for the thread start

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: Approach path in [mm] with up to 9 decimal places

Default: 3

Access: LEVEL3

Reaction: RESET

## Protection-zone monitoring

Settings in the configuration editor	MP number
Axes Settings LinearAxis [Key name of the spindle axis] CfgProtectionZone <b>limitPositive</b>	301001
<b>limitNegative</b>	301002
Aggregates CfgGlobalProperties <b>protectionZone</b>	601805

Use the parameters **MP\_limitPositive** and **MP\_limitNegative** to specify the positive and negative values for the protection zone.

Set the **MP\_protectionZone** parameter to TRUE in order to suppress protection-zone monitoring.

### **MP\_limitPositive**

Positive protection zone  
Available from NCK software version: 597 110-03.  
Format: Numerical value  
Input: Positive limit value for the protection zone in [mm] with up to 9 decimal places  
If **MP\_limitPositive** = 0 and **MP\_limitNegative** = 0, then protection-zone monitoring is switched off.  
Default: 999 999 999 [mm]  
Access: LEVEL3  
Reaction: RUN

### **MP\_limitNegative**

Negative protection zone  
Available from NCK software version: 597 110-03.  
Format: Numerical value  
Input: Negative limit value for the protection zone in [mm] with up to 9 decimal places  
If **MP\_limitPositive** = 0 and **MP\_limitNegative** = 0, then protection-zone monitoring is switched off.  
Default: -999 999 999 [mm]  
Access: LEVEL3  
Reaction: RUN

### **MP\_protectionZone**

Switch off protection-zone monitoring  
Available from NCK software version: 597 110-03.  
Format: Selection menu  
Selection: TRUE  
Protective-zone monitoring inactive  
FALSE  
Protective-zone monitoring active  
Default: TRUE  
Access: LEVEL1  
Reaction: RUN



### 7.11.3 Spindles

Settings in the configuration editor	MP number
Axes Settings SpindleAxis [Key name of the spindle axis] CfgMachineTable <b>sysKinSimple</b> <b>basisTransKinSim</b> <b>sys</b> <b>basisTrans</b>	    300703 300704 300701 300702
Aggregates General CfgGlobalProperties <b>freezeVconst</b>	   601808

#### Subkinematics (as of NC SW 548 328-03)

In **MP\_sysKinSimple**, enter the key name of the subkinematics for the tool spindle.

#### **MP\_sysKinSimple**

Subkinematics of the tool spindle  
 Available from NCK software version: 597 110-04.

Format: Selection menu  
 Selection: Key names from Channels/Kinematics/CfgKinSimpleModel  
 Default: K\_WP\_S1  
 Access: LEVEL3  
 Reaction: RESET

The key name of the subkinematics for the machine base is to be entered in **MP\_basisTransKinSim**.

#### **MP\_basisTransKinSim**

Subkinematics of the machine base  
 Available from NCK software version: 597 110-04.

Format: Selection menu  
 Selection: Key names from Channels/Kinematics/CfgKinSimpleModel  
 Default: K\_WP\_S1\_BASE  
 Access: LEVEL3  
 Reaction: RESET



## Subkinematics (up to NC SW 548 328-02)

For main spindles you use the parameter **MP\_sys** to specify to which machine-base system this spindle is assigned.

### MP\_sys

Assign the spindle to the machine-base system  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: Key names from Channels/Kinematics/CfgTrafoByDir  
Default: KT\_MT\_S1  
Access: LEVEL3  
Reaction: RESET

In the **MP\_basisTrans** parameter, specify the standard vector for datum shifts. The control shows a selection menu of all key names of the coordinate transformations available under CfgTrafoByDir.

### MP\_basisTrans

Standard vector for datum shifts  
Available from NCK software version: 597 110-03.

Format: Selection menu  
Selection: Key names from Channels/Kinematics/CfgTrafoByDir  
Default: KT\_MT\_S1\_BASISTRANS  
Access: LEVEL3  
Reaction: RESET

## Freeze spindle speed for rapid traverse

With **MP\_freezeVconst** you can prevent the spindle from changing its speed during constant surface speed Vconst according to the current diameter if there are several rapid traverse movements. The speed remains unchanged during the first rapid traverse movement after a feed rate and is not brought to the speed corresponding to the diameter at the target point until the last rapid traverse path before a feed rate path. This prevents unnecessary braking and acceleration of the spindle during several successive rapid traverse movements.

### MP\_freezeVconst

Freezing the spindle speed for rapid traverse movements and active constant surface speed.

Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **TRUE**

The spindle speed is held constant for rapid traverse movements and active constant surface speed.

**FALSE**

The spindle speed is always adjusted to the current diameter for rapid traverse movements and active constant surface speed.

Default: -

Access: LEVEL3

Reaction: RUN

## 7.11.4 C axis

Settings in the configuration editor	MP number
Axes Settings C axis [Key name of the C axis] CfgCAxisProperties <b>blockBrake</b> <b>spindlePrePosit</b> <b>relatedWpSpindle</b>	     300801 300802 300803
Aggregates General CfgAggregateKeys <b>caxisKeys</b>	    600004

List all C axes of the machine in **MP\_caxisKeys**. The control needs this information in order to distinguish C axes from the "C" rotary axis.

### MP\_caxisKeys

List of the key names of all C axes of the machine  
 Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: Key names of all existing machine axes under PhysicalAxis.  
 Select the key names of the C axes and enter them here.

Default: -

Access: LEVEL3

Reaction: RESET

Enter in **MP\_blockBrake** whether a shoe brake is present.

### MP\_blockBrake

Shoe brake present  
 Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**  
 Shoe brake present

**FALSE**

Shoe brake not present

Default: FALSE

Access: LEVEL3

Reaction: RESET

Specify in the parameter **MP\_spindlePrePosit** whether the spindle is to be pre-positioned upon M19. Enter the angle for pre-positioning in degrees [°].

### **MP\_spindlePrePosit**

Spindle pre-positioning upon M19  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to 99 [°]  
Angle in [°] to which the spindle is positioned before the C axis is positioned.

Default: 0 [°]  
Access: LEVEL3  
Reaction: RESET

In the optional parameter **MP\_relatedWpSpindle** you specify the assigned workpiece spindle for C axes with separate drive.

### **MP\_relatedWpSpindle**

Assigned workpiece spindle  
Available from NCK software version: 597 110-03.

Format: Selection menu  
Selection: Key names of all existing machine axes under PhysicalAxis.  
Select the workpiece spindle assigned to the C axis.  
No entry = A workpiece spindle was assigned to the C axis through CfgProgAxis/relatedAxis.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN



### 7.11.5 Tailstock and steady rest

Settings in the configuration editor	MP number
Aggregates General CfgAggregateKeys <b>tailstockKeys</b> <b>steadyRestKeys</b>	   600002 600003

Enter the key names of all tailstocks existing on the machine in **MP\_tailstockKeys**. Enter the key names of all steady rests on the machine in **MP\_steadyRestKeys**. The control needs this information to be able to implement tailstocks and steady rests as programmable axes.

#### **MP\_tailstockKeys**

List of the key names of all tailstocks of the machine  
 Available from NCK software version: 597 110-05.

Format: Array [0...1]  
 Input: Max. 18 characters  
 Default: No value, parameter optional  
 Access: LEVEL3  
 Reaction: RESET

#### **MP\_steadyRestKeys**

List of the key names of all steady rests of the machine  
 Available from NCK software version: 597 110-05.

Format: Array [0...1]  
 Input: Max. 18 characters  
 Default: No value, parameter optional  
 Access: LEVEL3  
 Reaction: RESET



## 7.11.6 Tool carriers

The description of the tool carriers of a machine is set up as follows:

- **CfgAggregateKeys:**  
List of the tool carriers of the machine
- **CfgAssignAggregate:**  
Assign tool carrier to the machining channel
- **CfgTHDescription:**  
Description of the individual tool carriers
- **CfgToolMount:**  
Description of the tool mounts of a tool carrier (see "Tool holders (mounts)" on page 1400)

Settings in the configuration editor	MP number
Aggregates	
General	
CfgAggregateKeys	
<b>toolHolderKeys</b>	600001
ToolHolder	
[Key name of the tool carrier]	
CfgTHDescription	
<b>ordinalNr</b>	600203
<b>type</b>	600204
<b>spindleNr</b>	600207
<b>maxSwivelPosition</b>	600208
<b>xDimToSlideRef</b>	600210
<b>zDimToSlideRef</b>	600211
<b>yDimToSlideRef</b>	600212
<b>coolantCirc</b>	600213
CfgToolMountKeys	
<b>toolMountKeys</b>	600101
Channels	
ChannelSettings	
[Key name of the machining channel]	
CfgAssignAggregate	
<b>assignToolHolder</b>	203901

List in **MP\_toolHolderKeys** all tool carriers of the machine. The control supports up to six tool carriers per machine.

### MP\_toolHolderKeys

List with the key names of all tool carriers of the machine  
Available from NCK software version: 597 110-01.

Format: Selection menu  
 Selection: Key names of the tool carriers from the ToolHolder folder  
 Default: –  
 Access: LEVEL3  
 Reaction: RESET





Use **MP\_assignToolHolder** to assign the tool carrier(s) to a machining channel. The control supports up to three tool carriers per machining channel.

### **MP\_assignToolHolder**

List with the key names of the tool carriers of this machining channel

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: Key names of the tool carriers from the ToolHolder folder

Default: –

Access: LEVEL3

Reaction: RESET

The following parameters describe the type of the tool carrier and its geometric position. In addition, the assigned spindle and the coolant circuits are declared if driven tools are intended.

### **MP\_ordinalNr**

Number of the tool carrier

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0 to 9

Default: 1

Access: LEVEL3

Reaction: RESET

### **MP\_type**

Type of tool carrier

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **None**

**Turret**

**Multifix**

(only one tool mount)

Default: MultiFix

Access: LEVEL3

Reaction: RESET

In the parameter **MP\_spindleNr** you define the spindle for driven tools. During generation of the NC program, this parameter for G and M functions for driven tools is evaluated.

### **MP\_spindleNr**

(Code of the) spindle for driven tool  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **NoSpindle**  
No driven tool  
**Spindle1**  
Spindle 1 for driven tool  
**Spindle2**  
Spindle 2 for driven tool  
**Spindle3**  
Spindle 3 for driven tool

Default: Spindle2

Access: LEVEL3

Reaction: RESET

For tool turrets, enter the number of swivel positions in **MP\_maxSwivelPosition**. If a simple tool holder is used (example: Multifix), enter "1"

### **MP\_maxSwivelPosition**

Number of turret swivel positions  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 1 to 99  
Turret: Enter number of swivel positions (2 to 99)  
Multifix: Enter 1

Default: 32

Access: LEVEL3

Reaction: RESET

The tool holders (mounts) of a turret can be located on the left, on the right, and/or on the front. Therefore, the number of tool holders can be a multiple of the number of swivel positions.

### **MP\_xDimToSlideRef**

X dimension for slide reference  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: -100 000.000 to 100 000.000 [mm]  
Distance from slide reference point to tool carrier reference point in [mm].  
If the slide reference and the tool carrier reference are identical, the dimension = 0.

Default: 888.88 [mm]

Access: LEVEL3

Reaction: RESET



### MP\_zDimToSlideRef

Z dimension for slide reference  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: -100 000.0000 to +100 000.0000 [mm]  
Distance from slide reference point to tool carrier reference point in [mm].  
If the slide reference and the tool carrier reference are identical, the dimension = 0.  
Default: 0  
Access: LEVEL3  
Reaction: RESET

### MP\_yDimToSlideRef

Y dimension for slide reference  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: -100 000.0000 to +100 000.0000 [mm]  
Distance from slide reference point to tool carrier reference point in [mm].  
If the slide reference and the tool carrier reference are identical, the dimension = 0.  
Default: 0  
Access: LEVEL3  
Reaction: RESET

Enter the numbers of the coolant circuits assigned to this tool carrier in the **coolantCirc** list.

### MP\_coolantCirc

List with the numbers of the allocated coolant circuits  
Available from NCK software version: 597 110-05.  
Format: Array [0...3]  
Input: -2147483648 to 2147483647  
Default: [0]: 1  
[1]: 2  
[2]: 0  
[3]: 0  
Access: LEVEL3  
Reaction: RESET

In **MP\_toolMountKeys**, list all tool mounts of the tool carrier. The tool mounts are described in the **CfgToolMount** parameter object.

### MP\_toolMountKeys

List of the key names of all tool mounts of this tool carrier  
Available from NCK software version: 597 110-01.  
Format: Selection menu  
Selection: Key names from the ToolMount folder  
Default: -  
Access: LEVEL3  
Reaction: RESET

### 7.11.7 Tool holders (mounts)

The tool holders are assigned to a tool carrier in the **MP\_toolMountKeys** parameter (see "Tool carriers" on page 1396).

The position and properties of each tool holder are described in **CfgToolMount**.

Settings in the configuration editor	MP number
Aggregates	
ToolMount	
[Key name of the tool holder]	
CfgToolMount	
<b>mountPosWAPP</b>	600401
<b>freeTnr</b>	600402
<b>distCarrierRefX</b>	600407
<b>distCarrierRefZ</b>	600408
<b>distCarrierRefY</b>	600409
<b>correctionX</b>	600410
<b>correctionZ</b>	600411
<b>correctionY</b>	600412
<b>mirroringAxes</b>	600416
<b>convTblNr</b>	600417

Define in **MP\_mountPosWAPP** the number of the tool holder according to the "WAPP" principle. The **mountPosWAPP** attribute consists of the following parts:

- W = Number of the tool carrier (1 to 6)
- A = Tool holder number (0...3)
- PP = Swivel pocket (1...99)

#### **MP\_mountPosWAPP**

(W)APP designation of holder location

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 1 to 6999

Enter the number of this tool holder according to the WAPP principle.

W = Tool carrier number (1 to 6)

A = Holder position (0 to 3)

PP = Swivel position of the turret

Default: No value, parameter optional (initial value: 1001)

Access: LEVEL3

Reaction: RESET

**Example:** For holder 0 of swivel pocket 12 of tool carrier 1, the entry in **mountPosWAPP** is 1012.

Assign in **MP\_freeTnr** a unique T number (1 to 899) to this tool holder. This T number is used in manual operation, in the NC program and in the turret assignment table (ToolAllo.tch) in order to activate the tool of this holder. Use the WAPP number if you do not define the T number.

The T number 0 is reserved by the control, and represents a tool whose geometric dimensions are 0. For reasons of clarity, the tools are normally numbered sequentially.

### **MP\_freeTnr**

Free T number of the tool holder  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0: The free T number is not used  
1 to 899: Each tool holder is assigned a unique number.  
Default: No value, parameter optional (initial value: 1)  
Access: LEVEL3  
Reaction: RESET

The tool holders are dimensioned relative to the tool carrier. The control adds the values from **MP\_distCarrierRef\*** and **MP\_correction\***.

### **MP\_distCarrierRefX**

X dimension for tool carrier reference  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: -100 000.000 to +100 000.000 [mm]  
Enter the distance in millimeters [mm] from the tool holder datum to the tool carrier datum.  
Default: No value, parameter optional (initial value: 0)  
Access: LEVEL3  
Reaction: RESET

### **MP\_distCarrierRefZ**

Z dimension for tool carrier reference  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: -100 000.000 to +100 000.000 [mm]  
Enter the distance in millimeters [mm] from the tool holder datum to the tool carrier datum.  
Default: No value, parameter optional (initial value: 0)  
Access: LEVEL3  
Reaction: RESET

### **MP\_distCarrierRefY**

Y dimension for tool carrier reference  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -100 000.000 to +100 000.000 [mm]  
Enter the distance in millimeters [mm] from the tool holder datum to the tool carrier datum.

Default: No value, parameter optional (initial value: 0)  
Access: LEVEL3  
Reaction: RESET

### **MP\_correctionX**

Correction in X of the tool-holder position  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -100 000.000 to +100 000.000  
Correction value in [mm]

Default: 0  
Access: LEVEL3  
Reaction: RESET

### **MP\_correctionZ**

Correction in Z of the tool-holder position  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -100 000.000 to +100 000.000  
Correction value in [mm]

Default: 0  
Access: LEVEL3  
Reaction: RESET

### **MP\_correctionY**

Correction in Y of the tool-holder position  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -100 000.000 to +100 000.000  
Correction value in [mm]

Default: 0  
Access: LEVEL3  
Reaction: RESET



## Working with two tool carriers

The MANUALplus 620 mirrors dimensions and converts operations if your machine is equipped with **two tool carriers** (example: one tool carrier in front of the workpiece, the other behind it).

The kinematics are based on the "standard tool carrier." You also define the **coordinate system** in **MP\_worldCoorSystem** based on the standard tool carrier.

When entering the dimensions of tools for the "additional tool carrier," enter them as if this tool carrier were arranged in the "standard quadrant."

You program operations with the "additional tool carrier" as if it were arranged in the "standard quadrant." Because of the **MP\_mirroringAxes** parameter, the MANUALplus 620 knows the position of the tools. It therefore starts mirroring, and because of the **MP\_convTbINr** parameter, converting, if the "additional tool carrier" is used.

Define in **MP\_mirroringAxes** which axes, if any, are to be mirrored for this tool holder. If mirroring is not necessary, then the entry is omitted. The tool dimensions and traverse paths are mirrored.

### MP\_mirroringAxes

Axes to be mirrored for this tool holder

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: Key name of the axes to be mirrored

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

Define in **MP\_convTbINr** the number of the conversion table to be activated when this tool holder is inserted (for conversions: see "Conversions" on page 1408).

### MP\_convTbINr

Number of the conversion table to be activated

Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0: Do not perform any conversion

1: Activate conversion table 1 (file: conv1.hc)

2: Activate conversion table 2 (file: conv2.hc)

3: Activate conversion table 3 (file: conv3.hc)

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

## 7.11.8 Transfer of data to the PLC

Settings in the configuration editor	MP number
System	
PLC	
CfgPlcSymName	
<b>stoppingAngle</b>	116101
<b>maxSpeedSpindle</b>	116102
<b>dbLoadDisplay</b>	116103
<b>readTsfData</b>	116104
<b>displayMode</b>	116105
<b>setToolPlace</b>	116106

### Transferring spindle data to the PLC

The two machine parameters **MP\_stoppingAngle** and **MP\_maxSpeedSpindle** are used to transfer information about the spindle to the PLC program. Use the dialog "Set T, S, F" to enter values for the stopping angle [°] and the maximum spindle speed [1/min]. The PLC can manipulate the two values once the dialog is closed.

#### **MP\_stoppingAngle**

PLC operand for transfer of the spindle stopping angle  
Available from NCK software version: 597110-01.

Format: String

Input: Max. 500 characters

Enter the name of a PLC operand (double word) with which the stopping angle of the spindle is transferred to the PLC.

Default: For HEIDENHAIN basic PLC program:  
**NP\_DG\_Transfer\_Stopping\_Angle**

Access: LEVEL1

Reaction: NOTHING

#### **MP\_maxSpeedSpindle**

PLC operand for transfer of the maximum spindle speed  
Available from NCK software version: 597110-01.

Format: String

Input: Max. 500 characters

Enter the name of a PLC operand (double word) with which the maximum spindle speed is transferred to the PLC.

Default: For HEIDENHAIN basic PLC program:  
**NP\_DG\_Transfer\_Speed\_Limit**

Access: LEVEL1

Reaction: NOTHING





## Transferring data from the tool editor to the PLC

In the tool editor an integer value can be assigned to each tool via the "PLC" input field. The associated dialog opens after the **Edit** soft key has been pressed, and is located on the second page of the dialog window. The PLC can read the entered values directly from the tool table. This makes it possible for the PLC to group the tools according to certain criteria, and manage them separately.

## Load display for analog drives

The following attribute evaluation was added to the "LoadDisplay" dashboard element in order to be able to assign the motor data to a load display when analog axis drives and spindle drives are used.

- Bit 0 = 0    Display IPO data (as previously)
- Bit 0 = 1    Display PLC data (with analog drives)

In **MP\_dbLoadDisplay**, enter the PLC program marker whose value is to be displayed in the dashboard by the load display.

This marker (called **PN\_DG\_LoadDisplay\_Transfer**, for example) is defined as integer array [MAX\_AXIS] in the PLC program.

PN\_DG\_LoadDisplay\_Transfer                      Integer axis [MAX\_AXIS]  
Array with max. number of logical axes      (const long MAX\_AXIS = 10)

The axis-specific integer values are displayed on a one-to-one basis (e.g. if the value is 55, "55%" is displayed). The maximum display value is 999%.

### MP\_dbLoadDisplay

PLC operand for dashboard load display  
Available from NCK software version: 597 110-04.

Format:            String  
Input:             Max. 500 characters  
                      Enter the name of a PLC operand (double word) with which the load value of the respective axis or spindle is transferred to the load display of the dashboard.

Default:           For HEIDENHAIN basic PLC program:  
                      **PN\_DG\_Transfer\_utilization\_display**

Access:            LEVEL3  
Reaction:          NOTHING

## Transferring the spindle speed and feed rate data to the PLC

With the dialog "**Set T, S, F**" you can choose between constant surface speed [m/min] or constant rotational speed [1/min] for the spindle speed. For the feed rate you can choose between feed per revolution [mm/1] or feed per minute [mm/min]. The input values of these parameters are read by the PLC from the tables **ch\_tsf.mch** and **sp\_tsf.msp**, if **MP\_readTsfData = TRUE** is set.

### MP\_readTsfData

PLC reads data from "Set T, S, F" dialog  
Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **TRUE**  
The data on feed rate and spindle speed in the **Set T, S, F** dialog is read by the PLC from the **ch\_tsf.mch** and **sp\_tsf.msp** tables.

**FALSE**  
The control always starts with feed per revolution and constant cutting speed.

Default:

Access: LEVEL3

Reaction: NOTHING

## Transfer display mode to PLC

In **MP\_displayMode**, enter a symbolic variable name in order to transfer the active display mode of the machine display (e.g. "manual operation" = 0 or "automatic mode" = 1) to the PLC. This makes it possible in the **Program Run** operating mode, for example to switch the machine display ("Dashboard") to automatic mode already before activating cycle start.

### MP\_displayMode

Transfer display mode to PLC  
Available from NCK software version: 597 110-04.

Format: String

Input: Max. 500 characters  
Enter the name of a PLC operand (double word) with which the current display mode is transferred to the PLC.

Default: -

Access: LEVEL3

Reaction: NOTHING



## Tool pocket preset by the PLC

With the machine parameter **MP\_setToolPlace** under CfgPlcSymName, a symbolic variable name can be defined under which the PLC can preset a tool pocket. The user interface evaluates the request, inserts the tool in the tool pocket and displays the T number. As an acknowledgment, the defined tool is overwritten by the NC in the variable with (0). Then, as with a normal tool change, the tool call strobe is set and the requested T number is transferred. If the tool change cannot be performed, a (-1) is entered. At present the tool preset by the PLC is permitted only in machine mode.

### **MP\_setToolPlace**

	Tool pocket preset by the PLC
	Available from NCK software version: 597 110-04.
Format:	String
Input:	Max. 500 characters
	Symbolic variable name under which the PLC can define a tool pocket, which is then inserted by the user interface and displayed.
Default:	-
Access:	LEVEL3
Reaction:	NOTHING

## 7.11.9 Conversions

Conversions are required in order to mirror the working space. Example: Reversing the direction of rotation for circular arcs during machining in front of or behind the turning center, or when machining the rear face.

If the conversion table is active, the interpreter replaces a function listed in G\_ORG/M\_ORG with the corresponding function from G\_CONV/M\_CONV.

The conversion lists are stored in files. They are configured by HEIDENHAIN. Conversion list 1 has the following structure:

NR	G_ORG	G_CONV	M_ORG	M_CONV
0	2	3	3	4
1	3	2	4	3
2	12	13	203	3
3	13	12	303	103
4	297	97	0	0
5	397	197	0	0

The conversion can only be used for DIN programs (not for cycle programs).

## 7.11.10 Global settings

### Tool life management

Settings in the configuration editor	MP number
Aggregates General CfgGlobalProperties <b>lifeTime</b>	601801

Use **MP\_lifeTime** to switch tool-life monitoring for tool service age or workpiece quantity on or off.

#### MP\_lifeTime

Activate/deactivate tool life monitoring  
 Available from NCK software version: 597 110-01.

Format: Selection menu  
 Selection: **ON**  
 Monitoring on  
**OFF**  
 Monitoring off

Default: ON  
 Access: LEVEL1  
 Reaction: RUN

## Cycle selection in Program Run

Settings in the configuration editor	MP number
Aggregates General CfgGlobalProperties <b>ncStartWithActCyc</b>	601809

When selecting the Program Run mode, until now the first cycle in a cycle program was always selected, regardless of the cycle selected in teach-in. This behavior can now be changed via the **MP\_ncStartWithActCyc** machine parameter insofar as the cycle selected last is confirmed when changing from Teach-in to Program Run.

### MP\_ncStartWithActCyc

Program run with the most recently selected cycle  
 Available from NCK software version: 597 110-05.

Format: Selection menu

Selection: **On**

When Program Run is selected, the most recently selected cycle remains active

**Off**

When switching to Program Run, the first cycle of the cycle program is always selected.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

## File preview during program selection

Settings in the configuration editor	MP number
System DisplaySettings CfgGlbDispSettings <b>mmiFilePreview</b>	604804

A file preview can now be displayed below the list of files as a standard feature in the program selection of cycle programs. You can enable and disable this default display of the file preview via **MP\_mmiFilePreview**.

### MP\_mmiFilePreview

File preview during program selection  
Available from NCK software version: 597 110-05.

Format: Selection menu

Selection: **TRUE**  
File preview is displayed below the file list.  
**FALSE**  
No display of the file preview below the file list.

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING

## Selection of spindle and channel by PLC

Settings in the configuration editor	MP number
System DisplaySettings CfgGlbDispSettings <b>plcSpindleSelect</b> <b>plcChannelSelect</b>	604801 604802

In order to define the spindle (e.g. spindle or driven tool) to be assigned the TSF dialog, the spindle can be selected by the PLC. You can activate the spindle selection with **MP\_plcSpindleSelect**. The selected spindle is then entered in a non-editable input field in the TSF dialog. When the spindle data is saved, it is assigned only to the selected spindle.

Spindle selection is implemented in the PLC program. The machine manufacturer defines whether a machine key or a soft key is used for switchover.



Channel selection using **MP\_plcChannelSelect** has been prepared, but it currently has no function.

### **MP\_plcSpindleSelect**

Selection of spindle number by PLC

Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **TRUE**

Spindle-dependent input (speed, direction of rotation, etc.) refers to the spindle number selected by the PLC.

**FALSE**

Input refers to the spindle assigned to the tool carrier

Default: -

Access: LEVEL3

Reaction: NOTHING

### **MP\_plcChannelSelect**

Selection of channel number via PLC

Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **TRUE**

Channel-dependent input refers to the channel number selected by the PLC

**FALSE**

Input is possible for only one channel

Default: -

Access: LEVEL3

Reaction: NOTHING

## Selecting the spindle and channel display

When two or more channels are supported, with Module 9480 you can control which channel provides the data to be displayed in the user interface.

With Module 9482 you can control the display of spindle data when two or more spindles are supported.

### Module 9480 Select the channel display

On controls that support multiple channels, this module makes it possible to control the display of channel data. In addition, the user can enter information (e.g. through dialog menus) for a selected channel. The module selects the program channel for the selected operating panel. There is no explicit response time by which this request is accepted by the operating panel. The execution of this module can be monitored with Module 9481.

Call:

PS B/W/D/K <Operating panel>  
0: At present only one user interface possible

PS B/W/D/K <Action>  
Bit 0: Display of channel data  
Bit 1: Entry of channel information

PS B/W/D/K <Channel index>  
0: First channel  
1: Second channel  
etc.

CM 9480

PL D <Error code>  
0 : New channel display selected  
1: Addressed operating panel not in permitted range  
2: Addressed channel not in permitted range  
3: Action not valid  
4: Operating panel not designed for switchable channel display  
5: Module not executed, as switchover already active for operating panel

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	No error
	1	See error code above





### Module 9481 Find the channel display

The module provides the active and the selected channel display of an operating panel.

Call:

PS B/W/D/K <Operating panel>  
0: At present only one user interface possible

CM 9481

PL D <Index of the active channel used by the user interface>  
1: No active channel present

PL D <Index of the selected channel that was preset by the PLC>  
1: No selected channel present

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	No error
	1	Addressed operating panel not in permitted range
	2	Addressed operating panel not designed for switchable channel display

### Module 9482 Select the spindle display

On controls that support multiple channels, this module makes it possible to control the display of spindle data. In addition, user entries (e.g. through dialog menus) for a selected spindle can also be enabled. The module selects the program spindle for the selected operating panel. There is no explicit response time by which this request is accepted by the operating panel. The execution of this module can be monitored with Module 9483.

Call:

PS B/W/D/K <Operating panel>  
0: At present only one user interface possible

PS B/W/D/K <Action>  
Bit 0: Display of spindle data  
Bit 1: Entry of spindle information

PS B/W/D/K <Logical spindle number>

CM 9482

PL D <Error code>  
0: New spindle display selected  
1: Addressed operating panel not in permitted range  
2: Addressed spindle not in permitted range  
3: Action not valid  
4: Operating panel not designed for switchable channel display  
5: Module not executed, as switchover already active for operating panel

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	No error
	1	See error code above

**Module 9483 Find the spindle display**

The module provides the active and the selected spindle display of an operating panel.

Call:

PS B/W/D/K <Operating panel>  
0: At present only one user interface possible

CM 9483  
PL D <Logical spindle number actively used by the user interface>  
1: No active spindle available  
PL D <Logical spindle selected by the PLC>  
1: No selected spindle available

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	No error
	1	Addressed operating panel not in permitted range
	2	Addressed operating panel not designed for switchable spindle display

**Interpreter stop upon tool change**

Settings in the configuration editor	MP number
Aggregates General CfgGlobalProperties <b>iStopT</b>	601802

The interpreter pre-interprets approx. 15 to 20 NC blocks. If variables are used for programming, then it must be ensured that the variable is assigned before the NC block is interpreted. This can be achieved with an **interpreter stop**, which interrupts the pre-interpretation.

Use the **MP\_iStopT** parameter to specify whether an interpreter stop is triggered before the tool change.



## MP\_iStopT

Interpreter stop upon tool change  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**  
Interpreter stop before tool change  
**FALSE**  
No interpreter stop

Default: FALSE

Access: LEVEL3

Reaction: RUN

**Example for tool life management:** During a tool change, the control checks the tool life of the tool. If "Interpreter stop at tool change" is active, the pre-interpretation is stopped and the actual usage time of the tool is taken into account. Without an interpreter stop, it is possible for some NC blocks to have been pre-interpreted but not yet performed. The usage time of the tool for these blocks is not taken into account during the tool change.

## Tapping

Settings in the configuration editor	MP number
Aggregates General CfgGlobalProperties <b>threadDwell</b>	601803

Use **MP\_threadDwell** to halt the NC program for several seconds during tapping. This function is usually used during the setup procedure.

## MP\_threadDwell

Dwell time for tapping  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0 to 65535 [s]  
Dwell time in seconds [s] at the end point of the thread

Default: 0 [s]

Access: LEVEL3

Reaction: RUN

## NC stop while tapping

Settings in the configuration editor	MP number
Aggregates General CfgGlobalProperties <b>threadLiftOff</b>	601804

Use **MP\_threadLiftOff** to specify if a tapping process can be interrupted by an NC stop. During such an interruption, the threading tool retracts by the programmed distance.

### MP\_threadLiftOff

Liftoff out of the thread  
 Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**  
 Upon NC stop in the thread the tool is lifted off by the programmed distance  
**FALSE**  
 NC stop not permitted while in the thread.

Default: FALSE

Access: LEVEL3

Reaction: RUN

## Activate handwheel in the thread

Settings in the configuration editor	MP number
Aggregates General CfgGlobalProperties <b>threadHandWheelOn</b>	601807

With **MP\_threadHandWheelOn**, you activate the "Handwheel in thread" function, which makes it possible to compensate position and angular error of the linear and spindle axes. In **MP\_threadHandWheelOn**, enter the value **TRUE**, to automatically insert the required G922 function in the thread cycles.



### MP\_threadHandWheelOn

Activation of the "handwheel in thread" function.  
Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **TRUE**

The function G922 is automatically inserted in the thread cycles.

**FALSE**

The function G922 is not automatically inserted in the thread cycles.

Default: -

Access: LEVEL3

Reaction: RUN

### Starting block of cycle programs in program run

Settings in the configuration editor	MP number
Aggregates General CfgGlobalProperties <b>ncStartWithActCyc</b>	601809

In **MP\_ncStartWithActCyc** you can define whether the cycle selected last in Teach-in is to be used as the start cycle when switching to Program Run, or whether the first cycle of the cycle program is to be selected automatically as the start cycle.

### MP\_ncStartWithActCyc

Program run with the most recently selected cycle  
Available from NCK software version: 597 110-05.

Format: Selection menu

Selection: **On**

When Program Run is selected, the most recently selected cycle remains active

**Off**

When switching to Program Run, the first cycle is always selected automatically.

Default: -

Access: LEVEL3

Reaction: RUN

## 7.11.11 Settings for cycles

Settings in the configuration editor	MP number
ProcessingData	
CfgGlobalTechPara	
<b>safetyDistBlankOut</b>	602005
<b>safetyDistBlankIn</b>	602006
<b>safetyDistWorkpOut</b>	602007
<b>safetyDistWorkpIn</b>	602008

You specify the safety clearances for cycle programming in the **CfgGlobalTechPara** parameter object. A distinction is made between machining of a workpiece blank and a prepared workpiece, as well as inside and outside machining. The control uses the global safety clearances if no safety clearances are defined in the cycle or DIN program.

### MP\_safetyDistBlankOut

Global safety clearance to the workpiece blank—outside  
Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 0.000 to 100 000.000 [mm]  
Default: 0  
Access: LEVEL1  
Reaction: RUN

### MP\_safetyDistBlankIn

Global safety clearance to the workpiece blank—inside  
Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 0.000 to 100 000.000 [mm]  
Default: 0  
Access: LEVEL1  
Reaction: RUN

### MP\_safetyDistWorkpOut

Global safety clearance to the prepared workpiece—outside  
Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 0.000 to 100 000.000 [mm]  
Default: 0  
Access: LEVEL1  
Reaction: RUN

### MP\_safetyDistWorkpIn

Global safety clearance to the prepared workpiece—inside  
Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 0.000 to 100 000.000 [mm]  
Default: 0  
Access: LEVEL1  
Reaction: RUN



## 7.11.12 Settings for smart.Turn operating mode

Settings in the configuration editor	MP number
ProcessingData	
CfgGlobalTechPara	
<b>DefaultG14</b>	602009
<b>DefaultCLT</b>	602010
<b>DefaultG60</b>	602011
<b>DefGlobG47P</b>	602012
<b>DefGlobG147SCT</b>	602013
<b>DefGlobG147SCK</b>	602014
<b>DefGlobOverMeasI</b>	602015
<b>DefGlobOverMeasK</b>	602016
<b>DefaultM3M4</b>	602017

You specify the global settings for programming with smart.Turn in the **CfgGlobalTechPara** parameter object. The parameters defined here are used in the start unit. The global settings of the start unit are the default values for all further units.

### MP\_DefaultG14

Settings for "Tool change point GWW" in the start unit  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: **-1: No axis**

Default setting: Do not generate a G14

**0: Simultaneously**

Default setting: G14 Q0

**1: First X, then Z**

Default setting: G14 Q1

**2: First Z, then X**

Default setting: G14 Q2

**3: Only X**

Default setting: G14 Q2

**4: Only Z**

Default setting: G14 Q4

Default: 0

Access: LEVEL1

Reaction: RUN

### **MP\_DefaultCLT**

Settings for "Coolant CLT" in the start unit  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: **0: Without**  
Default setting: Do not activate a coolant circuit  
**1: Coolant 1 on**  
Default setting: Activate coolant circuit 1  
**2: Coolant 2 on**  
Default setting: Activate coolant circuit 2

Default: 1

Access: LEVEL1

Reaction: RUN

### **MP\_DefaultG60**

Settings for "Protective zone G60" in the start unit  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 0: Active  
Default setting: G60 Q0  
1: Inactive  
Default setting: G60 Q1

Default: 0

Access: LEVEL1

Reaction: RUN

### **MP\_DefGlobG47P**

Global "Safety clearance G47" for the start unit. The "G47 P.." of the machining unit is generated with this safety clearance.  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: Safety clearance in [mm] with up to 9 decimal places

Default: 2 [mm]

Access: LEVEL1

Reaction: RUN

### **MP\_DefGlobG147SCI**

Global "Safety clearance plane SCI" for the start unit. The "I" of the "G147 I.. K.." call of the machining unit is generated with this safety clearance.  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: Safety clearance in [mm] with up to 9 decimal places

Default: 2 [mm]

Access: LEVEL1

Reaction: RUN





### **MP\_DefGlobG147SCK**

Global "Safety clearance infeed direction SCK" for the start unit. The "K" of the "G147 I.. K.." call of the machining unit is generated with this safety clearance.

Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: Safety clearance in [mm] with up to 9 decimal places  
Default: 2 [mm]  
Access: LEVEL1  
Reaction: RUN

### **MP\_DefGlobOverMeasl**

Global "Oversize I (X direction)" for the start unit This safety clearance is used for "Oversize I" during generation of the cycles for turning.

Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: Oversize in [mm] with up to 9 decimal places  
Default: 2 [mm]  
Access: LEVEL1  
Reaction: RUN

### **MP\_DefGlobOverMeasK**

Global "Oversize K (Z direction)" for the start unit This safety clearance is used for "Oversize K" during generation of the cycles for turning.

Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: Oversize in [mm] with up to 9 decimal places  
Default: 2 [mm]  
Access: LEVEL1  
Reaction: RUN

### **MP\_DefaultM3M4**

Default for the spindle "direction of rotation MD" in the "Tool" tab when creating/opening a new unit.

Available from NCK software version: 597 110-05.

Format: Selection menu  
Selection: **M3**  
**M4**  
Default: M3  
Access: LEVEL1  
Reaction: RUN

### 7.11.13 Settings for the simulation

Settings in the configuration editor	MP number
System	
Simulation	
CfgSimGeneral	
<b>restartAtM99</b>	114801
<b>pathDelay</b>	114802

If an NC program ends with M99, the control uses **MP\_restartAtM99** to check whether the simulation of the NC program should be repeated. Application example: Continuous simulation for exhibitions, etc.

#### **MP\_restartAtM99**

Assign tool holder to an inner/outer pitch circle  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **on**  
If M99, then the NC program is simulated again.  
**off**  
If M99, then the NC program is not simulated again.

Default: off

Access: LEVEL1

Reaction: NOTHING

**MP\_pathDelay** allows you to influence the speed of the simulation. After output of a traversed distance, the control waits for the time entered in "path delay."

#### **MP\_pathDelay**

Path delay  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: Enter the delay [s] (smallest unit: 10 ms).

Default: 0

Access: LEVEL1

Reaction: NOTHING



## Calculating the operating time

Settings in the configuration editor	MP number
System	
Simulation	
CfgTimeDetGeneral	
<b>toolChangeTime</b>	115001
<b>gearShiftingTime</b>	115002
<b>mFunTimeAllow</b>	115003
ProcessingTime	
CfgmFunKeys	
<b>mFunTimeKeys</b>	115401
CfgTimeDetMfun	
[Key name of the M time allowance]	
<b>mFun</b>	115101
<b>timeAllow</b>	115102

The time calculation function of the simulation calculates the non-productive times on the basis of the parameters entered here. The time entered in **MP\_mFunTimeAllow** is used for all M functions.

You can enter additional time allowances for specific M functions in the **ProcessingTime** parameter object.

### MP\_toolChangeTime

Time allowance for tool change  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 to 10 000 000.000  
Time for the tool change in seconds [s].  
Default: 0 [s]  
Access: LEVEL1  
Reaction: NOTHING

### MP\_gearShiftingTime

Time allowance for gear shifting  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 to 10 000 000.000  
Time for gear shifting in [s].  
Default: 0 [s]  
Access: LEVEL1  
Reaction: NOTHING

### MP\_mFunTimeAllow

General time allowance for M function  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 to 10 000 000.000  
Time for performing M functions in [s].  
Default: 0 [s]  
Access: LEVEL1  
Reaction: NOTHING

Proceed as follows to assign individual time allowances to M functions:

- ▶ Create a new key name for the M function's time allowance under **CfgTimeDetMfun**.
- ▶ Declare the M function in **MP\_mFun** and the individual time allowance in **MP\_timeAllow**. The simulation adds this individual time allowance to the time allowance from **MP\_mFunTimeAllow**.
- ▶ Enter the new key name for the time allowance to the list under **CfgmFunKeys/mFunTimeKeys**. The new key name is automatically offered at the very end of the list in the selection menu.

### **MP\_mFunTimeKeys**

Key names for M functions with specific time allowances  
Format: Array [0...29]  
Input: Key names for M functions with specific time allowances.  
Default: –  
Access: LEVEL1  
Reaction: NOTHING

### **MP\_mFun**

M function with specific time allowance  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0 to 999  
Number of the M function with specific time allowance.  
Default: 0  
Access: LEVEL1  
Reaction: NOTHING

### **MP\_timeAllow**

Operating time of the M function  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 to 10 000 000.000 [s]  
Operating time of the M function in seconds [s] for the simulation's time calculation.  
Default: 0 [s]  
Access: LEVEL1  
Reaction: NOTHING

## Simulation window, standard workpiece blank

Settings in the configuration editor	MP number
System	
Simulation	
CfgSimWindowSize	
<b>zeroPosX</b>	115201
<b>zeroPosZ</b>	115202
<b>deltaX</b>	115203
<b>deltaZ</b>	115204
CfgSimBlank	
<b>outsideDiameter</b>	115301
<b>blankLength</b>	115302
<b>rightBlankEdge</b>	115303
<b>insideDiameter</b>	115304

If no **workpiece blank** is programmed, the control works with the standard window size from the **CfgSimWindowSize** parameter object and the standard workpiece blank from the **CfgSimBlank** parameter object.

### MP\_zeroPosX

Zero position in X  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -100 000.000 to +100 000.000  
Distance of the coordinate origin referenced to the lower window in [mm].

Default: -100 [mm]  
Access: LEVEL1  
Reaction: NOTHING

### MP\_zeroPosZ

Zero position in Z  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: -100 000.000 to +100 000.000  
Distance of the coordinate origin referenced to the left window in [mm].

Default: -150 [mm]  
Access: LEVEL1  
Reaction: NOTHING

### MP\_deltaX

Vertical expansion of the graphic window  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0.000 to 100 000.000  
Vertical expansion of the graphic window in [mm].

Default: 200 [mm]  
Access: LEVEL1  
Reaction: NOTHING

### **MP\_deltaZ**

Horizontal expansion of the graphic window  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 to 100 000.000  
Horizontal expansion of the graphic window in [mm].  
Default: 200 [mm]  
Access: LEVEL1  
Reaction: NOTHING

### **MP\_outsideDiameter**

Outside diameter of the blank  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 to 100 000.000 [mm]  
Outside diameter of the blank in [mm].  
Default: 100 [mm]  
Access: LEVEL1  
Reaction: NOTHING

### **MP\_blankLength**

Workpiece blank length  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: 0.000 to 100 000.000 [mm]  
Total length of the blank in [mm].  
Default: 80 [mm]  
Access: LEVEL1  
Reaction: NOTHING

### **MP\_rightBlankEdge**

Oversize of the workpiece blank  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: -100 000.000 to +100 000.000  
Oversize of the workpiece blank referenced to the workpiece datum in [mm].  
Default: 0 [mm]  
Access: LEVEL1  
Reaction: NOTHING

### **MP\_insideDiameter**

Inside diameter of the blank  
Available from NCK software version: 597 110-01.  
Format: Numerical value  
Input: For hollow cylinders: inside diameter [mm]  
For solid workpieces: enter 0 [mm]  
Default: 0 [mm]  
Access: LEVEL1  
Reaction: NOTHING

### 7.11.14 User parameters

Parameters that the operator can change without needing to enter a code number are called user parameters. These are used to:

- Set the unit of measure
- Configure the display settings
- Set automatic operation
- Set tool measurement
- Set the behavior of the simulation
- Define global safety clearances
- Etc.

Select in the **Organization** operating mode:



▶ Press the soft key

### Parameter settings

User parameters are a subgroup of the configuration parameters. They are described as part of the configuration parameters (see table).

User parameters	Config parameters	Page
<b>Definition of unit of measure in effect for display</b>	System/ DisplaySettings/ CfgUnitOfMeasure	1223
<b>General display settings</b>	System/ DisplaySettings/ CfgGlbDispSettings	1223
<b>General settings for automatic operation</b>	System/ CfgGlobalProperties	1410
<b>Tool measurement</b>	System/ CfgToolMeasuring	1410
<b>Simulation – general settings</b>	Simulation/ CfgSimGeneral	1422
<b>Simulation – machining times for the NC functions in general</b>	Simulation/ CfgTimeDetGeneral	1423
<b>Simulation – operating times for M functions</b>	Simulation/ CfgTimeDetMfun	1423
<b>Simulation – specification of the (standard) window size</b>	System/Simulation/ CfgSimWindowSize	1425
<b>Simulation – specification of the (standard) blank size</b>	System/Simulation/ CfgSimWindowSize	1425
<b>Processing – General settings – Safety clearances</b>	ProcessingData/ CfgGlobalTechPara	1418

## 7.12 Configuration of the Lathe

The MANUALplus 620 is shipped with a modular standard configuration. You can adapt this standard configuration to your machine with very little effort. This chapter describes what configurations are possible and how they are set.

Based on the basic configuration, you can enter settings for the following components:

- Coordinate system of the lathe
- Linear axes
- Spindles, gear stages
- C axis, driven tool
- Y axis
- W axis
- Tool carrier

### 7.12.1 Coordinate system

Specify in **MP\_coordSystem** the coordinate system of the lathe.

The MANUALplus 620 supports horizontal and vertical lathes, each with the tool carrier located in front or behind the workpiece. The standard configuration describes a horizontal lathe with tool carrier behind the workpiece.

Settings in the configuration editor	MP number
System DisplaySettings CfgCoordSystem <b>coordSystem</b>	114901

Selectable configurations:

- +X, +Z Tool carrier behind the workpiece
- X, +Z Tool carrier in front of the workpiece
- +Z, +X Vertical lathe: tool carrier to the right of the workpiece
- +Z, -X Vertical lathe: tool carrier to the left of the workpiece



## 7.12.2 Settings for linear axes

### Counting direction of the axes

Check the counting directions of the actual and nominal values of the individual axes in the **MP\_signCorrActualVal** and **MP\_signCorrNominalVal** parameters.

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the axis] CfgAxisHardware <b>signCorrActualVal</b> <b>signCorrNominalVal</b>	    400001 400002

### Reference positions of the axes

Then, starting from the positive quadrant, set the reference position of each axis via the **MP\_refPos** parameter.

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the axis] CfgReferencing <b>refPosition</b>	    400403

### Software limit switch

Set the software limit switches in the **MP\_swLimitSwitchPos** and **MP\_swLimitSwitchNeg** parameters.

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the axis] CfgPositionLimits <b>swLimitSwitchPos</b> <b>swLimitSwitchNeg</b>	    400501 400502

### Traverse direction of the handwheels

For handwheels connected to the position inputs, check the traverse direction in the **MP\_countDir** parameter.

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the axis] CfgAxisHandwheel <b>countDir</b>	    400202

## Manual direction keys

Check the direction of motion of the manual direction keys in the **NP\_MG\_key\_X\_inv\_direction** operand.

Settings in the configuration editor	MP number
System PLC CfgOemBool [NP_MG_key_X_inv_direction] value [0]: false	104501
[NP_MG_key_Z_inv_direction] value [0]: false	104501

### 7.12.3 Settings for spindles

#### Direction of spindle rotation

Check the direction of spindle rotation (M functions M3 and M4) in the **MP\_signCorrActualVal**, **MP\_signCorrNominalVal** and **MP\_changeTurnDir** parameters (see "Direction of rotation for spindles with C axis" on page 664).

Settings in the configuration editor	MP number
Axes ParameterSets [Key name of spindle] CfgAxisHardware <b>signCorrActualVal</b> <b>signCorrNominalVal</b>	400001 400002
CfgSpindle <b>changeTurnDir</b>	401509

#### Activating further gear stages

The standard configuration contains additional inactive parameters for further gear stages for the main spindle S1 (**PS1\_1**, **PS1\_2**, **PS1\_3**). These parameter blocks were gated in **KeySynonym/CfgKeySynonym** to the parameter set for gear stage 0 (**PS1\_0**), and are therefore identical as a default. You only have to change the parameters that differ in the individual gear stages. The parameter set **PS1\_C1** was preconfigured for C-axis operation with spindle S1.

Make changes to the parameter sets in **Axes/ParameterSets**. The parameter sets describe the axis control response, the encoder connection, the encoder signals, etc.



Assign a parameter set to an axis by entering the key name of the parameter set in **MP\_parList** (see "Assigning parameter sets" on page 637).

Settings in the configuration editor	MP number
Axes PhysicalAxis [Key name of the axis] CfgAxis parList [0]: <b>PS1_0</b> [1]: <b>PS1_1</b> ...	     300107 300107

The switching between gear stages is controlled by the PLC. Transfer to the PLC a selection of the parameter sets listed in **MP\_parList** by entering them in **MP\_gearSpeed0**.

Settings in the configuration editor	MP number
System PLC CfgPlcSStrobe [Key name of S strobe] parList gearSpeed0 [0]: <b>PS1_0</b> [1]: <b>PS1_1</b> ...	     104008 104008

The configuration object CfgFeedLimits of the respective parameter set defines the minimum and maximum spindle shaft speed for each gear stage. The list must be sorted in ascending order, with the smallest shaft speed at the top. Gear ranges are not supported if the list is missing or empty.



## Configuration as external spindle

Settings in the configuration editor	MP number
Axes	
PhysicalAxis	
[Key name of the axis]	
CfgAxis	
<b>axisHw</b>	300104
<b>axisMode</b>	300105

In order to operate an externally driven tool (e.g.drilling machine via spindle S2) only by the PLC without an additional control loop, you can configure the driven tool as an external spindle.

To configure a spindle as an external spindle, enter the value **None** in **MP\_axisHw**. You must also enter the value **PlcControlled** in **MP\_axisMode**.



### Note

For external spindles, you can only enter feed rate per minute (G94) and constant speed (G97) when entering the feed rate and rotational speed in the TSF menu.

## 7.12.4 Driven tool

A driven tool powered by spindle S2 is preconfigured in the standard configuration of the MANUALplus 620.

### Configuration without driven tool

Remove spindle S2 from the configuration if your machine is operated without a driven tool.

- ▶ Remove spindle S2 from the **axisList** and **spindleIndices** lists of the **CfgAxes** entity.

Settings in the configuration editor	MP number
System	
CfgAxes	
axisList	100001
<b>[0]: X1</b>	
<b>[1]: Z1</b>	
<b>[2]: S1</b>	
<b>[3]: S2</b>	
spindleIndices	100002
<b>[0]: S1</b>	
<b>[1]: S2</b>	

- ▶ Remove kinematics that contain spindle S2 (**K1\_CH1\_S12\_C1** and **K2\_CH1\_S12**)



When using the new kinematic model (as of NC SW 548 328-03):

Settings in the configuration editor	MP number
Channels ChannelSettings [Key name of the machining channel] CfgKinList kinCompositeModels <b>[0]: K1_CH1_S12_C1</b> <b>[1]: K2_CH1_S12</b> <b>[2]: K3_CH1_S1_C1</b> <b>[3]: K4_CH1_S1</b>	203001

When using the old kinematic model (up to NC SW 548 328-02):

Settings in the configuration editor	MP number
Channels ChannelSettings [Key name of the machining channel] CfgChannelAxes kinModels <b>[0]: K1_CH1_S12_C1</b> <b>[1]: K2_CH1_S12</b> <b>[2]: K3_CH1_S1_C1</b> <b>[3]: K4_CH1_S1</b>	200306

### Configuration with driven tool

If you want to reinsert spindle S2, then you must undo the steps described in the section above.



#### Warning

When reinserting spindle S2 into your configuration, do not reverse the order of the steps described in the section above!

## 7.12.5 Settings for the C axis

In addition to a C axis driven by the workpiece spindle (spindle S1), the standard configuration of the MANUALplus 620 also has parameters for a separately driven C axis (spindle S4).

The standard configuration has a preconfiguration for a C axis driven by the workpiece spindle (spindle S1).

### C axis driven via workpiece spindle

**Removing the C axis:** Make the following changes if your machine is to be operated without a C axis or with a separately driven C axis:

- ▶ Remove the C1 entry from the **CfgChannelAxes** entity in the **progAxis** list

Settings in the configuration editor	MP number
Channels ChannelSettings [Key name of the machining channel] CfgChannelAxes progAxis [0]: X1 [1]: Y1 [2]: Z1 [3]: C1	200301

- ▶ When using the new kinematic model (as of NC software level 548328-03), remove the associated C-axis kinematics (**K1\_CH1\_S12\_C1** and **K3\_CH1\_S1\_C1**) from the **CfgKinList** entity in the **kinCompositeModels** list.

Settings in the configuration editor	MP number
Channels ChannelSettings [Key name of the machining channel] CfgKinList kinCompositeModels [0]: K1_CH1_S12_C1 [1]: K2_CH1_S12 [2]: K3_CH1_S1_C1 [3]: K4_CH1_S1	203001

- ▶ When using the old kinematic model (up to NC software level 548328-02), remove the associated C-axis kinematics (**K1\_CH1\_S12\_C1** and **K3\_CH1\_S1\_C1**) from the **CfgChannelAxis** entity in the **kinModels** list.



Settings in the configuration editor	MP number
Channels ChannelSettings [Key name of the machining channel] CfgChannelAxes kinModels [0]: K1_CH1_S12_C1 [1]: K2_CH1_S12 [2]: K3_CH1_S1_C1 [3]: K4_CH1_S1	200306

- ▶ Remove the C1 entry from the **CfgAggregateKeys** entity in the **caxisKeys** list

Settings in the configuration editor	MP number
Aggregates General CfgAggregateKeys caxisKeys [0]: C1	600004

**Inserting a C axis:** In order to create a configuration with a C axis driven by the workpiece spindle, the steps described above must be undone.



#### Warning

When reinserting the C axis into your configuration, do not reverse the order of the steps described in the section above!

## C axis with separate drive

The standard configuration features two spindles (workpiece spindle S1 and tool spindle S2). The C axis with separate drive is realized via spindle 4 (S4). Spindle S3 must be configured additionally to spindle S4. The parameters already exist in the axis data (PS3\_0, PS4\_0 and PS4\_C1). Spindle S3 is marked as inactive in the axisMode parameter in the CfgAxis entity.



### Note

Please note that, if the same position encoder is used for the main spindle and the C axis, the operation of a separately driven C axis along with the use of a CC 61xx is not possible until the beginning of 2012. Contact HEIDENHAIN if you need this feature before the above mentioned date.

Make the following changes to activate the C axis with separate drive via spindle S4:

- ▶ Insert spindles S3 and S4 in the **axisList** and **spindleIndices** lists under **CfgAxes**.

Settings in the configuration editor	MP number
System CfgAxes axisList [0]: X1 [1]: Z1 [2]: S1 [3]: S2 [4]: S3 [5]: S4	100001

Settings in the configuration editor	MP number
System CfgAxes spindleIndices [0]: S1 [1]: S2 [2]: S3 [3]: S4	100002

- ▶ Assign the separate spindle (S4) to the C axis (C1) in **MP\_relatedAxis**

Settings in the configuration editor	MP number
Axes CfgProgAxis [Key name of the C axis] <b>relatedAxis: S4</b>	300005

- ▶ In addition, assign the workpiece spindle (S1) to the C axis in **MP\_relatedWpSpindle**.





Settings in the configuration editor	MP number
Axes Settings C axis [Key name of the C axis] CfgCAxisProperties <b>relatedWpSpindle: S1</b>	300803


- ▶ Deactivate spindle S3 with the **MP\_axisMode** parameter in **CfgAxis**.


Settings in the configuration editor	MP number
Axes PhysicalAxis [Key name of the spindle axis] CfgAxis <b>axisMode: NotActive</b>	300105

- ▶ Set the **MP\_plcSpindleSelect** parameter in **CfgGlbDispSettings** to **TRUE** to define the spindle (e.g. main spindle, C axis or driven tool) to be assigned the TSF dialog.

Settings in the configuration editor	MP number
System DisplaySettings CfgGlbDispSettings <b>plcSpindleSelect</b>	604801

Activate the appropriate axis compensation for spindle S4:

- ▶ Switch to the **Organization** mode of operation.
- ▶ Press the  soft key.
- ▶ Enter the code number **95148**.
- ▶ Press the **END** soft key.
- ▶ Shift the soft-key row to the right and press the **PGMGT** soft key.
- ▶ On the **PLC:** drive, go to the **PLC:table** directory and select the **config.cma** file.
- ▶ In the table that opens, activate the row in which the **AXIS\_C1** entry for axis compensation is entered for spindle S4 instead of spindle S1. For a row to be active, the asterisk must be in the **ACTIVE** column at the beginning of the row.
- ▶ If the asterisk is not in the row for your configuration, use the arrow keys to move the cursor to the asterisk, and press the **TAB** key to remove it. Now use the cursor to mark the **ACTIVE** column of the desired row, and enter the asterisk by pressing the **ENTER** key.



→ Maschine smart.Turn Werkzeug-Editor Tabelle

Tabelle aktiv? ja=ENT/nein=NOENT

Datei: e:\table\config.cma Zeile: 0

NR	ACTIVE	X1	Z1	S1	S2	S3	S4	Y1	W1
0	*	AXIS_X1	AXIS_Z1	AXIS_C1				AXIS_Y1	AXIS_W1
1		AXIS_X1	AXIS_Z1				AXIS_C1	AXIS_Y1	AXIS_W1

ANFANG ENDE SEITE SEITE ZEILE EINFÜGEN ZEILE LÖSCHEN SUCHEN ENDE

## 7.12.6 Configuring the Y axis

In addition to the X and Z axes, you can optionally activate the Y axis that is perpendicular to these axes. If the Y axis is to be positioned at an angle not equal to 90° to the X or Z axis, the Y axis can also be configured as oblique axis.

The configuration data of the MANUALplus 620 contain preconfigured kinematics and axis data for the Y axis. In order to activate the Y axis, the configuration data must be modified as follows.

### Activation of Y axis

**Activate the Y axis:** Make the following changes if your machine is to be operated with a Y axis:

- ▶ Remove the Y1 entry in the entity **CfgAxes** from the list **specCoordSysList**.

Settings in the configuration editor	MP number
System CfgAxes specCoordSysList [0]: Y1	100003

- ▶ Insert the entry Y1 in the list **axisList** of the entity **CfgAxes**.

Settings in the configuration editor	MP number
System CfgAxes axisList [0]: X1 [1]: Z1 [2]: Y1 [3]: S1 [4]: S2	100001

- ▶ Add the entry Y1 to the lists **refAxis** and **restoreAxis** of the entity **CfgChannelAxes** to define for the Y axis the reference sequence and the sequence for returning to the contour.

Settings in the configuration editor	MP number
Channels ChannelSettings [Key name of the machining channel] CfgChannelAxes refAxis [0]: X1 [1]: Y1 [2]: Z1	200303
restoreAxis [0]: Z1 [1]: Y1 [2]: X1	200305

- ▶ To display the current position and distance-to-go of the Y axis in the dashboard, change the entries in the lists **opmodeStartup**, **opmodeReference**, **opmodeManual** and **opmodeAutomatic** of the entity **CfgChannDashboard** as follows.

Settings in the configuration editor	MP number
Channels	
ChannelSettings	
[Key name of the machining channel]	
CfgChannDashboard	
opmodeStartup	
[0]: <b>DB_STARTUP1_Y</b>	203402
opmodeReference	
[0]: <b>DB_REFER1_Y</b>	203403
opmodeManual	
[0]: <b>DB_MANUAL1_Y</b>	203404
opmodeAutomatic	
[0]: <b>DB_AUTO1_Y</b>	203406

- ▶ Switch off the test mode of the Y axis by entering **MP\_testMode** =FALSE. Please remember that the Y axis must be connected electrically if **MP\_axisMode** = Active. In this case, you should also verify if a speed encoder input is assigned to the Y axis in **MP\_speedEncoderInput**, and a nominal speed command output in **MP\_pwmSignalOutput**.

Settings in the configuration editor	MP number
Axes	
PhysicalAxis	
[Y1]	
CfgAxis	
<b>testMode</b>	Y1.300106




## Y axis as oblique axis

The term **oblique axis** is used to describe an axis that is superposed on another axis, and is **not** perpendicular to this axis. "Superposed" means that the axis is connected to the base axis, and moves with the base axis.

The Y axis is usually used as an oblique axis. The following variants exist:

- Variant 1: The oblique axis  $Y'$  is superposed on the X axis, and is at an angle other than  $90^\circ$  to the X axis.
- Variant 2: The X axis is superposed on the oblique axis  $Y'$ , and is at an angle other than  $90^\circ$  to the  $Y'$  axis.

In both cases if the  $Y'$  axis is moved, then compensating movements must take place in the X axis.




Designations:

- **X**: X axis (coupling axis)
- **Y**: (virtual ) Y axis
- **Y'**: Oblique axis
- **w**: Angle between coupling axis and oblique axis

Example:

The tool is traversed from position Y1 to Y2. The oblique axis moves along the path Y'12. At the same time, the X axis is moved along the path Xa in compensation (see the sketch).



In the kinematics of the Y axis, a rectangular coordinate system ( $w = 90^\circ$ ) was preconfigured, in which the Y axis is superposed on the X axis. If you want to design the Y axis as an oblique axis, you must correct the transformation of the Y axis (**KT\_Y1**) according to the angle that is formed by the Y axis and the X axis.

If movement is in the positive Y direction, the compensating motion in the X axis is in the negative X direction for angles from  $0^\circ$  to  $90^\circ$ .

**Settings for the new kinematic model (as of NC SW 548 328-03)**

When using the new kinematic model, the following steps are necessary for activating the subkinematics for Y as oblique axis (for example  $C=30^\circ$ ).

- ▶ Delete subkinematics **K\_XYZ\_CH1** and rename **K\_XYZ\_CH1\_Y30** to **K\_XYZ\_CH1**.

Settings in the configuration editor	MP number
Channels	
Kinematics	
CfgKinSimpleModel	
...	
<b>K_XYZ_CH1</b>	202800
...	
<b>K_XYZ_CH1_Y30</b>	202800



- For a configuration with turret and multifix, the mirrored subkinematics **K\_XYZ\_CH1\_Y30\_MIR** for the Y axis with oblique-axis coupling must be inserted instead of **K\_XYZ\_CH1\_MIR** into the tool holder description (in the **kinModel** list).

Settings in the configuration editor	MP number
Aggregates ToolMount TH2_TM001_MULTI CfgToolMount kinModel <b>K_WP_S1_MIR_X</b> <b>K_XYZ_CH1_Y30_MIR</b>	600419

**Settings for the old kinematic model (up to NC SW 548 328-02)**

The following table illustrates the transformation settings required for angles of 30°, 45° and 60°. However, you can also specify any intermediate values for angle  $w$ .

<b>w = 90° (preconfigured)</b>	<b>w = 30°</b>	<b>w = 45°</b>	<b>w = 60°</b>	<b>f(w)</b>
Channels Kinematics CfgTrafoByDir KT_Y1 <b>zDir</b> <b>[0] : 1</b> <b>[1] : 0</b> <b>[2] : 0</b> <b>xDir</b> <b>No</b> <b>Change</b>				
	<b>0.866</b>	<b>0.707</b>	<b>0.5</b>	<b>cos (w)</b>
	<b>0</b>	<b>0</b>	<b>0</b>	<b>sin (w)</b>
	<b>0.5</b>	<b>0.707</b>	<b>0.866</b>	
Channels Kinematics CfgTrafoByDir KT_TH1 <b>zDir</b> <b>No</b> <b>Change</b> <b>xDir</b> <b>[0] : 0</b> <b>[1] : 1</b> <b>[2] : 0</b>				
	<b>0</b>	<b>0</b>	<b>0</b>	<b>cos (w)</b>
	<b>0.866</b>	<b>0.707</b>	<b>0.5</b>	<b>sin (w)</b>
	<b>0.5</b>	<b>0.707</b>	<b>0.866</b>	



## Activating compensating movement in Manual mode

If the Y axis is designed as an oblique axis, the compensating motion of the axis coupled to the Y axis can also be activated in Manual mode of operation by using **MP\_kinManualMode**.

Settings in the configuration editor	MP number
Channels ChannelSettings [CH_NC1] CfgChannelProperties <b>kinManualMode</b>	203804

Reference dimensions and limit switches must be entered for each individual axis. The positions are then displayed in the rectangular coordinate system.

### MP\_kinManualMode

Switch kinematics off/on in Manual mode  
Available from NCK software version: 597 110-04.

Format: Selection menu  
Selection: **on**  
Kinematics active in Manual mode  
**off**  
Kinematics not active in Manual mode

Default: -  
Access: LEVEL3  
Reaction: RUN

## Reference run with the oblique axis

The oblique axis and coupling axis move independently of each other during reference run. When the oblique axis is traversed, the compensating motions only take place after all axes have determined the reference points.

## Activating compensation value tables

Copies of the compensation value tables that were expanded for the Y axis are saved in the directory **tnc:\update\o\table** during the software update. These tables (axis\_x1.com, axis\_y1.com, ...) are not active. In order to activate the compensation value tables expanded by HEIDENHAIN, use **TNCremoNT** to save the tables stored in **tnc:\table** and replace them with the tables contained in the directory **tnc:\update\o\table**. After this, previously existing compensation values must be updated accordingly.





## Tool change with active Y axis

Settings in the configuration editor	MP number
Aggregates General CfgGlobalProperties <b>doProgAfterTCall</b>	601806

Use **MP\_doProgAfterTCall** to define whether a subprogram is to be run after a tool change so that the Y axis moves to position Y=0. The expert program **\_tcall1.ncs** is used as subprogram by default (see "Expert programs" on page 1476).

### MP\_doProgAfterTCall

Run subprogram \_tcall1.ncs after the tool change  
Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **TRUE**

The subprogram \_tcall1.ncs is run after the tool change

**FALSE**

No subprogram is run after the tool change

Default: -

Access: LEVEL3


Reaction: RUN

## Deactivating the Y axis

If you want to remove the Y axis from the configuration of your machine, you must follow the above-described procedure in reverse order.

## 7.12.7 Configuring parallel axes

In addition to the principal axes X, Y and Z you can configure the parallel secondary axes U, V and W. The principal axes are assigned to the secondary axes as follows:




Principal axis	Parallel axis	Rotary axis
X	U	A
Y	V	B
Z	W	C

The MANUALplus 620 includes prepared configuration data for the parallel axes U, V and W. To activate the parallel axes, the configuration data must be installed and the configuration parameters must be modified as described below.

### Installing the configuration data


Proceed as follows to install the configuration data:

- ▶ Switch to the **Organization** mode of operation.
- ▶ Press the  soft key.
- ▶ Enter the code number **95148**.
- ▶ Press the **COPY SAMPLE FILES** soft key to copy the prepared configuration data to the **OEM:\Update\vbck\para** directory.
- ▶ Copy the configuration data to the **TNC:\bck\para** directory.
- ▶ Switch to the **Transfer** mode of operation.
- ▶ Press the **Parameter** soft key and select the corresponding **AxisU1/V1/W1\_AddOn.zip**. The complete **AxisUVW\_AddOnFull.zip** should only be used for newly installed systems because it also overwrites existing settings.
- ▶ Press the **Parameter Restore** soft key to install the selected AddOn.zip on the control.

In addition, the machine parameters must be modified as described below:

## Configuring the parallel axes (U, V, W)

Make the following changes if your machine is to be operated with a U, V or W axis:

- ▶ Switch to the **Organization** mode of operation.
- ▶ Press the  soft key.
- ▶ Enter the code number **95148**.
- ▶ Press the **CONFIG FILE LISTS** soft key.
- ▶ Enter the **axis\_u1.cfg**, **axis\_v1.cfg** and **axis\_w1.cfg** files in the **dataFiles** list in CfgConfigDataFiles.

Settings in the configuration editor	MP number
CfgConfigDataFiles dataFiles ... [.]: %oemPath%\axis_u1.cfg [.]: %oemPath%\axis_v1.cfg [.]: %oemPath%\axis_w1.cfg ...	106303

- ▶ Define the type of parallel axis (linear axis, rotary axis) in **MP\_progKind**, see "MP\_progKind" on page 629. The direction of movement of the parallel axis can also be defined in CfgProgAxis with **MP\_dir**, see "MP\_dir" on page 628. The MANUALplus 620 supports various methods for treating movements of parallel axes, see "Parallel Axes" on page 762. Please note that option 94 "Parallel Axes" is only required for automatic position compensation in the principal axis for movements of the parallel axis (**MP\_parAxComp = Display**).
- ▶ Now add the parallel axes (U, V, W) to the **axisList** in **CfgAxes**. To do so, press the **MORE FUNCTIONS** soft key, then the **INSERT** soft key and select **U1, V1, W1** in the pop-up window.

Settings in the configuration editor	MP number
System CfgAxes axisList [0]: X1 [1]: Z1 [2]: U1 [3]: V1 [4]: W1 [5]: S1 [6]: S2	100001

- Now you have to add the parallel axes (U, V, W) to the list of programmed axes.

Settings in the configuration editor	MP number
Channels Channel Settings [Key name of the machining channel] CfgChannelAxes progAxis [0]: X1 [1]: Y1 [2]: Z1 [3]: U1 [4]: V1 [5]: W1 [6]: C1	200301

### Including the parallel axes (U, V, W) in the kinematic models

- To be able to insert the parallel axes as machine axes into a kinematic chain, enter these now in **CfgKinSimpleAxis**. To do so, copy the existing entry "MachAxisX1" and rename it to **MachAxisU1**, **MachAxisV1** or **MachAxisW1**. In **MP\_dir**, define the direction of the machine axis and in **MP\_axisRef** the reference to the associated machine axis.

Settings in the configuration editor	MP number
Channels Kinematics CfgKinSimpleAxis MachAxisU1 dir: X axisRef: U1 MachAxisV1 dir: Y axisRef: V1 MachAxisW1 dir: Z axisRef: W1	202700 202701 202702 ...



- Copy the subkinematics K\_XYZ\_CH1 located in **CfgKinSimpleModel** and rename it to the new subkinematics **K\_XYZUVW\_CH1**. Expand the **kinObjects** list of this subkinematics to include the parallel axes (U, V, W).

Settings in the configuration editor	MP number
Channels	
Kinematics	
CfgKinSimpleModel	
K_XYZUVW_CH1	202800
<b>kinObjects</b>	202801
[0]: TransMaAxDummy2_CO	...
[1]: MachAxisY1	
[2]: TransMaAxDummy1_CO	
[3]: MachAxisX1	
[4]: MachAxisZ1	
[5]: MachAxisU1	
[6]: MachAxisV1	
[7]: MachAxisW1	
[8]: MACH_BASE	

- Enter the subkinematics **K\_XYZUVW\_CH1** into the **subKinList** of the **K1\_CH1\_S12\_C1** subkinematics model in **CfgKinComposModel**. Then repeat this step for all kinematic models being used (e.g. K1\_CH1\_S12\_C1, K2\_CH1\_S12,...)

Settings in the configuration editor	MP number
Channels	
Kinematics	
CfgKinComposModel	
K1_CH1_S12_C1	202900
<b>subKinList</b>	202901
[0]: TOOL_TH1	...
[1]: K_XYZUVW_CH1	
[2]: K_C1	
[3]: K_WP_S1	



**Dashboard display of the parallel axes (U, V, W)**

- ▶ To be able to display the positions of the parallel axes in the dashboard, copy the dashboard element **DB\_C1** located in **CfgDashboardElemnt** and rename it to **DB\_U1**, **DB\_V1** or **DB\_W1**.

Settings in the configuration editor	MP number
DisplaySettings	
CfgDashboardElemnt	
DB_U1	113100
<b>dashboardpicType: ActualCAxisValue</b>	113101
<b>attribut: 0</b>	113102
<b>entityList: U1</b>	113103
DB_V1	...
<b>dashboardpicType: ActualCAxisValue</b>	
<b>attribut: 0</b>	
<b>entityList: V1</b>	
DB_W1	
<b>dashboardpicType: ActualCAxisValue</b>	
<b>attribut: 0</b>	
<b>entityList: W1</b>	

- ▶ Then enter the dashboard elements (DB\_U1, DB\_V1, DB\_W1) into the **elementList** of a dashboard display (e.g. DB\_DEFAULT).

Settings in the configuration editor	MP number
DisplaySettings	
CfgDashboard	
DB_DEFAULT	113200
<b>elementList</b>	113201



### Activating parallel axes

- ▶ Switch off the test mode of the parallel axis by entering **MP\_testMode** =FALSE. Please remember that the U/V/W axis must be connected electrically if **MP\_axisMode** = Active. In this case, you should also verify if a speed encoder input is assigned to the U/V/W axis in **MP\_speedEncoderInput**, and a nominal speed command output in **MP\_pwmSignalOutput**.

Settings in the configuration editor	MP number
Axes PhysicalAxis [W1] CfgAxis <b>testMode</b>	300106

- ▶ Before exiting the configuration editor, save all the changes you have made and restart the control.

### Activating compensation value tables

- ▶ Copies of the compensation value tables that were expanded for the U/V/W axis are saved in the directory **oem:\update\o\table** during the software update. These tables (axis\_x1.com, axis\_w1.com, ...) are not active. In order to activate the compensation value tables expanded by HEIDENHAIN, use **TNCremoNT** to save the tables stored in **tnc:\table** and replace them with the tables contained in the directory **tnc:\update\o\table**. After this, previously existing compensation values must be updated accordingly.

### Deactivating parallel axes

If you want to remove a parallel axis from the configuration of your machine, you must follow the above-described procedure in reverse order.

### 7.12.8 Activating gantry axes

The fundamental configuration of gantry axes and axes with master-slave torque control is made with the machine parameters in **CfgAxisCoupling**, see "Synchronized Axes (Option 24)" on page 764

The MANUALplus 620 includes prepared configuration data for a gantry axis G1. To activate the gantry axis G1, the configuration data must be installed and the configuration parameters must be modified as described below.




#### Note

The number of slave axes in master-slave torque control and gantry combinations is restricted by the controller unit on which the master axis is configured. The slave axes and the master axis must be configured on the same drive-control motherboard (DSPs). Thus, up to five slave axes are possible per CC 61xx.

#### Installing the configuration data

Proceed as follows to install the configuration data:

- ▶ Switch to the **Organization** mode of operation.
- ▶ Press the  soft key.
- ▶ Enter the code number **95148**.
- ▶ Press the **COPY SAMPLE FILES** soft key to copy the prepared configuration data to the **OEM:\Update\vbck\para** directory.
- ▶ Copy the configuration data to the **TNC:\bck\para** directory.
- ▶ Switch to the **Transfer** mode of operation.
- ▶ Press the **Parameter** soft key and select the corresponding MpGantryAxis\_AddOn.zip.
- ▶ Press the **Parameter Restore** soft key to install the **GantryAxis\_AddOn.zip** on the control. The complete **GantryAxis\_AddOnFull.zip** should only be used for newly installed systems because it also overwrites existing settings.


In addition, the machine parameters must be modified as described below:





## Configuring gantry axis G1

Make the following changes if your machine is to be operated with a gantry axis G1:

- ▶ Switch to the **Organization** mode of operation.
- ▶ Press the  soft key.
- ▶ Enter the code number **95148**.
- ▶ Press the **CONFIG FILE LISTS** soft key.
- ▶ Enter the **axis\_g1.cfg** file in the **dataFiles** list located in CfgConfigDataFiles.

Settings in the configuration editor	MP number
CfgConfigDataFiles dataFiles ... [.]: %oemPath%\axis_u1.cfg [.]: %oemPath%\axis_v1.cfg [.]: %oemPath%\axis_w1.cfg ...	106303

- ▶ Define the type of gantry axis G1 (linear axis, rotary axis) in **MP\_progKind**, see "MP\_progKind" on page 629. The direction of movement of the gantry axis can also be defined in CfgProgAxis with **MP\_dir**, see "MP\_dir" on page 628.
- ▶ Now add the gantry axis G1 to the **axisList** in **CfgAxes**. To do so, press the **MORE FUNCTIONS** soft key, then the **INSERT** soft key and select **G1** in the pop-up window.

Settings in the configuration editor	MP number
System CfgAxes axisList [0]: X1 [1]: Z1 [2]: S1 [3]: S2 [4]: G1	100001

## Dashboard display of the gantry axis

- ▶ To be able to display the position of the gantry axis in the dashboard, copy the dashboard element **DB\_X1\_POS** located in **CfgDashboardElemnt** and rename it to **DB\_G1\_POS**.

Settings in the configuration editor	MP number
DisplaySettings	
CfgDashboardElemnt	
DB_G1_POS	113100
<b>dashboardpicType: ActualValue</b>	113101
<b>attribut: 1</b>	113102
<b>entityList: G1</b>	113103

- ▶ Then enter the dashboard element (DB\_G1\_POS) into the **elementList** of a dashboard display (e.g. DB\_DEFAULT).

Settings in the configuration editor	MP number
DisplaySettings	
CfgDashboard	
DB_DEFAULT	113200
<b>elementList</b>	113201

## Activating the gantry axis


- ▶ Switch off the test mode of the gantry axis G1 by entering **MP\_testMode = FALSE**. Please remember that the gantry axis must be connected electrically if **MP\_axisMode = Active**. In this case, you should also verify if a speed encoder input is assigned to the gantry axis in **MP\_speedEncoderInput**, and a nominal speed command output in **MP\_pwmSignalOutput**.

Settings in the configuration editor	MP number
Axes	
PhysicalAxis	
[W1]	
CfgAxis	
<b>testMode</b>	300106

- ▶ Before exiting the configuration editor, save all the changes you have made and restart the control.

### 7.12.9 Configuring rear-side machining


As of NC software 548 328-04, the MANUALplus 620 optionally supports rear-side machining with an opposing spindle.



The MANUALplus 620 includes prepared configuration data for rear-side machining with a slide (X1 and Z1 axis) and an opposing spindle S4. In addition to the C axis C1 of the main spindle, the C axis C2 on the opposing spindle is supported, too. To activate rear-side machining, the configuration data must be installed and the configuration parameters must be modified as described below.

#### Installing the configuration data


Proceed as follows to install the configuration data:

- ▶ Switch to the **Organization** mode of operation.
- ▶ Press the  soft key.
- ▶ Enter the code number **95148**.
- ▶ Press the **COPY SAMPLE FILES** soft key to copy the prepared configuration data to the **OEM:\Update\wbck\para** directory.
- ▶ Copy the configuration data to the **TNC:\wbck\para** directory.
- ▶ Switch to the **Transfer** mode of operation.
- ▶ Press the **Parameter** soft key and select the corresponding **RsmAddOn.zip**. The complete **RsmAddOnFull.zip** should only be used for newly installed systems because it also overwrites existing settings.
- ▶ Press the **Parameter Restore** soft key to install the RsmAddOn.zip on the control. During the installation, the following configuration data and expert programs are transferred:
  - kinem\_rsb.cfg (kinematics for rear-side machining)
  - axis\_c2.cfg (axis data for C axis C2)
  - c2\_ein.ncs (activate C axis C2)
  - c2\_aus.ncs (deactivate C axis C2)

In addition, the machine parameters must be modified as described below:

## Configuring rear-side machining

Make the following changes if your machine is to support rear-side machining with an opposing spindle:

- ▶ Switch to the **Organization** mode of operation.
- ▶ Press the  soft key.
- ▶ Enter the code number **95148**.
- ▶ Press the **CONFIG FILE LISTS** soft key.
- ▶ In the **dataFiles** list located in CfgConfigDataFiles, enter the files **axis\_c2.cfg** and **kinem\_rsb.cfg**.

Settings in the configuration editor	MP number
CfgConfigDataFiles dataFiles ... [.]: %oemPath%\axis_c2.cfg [.]: %oemPath%\kinem_rsb.cfg ...	106303

- ▶ Now add the spindles S3 and S4 to the **axisList** in **CfgAxes**. To do so, press the **MORE FUNCTIONS** soft key, then the **INSERT** soft key and select **S3, S4** in the pop-up window.

Settings in the configuration editor	MP number
System CfgAxes axisList [0]: X1 [1]: Z1 [2]: S1 [3]: S2 [4]: S3 [5]: S4	100001

- ▶ Now enter the spindles S3 and S4 in the **spindleIndices** list.

Settings in the configuration editor	MP number
System CfgAxes spindleIndices [0]: S1 [1]: S2 [2]: S3 [3]: S4	100002

► Now add the C2 axis to the **progAxis** list of all programmable axes

Settings in the configuration editor	MP number
Channels ChannelSettings [Key name of the machining channel] CfgChannelAxes progAxis [0]: X1 [1]: Y1 [2]: Z1 [3]: C1 [4]: C2	200301

► Enter the C2 axis in the **caxisKeys** list to identify it as C axis for the control.

Settings in the configuration editor	MP number
Aggregates General CfgAggregateKeys caxisKeys [0]: C1 [1]: C2	600004

► For operation as C2 axis, now the **PS4\_C2** parameter set has to be assigned to the spindle S4.

Settings in the configuration editor	MP number
Axes PhysicalAxis S4 CfgAxis parList [0]: PS4_0 [1]: PS4_C2	300107



## Kinematic models for rear-side machining

- ▶ The following kinematics are preconfigured on the MANUALplus 620 for rear-side machining with opposing spindle and mirroring of the Z axis.
  - K41\_CH1\_S42\_C2
  - K42\_CH1\_S42
  - K43\_CH1\_S4\_C2
  - K44\_CH1\_S4
- ▶ For machining with the opposing spindle C2 in C-axis operation without mirroring of the Z axis, the following kinematics are preconfigured on the MANUALplus 620:
  - K10\_CH1\_S12\_C2
  - K11\_CH1\_S1\_C2

Settings in the configuration editor	MP number
Channels Kinematics CfgKinComposModel <b>K41_CH1_S42_C2</b> <b>K42_CH1_S42</b> <b>K43_CH1_S4_C2</b> <b>K44_CH1_S4</b> <b>K10_CH1_S12_C2</b> <b>K11_CH1_S1_C2</b>	202900

- ▶ For display- and cycle support of rear-side machining, the kinematics and transformations must be specified in **CfgRearSideKinem** and **CfgRearSideTrafo**. This is done automatically during the installation of **RsmAddOn.zip** or **RsmAddOnFull.zip**. Subsequent changes to the configuration only have to be made as indicated below if such changes become necessary in special cases. The following settings are already configured:
  - ▶ The **kinList** located in **CfgRearSideKinem** contains the key names of all kinematics for rear-side machining.

Settings in the configuration editor	MP number
Aggregates RearSideMachining CfgRearSideKinem [Key name of the machining channel] kinList <b>[0]: K41_CH1_S42_C2</b> <b>[1]: K42_CH1_S42</b> <b>[2]: K43_CH1_S4_C2</b> <b>[3]: K44_CH1_S4</b>	605701



- ▶ The **specWpSpindleList** located in **CfgRearSideKinem** contains the key names of all workpiece spindles with special transformations for rear-side machining.

Settings in the configuration editor	MP number
Aggregates RearSideMachining CfgRearSideKinem [Key name of the machining channel] specWpSpindleList <b>[0]: S4</b>	605702

- ▶ The **mirAxis** list located in **CfgRearSideTrafo** contains the key names of all mirrored axes for rear-side machining. The transformations for mirroring the axes entered here are listed in **trafoMirAxis**. The transformation is assigned to the axis through the list index. The transformation for mirroring the Z1 axis is named **Trans\_A180** and is performed counterclockwise so that the direction of the X axis and Y axis is maintained and only the Z1 axis is rotated by 180°. The transformation for tool length mirroring in the Z direction with the lists **toolLengthDir** and **trafoMirToolLength** is currently not yet available.

Settings in the configuration editor	MP number
Aggregates RearSideMachining CfgRearSideTrafo [Key name of the workpiece spindle for RSM]	605804
mirAxis <b>[0]: Z1</b>	605801
trafoMirAxis <b>[0]: Trans_A180</b>	605805
toolLengthDir <b>[0]: ...</b>	605802
trafoMirToolLength <b>[0]: ...</b>	



- ▶ The **zeroPointOffsAxis** list located in **CfgRearSideTrafo** contains the key names of the axes with datum shift. The transformations for the datum shift of the axes entered here are listed in the **zeroPointOffset** list. The transformation for the datum shift is assigned to the axis through the list index. The transformation for the datum shift of the Z1 axis is named **Trans\_Z1** and is contained in the **zeroPointOffset** list.

Settings in the configuration editor	MP number
Aggregates	
RearSideMachining	
CfgRearSideTrafo	
[Key name of the workpiece spindle for RSM]	605806
zeroPointOffsAxis	
[0]: Z1	605803
zeroPointOffset	
[0]: Trans_Z1	

- ▶ The kinematics group for rear-side machining with the opposing spindle S4 is activated with the G function **G30 Q4**. When the program is canceled or finished, the currently active kinematics for rear-side-machining remains active at first and is only deactivated when a new program is selected in Program Run or when the control is restarted.



## Expanding the dashboard display for rear-side machining

- ▶ To be able to display the position of the opposing spindle C2 in the dashboard during C-axis operation, copy the dashboard element **DB\_C1** located in **CfgDashboardElemnt** and rename it to **DB\_C2**.

Settings in the configuration editor	MP number
DisplaySettings	
CfgDashboardElemnt	
DB_C1	113100
<b>dashboardpicType: ActualCAxisValue</b>	113101
<b>attribut: 0</b>	113102
<b>entityList: C1</b>	113103
DB_C2	...
<b>dashboardpicType: ActualCAxisValue</b>	
<b>attribut: 0</b>	
<b>entityList: C2</b>	

- ▶ Then enter the dashboard elements **DB\_S4** and **DB\_C2** for displaying the position of the opposing spindle in the **elementList** of a dashboard display (e.g. DB\_DEFAULT). The **DB\_CH1\_RSM** dashboard element is intended for displaying the status of rear-side machining and the active datum shift of the configured mirrored axis.

Settings in the configuration editor	MP number
DisplaySettings	
CfgDashboard	
DB_DEFAULT	113200
<b>elementList</b>	113201

- ▶ Set the **MP\_plcSpindleSelect** parameter in **CfgGlbDispSettings** entity to **TRUE** to define the spindle (e.g. main spindle, opposing spindle, C1/C2 axis or driven tool) to be assigned the TSF dialog.

Settings in the configuration editor	MP number
System	
DisplaySettings	
CfgGlbDispSettings	
<b>plcSpindleSelect</b>	604801

### **MP\_kinList**

List of the key names of all kinematics for rear-side machining  
Available from NCK software version: 597 110-05.

Format: Array [0...100]

Input: Enter the key names of all kinematics for rear-side machining in this list.

Default: No value, parameter optional

Access: LEVEL1

Reaction: RUN

### **MP\_specWpSpindleList**

List of the key names of all workpiece spindles for rear-side machining

Available from NCK software version: 597 110-05.

Format: Array [0...100]

Input: Enter the key names of all workpiece spindles with special transformations for rear-side machining in this list.

Default: No value, parameter optional

Access: LEVEL1

Reaction: RUN

### **MP\_mirAxis**

List with the key names of the mirrored axes

Available from NCK software version: 597 110-05.

Format: Array [0...100]

Input: For the axes entered here, enter the transformations for mirroring in **MP\_trafoMirAxis**. The transformation is assigned to the axis through the list index.

Default: No value, parameter optional

Access: LEVEL1

Reaction: RUN

### **MP\_trafoMirAxis**

List of the key names of the transformations for axis mirroring

Available from NCK software version: 597 110-05.

Format: Array [0...100]

Input: For the axes located in **MP\_mirAxis**, enter here the transformations for mirroring the axes. The transformation is assigned to the axis through the list index.

Default: No value, parameter optional

Access: LEVEL1

Reaction: RUN

### **MP\_toolLengthDir**

List with the axis directions of the mirrored tool lengths

Available from NCK software version: 597 110-05.

Format: Array [0...100]

Input: Enter the transformations for mirroring the tool lengths in **MP\_trafoMirToolLength**. The transformation is assigned to the direction of the tool length through the list index.

Default: No value, parameter optional

Access: LEVEL1

Reaction: RUN



### **MP\_trafoMirToolLength**

Transformation for mirroring the tool length  
Available from NCK software version: 597 110-05.

Format: Array [0...100]

Input: For the directions located in **MP\_toolLengthDir** , enter here the transformations for mirroring the tool lengths. The transformation is assigned to the direction of the mirrored tool length through the list index.

Default: No value, parameter optional

Access: LEVEL1

Reaction: RUN

### **MP\_zeroPointOffsAxis**

List with the key names of the axes with datum shift  
Available from NCK software version: 597 110-05.

Format: Array [0...100]

Input: For the axes entered in this list, enter the transformations for the datum shift in "**MP\_zeroPointOffset** ". The transformation for the datum shift is assigned to the axis through the list index.

Default: No value, parameter optional

Access: LEVEL1

Reaction: RUN

### **MP\_zeroPointOffset**

List of the datum shifts of the axes  
Available from NCK software version: 597 110-05.

Format: Array [0...100]

Input: For the axes located in **MP\_zeroPointOffsAxis** , enter the transformations for the datum shift in this list. The transformation for the datum shift (zero-point offset) is assigned to the axis through the list index.

Default: No value, parameter optional

Access: LEVEL1

Reaction: RUN

### 7.12.10 Traversing to a fixed stop (G916) and sleeve monitoring (G930)


Settings in the configuration editor	MP number
Axes ParameterSets [Key name of the parameter set] CfgDeadStop <b>deadStopLag</b> <b>forthTorqueFactor</b> <b>minTorque</b> <b>maxTorque</b> <b>torqueTolerance</b>	   403001 403003 403004 403005 403006

The "traverse to a fixed stop" function (G916) is now available for transferring a workpiece from the main spindle to the traversable opposing spindle. To do this, the control moves up to the fixed stop and stops as soon as the servo lag limit parameterized in **MP\_deadStopLag** has been reached. The contact force at the stop position can be programmed. Then the control deletes the remaining traverse path, saves the stop position and retracts the slide by the programmed return path and the servo lag.

This function can also be used for sleeve monitoring (G930), where a programmable tailstock or the opposing spindle can be pressed with a defined retention force against the workpiece in the main spindle. Sleeve monitoring can be activated for only one axis per NC channel.


#### Traversing to a fixed stop G916

If "traversing to a fixed stop G916" is programmed for an assigned axis, the following parameters are relevant:



- H: Contact force in daNewtons (1 daNewton = 10 newtons)
- D: Axis number (X=1, Y=2, Z=3, U=4, V=5, W=6, A=7, B=8, C=9)
- K: Incremental distance
- R: Return path
- V: Type (variant) of departure
  - V=0: Stay at fixed stop
  - V=1: Return to start position
  - V=2: Retract by return path R
- O: Error evaluation
  - O=0: Error evaluation in expert program
  - O=1: The control issues an error message

The sequence of the "traversing to a fixed stop G916" function is as follows:



- 1: Dead stop is reached
- 2: The following error (servo lag) limit is reached. The IPO reports the actual position.
- 3: The "return path" parameter is set by the IPO as pseudo following error
- 4: The return path (pseudo following error) is traversed

Set the following-error limit in **MP\_deadStopLag**.

### **MP\_deadStopLag**

Max. permissible following error (servo lag)  
Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0.000 000 000 to 999 999 999 [mm]

This following-error limit is effective with the "traverse to fixed stop" command at constant velocity. During the acceleration phase the value set in the **MP\_servoLagMax2** parameter is also effective in this operating mode.

Default: 0.01 [mm]


Access: LEVEL3

Reaction: RUN

## Sleeve monitoring G930

With the G930 function you can activate sleeve monitoring for one axis per NC channel. It monitors the maximum contact force for one axis. G930 moves the defined axis by the programmed distance until the defined contact force has been reached.

The parameter value from **MP\_forthTorqueFactor**, in which you have to configure the mechanical influences (screw pitch, distance from the center, lever arms etc.), is required to convert the programmed contact force to the torque-producing current  $I_q$ . The factor from **MP\_forthTorqueFactor** can be determined from the mechanical machine components by means of the following drawing.



In the following, the motor torque  $D_M$  is to be determined depending on the contact force  $F_{rst}$  of the tailstock.

Torque of the motor gear wheel:

$$D_M = F_M \cdot r_M$$

Therefore:

$$F_M = \frac{D_M}{r_M}$$

Torque of the drive gear wheel depending on the motor torque:

$$D_A = F_M \cdot r_A$$

Therefore:

$$D_A = \frac{r_A}{r_M} \cdot D_M$$

The work done by the motor force  $F_M$  within one revolution of the drive gear wheel is equal to the work done by the contact force  $F_{rst}$  of the tailstock on the path  $\Delta s$  (not considering friction losses in the ball screw).

$$F_M \cdot 2\pi \cdot r_A = F_{rst} \cdot \Delta s$$

Therefore:

$$2\pi \cdot D_A = F_{rst} \cdot \Delta s$$

This equation results in the motor torque  $D_M$ , depending on the contact force  $F_{rst}$  of the tailstock:

$$2\pi \cdot D_M \cdot \frac{r_A}{r_M} = F_{rst} \cdot \Delta s$$

Therefore:

$$D_M = \frac{1}{2\pi} \cdot \frac{r_M}{r_A} \cdot \Delta s \cdot F_{rst}$$

The factor  $\frac{1}{2\pi} \cdot \frac{r_M}{r_A} \cdot \Delta s$  must be entered in **MP\_forthTorqueFactor**.

$$D_M = \text{forthTorqueFactor} \cdot F_{rst}$$

Based on the motor torque  $D_M$  calculated as described, the torque-producing current  $I_q$  as a limit value is obtained using the data from the motor table.

■ Asynchronous motor (static torque):

$$I_q = \frac{D_M \cdot nn \cdot 2\pi \cdot \sqrt{I_N^2 - I_0^2}}{P_N \cdot 60}$$

$$I_q = \frac{\text{forthTorqueFactor} \cdot F_{rst} \cdot nn \cdot 2\pi \cdot \sqrt{I_N^2 - I_0^2}}{P_N \cdot 60}$$

- Synchronous motor:

$$I_q = \frac{D_M \cdot n_n \cdot 2\pi \cdot I_N \cdot \sqrt{2}}{P_N \cdot 60}$$

$$I_q = \frac{\text{forthTorqueFactor} \cdot F_{rst} \cdot n_n \cdot 2\pi \cdot I_N \cdot \sqrt{2}}{P_N \cdot 60}$$

You can get the missing values from the motor table:

- PN: Power rating of the motor
- nn: Rated speed of the motor
- IN: Rated current of the motor
- IO: No-load current of the motor

### **MP\_forthTorqueFactor**

Conversion factor of the programmed force to a torque  
Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0.100 000 000 to 1

Because a maximum force is programmed, but physically only the motor torque can be limited, the force must be converted with this factor to torque.

Default: 0.1

Access: LEVEL3

Reaction: RUN

When G930 "sleeve monitoring" is active, you can define a minimum/maximum limit for the torque-producing current  $I_q$  with **MP\_minTorque** and **MP\_maxTorque**. Enter the minimum or maximum value in percent of the value of the no-load current (synchronous motor) or of the rated current (asynchronous motor) from the motor table.

Depending on the value of the programmed contact force, the PLC specifies a value for the torque-producing current  $I_q$ . In **MP\_torqueTolerance**, you can program a tolerance window around this PLC-specified value for the current  $I_q$ . If the instantaneously consumed current of the axis reaches a value within this tolerance window, a status message to the PLC is generated.



### **MP\_minTorque**

Minimum limit of the torque-producing current I<sub>q</sub> with active sleeve monitoring

Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0.000 000 000 to 100 [%]

The no-load current (synchronous motor) or rated current (asynchronous motor) from the motor table cannot fall below this percentage, independently of the programmed contact force.

Default: 20 [%]

Access: LEVEL3

Reaction: RUN

### **MP\_maxTorque**

Maximum limit of the torque-producing current I<sub>q</sub> with active sleeve monitoring

Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0.000 000 000 to 100 [%]

This percentage of the no-load current (synchronous motor) or rated current (asynchronous motor) from the motor table cannot be exceeded, independently of the programmed contact force.

Default: 100 [%]

Access: LEVEL3

Reaction: RUN

### **MP\_torqueTolerance**

Tolerance window for status message

Available from NCK software version: 597 110-05.

Format: Numerical value

Input: 0.000 000 000 to 100 [%]

If the instantaneously consumed current of the axis is within this tolerance window around the PLC-specified current I<sub>q</sub>, a status message to the PLC is generated.

Default: 20 [%]

Access: LEVEL3

Reaction: RUN

### 7.12.11 Configuring the tool carrier

The following tool carriers are preconfigured in the basic configuration:

- **Multifix** quick change tool holder (factory default setting)
- **Tool turret**
- **Multifix and tool turret**

Depending on the three configurations named above, the following key names are assigned to the tool carriers in the control:

Machine configuration	Multifix	Tool turret	Multifix and tool turret
Multifix	TH1_MULTI	-	TH2_MULTI
Tool turret	-	TH1_REV	TH1_REV

Enter the settings described below in the configuration editor.

#### Multifix as tool carrier

The tool carrier TH1\_MULTI and the tool holder TH1\_TM001\_MULTI are already configured in the standard configuration.

- In the two entities listed below, enter the key name **TH1\_MULTI** for the multifix tool carrier.

Settings in the configuration editor	MP number
Channels ChannelSettings CH_NC1 CfgAssignAggregate assignToolHolder <b>[0]: TH1_MULTI</b>	203901
Aggregates General CfgAggregateKeys toolHolderKeys <b>[0]: TH1_MULTI</b>	600001



- ▶ Check the description, and add the dimensions of the tool carrier **TH1\_MULTI** (see "Tool carriers" on page 1396) and the tool holder **TH1\_TM001\_MULTI** (see "Tool holders (mounts)" on page 1400).

Settings in the configuration editor	MP number
Aggregates	
ToolHolder	
TH1_MULTI	
CfgTHDescription	600200
<b>ordinalNr</b>	600203
...	...
Aggregates	
ToolMount	
TH1_TM001_MULTI	
CfgToolMount	600400
<b>mountPosWAPP</b>	600401
...	...

### Tool turret

The tool carrier TH1\_REV is already configured in the standard configuration.

- ▶ In the two entities listed below, enter the key name **TH1\_REV** for the tool turret.

Settings in the configuration editor	MP number
Channels	
ChannelSettings	
CH_NC1	
CfgAssignAggregate	
assignToolHolder	
<b>[0]: TH1_REV</b>	203901
Aggregates	
General	
CfgAggregateKeys	
toolHolderKeys	
<b>[0]: TH1_REV</b>	600001



- ▶ Specify the number of swivel positions in **MP\_maxSwivelPosition**.
- ▶ Check the description, and add the dimensions of the tool carrier **TH1\_REV** (see "Tool carriers" on page 1396).

Settings in the configuration editor	MP number
Aggregates	
ToolHolder	
TH1_REV	
CfgTHDescription	600200
<b>ordinalNr</b>	600203
...	...
<b>maxSwivelPosition</b>	600208

In the standard configuration, three tool holders are configured for each of the 12 swivel pockets, meaning a total of 36 tool holders for the tool turret. A key name is assigned to each tool holder. The prepared key names include:

- the tool carrier (TH1)
  - the number of the tool holder (TMx01 to TMx12)
  - the number of the swivel pocket (TM0xx...TM2xx)
  - the type of the tool carrier (MULTI or REV).
- ▶ Delete the key names of unused tool holders.

Settings in the configuration editor	MP number
Aggregates	
ToolHolder	
TH1_REV	
CfgToolMountKeys	
toolMountKeys	
<b>[0]:TH1_TM001_REV</b>	600101
...	...
<b>[36]:TH1_TM212_REV</b>	

The standard configuration includes 36 tool holders on the tool turret (TH1\_TM001\_REV .. TH1\_TM212\_REV).



- ▶ Check the descriptions, and add the dimensions of the **tool holders** used on your machine (see "Tool holders (mounts)" on page 1400).

Settings in the configuration editor	MP number
Aggregates	
ToolMount	
TH1_TM001_REV	
CfgToolMount	600400
<b>mountPosWAPP</b>	600401
...	...
TH1_TM002_REV	
CfgToolMount	600400
<b>mountPosWAPP</b>	600401
...	...
...	...

### Multifix and tool turret

The tool carriers TH1\_REV and TH2\_MULTI are already configured in the standard configuration.

- ▶ In the two entities listed below, enter the key names **TH1\_REV** for the tool turret and **TH2\_MULTI** for the multifix tool carrier.

Settings in the configuration editor	MP number
Channels	
ChannelSettings	
CH_NC1	
CfgAssignAggregate	
assignToolHolder	203901
<b>[0]: TH1_REV</b>	
<b>[0]: TH2_MULTI</b>	
Aggregates	
General	
CfgAggregateKeys	
toolHolderKeys	600001
<b>[0]: TH1_REV</b>	
<b>[0]: TH2_MULTI</b>	



#### Note

For the turret-Multifix configuration it is assumed that the tool turret is in the positive quadrant as standard tool carrier.



- ▶ Specify the number of swivel pockets for the tool turret in **MP\_maxSwivelPosition**.
- ▶ Check the description, and add the dimensions of the tool carriers **TH1\_REV** and **TH2\_MULTI** (see "Tool carriers" on page 1396).

Settings in the configuration editor	MP number
Aggregates	
ToolHolder	
TH1_REV	
CfgTHDescription	600200
<b>ordinalNr</b>	600203
...	...
<b>maxSwivelPosition</b>	600208
...	
TH2_MULTI	
CfgTHDescription	600200
<b>ordinalNr</b>	600203
...	...

The standard configuration includes 36 tool holders on the tool turret (TH1\_TM001\_REV .. TH1\_TM212\_REV). The key name TH2\_TM001\_MULTI is entered for the tool holder of the Multifix tool carrier.

- ▶ Delete the key names of unused tool holders of the tool turret.

Settings in the configuration editor	MP number
Aggregates	
ToolHolder	
TH1_REV	
CfgToolMountKeys	
toolMountKeys	
<b>[0]:TH1_TM001_REV</b>	600101
...	...
<b>[36]:TH1_TM212_REV</b>	
TH2_MULTI	
CfgToolMountKeys	
toolMountKeys	
<b>[0]:TH2_TM001_MULTI</b>	600101



The standard configuration includes 36 tool holders on the tool turret (TH1\_TM001\_REV .. TH1\_TM212\_REV) as well as the tool holder of the Multifix tool carrier (TH2\_TM001\_MULTI).

- Check the descriptions, and add the dimensions of the **tool holders** used on your machine of the tool turret and the Multifix tool carrier (see "Tool holders (mounts)" on page 1400).

Settings in the configuration editor	MP number
Aggregates	
ToolMount	
TH1_TM001_REV	
CfgToolMount	600400
<b>mountPosWAPP</b>	600401
...	...
TH1_TM002_REV	
CfgToolMount	600400
<b>mountPosWAPP</b>	600401
...	...
...	
TH2_TM001_MULTI	
CfgToolMount	600400
<b>mountPosWAPP</b>	600401
...	...

Mirroring of the X axis is then activated for the Multifix with the **KT\_MT\_S1\_MIRROR** and **KT\_TH1\_MIRROR** parameters. Additionally for C-axis operation, the C-axis position is rotated by 180° with parameter **MP\_mirroringAxes = X1** (rotation of the C axis around Z). (See "Working with two tool carriers" on page 1403.)

Settings in the configuration editor	MP number
Aggregates	
ToolMount	
TH2_TM001_MULTI	
CfgToolMount	
coorTrafo	600415
[0]: <b>KT_MT_S1_MIRROR</b>	
[1]: <b>KT_TH1_MIRROR</b>	
mirroringAxes	600416
[0]: <b>X1</b>	



## 7.12.12 Expert programs

HEIDENHAIN provides numerous subprograms that realize useful functions for the operator. These "expert programs" (\*.ncs) are used explicitly with M and G functions, or are internally called and performed with cycles. For example, the C axis can be switched on with the C-axis expert program via the M14 function, and switched off again via M15, without needing to make any changes to the control's configuration.

Expert programs (*.ncs)	Function
<b>_c1_ein.ncs</b>	Activate the C axis (M14)
<b>_c1_aus.ncs</b>	Deactivate the C axis (M15)
<b>_M417.ncs</b>	Deactivate protection zone (M417)
<b>_M418.ncs</b>	Activate protection zone (M418)
<b>_G85.ncs</b>	Undercut (G85)
<b>_G87G88.ncs</b>	Transition radius/chamfer (G87, G88)
<b>_G500.ncs</b>	Undercut type E according to EPL2/4 (G500)
<b>_G501.ncs..._G599.ncs</b>	Customer cycles
<b>_g798.ncs</b>	Helical slot milling (G798)
<b>_g799.ncs</b>	Thread milling with the C axis (G799)
<b>_G800.ncs</b>	Thread milling, lateral surface, with (G800)
<b>_G806.ncs</b>	Thread milling, front face, with Y axis (G806)
<b>_CHAR.NCS</b>	Engraving cycle: XC plane, front face (G801) ZC plane, lateral surface (G802) XY plane, front face, Y axis (G803) YZ plane, lateral surface, Y axis (G804)
<b>_Measure.ncs</b>	Touch probe cycle for tool measurement
<b>_tcall1.ncs</b>	Positions the Y axis to Y=0 after every tool change if <b>MP_doProgAfterTCall = TRUE</b> .
<b>_tcall2.ncs</b>	Identical to _tcall1.ncs, for a second slide.





The expert programs are based on the NC syntax, and can be edited with the help of a text editor or the smart.Turn editor. Since the programs are programmed using variables, they are written as generally as possible. For example, offsets are assigned to be able to also use the M14 function for configured subspindles. The main spindle is addressed with M014, the first subspindle with M114, the second subspindle with M214, etc.

For more information about the expert programs, refer to your control's User's Manual.

If a software update is performed on the **SYS:** drive of the control, the current C-axis programs are copied to the **PLC:\Update\nc\_prog\ncps** directory. The new files all contain the current version of the default settings managed by HEIDENHAIN. For more information about software updates, see "NC software exchange on the MANUALplus 620" on page 137.

The control searches for active expert programs first in TNC:\nc\_prog\ncps and then, which is new, also in **PLC:\nc\_prog\ncps**.



#### Note

HEIDENHAIN recommends removing all expert programs from TNC:\nc\_prog\ncps and saving them in the protected zone in **PLC:\nc\_prog\ncps**.

### 7.12.13 Manual programs


If the menu guidance of the user interface (3x3 menu) is expanded with **MP\_extManualMode** (see "Expanded menu structure" on page 1228), then in the **Machine** operating mode, under the **Manual program** menu item of the user interface, previously defined NC subprograms can be shown in a clearly structured list view, from which they can be opened.

In the file **PLC:\resourceManualProgManualProg\_en.str** you associate the program names shown in the list of manual programs with the NC subprograms stored under **TNC:\nc\_prog\ncps**. Please note the following format for this:

"Sample program", "program name.nc"

In the file **ManualProg\_de.str** you first enter any name for the program (this is how the NC subprogram will appear in the list of manual programs).

Separated by a comma, you then enter in quotation marks the actual program name including the file extension .nc, as it is stored in the NCPS program folder.







# 8 PLC Programming

## 8.1 PLC Functions

The integrated PLC of the control contains its own text editor for creating the statement list for the PLC program. You enter PLC commands and comments using an optional USB keyboard. An even simpler way is to create your PLC program on a PC with the PLC development software **PLCdesignNT**. If you want to use **PLCdesignNT**, please contact HEIDENHAIN.

The control supports you with the COMPILE function, which compiles the PLC program and checks it for logical errors, and the API DATA, TABLE, TRACE and WATCH LIST functions, with which you can check the status of the PLC operands.

The control starts the PLC cycles at the clock rate of the PLC cycle time. In **MP\_ipoCycle**, you set the PLC cycle time to a multiple of the IPO clock. Use Module 9196 to determine the PLC cycle time setting.

Settings in the configuration editor	MP number
System	
CfgCycleTimes	
<b>ipoCycle</b>	100301
<b>plcCount</b>	100302

### MP\_ipoCycle

Cycle time of position controller (interpolation clock pulse)  
Format: Selection menu  
Selection: 3 ms  
At present, only a cycle time of 3 ms for the position controller is supported. Therefore no other values can be selected.  
Default: 3 ms  
Access: LEVEL3  
Reaction: RESET

### MP\_plcCount

PLC cycle time (Look Ahead cycle time)  
Format: Numerical value  
Input: 3 to 10 [ · **MP\_ipoCycle**]  
The PLC and the Look Ahead run at a clock rate that is a multiple of the IPO clock (interpolation clock). The Look Ahead function is triggered exactly two IPO clock pulses after the PLC.  
Default: 7  
Access: LEVEL3  
Reaction: RESET

### Module 9196 Find the PLC cycle time

The PLC cycle time is determined in  $\mu$ s.

Call:  
CM 9196  
PL D <PLC cycle time in [ $\mu$ s]>

### 8.1.1 The API 3.0 symbolic memory interface

The PLC programmer needs an interface for coupling his program to the functions and states of the NC part of the control. Often such an interface is known as API (**Application Programming Interface**). Three methods are used for HEIDENHAIN PLC programming:

- Integrated system subprograms (modules) are available: **PLC modules**
- On HEIDENHAIN NCK-based controls, a shared, structured data area is available, which the PLC programmer accesses with symbolic structure operands: **The API 3.0 symbolic memory interface**.  
This Technical Manual deals only with the symbolic memory interface.

If you are using the API 3.0 symbolic memory interface, symbolic operands are available, see "Overview of the PLC Operands" on page 604

#### Use

The following structures exist:

Group	Type of structure	Structure definitions
General data	ApiGen	PlcApiGeneral
Operating modes	ApiOmg	PlcApiOmg[OMG_COUNT]
Processing channels	ApiChn	PlcApiChannel[CHANNEL_COUNT]
Axes	ApiAxis	PlcApiAxis[AXIS_COUNT]
Spindles	ApiSpin	PlcApiSpindle[SPINDLE_COUNT]



Individual structure elements are accessed by indexes (except for the "General data" group).

Example of a PLC command line:

```
L PlcApiAxis[x].NN_AxInMotion
IFT
...
ENDI
```



#### Note

Further information about working with indexed structures is provided in the online help of PLCdesignNT.

### ApiMarker.def definition file

HEIDENHAIN makes the **ApiMarker.def** file available to the PLC developer. As soon as the file is included in the PLC program via the **INCLUDE** command, the control uses the symbolic API 3.0. Collected in structures, the file contains all symbolic PLC operands.

#### Example:

```
* =====
#TYPEDEF PlcApiAxis
* =====
internal                D
NN_AxLogNumber          D    * logical axis number
NN_AxDriveReady         M    * drive is ready to work
PP_AxDriveOnRequest     M    * drive on request
NN_AxDriveOn            M    * drive is on
.
.
.
```



#### Note

The **ApiMarker.def** file is located on the PLC partition of the control.

HEIDENHAIN releases a revised version of the **ApiMarker.def** file at irregular intervals. The most recent version of the **ApiMarker.def** file is automatically transferred to the control when the NC software is updated. The old **ApiMarker.def** file in the main directory of the PLC program will not be overwritten in order to ensure executability of the PLC program.

After an update of the NC software, you will find the current version of the file in the following directory of the control:


**PLC:\proto\plc\ApiMarker.def**

You can also find the file on the HESIS Web Including FileBase on the Internet at <http://filebase.heidenhain.de>.



## Name convention for symbolic PLC operands

The first two letters at the beginning of the symbolic operands give information about the setting and resetting behavior:



Operand	Data direction	Setting or resetting behavior
NN_xxx	NC → PLC	Set by NC, reset by NC
NP_xxx	NC → PLC	Set by NC, reset by PLC
PP_xxx	PLC → NC	Set by PLC, reset by PLC
PN_xxx	PLC → NC	Set by PLC, reset by NC

For a list and description of all PLC operands see "Overview of the PLC Operands" on page 604.

## Programming with the symbolic API

In the definition file **ApiMarker.def**, associated symbolic PLC operands are structured into five groups with the **#TYPEDEF** command:

- PlcApiGeneral
- PlcApiOmg
- PlcApiChannel
- PlcApiAxis
- PlcApiSpindle

The **#TYPE** command assigns an abbreviated structure symbol to each of the five operand groups:


- PlcApiGeneral     =     **ApiGen**
- PlcApiOmg         =     **ApiOmg**
- PlcApiChannel     =     **ApiChn**
- PlcApiAxis        =     **ApiAxis**
- PlcApiSpindle     =     **ApiSpin**

You address individual elements of these five structures by entering the structure symbol, followed by a period as a separator, and then the name of the operand, e.g. **ApiSpin.NN\_SpiOverrideInput**.

The structures **ApiOMG**, **ApiChn** and **ApiAxis** are accessed by indexes, e.g. **PlcApiAxis[x].NN\_AxInMotion**.

Example of program:





**Note**

More information about programming with structures is provided in the online help of PLCdesignNT.



## 8.1.2 HEIDENHAIN PLC basic program

A PLC basic program for the control is available from HEIDENHAIN. This comprehensive PLC program serves as a basis for adapting the control to the requirements of the respective machine.

You need the **PLCdesignNT** software to adapt the PLC basic program.

Registered customers can download the current version of the PLC basic program from the "HESIS-Web Including Filebase" on the Internet (<http://hesis.heidenhain.de>).

The PLC basic program provides the following functions:

- Controlling all axes
- Positioning the axes after reference run
- Clamped axes
- Homing the axes, reference end positions
- Compensating the axis temperature
- Feed rate control
- Controlling and orienting the spindle
- Spindle brake
- Gear switching via M functions
- C axis via main drive
- C axis with separate drive
- Positioning of the tool turret with three-phase motor
- Servo turret (one drive for the turret wheel and the driven tool)
- Tool change for multifix tools
- PLC soft keys
- Displaying and managing PLC error messages
- Positioning the PLC axis (example)
- Hydraulic control
- Hydraulic chuck
- Sleeve 2, pressure
- Coupled tailstock
- Steady rest 2, pressure
- Turret control via Sauter switch module
- Electronic handwheels (with C or Y axis assignment)
- Controlling the coolant system
- Handling M functions
- Lubrication
- Chip conveyor
- Touch probes
- Controlling the doors



### Note

If you have any questions regarding the PLC basic program, please contact the HEIDENHAIN PLC hotline.


Telephone: +49 / 8669 / 31-3102

E-mail: [service.plc@heidenhain.de](mailto:service.plc@heidenhain.de)



### 8.1.3 Selecting the PLC programming mode of operation

Start the **PLC programming** mode of operation:


- ▶ Select the **Organization** mode
- ▶ Press the  soft key.
- ▶ Enter the code number 807667. Confirm with the **ENT** key or the **OK** button or soft key  
If you have already entered the code number, press the **PLC EDIT** soft key

Exit PLC mode:

- ▶ Press the **END** soft key or the **END** key.

### 8.1.4 PLC main menu

After you have entered the code number (or pressed the **PLC EDIT** soft key), the control displays the PLC main menu:



#### Processing time maximum:

Maximum run time of the PLC program.

The run time of the PLC program is monitored. If the PLC cycle has not been completed two interpolator clock pulses before the PLC cycle time elapses, the control issues the error message **PLC: time out**.

#### Processing time current:

The time taken for the latest PLC scan in %.

The PLC processing time (time for a PLC cycle) is given as a percentage of the maximum time: 100% is the equivalent of a run time of 1 ms at a cycle time of 21 ms. Use the following formula to calculate the run time  $t_{run}$  [ms] as a function of the PLC cycle time  $t_{PLC}$  [ms] and the processing time  $t_{calc.}$  [%]:

$$t_{run} = \frac{t_{PLC} \cdot t_{calc.}}{21}$$

**Code length:**

Length of the compiled sequential program in bytes.

**Running PGM:**

Name of the last compiled PLC program (program in process memory)

During switch-on, the control automatically compiles the program that was selected in process memory before switch-off.

The files only become active after they have been compiled.

**Trace PGM:**









Name of the last program or file opened with the **TRACE** function

**Editor PGM:**

Name of the program or file in the editor's main memory

**PLC functions of the main menu**

From the PLC main menu you can use soft keys to access the following PLC functions:









Soft key	Function	Page
	Edit the file located in RAM memory	1498
	Compile the PLC program	1497
	Display the states of the symbolic operands (new programming interface)	1490
	Display the states of the selected operands in a table	1491
	Display the logical states of the PLC operands (M/I/O/T/C/B/W/D)	1493
	Display the TRACE function	1495
	Call the diagnostic functions	1501
	Exit the <b>PLC programming</b> mode	–



## 8.1.5 File management


You call the file management by pressing the COMPILE PLC PGM soft key in the PLC programming mode of operation

File types displayed by the control when you press the **SELECT TYPE** soft key:

Soft key	Function
	Show only PLC programs (*.PLC)
	Show only PLC source files (*.SRC)
	Show only PLC definition files (*.DEF)
	Show only PLC machine configuration files (*.MCG)
	Show only PLC error tables (*.PET)
	Set a default display filter with the PLC file extensions *.PLC, *.SRC, *.DEF and *.PET.
	Specify a user-defined display filter. Enter "**.*" to display all files. If you enter more than one file extension, separate them with a semicolon.
	Return to the previous menu

## 8.1.6 The API DATA function

The API DATA function enables you to display the states or contents of the symbolic API markers and API double words on the control.



Soft keys for the API DATA function

Soft key	Function
	Display the contents of general API markers
	Display the contents of the API markers for machining groups
	Display channel-specific API data
	Display axis-specific API data
	Display the API markers that apply to the spindle
	Show operand contents in hexadecimal or decimal notation
	Freeze the screen
	Return to the previous menu
















## 8.1.7 The WATCH LIST function

The WATCH LIST function enables you to create a table providing a dynamic overview of the states of the selected PLC operands.

Meaning of the columns in the WATCH LIST:

- MODULE: **<Global>** for global symbolic operands or path with the name of the \*.SRC file in which the operand is defined
- ADDR: Absolute address of the operand
- TYPE: Type (M for marker, B for byte, W for word, etc.) of the PLC operand
- VALUE: Contents of the operand
- COMMENT: Comment for the operand

Soft keys within the WATCH LIST function:

Soft key	Function
	Insert a new line above the current line
	Delete the current line
	Display a selection list with all symbolic operands used in the active PLC program
	Mark the operand selected for transfer to the WATCH LIST. The operand is marked with an asterisk "*."
	Unmark the selected operand
	Unmark all operands
	Load selected operands into the WATCH LIST
	Return to the previous menu
	Load or save the WATCH LIST
	Load the saved WATCH LIST selection from the memory card (*.WLT file)
	Save the active WATCH LIST to the memory card
	Return to the previous menu
	Show operand contents in hexadecimal or decimal notation
	Freeze the screen. Current changes are no longer displayed.
	Return to the PLC main menu

## Display of symbolic operands in the WATCH LIST

- ▶ Press the **WATCH LIST** soft key to call the menu of the WATCH LIST function.
- ▶ Press the **SYMBOL LIST** soft key to open a list box containing all global and local operands used in the PLC program.
- ▶ Use the arrow keys to move within the SYMBOL LIST. Press the right arrow key to open a tree structure. Press the left arrow key to close an open tree structure.
- ▶ Use the arrow keys to select the desired operand and press the **SELECT** soft key to transfer it.
- ▶ Press the **INSERT** soft key to insert the selected operand.



### Note

Operands can only be selected with the **SYMBOL LIST** soft key if you are working with the \*.SRC source files of the PLC program on the control. Otherwise the error message **Selection list is empty** appears.

## Display of operands in the WATCH LIST

- ▶ Press the **WATCH LIST** soft key to call the menu of the WATCH LIST function.
- ▶ Press the **INSERT LINE** soft key.
- ▶ The following dialog box appears:

Symbolischer Operandenname

Symbol

Module

Enter the symbolic operand name in the **Symbol** input box, or enter the module name in the **Module** input box. Press the GOTO key to view a history list of the operand and module names last entered.

- ▶ Confirm your entry with the OK soft key or button.

## Internal process of the WATCH LIST function

If you are working with the source files (\*.SRC), the control internally creates a complete symbol list from the \*.MAP file, identifying the structures and arrays. In another step, the control resolves the structure elements and array elements, removes the nesting levels and internally creates a new list file. The generated information is displayed in a tree structure (SYMBOL LIST function). When you select and then insert symbols the first time, the file PLC:TABLEXTMP.WLT is automatically created. This file is automatically saved when you exit the WATCH LIST function and loaded when you call the WATCH LIST again. You can save the active WATCH LIST under any desired name and then reload it. The control remembers the last active WATCH LIST and automatically loads it when you call the function again.





## 8.1.8 The TABLE function

From the PLC main menu, press the **TABLE** soft key to select the table of markers, inputs, outputs, counters, timers, bytes, words, double words, and strings. The states are displayed dynamically on the screen.

To select a certain operand:

- ▶ Use the arrow keys, or
- ▶ Press the GOTO key. A dialog box appears. Enter the number of the operand and confirm your entry with the **OK** soft key.










To set or reset markers, inputs, outputs, timers or counters:












- ▶ Press the **SET/RESET** soft key.

To change bytes, words, double words or strings:

- ▶ Use the arrow keys or the GOTO key to select the desired operand.
- ▶ Press the ENT key and enter the new value. Conclude your entry with the ENT key.

Soft keys within the TABLE function:

Soft key	Submenu	Function
	Select Markers/Inputs/Outputs/Timers/Counters for <b>TABLE</b> .	
		Show a list of the markers
		Show a list of the inputs
		Show a list of the outputs
		Show a list of the timers
		Show a list of the counters
		Set/reset the selected operand
		Freeze the screen. Current changes to PLC operands are no longer shown.
		Return to the PLC main menu

Soft key	Submenu	Function
	Select Bytes/Words/Double words/Strings for <b>TABLE</b>	
		Show a list of the bytes
		Show a list of the words
		Show a list of the double words
		Show a list of the strings
		Show operand contents in hexadecimal or decimal notation
		Freeze the screen. Current changes to PLC operands are no longer shown.
		Return to the PLC main menu
	Save states of selectable operand ranges in an ASCII file. Ranges of more than one operand can be saved, e.g. <b>M0..M100,W100..W118</b>	
	Load the states of saved operands from an ASCII file	
	Return to the PLC main menu	

## 8.1.9 The TRACE function

The TRACE function enables you to:

- Check the logical states of markers, inputs, outputs, timers, and counters
- Check the content of bytes, words and double words

From the PLC main menu, press the TRACE soft key to select the TRACE function. The control displays:














- The statement list (STL) of the selected PLC program
- For every program line, the content of the operand and the accumulator in HEX or decimal code (selectable by soft key)

The control identifies every cyclically executed command with an asterisk (\*). Use the arrow keys or the GOTO function to select the program section that the control should display on the screen. In addition, you can use the NAVIGATE soft key to call additional soft keys for navigating in the source text and a search function.

The PLC program to be displayed is selected with the **SELECT MODULE** soft key, and must be the currently active main program or a file integrated with USES.

Operand	Accu	Index	Actv.	Line	Command	Comment
0	0		*	301	O	ApiGen.NM_GenCycleAfterPlcStop
0	0		*	302	O	ApiGen.NM_GenCycleAfterReConfig
1	0		*	303	R	MG_Maschinenparameter_gelesen
				304	CMT	Init_nach_Reset
				305		
1	1		*	306	L	ApiGen.NM_GenMcInitialized
1	0		*	307	AN	MG_Maschinenparameter_gelesen
0	0		*	308	O	MG_Maschinenparameter_S_lesen
				309	CMT	MP_lesen
				310		
				311		
				312		#ifdef Simulation
0	1		*	313	LN	NP_MG_SPG_MSU_Simulation_inaktiv
				314	CMT	Simulation_Beginn
				315		#endif
				316		
				317		#if WZ_Magazin - &Asynchron
				318	ON	Status_Achse
				319		#endif
				320		






Soft keys within the TRACE function:

Soft key	Submenu	Function
		Open the submenu for navigating in the STL selected for the trace function
		Jump to the beginning of the STL
		Jump to the end of the STL
		Scroll back one page in the STL
		Scroll forward one page in the STL
		Find text in the STL
		Find the next hit
		Return to the previous menu
		Add the PLC operands of the currently marked line to the WATCH LIST
		Show operand or accumulator contents in hexadecimal or decimal notation
		Open the file manager. The PLC program to be run in "Trace" mode can be selected.
		Freeze the screen. Current changes to PLC operands are no longer shown.
		Return to the PLC main menu

### 8.1.10 The COMPILE function

Compiling a completed PLC program transfers it to the process memory where it can then become active. The name of the compiled program then appears in the line **Running PGM** in the main menu.

Soft keys within the COMPILE function:

Soft key	Function
	Compile the current PLC program, current PLC error table, and current soft-key project file ( <b>MP_mainPgm</b> , <b>MP_errorTable</b> and <b>MP_softkeyProject</b> entries in the <b>CfgPlcPath</b> machine parameter).
	Only compile the current PLC program (entry <b>CfgPlcPath =&gt; MP_mainPgm</b> )
	Only compile the current PLC error table (entry <b>CfgPlcPath =&gt; MP_errorTable</b> )
	Select and compile a PLC program
	Select and compile a PLC error table

To compile a PLC program:

- ▶ Press the **COMPILE PLC PGM** soft key for the control to switch to the program manager.
- ▶ Use the arrow keys to select the PLC program to be compiled.
- ▶ Press the **SELECT** soft key.



#### Note



The compilation of very extensive PLC programs may take some time. Compilation is completed when the PLC main menu appears on the screen again and values are displayed under **Processing time**. If errors occur during the compilation of the program, the control displays a corresponding message in the PLC main menu.

## 8.1.11 The EDIT function

Pressing the **EDIT** soft key or selecting an editable file in the program manager opens the editor. PLC source texts (\*.SRC, \*.PLC), PLC definition files (\*.DEF) and PLC error tables are editable files.

The feature content is like that of an ASCII editor. The cursor can be positioned in all directions and line breaks can be inserted. Tables are opened in a separate table editor.


The editor's display window takes up the entire screen and is divided into two sections only in case of an error. The upper part of the window is the workspace. In the lower third of the window, the PLC compiler displays status and error messages only in the event of an error.

If errors occurred during compilation of the PLC programs, you can use the soft keys  and  to jump between the individual errors in the editor window. Also, the errors are automatically marked with the cursor.



























### Note

The complete feature content of the editor only becomes available after you have connected an external USB keyboard.



Soft keys within the EDIT function:

Soft key	Submenu	Function
		Open the submenu for navigation in the editing window
		The cursor jumps to the beginning of the file in the active window
		The cursor jumps to the end of the file in the active window
		Scroll back one page in the open file
		Scroll forward one page in the open file
		Open the dialog box of the search function
		Return to the previous menu
		Open the submenu for selection of the COMPILE function
		Compile the current PLC program, current PLC error table, and current soft-key project file ( <b>MP_mainPgm</b> , <b>MP_errorTable</b> and <b>MP_softkeyProject</b> entries in the <b>CfgPlcPath</b> machine parameter).
		Only compile the current PLC program (entry <b>CfgPlcPath =&gt; MP_mainPgm</b> )
		Only compile the current PLC error table (entry <b>CfgPlcPath =&gt; MP_errorTable</b> )
		Select and compile a PLC program
		Select and compile a PLC error table
		Jump forward in the editing window to the next error
		Jump back in the editing window to the previous error

Soft key	Submenu	Function
		Open the status and error message window of the PLC compiler, even is there is no error pending
		The cursor jumps to the beginning of the file in the active window
		The cursor jumps to the end of the file in the active window
		Scroll back one page in the selected window
		Scroll forward one page in the selected window
		Open the file highlighted by the cursor (only displayed if the cursor is located in the lower window)
		Switch between the upper part (workspace) and the lower part of the window (status messages of the PLC compiler)
		Return to the previous menu
		Return to the PLC main menu










### 8.1.12 Diagnostic functions

The MANUALplus 620 features numerous diagnostic functions for finding errors.

To call the diagnostic functions:

- ▶ Select the **Organization** mode of operation.
- ▶ Enter the code number 95148.
- ▶ Press the **DIAGNOSIS** soft key

The following diagnostic functions are available:

Soft key	Soft key	Soft key	Function
			After pressing this soft key, you can test various HSCI and Profibus settings, provided that you are using one of the two bus systems.
			After pressing this soft key, you can test various Profibus settings, provided that you are using a Profibus system.
			After pressing this soft key, you can test various HSCI settings, provided that you are using an HSCI system.
			Various drive diagnosis functions can be selected after pressing this soft key. Before selecting the diagnostic function, under <b>Supply unit</b> you must select the power supply unit being used, so that the signals present are not interpreted as errors.
			The integrated oscilloscope is started.
			The following soft key appears only if the <b>Power Interrupted</b> message was not acknowledged, and if the code number 688379 or 807667 was entered.
			The integrated oscilloscope for commissioning the current controller is opened.
			The file TNC:\herosdiagnose.txt is created after pressing this soft key. HEIDENHAIN uses this file for diagnosis of the operating system.


## 8.1.13 Bus diagnosis

The control features functions for diagnosis of the HSCI or PROFIBUS system.

You can access the functions as follows:

- ▶ Switch to the **Organization** mode of operation.
- ▶ Enter the code number 95148.
- ▶ Press the DIAGNOSIS soft key
- ▶ Press the BUS DIAGNOSIS soft key.

Example screen:












In Diagnosis mode, the structure of the HSCI/PROFIBUS system as well as the details of the HSCI/PROFIBUS components can be displayed.

The **HSCI** and **PROFIBUS** tabs above the left window are only shown if both bus systems are connected to the control. In this case you can switch between the bus systems by pressing the HSCI and PROFIBUS soft keys.

The detected, actually connected hardware at the HSCI bus (actual configuration) is displayed. The control also knows from the IOC file the previously configured hardware configuration to be expected (nominal configuration). The HSCI bus diagnosis compares the actual configuration to the nominal configuration and reveals deviations. At HSCI bus positions where a deviation was found, the actually configured hardware (**IOC:**) is displayed behind the detected connected hardware (display, e.g. **/IOC: MB 620T**). This provides you with a direct comparison of the actual configuration and the nominal configuration in order to support you in finding errors. HSCI components that are missing from the actual configuration (e.g. due to an interruption in the HSCI bus) are identified by a corresponding symbol.

## Soft keys for HSCI/ PROFIBUS diagnostics

The following soft keys are available in the main menu for bus diagnosis:

Soft key	Submenu	Function
HSCI		Select the HSCI or PROFIBUS bus system
PROFIBUS		
		Open the HSCI/PROFIBUS tree
		Shrink the HSCI/PROFIBUS tree
		Move the separating line (enlarge/reduce the window size)
		
MORE FUNCTIONS		Opens the submenu with additional functions.
		Move the state window up or down
		
		Open/Close HSCI/PROFIBUS slaves
		
FIND		Find an HSCI/PROFIBUS component
		Return to the previous soft key row
END		Exit the BUS diagnostics

Navigation with the arrow keys of the operating panel:

- ↓, ↑ Select an HSCI/PROFIBUS component
- → (or + key) Open the HSCI/PROFIBUS component for the connected modules or terminals to appear
- ← (or – key) Close the HSCI/PROFIBUS component

## Screen contents

"HSCI/PROFIBUS" window (at left)

- Arrangement and designation of the HSCI/PROFIBUS components and terminals

- Status of the HSCI/PROFIBUS components and terminals:



OK



Error (further information in the text window)








Warning (further information in the text window)



Undefined state (further information in the text window)

"Attributes" window (at upper right)

Configuration parameters of the selected HSCI/PROFIBUS component (see table).

Field	Function	Formed from...
Designation and symbol of the HSCI/PROFIBUS component		
	 HSCI master	
	 PROFIBUS master	
	 Slave	
	 (Slave) modules, AS-i slave	
	 Terminal	
Name	Name of the slave, slave module or terminal	<ul style="list-style-type: none"> <li>■ "Name" entered for the slave/slave module</li> <li>■ "Symbolic name" entered for the terminal</li> </ul>

Field	Function	Formed from...
Comment	Name of the slave (for slaves and slave modules) or terminal description	<ul style="list-style-type: none"> <li>■ Master entries: <ul style="list-style-type: none"> <li>• "Configuration file"</li> </ul> </li> <li>■ Master/slave entries: <ul style="list-style-type: none"> <li>• "Name"</li> <li>• "Hardware ID"</li> <li>• "Hardware serial number"</li> <li>• "Firmware ID"</li> <li>• "Firmware timestamp"</li> <li>• "Configuration file"</li> </ul> </li> <li>■ Terminal entries: <ul style="list-style-type: none"> <li>• "Comment"</li> <li>• "Pin name"</li> <li>• "Plan page"</li> <li>• "Order number"</li> </ul> </li> </ul>
Option	Designation of the option	Slave / slave module entered in "block"
Bus address	HSCI/PROFIBUS address	Slave entered in "HSCI/PROFIBUS address"
Slot	Slot number of the slave module	
Terminal	Terminal number	Determined from the terminals entered in "I/O offset" and "I/O bit"
Operand	Operand designation	Terminal entered in "PLC operand address"
Order no.	Order number	"Order number" entered for the terminal
Plan page	Wiring diagram page	"Page" entered for the terminal
Pin name	Terminal name	"Pin name" entered for the terminal

**"State" window (at lower right)**

Current status of selected HSCI/PROFIBUS component.

- **Value:** Operand value of the terminal in decimal and hexadecimal code
- **Text:** Error texts that appear when an error occurs; otherwise, no display. The texts displayed are error-specific texts from the HDD/GSD file or the error information configured in IOconfig.
- Display of S status (31 bits) in HEX code. The meaning is displayed in abbreviated form below the S status.



Safe status bit	Signal	Meaning
10	-PF.PS.AC	Power supply of inverter too low (parameterized LIFT OFF function in some cases).
11	-PF.PS.DC	DC-link voltage $U_z$ too low (CC: SS1)
12	-PF.BOARD	Error in the supply voltage of the respective module (SS1F)
13	-N0	Internal safe status bit (CC: SS1)
14	-REQ.SS2	Alarm (SS2)
15	-	Reserved

The following additional status bits are available for an external PL:

Safe status bit	Signal	Meaning
16	-SPL.A.WD	SPL watchdog, channel A
17	-SPL.B.WD	Only in controls with functional safety (FS): SPL watchdog, channel B
18	PGOOD.NC	Voltage monitoring of NC reports a fault
19	PGOOD.PLC	Voltage monitoring of PLC reports an error
20	-INT	Internal interrupt
21..31	1	Reserved

The following additional status bits are available for an external MB machine operating panel:

Safe status bit	Signal	Meaning
16	-SMOP.A.WD	SMOP watchdog, channel A
17	-SMOP.B.WD	Only in controls with functional safety: SMOP watchdog, channel B
18	PGOOD.A	Voltage monitoring of channel A reports a fault
19	PGOOD.B	Voltage monitoring of channel B reports a fault
20	1	Reserved
21..31	1	Reserved





## 8.2 PLC Compiler

### 8.2.1 Configuration file for the PLC compiler

The configuration file for the PLC compiler (**\*.MCG**) contains configuration definitions that describe a specific machine configuration and can be used for conditional compiling.

By using keywords in the configuration file, you can define different settings, e.g. influence the memory allocation of the control, specify the structure of the symbolic memory interface, or modify the configuration data of the PLC run-time system.

In the **MP\_compCfgFile** machine parameter, you specify the path for the configuration file of the PLC compiler. For example:

**MP\_compCfgFile** = %PLC%\p1c\program\oem.mcg

See page 1545.

Enter certain keywords to perform changes. After the compilation of the PLC program, the NC detects the changed settings, and the control must be restarted.

You use the keyword **DEFINE** and the constants **GENERAL\_COUNT**, **OMG\_COUNT**, **CHANNEL\_COUNT**, **AXIS\_COUNT** and **SPINDLE\_COUNT** to specify the structure of the symbolic memory interface (see the table on the next page).

An NCK-based control currently supports up to 20 axes (**MAX\_AXIS** = 20). This value cannot be changed, and represents the upper limit for all configurable axes (including the manually operated axes as well as those that are only displayed).

The value of the **AXIS\_COUNT** constant defines the number of axes of the machine. NCK-based controls count spindles together with axes, therefore you must include the spindle(s) in the value for **AXIS\_COUNT**.

Also, under **SPINDLE\_COUNT** you indicate how many of the axes defined in **AXIS\_COUNT** are spindles.

Every control with NCK software also has the following internal constants with product-specific upper limits:

**MAX\_OMG\_PRODUCT**, **MAX\_CHANNEL\_PRODUCT**,  
**MAX\_SPINDLE\_PRODUCT** and **MAX\_AXIS\_PRODUCT**.

These product-specific limits are predefined and cannot be changed. If your settings in the configuration file exceed these values, then the product-specific upper limits automatically take effect.

The number of axes defined in **AXIS\_COUNT** must match the setting of the **MP\_axisList** parameter (System/CfgAxes) in the machine configuration.

Otherwise the control will issue an error message when compiling the PLC program.

If bits are transferred or returned, then bit 0 corresponds to the axis with index 0 from the list parameter CfgAxes\axisList (100001), bit 1 corresponds to the axis with index 2, etc.

If constants are transferred or returned for an axis or spindle, then the value of the constant corresponds to the index from CfgAxes/axisList (100001).

Spindles are handled like axes. The corresponding index from CfgAxes/axisList is returned. For example:

**CM 9159**

**PL W/D <Drive will be brought to a standstill in 200 ms>**  
**Bit 0: Axis with index 0 from CfgAxes/axisList**  
**Bit 1: Axis with index 1 from CfgAxes/axisList**  
 .  
 .  
 .

It usually makes sense to set the constants GENERAL\_COUNT, OMG\_COUNT, CHANNEL\_COUNT, AXIS\_COUNT and SPINDLE\_COUNT to the product-specific upper limits:

<b>End product</b>	<b>MAX_OMG_PRODUCT</b>	<b>MAX_CHANNEL_PRODUCT</b>	<b>MAX_SPINDLE_PRODUCT</b>	<b>MAX_AXIS_PRODUCT</b>
MANUALplus 620	2	2	6	10
Programming station	1	1	2	20



## Available keywords

Keyword	Description	Example	
<b>DEFINE</b>	Configuration definitions for controlling the conditional compilation, soft-key menu generation and cycle-project configuration  The NCK-based controls use the following configuration definitions to specify the structure of the API 3.0 symbolic programming interface:		
	GENERAL_COUNT	Number of structures for miscellaneous data (ApiGen)	DEFINE GENERAL_COUNT = 1
	OMG_COUNT	Number of operating mode groups (ApiOmg)	DEFINE OMG_COUNT = 1
	CHANNEL_COUNT	Number of machining channels (ApiChn)	DEFINE CHANNEL_COUNT = 1
	AXIS_COUNT	Number of axes (ApiAxis). Define the same number of axes in the System/CfgAxes/axisList machine parameter. Spindles are included in this count.	DEFINE AXIS_COUNT = 10
	SPINDLE_COUNT	Number of spindles included in the axes defined under AXIS_COUNT (ApiSpin)	DEFINE SPINDLE_COUNT = 2
<b>REBYTEMIN</b>	Start address of the bytes, words or double words whose data remains stored after a power interruption (remanence). Default value: 0	REBYTEMIN = 0	
<b>REBYTEMAX</b>	End address of the bytes, words or double words whose data remains stored after a power interruption (remanence). The range defined by REBYTEMIN and REBYTEMAX may not be larger than 1024 bytes. Default value: -1 = Deactivated	REBYTEMAX = 200	
<b>REMARKERMIN</b>	Start address of the markers whose data remains stored after a power interruption (remanence). Default value: 0	REMARKERMIN = 0	

<b>Keyword</b>	<b>Description</b>	<b>Example</b>	
<b>REMARKERMAX</b>	End address of the markers whose data remains stored after a power interruption (remanence). The range defined by REMMARKERMIN and REMMARKERMAX may not consist of more than 2048 markers. Default value: -1 = Deactivated	REMARKERMAX = 150	
<b>MARKERS</b>	A total of 100 000 bytes is available for all keywords, timers, counters and strings combined	Number of markers available. Default value: 10000	MARKERS = 15000
<b>BYTES</b>		Size in bytes for the byte/word/double word memory. Default value: 10000	BYTES = 20000
<b>INPUTS</b>		Number of input markers available. Default value: 384	INPUTS = 450
<b>OUTPUTS</b>		Number of output markers available. Default value: 192	OUTPUTS = 250
<b>INPUTBYTES</b>		Size in bytes for the byte/word/double word memory range used by the Profibus inputs. Default value: 1000	
<b>OUTPUTBYTES</b>		Size in bytes for the byte/word/double word memory range used by the Profibus outputs. Default value: 1000	



Along with the keywords there are also system parameters. System parameters are identified by a preceding and following \$ character. Depending on which options have been set, they are defined via the compiler and can be used for conditional compilation. For more information, please refer to the PLCdesignNT help.

Available system parameters:

<b>System parameters</b>	<b>Meaning</b>
For interrogation with #ifdef:	
<b>\$&lt;nc model&gt;\$</b>	Current control model, e.g. <b>#ifdef \$TNC620\$</b>
<b>\$&lt;nc variante&gt;\$</b>	Current NC ID number, e.g. <b>#ifdef \$340560_03\$</b>
<b>\$&lt;nc basisvar.&gt;\$</b>	Current NC basic ID number, e.g. <b>#ifdef \$340560\$</b>
For interrogation with #if:	
<b>\$&lt;VARIANT&gt;\$</b>	Current NC ID number as numerical value, e.g. <b>#if \$VARIANT\$ &gt;= 34056003</b>
<b>\$&lt;VARIANTBASE&gt;\$</b>	Current NC basic ID number as numerical value, e.g. <b>#if \$VARIANTBASE\$ = 340560</b>
<b>\$&lt;VARIANTINDEX&gt;\$</b>	Current NC ID number index as numerical value, e.g. <b>#if \$VARIANT\$ &gt;= 03</b>
<b>\$&lt;VERSIONBASE&gt;\$</b>	Current compiler basic version as numerical value
<b>\$&lt;VERSIONINDEX&gt;\$</b>	Current compiler index as numerical value

## 8.2.2 Conditional compilation

Depending on freely definable, symbolic OEM machine parameters, a PLC program can be conditionally compiled on the MANUALplus 620. This allows you to select and deselect machine options by entering the options in machine parameters, or to select specific operating states of the machine, for example. Therefore, only one PLC program is necessary for all variants of machine options.

Settings in the configuration editor	
System	
PLC	
CfgOemBool	<b>[Key name of arbitrary parameter]</b>
CfgOemInt	<b>[Key name of arbitrary parameter]</b>
CfgOemString	<b>[Key name of arbitrary parameter]</b>
CfgOemPosition	<b>[Key name of arbitrary parameter]</b>

For more information about the freely definable OEM machine parameters, see „Data transfer machine parameters => PLC" on page 1657.

You can give the machine operator access via user parameters to the machine parameters that you define yourself, see "User Parameters" on page 365.

- ▶ Enter the commands for the conditional compilation in the PLC program.
- ▶ Create a PLC configuration file (\*.MCG) with DEFINE instructions, which will partially be replaced by contents of the OEM machine parameters.
- ▶ In **MP\_compCfgFile**, enter the path for the PLC compiler configuration file.
- ▶ Restart the MANUALplus 620 or recompile the PLC program.



### Example:

Settings in the configuration editor	
System	
Paths	
CfgPlcPaths	
<b>compCfgFile:</b>	%OEM%\plc\oem.mcg
PLC	
CfgOemBool	
NP_MG_STAR_DELTA	
value	
<b>[0]:</b>	TRUE
CfgOemInt	
NP_DG_TOOLCHANGER	
value	
<b>[0]:</b>	3
NP_DG_SWIVEL_HEAD	
value	
<b>[0]:</b>	2

Entries in OEM.MCG:

```
DEFINE %CfgOemBool.NP_MG_STAR_DELTA.value.0%
DEFINE %CfgOemInt.NP_DG_TOOLCHANGER.value.0%
DEFINE %CfgOemInt.NP_DG_SWIVEL_HEAD.value.0%
```

Instructions for conditional compilation in the PLC program:

```
#if NP_MG_STAR_DELTA = 1
...
#endif

#if NP_DG_TOOLCHANGER = 3
...
#endif

#if NP_DG_SWIVEL_HEAD = 2
...
#endif
```

## 8.3 Configuring PLC Input/Output Systems

Settings in the configuration editor	MP number
System PLC CfgPlcPeriphery <b>iocProject</b> <b>iocOption</b>	   103402 103403

You can configure the PLC input/output systems with HSCI interface (PL 6xxx, UEC 11x, MB machine operating panel with connected HR handwheel) and the PROFIBUS components using the IOconfig PC software.

The components of an HSCI/PROFIBUS system are specified in a **project** with IOconfig and their arrangement is described. On the basis of this data, IOconfig generates the **IOC file** (\*.IOC), which contains all relevant configuration data.

Then you transfer the IOC file to the control. Enter the path/name of the project file in the **MP\_iocProject** parameter. With the next start-up, the IOC file is then read in and evaluated by the control.



### Note

All information required for using the IOconfig PC software and configuring HSCI and PROFIBUS components is contained in the IOconfig Technical Information, which is available for registered customers from the HEIDENHAIN FileBase on the Internet.

### MP\_iocProject

Configuration file for IOC hardware (HSCI and PROFIBUS components)  
Available from NCK software version: 597 110-03.

Format: String  
Input: Max. 260 characters  
Path and file name of the IOC project file, for example:  
**%0EM%\plc\ioc\project.ioc**

Default: –  
Access: LEVEL3  
Reaction: RESET





Hardware components that are not required for every machine but are principally intended as maximum scope of upgrading for a specific machine series are called Options.

With the IOconfig PC software, the desired components are configured as options and specially identified in the IOC file. With the **MP\_iocOption** machine parameter you specify which option(s) is/are active on the current machine:

### **MP\_iocOption**

	Option data for IOC hardware (HSCI, PROFIBUS) Available from NCK software version: 597 110-03.
Format:	Array [0...99]
Input:	Name(s) of IOC options – : By inserting "-" in front of the name of the option, it can be disabled.
Default:	No value, parameter optional
Access:	LEVEL3
Reaction:	RESET

## 8.4 Operands

### 8.4.1 Overview of operands

The symbolic PLC operands that are predefined by HEIDENHAIN for the API 3.0 symbolic programming interface are listed in Chapter 5 (see "Overview of the PLC Operands" on page 604).

Operand	Abbreviation	Address range
Marker	M (marker)	<p><b>M0 to M9999</b></p> <p><b>M0 to M999</b> are free; they are deleted only after entering the code number 531210, not during a reset (nonvolatile range); the range can be reduced in the *.CFG file of the PLC compiler.</p> <p><b>M1000 to M3999</b> are free; they are deleted during reset.</p> <p><b>M4000 to M5999</b> are reserved for the NC-PLC interface if you are using the old TNC-API. (M4800 to M4999 are deleted before the first run of the PLC program, e.g. after compilation or restarting).</p> <p>They are freely usable if you are using the new symbolic API.</p> <p><b>M6000 to M9999</b> are free; they are deleted during reset.</p>
Input	I (input)	<p><b>I0 to I999</b></p> <p>Maximum 8</p> <p>C input/output systems (PL 6xxx) are allowed in the HSCI system, and of these, one PL 62xx or one UEC 11x system PL.</p> <p>Inputs are assigned to symbolic operands using the PC software IOconfig.</p>
Output	O (output)	<p><b>O0 to O999</b></p> <p>A maximum of 8 external PLC input/output systems (PL 6xxx) are allowed in the HSCI system, and of these, one PL 62xx or 1 UEC 11x system PL.</p> <p>Outputs are assigned to symbolic operands using the PC software IOconfig.</p>
Counters	C (counter)	<p>Start counter: <b>C0 to C47</b></p> <p>Counter contents: <b>C48 to C95</b></p> <p>Counter pulse release: <b>C96 to C143</b></p>
Timer	T (timer)	<p>Timer start: <b>T0 to T47</b></p> <p>Timer is running: <b>T48 to T95 and T96 to T999</b></p>

Operand	Abbreviation	Address range
Byte	B (byte)	<b>B0 to B9999</b> (8 bits)
Word	W (word)	<p><b>B0 to B255</b> are free; depending on the definition in the *.CFG file of the PLC compiler, the defined range is deleted only after entering the code number 531210, not during reset (nonvolatile range). If no range is defined in the *.CFG file, B0 to B127 is the nonvolatile range.</p> <p><b>B256 to B2047</b> are reserved for the NC-PLC interface if you are using the old TNC-API. They are freely usable if you are using the new symbolic API.</p> <p><b>B2048 to B9999</b> are free; they are deleted during reset.</p>
Double word	D (double word)	
Constant	K	<b>-2 147 483 647 to +2 147 483 647</b>
String	S	<b>S0 to S99</b>



## Module 9405 Convert a symbolic operand into a numerical PLC operand

Module 9405 converts symbolic names of variables in character strings into the absolute addresses of the corresponding PLC operands. This module enables you to reduce the run time of your PLC program if you regularly read data from SQL tables.

The symbolic names must be contained within single quotes and follow a colon, e.g.

**: 'S\_StringVariable'.**

If this conversion already occurred once during the initialization of the PLC program, then the processing time is reduced for the subsequent module calls that replace the embedded variables with the momentary values. This affects modules 9440 and 9450, for example.

### Example:

Two symbolic operands are to be converted. The operand **MG\_W\_TOOLNR** has the absolute address **W1234** and the numerical value **5**.

The operand **MG\_W\_POCKET** has the absolute address **W3456** and the numerical value **19**.

Output string:

```
UPDATE TOOL_P SET T = : 'MG_W_TOOLNR' WHERE P = : 'MG_W_POCKET'
```

After execution of Module 9405:

```
UPDATE TOOL_P SET T = : 'W1234' WHERE P = : 'W3456'
```

After execution of Module 9450:

```
UPDATE TOOL_P SET T = 5 WHERE P = 19
```

Call:

PS B/W/D/K/S<String with symbolic name>

PS B/W/D/K/S<Target for string with resolved symbols>

CM 9405

PL B/W/D <Error number>

0: Module executed correctly

2: Parameter does not exist

3: Invalid address transferred

11: String could not be converted

12: String too long

15: Module was not called in a submit job

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Module executed successfully
	1	See above for errors



### 8.4.2 Operand addressing (byte, word, double word)

The memory for operands B (8 bits), W (16 bits), and D (32 bits) is only 8 bits wide. Since the operands can be 8, 16 or 32 bits wide, an overlap of the memory areas will occur, which you must take into account when addressing the memory.

Double word	Word	Byte	Memory	Word address	Double-word address		
D0	W0	B0	8 bits	High byte	Highest byte		
		B1	8 bits	Low byte			
	W2	B2	8 bits	High byte		Lowest byte	
		B3	8 bits	Low byte			
D4	W4	B4	8 bits	High byte	Highest byte		
		B5	8 bits	Low byte			
•	•	•	•	•			
•	•	•	•	•			
•	•	•	•	•			
D1020	W1020	B1020	8 bits	High byte		Highest byte	
		B1021	8 bits	Low byte			
	NN_GenApiModuleErrorCode (W1022)	B1022	8 bits	High byte			Lowest byte
		B1023	8 bits	Low byte			

For byte addressing, every address is accessible; for word addressing, every second address; and for double word addressing, every fourth from 0 to 4092. The address parameter indicates the high byte of the word address (W) and the highest byte of the double-word address (D).

Markers, timers and counters are addressed with the corresponding code letters M, T or C followed by the operand number (e.g. M500, T7, C18).

### 8.4.3 Timers and counters

Settings in the configuration editor	MP number
System	
PLC	
CfgPlcTimer	
[Key name of the timer]	
<b>run</b>	103503
<b>start</b>	103504
<b>gate</b>	103505
<b>unit</b>	103501
<b>value</b>	103502

#### Timers

The PLC has 999 timers, which you control through special markers with the symbol **T**.

T0 to T47 are reserved as start markers for the timers, T48 to T999 are reserved as process markers.

The key name of the timer is freely selectable in the machine configuration. The process marker (e.g. T48) is defined with the optional machine parameter **MP\_run**. If no value is entered in **MP\_run**, the control uses the key name of the timer as process marker.

You must define the run times of the timers in machine parameter **MP\_value**. As the time unit, under **MP\_unit** you can choose between seconds and PLC cycles.

You start the first 48 timers by setting one of the timers with the process markers T0 to T47 for at most one PLC scan (otherwise the control restarts the timer with the negative edge for each additional scan). The control reserves the timer with the duration defined in machine parameter **MP\_value** and sets the process marker until the defined duration has expired. A change of the default value for a PLC timer only becomes effective after a PLC program restart.

The optional machine parameters **MP\_start** and **MP\_gate** are not evaluated by the control. The PLCdesignNT development environment uses them for the automatic generation of PLC definition files.

You can also set and start timers T0 to T47 with Module 9006 (see "Module 9006: Set and start PLC timer" on page 1530).

Timers T96 to T999 can only be started through Module 9006.


Cyclic timers (> T96) can be defined and started with Module 9197 (see "Module 9197 Start cyclic timer" on page 1531). They are reset for one PLC cycle, and are then restarted automatically.



Example:

Start of timer 1

Run time in [timer] = 10 (PLC cycles)



Start timer	Timer is running	Machine parameters
T0	T48	timer[0]
T1	T49	timer[1]
T2	T50	timer[2]
T3	T51	timer[3]
T4	T52	timer[4]
T5	T53	timer[5]
T6	T54	timer[6]
T7	T55	timer[7]
T8	T56	timer[8]
T9	T57	timer[9]
T10	T58	timer[10]
T11	T59	timer[11]
T12	T60	timer[12]
T13	T61	timer[13]
T14	T62	timer[14]
T15	T63	timer[15]
T16	T64	timer[16]
T17	T65	timer[17]
T18	T66	timer[18]
T19	T67	timer[19]
T20	T68	timer[20]
T21	T69	timer[21]
T22	T70	timer[22]
T23	T71	timer[23]
T24	T72	timer[24]
T25	T73	timer[25]

<b>Start timer</b>	<b>Timer is running</b>	<b>Machine parameters</b>
T26	T74	timer[26]
T27	T75	timer[27]
T28	T76	timer[28]
T29	T77	timer[29]
T30	T78	timer[30]
T31	T79	timer[31]
T32	T80	timer[32]
T33	T81	timer[33]
T34	T82	timer[34]
T35	T83	timer[35]
T36	T84	timer[36]
T37	T85	timer[37]
T38	T86	timer[38]
T39	T87	timer[39]
T40	T88	timer[40]
T41	T89	timer[41]
T42	T90	timer[42]
T43	T91	timer[43]
T44	T92	timer[44]
T45	T93	timer[45]
T46	T94	timer[46]
T47	T95	timer[47]





## Counters

The PLC has 48 counters, which you control via special markers with the symbol **C**.

C0 to C47 are reserved as start markers for the timers, C48 to C95 are reserved as process markers.

The key name of the counter is freely selectable in the machine configuration. The process marker (e.g. C48) is defined with the optional machine parameter **MP\_run**. If no value is entered in **MP\_run**, the control uses the key name of the counter as process marker.

You must define the default values for the counters in machine parameter **MP\_value**. As the time unit, under **MP\_unit** you can choose between seconds and PLC cycles.


After you have set a marker from the C0 to C47 range, the control loads the counter with the value that is saved in machine parameter **MP\_value**. As the time unit, under **MP\_unit** you can choose between seconds and PLC cycles. The marker range C48 to C95 (process markers) indicates whether the counter has expired. Use markers C96 to C143 (enabling markers) to start and stop the counter.

The optional machine parameters **MP\_start** and **MP\_gate** are not evaluated by the control. The PLCdesignNT development environment uses them for the automatic generation of PLC definition files.

Example:

Logic diagram for counter C1

Counter default in [counter] = 10 (PLC cycles)



<b>Start counter</b>	<b>Counter is running</b>	<b>Enable counter</b>	<b>Machine parameters</b>
C0	C48	C96	counter[0]
C1	C49	C97	counter[1]
C2	C50	C98	counter[2]
C3	C51	C99	counter[3]
C4	C52	C100	counter[4]
C5	C53	C101	counter[5]
C6	C54	C102	counter[6]
C7	C55	C103	counter[7]
C8	C56	C104	counter[8]
C9	C57	C105	counter[9]
C10	C58	C106	counter[10]
C11	C59	C107	counter[11]
C12	C60	C108	counter[12]
C13	C61	C109	counter[13]
C14	C62	C110	counter[14]
C15	C63	C111	counter[15]
C16	C64	C112	counter[16]
C17	C65	C113	counter[17]
C18	C66	C114	counter[18]
C19	C67	C115	counter[19]
C20	C68	C116	counter[20]
C21	C69	C117	counter[21]
C22	C70	C118	counter[22]
C23	C71	C119	counter[23]
C24	C72	C120	counter[24]
C25	C73	C121	counter[25]
C26	C74	C122	counter[26]
C27	C75	C123	counter[27]
C28	C76	C124	counter[28]
C29	C77	C125	counter[29]
C30	C78	C126	counter[30]
C31	C79	C127	counter[31]
C32	C80	C128	counter[32]
C33	C81	C129	counter[33]
C34	C82	C130	counter[34]
C35	C83	C131	counter[35]
C36	C84	C132	counter[36]
C37	C85	C133	counter[37]
C38	C86	C134	counter[38]



Start counter	Counter is running	Enable counter	Machine parameters
C39	C87	C135	counter[39]
C40	C88	C136	counter[40]
C41	C89	C137	counter[41]
C42	C90	C138	counter[42]
C43	C91	C139	counter[43]
C44	C92	C140	counter[44]
C45	C93	C141	counter[45]
C46	C94	C142	counter[46]
C47	C95	C143	counter[47]

### MP\_run

Process marker for the timer or counter  
Available from NCK software version: 597 110-03.

Format: String

Input: Max. 80 characters

Identifies the timer or counter (process marker), for which the respectively configured time applies.

Timer: T48 to T999

Counter: C48 to C95

If two or more times are configured, the parameter identifies the first timer or counter.

Default: No entry, value optional

Access: LEVEL3

Reaction: NOTHING

### MP\_start

Start marker for the timer or counter  
Available from NCK software version: 597 110-03.

Format: String

Input: Max. 80 characters

Identifies the start marker for the timer or counter.

Timer: T0 to T47

Counter: C0 to C47

There is no start marker for timers T96 to T999. They can be started only through Module 9006.

This parameter is not evaluated by the control. The PLCdesignNT development environment uses it for the automatic generation of PLC definition files.

Default: No entry, value optional

Access: LEVEL3

Reaction: NOTHING

### **MP\_gate**

Release marker for counters  
Available from NCK software version: 597 110-03.

Format: String  
Input: Max. 80 characters

Only for counters:  
Identifies the enabling marker (gate marker) for the corresponding counter.  
Gate markers are C96 to C143.  
This parameter is not evaluated by the control. The PLCdesignNT development environment uses it for the automatic generation of PLC definition files.

Default: No entry, value optional  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_unit**

Time unit for timers and counters  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: **SECONDS**  
Input in seconds  
**PLC\_CYCLES**  
Input in number of PLC cycles

Default: SECONDS  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_value**

Default values for PLC timers and counters  
Available from NCK software version: 597 110-01.

Format: Array [1...99]  
Input: Minimum value: 0  
Maximum value: 1000 000  
Decimal places: 3

Default: 0  
Access: LEVEL3  
Reaction: NOTHING



## Management of timer addresses

The MANUALplus 620 references the timers and counters via symbolic names. The **CfgPlcTimer** configuration object is configured in the configuration editor for this:

- Parameter **MP\_run** (103503):  
Name of the process marker (if the attribute is missing then the key is the name of the marker)
- Parameter **MP\_start** (103504):  
Name of the start marker (timer to NR48 and counter)
- Parameter **MP\_gate** (103505):  
Name of the gate marker (only counter)

The PLC compiler of the MANUALplus 620 can manage timer addresses itself (as with B/W/D and markers). The **#pragma range** pragma instruction must be entered in the source code for this.

This pragma instruction also has the following effects:

- Global/static memory is reserved in rising order
- Support of two ranges each for /bn and /mn areas
- Compiler range /sn for strings

Syntax:

(Instruction for range reservation of the timers and counters. The range must be between 48 and 999 in each case.)

```
#define /tn <min value> <max value>
#define /cn <min value> <max value>
```

Definition of a timer started via a module:

```
#define <run timer name> T
```

Definition of a timer started via a start timer:

```
#define /ts:<start timer name> <run timer name> T
```

Definition of a counter started via a module:

```
#define <run counter name> C
```

Definition of a counter started via a start counter:

```
#define /cs:<start counter name> /cg:<counter gate name>
<run counter name> C
```

### Module 9006: Set and start PLC timer

Use Module 9006 to define the run time for a PLC timer and start the timer.  
Constraints:

- If during a PLC scan a timer from T0 to T47 is set in the PLC program, and the same timer is activated through Module 9006, then the direct activation through T0 to T47 has priority regardless of whether the module is called before or after setting T0 to T47.
- Immediately after the module call, one of the markers T48 to T96 is set. T0 to T47 are not set.
- The control rounds the actual run time up to integral PLC cycle times.
- Cancel run time: Reset timers T48 to T999.

Call:

```
PS   B/W/D/K  <Timer number>
        Input value: 0 to 999
PS   B/W/D/K  <Run time>
        0 to 1 000 000 000 [ms]
        -1: Run time from machine parameter

CM   9006
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Timer started
	1	Error. See NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Invalid timer number or excessive run time
	2	Timer already assigned for cyclic timer
	3	Timer is started as cyclic timer (Module 9197)



### Module 9197 Start cyclic timer

Module 9197 can define and start a timer > T96 as cyclic timer. After expiration of the defined time, the timer is reset for a PLC cycle and afterwards is automatically restarted.

- A cyclic timer can be stopped by setting the run time to 0.
- The programmed timer is set immediately after the module call.
- The run time is programmed in [ms].
- The control rounds the actual run time up to integral PLC cycle times.

Call:

PS B/W/D/K <Timer number>  
96 to 999

PS B/W/D/K <Run time>  
0 to 1 000 000 000 [ms]  
-1: Run time from machine configuration

CM 9197

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Timer started
	1	Error. See NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Excessive run time
	3	Invalid timer number

## 8.4.4 Fast PLC inputs

Settings in the configuration editor	MP number
System	
PLC	
CfgPlcFastInput	
<b>number</b>	103701
<b>significance</b>	103702
<b>operand</b>	103703

With CfgPlcFastInput, you define the PLC inputs that are interrogated within the position controller cycle time (see "MP\_ipoCycle" on page 1481) instead of within the defined PLC cycle time (see "MP\_plcCount" on page 1481). In MP\_number, enter the PLC input of the control that is to be used as a fast PLC input. You define the associated symbolic PLC operands set by the fast PLC input in **MP\_operand**.

A maximum of five PLC inputs can be defined as fast PLC inputs. For this purpose, five input arrays [arrays 0...4] are available in the configuration editor of the control.

For the control to identify with certainty a signal change, the signal duration at the fast PLC input must last a minimum of 4 ms.



### Warning

Only the PLC inputs of the control can be defined as fast PLC inputs, and not the inputs on a PL 510.

### MP\_number

Numerical designation for fast PLC inputs  
Available from NCK software version: 597 110-01.

Format: Array [0...4]  
Input: 0 to 31 [no. of the PLC input on the MC]  
Default: 0  
Access: LEVEL3  
Reaction: RUN



### MP\_significance

Activation criterion for fast PLC inputs  
Format: Selection menu  
Selection: **lowActive**  
Activate at LOW level  
**highActive**  
Activate at HIGH level  
**allEdges**  
Activate at both levels  
**disabled**  
Switched off  
Default: disabled  
Access: LEVEL3  
Reaction: RUN

### MP\_operand

PLC operand for fast PLC inputs  
Format: Array [0...4]  
Input: A string with max. 24 characters can be entered for each array.  
Example:  
**NN\_FastInput\_01**  
Default: NN\_FastInput\_01 to NN\_FastInput\_05  
Access: LEVEL3  
Reaction: RUN

## 8.5 Data Organization

### 8.5.1 Data organization on the CFR memory card

The **CFR** memory card of the MANUALplus 620 is divided into three partitions:

#### TNC partition

User-specific data such as NC programs, tool tables, and datum tables.

#### PLC partition

Your OEM-specific data such as system files, PLC programs, machine parameters, help files, PLC dialogs, PLC error tables, compensation value tables and OEM cycles. The PLC partition is visible only after you have entered the code number 807667.

As a machine tool builder, you are concerned primarily with the PLC partition.



#### Note

Define all your machine-specific settings with the configuration editor!

#### SYS partition

For HEIDENHAIN

System-specific files, such as system files, NC dialogs, HEIDENHAIN cycles, etc.

The partition SYS can neither be viewed nor selected.



#### Warning

Alterations to the system partition can impair proper function of the control!

#### Size of the partitions

The storage capacity of the CFR memory card is 1 GB.

Partition	Contents	Size
SYS:	System files	640 MB
PLC:	OEM files	50 MB
TNC:	User files	300 MB

## Memory-space monitoring

The control monitors the amount of memory available. The memory available on the CFR CompactFlash memory card as well as the RAM main memory are monitored. If warning thresholds are reached or exceeded, the error message **Too little free memory on <partition/memory>** is output. The control checks the memory cyclically. The warning message is repeated each cycle until you have made more memory available, such as by deleting files that are no longer needed. Press the ERR key and the INTERNAL INFO soft key to have the control display the affected partition, the warning threshold and the remaining memory available. If the **Not enough free RAM** error message is displayed, HEIDENHAIN recommends closing memory-intensive applications (such as the **Test Run** operating mode or editing graphics) until any active workpiece machining process is completed. Then restart the control.

Partition or memory	Warning threshold [MB]	Cycle time for checking [s]
TNC:\	1	30
PLC:\	1	60
Main memory (RAM)	20	30

## 8.5.2 Data organization on the hard disk

There are three different drives (partitions):

### TNC partition

User-specific data such as NC programs, tool tables, and datum tables.

### PLC partition

Your OEM-specific data such as system files, PLC programs, machine parameters, help files, PLC dialogs, PLC error tables, compensation value tables and OEM cycles. The PLC partition is visible only after you have entered the code number 807667.

As a machine tool builder, you are concerned primarily with the PLC partition.



#### Note

Define all your machine-specific settings with the configuration editor!

### SYS partition

For HEIDENHAIN

System-specific files, such as system files, NC dialogs, HEIDENHAIN cycles, etc.

The partition SYS can neither be viewed nor selected.



#### Warning

Alterations to the system partition can impair proper function of the control!

### Assignment to drives

Partition	Contents	Hardware code
SYS	System files	"R" drive
PLC	OEM files	"O" drive
TNC	User files	"V" drive



### 8.5.3 Compressing graphic files

Use the ZIP packer to compress graphic files (e.g. PLC soft keys, support graphics for cycles, or the startup screen) in order to save memory space. For example, the size of a 2-MB bitmap file (\*.bmp, \*.bmx) can be reduced to 40 KB with the ZIP packer. You have two basic possibilities:

#### **Zipping individual files (e.g. the startup screen):**

Compress the graphics file and give the ZIP file the following name:

**[File name].[extension].zip**

Example:

The startup screen **startup\_1024x768.bmp** is compressed and saved as **startup\_1024x768.bmp.zip** to **PLC:\resource**. Make sure to remove the original **startup\_1024x768.bmp** file, since the control first searches for uncompressed files. If the uncompressed \*.bmp does not exist, then the control automatically uses the ZIP archive whose file name contains the graphics file. The file is automatically unzipped and displayed at run-time.

#### **Zipping entire directories (e.g. all support graphics)**

You can compress all graphics files in a directory into one ZIP archive. You must use the directory name as the name of the ZIP archive. The original directory must be renamed or deleted.

Example:

The following cycle support graphics are contained in the **PLC:\oemcyc\h1p\nc** directory:

- **PLC:\oemcyc\h1p\nc\help1.bmp**
- **PLC:\oemcyc\h1p\nc\help2.bmp**
- **PLC:\oemcyc\h1p\nc\help3.bmp**

A ZIP archive with the file name **h1p.zip** is now created with the following contents:

- **nc\help1.bmp**
- **nc\help2.bmp**
- **nc\help3.bmp**

The ZIP file is saved in the **PLC:\oemcyc** directory, and the uncompressed original **PLC:\oemcyc\h1p\nc** directory is removed or renamed.

The path to the zipped graphics file **help1.bmp** from the example above is:

- **PLC:\oemcyc\h1p\nc\help1.bmp** or
- **PLC:\oemcyc\h1p.zip\nc\help1.bmp**

## 8.5.4 Configuring the displayed drives and directories in the file manager

Settings in the configuration editor	MP number
System	
Paths	
CfgOemPath <b>ncDir</b>	102006
CfgUserPath <b>ncDir</b>	102201

Use the machine parameter **MP\_ncDir** to define a list of drives and/or directories, which are displayed in the file manager of the control. The drives and paths are visible only if the user has the required access right.

In the factory default setting of the NC software, the three drives TNC:\, PLC:\ and SYS:\ are already configured through the environmental variables %USR%, %OEM% and %SYS%. The SYS partition is reserved exclusively for HEIDENHAIN and is not visible without the HEIDENHAIN daily password. The PLC:\ partition only becomes visible when you enter the PLC code number 807667.

You can add further drives or directories to the list in **MP\_ncDir**, which are to be displayed in the folder tree after the file manager has been opened.

### CfgOemPath:

#### MP\_ncDir

List of drives and/or directories

Available from NCK software version: 597 110-01.

Format: Array [0...9]

Input: The drives and directories entered here are visible in the file manager, provided that you have the required access rights. The respective paths may contain NC programs or tables, for example, floppy disk drive directories, HDR or CFR directories, network drives, etc.

Default: [0]: %USR%\  
[1]: %OEM%\  
[2]: %SYS%\

Access: LEVEL3

Reaction: RESET

**CfgUserPath:****MP\_ncDir**

List of drives and/or directories

Available from NCK software version: 597 110-01.

Format: Array [0...9]

Input: The drives and directories entered here are visible in the file manager, provided that you have the required access rights. The respective paths may contain NC programs or tables, for example, floppy disk drive directories, HDR or CFR directories, network drives, etc.

Default: No value, parameter optional

Access: LEVEL1

Reaction: NOTHING



## 8.5.5 PLC system files

Paths and names for PLC system files and data are defined in the **plc.cfg** file.



### Note

Make sure that you only make entries to the plc.cfg file by using the configuration editor.

### Path for the plc.cfg file

Settings in the configuration editor	
CfgConfigDataFiles	
dataFiles	
...	
...	
<b>[10]:</b>	PLC:\config\plc.cfg
...	
...	

In the configuration editor (code number 95148), press the **CONFIG FILE LISTS** soft key to enter the path for the **plc.cfg** file.

In the CfgDataFiles object, under **dataFiles** you enter the paths of all \*.cfg files required for the system (see "Machine Parameters" on page 327).

The default path for the plc.cfg file is PLC:\config\plc.cfg.

This means that the control looks for the necessary entries for PLC system data in this file in this path.

### Paths and names for PLC programs and text files

Settings in the configuration editor	MP number
System	
Paths	
CfgPlcPath	
<b>mainPgm</b>	102301
<b>pwmPgm</b>	102302
<b>errorTable</b>	102303
<b>errorText</b>	102304
<b>dialog</b>	102305
<b>softkeyProject</b>	102306
<b>compCfgFile</b>	102308
<b>events</b>	102309
<b>keymapFile</b>	102310
<b>magazineRules</b>	102311
<b>pythonScripts</b>	102315





In the configuration editor, specify under **cfgPlcPath** which directories and names are used for storing PLC programs and files for PLC error messages.

The following path and file names must be specified:

■ **MP\_mainPgm:**

The path and name of the PLC main program (\*.src or \*.plc). All necessary program modules (\*.src) are called from this program as required. The program modules must be in the same directory as the PLC main program.

■ **MP\_pwmPgm:**

Path and name of the PLC program for commissioning the machine (see Current Controller Adjustment). This PLC program is used as an alternative if the machine parameter **MP\_currentControlAdjust** is set to "on."

■ **MP\_errorTable:**

Path and file name for the PET table (file name is plc\_err.pet); PLC error table with references to error message texts (plc\_err.a) and attributes for the control's behavior when an error occurs (created with the PLCtext software); see PLCdesignNT User's Manual.

■ **MP\_errorText:**

File name for error message texts (e.g. **ErrorText.csv**); only the file name is entered – the language-sensitive text files must be saved in language-specific directories which cannot be changed.

- German texts in %OEM%\plc\language\de\ErrorText.csv
- English texts in %OEM%\plc\language\en\ErrorText.csv
- Czech texts in %OEM%\plc\language\cs\ErrorText.csv
- French texts in %OEM%\plc\language\fr\ErrorText.csv
- Italian texts in %OEM%\plc\language\it\ErrorText.csv
- Spanish texts in %OEM%\plc\language\es\ErrorText.csv
- Portuguese texts in %OEM%\plc\language\pt\ErrorText.csv
- Swedish texts in %OEM%\plc\language\sv\ErrorText.csv
- Danish texts in %OEM%\plc\language\da\ErrorText.csv
- Finnish texts in %OEM%\plc\language\fi\ErrorText.csv
- Dutch texts in %OEM%\plc\language\nl\ErrorText.csv
- Polish texts in %OEM%\plc\language\pl\ErrorText.csv
- Hungarian texts in %OEM%\plc\language\hu\ErrorText.csv
- Russian texts in %OEM%\plc\language\ru\ErrorText.csv
- Chinese texts in %OEM%\plc\language\zh\ErrorText.csv
- Chinese (Traditional) texts in %OEM%\plc\language\zh-tw\ErrorText.csv
- Slovenian texts in %OEM%\plc\language\sl\ErrorText.csv
- Slovak texts in %OEM%\plc\language\sk\ErrorText.csv
- Latvian texts in %OEM%\plc\language\lv\ErrorText.csv
- Norwegian texts in %OEM%\plc\language\no\ErrorText.csv
- Korean texts in %OEM%\plc\language\ko\ErrorText.csv
- Estonian texts in %OEM%\plc\language\et\ErrorText.csv
- Turkish texts in %OEM%\plc\language\tr\ErrorText.csv
- Romanian texts in %OEM%\plc\language\ro\ErrorText.csv
- Lithuanian texts in %OEM%\plc\language\lt\ErrorText.csv



- **MP\_dialog:**  
File name for PLC dialogs (e.g. Dialog.csv); only the file name is entered – the language-sensitive text files must be saved in language-specific directories which cannot be changed. (see error message texts)
- **MP\_softkeyProject:**  
Path and name of project file for PLC soft keys;
- **MP\_compCfgFile:**  
Path and name of the configuration file for the PLC compiler;
- **MP\_events:** (not currently evaluated!)  
Path and file name of the PLC event list (spawn processes)
- **MP\_keymapFile:**  
Preset by HEIDENHAIN and should not be changed.  
Path and name of the configuration file for the keyboard mapping.
- **MP\_magazineRules:** (optional)  
Path and name of a file with magazine rules for managing the tool memory.  
Example: %0EM%\plc\tchrules.tcr
- **MP\_pythonScripts:** (optional)  
Key names of Python scripts, which must be defined in **CfgPythonScript**.  
Specifies which Python scripts are automatically started after compilation of the PLC program.  
(Software option 46 is required!)  
If Python scripts provided by HEIDENHAIN and stored on the SYS partition are to be started, you can select them here, as well. The software option 46 is not required for these Python scripts.



### **MP\_mainPgm**

Path and file name of the PLC main program  
Format: String  
Input: Max. 260 characters  
Path and file name of the PLC main program  
Example: %OEM%\PLC\main.src  
Default: –  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_pwmPgm**

Path and file name of the PLC commissioning program  
Format: String  
Input: File name and path of the PLC program for commissioning the current controller. This PLC program is compiled and used as an alternative if the machine parameter **MP\_currentControlAdjust** (System/CfgHardware) is set to "on."  
Example: %OEM%\PLC\SetUp.p1c  
Default: –  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_errorTable**

Path and file name of the PET table  
Format: String  
Input: Max. 260 characters  
Path and file name of the PLC error table  
Example: %OEM%\PLC\LANGUAGE\ERR\_TAB.PET  
Default: –  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_errorText**

Name of the text file for PLC error texts  
Format: String  
Input: Max. 260 characters  
Name (without path) of the text file for PLC error texts. The language-sensitive text files must be saved in language-specific directories that cannot be changed.  
Example: **ErrorText.csv**  
Default: –  
Access: LEVEL3  
Reaction: NOTHING



### **MP\_dialog**

Name of the text file for PLC dialogs

Format: String

Input: Max. 260 characters

Name (without path) of the text file for PLC error texts.  
The language-sensitive text files must be saved in language-specific directories that cannot be changed.  
Example: **dialog.csv**

Default: -

Access: LEVEL3

Reaction: NOTHING

### **MP\_softkeyProject**

Path and name of the project file for PLC soft keys

Format: String

Input: Max. 260 characters

Path and name of the file  
Example: **%OEM%\BasisPgm\Softkeys\softkeys.xrs**

Default: -

Access: LEVEL3

Reaction: NOTHING

### **MP\_compErrorTable**

Path and file name of the error table of the PLC compiler  
(Value preset by HEIDENHAIN and should not be changed!)

Format: String

Input: Max. 260 characters

Path and name of the file  
Default: **%SYS%\config\plccomp.ert**

Access: LEVEL3

Reaction: NOTHING



#### Note

Be sure not to change the default value in **MP\_compErrorTable**, or proper operation of the PLC compiler can no longer be guaranteed.



### MP\_compCfgFile

Path and name of the configuration file for the PLC compiler  
Format: String  
Input: Max. 260 characters  
Path and name of the file  
Example: %OEM%\BasisPgm\Programm\OEM.cfg  
Default: –  
Access: LEVEL3  
Reaction: NOTHING

### MP\_keymapFile

Path and name of the configuration file for the keyboard mapping.  
(Value preset by HEIDENHAIN and should not be changed!)  
Format: String  
Input: Max. 260 characters  
Path and name of the file  
Default: %SYS%\resource\plc\keymap\_te530s.xml  
Access: LEVEL3  
Reaction: NOTHING



#### Note

Be sure not to change the default value in **MP\_keymapFile**, or proper operation of the control can no longer be guaranteed.

### MP\_magazineRules

Path and name of an ASCII file (\*.TCR) with magazine rules  
Available from NCK software version: 597 110-02.  
Format: String  
Input: Max. 260 characters  
Path and name of the file  
Example: %OEM%\plc\tchrules.tcr  
Default: Optional input  
Access: LEVEL3  
Reaction: NOTHING

### MP\_pythonScripts

Python scripts to be started  
Available from NCK software version: 597 110-05.  
Format: Array [0..8]  
Input: Key names of Python scripts from CfgPythonScript  
Specifies which Python scripts are to be started automatically after compilation of the PLC program.  
Default: No value, parameter optional  
Access: LEVEL2  
Reaction: NOTHING

## Path entries for OEM cycles

Settings in the configuration editor	MP number
System	
Paths	
CfgOemPath	
<b>cycleMainTreeFile</b>	102003
<b>cycleSubTreeFiles</b>	102004
<b>oemCycle</b>	102005

Use the machine parameters **MP\_cycleMainTreeFile**, **MP\_cycleSubTreeFiles** and **MP\_oemCycle** to inform the control about the location where the CycleDesign cycle files are stored and about the path of the OEM cycles.

### MP\_cycleMainTreeFile

Path and name for the OEM cycle file (.CDF)  
Available from NCK software version: 597 110-01.

Format: String  
Input: Max. 260 characters  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### MP\_cycleSubTreeFiles

List of paths/names of user cycle files (.CDF)  
Available from NCK software version: 597 110-01.

Format: Array [0...9]  
Input: String of max. 260 characters  
The soft-key rows of these files are appended to the soft-key rows of the system or OEM cycle files.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### MP\_oemCycle

Path for OEM cycles  
Available from NCK software version: 597 110-01.

Format: String  
Input: Max. 260 characters  
Default: %OEM%\oemcyc  
Access: LEVEL3  
Reaction: RESET



## PLC program version

Settings in the configuration editor	MP number
System Versions CfgPlcVersion <b>plcVersion</b>	107301

Enter the version number of the PLC program in **MP\_plcVersion**, which should be displayed on the screen of the control in the MOD dialog.

### MP\_plcVersion

PLC software version; displayed version of the PLC program

Format: String

Input: Max. 32 characters  
PLC program version  
Example: **MANUALplus 620\_BasisPgm\_v1.5**

Default: -

Access: LEVEL3

Reaction: NOTHING



## 8.6 M Functions (M Strobe)

In the control you can program miscellaneous functions, also known as M functions. The code of an M function is transferred to the PLC before or after execution of the NC block.

Certain M functions are reserved for the NC or have fixed meanings for the NC. The other M functions are freely available and are evaluated by the PLC.

The structure of the M Functions menu in the DIN/ISO mode of the **smart.Turn** Programming mode can be adapted to the available M functions.

M functions are channel-sensitive. M functions are configured in two steps:

- In the channel-sensitive parameter **MP\_mStrobes**, you define a key name for each M function used in this machining channel. In this way, you assign the M functions to this machining channel.
- In the parameter object **System/PLC/CfgPlcMStrobe**, you configure the M function.

### 8.6.1 Assigning M functions to the machining channels

Settings in the configuration editor	MP number
Channel	
ChannelSettings	
[Key name of the channel]	
CfgPlcStrobes	
<b>mStrobes</b>	201601
<b>unitOfMeasure</b>	201605

#### MP\_mStrobes

M strobe descriptions of this machining channel

Format: Array [0...99]

Input: Key name of the M strobes used in this machining channel

Default: –

Access: LEVEL3

Reaction: RESET

In the marker defined in **MP\_unitOfMeasure**, the PLC is informed of the unit of measure used in the NC program when M, S, T or alias strobes are executed.

#### MP\_unitOfMeasure

Symbolic name or number of the PLC marker for the unit of measure of the NC program

Format: String

Input: Name of the PLC marker, which informs the PLC of the unit of measure of the NC program to be run.  
 PLC marker = 1: Inches  
 PLC marker = 0: Metric system

Default: Value optional

Access: LEVEL3

Reaction: RESET



## 8.6.2 Configuration of M functions

Settings in the configuration editor	MP number
System	
PLC	
CfgPlcMStrobe	
[Key name of M strobe]	
<b>min</b>	103901
<b>max</b>	103902
<b>signal</b>	103903
<b>acknowledge</b>	103904
<b>code</b>	103905
<b>data</b>	103906
<b>revoke</b>	103907
<b>split</b>	103908
<b>track</b>	103914
<b>singular</b>	103910
<b>blockEnd</b>	103911
<b>blockSearch</b>	103912
<b>sync</b>	103913
<b>macro</b>	103914

### Transfer of the M function

If there is more than one M function number with the same transfer parameters, the M function numbers can be defined in a parameter object.

- Multiple M codes in the parameter object:
  - **MP\_min**: Code of the first M function
  - **MP\_max**: Greatest M code of the group
- One M code in the parameter object:
  - **MP\_min**: M code of the parameter object
  - **MP\_max**: No entry

If **MP\_code** is defined, the NC transfers the programmed M code in the PLC word marker defined in **MP\_code** and other data of the M function in the PLC word marker defined in **MP\_data**.

### **MP\_min**

Code of the first M function  
Format: Numerical value  
Input: 0 to 9999  
First M code described in the parameter object. The properties described in this parameter object apply for the specified M functions.  
Default: 0  
Access: LEVEL3  
Reaction: RESET

### **MP\_max**

Code of the last M function  
Format: Numerical value  
Input: 0 to 9999  
Code of the last (greatest) M function described in the parameter object.  
No entry: The properties of the parameter object apply only to the M function defined in **MP\_min**.  
Default: No entry, value optional  
Access: LEVEL3  
Reaction: RESET

## **Transfer and acknowledgment of M function**

In the **Program Run, Full Sequence** and **Program Run, Single Block** operating modes, the next NC block is not run until the PLC has acknowledged execution of the M function.

There are two possibilities for transferring the M strobe to the PLC and for acknowledgment by the PLC:

- Transfer and acknowledgment with **MP\_signal**
  - Transfer of the M strobe: The PLC marker defined in **MP\_signal** is set
  - Acknowledgment of the M strobe: The PLC marker defined in **MP\_signal** is reset.
- Transfer with **MP\_signal** and acknowledgment with **MP\_acknowledge**:
  - Transfer of the M strobe: The PLC marker defined in **MP\_signal** is set
  - Acknowledgment of the M strobe: The PLC marker defined in **MP\_acknowledge** is set.

HEIDENHAIN recommends that you only use **MP\_signal** for transfer and acknowledgment.

If **MP\_signal** and **MP\_acknowledge** are not defined, the data of the M strobe are saved without synchronization with the PLC program. The output is immediately acknowledged.

### **MP\_signal**

Symbolic name or number of the PLC marker that is set when the function is decoded.

Format: String

Input: Max. 80 characters

If you have not entered a value in the parameter

**MP\_acknowledge**, resetting this marker means an acknowledgment of the strobe.

No entry: The data connected with the output of the strobe is saved without synchronization with the PLC program and the output is immediately acknowledged.

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET

### **MP\_acknowledge**

Symbolic name or number of the PLC marker that is set for acknowledging the strobe.

Available from NCK software version: 597 110-02.

Format: String

Input: Max. 80 characters

No entry: The strobe is reset with the PLC marker entered in **MP\_signal**.

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET

### **MP\_code**

Symbolic name or number of the PLC word marker for the M code

Format:

String

Input:

Max. 80 characters

Name of the PLC word marker in which the M code is transferred to the PLC

Example: **DG\_M\_Function\_M10**

Default:

No entry, value optional

Access:

LEVEL3

Reaction:

RESET

### **MP\_data**

Symbolic name or number of the PLC word marker for additional data

Format:

String

Input:

Max. 80 characters

Symbolic name or number of the PLC word marker in which the additional data of the M function is transmitted to the PLC.

The field size determined from the symbol defines up to how many data can be saved in the programmed sequence.

If an absolute number is given, only one value is saved.

If no value is entered, no data can be passed to the PLC.

Default:

No entry, value optional

Access:

LEVEL3

Reaction:

RESET

### **MP\_revoke**

Numbers of M functions whose effect will be canceled by the output of the strobe.

Available from NCK software version: 597 110-02.

Format:

Array [0...19]

Input:

0 to 9999

In the list, enter the numbers of the functions whose effect will be canceled when this code is output.

Example – Configuration of function M5: Calling function M5 cancels the effect of functions M3 and M4. In this example, you would enter the key names of the functions M3 and M4.

The parameter is effective for updating the status of the function in the status display and during block scan.

Note:

S outputs for the same spindle as well as T outputs and T2 outputs always cancel each other. However, in some cases they may also cancel other M functions. M functions cannot cancel the effects of S, T and T2 outputs.

If specific codes cancel each other, they cannot be combined in a strobe.

Default:

No entry, value optional

Access:

LEVEL3

Reaction:

RESET

### MP\_split

The M function is split into the specified M functions  
Available from NCK software version: 597 110-02.

Format: Array [0...1] (max. two M functions)

Input: The currently active M function can be split into the two specified M functions. You can cancel it in part by canceling one of the specified M functions. The currently active M function is split up if part of it is canceled by the **MP\_revoke** parameter.

Example:

Mxx = Spindle ON clockwise (M3) + coolant ON (M8)

If function Mxx is active and an M5 is collected during the block scan, for example, the function M3 contained in Mxx is canceled. Only function M8 remains active. In this case, enter the key names "M3" and "M8" into the parameter.

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET

### MP\_group

After a block scan, the collected M functions are implemented in the order of their group IDs (starting from the lowest).

Available from NCK software version: 597110-03.

Format: Numerical value

Default: Value optional

Access: LEVEL3

Reaction: RESET

### MP\_track

Automatic tracking of the active M functions

Available from NCK software version: 597 110-03.

Format: Selection menu

Selection: Normally the PLC program has to use the Module 9088 to implement the status of the active M function. Set this parameter to TRUE if the PLC run-time system is to implement the status automatically.

#### **TRUE**

The status of the active M function is tracked automatically, depending on the **MP\_trackMState** parameter (CfgPlcOptions).

#### **FALSE**

The status of the active M function must be tracked by calling Module 9088.

#### **No value:**

The status of the active M function is tracked automatically, depending on the **MP\_trackMState** parameter (CfgPlcOptions).

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET

In **MP\_singular**, M codes to be output in a separate strobe are defined.

### **MP\_singular**

Function is output in a separate strobe

Format: Selection menu

Selection: Use the parameter **MP\_singular** to prevent the function from being output in a strobe together with other functions. If several M, S, T functions are programmed in an NC block, the strobes can be set in parallel by the NC. With this parameter, you can exclude the current function from this parallel collection and simultaneous transmission in one strobe.

**TRUE**  
Function is output in a separate strobe. Combined output is prevented.

**FALSE**  
Function can be combined with other functions

Default: TRUE

Access: LEVEL3

Reaction: RESET

### **Execution at the beginning or end of block**

In **MP\_blockEnd**, you define whether the M function is to be executed at the beginning or end of block.

### **MP\_blockEnd**

Function output at block end

Format: Selection menu

Selection: **TRUE**  
Function is executed at block end.

**FALSE**  
Function is executed at beginning of block.

Default: FALSE

Access: LEVEL3

Reaction: RESET

### **Output of M code during block scan**

Use the parameter **MP\_blockSearch** to define whether the M code should also be output during the block scan.

### **MP\_blockSearch**

Function output also during block scan  
Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **TRUE**  
Function is also output during the block scan.

**FALSE**  
Function is not output during the block scan. The function is collected and restored.

Default: FALSE

Access: LEVEL3

Reaction: RESET



## Synchronization of the M function with the NC program

**MP\_sync** defines the synchronization of the M function with NC program run.

### MP\_sync

Synchronization of function with the NC

Format: Selection menu

Selection: **SYNC\_EXEC**

The function is synchronized with program run. The output of movement by the interpolator is stopped; then the function is executed.

Please note:

After this function has been executed, the look-ahead calculation continues using the position values that were active **before** execution of the function. This setting is not suitable, for example, for M functions executing PLC positioning movements!

### **SYNC\_CALC**

The function is synchronized with program calculation. The interpretation of the NC program is stopped and the path is calculated internally; then the function is executed. The M function is completely executed. After successful execution has been acknowledged, calculation continues with new position values.

### **ASYNC**

The function is output without synchronization.

Default: SYNC\_EXEC

Access: LEVEL3

Reaction: RESET

## Calling an NC macro with an M function

An NC subprogram can be executed instead of transferring an M function to the PLC. The path and name of the NC subprogram are entered in the parameter **MP\_macro**.

M functions that call an NC subprogram are not sent to the PLC.

### MP\_macro

Call of an NC subprogram instead of the M function

Format: String

Input: Max. 260 characters

Path and file name of the NC subprogram

Example: %OEM%\programs\MMacro10.ncs

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET



### Note

A maximum of six NC programs can be nested (subprograms, cycles, macros).

## Adjust the M function menu

In the DIN/ISO mode of the **smart.Turn** Programming mode you can insert M functions directly into the NC program by means of an M Function menu (M menu). The structure and menu texts of the M menu are defined in language-sensitive files \*.str under **PLC:resource\MFktMenu** and can be adjusted to the available M functions.



### Note

As the language of the M menu is not switched when the language is changed during run time, the control must be re-started in such a case.

A menu entry comprises:

- **Menu position:** 3-digit number
  - 1st number: 1st menu level (1st pull-down menu)  
The number 1 is assigned to "Program Functions"—please use the numbers 2 to 9
  - 2nd number: 2nd menu level—up to 9 entries under each entry of the 1st menu level
  - 3rd number: 3rd menu level—up to 9 entries under each entry of the 2nd menu level
- **M number:** appears after the menu item has been selected
  - Further menu level follows: the M number has no significance
  - Negative M number: The menu item is visible, but not selectable
- **Menu text:** Menu item text (enclosed in quotation marks "...").
- **Comment:**
  - Follows the closing quotation mark of the menu text
  - Use a semicolon (";") to start the comment lines in the first column.
- Line feeds can be inserted at any location.



An excerpt of the **MFktMenu\_de.str** file is shown below. The M menu resulting from this menu description is depicted in the figure following it.


Excerpt from a menu description (MFktMenu\_de.str):

```

200, 0, "Main spindle"
210, 4, "Spindle CCW ON"      M4"
220, 3, "Spindle CW ON"     M3"
230, 5, "Spindle STOP"      M5"
240, 0, "C axis drive"
241, 14, "C axis 1 ON"       M14"
242, 15, "C axis 1 OFF"     M15"
250, 19, "Spindle point stop" M19"
260, 0, "Special functions"
261, 12, "Index ON"         M12" Spindle brake ON
262, 13, "Index OFF"       M13" Spindle brake off
;
300, 0, "Coolant"
310, 108, "Circulation 1 ON" M108"
320, 107, "Circulation 2 ON" M107"
330, 109, "All OFF"         M109"
340, 50, "Chuck jaw flushing ON" M50"
350, 51, "Chuck jaw flushing OFF" M51"
360, 49, "Lubrication pulse ON" M49"
;
400, 0, "Chuck"
...

```

This description creates the following menu:



### 8.6.3 Overview of M functions of the MANUALplus 620

The M functions listed in the table below are executed/evaluated by the NC and then forwarded to the PLC for further execution. These M functions cannot be used for any other purposes.

<b>M code</b>	<b>Function</b>
M0	Programmed stop
M1	Selectable stop
M7	Coolant
M8	Coolant
M9	Coolant
M12	Spindle brake ON
M13	Spindle brake OFF
M14	Position C axis (assigned to spindle 1)
M15	Move C axis out (assigned to spindle 1)
M30	Program end without restart
M41 to M44	Gear ranges
M91	Program end without spindle stop (for retraction program during tool inspection)
M97	Multilateral synchronization (not with MANUALplus 620)
M99	Program end with restart
M114	Position C axis (assigned to spindle 2)
M115	Move C axis out (assigned to spindle 2)
M214	Position C axis (assigned to spindle 3)
M215	Move C axis out (assigned to spindle 3)
M314	Position C axis (assigned to spindle 4)
M315	Move C axis out (assigned to spindle 4)



The M codes listed in the following table "usually" have the described meaning.

<b>M code</b>	<b>Function</b>
M3	CW spindle rotation for spindle/screw 1
M4	CCW spindle rotation for spindle/screw 1
M5	Spindle stop for spindle/screw 1
M19	Position control for spindle/screw 1
M33	Open the spindle chuck while it is running
M36	Open the spindle chuck
M37	Close the spindle chuck
M103	CW spindle rotation for spindle/screw 2
M104	CCW spindle rotation for spindle/screw 2
M105	Spindle stop for spindle/screw 2
M119	Position control for spindle/screw 2
M203	CW spindle rotation for spindle/screw 3
M204	CCW spindle rotation for spindle/screw 3
M205	Spindle stop for spindle/screw 3
M219	Position control for spindle/screw 3
M303	CW spindle rotation for spindle/screw 4
M304	CCW spindle rotation for spindle/screw 4
M305	Spindle stop for spindle/screw 4
M319	Position control for spindle/screw 4



## 8.7 S Function (S Strobe)

The S function is channel-sensitive. S functions are configured in two steps:

- In the channel-sensitive parameter **MP\_sStrobes**, you define a key name for the S function. In this way, you assign the S functions to a machining channel.
- In the parameter object **System/PLC/CfgPlcSStrobe**, you configure the S function.



### Note

If the rotational speed is programmed within a G function, the S strobe will not be used. Then the rotational speed or constant cutting speed will be transmitted to the PLC in an M strobe.

### 8.7.1 Assigning S functions to the machining channels

Settings in the configuration editor	MP number
Channel	
ChannelSettings	
[Key name of the channel]	
CfgPlcStrobes	
<b>sStrobe</b>	201602
<b>unitOfMeasure</b>	201605

#### MP\_sStrobe

S strobe description of this machining channel

Format: Selection menu

Selection: Key name of the S strobe used in this machining channel

Default: –

Access: LEVEL3

Reaction: RESET

In the marker defined in **MP\_unitOfMeasure**, the PLC is informed of the unit of measure used in the NC program when M, S, T or alias strobes are executed (see "MP\_unitOfMeasure" on page 1548).

## 8.7.2 Configuration of S function

Settings in the configuration editor	MP number
System	
PLC	
CfgPlcSStrobe	
[Key name of S strobe]	
<b>type</b>	104017
<b>condition</b>	104001
<b>signal</b>	104002
<b>acknowledge</b>	104003
<b>spindleSpeed</b>	104004
<b>badSpeed</b>	104005
<b>cuttingSpeed</b>	104018
<b>spindleMode</b>	104006
<b>gearCode</b>	104007
<b>gearSpeed0</b>	104008
<b>gearSpeed1</b>	104009
<b>gearStop</b>	104010
<b>sCode</b>	104011
<b>revoke</b>	104012
<b>singular</b>	104013
<b>blockSearch</b>	104014
<b>sync</b>	104015
<b>syncGear</b>	104016

### Transfer and acknowledgment of S function

Use parameter **MP\_condition** to define the conditions for the output of the S strobe.

There are two possibilities for transferring the S strobe to the PLC and for acknowledgment by the PLC:

- Transfer and acknowledgment with **MP\_signal**
  - Transfer of the S strobe: The PLC marker defined in **MP\_signal** is set.
  - Acknowledgment of the S strobe: The PLC marker defined in **MP\_signal** is reset.
- Transfer with **MP\_signal** and acknowledgment with **MP\_acknowledge**:
  - Transfer of the S strobe: The PLC marker defined in **MP\_signal** is set.
  - Acknowledgment of the S strobe: The PLC marker defined in **MP\_acknowledge** is set.

HEIDENHAIN recommends that you only use **MP\_signal** for transfer and acknowledgment.

If **MP\_signal** and **MP\_acknowledge** are not defined, the data of the S strobe is saved without synchronization with the PLC program. The output is immediately acknowledged.

### **MP\_condition**

Condition for sending the strobe to the PLC  
Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **COND\_ALWAYS**

Strobe is output with every programmed S code

#### **COND\_ST**

Strobe is output only if spindle speed changes

#### **COND\_GP**

Strobe is output only if gear range changes

If the parameter is missing from the configuration, the strobe is always output.

Default: COND\_ST

Access: LEVEL3

Reaction: RESET

### **MP\_signal**

Symbolic name or number of the PLC marker that is set when the function is decoded.

Format: String

Input: Max. 80 characters

If you have not entered a value in the parameter **MP\_acknowledge**, resetting this marker means an acknowledgment of the strobe.

No entry: The data connected with the output of the strobe is saved without synchronization with the PLC program and the output is immediately acknowledged.

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET

### **MP\_acknowledge**

Symbolic name or number of the PLC marker that is set for acknowledging the strobe.

Available from NCK software version: 597 110-02.

Format: String

Input: Max. 80 characters

No entry: The strobe is reset with the PLC marker entered in

#### **MP\_signal.**

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET



When the spindle speed or mode of rotation is changed in the **T, S, F** menu or the NC program, a strobe signal is generated and communicated to the PLC via the operand defined in **MP\_signal**. At the same time the NC transmits the programmed spindle speed in the PLC word defined in **MP\_spindleSpeed** and the constant cutting speed in the PLC word defined in **MP\_cuttingSpeed**. Depending on the value entered in the PLC word defined in **MP\_spindleMode** for the spindle rotation, the PLC evaluates either **MP\_spindleSpeed** (with constant spindle speed = 96) or **MP\_cuttingSpeed** (with constant cutting speed = 97).

If there are several spindles in an NC channel, you must enter in **MP\_type** which spindle the S strobe is to refer to.

The PLC checks the programmed spindle speed in addition. The result of this check is saved in the PLC marker defined in **MP\_badSpeed**. If the marker is set, the spindle speed is outside the permissible range. If **MP\_badSpeed** is not defined, the spindle speed is not checked.

### **MP\_type**

If there are several spindles in an NC channel, you must enter in **MP\_type** which spindle the S strobe is to refer to.

Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0: S strobe refers to the main spindle  
1: S strobe refers to spindle 1 (driven tool)  
2: S strobe refers to spindle 2 (driven tool)  
3: S strobe refers to opposing spindle  
Default: 0  
Access: LEVEL3  
Reaction: RESET

### **MP\_spindleSpeed**

Symbolic name or number of the PLC word for transmitting the spindle speed

Available from NCK software version: 597 110-01.

Format: String  
Input: Name of the PLC word in which the spindle speed is transmitted to the PLC  
If the parameter is missing, the spindle speed cannot be read as a numerical value.  
Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET



### **MP\_badSpeed**

Symbolic name or number of the PLC marker for impermissible spindle speeds

Available from NCK software version: 597 110-01.

Format: String

Input: Name of the PLC marker which is set if the spindle speed is outside the permissible range.

No entry: The spindle speed is not monitored.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

### **MP\_cuttingSpeed**

Symbolic name or number of the PLC word for transmitting the constant cutting speed

Available from NCK software version: 597 110-01.

Format: String

Input: Name of the PLC word in which the constant cutting speed is transmitted to the PLC.

If the parameter is missing, the constant cutting speed cannot be read as a numerical value.

Default:

Access: LEVEL3

Reaction: RESET

### **MP\_spindleMode**

Symbolic name or number of the PLC word for transmission of the spindle mode of rotation (96 for constant spindle speed, 97 for constant cutting speed). Depending on the value of the PLC operand defined in MP\_spindleMode, the PLC evaluates either the content of MP\_spindleSpeed or MP\_cuttingSpeed.

Available from NCK software version: 597 110-01.

Format: String

Input: Name of the PLC word in which the spindle mode of rotation is transmitted to the PLC

If the parameter is missing, the constant cutting speed cannot be read as a numerical value.

Default:

Access: LEVEL3

Reaction: RESET

In **MP\_singular**, the S codes that must be output in a separate strobe and must not be combined with other codes are defined.



### MP\_singular

Function is output in a separate strobe

Format: Selection menu

Selection: Use the parameter **MP\_singular** to prevent the function from being output in a strobe together with other functions. If several M, S, T functions are programmed in an NC block, the strobes can be set in parallel by the NC. With this parameter, you can exclude the current function from this parallel collection and simultaneous transmission in one strobe.

**TRUE**  
Function is output in a separate strobe. Combined output is prevented.

**FALSE**  
Function can be combined with other functions

Default: TRUE

Access: LEVEL3

Reaction: RESET

### MP\_revoke

Numbers of functions whose effect will be canceled by the output of the strobe.

Available from NCK software version: 597 110-02.

Format: Array [0...19]

Input: 0 to 9999

In the list, enter the numbers of the functions whose effect will be canceled when this code is output.

Example – Configuration of function M5: Calling function M5 cancels the effect of functions M3 and M4. In this example, you would enter the key names of the functions M3 and M4.

The parameter is effective for updating the status of the function in the status display and during block scan.

Note:  
S outputs for the same spindle as well as T outputs and T2 outputs always cancel each other. However, in some cases they may also cancel other M functions. M functions cannot cancel the effects of S, T and T2 outputs.

If specific codes cancel each other, they cannot be combined in a strobe.

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET

Parameter **MP\_blockSearch** is used to define the behavior of the S function during block scan:

### **MP\_blockSearch**

S function output during block scan

Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **TRUE**

S function is also output during block scan.

**FALSE**

S function is not output during block scan. The function is collected and restored.

Default: FALSE

Access: LEVEL3

Reaction: RESET



## Gear shifting

You control the gear shifting through PLC outputs. The gear range is determined by the **MP\_nominalSpeed** of each gear-range parameter set. The output of the gear range is defined in **MP\_condition**. Use **MP\_gearStop** to define if the spindle speed should automatically be reduced to 0 when shifting between gears.

- ▶ Configure a separate spindle parameter set for each gear stage.
- ▶ Use **MP\_gearCode** to define a word marker, in which the gear range is transmitted to the PLC during decoding.



### Note

Use the "KeySynonym" function to create new parameter sets rapidly and easily. (in the configuration editor under **KeySynonym** -> **CfgKeySynonym**). Only the first parameter set must be fully defined. All further parameters sets are "linked" to the first set (**MP\_relatedTo**), so you only have to describe the differing parameters. For more information, please refer to „The KeySynonym Function" on page 377.

- ▶ In the list parameter **MP\_gearSpeed0**, enter the names of spindle parameters sets for the operating mode 0. These parameter sets define the gear ranges for operating mode 0 if it is selected with PLC Module 9163. (See "Switching the operating modes" on page 1029.)
- ▶ Proceed in the same manner for operating mode 1 and enter the parameter sets in **MP\_gearSpeed1**.

Each of the lists must be sorted in ascending order, with the smallest gear shaft speed at the top. Gear ranges are not supported if the list is missing or empty.

- ▶ Use the **CfgFeedLimits** configuration datum of a parameter set to define the minimum and maximum spindle shaft speed for each gear range.
- ▶ Use the parameter **MP\_nominalSpeed (CfgFeedLimits)** to define the rated speed for each gear range.
- ▶ For digitally controlled spindles:  
Use the parameter **MP\_gearShiftSpeed** to define the gear shifting speed for each gear range.
- ▶ For analog controlled spindles:  
Use the optional parameter **MP\_gearShiftVoltage** to define for each gear range the nominal-voltage output for gear shifting.

The control selects the necessary gear range based on this shaft speed. The minimum and maximum shaft speeds of the individual gear ranges (**MP\_minFeed** and **MP\_maxFeed** parameters) may overlap.

**Module 9416 Select gear range and assigned settings for spindle**

With Module 9416 you select the gear range and the assigned parameter set, as well as other settings, for a spindle.

Constraints:

- The module is only supported by the symbolic memory interface (API 3.0). If you are using the iTNC-compatible memory interface (API 1.0), the module returns an error.
- Enter the value 0 for <gear range> if no gear ranges are configured, but other settings are to be changed.

Call:

```

PS    B/W/D/K  <Spindle index>
PS    B/W/D/K  <Mode>
                        Bit 0: Direction of spindle rotation
                        0: Direction of rotation not inverted
                        1: Direction of rotation inverted
PS    B/W/D/K  <Gear range>
CM    9416
PL    D        <Error number>
                        0: Module successfully executed
                        1: Faulty module call (invalid spindle number)
                        2: Faulty module call (negative gear range)
                        3: Invalid gear range

```

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error	0	No error; gear range or spindle settings were selected
	1	Error code in NN_GenApiModuleErrorCode or see error code above
NN_GenApiModule ErrorCode	2	Invalid task data transferred (see error number in returned value)
	99	Module is not supported (control does not operate with symbolic memory interface)



### MP\_gearCode

Symbolic name or number of the PLC word for the gear range  
Available from NCK software version: 597 110-01.

Format: String

Input: Name of the PLC word in which the gear range is transmitted to the PLC  
No entry: No gear range is transmitted

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

### MP\_gearSpeed0

Key names of parameter sets for gear ranges (operating mode 0)  
Available from NCK software version: 597 110-02.

Format: Array [0...99]

Input: List with key names for spindle parameter sets for operating mode 0.

Default: –

Access: LEVEL3

Reaction: RESET

### MP\_gearSpeed1

Key names of parameter sets for gear ranges (operating mode 1)  
Available from NCK software version: 597 110-02.

Format: Array

Input: List with key names for spindle parameter sets for operating mode 1.

Default: –

Access: LEVEL3

Reaction: RESET

### MP\_gearStop

Switch off the spindle when the gear range is changed (cf. iTNC 530: MP3030 bit#1)  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: **TRUE**  
If a strobe for changing the gear range is output, the control automatically switches the spindle off.  
**FALSE**  
If a strobe for changing the gear range is output, the spindle is not switched off.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

### **MP\_nominalSpeed**

Rated speed for the gear range  
Available from NCK software version: 597 110-02.

Format: Numerical value  
Input: Shaft speed [rpm]  
Enter the greatest programmable shaft speed at which this spindle parameter set is to be used. If a shaft speed greater than the given one is programmed, the next higher gear range is switched to.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RUN

### **MP\_sync**

Synchronization of function with the NC

Format: Selection menu  
Selection: **SYNC\_EXEC**  
The function is synchronized with program run. The output of movement by the interpolator is stopped; then the function is executed.  
Please note:  
After this function has been executed, the look-ahead calculation continues using the position values that were active **before** execution of the function. This setting is not suitable for M functions executing PLC positioning movements, for example.

**SYNC\_CALC**  
The function is synchronized with program calculation. The interpretation of the NC program is stopped and the path is calculated internally; then the function is executed. The M function is completely executed. After successful execution has been acknowledged, calculation continues with new position values.

**ASync**  
The function is output without synchronization.

Default: SYNC\_EXEC  
Access: LEVEL3  
Reaction: RESET



### **MP\_syncGear**

Synchronization of function with the NC if the gear speed changes

Format: Selection menu

Selection: **SYNC\_EXEC**

The function is synchronized with program run. The output of movement by the interpolator is stopped; then the function is executed.

Please note:

After this function has been executed, the look-ahead calculation continues using the position values that were active **before** execution of the function. This setting is not suitable for M functions executing PLC positioning movements, for example.

#### **SYNC\_CALC**

The function is synchronized with program calculation. The interpretation of the NC program is stopped and the path is calculated internally; then the function is executed. The M function is completely executed. After successful execution has been acknowledged, calculation continues with new position values.

#### **ASYNC**

The function is output without synchronization.

If the parameter is missing, synchronization is as given by the parameter **MP\_sync**.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

### **MP\_gearShiftSpeed**

Speed for gear shifting

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: RPM [1/min] with up to 9 decimal places

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

### **MP\_gearShiftVoltage**

Nominal voltage value output for gear shifting

Available from NCK software version: 597 110-03.

Format: Numerical value

Input: Voltage in volts [V] with up to 9 decimal places

Default: No value, parameter optional

Access: LEVEL3

Reaction: RUN

## Coded output of spindle speed

Use the parameter **MP\_sCode** to configure a word marker for the coded output of the spindle speed (S code). You must output the speed code to the spindle drive through PLC outputs.

If the speed code is changed, the NC sets the S strobe. If you acknowledge the S code with the marker defined in **MP\_acknowledge**, the NC program is continued and the S strobe is reset by the NC.

If required, the programmed spindle speed is rounded off to the next standard value by the NC and given in S code as per DIN 66025 (see the S-code table below).

Speeds of 0 to 9000 min<sup>-1</sup> are possible.

- ▶ Use the machine parameter **MP\_sCode** to define a symbolic name or the number of a word marker, in which the S code of the spindle speed is transmitted to the PLC.

### MP\_sCode

	Word marker for the coded output of the spindle speed Available from NCK software version: 597 110-03.
Format:	String
Input:	Max. 80 characters Enter the symbolic name (API 3.0) or the number of a word marker (API 1.0), to which the S code of the spindle speed is written. Example: <b>NP_WG_S_Code</b> (API 3.0) <b>W258</b> (API 1.0)
Default:	No value, parameter optional
Access:	LEVEL3
Reaction:	RESET





## S code table

S code	min <sup>-1</sup>
S 00	0
S 01	0.112
S 02	0.125
S 03	0.14
S 04	0.16
S 05	0.18
S 06	0.2
S 07	0.224
S 08	0.25
S 09	0.28
S 10	0.315
S 11	0.355
S 12	0.4
S 13	0.45
S 14	0.5
S 15	0.56
S 16	0.63
S 17	0.71
S 18	0.8
S 19	0.9
S 20	1
S 21	1.12
S 22	1.25
S 23	1.4
S 24	1.6
S 25	1.8
S 26	2
S 27	2.24
S 28	2.5
S 29	2.8
S 30	3.15
S 31	3.55
S 32	4
S 33	4.5
S 34	5
S 35	5.6
S 36	6.3
S 37	7.1
S 38	8
S 39	9
S 40	10

S code	min <sup>-1</sup>
S 41	11.2
S 42	12.5
S 43	14
S 44	16
S 45	18
S 46	20
S 47	22.4
S 48	25
S 49	28
S 50	31.5
S 51	35.5
S 52	40
S 53	45
S 54	50
S 55	56
S 56	63
S 57	71
S 58	80
S 59	90
S 60	100
S 61	112
S 62	125
S 63	140
S 64	160
S 65	180
S 66	200
S 67	224
S 68	250
S 69	280
S 70	315
S 71	355
S 72	400
S 73	450
S 74	500
S 75	560
S 76	630
S 77	710
S 78	800
S 79	900
S 80	1000
S 81	1120

S code	min <sup>-1</sup>
S 83	1400
S 84	1600
S 85	1800
S 86	2000
S 87	2240
S 88	2500
S 89	2800
S 90	3150
S 91	3550
S 92	4000
S 93	4500
S 94	5000
S 95	5600
S 96	6300
S 97	7100
S 98	8000
S 99	9000

## 8.8 T Functions (T Strobe)

T functions are channel-sensitive. T functions are configured in two steps:

- In the channel-sensitive parameter **MP\_tStrobes**, you define key names for the T functions. In this way, you assign the T functions to the machining channel.
- You configure the T functions in the parameter object **System/PLC/CfgPlcTStrobe**.

### 8.8.1 Assigning T functions to the machining channels

Settings in the configuration editor	MP number
Channel	
ChannelSettings	
[Key name of the channel]	
CfgPlcStrobes	
<b>tStrobes</b>	201603
<b>unitOfMeasure</b>	201605

#### MP\_tStrobes

T strobe description of this machining channel

Format: Array [0..18]

Input: Key name of the T strobes used in this machining channel

Default: [0]: ToolCall0  
[1]: ToolCall  
[2]: ToolDef

Access: LEVEL3

Reaction: RESET

In the marker defined in **MP\_unitOfMeasure**, the PLC is informed of the unit of measure used in the NC program when M, S, T or alias strobes are executed (see "MP\_unitOfMeasure" on page 1548).



## 8.8.2 Configuration of T functions

Settings in the configuration editor	MP number
System	
PLC	
CfgPlcTStrobe	
[Key name of S strobe]	
<b>type</b>	104101
<b>condition</b>	104102
<b>signal</b>	104103
<b>acknowledge</b>	104104
<b>toolNumber</b>	104105
<b>toolIndex</b>	104106
<b>toolMagazine</b>	104107
<b>pocketNumber</b>	104108
<b>unloadTool</b>	104109
<b>externalTool</b>	104110
<b>internalTool</b>	104111
<b>specialTool</b>	104112
<b>revoke</b>	104113
<b>singular</b>	104114
<b>blockSearch</b>	104115
<b>sync</b>	104116

### Transfer and acknowledgment of T function

**MP\_type** specifies the type of tool call.

Use the parameter **MP\_condition** to define the conditions for the output of the T strobe.

There are two possibilities for transferring the T strobe to the PLC and for acknowledgment by the PLC:

- Transfer and acknowledgment with **MP\_signal**
  - Transfer of the S strobe: The PLC marker defined in **MP\_signal** is set.
  - Acknowledgment of the S strobe: The PLC marker defined in **MP\_signal** is reset.
- Transfer with **MP\_signal** and acknowledgment with **MP\_acknowledge**:
  - Transfer of the S strobe: The PLC marker defined in **MP\_signal** is set.
  - Acknowledgment of the S strobe: The PLC marker defined in **MP\_acknowledge** is set.

HEIDENHAIN recommends that you only use **MP\_signal** for transfer and acknowledgment.

If **MP\_signal** and **MP\_acknowledge** are not defined, the data of the S strobe is saved without synchronization with the PLC program. The output is immediately acknowledged.

The NC transfers the other data for the tool call in the PLC words defined in the following parameters:

- MP\_toolNumber: Tool number (as specified in MP\_Aggregates/ToolMount/...)
- MP\_toolIndex: Number of the cutting edge if tools with several cutting edges are used
- MP\_toolMagazine: Reserved
- MP\_pocketNumber: Reserved

## Machine parameters

### MP\_type

Type of T function  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **T0**  
Remove tool from spindle  
**T1**  
Insert tool in spindle  
**T2**  
Prepare the next tool change

Default: –

Access: LEVEL3

Reaction: RESET

Parameter **MP\_condition** specifies, whether a tool number transferred with a T strobe is accompanied by a transfer of the strobe to the PLC program.

However, the configuration for a T1 strobe dominates the configuration for a T0 strobe if a real exchange (T1 and T0 together) of the tool takes place.

### MP\_condition

Condition for sending the strobe to the PLC  
Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **COND\_ALWAYS**  
Strobe is output with every programmed T code  
**COND\_ST**  
Strobe is output only if tool number changes  
**COND\_GP**  
Strobe is output only if pocket number changes  
If the parameter is missing from the configuration, the strobe is always output.

Default: COND\_ST

Access: LEVEL3

Reaction: RESET



### **MP\_signal**

Symbolic name or number of the PLC marker that is set when the function is decoded.

Format: String

Input: Max. 80 characters

If you have not entered a value in the parameter **MP\_acknowledge**, resetting this marker means an acknowledgment of the strobe.

No entry: The data connected with the output of the strobe is saved without synchronization with the PLC program and the output is immediately acknowledged.

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET

### **MP\_acknowledge**

Symbolic name or number of the PLC marker that is set for acknowledging the strobe.

Available from NCK software version: 597 110-02.

Format: String

Input: Max. 80 characters

No entry: The strobe is reset with the PLC marker entered in **MP\_signal**.

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET

### **MP\_toolNumber**

Symbolic name or number of the PLC word for transmitting the tool number

Available from NCK software version: 597 110-01.

Format: String

Input: Max. 80 characters

Name of the PLC word in which the tool number is transmitted to the PLC

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

### **MP\_toolIndex**

Symbolic name or number of the PLC word for transmitting the tool index  
Available from NCK software version: 597 110-01.

Format: String  
Input: Max. 80 characters  
Name of the PLC word in which the tool index is transmitted to the PLC

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### **MP\_toolMagazine**

Symbolic name or number of the PLC word for transmitting the magazine number of the tool  
Available from NCK software version: 597 110-01.

Format: String  
Input: Max. 80 characters  
Name of the PLC word in which the magazine number of the tool is transmitted to the PLC

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### **MP\_pocketNumber**

Symbolic name or number of the PLC word for transmitting the pocket number of the tool  
Available from NCK software version: 597 110-01.

Format: String  
Input: Name of the PLC word in which the pocket number of the tool is transmitted to the PLC

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET

### **MP\_unloadTool**

Symbolic name or number of the PLC marker that is set during decoding if no tool is loaded  
Available from NCK software version: 597 110-03.

Format: String  
Input: Max. 80 characters  
The definition of this marker is not necessary if the T0 and T1 strobes are otherwise distinguished.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: RESET



### **MP\_externalTool**

Symbolic name or number of the PLC marker that is set during decoding if a tool is loaded that is not in the magazine  
Available from NCK software version: 597 110-03.

Format: String

Input: Max. 80 characters

The definition of this marker is not necessary if the magazine and pocket numbers are evaluated elsewhere or are irrelevant.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

### **MP\_internalTool**

Symbolic name or number of the PLC marker that is set during decoding if a tool is loaded that is in the magazine  
Available from NCK software version: 597 110-03.

Format: String

Input: Max. 80 characters

The definition of this marker is not necessary if the magazine and pocket numbers are evaluated elsewhere or are irrelevant.

Default: No value, parameter optional

Access: LEVEL3

Reaction: RESET

### **MP\_specialTool**

Symbolic name or number of the PLC marker that is set during decoding if a special tool is loaded  
Available from NCK software version: 597 110-03.

Format: String

Input: Max. 80 characters

Default: The definition of this marker is not necessary if no special tools are used.

Access: LEVEL3

Reaction: RESET

In **MP\_singular**, the S codes that must be output in a separate strobe and must not be combined with other codes are defined.

### **MP\_singular**

Function is output in a separate strobe

Format: Selection menu

Selection: Use the parameter **MP\_singular** to prevent the function from being output in a strobe together with other functions.  
If several M, S, T functions are programmed in an NC block, the strobes can be set in parallel by the NC. With this parameter, you can exclude the current function from this parallel collection and simultaneous transmission in one strobe.

**TRUE**  
Function is output in a separate strobe. Combined output is prevented.

**FALSE**  
Function can be combined with other functions

Default: TRUE

Access: LEVEL3

Reaction: RESET

### **MP\_revoke**

Numbers of functions whose effect will be canceled by the output of the strobe.  
Available from NCK software version: 597 110-02.

Format: Array [0...19]

Input: 0 to 9999  
In the list, enter the numbers of the functions whose effect will be canceled when this code is output.  
Example – Configuration of function M5: Calling function M5 cancels the effect of functions M3 and M4. In this example, you would enter the key names of the functions M3 and M4.  
The parameter is effective for updating the status of the function in the status display and during block scan.

Note:  
S outputs for the same spindle as well as T outputs and T2 outputs always cancel each other. However, in some cases they may also cancel other M functions. M functions cannot cancel the effects of S, T and T2 outputs.  
If specific codes cancel each other, they cannot be combined in a strobe.

Default: No entry, value optional

Access: LEVEL3

Reaction: RESET





Parameter **MP\_blockSearch** is used to define the behavior of the S function during block scan:

### **MP\_blockSearch**

S function output during block scan  
Available from NCK software version: 597 110-02.

Format: Selection menu

Selection: **TRUE**  
S function is also output during block scan.  
**FALSE**  
S function is not output during block scan. The function is collected and restored.

Default: FALSE

Access: LEVEL3

Reaction: RESET

### **MP\_sync**

Synchronization of function with the NC

Format: Selection menu

Selection: **SYNC\_EXEC**  
The function is synchronized with program run. The output of movement by the interpolator is stopped; then the function is executed.  
Please note:  
After this function has been executed, the look-ahead calculation continues using the position values that were active **before** execution of the function. This setting is not suitable for M functions executing PLC positioning movements, for example.

**SYNC\_CALC**  
The function is synchronized with program calculation. The interpretation of the NC program is stopped and the path is calculated internally; then the function is executed. The M function is completely executed. After successful execution has been acknowledged, calculation continues with new position values.

**ASYNC**  
The function is output without synchronization.

Default: SYNC\_EXEC

Access: LEVEL3

Reaction: RESET

## 8.9 Alias Functions (Alias Strobe)

Alias functions are used to map control-specific functions on M functions.

In **CfgPlcStrobeAlias**, you can define channel-sensitive, but control-specific, functions. Alias functions are configured in two steps:

- In the channel-sensitive parameter **MP\_aliasStrobes**, you define key names for the functions. In this way, you assign the functions to the machining channel.
- In the parameter object **System/PLC/CfgPlcStrobeAlias**, you configure the functions.



### Note

The alias functions are mapped on M functions. In the parameter object **CfgPlcMStrobe**, you define the M functions used.

### 8.9.1 Assigning alias functions to the machining channels

Settings in the configuration editor	MP number
Channel	
ChannelSettings	
[Key name of the channel]	
CfgPlcStrobes	
<b>aliasStrobes</b>	201604
<b>unitOfMeasure</b>	201605

#### MP\_aliasStrobes

List of implemented strobes in this channel  
Available from NCK software version: 597 110-01.

Format: Array [0..18]

Input: Key names of the alias strobes used in this machining channel for the reproduction of control-dependent functions on a uniform M-function transfer to the PLC program.

Example: **GFUNC\_CH1**

Default: –

Access: LEVEL3

Reaction: RESET

In the marker defined in **MP\_unitOfMeasure**, the PLC is informed of the unit of measure used in the NC program when M, S, T or alias strobes are executed (see "MP\_unitOfMeasure" on page 1548).



## 8.9.2 Configuration of alias functions

Settings in the configuration editor	MP number
System	
PLC	
CfgPlcStrobeAlias	
[Key name of alias strobe]	
<b>type</b>	104201
<b>mCode</b>	104202
<b>mOffset</b>	104203

You define data exchange between the NC and the PLC in the parameter object **CfgPlcStrobeAlias**. The organization of this data exchange varies depending on the control and is described in more detail in the Chapter „Data Transfer NC => PLC, PLC => NC" on page 1654.

**MP\_type** specifies the type of call. In **MP\_mCode**, you specify the M function on which the alias function is to be mapped.

### MP\_type

Type of alias function

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **FN19 (not with MANUALplus 620)**

Two values are transmitted synchronously from the NC program to the PLC.

**FN29 (not with MANUALplus 620)**

Up to eight values are transmitted asynchronously from the NC program to the PLC.

**CYCLE13 (not with MANUALplus 620)**

Define spindle position for M19

TCHPROBE

Call measuring cycles

**GFUNCTION**

G functions are transmitted to the PLC. The G functions, including the function parameters, are transferred in an M strobe.

Default: FN19

Access: LEVEL3

Reaction: RESET

### **MP\_mCode**

Number of the M function  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: 0 to 9999  
Number of the M function for which the control-dependent function is mapped.

Default: 0  
Access: LEVEL3  
Reaction: RESET

If the GFUNCTION type is defined and **MP\_mOffset** = TRUE, the difference between the M functions and G functions is indicated by the entry **MP\_mCode** for the M strobe:

- Number in M strobe < Entry **MP\_mOffset**: M function is defined
- Number in M strobe > Entry **MP\_mOffset**: G function is defined

### **MP\_mOffset**

Transferred M code is offset  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: **TRUE**  
The first numerical value transferred is used as an offset and entered in the parameter MP\_min of the associated M function. The remaining numerical values are written to the double word entered in MP\_data.

**FALSE**  
No offset is used. The control always issues the M function given under MP\_min. Both transferred numerical values are written to the array of double words entered in MP\_data.

Default: FALSE  
Access: LEVEL3  
Reaction: RESET



## 8.10 Python Settings (Option 46)

Under System/PLC/PythonSettings you define general settings for software option 46 "Python OEM Process."

Settings in the configuration editor	MP number
System PLC PythonSettings Process CfgPythonScript [Key name of the Python script] <b>path</b> <b>jobName</b> <b>parameter</b> <b>memLimit</b>	      118303 118304 118301 118302
System Paths CfgPlcPath <b>pythonScripts</b>	   102315

Using **CfgPythonScript** you can specify a Python script that is to be started automatically during start-up of the MANUALplus 620. In this case, a PLC module call for starting the Python script is not required. The specified script is started automatically when the **Power Interrupted** message is acknowledged.

Proceed as follows to have a Python script started automatically during start-up:

- ▶ Place the cursor on **CfgPythonScript** and press the INSERT soft key.
- ▶ Enter a key name for the script (freely selectable) and specify the **\*.CFG** storage file.
- ▶ In **MP\_path**, **MP\_jobName**, **MP\_parameter** and **MP\_memLimit**, define the settings for calling the Python script.
- ▶ For the script to be started automatically during start-up, the key name defined in **CfgPythonScript** must be entered under System/Paths/CfgPlcPath/pythonScripts, see "MP\_pythonScripts" on page 1545.

### **MP\_path**

Path/name of the Python script  
Available from NCK software version: 597 110-05.

Format: String

Input: Max. 260 characters

Path/name of the Python script

The specified Python script is started when you press the soft key given in the key name.

Default: –

Access: LEVEL3

Reaction: RUN

### **MP\_jobName**

Name of the Python application

Available from NCK software version: 597 110-05.

Format: String

Input: Max. 17 characters

Specifies the name of the Python application. You can choose any name you want. The application will be displayed with this name, e.g. in the PLC process monitor.

Default: –

Access: LEVEL3

Reaction: RUN

### **MP\_parameter**

Calling parameters for the Python script

Available from NCK software version: 597 110-05.

Format: String

Input: Max. 127 characters

Specifies expanded calling parameters for the Python script.

Default: –

Access: LEVEL3

Reaction: RUN

### **MP\_memLimit**

Memory limit for the Python application

Available from NCK software version: 597 110-05.

Format: Numerical value

Input: Memory limit in megabytes [MB]

Default: –

Access: LEVEL3

Reaction: RUN



## MP\_runControl

Process monitoring

Available from NCK software version: 597 110-05.

Format: Selection menu

Selection: **None**

Every actuation of the soft key starts a new process of the script.

### **Restart**

A running process is ended and a new one started.

### **Once**

If a process of the script is already running, no further process is started.

Default: –

Access: LEVEL3

Reaction: RUN



### Note

For more information about Python, refer to the "Python in HEIDENHAIN Controls" supplement to the Technical Manual. Please contact HEIDENHAIN if you require a copy of this supplementary documentation.

## 8.11 User-Defined Cycles

### OEM cycles (G5xx)

With the MANUALplus 620 you can realize OEM cycles. The G functions G500 to G590 are intended for this purpose. When such G functions are called, corresponding subprograms named "\_G5xx.ncs" are used, which are saved in the **TNC:\nc\_prog\ncps** folder.

The following must be noted for the creation of OEM cycles:

- Dialogs are defined in the **PLC:\resource\formdlg\g\_oem.fdxml** file
- The dialog texts must be written in a selected language directly in the dialog description. Language-sensitive calls via a TextID are currently not yet possible
- The dialogs can be combined with images that are independent of any orientation. A separate image list containing all images of this function is defined for every G function at the beginning of the **g\_oem.fdxml** file. The image list also includes the paths to the storage locations of every image. In the default setting, the images are saved under **PLC:\resource\formdlg\WpE-dit\common\_gfkt\..**
- The formats already defined in the **PLC:\resource\formdlg\pformats.xml** file can be used for the parameters
- The following designations can be used for parameters G500...G590: **\_A, \_B, \_C, \_D, \_E, \_F, \_H, \_I, \_J, \_K, \_O, \_P, \_Q, \_R, \_S, \_T, \_U, \_V, \_W, \_X, \_Y, \_Z**
- It must be considered that the transfer value for **#\_X** is transferred divided by 2, as it usually is a diameter value.
- The following G5xx programs are predefined:
  - G593 – Feed rate per tooth for spindle 6
  - G595 – Feed rate per revolution for spindle 6
  - G596 – Constant cutting speed for spindle 6
  - G595 – Rotational speed for spindle 6

### PLC-G functions (G6xx)

In addition to the OEM cycles (G5xx), the PLC-G functions G602 to G699 can be defined with the MANUALplus 620. Unlike OEM cycles, the PLC-G functions do not require subprograms but are processed directly in the PLC.

The same rules as for the OEM cycles (see above) apply to the creation of dialogs with images.

The G functions G600 and G601 are reserved for tool preselection and tools from the magazine. The following parameters can be defined for G602...G699: **\_X, \_Y, \_Z, \_H, \_Q, \_C, \_F, \_S, \_T**



## 8.12 Tables

Different types of tables are managed in the control, such as motor tables, datum tables and tool tables.

Every table has its own structure. This means that the number of columns, the column designations, the dialogs for column entries, etc. vary depending on the table.

Each table type has certain characteristics. A table type is identified by its file extension, e.g. ".T" for tool tables. Tables with the same extension have the same characteristics.



### Note

Tables of different types, meaning tables with different extensions, are not compatible with each other. This means that you cannot copy tables from one extension to another, or simply change extensions.

Table characteristics are set in the configuration editor. The different table characteristics are defined in the configuration object **CfgTableProperties**, and the column characteristics in the configuration object **CfgColumnDescription**.

### 8.12.1 Table types of the MANUALplus 620

Different types of tables for different tasks are saved in the control as a standard feature. The functions of the individual tables, broken down by partitions, are described in the following.

#### User tables

User tables (**TNC:table**) primarily contain the parameters for tool management.

- The table **add\_cor1.hac** contains the tool-independent compensation values D901...D916. These compensation values are added to the active wear compensation values of the tools and are activated with G149. Switch-off is done with G149 D900, program cancelation or program end.
- The table **techdata.hte** contains the technology data based on the criteria of material, cutting material and machining mode. In its standard version, you can store the cutting data for 9 workpiece-material/tool-material combinations in the technology database. Each workpiece-material/tool-material combination includes the cutting speed, the main and secondary feed rates, and the infeed for 16 machining modes.
- The turret assignment table **ToolAllo.tch** depends on the machine configuration. HEIDENHAIN provides a configuration for a turret with 3\*12 pockets plus Multifix, which can also be used for smaller systems (e.g. turret with 1\*8 pockets). If the free T numbers in the tool carrier configuration changes, the turret assignment table also needs to be adjusted. The tools for the individual turret pockets can be selected from the tool table **toolturn.htt** simply by pressing a key.
- In the datum table **zero\_po1.hzp** the datums for all axes of a channel relative to the workpiece spindles and C axis are entered.

Table name	Group	Meaning
<b>add_cor1.hac</b>	USR	Additive compensations (D corrections)
<b>mach_dim.hmd</b>		Machine dimensions (not for MANUALplus 620)
<b>techdata.hte</b>		Technology data
<b>ToolAllo.tch</b>		Turret assignment table
<b>toolturn.htt</b>		Tool Table
<b>to_hold.hld</b>		Tool holder table (not for MANUALplus 620)
<b>to_text.mxt</b>		Tool texts
<b>zero_po1.hzp</b>		Datum table



## OEM tables

OEM tables are stored in the **PLC:\table** directory.

- The **axis\_c1.com**, **axis\_x1.com** and **axis\_z1.com** tables contain parameters for axis compensation and must be assigned explicitly to the individual axes in the **config.cma** table.
- Machining data is saved in the two following tables: The **ch\_pro.mch** table contains the values for the feed per minute and revolution (G94, G95) and the **sp\_pro.msp** table the values for the angle upon spindle stop (M19), for constant surface speed (G96), constant spindle speed (G97) and the speed limitation (G26). The data is entered into the table by the MMI and activated again after start-up of the control. The data is taken over in automatic mode in NC Stop condition.
- If motors are used whose parameters are not contained in the standard table (SYS:\table\MOTOR.MOT, write-protected), these can be entered in the table **MOTOR\_OEM.MOT**.
- The PLC error message table **plctestpgm.pet** is on the control for test purposes only. In shipping condition it is replaced by a freely selectable table or the **err\_tab.pet** error message table of the HEIDENHAIN PLC basic program (see "PET table (PLC error table)" on page 1268).
- To be able to access SQL tables from the NC program via a table number, the SQL tables are assigned numbers in the **SqlRef.hsh** table.

Table name	Group	Meaning
<b>axis_c1.com</b>	OEM	Axis compensation for C Axis
<b>axis_x1.com</b>		Axis compensation for X axis
<b>axis_z1.com</b>		Axis compensation for Z axis
<b>config.cma</b>		Compensation value table for all axes
<b>ch_pro.mch</b>		Current values for G94 and G95
<b>conv_oem.hco</b>		OEM conversion list for M Functions
<b>cool_cir.hcc</b>		Coolant (M functions for switching on and off a maximum of 8 coolant circuits)
<b>MOTOR_OEM.MOT</b>		Motor data (table is empty; default table on PLC:\table)
<b>PlcTestPgm.pet</b>		Test PLC error message table
pos_corr.hpc		Position compensations (not for MANUALplus 620)
<b>sp_pro.msp</b>		Current values for M19, G96, G97 and G26
<b>SqlRef.hsh</b>		Table numbering for table accesses from the NC program

## System tables

The write-protected directory **SYS:table** contains the control's system tables.

- In the **conv1.hc** table, converted G and M functions are assigned to the original G and M functions (e. G. for rear-side machining). The conversion list is assigned to a tool holder by entering the number of the conversion list in **MP\_convTbINr** (e.g. MP\_convTbINr = 1 for conv1.hc).
- The **inverter.inv** table contains important parameters of the power modules (see "Entries in the power module table (inverter.inv)" on page 1078).



### Note

The power module table of older HEIDENHAIN contouring controls, **motor.amp**, is no longer supported by the control!

- The **supply.spy** table contains important parameters of the supply modules (see "Entries in the power supply module table: (supply.spy)" on page 1077).
- **JhNcError.pet** error message table
- The HEIDENHAIN standard motor table, **MOTOR.MOT**, contains important motor parameters (see "Entries in the motor table (motor.mot)" on page 1078).

Table name	Group	Meaning
<b>conv1.hc</b>	SYS	Heidenhain conversion list for M and G functions
<b>inverter.inv</b>		Power module table
<b>JhNcError.pet</b>		PLC error message list
<b>MOTOR.MOT</b>		Motor data
simu.hsi		Colors, chucking equipment (not for MANUALplus 620)
<b>supply.spy</b>		Supply module table



## 8.12.2 Creating a new table type

Settings in the configuration editor	MP number
System	
Path	
CfgTablePath	
<b>path</b>	102501
CfgOemPath	
<b>oemTable</b>	102001
ProgramManager	
CfgFileType	
<b>unitOfMeasure</b>	102901
<b>standardEditor</b>	102902
<b>fileSize</b>	102903
<b>alternateEditor</b>	102904
<b>softkeyIcon</b>	102905
<b>softkeyIconVariant</b>	102906
<b>protect</b>	102907
TableSettings	
CfgTableProperties	
[Key name of the table]	105501
<b>columnKeys</b>	105502
<b>primaryKey</b>	
Columns	
[Key name of the table column]	
CfgColumnDescription	105601
<b>width</b>	105602
<b>unit</b>	105603
<b>initial</b>	105604
<b>minimum</b>	105605
<b>maximum</b>	105606
<b>charset</b>	105607
<b>unique</b>	105608
<b>readonly</b>	105609
<b>unitsInch</b>	
CfgColumnText	105701
dialogText	105701.501
<b>dialogRes</b>	105701.502
<b>text</b>	105701.503
<b>info</b>	105702
<b>softkeyIcon</b>	105703
<b>iconVariant</b>	105704
choice	
<b>value</b>	
dialog	
<b>dialogRes</b>	
<b>text</b>	
<b>info</b>	105705
lockValue	105705.401
<b>value</b>	105705.402
<b>dialog</b>	

Proceed as follows to create a new table type:

- ▶ Define a new file extension (System/ProgramManager/CfgFileType).
- ▶ Create a table configuration (System/TableSettings/CfgTableProperties).
- ▶ Create a column configuration (System/TableSettings/Columns).
- ▶ Create a new table using the file manager.
- ▶ Insert rows into the table with the table editor.

## Specifying the file extension

The extension determines the type of table. The following constraints apply:

- Maximum length of three characters
- Only numbers or capital letters are permitted (this means no blank spaces or special characters).
- Do not use extensions that are already used for other tables or files.  
In the configuration editor, under System/ProgramManager/CfgFileType and System/TableSettings/CfgTableProperties check whether the desired extension appears. The desired extension should not already appear here.

The new file extension must be entered in the configuration data so that a table with this extension can be opened by the table editor:

- ▶ Enter the code number 95148.
- ▶ Press the CONFIG DATA soft key.
- ▶ Select the object **System/ProgramManager/CfgFileType**.
- ▶ Press the INSERT soft key.
- ▶ Select **MP\_unitOfMeasure**.  
If you want to be able to choose if the table or file is to contain values in mm or in inches (specified by soft key when opening a new file), enter "UNIT\_MMINCH."
- ▶ Select **MP\_standardEditor**.  
Select the input value TABLE EDITOR.
- ▶ Activate the parameters **MP\_alternateEditor** and **MP\_fileSize** as optional parameters.  
**MP\_alternateEditor** defines an alternative editor for files whose size exceeds the size defined in **MP\_fileSize**.
- ▶ Activate the optional parameters **MP\_softkeyIcon** and **MP\_softkeyIconVariant**.  
An icon can be used instead of a text in the table editor if, in addition, the parameter **MP\_choice** (TableSettings/Columns/CfgColumnText) is defined.
- ▶ Optionally, use **MP\_protect** to protect the file type from editing.  
Disables filtering or editing of a file type.
- ▶ Save the information with the END or SAVE soft key.



### MP\_unitOfMeasure

Alternative unit of measure for file/table  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **UNIT\_INDEPENDENT**  
Input without unit of measure  
**UNIT\_MM**  
Input in mm  
**UNIT\_INCH**  
Input in inches  
**UNIT\_MMINCH**  
Input in mm or inches

Default: UNIT\_INDEPENDENT

Access: LEVEL3

Reaction: NOTHING

### MP\_standardEditor

Editor for file/table  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TEXT EDITOR**  
Opens the text editor of the control when a file is selected.  
**PROGRAM EDITOR**  
Opens the NC program editor of the control when a file is selected.  
**TABLE EDITOR**  
Opens the table editor of the control when a file is selected.  
**HELP VIEWER**  
Opens the HTML HELP VIEWER (Mozilla) of the control when a file is selected.  
**PATTERN EDITOR**  
Opens the point-pattern editor of the control when a file is selected.

Default: TEXT EDITOR

Access: LEVEL3

Reaction: NOTHING

### MP\_fileSize

File size from which the alternate editor (MP\_alternateEditor) is used  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: Value in kilobytes [KB] e.g. 100

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING

### **MP\_alternateEditor**

Alternate editor used for files starting from the size in  
MP\_fileSize  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TEXT EDITOR**  
ASCII editor of the control  
**PROGRAM EDITOR**  
NC program editor of the control  
**TABLE EDITOR**  
Table editor of the control

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING

### **MP\_softkeyIcon**

Path / file name of a soft-key icon  
Available from NCK software version: 597 110-01.

Format: String

Input: Max. 500 characters  
The path and file name of an icon may be used instead of a text.  
The icon is used for the generic soft key in the table editor if, in  
addition, the parameter **MP\_choice** (TableSettings/Columns/  
CfgColumnText) is defined.

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING

### **MP\_softkeyIconVariant**

Number of a soft-key-icon variant  
Available from NCK software version: 597 110-01.

Format: Numerical value

Input: 0 to 100  
A variant number can be entered in addition to the path and the  
file name defined in **MP\_softkeyIcon**.

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING





## MP\_protect

Disable file types  
Available from NCK software version: 597 110-04.

Format: Selection menu

Selection: **LOCK\_OFF**  
File type not locked  
**LOCK\_SOFTKEY**  
Lock the **SELECT TYPE** soft key for selection of the file type  
**LOCK\_FILETYPE**  
Lock file types from editing  
**LOCK\_ALL**  
Lock the **SELECT TYPE** soft key for selection of the file type and lock the file type to prevent editing

Default: LOCK\_OFF

Access: LEVEL3

Reaction: NOTHING

## Table description

Specify in the configuration editor which columns are used in a table.

- ▶ Enter the code number 95148.
- ▶ Press the CONFIG DATA soft key.
- ▶ Select the object **System/TableSettings/CfgTableProperties**.
- ▶ Press the INSERT soft key.
- ▶ Enter the extension of the new table;  
Specify the file (memory file) in which the configuration data are to be saved (normally PLC:\config\oemtable.cfg)
- ▶ Confirm with OK.
- ▶ Select **MP\_columnKeys**.
- ▶ Enter the first column name in the field [0];  
The name is in the following format: Tableextension.Columnname.  
The **column name** must not have any other periods, commas or special characters. Hyphens are permitted.  
For columns used with the same meaning in different tables, only the column name needs to be given. Examples of such columns are the columns predefined by HEIDENHAIN, such as **NAME** or **NR**.  
The table extension must always be entered in uppercase letters.
- ▶ Use the INSERT soft key to create more columns according to the above procedure.
- ▶ Confirm with OK.
- ▶ Select **MP\_primaryKey** and assign the column name (name from **MP\_columnKeys**).
- ▶ Confirm with OK.
- ▶ Press the SAVE soft key to save the data.

### **MP\_columnKeys**

List of column names  
Available from NCK software version: 597 110-01.

Format: Array [0...]  
Input: xxx.xxx  
Name of the column in uppercase letters in the format <table extension>.<column name>;  
Max. 20 characters

Default: -  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_primaryKey**

Name of the column, based upon which the data is sorted in ascending order  
Available from NCK software version: 597 110-01.

Format: String  
Input: <Column name>  
Max. 18 characters  
Name of the column must also be entered in **MP\_columnKeys**.

Default: -  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_foreignKey**

Specify a character string of the type <column name><blank><referential action> for each list item.

Format: Array [1...79]  
Input: Valid values for <referential action> are NO ACTION, RESTRICT, SET NULL, SET DEFAULT and INHERIT.  
Max. 40 characters

Default: -  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_modificationKey**

Enter the key name of the column in which the timestamp is to be entered if the line is modified

Format: String  
Input: <Table extension>.<column name>;  
Max. 18 characters

Default: -  
Access: LEVEL3  
Reaction: NOTHING



**Column description** Description of the individual columns takes place in the configuration editor.

- ▶ Enter the code number 95148.
- ▶ Press the CONFIG DATA soft key.
- ▶ Select the object **System/TableSettings/Columns.**
- ▶ Press the INSERT soft key.
- ▶ Enter the name of the new column (see column name under table description). Add the extension as a prefix to the column name ([extension].[column]) if you want to assign the new column to a specific table type. For example: **TAB.POS1**
- ▶ Select the object **System/TableSettings/Columns/CfgColumnDescription.**
- ▶ Press the INSERT soft key; confirm the suggestion with OK.
- ▶ Select **MP\_width**; enter the max. column width (number of characters).
- ▶ Select **MP\_unit**; enter the unit of measurement.
- ▶ Select **MP\_initial** (optional parameter); enter the default value.
- ▶ Select **MP\_minimum**; enter the minimum value for numerical values.
- ▶ Select **MP\_maximum**; enter the maximum value for numerical values.



#### Note

It is essential that you enter the minimum and maximum values!

- ▶ Select **MP\_charset** (optional parameters); defines the number of permissible characters. If the number is not defined, all characters are allowed.
- ▶ Select **MP\_unique** (optional parameter); insert this parameter if the column is to contain unambiguous values. If the attribute is not defined, the same values may appear more than once in different rows.
- ▶ Select **MP\_readonly**; protect data from access; The column representing the "primaryKey" of the table should be write-protected (set MP\_readonly to TRUE).
- ▶ Select **MP\_unitInch**; specify the unit of measurement.
- ▶ Select **MP\_choice** (optional);  
A list of value/text pairs can be defined here. Only these texts are then available in the table via a selection list (in the **Programming** mode of operation, the COLUMN NAME soft key opens the selection list). This stands for a value, which is then displayed. The text for the selection list can be entered directly (MP\_text), or you can enter a link to a dialog table (MP\_dialogRes).
- ▶ Select **MP\_value** (optional); enter the value for MP\_dialog.
- ▶ Select **MP\_dialog** (optional);
- ▶ Select **MP\_dialogRes** (optional); leave the attribute empty if the text is not to be language-sensitive.
- ▶ Select **MP\_text** (optional); enter the text for MP\_value.  
(keep MP\_width in mind)

- ▶ Select **MP\_lockValue** (optional);  
If the value entered in the column equals the value given here, the text in MP\_text is displayed. It can no longer be edited. This way editing can be disabled depending on the value.
- ▶ Select **MP\_value** (optional); enter the value for MP\_dialog.
- ▶ Select **MP\_dialog** (optional);
- ▶ (MP\_dialogRes in preparation);
- ▶ Select **MP\_text** (optional); enter the text for MP\_value.  
(keep MP\_width in mind)
- ▶ Select **CfgColumnText**; enter the dialog text for the columns.
- ▶ Carry out the above procedure for all new columns, and save the information with the SAVE soft key.

The following machine parameters are used for defining the columns.

### **MP\_width**

	Column width
	Available from NCK software version: 597 110-01.
Format:	Numerical value
Input:	2 to 50 (column width of max. 50 characters)
Default:	2
Access:	LEVEL3
Reaction:	NOTHING



**MP\_unit**

Data type of values in the column

Available from NCK software version: 597 110-01.

Format:

Selection menu

Selection:

**TEXT**

Text entry

**SIGN**

Algebraic sign + or –

**BIN**

Binary number

**DEC**

Decimal, positive, whole number  
(cardinal number)

**HEX**

Hexadecimal number

**INT**

Whole number

**LENGTH**

Length

**FEED**

Feed rate (mm/min or 0.1 ipm)

**IFEED**

Feed rate (mm/min or ipm)

**FEED\_CUT**

Cutting speed in m/min or feet/min

**FEED\_ROT**

Feed rate in mm/revolution or inch/revolution

**FLOAT**

Floating-point number

**BOOL**

Logical value

**INDEX**

Index with subindices

**TSTAMP**

Time/Date

Default:

TEXT

Access:

LEVEL3

Reaction:

NOTHING

## MP\_initial

Value automatically entered in a column when a new table is created (optional).

Available from NCK software version: 597 110-01.

Format: String

Input: Max. 50 characters

NULL: No default value. This column may be left blank.

Value: Default value. When a new row is inserted, this value is assigned as a default to the column.

If a default value other than NULL is given, then a valid value must always be entered in the column.

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING

With **MP\_minimum** and **MP\_maximum** you define the permissible input ranges for the table column. Depending on the unit of measure selected in **MP\_unit**, the following maximum input values are permitted:

Unit of measure MP_unit	Limit value MP_minimum	Limit value MP_maximum	Remark
INT	-2147483647	+2147483646	If no input range is configured, the following range applies: -999999999 to +999999999
BIN	%00000000	%11111111	
DEC	0	999999999	
INDEX	0	999999999	
HEX	\$0	\$FFFFFFF	
LENGTH	-999999999	+999999999	
FEED	-999999999	+999999999	
IFEED	-999999999	+999999999	
FLOAT	-999999999	+999999999	
FEED_CUT	-999999999	+999999999	
FEED_ROT	-999999999	+999999999	



### Note

The input range is additionally limited by the actual (or configured) column width (**MP\_width**).

### MP\_minimum

Smallest permissible input value  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: Max. 50 characters  
e.g.: -99999.9999

The minimum value is considered only for the columns with numerical values or logical values. It defines the smallest permissible numerical input value or the text representing the logical value FALSE. For values of the FLOAT, FEED, IFEED or LENGTH data types, the given number of decimal places determines the number of decimal places used for values in this column, e.g. 0.001 means 3 decimal places.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

### MP\_maximum

Largest permissible input value  
Available from NCK software version: 597 110-01.

Format: Numerical value  
Input: Max. 50 characters  
e.g.: 99999.9999

The maximum value is considered only for the columns with numerical values or logical values. It defines the largest permissible numerical input value or the text representing the logical value TRUE. For values of the FLOAT, FEED, IFEED or LENGTH data types, the given number of decimal places determines the number of decimal places used for values in this column, e.g. 300.000 means 3 decimal places.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

### MP\_charset

Number of permissible characters for columns with text (optional)  
Available from NCK software version: 597 110-01.

Format: String  
Input: Max. 224 characters

The number of permissible characters is evaluated only for text columns (**MP\_unit** = TEXT). If this parameter is not defined, all characters are allowed; otherwise, only the characters listed here are allowed.

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

### MP\_unique

Defines whether only unambiguous values are allowed in the column (optional)

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **FALSE**

Values may occur more than once

**TRUE**

Only unambiguous values allowed

Default: No value, parameter optional (= FALSE)

Access: LEVEL3

Reaction: NOTHING

### MP\_readonly

Write protection on column entry

If the attribute is set to TRUE, the value assigned when inserting the line cannot be changed. If the attribute is not set or set to FALSE, values may be overwritten.

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **FALSE**

Values may be overwritten

**TRUE**

Values are write-protected

Default: No value, parameter optional (= FALSE)

Access: LEVEL3

Reaction: NOTHING

### MP\_unitsInch

Values in inches (optional)

If lengths and feed rates are to be specified in the column in a definite unit of measure, enter TRUE here for values in inches and FALSE for values in mm. If the parameter is not set, the unit of measure is taken from the corresponding table.

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **FALSE**

Column entry in mm

**TRUE**

Column entry in inches

Default: No value, parameter optional

Access: LEVEL3

Reaction: NOTHING

If, in the table editor, you want to display language-sensitive texts for columns, you must insert a CfgColumnText data object. However, this object is not absolutely necessary. If the object is missing, the column name is shown in the dialog line in the table editor. When inserting, the same column name must be given as in CfgColumnDescriptor.



### 8.12.3 Defining the path for OEM tables

Use the machine parameter `MP_oemTable` to define the path for OEM tables. OEM tables include tables such as the `*.CMA` and `*.COM` compensation-value tables for axis-error compensation or the `*.MOT` OEM motor table. With **MP\_oemTable**, you inform the control about the location where the OEM tables are stored. The default setting `%OEM%\table` is entered in the parameter.

#### **MP\_oemTable**

	Path for OEM tables
	Available from NCK software version: 597 110-01.
Format:	String
Input:	Max. 260 characters
Default:	<code>%OEM%\table</code>
Access:	LEVEL3
Reaction:	RESET

### 8.12.4 Symbolic names for tables

For access via SQL commands, tables are identified with a symbolic name and a file name including the path for the table characteristics.

Direct use of these paths, such as from cycles, has the disadvantage that if the drives or paths are changed, or if other tables are selected, the cycles must be changed.

In order to avoid this disadvantage, symbolic table names are used. These table names are place holders for the actual table name and path. When accessing a table, the control replaces the symbolic table name with the real table path and name.

Symbolic table names are saved in the control's configuration data in the **CfgTablePath** object (new key name). A symbolic table name should consist only of capital letters.

The logic names do not have to be in any certain format. Any name can refer to any table or table type.

The table being referenced does not even have to exist at the time that the logic table name is given. It can also be created afterwards.

Proceed as follows for specifying a symbolic table name:

- ▶ Enter the code number 95148.
- ▶ Press the **CONFIG DATA** soft key.
- ▶ Select the **System/Paths/CfgTablePath** object.
- ▶ Press the **INSERT** soft key.
- ▶ Enter the symbolic table name (key name) and the storage file (e.g. the file **PLC:\config\oemtable.cfg**) and confirm with **OK**.
- ▶ Define the storage location of the table in **MP\_path**.
- ▶ Press the **SAVE** soft key to save the data.

**MP\_path**

Path for tables  
Available from NCK software version: 597 110-01.

Format: String

Input: Max. 80 characters  
Path/name consisting of device name, up to 6 directories, file name and extension  
Example:  
**%USR%\table\tool.t**

Default: -

Access: LEVEL3

Reaction: NOTHING

**8.12.5 Editing tables via the PLC**

You can also read tables and overwrite individual fields via PLC modules.

**Note**

The following modules must be called in a submit job or spawn job.  
When entering the column names, pay attention to the case of the letters (whether they are small or capital).

Access via PLC module to the tables of the system partition is read-only!

**Module 9240 Open a file**

The module opens the file for access via the PLC. The "file handle" is created. This is a number which must be given for each subsequent access (such as in another PLC module).

Files should not be kept open unnecessarily, since they cannot be erased by the file manager during this time.

Ending a process (EM in a submit job) also closes all files opened by the process. The same applies if a process is canceled by a CAN instruction or by a renewed compiling of the PLC program.

The file handle must be saved in a double word.

Up to eight files may be open at once. However, the file can only be accessed by the process that opened it (SUBMIT job or SPAWN job). A file can also be opened more than once. If you want to prevent the file from being opened by more than one process, use the "lock file" mode.

To maintain a high processing speed, the file should be opened with the "BUFFERED" option for reading and writing ASCII texts. In this mode a part of the file is buffered in the main memory. This mode is not permitted for tables.



To append data to an existing file, set bit 0 = 1 (reading and writing) **and** bit 2 = 0 (record oriented).

Call:

```
PS    B/W/D/K <Mode>
      Bit#0 = 0: Read only
      Bit#0=1: Read and write
      Bit#1=0: Do not lock file
      Bit#1 = 1: Lock file
      Bit#2 = 0: Record oriented (for tables)
      Bit#2 = 1: Buffered (for ASCII files)
PS    B/W/D/K/S<String with file name>
      Complete path, file name and extension
CM    9240
PL    D      <File handle>
      Number for use in other modules
      -1: Error code in NN_GenApiModuleErrorCode (W1022)
```

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModuleErrorCode (W1022)	1	Impermissible mode
	3	Incorrect string number
	7	File could not be opened
	20	Module was not called in a spawn or submit job

**Module 9241 Close a file**

With this module you close a file that has been opened with Module 9240. You must close the file in the process (submit job or spawn job) in which you opened it.

Call:

```
PS    D      <File handle>
      Number from Module 9240
CM    9241
```

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModuleError (M4203)	0	File was closed
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModuleError (W1022)	2	Incorrect file handle
	20	Module was not called in a spawn or submit job



### Module 9242 Position in a file

With this module you change the position of the cursor in a file opened with Module 9240. The new position is provided as result from Module 9242.

If the file was opened in the "record oriented" mode (tables), the cursor is positioned line by line.

If the file was opened in the "buffered" mode, the cursor is positioned character by character.

If you indicate a position before the beginning or after the end of the file, the cursor is positioned to the beginning or end of the file, respectively. The addressing of the new position is relative to the beginning or end of the file, or to the current position. You can interrogate the current position by transferring the position value zero relative to the current position.

Call only in a submit job or spawn job.

Call:

```
PS    D           <File handle>
        Number from Module 9240
PS    B/W/D/K    <Desired position>
PS    B/W/D/K    <Mode>
        0: Position relative to the file beginning
        1: Position relative to the current position
        2: Position relative to the file end
CM    9242
PL    B/W/D/K    <New position>
        -1: Error code in NN_GenApiModuleErrorCode (W1022)
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule ErrorCode (W1022)	1	Impermissible mode
	2	Incorrect file handle
	7	File system error
	20	Module was not called in a spawn job or submit job



### Module 9243 Read from an ASCII file line by line

To read from a table, use Module 9245.

The module reads a line from the ASCII file opened with Module 9240,

and writes it to a PLC string.

Different processing times will result depending on whether you opened the file with the "buffered" option (buffered is faster).

The module reads up to a line break (line feed, '\n'), but not more than 127 characters. The line break is not saved in the result string, but is counted for the number of characters read.

The result is undefined when reading non-ASCII-coded files.

A certain amount of binary data is saved in the target string, but cannot be used.

Call:

```
PS   D      <File handle>
      Number from Module 9240
PS   B/W/D/K <String number with result>
      0 to 7
CM   9243
PL   B/W/D   <Number of read bytes>
      >0: Line has been read
      0: File end has been reached
      -1: Error code in NN_GenApiModuleErrorCode (W1022)
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule ErrorCode (W1022)	2	Incorrect file handle
	3	Incorrect string number
	7	File system error
	20	Module was not called in a spawn job or submit job



### Module 9244 Write to an ASCII file line by line

To write to a table, use Module 9246.

The module writes a line from a PLC string to an ASCII file already opened by Module 9240 in "buffered" mode.

If file is opened in "buffered" mode:

- Processing time is shorter.
- Files are saved to the hard disk only if more than 512 bytes are overwritten in several calls, or if the file is closed.
- The number of data specified in the transfer string is overwritten.

If file is opened in "record oriented" mode:

- Processing time is longer.
- The data is immediately saved to the hard disk.
- Exactly one line is overwritten. If there is a difference in length, the subsequent data is displaced by the difference.

Call:

```
PS   D           <File handle>
      Number from Module 9240
PS   B/W/D/K/S<String number, source data>
      0 to 7
CM   9244
PL   B/W/D       <Number of written bytes (including LF)>
      -1: Error code in NN_GenApiModuleErrorCode (W1022)
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule ErrorCode (W1022)	2	Incorrect file handle
	3	Incorrect string number
	7	File system error
	20	Module was not called in a spawn job or submit job



### Module 9245 Read a field from a table

The module reads a data field from a table opened before by Module 9240 in "record-oriented" mode into a string. The data field is addressed by the field name and the line number.

To maintain a high processing speed, multiple lines should be read in ascending order.

Pay attention to the upper/lower case of field names.

If an error occurs, the content of the target string is undefined.

The module provides the contents as a string.

Call:

```
PS   D           <File handle>
      from Module 9240
PS   B/W/D/K <Line>
      0 to 65 535
PS   B/W/D/K/S<String number, column name>
      0 to 15
PS   B/W/D/K/S<String number, result>
      0 to 15
CM   9245
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Field was read
	1	Error code in W1022
NN_GenApiModule ErrorCode (W1022)	1	Line does not exist in table
	2	Incorrect "file handle" or table was opened in "buffered" mode
	3	Impermissible string numbers
	7	The table could not be read from
	20	Module was not called in a spawn job or submit job
	29	The opened file is not a table (extension .TAB, .P)
30	Column name not found	



### Module 9246 Write to a field in a table

The module writes a string to a data field in a table opened by Module 9240 in "record-oriented" mode. The data field is addressed by the field name and the line number.

To maintain a high processing speed, multiple lines should be written in ascending order.

Pay attention to the upper/lower case of field names.

The field defined by the column name and line number is overwritten.

The module transfers a string.

Call:

```
PS   D           <File handle>
      from Module 9240
PS   B/W/D/K   <Line>
      0 to 65 535
PS   B/W/D/K/S<String number, column name>
      0 to 15
PS   B/W/D/K/S<String number, contents to be written>
      0 to 15
CM   9246
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Field was written to
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Line does not exist in table
	2	Incorrect "file handle" or table was opened in "buffered" mode
	3	Impermissible string numbers
	6	Table is write-protected
	7	Not a numerical field (Module 9256)
	11	The transferred value cannot be saved to the addressed field. Incorrect format
	20	Module was not called in a spawn or submit job
	29	Opened file is not of the .TAB or .P type.
30	Column name not found	





### Module 9247 Search for a condition in a table

In a table opened by Module 9240 in "record-oriented" mode, the function searches for a data record which fulfills one or more conditions. The conditions are formulated with a subgroup of the System Query Language (SQL) database language.

Pay attention to the case of the letters (whether they are small or capital) in the commands and column names.

If you indicate a starting line, the module can search for several suitable field entries.

Permissible SQL commands:

Command	Meaning
+, -, *, /	Arithmetic operators
NOT, AND, OR	Logical operators
<, >, <=, >=, ==, <>	Comparisons
LIKE 'abc'	Text comparison
LIKE '_abc%'	Partial string
()	Parentheses
MIN(column name)	Minimal value from the column
MAX(column name)	Maximum value from the column

Example:

Search a table for the line with the NC program 1.nc and the set datum X=-10.  
String contents:

```
WHERE (PAL/PGM LIKE 'PGM') AND (NAME LIKE '1.nc') AND (X=-10)
```

Call:

```
PS   D           <File handle>
      from Module 9240
PS   B/W/D/K     <Starting line>
      0 to 65 535
PS   B/W/D/K/S   <String number of condition or string with condition>
      0 to 7
CM   9247
PL   B/W/D       <Line that fulfills the condition>
      -1: Error code in NN_GenApiModuleErrorCode (W1022)
```

**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule ErrorCode (W1022)	1	Start line does not exist in table
	2	Incorrect "file handle" or table was opened in "buffered" mode
	3	Impermissible string numbers
	7	Module could not be read from the table
	20	Module was not called in a spawn job or submit job
	29	Incorrect file format
	30	Column name not found
	31	Syntax error in the transferred condition
	32	No data record found that fulfills the condition

**Module 9249 Read and reset "errno"**

This function reads the error status "errno" of the operating and file system, and resets this status to 0. This status can be used for more accurate determination of the errors in certain modules (e.g. 9240, 9242, 9243, 9244).

**Constraints:**

- "errno" always contains the code of the most recent error. The variable is only cleared with Module 9249.
- "errno" is only valid within a PLC process (SUBMIT job), and is separately present for each process.
- The definitions of the C programming language (UNIX compatible) as well as specific expansions by HEIDENHAIN are valid for the contents of "errno." A separate documentation exists for this.
- In order to use "errno" to see if an error has occurred, the module must be called before a program sequence in order to clear the contents of "errno."

Call:

```
CM  9249
PL  W/D    <errno>
```





**Error recognition:**

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Editor was opened
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	<ul style="list-style-type: none"> <li>– Invalid values for the strings for file name and field name were transferred</li> <li>– The range defined by the entries for first and last line is not logical. Possibilities include start&gt;end, or start after file end, or the given file is an empty document, or the start and/or end contain negative values.</li> <li>– Values for additional parameters were given, which is not permitted in this context, or options which are only intended for complete files were activated for a partial file (not all lines/columns)</li> </ul>
	6	A write-protected file cannot be opened with transferred write-protection (bit 3).
	7	The given file cannot be read from, or the temporary file cannot be created.
	8	The module was called during an NC operating mode in which the table editor cannot be started.
	20	The module was called from the cyclic program part.
	28	A file has already been opened by the PLC for editing
	29	The given file does not exist or is not of the type .TAB or .P.
	30	The given field names do not exist in the given file.
36	An invalid file name or file type was programmed.	



### Module 9251 Exit table editor of the PLC

The module ends the PLC's table editor, which had been started with Module 9250. Select whether the changed data are to be assumed in the original file, or whether the editor is closed without updating.

#### Constraints:

- The editor must have been started with Module 9250, and the file SYS:\TEMP\PLCTABED.TDB must have been created. The contents of this file are inserted into the original file given in the call for Module 9250.
- Only the lines and columns contained in the temporary file are inserted. All other lines and columns in the original file remain unchanged.
- The entered values are not checked. The PLC can automatically read and check the temporary file beforehand.
- The temporary file must not be open by the PLC at the time the module is called, because it cannot be deleted then. Calling Module 9250 again could then fail.

Call:

PS B/W/D/K <Store changes>  
(0 = no, 1 = yes)

CM 9251

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Editor was exited
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	3	An incorrect value was entered for the "Store changes" parameter.
	6	The changes could not be stored in the original file. See "errno" for the cause.
	20	The module was called from the cyclic program part.
	28	No editor had been opened with Module 9250.

### Module 9252 Position the cursor in the PLC table editor.

The module moves the input field in the PLC table editor to a certain line and column.

#### Constraints:

- The PLC table editor must have been opened with Module 9250.
- The specified field must be contained in the group of fields to be edited from Module 9250.
- The line for positioning must be defined relative to the created temporary file, starting from line 0, meaning that it might be necessary to deduct a start line defined with Module 9250 from the line in the original file.

Call:

PS B/W/D/K/S<Field name>  
(string number 0..3 or constant string)

PS B/W/D/K <Line>  
(relative to the temporary file)

CM 9252

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Cursor was set
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	The given line is not contained in the file being edited.
	3	An invalid value was transferred for the string of the field name.
	20	The module was called from the cyclic program part.
	28	No editor had been opened with Module 9250.
	30	The given field name does not exist in the given file.



### Module 9255 Read a field from a table

The module reads a data field from a table opened by Module 9240 in "record-oriented" mode as an integer value. The data field is addressed by the field name and the line number.

To maintain a high processing speed, multiple lines should be read in ascending order.

Pay attention to the upper/lower case of field names.

If an error occurs, the number value of the result is undefined.

The function can only be used on fields containing numerical values.

If digits can be entered after the decimal point in the selected field, the numerical value is standardized to the last digit after the decimal point, meaning that for n digits after the decimal point, the value is multiplied by  $10^n$ .

Call:

```
PS   D           <File handle>
      from Module 9240
PS   B/W/D/K     <Line>
      0 to 65 535
PS   B/W/D/K/S  <String number, column name>
      0 to 15
CM   9255
PL   B/W/D     <Result>
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Field was read
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Line does not exist in table
	2	Incorrect "file handle" or table was opened in "buffered" mode
	3	Impermissible string numbers
	7	The table could not be read from
	20	Module was not called in a spawn job or submit job
	29	The opened file is not a table (extension .TAB, .P)
	30	Column name not found

### Module 9256 Write to a field in a table

The module writes an integer value to a data field in a table opened by Module 9240 in "record-oriented" mode. The data field is addressed by the field name and the line number.

The field defined by the column name and line number is overwritten.

Constraints:

- The file must not have been opened by Module 9240 in "buffered" mode.
- Only files of the type .TAB (freely definable tables) and .P (pallet tables) are permitted.
- To maintain a high processing speed, multiple lines should be written in ascending order.
- Pay attention to the upper/lower case of field names.
- Only fields defined for numerical values can be written to.
- If digits can be entered after the decimal point in the selected field, the numerical value is standardized to the last digit after the decimal point, meaning that for n digits after the decimal point, the value is divided by  $10^n$ .

Call:

```
PS   D           <File handle>
                        from Module 9240
PS   B/W/D/K   <Line>
                        0 to 65 535
PS   B/W/D/K/S<String number, column name>
                        0 to 15
PS   B/W/D/K   <Numerical value to be written>
CM   9256
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Field was written to
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Line does not exist in table
	2	Incorrect "file handle" or table was opened in "buffered" mode
	3	Impermissible string numbers
	6	Table is write-protected
	7	Not a numerical field (Module 9256)
	11	The transferred value cannot be saved to the addressed field. Incorrect format
	20	Module was not called in a spawn or submit job
	29	Opened file is not of the .TAB or .P type.
30	Column name not found	





## 8.12.6 Access to tables via SQL commands

The NC software accesses the tables via a server. Accesses from the NC program, the PLC program and the editor are synchronized with each other, and locked against each other. This server is controlled with SQL commands.

The server is based on a transaction model which performs read or write operations for more than one row or column in such a way that they cannot be interrupted by other read or write operations.

A transaction consists of the following steps

- Selecting data
- Reading data
- Editing data (if required)
- Confirming or rejecting the changes

### Selecting the data

To select data, use the SQL statement **SELECT**. The SELECT statement finds the columns of the rows of a table, which satisfy the entered **WHERE** condition.

The table is usually designated by a synonym. These synonyms are configuration data which can also be created, assigned and deleted via the SQL server. In addition, you can specify a table by using its path name, provided that you enclose the path name in single quotation marks.

The result of the query is a result set which is created and managed by the SQL server. The SQL server assigns a **handle** to the result set, which enables you to identify the result set for reading/editing data and completing the transaction. The handle is the result of the query, which is visible in the NC program. The value 0 indicates an invalid handle, i.e. it was not possible to create a result set for that query. If no rows that satisfy the specified condition are found, an empty result set is created and assigned a valid handle.

The ORDER BY function sorts the rows in the result set according to the values of a column in increasing or decreasing order. The row numbers in the result set are listed in increasing order and are not related to the row numbers in the table file.

You can create a dynamic query, for example, by replacing the comparison value in the **WHERE** condition with a reference to a Q parameter. To do this, program a colon (:) instead of the value and enclose the Q parameter in single quotation marks (e.g. 'Q2'). During interpretation this expression is replaced by the current content of the Q parameter.

The **FOR UPDATE** function locks the selected rows for the duration of the transaction. As a result, third parties can only read the data, but cannot edit them. However, this query cannot be executed if it is to access data that have already been locked.

## Reading data

In order to read the selected data, use **SQL BIND** to bind the data of a column to a parameter that accesses the data from the NC program.

The data can be bound to a Q parameter (e.g. **SQL BIND Q5 'TOOL.L'**) or directly to a system datum of the interpreter (e.g.

**SQL SYSBIND ID350 NR52 IDX 1 'PROBE.L'**). When a row is read, the content of the respective columns is stored in the bound parameter. To cancel the binding, it must be programmed again without specifying a column. The bindings are globally effective and must be canceled explicitly. The bindings must be unambiguous. The attempt to bind more than one parameter to a column will fail.

Use **SQL FETCH** to read the data of the result row by row. The result set is identified by the indicated **handle**. It is therefore possible to read various result sets alternately. An index in the range from 0 to n can be defined for the result-set row to be read. If no index is specified, the first row is read. The result of the function is 0 if data was read and stored in the bound parameters. The result of the function does not equal 0 if no data was read.

## Editing data

If you want to edit data, you first have to edit the data in the bound parameters. The **SQL UPDATE** command, copies the data into the result set which is identified by the **handle**. An index in the range from 0 to n can be defined for the result-set row to be written. If no index is specified, the first row is edited. The result of the function is 0 if the data have correctly been transferred to the result set. The result of the function is not 0 if an error occurred during transfer.

Afterwards the changes are only visible within the edited result set. If you reread the edited row, the edited data are shown; if you enter a new query and reread the row, the original data will be shown. Third parties will still see the original data. The data is not transferred to the table until the transaction has been concluded. Thus it is possible to edit more than one row in a consistent manner in one transaction.



## Concluding the transaction

Be sure to conclude every transaction. This way the resources assigned in the SQL server are released for the result set.

After concluding the transaction with **SQL COMMIT**, all changes are transferred from the result set into the table.

To cancel all changes, conclude the transaction with **SQL ROLLBACK**.

Once transferred, these changes cannot be undone. After the transaction has been completed, the rows locked during the selection are unlocked.

The transaction to be completed is identified by the **handle**. After the transaction has been completed successfully, the **handle** becomes invalid and cannot be used for accessing data any longer.

The result of the **SQL COMMIT** function will not be 0 if the edited data could not be transferred into the table file. This happens when edited rows were not locked during the selection and are locked by third parties at the time of commitment. The SQL server first checks whether all edited rows may be rewritten before it transfers the first change. The isolation of accesses ensures that the effects of the transaction are invisible to others until the transaction is committed. It may, however, happen that errors occur while a file is being accessed.

The **SQL ROLLBACK** function enables you to remove all rows, except for the indicated row, from the result set by defining an index. As a result, the changes made to the removed rows are canceled. This is especially useful if you first select and, as a consequence, lock more than one row, but then decide that you want to edit only one row. The other rows can then immediately be released. The handle remains effective until the transaction has been completed for all rows. If no index or an invalid index has been defined, the entire transaction is completed. The result of the function does not equal 0 if an error has occurred.

## Reference for syntax elements

### BNF notation

The following specifies the individual syntax elements in BNF notation. The individual NC blocks are listed in alphabetical order.

A specified syntax element is identified by a name in italics.

Individual characters are enclosed in single quotation marks; entire code words are plain text and are not enclosed in single quotation marks.

A single simple expression is enclosed in square brackets [ ], whereas a multiple expression is enclosed in braces { }. Two expressions separated by the "|" symbol indicate alternative options.

Expressions may contain letters, numbers, and symbols.

- uppercase := 'A'...'Z'
- lowercase := 'a'...'z'
- digit := '0'...'9'
- index := digit { digit }
- number := [ '+' | '-' ] digit { digit } [ '.' digit { digit }
- literal := "'" { uppercase | lowercase | digit | symbol } "'"
- name := uppercase { uppercase | lowercase | digit | '\$' | '#' | '\_' }

### Context elements

The following elements can only occur within the context of an NC block.

### Q parameters

A Q parameter can be addressed directly or indirectly via another Q parameter.

- q-number := Q index
- q-reference := Q REF Q index
- q-parameter := q-number | q-reference

### SQL parameters

Q parameters and system parameters can be bound to the column name of a table.

Definition

- system-group := ID index
- system-number := NR index
- system-index := IDX index
- system-parameter := system-group system-number system-index
- sql-parameter := q-parameter | system-parameter



## SQL-HANDLE

The SQL handle identifies the result set of a previous SQL query. Only values assigned by the SQL server are valid handles.  
The value 0 identifies an invalid handle.

Definition

■ `sql-handle := HANDLE q-number`

## SQL index

The SQL index identifies the row from the result set. The indices start at 0 and are listed in increasing order.

If no index is specified, the first row from the result set is automatically transferred.

Definition

■ `sql-index := INDEX ( index | q-number )`

## SQL column

The name of the table and of the column to be bound is to be enclosed in double quotation marks.

Definition

■ `table-name := name`

■ `column-name := name`

■ `sql-column := "" table-name '.' column-name ""`

## SQL statement

Enclose the statement to be executed in double quotation marks. A reference to a Q parameter can be used within a statement. Enclose the Q parameter in single quotes after a colon. The interpreter replaces this sequence with the value of the Q parameter.

Definition

■ `sql-replacement:= ':' "" q-parameter ""`

■ `sql-statement:= literal`

Example:

**SQL Q5 " SELECT L, R FROM TOOL WHERE N = :Q2' "**

## SQL

The NC block SQL defines an SQL statement to be executed. The SQL HANDLE, which will enable you to access the data at a later date, is stored in the specified parameter. It is valid until the transaction has been committed or canceled for all rows of the result set.

Definition

■ `sql-execute := SQL q-parameter sql-statement`

Example:

**SQL Q5 " SELECT L, R FROM TOOL WHERE N = :Q2' "**

## SQL BIND

The NC block SQL BIND binds a Q parameter to a column of a table. If you redefine the NC block without specifying a column, the binding will be canceled.  
Otherwise, the binding remains in effect until the current subprogram or cycle is completed.

Definition

■ sql-bind:= SQL BIND q-parameter [ sql-column ]

Example:

SQL BIND Q63 "TCHPROBE.OFFS0"

## SQL SYSBIND

The NC block SQL SYSBIND binds a system parameter to a column of a table. If you redefine the NC block without specifying a column, the binding will be canceled. As with SQL BIND, if not otherwise specified, the binding remains in effect until the subprogram or cycle is completed.

Definition

■ sql-bind := SQL SYSBIND system-parameter [ sql-column ]

Example:

**SQL SYSBIND Q63 "ID50 NR1 IDX1"**

## SQL FETCH

The NC block SQL FETCH reads a row from the result set of an SQL query and assigns the data to the bound parameters. If the values in the table are expressed in inches, lengths and feed rates are converted into millimeters during the reading process. The values in the bound parameters are always assumed to be metric. As with FN18, this also applies if the current program is entered in inches. If no index has been specified, the first row of the result set is transferred. The specified Q parameter is assigned a return code. If the command has been completed successfully, the Q parameter is assigned a zero. If not, it is assigned a one.

Definition

■ sql-fetch:= SQL FETCH q-parameter sql-handle [ sql-index ]

Example:

**SQL FETCH Q80 HANDLE Q5 INDEXO**

## SQL UPDATE

The NC block SQL UPDATE assigns the data from the bound parameters to the corresponding rows or columns of the table. If the values in the table are expressed in inches, lengths and feed rates are converted into millimeters before the assignment process. The values in the bound parameters are always assumed to be metric. As with FN17, this also applies if the current program is entered in inches.

The specified Q parameter is assigned a return code. If the command has been completed successfully, the Q parameter is assigned a zero. If not, it is assigned a one.

Definition

■ sql-update := SQL UPDATE q-parameter sql-handle [ sql-index ]

Example:

**SQL UPDATE Q80 HANDLE Q5 INDEXO**



## SQL COMMIT

The NC block SQL COMMIT cancels locks on table rows or table columns. Edited table data are permanently transferred through SQL COMMIT. The specified Q parameter is assigned a return code. If the command has been completed successfully, the Q parameter is assigned a zero. If not, it is assigned a one.

Definition

■ sql-commit := SQL COMMIT q-parameter sql-handle

Example:

**SQL COMMIT Q80 HANDLE Q5**

## SQL ROLLBACK

The NC block SQL ROLLBACK undoes a transaction. In particular, the lock on rows in an SQL statement "SELECT ... FOR UPDATE" is canceled. The specified Q parameter is assigned a return code. If the command has been completed successfully, the Q parameter is assigned a zero. If not, it is assigned a one.

If required, you can specify in the index the row for which the transaction is to take effect.

Definition

■ sql-rollback := SQL ROLLBACK q-parameter sql-handle [ sql-index ]

Example:

**SQL ROLLBACK Q80 HANDLE Q5**

## Command options for SELECT and UPDATE

Command options allow you to define conditions, sorting sequences and locks that modify the effect of a command.

### WHERE

The WHERE option limits the effect of a command to the rows of a table which satisfy the specified condition.

Definition

■ where-option:= WHERE condition

### ORDER BY

The ORDER BY option influences the sequence of rows in the result set. At present, it is only possible to sort by column (default ASC).

Definition

■ order-option:= ORDER BY column [ ASC | DESC ]

### FOR UPDATE

The FOR UPDATE option already locks the rows during selection (pessimistic locking).

Without the FOR UPDATE option, the selected rows are not locked until the COMMIT command is executed (optimistic locking).

Definition

■ update-option:= FOR UPDATE

## FOR NOTIFICATION

The FOR NOTIFICATION option monitors the table for changes. FOR NOTIFICATION provides the client with a result containing information on the change.

Definition

- lock-option := FOR UPDATE | FOR NOTIFICATION

## SQL commands

### SELECT

In a SELECT statement a list of the columns to be selected and the table preceded by the keyword FROM must be specified. In addition, it may contain a condition with the keyword WHERE, a sorting sequence with the keyword ORDER BY and a command for pessimistic locking with the keyword FOR UPDATE.

Definition

- select-list := '\*' | column-list
- select-option:= [ where-option ] [ order-option ] [ lock-option ]
- select-statement := SELECT select-list FROM table select-option

Examples:

```
SELECT * FROM TOOL WHERE RT == 5 AND LOCK <> 1 ORDER BY TIME
```

```
SELECT TIME FROM TOOL WHERE NR==7 FOR UPDATE
```

```
SELECT L,R,R2 FROM 'OEM:\TOOL.T' WHERE NAME LIKE 'T1999'
```

### UPDATE

In an UPDATE statement the table and the columns to be edited preceded by the keyword SET must be specified. Furthermore, it may contain a condition with the keyword WHERE. If the WHERE condition is not specified, all rows are edited.

Definition

- assignment := column '=' expression
- update-list := assignment { ',' assignment }
- update-option:= [ where-option ]
- update-statement := UPDATE table SET update-list update-option

Examples:

```
UPDATE TOOL SET LOCK = 1 WHERE RT == 5 AND LOCK <> 1
```

```
UPDATE TOOL SET TIME = 0, LOCK = 0
```

```
UPDATE 'OEM:\TOOL.T' SET TIME = MAXTIME WHERE NAME LIKE 'T1999'
```





## INSERT

In an INSERT statement the table and the values to be set which are to be enclosed within parentheses, separated by commas and preceded by the keyword VALUES must be specified. Be sure to assign all columns. The INSERT command appends a new row to the table. It is not possible to insert a new row between two rows.

### Definition

- insert-list := '(' expression-list ')'
- insert-statement:= INSERT INTO table VALUES insert-list

### Examples:

```
INSERT INTO TOOL VALUES (9,1,'T2000',0,1000)
```

```
INSERT INTO 'OEM:\TOOL.T' VALUES (9,1,'T2000',0,1000)
```

## RENAME TABLE

The name of a table file is changed. If a logical table name is specified, the file identified by the name will be edited. Make sure that the name of the target file does not already exist. The name stored internally will be edited accordingly.

With this command, the previous table is copied into a new table. Then the previous table is deleted. This command allows you to move a table to another directory.

### Definition

- rename-table-statement:= RENAME TABLE table TO table

### Examples:

```
RENAME TABLE TOOL TO 'OEM:\TOOL.T'
```

```
RENAME TABLE 'OEM:\TOOL.T' TO 'OEM:\TOOL2.T'
```

## CREATE TABLE

A CREATE TABLE statement creates a new table (new table file). Make sure that the specified table name does not already exist. The names of the columns to be inserted are given as a list. The properties of the columns are read from the configuration. A column configuration for each column name must be available for this. The column width is determined from the width configured for a column or from the length of the column name, depending on which width is larger.

If you enter an asterisk \* instead of the list of column names, all the columns defined in the configuration for this type of table (table extension) will be used.

The ASINCH option is used to specify whether a table is to contain values in inches. As a result, inch-sensitive columns (defined in the column configuration) are created as inch columns in the table. If this option is not specified, the respective columns are created as millimeter columns.

With the LOCALCONFIG option, the properties of the table are stored locally in the table.

Definition

- create-list := '\*' | column-list
- create-table-statement:= CREATE TABLE table '(' create-list ')' [ASINCH] [LOCALCONFIG]

Examples:

```
CREATE TABLE TOOL(L,R,R2,DL,DR,DR2,TL,RT,TIME1,TIME2,  
CUR_TIME,PLC) ASINCH
```

```
CREATE TABLE 'OEM:\TOOL.T' (L,R,R2,DL,DR,DR2,TL,RT,TIME1,TIME2,  
CUR_TIME,PLC)
```

```
CREATE TABLE *
```

## ALTER TABLE

ALTER TABLE modifies the properties of a table. This option enables you to add or delete columns, and to modify the properties of columns. When you add columns or modify the properties of columns, the new properties are read from the configuration. When column properties are modified, the values are not modified. If the width of the new column is larger than the width of the previous one, the column is extended to the new width. If the width of the new column is smaller, however, the column is not changed, so as to avoid any loss of data.

A new column is inserted in the table at the position which is determined from the columns defined for the respective type of table (table extension) in the configuration. The sequence of columns in the table is derived from the configuration data.

Definition

- alter-table-options:= ADD | MODIFY | DROP
- alter-table-statement:= ALTER TABLE table alter-table-options '(' column-list ')'

Examples:

```
ALTER TABLE TOOL ADD (DOC)
```

```
ALTER TABLE 'OEM:\TOOL.T' MODIFY (L)
```



## **COPY TABLE**

COPY TABLE copies the table into a new table. Make sure that the name of the target file does not already exist. The name stored internally will be modified accordingly. It is possible to specify logical table names.

Definition

■ copy-table-statement:= COPY TABLE table TO table

Examples:

**COPY TABLE TOOL TO 'OEM:\TOOL.T'**

**COPY TABLE 'OEM:\TOOL.T' TO 'OEM:\TOOL2.T'**

## **DROP TABLE**

DROP TABLE deletes an existing table file. If a logical table name is specified, the file identified by the name will be deleted.

Definition

■ drop-table-statement:= DROP TABLE table

Examples:

**DROP TABLE TOOL**

**DROP TABLE 'OEM:\TOOL.T'**

## **RENAME COLUMN**

RENAME COLUMN changes the name of an existing column. The properties of the column are not changed. If the configuration of the table is stored locally in the table, the name of the column is also changed in the respective configuration data.

Definition

■ rename-column-statement:= RENAME COLUMN table '(' column-list ')' TO '(' column-list ')'

Example:

**RENAME COLUMN TOOL ( DR2 ) TO ( DIR )**

## **CREATE SYNONYM**

CREATE SYNONYM creates a new logical table name. It is not necessary that the table file identified by the logical name already exists.

Definition

■ create-synonym-statement:= CREATE SYNONYM table-name FOR table-literal

Example:

**CREATE SYNONYM OUTIL FOR 'OEM:\TOOL.T'**

## **ALTER SYNONYM**

ALTER SYNONYM assigns another table file to the logical name.

Definition

■ alter-synonym-statement:= ALTER SYNONYM table-name TO table-literal

Examples:

**ALTER SYNONYM TOOL TO 'OEM:\TOOL2.T'**

## **DROP SYNONYM**

DROP SYNONYM removes a logical name. The table file identified by the logical name will not be removed.

Definition

■ drop-synonym-statement:= DROP SYNONYM table-name

Examples:

**DROP SYNONYM OUTIL**



## Application example for SQL commands

### Read data from table

To determine the positions in a measuring cycle, calibration data of a touch probe are to be transferred from the tchprobe.tp table.

The center offsets are indicated in the CAL\_OF1 and CAL\_OF2 columns.

- ▶ BIND links the Q parameters with column names:  
**SQL BIND Q63 "TCHPROBE.CAL\_OF1"**  
**SQL BIND Q64 "TCHPROBE.CAL\_OF2"**
- ▶ SELECT chooses those columns from the table (TNC:\table\tchprobe.tp) that are to be assigned to the active touch probe (WHERE ACTNR==1):  
**SQL Q5 "SELECT CAL\_OF1,CAL\_OF2 FROM 'TNC:\table\tchprobe.tp' WHERE ACTNR==1"**
- ▶ FETCH reads a row from the result set (HANDLE Q5) and assigns the data to the bound parameters. With INDEX0, the first row of the selected data is read:  
**SQL FETCH Q80 HANDLE Q5 INDEX0**
- ▶ Safety check (Q80 is equal to zero?)
- ▶ The data is assigned to Q parameters:  
**Q43 = Q63**  
**Q44 = Q64**
- ▶ ROLLBACK releases the selected data:  
**SQL ROLLBACK Q80 HANDLE Q5**
- ▶ Safety check (Q80 is equal to zero?)
- ▶ Following that, the bindings are undone:  
**SQL BIND Q63**  
**SQL BIND Q64**

## Write data to table

The triggering touch probe was newly calibrated. The Q parameters Q891, Q798 and Q799 contain the values determined for radius, center offset in the principal axis and center offset in the secondary axis.

The following SQL commands update the table entries with the calibration data.

- ▶ BIND links the Q parameters with column names:

```
SQL BIND Q891 "TOOL.R0"  
SQL BIND Q798 "TCHPROBE.CAL_OF1"  
SQL BIND Q799 "TCHPROBE.CAL_OF2"
```

- ▶ SELECT chooses those columns from the table (TNC:\table\tchprobe.tp) that are to be assigned to the active touch probe (WHERE ACTNR==1):

```
SQL Q5 "SELECT R0,CAL_OF1,CAL_OF2 FROM 'TNC:\table\tchprobe.tp'  
WHERE ACTNR==1"
```

- ▶ FETCH reads a row from the result set (HANDLE Q5) and assigns the data to the bound parameters. With INDEX0, the first row of the selected data is read:

```
SQL FETCH Q80 HANDLE Q5 INDEX0
```

- ▶ Safety check (Q80 is equal to zero?)

- ▶ UPDATE writes the values from the bound Q parameters into the table:

```
SQL UPDATE Q80 HANDLE Q5 INDEX0
```

- ▶ Safety check (Q80 is equal to zero?)

- ▶ COMMIT makes the changes to the table permanent:

```
SQL COMMIT Q80 HANDLE Q5
```

- ▶ Safety check (Q80 is equal to zero?)

- ▶ Following that, the bindings are undone:

```
SQL BIND Q891  
SQL BIND Q798  
SQL BIND Q799
```



### Note

The SQL commands FETCH, UPDATE, COMMIT and ROLLBACK assign a return code to the Q parameters.

If the command has been completed successfully, the Q parameter is assigned a zero. If not, it is assigned a one.

You should always make a safety check after these commands.



## 8.12.7 PLC modules for the SQL statements

### Module 9440 Open a transaction

Module 9440 executes the SELECT statement that is given to the module. For a description of the supported queries, see "SELECT" on page 1628. If the statement was executed successfully, a transaction is opened and its handle is returned. This handle can be used to read data from a machine table (tool table, for example), or to change data in the table. The cursor is placed on the first record of the result set. In order to save changes to the tables, the transaction must be concluded and closed with Module 9441 after changing the records.

If the statement contains a string : 'Bnnn' or : 'Wnnn' or : 'Dnnn' (with nnn reading as number from 0 to the maximal number of BYTEs, WORDs or DWORDs respectively), this string is replaced by the integer value found in the associated PLC data.

Constraints:

- The module can only be executed within a submit job.
- No more than 10 transactions may be open at the same time.

Possible errors:

- The module was not called in a submit job
- The statement is syntactically not correct
- The table given does not exist, is not accessible or is fully or partially locked
- The columns given do not exist within the table
- No records were selected

Call:

PL B/W/D/K/S<Valid SQL statement>

CM 9440

PL D <Transaction handle>

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Transaction was successfully opened
	1	Error. See <Error number>

### Module 9441 Conclude and close a transaction

Module 9441 concludes a transaction. The module tries to write all buffered changes to the selected machine table. If the action is successful, the transaction is closed and the transaction handle is invalidated. Otherwise, the transaction remains open. In order to conclude the transaction despite this, correct the modifications so that no constraints are violated. If the changes are not successful, the buffered changes cannot be saved (conclusion with Module 9451).

Constraints:

- The module can only be executed within a submit job.

Possible errors:

- The module was not called in a submit job
- No transaction was opened for the given handle
- At least one modification made violates a uniqueness constraint defined for a column
- At least one modification made violates a foreign key constraint defined for a column

Call:

```
PS   B/W/D/K           <Transaction handle>
CM   9441
PL   B/W/D   <Error number>
```

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Transaction was successfully closed
Error	1	Error. See <Error number>





### Module 9442 Seek a record in the result set

Module 9442 positions the cursor on the record, defined by the record number, in the result set. If the given record number does not identify the desired record unambiguously, the cursor is then placed on the first or last record (depending on the value of the record number given). The first record is addressed by the record number 0.

Constraints:

- The module can only be executed within a submit job.
- There must already be a result set before Module 9442 can be used.

Possible errors:

- The module was not called in a submit job
- No transaction was opened for the given handle
- The record number exceeds the number of selected records.
- The statement did not lock the selected records and the record was deleted by another statement

Call:

PS B/W/D/K <Transaction handle>

PS B/W/D/K <Record number>

CM 9442

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Record was found
Error	1	Error. See <Error number>

### Module 9443 Fetch a record from the result set

Module 9443 reads a record (line) from a table and saves it in a string. There must already be a transaction open whose transaction handle is given to the module. The values are returned as a comma separated list.

Empty fields are output as two successive commas (...,,...).

A decimal point is always used for data types **REAL**, **LENGTH**, and **FEED**. Values of the data types **SIGN**, **BOOL** and **TEXT** are enclosed in single quotes ( ' ).

Constraints:

- The module can only be executed within a submit job.
- There must already be a result set before Module 9443 can be used.

Possible errors:

- The module was not called in a submit job
- An invalid string address is given to the module
- No transaction was opened for the given handle
- No record was picked
- The length of the string exceeds the maximal string length

Call:

PS B/W/D/K <Transaction handle>  
PS B/W/D/K <String address in which the TNC saves the record>  
CM 9443  
PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Record was read and copied
Error	1	Error. See <Error number>



### Module 9444 Change a record in the result set

Module 9444 reads a string and saves it in the current record. The current record is the one in which the cursor is located at present. If the cursor is at the end of the result set, a new entry is added. There must already be a transaction open whose transaction handle is given to the module. The values must be given in the string as a comma separated list and in the appropriate table format.

Empty fields are output as two successive commas (...,...) or via the keyword NULL (... ,NULL, ...).

A decimal point is always used for data types **REAL**, **LENGTH**, and **FEED**. Values of the data types **SIGN**, **BOOL** and **TEXT** are enclosed in single quotes ( ' ).

The modifications are buffered until the transaction is committed.

Constraints:

- The module can only be executed within a submit job.
- There must already be a result set before Module 9444 can be used.

Possible errors:

- The module was not called in a submit job
- An invalid string address is given to the module
- At least one transferred value is outside the valid range
- At least one transferred value is syntactically incorrect

Call:

PS B/W/D/K <Transaction handle>

PS B/W/D/K <String address>

CM 9444

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Record was updated and inserted
Error	1	Error. See <Error number>

### Module 9445 Read a single value from a table

Module 9445 reads a single value from a table cell and copies this value to a string. The cell content is selected via a SQL statement. For a description of the supported queries, see "SELECT" on page 1628. This SQL statement is given to the module beforehand.

If the statement contains a string **: 'Bnnn'** or **: 'Wnnn'** or **: 'Dnnn'** (with nnn reading as number from 0 to the maximal number of BYTEs, WORDs or DWORDs respectively), this string is replaced by the integer value found in the associated PLC data.

A decimal point is always used for data types **REAL**, **LENGTH**, and **FEED**. Values of the data types **SIGN**, **BOOL** and **TEXT** are enclosed in single quotes ( ' ).

Constraints:

- The module can only be executed within a submit job.

Possible errors:

- The module was not called in a submit job
- An invalid string address is given to the module
- The statement is syntactically not correct
- The table given does not exist or is not accessible
- The columns given do not exist within the table
- More than one column was named in the statement
- No record or more than one record were selected by the statement

Call:

PS B/W/D/K <Valid SQL statement>  
PS B/W/D/K <String address for the read value>  
CM 9445  
PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Value was read
Error	1	Error. See <Error number>



### Module 9447 Delete record from result set

Module 9447 deletes the current record (table line). The current record is the one in which the cursor is located at present. There must already be a transaction open whose transaction handle is given to the module. The modification is buffered until the transaction is committed.

Constraints:

- The module can only be executed within a submit job.
- There must already be a result set before Module 9447 can be used.

Possible errors:

- The module was not called in a submit job
- No transaction was opened for the given handle

Call:

PS B/W/D/K <Transaction handle>

CM 9447

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Description was successfully loaded
Error	1	Error. See <Error number>

### Module 9448 Load a column description

Module 9448 loads the description of one or more columns into a cache. The column is specified by its qualified name in the form table.column. If a wildcard "\*" is given as the column (i.e. a qualified name in the form table.\*), the description of all columns of the given table is loaded. The description is used by various modules for the conversion to or from binary data. Required descriptions that were not found in the cache are automatically loaded during the execution of these modules. However, the execution time of these modules can be improved, if descriptions are cached.

Constraints:

- The module can only be executed within a submit job.

Possible errors:

- The referenced table does not exist.
- The referenced column does not exist.

Call:

PS B/W/D/K <String address with the qualified column name>

CM 9448

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Description was successfully loaded
Error	1	Error. See <Error number>



### Module 9449 Extract a value from a comma separated list

Module 9449 extracts a value from a comma-separated list of values.

Constraints:

- The module can only be executed within a submit job.

Possible errors:

- The module was not called in a submit job
- The index for the value exceeds the number of values in the string

Call:

PS B/W/D/K <String address for the list of values>

PS B/W/D/K <Index of the value to extract>

PS B/W/D/K <String address for the extracted value>

CM 9449

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Value was successfully extracted
Error	1	Error. See <Error number>

### Module 9450 Execute an SQL statement

Module 9450 executes the SQL statement that is given to the module. For a description of the supported SQL statements, see "SQL commands" on page 1628. This module may not be used to open a transaction (such as via a SELECT statement).

If the statement contains a string : 'Bnnn' or : 'Wnnn' or : 'Dnnn' (with nnn reading as number from 0 to the maximal number of BYTEs, WORDs or DWORDs respectively), this string is replaced by the integer value found in the associated PLC data.

Constraints:

- The module can only be executed within a submit job.

Possible errors:

- The module was not called in a submit job
- The statement is syntactically not correct
- The table given does not exist, is not accessible or is fully or partially locked
- The columns given do not exist within the table

Call:

PS B/W/D/K/S<Valid SQL statement>

CM 9450

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Statement was successfully executed
Error	1	Error. See <Error number>





### Module 9451 Roll back and close a transaction

Module 9451 does not save all buffered modifications of a table during a transaction to the table. The transaction is closed and the transaction handle is invalidated.

Constraints:

- The module can only be executed within a submit job.

Possible errors:

- The module was not called in a submit job
- No transaction was opened for the given handle

Call:

PS B/W/D/K <Transaction handle>

CM 9451

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Transaction was successfully closed
Error	1	Error. See <Error number>

### Module 9452 Seek next record in the result set of a query

Module 9452 positions the cursor to the next entry in the result set.

Constraints:

- The module can only be executed within a submit job.
- There must already be a result set before Module 9452 can be used.

Possible errors:

- The module was not called in a submit job
- No transaction was opened for the given handle
- The last record in the result set has been reached
- The statement did not lock the selected records and the record was deleted by another statement

Call:

PS B/W/D/K <Transaction handle>

CM 9452

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Record was found
Error	1	Error. See <Error number>



### Module 9453 Fetch binary data from the result set of a query

Module 9453 reads a record from a table and converts the data in the selected columns to binary values. There must already be a transaction open whose transaction handle is given to the module. The column values are copied to a number of successive DWORDs. The index of the first DWORD and the number of DWORDS are given to the module.

Data in a column of the type

- SIGN are converted to 0 or -1.
- BOOL are converted to 0 (FALSE) or +1 (TRUE).
- INDEX are each converted to a DWORD.
- REAL are converted to a DWORD by shifting the decimal separator to the right according to the maximum number of decimal places.  
For example, if the value 10.5 is in the table, Module 9453 supplies the value 105000.
- LENGTH and FEED are converted to a DWORD.
- Measurements in INCH are converted to metric units.

Constraints:

- The module can only be executed within a submit job.
- There must already be a result set before Module 9453 can be used.

Possible errors:

- The module was not called in a submit job
- No transaction was opened for the given handle
- No record was fetched
- The given number of DWORDs does not match the number of values
- The given range of DWORDs does not fit into the available memory

Call:

```
PS   B/W/D/K  <Transaction handle>
PS   B/W/D/K  <Index of the first DWORD>
PS   B/W/D/K  <Number of the DWORDs to store>
CM   9453
PL   B/W/D    <Error number>
```

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Data were read and converted
	1	Error. See <Error number>



### Module 9454 Update binary data in the result set of a query

Module 9454 reads binary data from a number of successive DWORDs. These data are used to update the current record in the result set. If the cursor is at the end of the result set, a new record is added. There must already be a transaction open whose transaction handle is given to the module. The values are read from a number of successive DWORDs. The index of the first DWORD and the number of DWORDs are given to the module.

Data in a column of the type

- SIGN are converted to 0 or -1.
- BOOL are converted to 0 (FALSE) or +1 (TRUE).
- INDEX are each converted to a DWORD.
- REAL are converted to a DWORD by shifting the decimal separator to the right according to the maximum number of places.  
For example, if the value 10.5 is in the table, Module 9453 supplies the value 105000.
- LENGTH and FEED are converted to a DWORD.
- Measurements in INCH are converted to metric units.

The modifications to the table are buffered until the transaction is committed.

Constraints:

- The module can only be executed within a submit job.
- There must already be a result set before Module 9454 can be used.

Possible errors:

- The module was not called in a submit job
- No transaction was opened for the given handle
- The given number of DWORDS does not match the number of values
- The given range does not fit into the available memory
- At least one transferred value is outside the valid range

Call:

```
PS   B/W/D/K <Transaction handle>
PS   B/W/D/K <Index of the first DWORD in which the control reads the
      values>
PS   B/W/D/K <Number of DWORDs with values>
CM   9453
PL   B/W/D   <Error number>
```

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Data were updated or inserted
Error	1	Error. See <Error number>



### Module 9455 Read a single numeric value from a table

Module 9455 reads a single value from a table and converts it to a binary value. The value is chosen via a given SELECT statement.

If the statement contains a string :'Bnnn' or :'Wnnn' or :'Dnnn' (with nnn reading as number from 0 to the maximal number of BYTEs, WORDs or DWORDs respectively) , this string is replaced by the integer value found in the corresponding PLC data.

Data in a column of the type

- SIGN are converted to 0 or -1.
- BOOL are converted to 0 (FALSE) or +1 (TRUE).
- INDEX are each converted to a DWORD.
- REAL are converted to a DWORD by shifting the decimal separator to the right according to the maximum number of places.  
For example, if the value 10.5 is in the table, Module 9453 supplies the value 105000.
- LENGTH and FEED are converted to a DWORD.
- Measurements in INCH are converted to metric units.

Constraints:

- The module can only be executed within a submit job.

Possible errors:

- The module was not called in a submit job
- An invalid string address is given to the module
- The given table does not exist or is not accessible
- The column given does not exist in the table
- The column does not hold a numerical value
- More than one column was named in the statement
- No record or more than one record were selected by the statement

Call:

PS B/W/D/K <Valid SQL statement>

CM 9455

PS B/W/D <Element value>

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Value was read
	1	Error. See <Error number>

### Module 9458 Unload a column description

Module 9458 removes the description of one or more columns from the cache. The column is specified by its qualified name in the form table.column. If a wildcard '\*' is given as the column (i.e. a qualified name in the form table.\*), the description of all columns of the given table is unloaded. In order to save memory, descriptions should be unloaded if they are no longer used. They must be unloaded, if a different table file is used with the same table name.

Constraints:

- The module can only be executed within a submit job.

Possible errors:

- The column given to the module was not found in the cache

Call:

PS B/W/D/K <String address with the qualified column name>

CM 9458

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error	0	Description was successfully unloaded
	1	Error. See <Error number>



### Module 9459 Change or insert a value in a comma separated list

Module 9459 changes or inserts a value in a comma-separated list of values. If the index is less than the number of values, the value in the list is replaced. If the index is equal to the number of values, the value is appended.

Constraints:

- The module can only be executed within a submit job.

Possible errors:

- The module was not called in a submit job
- The index for the value exceeds the number of values in the string

Call:

PS B/W/D/K <String address for the list of values>

PS B/W/D/K <Index of the value to insert>

PS B/W/D/K <String address for the extracted value>

CM 9459

PL B/W/D <Error number>

For the meaning of the error number, see "Return codes of PLC Modules 9440 to 9459 (error stack)" on page 1652.

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule	0	Value was successfully updated or inserted
Error	1	Error. See <Error number>

**Return codes of  
PLC Modules 9440  
to 9459 (error stack)**

The following errors can occur when running Modules 9440 to 9459, and are returned to the error stack:

<b>Value (error stack)</b>	<b>Meaning</b>
0	Module executed successfully
1	Parameter out of range
2	Parameter not defined
3	Invalid address programmed
4	Address too high or block too long
5	Specified address is not a double word address
11	String could not be converted
12	String too long
15	Module was not called in a submit job
16	No connection with SQL server established
17	Invalid transaction handle was programmed
20	Syntax of the statement is incorrect
25	Table file not found
26	Table file cannot be accessed
27	New file already exists
30	Table header is invalid
31	Configuration message is invalid
32	Table type has not been configured
33	Table contains no columns
34	Unexpected end of table
35	Table has already been opened
36	Table is write-protected
40	Column description is invalid
41	Column type was not configured
42	Column defined several times
43	Column already exists in table
44	Columns do not exist in table or record
45	No column given with the statement
50	Symbolic name already exists
51	Symbolic name does not exist
52	Symbolic name cannot be accessed
55	Index name already exists
56	Index name does not exist
57	Index must not be created
60	Data record already locked
61	Data record already deleted
62	Invalid length of a record
63	Index for result set too large
70	Invalid default value
71	Invalid value type





<b>Value (error stack)</b>	<b>Meaning</b>
72	Invalid number of values
73	Given value is not unique
75	Assigned value must not be null
76	Assigned value is invalid
77	Assigned value is too long
78	Assigned value is out of range
79	Assigned value already exists
80	Primary key must not be dropped or renamed
81	Primary key must not be updated
82	Primary key must not be set null
85	Action violates the referential integrity
86	Referential action conflicts with statement
90	Function not yet implemented
91	Internal (software) error



## 8.13 Data Transfer NC => PLC, PLC => NC

### 8.13.1 Introduction

Functions that are to be executed by the PLC are transferred from the NC to the PLC. The job (M, G or T function), the job parameter and the acknowledgment by the PLC are transmitted in strobes.

- M functions: Jobs from the NC to the PLC and acknowledgment by the PLC are transmitted in M strobes (see "M Functions (M Strobe)" on page 1548).
- Special G functions that are executed by the PLC must be configured correspondingly. This configuration is described below. Jobs from the NC to the PLC and acknowledgment by the PLC are transmitted in M strobes (see "M Functions (M Strobe)" on page 1548).
- T functions are executed by the PLC. Jobs from the NC to the PLC and acknowledgment by the PLC are transmitted in strobes (see "T Functions (T Strobe)" on page 1574).
- S functions are executed by the NC. However, an S strobe must be defined. To do so, define a dummy S strobe in the parameter object CfgPlcSStrobe (see "S Function (S Strobe)" on page 1560).

### 8.13.2 Data transfer NC program => PLC

Settings in the configuration editor	MP number
System	
PLC	
CfgPlcMStrobe:	1548
<b>[Key name of M strobe]</b>	
CfgPlcStrobeAlias	
[Key name of alias strobe]	
<b>type:</b>	GFUNCTION
<b>mCode:</b>	1000
<b>mOffset:</b>	TRUE
104201	
104202	
104203	
NCchannel	
ChannelSettings	
[Key name of the machining channel]	
CfgPlcStrobes	
<b>mStrobes</b>	201601
<b>aliasStrobes</b>	201604



The NC transfers M functions to the PLC via M strobes. If G functions are transferred to the PLC, the following configuration is required:

■ Channel-dependent parameter object

**NCchannel/ChannelSettings/key name of the channel/CfgPlcStrobes:**

- mStrobes: in addition to the key names of the M functions, also list the key names of the G functions to be transferred to the PLC
- aliasStrobes: define the key name of the alias strobes

■ Parameter object

**System/PLC/CfgPlcMStrobe:**

Use the key names to define the M and G functions and their transfer parameters. For G functions to be transferred to the PLC, the offset (here: 1000) is added to the number of the G function.

■ Parameter object

**System/PLC/CfgPlcStrobeAlias:**

Use the key name to assign the type GFUNCTION to the alias strobe and define the offset.

With the parameters of the alias strobe, you make the following definitions:

- MP\_type=GFUNCTION: (defined) G functions are transferred to the PLC
- MP\_mCode=1000 and MP\_mOffset=TRUE: Specifies that an offset (here 1000) is added to the code of the G functions
  - Codes < 1000 are M functions
  - Codes > 1000 are G functions

On the basis of the entries in **CfgPlcMStrobe**, the NC checks which G functions are transferred to the PLC. Transfer is activated with the M strobe (see "M Functions (M Strobe)" on page 1548).

The following applies to data transfer (parameter of the M or G function):

- M and G functions (except G600...G699): The address of the operand containing the parameter is in MP\_data
- G functions G600...G699: The operand specified in MP\_data contains the address of a data field with the following structure:

Transfer data = parameter of the G function	Progr. max. value	Multiplier of the NC	Max. value transferred	Value if not programmed
"X"	9999.999	1000	9 999 999	10 000 000
"Z"	9999.999	1000	9 999 999	10 000 000
"Y"	9999.999	1000	9 999 999	10 000 000
"C"	9999.999	1000	9 999 999	10 000 000
"F"	9999.999	1000	9 999 999	10 000 000
"S"	9999	1	9 999	FFFF hex
"T"	9999	1	9 999	FFFF hex
"H"	9999	1	9 999	FFFF hex
"Q"	9999	1	9 999	FFFF hex

The REAL values listed in the NC program for the parameters X, Z, Y, C and F are multiplied by 1000 and transferred as DWORD (double word) values. The S, T, H and Q parameters are transferred as WORD values.

## Overview of G functions

The machine tool builder defines the meaning of the G600 functions. The G functions that are also made available in the NC must be considered:

G code	G functions that are given to the PLC
Gx26	Speed limitation relative to the x spindle
Gx95	Feed rate per revolution relative to the x spindle
Gx96	Constant surface speed relative to the x spindle
Gx97	Constant speed relative to the x spindle



### Note

The user should define the spindle speed and the speed limitation after system start-up to ensure correct values.

### 8.13.3 Data transfer machine parameters => PLC

Settings in the configuration editor	MP number
System	
PLC	
CfgOemBool	
[Key name of arbitrary parameter]	
<b>value</b>	104501
<b>ignorePlc</b>	104502
CfgOemInt	
[Key name of arbitrary parameter]	
<b>value</b>	104601
<b>ignorePlc</b>	104602
CfgOemString	
[Key name of arbitrary parameter]	
<b>value</b>	104901
<b>ignorePlc</b>	104902
CfgOemPosition	
[Key name of arbitrary parameter]	
<b>value</b>	104701
<b>ignorePlc</b>	104702

Freely definable machine parameters are available for data transmission to the PLC. The control saves the contents of the machine parameters in PLC words.

In the machine parameters you can save, for example, values for PLC positioning movements and datum shifts, feed rates for PLC positioning movements or codes for the enabling of certain PLC functions or user texts for OEM cycles. You must evaluate the transferred characters and numerical values in your PLC program.

The freely definable machine parameters are divided into three groups:

■ **CfgOemBool:**

User parameters with logical values (TRUE, FALSE or ON, OFF)

■ **CfgOemInt:**

User parameters with integer values (whole numbers)

■ **CfgOemString**

User parameters with text data (lists with max. 9 strings, character length max. 100)

■ **CfgOemPosition:**

User parameters with fixed decimal values (position values)

If a parameter from CfgOemPosition is opened in the configuration editor (**Machine Parameter Programming** mode of operation), you can use the ACTUAL POSITION CAPTURE soft key to automatically capture the position value of an axis.

The soft key displays a soft-key row showing the available axes. When you press an axis soft key, the MANUALplus 620 captures the position of the axis in the REFNOML system.

Each of the freely definable parameters is in a subfolder (key name). The key name also specifies the name of the machine parameter. You specify the value of the parameter in the **value** subfolder.

If you do not want to copy a parameter to the PLC run-time system, the optional machine parameter **MP\_ignorePlc** must be inserted and set to TRUE.

### **MP\_value**

List of user parameter values  
Available from NCK software version: 597 110-01.

Format: Array  
Input: Value of the user parameter  
CfgOemBool: Logical values (Boolean)  
CfgOemInt: Whole numbers (integer values)  
CfgOemString: User text, e.g. for OEM cycles with max. 100 characters.  
CfgOemPosition: Fixed-point values (position)

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

### **MP\_ignorePlc**

Do not copy user parameter to the PLC run-time system  
Available from NCK software version: 597 110-01.

Format: Selection menu  
Selection: **TRUE**  
The parameter value is not copied to the PLC run-time system  
**FALSE**  
The parameter value is copied to the PLC run-time system

Default: No value, parameter optional  
Access: LEVEL3  
Reaction: NOTHING

## **User parameters**

You can give the machine operator access via user parameters to the machine parameters that you define yourself, see "User Parameters" on page 365.

## 8.14 Program Creation


### 8.14.1 ASCII editor

The integrated editor enables you to create and edit the PLC program and all other necessary files right at the control through the ASCII keyboard. You will find a complete description of the editor, including the associated soft keys, in the User's Manual for the control.

### 8.14.2 Program format

#### Command

A command is the smallest unit of a PLC program. It consists of the operation part and the operand part.



The operation describes the function to be executed. It defines how the operand is to be processed by the TNC. The operand shows what is to be operated with. It consists of the operand abbreviation and a parameter (address). With the PLC commands you can combine (gate), delete and load register and memory contents, both with bit and word processing. For word processing, you can address memory contents with a length of 8 bits (byte), 16 bits (word) or 32 bits (double word).

### 8.14.3 Program structure

To make it easier to maintain and expand your PLC program, you should give it a modular structure. Modular means that you write a separate program module for each function. You can then call the individual modules from the main program. You should interrogate improper functioning of the machine in the PLC program and indicate such malfunctions on the screen with plain-language error messages.

#### **Module 9019 Size of the processing stack**

To debug functions, you can use Module 9019 to interrogate the contents of the processing stack. The function answers with the number of the bytes that lie on the processing stack of the PLC at the moment. If the processing stack is empty, the PLC run-time system returns the value zero. A byte, word or double word occupies four bytes on the stack; a marker, input, output, timer or counter occupies two bytes.

Call:

CM 9019

PL B/W/D <Number of bytes on processing stack>





## 8.15 Command Set

### 8.15.1 Overview

The following table provides an overview of all commands explained in this chapter:

Group of functions	Syntax	Function
<b>Loading and saving commands</b>		
	L	Load
	LN	Load NOT
	L-	Load two's complement
	LB	Load BYTE
	LW	Load WORD
	LD	Load DOUBLE WORD
	=	Assignment
	B=	Assign BYTE
	W=	Assign WORD
	D=	Assign DOUBLE WORD
	=N	Assign NOT
	=-	Assign two's complement
<b>Setting commands</b>		
	S	Set
	R	Reset
	SN	Set NOT
	RN	Reset NOT
<b>Logical operations</b>		
	A	And
	AN	And NOT
	O	or
	ON	Or NOT
	XO	Exclusive OR
	XON	Exclusive OR NOT
<b>Arithmetic commands</b>		
	+	Addition
	-	Subtraction
	x	Multiplication
	/	Division
	MOD	Remainder

<b>Group of functions</b>	<b>Syntax</b>	<b>Function</b>
<b>Increment</b>		
	INC	Increment operand
	INCW	Increment word accumulator
	INCX	Increment index register
<b>Decrement</b>		
	DEC	Decrement operand
	DECW	Decrement word accumulator
	DECX	Decrement index register
<b>Comparisons</b>		
	==	Equal
	<	Less than
	>	Greater than
	<=	Less than or equal to
	>=	Greater than or equal to
	<>	Not equal to
<b>Parenthetical expressions in logical operations</b>		
	A [ ]	And [ ]
	AN [ ]	And NOT [ ]
	O [ ]	Or [ ]
	ON [ ]	Or NOT [ ]
	XO [ ]	Exclusive OR [ ]
	XON [ ]	Exclusive OR NOT [ ]
<b>Parenthetical expressions with arithmetical instructions</b>		
	+ [ ]	Addition [ ]
	- [ ]	Subtraction [ ]
	x [ ]	Multiplication [ ]
	/ [ ]	Division [ ]
	MOD [ ]	Remainder [ ]
<b>Parenthetical expressions in comparisons</b>		
	== [ ]	Equal to [ ]
	< [ ]	Less than [ ]
	> [ ]	Greater than [ ]
	<= [ ]	Less than or equal to [ ]
	>= [ ]	Greater than or equal to [ ]
	<> [ ]	Not equal to [ ]
<b>Shifting commands</b>		
	<<	Shift left
	>>	Shift right

Group of functions	Syntax	Function
<b>Bit commands</b>		
	BS	Bit set
	BC	Bit clear
	BT	Bit test
<b>Stack operations</b>		
	PS	Push data onto the data stack
	PL	Pull data from the data stack
	PSL	Push logic accumulator onto the data stack
	PSW	Push word accumulator onto the data stack
	PLL	Pull logic accumulator from the data stack
	PLW	Pull word accumulator from the data stack
<b>Jump commands</b>		
	JP	Unconditional jump
	JPT	Jump if logic accumulator = 1
	JPF	Jump if logic accumulator = 0
	CM	Call module
	CMT	Call module if logic accumulator = 1
	CMF	Call module if logic accumulator = 0
	EM	End of module, program end
	EMT	End of module if logic accumulator = 1
	EMF	End of module if logic accumulator = 0
	LBL	Label

## 8.15.2 LOAD (L)

### Logic processing with the LOAD command

**Syntax:** L (LOAD)

**Operands:** M, I, O, T, C

**Action:**

Load the value of the addressed operand into the logic accumulator. Always use the L command at the beginning of a logic chain in order to be able to gate the operand in the following program sequence.

**Example:**

Gate the inputs I4 and I5 with AND, and assign the result to output O2.

Initial state:

Input I4 = 1

Input I5 = 0

Output O2 = ?

Function	STL	Logic accumulator	Operand content
Load the operand content into the logic accumulator.	L I4	Logic accumulator = 1	
Gate the content of the logic accumulator and input I5 with AND.	A I5		0
Assign the gating result to output O2.	= O2		0



**Word processing  
with the LOAD  
command**

**Syntax:** L (LOAD)

**Operands:** B, W, D, K

**Action:**

Load the value of the addressed operand, or of a constant, into the word accumulator. If necessary, the accumulator is supplemented with the correct algebraic sign. In contrast to logical operations, you must always begin a sequence of word gating operations with an L command. You cannot replace the L command with a logical gating instruction.

**Example:**

Gate a constant and byte B5 with AND, and assign the result to byte B8.

Initial state:

Constant 54 = 36 (hex)

Byte B5 = 2A (hex)

Output B8 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K+54	36	
Gate the contents of the word accumulator and byte B5 with AND.	A B5		2A
Assign the gating result to byte B8.	= B8		22

### 8.15.3 LOAD NOT (LN)

#### Logic processing with the LOAD NOT command

**Syntax:** LN (LOAD NOT)

**Operands:** M, I, O, T, C

**Action:**

Load the one's complement of the addressed operand into the logic accumulator. Always use the L command at the beginning of a logic chain in order to be able to gate the operand in the following program sequence.

**Example:**

Gate the inverted logical state of inputs I4 and I5 with AND, and assign the result to output O2.

Initial state:

Input I4 = 0

Input I5 = 1

Output O2 = ?

Function	STL	Accumulator content	Operand content
Load the inverted operand content into the logic accumulator.	LN I4	0	
Gate the content of the logic accumulator and input I5 with AND.	A I5		1
Assign the gating result to output O2.	= O2		1



**Word processing  
with the LOAD NOT  
command**

**Syntax:** LN (LOAD NOT)

**Operands:** B, W, D, K

**Action:**

Load the complement of the addressed operand, or of a constant, into the word accumulator. If necessary, the accumulator is supplemented with the correct algebraic sign. In contrast to logical operations, you must always begin a sequence of word gating operations with an L command. You cannot replace the L command with a logical gating instruction.

**Example:**

Gate the complement of byte B6 and byte B5 with AND, and assign the result to byte B8.

Initial state:

Byte B5 = 2A (hex)

Byte B6 = B6 (hex)

Byte B8 = ?

Function	STL	Accumulator content	Operand content
Invert byte B6, and load into the word accu.	LN B6	2A	
Gate the contents of the word accumulator and byte B5 with AND.	A B5		B6
Assign the gating result to byte B8.	= B8		22



## 8.15.4 LOAD TWO'S COMPLEMENT (L-)

**Syntax:** L- (LOAD MINUS)

**Operands:** B, W, D, K

**Action:**

Load the two's complement of the addressed operand, or of a constant, into the word accumulator. If necessary, the control fills the accumulator with the correct algebraic sign. The two's complement allows negative numbers to be stored, i.e., a number loaded with the L command appears in the accumulator with an inverted sign. This command can be used only with word processing.

**Example:**

Negate the content of byte B5 and then add it to the content of byte B6. Assign the result to byte B8.

Initial state:

Byte B5 = 15 (dec)

Byte B6 = 20 (dec)

Byte B8 = ?

Function	STL	Accumulator content	Operand content
Load byte B5 into the word accumulator, invert the algebraic sign.	L- B5	-15	+15
Add the contents of the word accumulator and byte B6.	+ B6	+5	+20
Assign the gating result to byte B8.	= B8	+5	+5





### 8.15.5 LOAD BYTE (LB)

**Syntax:** LB (LOAD BYTE)

**Operands:** M, I, O, T, C

**Action:**

Copy 8 markers, inputs, outputs, timers or counters with ascending numbering into the word accumulator. Each operand occupies one bit in the accumulator. The control saves the given operand address as LSB in the accumulator, the given address + 1 as LSB + 1 and so on. The last (8th) operand becomes the MSB! If necessary, the control fills the accumulator with the correct algebraic sign.

**Example:**

A pure-binary coded value is read through inputs I3 to I10 and saved in byte B8 in order to process it later.

Initial state:

Input	I3	= 1	Input	I7	= 0
Input	I4	= 1	Input	I8	= 1
Input	I5	= 1	Input	I9	= 1
Input	I6	= 0	Input	I10	= 0

Function	STL	Accumulator content	Operand content
		7 6 5 4 3 2 1 0	I10 I9 I8 I7 I6 I5 I4 I3
Load inputs I3 to I10 into the accumulator (bit 0 to bit 7).	LB I3	1 1 1 0 0 1 1 0	0 1 1 0 0 1 1 1
			7 6 5 4 3 2 1 0
Assign accumulator contents to byte 8.	= B8	1 1 1 0 0 1 1 0	1 1 1 0 0 1 1 0

### 8.15.6 LOAD WORD (LW)

**Syntax:** LW (LOAD WORD)

**Operands:** M, I, O, T, C

**Action:**

Copy 16 markers, inputs, outputs, timer or counters with ascending numbering into the word accumulator. Each operand occupies one bit in the accumulator. The control saves the given operand address as LSB in the accumulator, the given address + 1 as LSB + 1 and so on. The last (16th) operand becomes the MSB! If necessary, the control fills the accumulator with the correct algebraic sign.

**Example:**

See example command LB. Use command LW in the same way as LB. However, the control processes 16 operands.



### 8.15.7 LOAD DOUBLE WORD (LD)

**Syntax:** LD (LOAD DOUBLE WORD)

**Operands:** M, I, O, T, C

**Action:**

Copy 32 markers, inputs, outputs, timers or counters with ascending numbering into the word accumulator. Each operand occupies one bit in the accumulator. The control saves the given operand address as LSB in the accumulator, the given address + 1 as LSB + 1 and so on. The last (32nd) operand becomes the MSB! If necessary, the control fills the accumulator with the correct algebraic sign.

**Example:**

See example command LB. Use command LD in the same way as LB. However, the control processes 32 operands.

### 8.15.8 ASSIGN (=)

**Logic processing with the ASSIGN command**

**Syntax:** = (STORE)

**Operands:** M, I, O, T, C

**Action:**

Assign the content of the logic accumulator to the addressed operand. Use the = command only at the end of a sequence of logical gating operations in order to transfer a gating result to a logic operand. This command can be used several times in succession (see example).

**Example:**

Gate the inputs I4 and I5 with AND, and assign the result to outputs O2 and O5.

Initial state:

Input	I4	= 1
Input	I5	= 0
Output	O2	= ?
Output	O5	= ?

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I4	1	1
Gate the content of the logic accumulator and input I5 with AND.	A I5	0	0
Assign the gating result to output O2.	= O2	0	0
Assign the gating result to output O5.	= O5	0	0



## Word processing with the ASSIGN command

**Syntax:** = (STORE)

**Operands:** B, W, D

**Action:**

Assign the content of the word accumulator to the addressed operand. Unlike bit processing, in word processing you can also use the = command within a sequence of word-gating operations. This command can be used several times in succession.

**Example:**

Gate a constant and byte B5 with AND, and assign the result to byte B8 and byte B10.

Initial state:

Constant 54 = 36 (hex)  
Byte B5 = 2A (hex)  
Byte B8 = ?  
Byte B10 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K+54	36	
Assign the contents of the word accumulator to byte B8.	= B8	36	36
Gate the contents of the word accumulator and byte B5 with AND.	A B5	22	2A
Assign the gating result to byte B8.	= B8	22	22
Assign the gating result to byte B10.	= B10	22	22

### 8.15.9 ASSIGN BYTE (B=)

**Syntax:** B= (STORE BYTE)

**Operands:** M, I, O, T, C

**Action:**

Assign 8 bits from the word accumulator to markers, inputs, outputs, timers or counters with ascending numbering. Every bit occupies an operand. The control assigns the LSB in the accumulator to the operand address specified in the command, the LSB +1 to the specified address +1, etc. The MSB is assigned to the last (8th) operand.

**Example:**

See example command W=. Use command B= in the same way as W=. However, the control processes 8 operands.



### 8.15.12 ASSIGN NOT (=N)

#### Logic processing

**Syntax:** =N (STORE NOT)

**Operands:** M, I, O, T, C

**Action:**

Assign the complement of the logic accumulator to the addressed operand.  
For an example, see the ASSIGN (=) command.

#### Word processing

**Syntax:** =N (STORE NOT)

**Operands:** B, W, D

**Action:**

Assign the complement of the word accumulator to the addressed operand.  
For an example, see the ASSIGN (=) command.

### 8.15.13 ASSIGN TWO'S COMPLEMENT (=-)

**Syntax:** =- (STORE MINUS)

**Operands:** B, W, D

**Action:**

Assign the TWO'S COMPLEMENT of the word accumulator to the addressed operand. For an example, see the ASSIGN (=) command.

## 8.15.14 SET (S)

**Syntax:** S (SET)

**Operands:** M, I, O, T, C

**Action:**

If the logic accumulator = 1, then set the addressed operand to 1, otherwise do not change it. Use the S command at the end of a sequence of logical gating operations in order to influence an operand, depending on the result of gating. This command can be used several times in succession (see example).

**Example:**

Gate input I4 and I5 with OR. If the gating result is 1, then set output O2 and marker M500.

Initial state:

Input I4 = 1

Input I5 = 0

Output O2 = ?

Marker M500 = ?

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I4	1	1
Gate the content of the logic accumulator and input I5 with OR.	O I5	1	0
Since the result of the operation is 1, set output O2.	S O2	1	1
Since the result of the operation is 1, set marker M500.	S M500	1	1



## 8.15.15 RESET (R)

**Syntax:** R (RESET)

**Operands:** M, I, O, T, C

**Action:**

If the logic accumulator = 1, then set the addressed operand to 0, otherwise do not change it. Use the R command at the end of a sequence of logical gating operations in order to influence an operand, depending on the result of gating. This command can be used several times in succession (see example).

**Example:**

Gate input I4 and I5 with OR. If the gating result is 1, then reset output O2 and marker M500.

Initial state:

Input I4 = 1

Input I5 = 0

Output O2 = ?

Marker M500 = ?

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I4	1	1
Gate the content of the logic accumulator and input I5 with OR.	O I5	1	0
Since the result of the operation is 1, reset output O2.	R O2	1	0
Since the result of the operation is 1, reset marker M500.	R M500	1	0

## 8.15.16 SET NOT (SN)

**Syntax:** SN (SET NOT)

**Operands:** M, I, O, T, C

**Action:**

If the logic accumulator = 0, then set the addressed operand to 1, otherwise do not change it. Use the SN command at the end of a sequence of logical gating operations in order to influence an operand depending on the result of gating. This command can be used several times in succession (see example).

**Example:**

Gate input I4 and I5 with OR. If the gating result is 0, then set output O2 and marker M500.

Initial state:

Input I4 = 0

Input I5 = 0

Output O2 = ?

Marker M500 = ?

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I4	0	0
Gate the content of the logic accumulator and input I5 with OR.	O I5	0	0
Since the result of the operation is 0, set output O2.	SN O2	0	1
Since the result of the operation is 0, set marker M500.	SN M500	0	1





### 8.15.17 RESET NOT (RN)

**Syntax:** RN (RESET NOT)

**Operands:** M, I, O, T, C

**Action:**

If the logic accumulator = 0, then set the addressed operand to 0, otherwise do not change it. Use the RN command at the end of a sequence of logical gating operations in order to influence an operand depending on the result of gating. This command can be used several times in succession (see example).

**Example:**

Gate input I4 and I5 with OR. If the gating result is 0, then reset output O2 and marker M500.

Initial state:

Input I4 = 0

Input I5 = 0

Output O2 = ?

Marker M500 = ?

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I4	0	0
Gate the content of the logic accumulator and input I5 with OR.	O I5	0	0
Since the result of the operation is 0, reset output O2.	RN O2	0	0
Since the result of the operation is 0, reset marker M500.	RN M500	0	0



## 8.15.18 AND (A)

### Logic processing with the AND command

**Syntax:** A (AND)

**Operands:** M, I, O, T, C

**Action:**

- At the beginning of a logic sequence, this command functions like an L command, i.e., the logical state of the operand is loaded into the logic accumulator. This is to ensure compatibility with the TNC 355, which does not have the special L command. In PLC programs, a sequence of logical gating operations should always be started with a load command (see L, LN, L-).
- Within a logic sequence, gate the content of the logic accumulator and the logical state of the operand with AND. The control saves the result of the operation in the logic accumulator.

**Example:**

Gate the inputs I4 and I5 with AND, and assign the result to output O2.

Initial state:

Input I4 = 1  
Input I5 = 0  
Output O2 = ?

Function	STL	Accumulat or content	Operand content
Load the operand content into the logic accumulator.	L I4	1	1
Gate the content of the logic accumulator and input I5 with AND.	A I5	0	1
Assign the gating result to output O2.	= O2	0	0



**Word processing  
with the AND  
command**

**Syntax:** A (AND)

**Operands:** B, W, D, K

**Action:**

Gate the contents of the word accumulator and the operand with AND. In accordance with the different data widths of the operands (B = 8 bits; W = 16 bits; D = K = 32 bits), 8, 16 or 32 bits, respectively, are influenced in the accumulator. Thus, bit 0 of the accumulator is gated with bit 0 of the operand, bit 1 of the accumulator with bit 1 of the operand, etc. The control saves the result of the operation in the word accumulator.

**Example:**

Gate the contents of byte B5 and byte B6 with AND, and assign the result to byte B8.

Initial state:

Byte B5 = 2A (hex)

Byte B6 = 36 (hex)

Byte B8 = ?

Function	STL	Accumulator content	Operand content
Load byte B6 into the word accumulator.	L B6	2A	2A
Gate the contents of the word accumulator and byte B5 with AND.	A B5	22	36
Assign the gating result to byte B8.	= B8	22	22



## 8.15.19 AND NOT (AN)

### Logic processing with the AND NOT command

**Syntax:** AN (AND NOT)

**Operands:** M, I, O, T, C

**Action:**

- At the beginning of a logic sequence, this command functions like an LN command, i.e., the logical state of the operand is loaded into the logic accumulator. You should always begin a sequence of logical gating operations with a load command (see L, LN, L-).
- Within a logic sequence, gate the content of the logic accumulator and the logical state of the operand with AND NOT. The control saves the result of the operation in the logic accumulator.

**Example:**

Gate the inputs I4 and I5 with AND NOT, and assign the result to output O2.

Initial state:

Input I4 = 1  
Input I5 = 1  
Output O2 = ?

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I4	1	1
Gate the content of logic accumulator and input I5 with AND NOT.	AN I5	1	1
Assign the gating result to output O2.	= O2	1	1



**Word processing  
with the AND NOT  
command**

**Syntax:** AN (AND NOT)

**Operands:** B, W, D, K

**Action:**

Gate the contents of the word accumulator and the operand with AND NOT. In accordance with the different data widths of the operands (B = 8 bits; W = 16 bits; D = K = 32 bits), 8, 16 or 32 bits, respectively, are influenced in the accumulator. Thus, bit 0 of the accumulator is gated with bit 0 of the operand, bit 1 of the accumulator with bit 1 of the operand, etc. The control saves the result of the operation in the word accumulator.

**Example:**

Gate the content of words W4 and W6 with AND NOT, and assign the result to word W8.

Initial state:

Word W4 = 36 AA (hex)

Word W6 = 3C 36 (hex)

Word W8 = ?

Function	STL	Accumulator content	Operand content
Load W6 into the word accumulator.	L W6	3C36	3C36
Gate the contents of word accumulator and word W4 with AND NOT.	AN W4	814	36AA
Assign the gating result to word W8.	= W8	814	814

## 8.15.20 OR (O)

### Logic processing with the OR command

**Syntax:** O (OR)

**Operands:** M, I, O, T, C

**Action:**

- At the beginning of a logic sequence, this command functions like an L command, i.e., the logical state of the operand is loaded into the logic accumulator. You should always begin a sequence of logical gating operations with a load command (see L, LN, L-).
- Within a logic sequence, gate the content of the logic accumulator and the logical state of the operand with OR. The control saves the result of the operation in the logic accumulator.

**Example:**

Gate the inputs I4 and I5 with OR, and assign the result to output O2.

Initial state:

Input I4 = 0  
Input I5 = 1  
Output O2 = ?

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I4	0	0
Gate the content of the logic accumulator and input I5 with OR.	O I5	1	1
Assign the gating result to output O2.	= O2	1	1



**Word processing  
with the OR  
command**

**Syntax:** O (OR)

**Operands:** B, W, D, K

**Action:**

Gate the contents of the word accumulator and the operand with OR. In accordance with the different data widths of the operands (B = 8 bits; W = 16 bits; D = K = 32 bits), 8, 16 or 32 bits, respectively, are influenced in the accumulator. Thus, bit 0 of the accumulator is gated with bit 0 of the operand, bit 1 of the accumulator with bit 1 of the operand, etc. The control saves the result of the operation in the word accumulator.

**Example:**

Gate the content of byte B5 and byte B6 with OR, and assign the result to word W8.

Initial state:

Byte B5 = 2A (hex)

Byte B6 = 36 (hex)

Word W8 = ?

Function	STL	Accumulator content	Operand content
Load byte B6 into the word accumulator.	L B6	36	36
Gate the contents of the word accumulator and byte B5 with OR.	O B5	3E	2A
Assign the gating result to word W8.	= W8	3E	3E

## 8.15.21 OR NOT (ON)

### Logic processing with the OR NOT command

**Syntax:** ON (OR NOT)

**Operands:** M, I, O, T, C

**Action:**

- At the beginning of a logic sequence, this command functions like an LN command, i.e., the complement of the operand is loaded into the logic accumulator. You should always begin a sequence of logical gating operations with a load command (see L, LN, L-).
- Within a logic sequence, gate the content of the logic accumulator and the logical state of the operand with OR NOT. The control saves the result of the operation in the logic accumulator.

**Example:**

Gate the inputs I4 and I5 with OR NOT, and assign the result to output O2.

Initial state:

Input I4 = 0  
Input I5 = 0  
Output O2 = ?

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I4	0	0
Gate the content of logic accumulator and input I5 with OR NOT.	ON I5	1	0
Assign the gating result to output O2.	= O2	1	1



**Word processing  
with the OR NOT  
command**

**Syntax:** ON (OR NOT)

**Operands:** B, W, D, K

**Action:**

Gate the contents of the word accumulator and the operand with OR NOT. In accordance with the different data widths of the operands (B = 8 bits; W = 16 bits; D = K = 32 bits), 8, 16 or 32 bits, respectively, are influenced in the accumulator. Thus, bit 0 of the accumulator is gated with bit 0 of the operand, bit 1 of the accumulator with bit 1 of the operand, etc. The control saves the result of the operation in the word accumulator.

**Example:**

Gate the content of words W4 and W6 with OR NOT, and assign the result to word W8.

Initial state:

Word W4 = 36 AA (hex)

Word W6 = 3C 36 (hex)

Word W8 = ?

Function	STL	Accumulator content	Operand content
Load W6 into the word accumulator.	L W6	3C36	3C36
Gate the contents of word accumulator and word W4 with OR NOT.	ON W4	814	36AA
Assign the gating result to word W8.	= W8	814	814

## 8.15.22 EXCLUSIVE OR (XO)

### Logic processing with the EXCLUSIVE OR command

**Syntax:** XO (EXCLUSIVE OR)

**Operands:** M, I, O, T, C

**Action:**

- At the beginning of a logic sequence, this command functions like an L command, i.e., the logical state of the operand is loaded into the logic accumulator. You should always begin a sequence of logical gating operations with a load command (see L, LN, L-).
- Within a logic sequence, gate the content of the logic accumulator and the logical state of the operand with EXCLUSIVE OR. The control saves the result of the operation in the logic accumulator.

**Example:**

Gate the inputs I4 and I5 with EXCLUSIVE OR, and assign the result to output O2.

Initial state:

Input I4 = 1

Input I5 = 1

Output O2 = ?

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I4	1	1
Gate the content of logic accumulator and input I5 with EXCLUSIVE OR.	XO I5	0	1
Assign the gating result to output O2.	= O2	0	0



**Word processing  
with the  
EXCLUSIVE OR  
command**

**Syntax:** XO (EXCLUSIVE OR)

**Operands:** B, W, D, K

**Action:**

Gate the contents of the word accumulator and the operand with EXCLUSIVE OR. In accordance with the different data widths of the operands (B = 8 bits; W = 16 bits; D = K = 32 bits), 8, 16 or 32 bits, respectively, are influenced in the accumulator. Thus, bit 0 of the accumulator is gated with bit 0 of the operand, bit 1 of the accumulator with bit 1 of the operand, etc. The control saves the result of the operation in the word accumulator.

**Example:**

Gate the contents of byte B5 and byte B6 with EXCLUSIVE OR, and assign the result to word W8.

Initial state:

Byte B5 = 2A (hex)

Byte B6 = 36 (hex)

Word W8 = ?

Function	STL	Accumulator content	Operand content
Load byte B6 into the word accumulator.	L B6	36	36
Gate the contents of the word accumulator and byte B5 with EXCLUSIVE OR.	XO B5	1C	2A
Assign the gating result to word W8.	= W8	1C	1C



### 8.15.23 EXCLUSIVE OR NOT (XON)

#### Logic processing with the EXCLUSIVE OR NOT command

**Syntax:** XON (EXCLUSIVE OR NOT)

**Operands:** M, I, O, T, C

**Action:**

- At the beginning of a logic sequence, this command functions like an LN command, i.e., the logical state of the operand is loaded into the logic accumulator. You should always begin a sequence of logical gating operations with a load command (see L, LN, L-).
- Within a logic sequence, gate the content of the logic accumulator and the logical state of the operand with EXCLUSIVE OR NOT. The control saves the result of the operation in the logic accumulator.

**Example:**

Gate the inputs I4 and marker M500 with EXCLUSIVE OR NOT, and assign the result to output O2.

Initial state:

Input I4 = 0  
 Marker M500 = 0  
 Output O2 = ?

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L M500	0	0
Gate the content of logic accumulator and input I4 with EXCLUSIVE OR NOT.	XON I4	1	0
Assign the gating result to output O2.	= O2	1	1

#### Word processing with the EXCLUSIVE OR NOT command

**Syntax:** XON (EXCLUSIVE OR NOT)

**Operands:** B, W, D, K

**Action:**

Gate the contents of the word accumulator and the operand with EXCLUSIVE OR NOT. In accordance with the different data widths of the operands (B = 8 bits; W = 16 bits; D = K = 32 bits), 8, 16 or 32 bits, respectively, are influenced in the accumulator. Thus, bit 0 of the accumulator is gated with bit 0 of the operand, bit 1 of the accumulator with bit 1 of the operand, etc. The control saves the result of the operation in the word accumulator.



**Example:**

Gate the content of words W4 and W6 with EXCLUSIVE OR NOT, and assign the result to word W8.

Initial state:

Word W4 = 36 AA (hex)

Word W6 = 3C 36 (hex)

Word W8 = ?

Function	STL	Accumulator content	Operand content
Load W6 into the word accumulator.	L W6	3C36	3C36
Gate the contents of word accumulator and word W4 with EXCLUSIVE OR NOT.	XON W4	FFFFF563	36AA
Assign the gating result to word W8.	= W8	FFFFF563	FFFFF563



## 8.15.24 ADDITION (+)

**Syntax:** + (PLUS)

**Operands:** B, W, D, K

**Action:**

The control extends the operand to the width of the accumulator (32 bits) and then adds the content of the operand to the content of the word accumulator. The result of the operation is stored in the word accumulator where you can process it further.

**Example:**

Add the constant and the number saved in word W6, then assign the result to double word D8.

Initial state:

Constant = 10 000 (dec)

Word W6 = 200 (dec)

Double word D8 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K10000	10000	
Add the content of the word accumulator and word W6.	+ W6	10200	200
Assign the result to double word D8.	= D8	10200	10200



## 8.15.25 SUBTRACTION (-)

**Syntax:** - (MINUS)

**Operands:** B, W, D, K

**Action:**

The control extends the operand to the width of the accumulator (32 bits) and then subtracts the content of the operand from the content of the word accumulator. The result of the operation is stored in the word accumulator where you can process it further.

**Example:**

Subtract the number saved in word W6 from the constant, and then assign the result to double word D8.

Initial state:

Constant = 10 000 (dec)

Word W6 = 200 (dec)

Double word D8 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K10000	10000	
Subtract word W6 from the content of the word accumulator.	- W6	9800	9800
Assign the result to double word D8.	= D8	9800	9800

## 8.15.26 MULTIPLICATION (X)

**Syntax:** x (MULTIPLY)

**Operands:** B, W, D, K

**Action:**

The control extends the operand to the width of the accumulator (32 bits) and then multiplies the content of the operand by the content of the word accumulator. The result of the operation is stored in the word accumulator where you can process it further. If the control cannot execute the multiplication correctly, it then sets marker M4200, otherwise it resets it.

**Example:**

Multiply the constant by the number saved in word W6, then assign the result to double word D8.

Initial state:

Constant = 100 (dec)

Word W6 = 20 (dec)

Double word D8 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K100	100	
Multiply the content of the word accumulator by word W6.	x W6	2000	20
Assign the result to double word D8.	= D8	2000	2000





## 8.15.27 DIVISION (/)

**Syntax:** / (DIVIDE)

**Operands:** B, W, D, K

**Action:**

The control extends the operand to the width of the accumulator (32 bits) and then divides the content of the word accumulator by the content of the operand. The result of the operation is stored in the word accumulator where you can process it further. If the control cannot execute the division correctly, it then sets marker M4201, otherwise it resets it.

**Example:**

Divide the constant by the number saved in word W6, then assign the result to double word D8.

Initial state:

Constant = 100 (dec)

Word W6 = 20 (dec)

Double word D8 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K100	100	
Divide the content of the word accumulator by word W6	/ W6	5	20
Assign the result to double word D8.	= D8	5	5

## 8.15.28 REMAINDER (MOD)

**Syntax:** MOD (MODULO)

**Operands:** B, W, D, K

**Action:**

The control extends the operand to the width of the accumulator (32 bits) and then calculates the remainder resulting from the division of the content of the word accumulator by the content of the operand. The remainder is stored in the word accumulator where you can process it. If the control cannot execute the MOD command correctly, it sets marker M4202, otherwise it resets it.

**Example:**

Divide the number saved in word W6 by the constant, then calculate the REMAINDER and assign the result to double word D8.

Initial state:

Word W6 = 50 (dec)

Constant = 15 (dec)

Double word D8 = ?

Function	STL	Accumulator content	Operand content
Load W6 into the word accumulator.	L W6	50	50
Divide the content of the word accumulator by a constant, then save the integral REMAINDER in the word accumulator.	MOD K15	11	15
Assign the REMAINDER to double word D8.	= D8	11	11



### 8.15.29 INCREMENT (INC)

**INCREMENT operand**      **Syntax:**    INC (INCREMENT)  
**Operands:**    B, W, D  
**Action:**  
Increase the content of the addressed operand by one.

**INCREMENT word accumulator**      **Syntax:**    INCW (INCREMENT WORD)  
**Operands:**    None  
**Action:**  
Increase the content of the word accumulator by one.

**INCREMENT index register**      **Syntax:**    INCX (INCREMENT INDEX)  
**Operands:**    None  
**Action:**  
Increase the content of the index register by one.

### 8.15.30 DECREMENT (DEC)

**DECREMENT operand**      **Syntax:**    DEC (DECREMENT)  
**Operands:**    B, W, D  
**Action:**  
Decrease the content of the addressed operand by one.

**DECREMENT word accumulator**      **Syntax:**    DECW (DECREMENT WORD)  
**Operands:**    None  
**Action:**  
Decrease the content of the word accumulator by one.

**DECREMENT index register**      **Syntax:**    DECX (DECREMENT INDEX)  
**Operands:**    None  
**Action:**  
Decrease the content of the index register by one.



### 8.15.31 EQUAL TO (==)

**Syntax:** == (EQUAL)

**Operands:** B, W, D, K

**Action:**

This command sets off a direct transition from word to logical processing. Compare the content of the word accumulator with the content of the addressed operand. If the word accumulator and the operand are equal, the condition is true and the control sets the logic accumulator to 1. If they are not equal, the logic accumulator is set to 0. The comparison takes place over the number of bits corresponding to the operand:  
where B = 8 bits, W = 16 bits, and D = K = 32 bits.

**Example:**

Compare a constant with the content of double word D8, and assign the result to marker M500.

Initial state:

Constant = 16 000 (dec)

Double word D8 = 15 000 (dec)

Marker M300 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K16000	16000	
Compare the content of the word accumulator with the operand content D8; if not equal, set the logic accumulator to 0.	== D8	0	15000
Assign the result to marker M500.	= M500	0	0



### 8.15.32 LESS THAN (<)

**Syntax:** < (LESS THAN)

**Operands:** B, W, D, K

**Action:**

This command sets off a direct transition from word to logical processing. Compare the content of the word accumulator with the content of the addressed operand. If the word accumulator is less than the operand, the condition is true and the control sets the logic accumulator to 1. If the word accumulator is greater than or equal to the operand, it sets the logic accumulator to 0. The comparison takes place over the number of bits in the operand:

where B = 8 bits, W = 16 bits, and D = K = 32 bits.

**Example:**

Compare a constant with the content of double word D8, and assign the result to marker M500.

Initial state:

Constant = 16 000 (dec)

Double word D8 = 15 000 (dec)

Marker M500 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K16000	16000	
Check whether word accumulator < operand; if not, set logic accumulator to 0.	< D8	0	15000
Assign the result to marker M500.	= M500	0	0

### 8.15.33 GREATER THAN (>)

**Syntax:** > (GREATER THAN)

**Operands:** B, W, D, K

**Action:**

This command sets off a direct transition from word to logical processing. Compare the content of the word accumulator with the content of the addressed operand. If the word accumulator is greater than the operand, the condition is true and the control sets the logic accumulator to 1. If the word accumulator is less than or equal to the operand, it sets the logic accumulator to 0. The comparison takes place over the number of bits in the operand: where B = 8 bits, W = 16 bits, and D = K = 32 bits.

**Example:**

Compare a constant with the content of double word D8, and assign the result to marker M500.

Initial state:

Constant = 16 000 (dec)

Double word D8 = 15 000 (dec)

Marker M500 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K16000	16000	
Check whether word accumulator > operand; if so, set logic accumulator to 1.	> D8	1	15000
Assign the result to marker M500.	= M500	1	1



### 8.15.34 LESS THAN OR EQUAL TO (<=)

**Syntax:** <= (LESS EQUAL)

**Operands:** B, W, D, K

**Action:**

This command sets off a direct transition from word to logical processing. Compare the content of the word accumulator with the content of the addressed operand. If the word accumulator is less than or equal to the operand, the condition is true and the control sets the logic accumulator to 1. If the word accumulator is greater than the operand, it sets the logic accumulator to 0. The comparison takes place over the number of bits in the operand:

where B = 8 bits, W = 16 bits, and D = K = 32 bits.

**Example:**

Compare a constant with the content of double word D8, and assign the result to marker M500.

Initial state:

Constant = 16 000 (dec)

Double word D8 = 15 000 (dec)

Marker M500 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K16000	16000	
Check whether word accumulator <= operand; if not, set logic accumulator to 0.	<= D8	0	15000
Assign the result to marker M500.	= M500	0	0

### 8.15.35 GREATER THAN OR EQUAL TO (>=)

**Syntax:**        >= (GREATER EQUAL)

**Operands:**    B, W, D, K

**Action:**

This command sets off a direct transition from word to logical processing. Compare the content of the word accumulator with the content of the addressed operand. If the word accumulator is greater than or equal to the operand, the condition is true and the control sets the logic accumulator to 1. If the word accumulator is less than the operand, it sets the logic accumulator to 0. The comparison takes place over the number of bits in the operand: where B = 8 bits, W = 16 bits, and D = K = 32 bits.

**Example:**

Compare a constant with the content of double word D8, and assign the result to marker M500.

Initial state:

Constant                = 16 000 (dec)

Double word D8        = 15 000 (dec)

Marker                M500 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K16000	16000	
Check whether word accumulator >= operand; if so, set logic accumulator to 1.	>= D8	1	15000
Assign the result to marker M500.	= M500	1	1





### 8.15.36 NOT EQUAL (<>)

**Syntax:** <> (NOT EQUAL)

**Operands:** B, W, D, K

**Action:**

This command sets off a direct transition from word to logical processing. Compare the content of the word accumulator with the content of the addressed operand. If the word accumulator and the operand are not equal, the condition is true and the control sets the logic accumulator to 1. If they are equal, the logic accumulator is set to 0. The comparison takes place over the number of bits corresponding to the operand:  
where B = 8 bits, W = 16 bits, and D = K = 32 bits.

**Example:**

Compare a constant with the content of double word D8, and assign the result to marker M500.

Initial state:

Constant = 16 000 (dec)

Double word D8 = 15 000 (dec)

Marker M500 = ?

Function	STL	Accumulator content	Operand content
Load the constant into the word accumulator.	L K16000	16000	
Check whether word accumulator <> operand; if so, set logic accumulator to 1.	<> D8	1	15000
Assign the result to marker M500.	= M500	1	1

## 8.15.37 AND [ ] (A[ ])

**Syntax:** A[ ] (AND [ ])

**Operands:** None

**Action:**

The use of parentheses enables you to alter the sequence of processing logical commands in a statement list. The opening-parenthesis command puts the content of the accumulator onto the program stack. If you address the logic accumulator in the last command before an opening-parenthesis statement, the control loads the content of the logic accumulator onto the program stack. If you address the word accumulator, the control loads the contents of the word accumulator. The "close-parenthesis" statement gates the buffered value from the program stack with the content of the logic accumulator or the word accumulator, depending on which accumulator was addressed prior to the "open-parenthesis" instruction. The control assigns the result of the gating operation to the corresponding accumulator. Maximum nesting depth: 16 parentheses.


Please note:

The sequence of function is the same for word processing; however, the control writes the complete word accumulator onto the program stack.

**Example:**

Example for the commands AND [ ], AND NOT [ ], OR [ ], OR NOT [ ], EXCLUSIVE OR [ ], EXCLUSIVE OR NOT [ ]:

Use parentheses to develop a statement list in accordance with the following logic circuit diagram:



Initial state:

Marker M500 = 0  
Input I0 = 0  
Marker M501 = 1  
Input I1 = 1  
Output O12 = ?

Function	STL	Accumulator content	Operand content
Load marker M500 into the logic accumulator.	L M500	0	0
Gate logic accumulator with marker M501.	O M501	1	1
Opening parenthesis: Buffer the accumulator content onto the program stack.	A[		
Load the state of input I0 into the logic accumulator.	L I0	0	0
Gate the logic accumulator with the state of input I1.	O I1	1	1
Closing parenthesis: Gate the accumulator content with the program stack (A[, O[...]).	]		
Assign the result of the total operation to output O12.	= O12	1	1

### 8.15.38 AND NOT [ ] (AN[ ])

**Syntax:** AN[ ] (AND NOT [ ])

**Operands:** None

**Action:**

See example of command A[ ] (AND [ ])

### 8.15.39 OR [ ] (O[ ])

**Syntax:** O[ ] (OR [ ])

**Operands:** None

**Action:**

See example of command A[ ] (AND [ ])

### 8.15.40 OR NOT [ ] (ON[ ])

**Syntax:** ON[ ] (OR NOT [ ])

**Operands:** None

**Action:**

See example of command A[ ] (AND [ ])

### 8.15.41 EXCLUSIVE OR [ ] (XO[ ])

**Syntax:** XO[ ] (EXCL: OR [ ])

**Operands:** None

**Action:**

See example of command A[ ] (AND [ ])

### 8.15.42 EXCLUSIVE OR NOT [ ] (XON[ ])

**Syntax:** XON[ ] (EXCL: OR NOT [ ])

**Operands:** None

**Action:**

See example of command A[ ] (AND [ ])



### 8.15.43 ADDITION [ ] (+ [ ])

**Syntax:** +[ ] (PLUS[ ])

**Operands:** None

**Action:**

Use parentheses together with arithmetical commands **only** for word processing. By using parentheses you can change the sequence of processing in a statement list. The opening-parenthesis command puts the content of the word accumulator onto the program stack. This clears the accumulator for calculation of intermediate results. The closing-parenthesis command gates the buffered value from the program stack with the content of the word accumulator. The control saves the result in the accumulator again. Maximum nesting depth: 16 parentheses. If an error occurs during calculation, the control sets the marker M4201.

**Example:**

Example for the commands ADD [ ], SUBTRACT [ ], MULTIPLY [ ], DIVIDE [ ], REMAINDER [ ].

Divide a constant by double word D36, add the result to double word D12, and assign the result to double word D100.

Initial state:

Constant = 1000 (dec)  
 Double word D12 = 15000 (dec)  
 Double word D36 = 100 (dec)  
 Double word D100 = ?

Function	STL	Accumulator content	Operand content
Load the double word D12 into the word accumulator.	L D12	15000	15000
Opening parenthesis: Buffer the accumulator content onto the program stack.	+[		
Load the constant K1000 into the word accumulator.	L K1000	1000	
Divide the word accumulator by the content of the double word D36.	/ D36	10	100
Closing parenthesis: Gate the accumulator content with the program stack (+[, -[ .....).	]		
Assign the result of the total operation to double word D100.	= D100	15010	15010



#### 8.15.44 SUBTRACT [ ] (-[ ])

**Syntax:** -[ ] (MINUS -[ ])

**Operands:** None

**Action:**

See example of command ADD [ ]

#### 8.15.45 MULTIPLY [ ] (x[ ])

**Syntax:** x[ ] (MULTIPLY [ ])

**Operands:** None

**Action:**

See example of command ADD [ ]

#### 8.15.46 DIVIDE [ ] (/[ ])

**Syntax:** /[ ] (DIVIDE [ ])

**Operands:** None

**Action:**

See example of command ADD [ ]

#### 8.15.47 REMAINDER [ ] (MOD[ ])

**Syntax:** MOD[ ] (MODULO [ ])

**Operands:** None

**Action:**

See example of command ADD [ ]



## 8.15.48 EQUAL TO [ ] (== [ ])

**Syntax:** ==[ ] (EQUAL[ ])

**Operands:** None

**Action:**

By using parentheses you can change the sequence of processing comparative commands in a statement list. The opening-parenthesis command puts the content of the word accumulator onto the program stack. This clears the accumulator for calculation of intermediate results.

The closing-parenthesis command gates the buffered value from the program stack with the content of the word accumulator. The control saves the result in the accumulator again. Maximum nesting depth: 16 parentheses.

Comparative commands cause a direct transition from word to logical processing. If the specified comparative condition is true, the control sets the logic accumulator to 1; if the condition is not fulfilled, it sets it to 0.

See next page for example.

**Example:**

Multiply a constant by double word D36, compare the result with double word D12, and assign the result to output O15.

Initial state:

Constant = 1000 (dec)  
 Double word D12 = 15000 (dec)  
 Double word D36 = 10 (dec)  
 Output O15 = ?

Function	STL	Accumulator content	Operand content
Load the double word D12 into the word accumulator.	L D12	15000	15000
Opening parenthesis: Buffer the accumulator content onto the program stack.	== [		
Load the constant into the word accumulator.	L K1000	1000	
Multiply the content of the word accumulator with double word D36.	x D36	10000	10
Closing parenthesis: Gate the accumulator content with the program stack (==[, >=[ ...]); if condition not fulfilled, set logic accumulator to 0.	]		
Assign the result to output O15.	= O15	0	0

#### 8.15.49 LESS THAN [ ] (<[ ])

**Syntax:** <[ ] (LESS THAN [ ])

**Operands:** None

**Action:**

See example of command EQUAL TO [ ]

#### 8.15.50 GREATER THAN [ ] (>[ ])

**Syntax:** >[ ] (GREATER THAN [ ])

**Operands:** None

**Action:**

See example of command EQUAL TO [ ]

#### 8.15.51 LESS THAN OR EQUAL TO [ ] (<=[ ])

**Syntax:** <=[ ] (LESS EQUAL [ ])

**Operands:** None

**Action:**

See example of command EQUAL TO [ ]

#### 8.15.52 GREATER THAN OR EQUAL TO [ ] (>=[ ])

**Syntax:** >=[ ] (GREATER EQUAL [ ])

**Operands:** None

**Action:**

See example of command EQUAL TO [ ]

#### 8.15.53 NOT EQUAL [ ] (<>[ ])

**Syntax:** <>[ ] (NOT EQUAL [ ])

**Operands:** None

**Action:**

See example of command EQUAL TO [ ]





### 8.15.54 SHIFT LEFT (<<)

**Syntax:** << (SHIFT LEFT)

**Operands:** B, W, D, K

**Action:**

A SHIFT LEFT statement multiplies the content of the word accumulator by two. This is done by simply shifting the bits in the accumulator by one place to the left. The result must lie in the range of -2 147 483 648 to +2 147 483 647, otherwise the accumulator contains an undefined value. You define the number of shifts through the operand. The control fills the right end of the accumulator with zeros.

This statement is one of the arithmetic commands because it includes the sign bit. For this reason, and to save time, you should not use this command to isolate bits.

**Example:**

Shift the content of double word D8 four times to the left, then assign it to double word D12.

Initial state:

Double word D8 = 3E 80 (hex)

Double word D12 = ?

Function	STL	Accumulator content	Operand content
Load the double word D8 into the word accumulator	L D8	3E80	3E80
Shift the content of the word accumulator to the left by the number of bits that are specified in the operand.	<< K+1	7D00	
	<< K+1	FA00	
	<< K+1	1F400	
	<< K+1	3E800	
Assign the result to double word D12.	= D12	3E800	3E800

Instead of using the << K+1 command four times, simply use the << K+4 command.



### 8.15.55 SHIFT RIGHT (>>)

**Syntax:** >> (SHIFT RIGHT)

**Operands:** B, W, D, K

**Action:**

A SHIFT RIGHT statement divides the content of the word accumulator by two. This is done by simply shifting the bits by one place to the right. You define the number of shifts through the operand. The bits that the control shifts to the right out of the accumulator are then lost. The control extends the left side of the accumulator with the correct sign.

This statement is one of the arithmetic commands because it includes the sign bit. For this reason, and to save time, you should not use this command to isolate bits.

**Example:**

Shift the content of double word D8 four times to the right, then assign it to double word D12.

Initial state:

Double word D8 = 3E 80 (hex)

Double word D12 = ?

Function	STL	Accumulator content	Operand content
Load the double word D8 into the word accumulator	L D8	3E80	3E80
Shift the content of the word accumulator to the right by the number of bits that are specified in the operand.	>> K+1	1F40	
	>> K+1	FA0	
	>> K+1	7D0	
	>> K+1	3E8	
Assign the result to double word D12.	= D12	3E8	3E8

Instead of using the >> K+1 command four times, simply use the >> K+4 command.

### 8.15.56 BIT SET (BS)

**Syntax:** BS (BIT SET)

**Operands:** B, W, D, K, X

**Action:**

With the BIT SET command you can set each bit in the accumulator to 1. The corresponding bits are selected (addressed) by the content of the specified operand or by a constant. As to the bit numbering, bit 0 = LSB and bit 31 = MSB. For operand contents greater than 32, the control uses the operand value modulo 32, i.e. the integral remainder of the result of the operand value divided by 32.



**Example:**

Load double word D8 into the accumulator, set bit 0 of the accumulator to 1, and save the result in double word D12.

Initial state:

Double word D8 = 3E 80 (hex)

Double word D12 = ?

Function	STL	Accumulator content	Operand content
Load the double word D8 into the word accumulator	L D8	3E80	3E80
Set the bit specified in the operand to 1.	BS K+0	3E81	
Assign the result to double word D12.	= D12	3E81	3E81

**8.15.57 BIT CLEAR (BC)**

**Syntax:** BC (BIT CLEAR)

**Operands:** B, W, D, K, X

**Action:**

The BIT CLEAR command is used to set each bit in the accumulator to 0. The corresponding bits are selected (addressed) by the content of the specified operand or by a constant. As to the bit numbering, bit 0 = LSB and bit 31 = MSB. For operand contents greater than 32, the control uses the operand value modulo 32, i.e. the integral remainder of the result of the operand value divided by 32.

**Example:**

Load double word D8 into the accumulator, set bit 0 of the accumulator to 0, and save the result in double word D12.

Initial state:

Double word D8 = 3E 81 (hex)

Double word D12 = ?

Function	STL	Accumulator content	Operand content
Load the double word D8 into the word accumulator	L D8	3E81	3E81
Set the bit specified in the operand to 0.	BC K+0	3E80	
Assign the result to double word D12.	= D12	3E80	3E80

## 8.15.58 BIT TEST (BT)

**Syntax:** BT (BIT TEST)

**Operands:** B, W, D, K, X

**Action:**

With the BIT TEST command, you can interrogate the status of each bit in the accumulator. With the BT command there is a direct transition from word to logic processing, i.e. the control checks the state of a bit in the word accumulator and then sets the logic accumulator. If the interrogated bit = 1, the control sets the logic accumulator to 1; otherwise it sets it to 0. The corresponding bits are selected (addressed) by the content of the specified operand or by a constant. As to the bit numbering, bit 0 = LSB and bit 31 = MSB. For operand contents greater than 32, the control uses the operand value modulo 32, i.e. the integral remainder of the result of the operand value divided by 32.

**Example:**

Load the double word D8 into the accumulator and assign the logical state of bit 0 to output O12.

Initial state:

Double word D8 = 3E 81 (hex)

Output O12 = ?

Function	STL	Accumulator content	Operand content
Load the double word D8 into the word accumulator	L D8	3E81	3E81
Check the state of the bit specified in the operand.	BT K+0	1	
Assign the result to output O12.	= O12	1	1



## 8.15.59 PUSH DATA ONTO THE DATA STACK (PS)

### Logic processing with the PS command

**Syntax:** PS (PUSH)  
**Operands:** M, I, O, T, C  
**Action:**

The PS command enables you to buffer data. To do this, the control loads the addressed operand onto the data stack. Because the data stack has a width of 32 bits, you must write to it with a minimum width of one word. The control copies the operand value into bit 7 of the data stack's current address. The vacant bits of the occupied memory remain undefined or unused. In the event of a stack overflow, the control outputs an error message.

Data stack [bit]																
31	...	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
x	...		x	x	x	x	x	x	L	x	x	x	x	x	x	x

**Example:**  
 See PSW command.

### Word processing with the PS command

**Syntax:** PS (PUSH)  
**Operands:** B, W, D, K  
**Action:**

The PS command enables you to buffer data. The control copies the addressed operand value into the current address of the data stack. During the word processing, the control copies two words per PS command onto the data stack and extends the operand—in accordance with the MSB—with the correct algebraic sign. In the event of a stack overflow, the control displays an error message.

Data stack for byte, word, double word and constant [bit]																
31	.....	24	23	.....	16	15	.....	8	7	.....	0					
x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D
K	K	K	K	K	K	K	K	K	K	K	K	K	K	K	K	K

**Example:**  
 See PSW command.



### 8.15.60 PULL DATA FROM THE DATA STACK (PL)

#### Logic processing with the PL command

**Syntax:** PL (PULL)  
**Operands:** M, I, O, T, C  
**Action:**

The PL command is the counterpart to the PS command. Data that has been buffered with the PUSH command can be taken from the data stack by using the PULL command. The control copies bit 7 of the data stack's current address into the addressed operand. If the stack is empty, the control displays an error message.

**Example:**

See PSW command.

#### Word processing with the PL command

**Syntax:** PL (PULL)  
**Operands:** B, W, D, K  
**Action:**

The PL command is the counterpart to the PS command. Data that has been buffered with the PUSH command can be taken from the data stack by using the PULL command. During the word processing, the control copies with the PL command two words of the current data stack address into the addressed memory area. If the stack is empty, the control displays an error message.

**Example:**

See PSW command.

### 8.15.61 PUSH LOGIC ACCUMULATOR ONTO THE DATA STACK (PSL)

**Syntax:** PSL (PUSH LOGICACCU)  
**Operands:** None  
**Action:**

The PSL command enables you to buffer the logic accumulator. With the PSL command, the control copies the logic accumulator onto the data stack. Because the data stack has a width of 32 bits, you must write to it with a minimum width of one word. The control copies the operand value into bit 7 of the data stack's current address. The vacant bits of the occupied memory remain undefined or unused. In the event of a stack overflow, the control outputs an error message.

Data stack [bit]																
31	...	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
x	...		x	x	x	x	x	x	L	x	x	x	x	x	x	x

**Example:**

See PSW command.



### 8.15.62 PUSH WORD ACCUMULATOR ONTO THE DATA STACK (PSW)

**Syntax:** PSW (PUSH WORDACCU)

**Operands:** None

**Action:**

The PSW command enables you to buffer the word accumulator. With the PSW command, the control copies the word accumulator onto the data stack. The content of the word accumulator (32 bits) occupies two words on the data stack. In the event of a stack overflow, the control displays an error message.

**Example:**

Since the sequence is the same for all stack operations, this example also applies to the commands PS, PL, PSW, PLL, PLW. The difference between the individual operations lies merely in the transferred data width.

Call Module 15 at a certain place in the program. After returning to the main program, restore the original accumulator content. Accumulator content before the module call: 1A 44 3E 18

Function	STL	Accumulator content	Data stack
Buffer the word accumulator in the data stack	PSW	1A443E18	1A443E18
Call subroutine 15	CM 15		
Restore data stack into word accumulator.	PLW	1A443E18	1A443E18

### 8.15.63 PULL LOGIC ACCUMULATOR FROM THE DATA STACK (PLL)

**Syntax:** PLL (PULL LOGICACCU)

**Operands:** None

**Action:**

The PLL command is the counterpart to the PSL command. Data that has been buffered with the PUSH command can be restored from the data stack by using the PULL command. The control copies bit 7 of the data stack's current address into the logic accumulator. If the stack is empty, the control displays an error message.

**Example:**

See PSW command.



### 8.15.64 PULL WORD ACCUMULATOR FROM THE DATA STACK (PLW)

**Syntax:** PLW (PULL WORDACCU)

**Operands:** None

**Action:**

The PLW command is the counterpart to the PSW command. Data that has been buffered with the PUSH command can be restored from the data stack by using the PULL command. During the word processing, the control copies with the PLW command two words of the current data stack address into the word accumulator. If the stack is empty, the control displays an error message.

**Example:**

See PSW command.

### 8.15.65 UNCONDITIONAL JUMP (JP)

**Syntax:** JP (JUMP)

**Operands:** Label (LBL)

**Action:**

After a JP command, the control jumps to the label that you have entered and resumes the program from there. The JP command interrupts a logic sequence.

**Example:**

See JPT command.





### 8.15.66 JUMP IF LOGIC ACCUMULATOR = 1 (JPT)

**Syntax:** JPT (JUMP IF TRUE)

**Operands:** Label (LBL)

**Action:**

The JPT command is a conditional jump command. If the logic accumulator = 1, the control resumes the program at the label that you have entered. If the logic accumulator = 0, the control does not jump. The JPT command interrupts a logic sequence.

**Example:**

This example also applies to the JP and JPF commands.

Depending on the state of the input I5, skip a certain program section.

Initial state:

Input I5 = 1

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I5	1	1
If logic accumulator =1, jump to LBL 10.	JPT 10	1	
Skip the function.	L I3		
Skip the function.	O M500		
Skip the function.	= 020		
Label	LBL 10		
Resume the program run.	L M100 .....	0	0



### 8.15.67 JUMP IF LOGIC ACCUMULATOR = 0 (JPF)

**Syntax:** JPT (JUMP IF FALSE)

**Operands:** Label (LBL)

**Action:**

The JPF command is a conditional jump command. If the logic accumulator = 0, the control resumes the program at the label that you have entered. If the logic accumulator = 1, the control does not jump. The JPF command interrupts a logic sequence.

**Example:**

See JPT command.

### 8.15.68 CALL MODULE (CM)

**Syntax:** CM (CALL MODULE)

**Operands:** Label (LBL)

**Action:**

After a CM command, the control calls the module that begins at the label that you have entered. Modules are independent subroutines that must be ended with the command EM. You can call modules as often as you wish from different places in your program. The CM command interrupts a logic sequence.

**Example:**

See CMF command.

### 8.15.69 CALL MODULE IF LOGIC ACCUMULATOR = 1 (CMT)

**Syntax:** CMT (CALL MODULE IF TRUE)

**Operands:** Label (LBL)

**Action:**

The CMT command is a conditional module call. If the logic accumulator = 1, the control calls the module that begins at the label you have entered. If the logic accumulator = 0, the control does not call the module. The CMT command interrupts a logic sequence.

**Example:**

See CMF command.



### 8.15.70 CALL MODULE IF LOGIC ACCUMULATOR = 0 (CMF)

**Syntax:** CMF (CALL MODULE IF FALSE)

**Operands:** Label (LBL)

**Action:**

The CMF command is a conditional module call. If the logic accumulator = 0, the control calls the module that begins at the label you have entered. If the logic accumulator = 1, the control does not call the module. The CMF command interrupts a logic sequence.

**Example:**

This example also applies to the CM and CMT commands.

Depending on the state of the input I5, call the Module 10. Initial state:  
Input I5 = 0

Function	STL	Accumulator content	Operand content
Load the operand content into the logic accumulator.	L I5	0	0
If logic accumulator =0, jump to LBL 10.	CMF 10	0	
Resume main program after module execution.	L M100	1	1
	⋮		
End of main program	EM		
Label: Beginning of module	LBL 10		
Statement in the module	L I3	0	0
Statement in the module	O M500	1	1
Statement in the module	= O20	1	1
End of module, resume the main program with the command L M100	EM		



### 8.15.71 END OF MODULE, END OF PROGRAM (EM)

**Syntax:** EM (END OF MODULE)

**Operands:** None

**Action:**

You must end each program or subroutine (module) with the EM command. An EM command at the end or within a module causes a return jump to the module call (CM, CMT, CMF). The control then resumes the program with the statement that follows the module call. The control interprets the EM command as program end. The control can reach the subsequent program instructions only through a jump command.

### 8.15.72 END OF MODULE IF LOGIC ACCUMULATOR = 1 (EMT)

**Syntax:** EMT (END OF MODULE IF TRUE)

**Operands:** None

**Action:**

An EMT command causes a return jump to the module call (CM, CMT, CMF) only if the logic accumulator = 1.

### 8.15.73 END OF MODULE IF LOGIC ACCUMULATOR = 0 (EMF)

**Syntax:** EMF (END OF MODULE IF FALSE)

**Operands:** None

**Action:**

An EMF command causes a return jump to the module call (CM, CMT, CMF) only if the logic accumulator = 0.

### 8.15.74 LABEL (LBL)

**Syntax:** LBL (LABEL)

**Operands:** ASCII name; maximum length: 32 characters

**Action:**

The label defines a program location as an entry point for the JP and CM commands. You can define up to 1000 jump labels per file. The ASCII name of the label may be up to 32 characters long. However, the control evaluates only the first 16 characters.

For importing global labels, see EXTERN statement.



## 8.16 INDEX Register (X Register)

You can use the index register for:

- Data transfer
- Buffering results
- Indexed addressing of operands

The index register is 32 bits wide.

You can use the X register anywhere in the program. The control does not check whether the current content is valid. Exception: For indexed write-accesses, the control checks whether the permissible address range is exceeded.

Example: = B100[X]

When the permissible address range is exceeded, the control issues the error message **320-0420 PLC: index range incorrect**. After restarting the control, you must not acknowledge the **POWER INTERRUPTED** message. Switch to the PLC editor, where you will be shown the error line.



### Note

At the beginning of the PLC cycle, the control sets the index register to 0. Assign the index register a defined value before using it in your program.

The following addresses are valid:

- Mn[X]
- In[X]
- On[X]
- Cn[X]
- Tn[X]Operand number = n+X
- Bn[X]Operand number = n+X
- Wn[X]Operand number = n+2\*X
- Dn[X]Operand number = n+4\*X
- BTX Content of index register = operand
- BCX Content of index register = operand
- BSX Content of index register = operand
- Sn[X]String number = n+X
- S#Dn[X]Dialog text number = n+X
- S#En[X]Error text number = n+X
- S#An[X]ASCII code +X
- Sn^X Substring from X-th character of the n-th string

The types K, and K\$ cannot be indexed.



### Note

If you address S#Dn[X] or S#En[X], the control loads the sequence <SUB>Dnnn or <SUB>Ennn in the string accumulator, where nnn is the modified string number.

## **Commands for operating the index register**

The following commands are available for exchanging data between the word accumulator and index register, or between the stack and index register:

- LX (Load index to accu) Index register – word accumulator
- =X (Store accumulator to index) Word accumulator – index register
- PSX (Push index register) Index register – stack
- PLX (Pull index register) Stack – index register
- INCX (Increment index register)
- DECX (Decrement index register)



## 8.17 Commands for String Processing

String processing enables you to use the PLC program to generate and manipulate any texts. Use Module 9082 to display these texts in the PLC window of the screen, and delete them with Module 9080. A string accumulator as well as 100 string memories (S0 to S99), in each of which you can save a maximum of 128 characters, are provided in the control for string processing:

String accumulator (characters)	
1	128
x x x x x x x x x x x x x x ..... x x x x x x x x x x x x x x	

String memory (characters)	
	1 128
S0	x x x x x x x x x x x x x x ..... x x x x x x x x x x x x x x
...	x x x x x x x x x x x x x x ..... x x x x x x x x x x x x x x

### Example

String accumulator (characters)	
1	128
C O O L A N T O N	

String accumulator and string memory are volatile, which means that they are erased by the control when power is switched off. The operand "S" is available for string processing. You can use the operand "S" with different arguments.



## Operand declaration

The "S" operands are to be used only for string processing. You can target the following addresses with the various arguments:

- Addressing string memory: After the operand designation, specify the number of the desired memory (S0 to S99).
- Symbolic operands (B/W/D operands) can now be used for indexed access to the string operands "S" or the PLC error and dialog files.

Examples: **#define offset D100**

```
...  
L S2[offset]  
= S8  
...
```

or

```
S#D900[NP_W1022_Module_error_status]
```

- Address part of a string: Use the address Sn^X (see INDEX Register). The control addresses the substring beginning with the X-th character of the specified string.  
Effective immediately, addressing with symbolic operands is also possible: Sn^symbolic operand (B/W/D operand).
- Immediate string: You can also enter a string directly in the PLC program. The text string, which may contain a maximum of 128 characters, must be indicated by quotation marks.  
Example: **"Coolant 1 on"**
- Texts from the PLC error message file or from the PLC dialog file: By specifying the line number you can read texts from the active error message file or dialog file: **PLC-ERROR: S#Exx xx**: Line number from the PLC error message file (0 to 999)  
**PLC-DIALOG: S#Dxx xx**: Line number from the PLC dialog file (0 to 999).  
Enter the string #Exx or #Dxx in the argument <arg> of the string command. The control then saves a 5-byte-long string <SUB> E0xx or <SUB> D0xx (<SUB> = ASCII <SUB>) in the accumulator. Instead of this string, the control reads the line xx of the active error message or dialog file on the screen.
- Enter an ASCII character in the string. Define the ASCII character through its code: S#Axxx

## Logical comparisons during string processing

Use the following procedure to compare two strings, depending on the argument:

- If you compare string memories or immediate strings, the control checks both strings character by character. After the first character that does not fulfill the condition of comparison, the control resets the logic accumulator. The control does not check the remaining characters. During a comparison, the control always uses the significance of the characters from the ASCII table. This results, for example, in:  
A < B  
AA > A
- If you have entered PLC error messages or PLC dialog texts in the argument, the control compares the position in the error-message file or dialog file (0 to 999), but not the actual text as in an immediate string.

The processing times depend on the length of the strings.



## 8.18 LOAD String (L)

**Syntax:** L (LOAD)

**Operands:** S <arg>

**Action:**

Load the string accumulator. The string that the control is to load is selected through the argument <arg> after the operand designation. See also "Operand declaration."

**Example:**

See OVWR command.

## 8.19 ADD String (+)

**Syntax:** + (PLUS)

**Operands:** S <arg>

**Action:**

Append another string to a string in the string accumulator. The string that the control is to load is selected through the argument <arg> after the operand designation. See also "Operand declaration." The resulting string must not be longer than 128 characters.

**Example:**

See OVWR command.

## 8.20 STORE String (=)

**Syntax:** = (STORE)

**Operands:** S <arg>

**Action:**

Assign the content of the string accumulator to the string memory. The memory into which the control is to copy the string is selected through the argument <arg> after the operand designation. Permissible arguments: 0 to 15 (String memory S0 to S99). See also "Operand declaration."

**Example:**

See OVWR command.

## 8.21 OVERWRITE String (OVWR)

**Syntax:** OVWR (OVERWRITE)

**Operands:** S <arg>

**Action:**

Save the string from the string accumulator in a string memory. This command differs from the = command in that the control does not transfer the "string end" character along with it. In this way you can overwrite the beginning of a string that is already in the string memory. The memory into which the control is to copy the string is selected through the argument <arg> after the operand designation. Permissible arguments: 0 to 99 (string memory S0 to S99). See also "Operand declaration."

**Example:**

This example also applies to the string commands L, + and =.

Add a string from the string memory S0 to an immediate string. The result is to overwrite the contents of string memory S1. Initial state:

Immediate string           = **HYDRAULICS**  
 String memory        S0    = **OIL**  
 String memory        S1    = **COOLANT MISSING**

String memory (characters)	
	1 128
S0	<b>O I L</b>
S1	<b>C O O L A N T M I S S I N G</b>
...	...

Function	STL	String accumulator (characters)
		1 128
Load the immediate string into the string accumulator	L S "HYDRAUL."	<b>O I L</b>
Add content of string memory S0 to string accumulator.	+ S0	<b>H Y D R A U L . O I L</b>
Overwrite content of string memory S1 with content of string accumulator.	OVWR S1	<b>H Y D R A U L . O I L</b>

Final status:

String memory (characters)	
	1 128
S0	<b>O I L</b>
S1	<b>H Y D R A U L . O I L M I S S I N G</b>
...	...



## 8.22 EQUAL TO Command for String Processing (==)

**Syntax:** == (EQUAL)

**Operands:** S <arg>

**Action:**

This command sets off a direct transition from string to logical processing. Compare the content of the string accumulator with the string in the argument. If the string accumulator and the operand are equal, the condition is true and the control sets the logic accumulator to 1. If they are not equal, the control sets the logic accumulator to 0.

**Example:**

See command <>.

## 8.23 LESS THAN Command for String Processing (<)

**Syntax:** < (LESS THAN)

**Operands:** S <arg>

**Action:**

This command sets off a direct transition from string to logical processing. Compare the content of the string accumulator with the string in the argument. If the string accumulator is less than the operand, the condition is true and the control sets the logic accumulator to 1. If the string accumulator is greater than or equal to the operand, it sets the logic accumulator to 0.

**Example:**

See command <>.

## 8.24 GREATER THAN Command for String Processing (>)

**Syntax:** > (GREATER THAN)

**Operands:** S <arg>

**Action:**

This command sets off a direct transition from string to logical processing. Compare the content of the string accumulator with the string in the argument. If the string accumulator is greater than the operand, the condition is true and the control sets the logic accumulator to 1. If the string accumulator is less than or equal to the operand, it sets the logic accumulator to 0.

**Example:**

See command <>.

## 8.25 LESS THAN OR EQUAL TO Command for String Processing (<=)

**Syntax:** <= (LESS EQUAL)

**Operands:** S <arg>

**Action:**

This command sets off a direct transition from string to logical processing. Compare the content of the string accumulator with the string in the argument. If the string accumulator is less than or equal to the operand, the condition is true and the control sets the logic accumulator to 1. If the string accumulator is greater than the operand, it sets the logic accumulator to 0.

**Example:**

See command <>.

## 8.26 GREATER THAN OR EQUAL TO Command for String Processing (>=)

**Syntax:** >= (GREATER EQUAL)

**Operands:** S <arg>

**Action:**

This command sets off a direct transition from string to logical processing. Compare the content of the string accumulator with the string in the argument. If the string accumulator is greater than or equal to the operand, the condition is true and the control sets the logic accumulator to 1. If the string accumulator is less than the operand, it sets the logic accumulator to 0.

**Example:**

See command <>.



## 8.27 NOT EQUAL Command for String Processing (<>)

**Syntax:** <> (NOT EQUAL)

**Operands:** S <arg>

**Action:**

This command sets off a direct transition from string to logical processing. Compare the content of the string accumulator with the string in the argument. If the string accumulator is not equal to the operand, the condition is true and the control sets the logic accumulator to 1. If the string accumulator is equal to the operand, it sets the logic accumulator to 0.

**Example:**

This example of string processing also applies to the commands =, <, >, <=, >=, <>.

Compare the immediate string with the content of the string memory S0. Depending on the result, call Module 50.

Initial state:

String memory S0 = SPINDLE 2  
 Immediate string = SPINDLE 1

String memory (characters)	
	1 128
S0	S P I N D L E 2
...	...

Function	STL	String accu. (characters), or logic accu.
		1 128
Load the immediate string into the string accumulator	LS "SPINDLE 1"	S P I N D L E 1
Gate the content of string memory S0 with content of string accumulator (=, <, >, >=, ...)	<> S0	S P I N D L E 2
If the condition is fulfilled, set logic accumulator to 1 and call the module.	CMT 50	Logic accumulator = 1



## 8.28 Modules for string processing

### Module 9070 Copy a number from a string

The control searches a selectable string memory (S0 to S99) for a numerical value. The control copies the first numerical value found as a string into another selectable string memory. The control does not check whether a conflict arises between the source and target string. It may overwrite the source string (even then, however, the function of the module is ensured). The control recognizes unsigned and signed numbers, with and without decimal places. Both the period and comma are permitted as decimal point. The control returns the position (in characters) of the first character after the found number in the string memory to be searched.

Call:

```
PS   K/B/W/D <Address of the string memory to be searched>
PS   K/B/W/D <Address of the string memory for the found number>
CM   9070
PL   B/W/D   <Offset end of numerical string in the searched string
          memory>
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Number copied
	1	Error. See NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	2	Invalid address of the source string or target string
	11	No number, no string end, or number string has a length of more than 79 characters

#### Example

```
L S"X-P0S.:123"
= S0
PS K+0
PS K+1
CM 9070
PL W520
```

String memory (characters)		Data stack [bit]
	1      ...      10      ...      128	
S0	X - P O S . : 1 2 3	
S1	1 2 3	10
...	...	



### Module 9071 Find the string length

The control finds the length of the string in a selectable string memory (S0 to S99).

Call:

PS K/B/W/D/S<String no. or string>

CM 9071

PL B/W/D <Length of the string>

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	String length found
	1	Error. See NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	2	Invalid immediate strings, address of the source or target string is out of range (S0 to S99), string memory was searched but no string end was found

### Module 9072 Copy a byte block into a string

The control copies a byte block from a PLC word memory into a PLC string (S0 to S99). The control does not check whether the byte block consists of valid ASCII characters. The module always copies the entire programmed length of the byte block, regardless of any string-end code (0x00) in the byte block. The control automatically sets a string end code (0x00) after the last copied byte. If there are any ASCII special characters in the copied byte block, the contents of the string may not be displayed in the PLC diagnosis correctly.

Call:

PS K/B/W/D <Start address of byte block>

PS K/B/W/D <Length of byte block>

PS K/B/W/D <PLC string>

CM 9072

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Byte block copied into PLC string (S0 to S99)
	1	Error. See NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Invalid start address of the programmed byte block
	2	Invalid length of the programmed byte block (max. 127 characters)
	4	Invalid sum of the start address and the programmed block length
	11	Invalid target string

### Module 9073 Copy a string into a byte block

The control copies a PLC string into the word range of the PLC. The control does not check whether the string consists of valid ASCII characters. The programmed length of the string is always copied, regardless of any end-of-string identifiers (0x00). If there are any ASCII special characters or an end-of-string identifier (0x00) in the copied string, the contents of the string will not be displayed correctly in the PLC diagnostics.

Call:

PS K/B/W/D <Target address of byte block>

PS K/B/W/D <Length of byte block>

PS K/B/W/D <PLC string>

CM 9073

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	PLC string copied into byte block
	1	Error. See NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Invalid target address of the programmed byte block
	2	Invalid length of the programmed byte block (up to 127 characters permitted)
	4	Invalid sum of the target address and the programmed block length
	11	Invalid source string





## 8.29 Submit Programs

Submit programs are subroutines that the PLC submits to the NC for processing. This allows you to solve problems that are very processor-intensive, require program loops, or must wait for external results. It is a prerequisite that these programs are not restricted to a definite time frame. Depending on the processor load, the control allocates a certain processing power to a submit program. You start submit programs from the PLC program. They can access all data memory areas (M/B/W/D) as the main program can. To prevent problems, ensure that data processed by the PLC program is clearly separated from data processed by the submit program. You can place up to eight submit programs in a queue (submit queue). Each submit program receives an "identifier" (a number between 1 and 255, assigned by the NC), which the control enters in the word accumulator. With this identifier and the REPLY function you can then interrogate whether the program is in the queue, is being processed, or has already been processed.

The control processes the submit programs in the sequence in which they were entered in the queue. If an error occurs during the execution of the submit programs, the control can set a symbolic PLC operand previously defined.

You can define any names for the symbolic operands displaying errors during the execution of submit programs. The operands are assigned to the respective error events in the configuration file of the PLC compiler (usually **PLCCOMP.CFG**).

The following arithmetical errors can be displayed:

Entry in PLCCOMP.CFG	Description
MULERROR	Overflow during multiplication
DIVERROR	Division by 0
MODERROR	Incorrectly executed modulo

For configuring an arbitrary symbolic marker in the configuration editor, see "Data transfer machine parameters => PLC" on page 1657.

The assignment of the error events to a symbolic marker in the **PLCCOMP.CFG** may look like this, for example:

```
MULERROR = MG_Overflow_during_multiplication
DIVERROR = MG_Division_by_0
MODERROR = MG_MODULO_executed_incorrectly
```

Also, the operands must be integrated in your PLC project:

```
#define /s MG_Overflow_during_multiplication      M
#define /s MG_Division_by_0                      M
#define /s MG_MODULO_executed_incorrectly       M
```

The control lists these markers separately in the submit job. This means that the same markers can be edited simultaneously in the PLC program without changing the original markers. No exact times can be stated for the commands for managing the submit queue.

## 8.30 Calling the Submit Program (SUBM)

**Syntax:** SUBM (SUBMIT)

**Operands:** Label (LBL)

**Action:**

Assign an identifier (1 to 255) to a labeled subroutine and put it in the queue. At the same time, the control writes the assigned number in the word accumulator. If programs are already entered in the submit queue, the control does not run the addressed program until the programs before it are finished. A submission to the queue may only take place from a PLC program. A SUBM command in a submit program is not possible.

If there is no room in the queue, or if you program the SUBM command in a submit program (nesting), the control assigns the value "0" to the word accumulator.

**Example:**

See CAN command.

## 8.31 Interrogating the Status of a Submit Program (RPLY)

**Syntax:** RPLY (REPLY)

**Operands:** B/W

**Action:**

Interrogate the status of the submit program with the specified identifier. You must have already stored the identifier in a byte or word when you call the submit program. With the RPLY command and the defined memory address (byte or word containing the identifier) the control transfers one of the following processing states to the word accumulator:

- Word accumulator = 0: Program complete/not in the queue
- Word accumulator = 1: Program running
- Word accumulator = 2: Program in the queue

**Example:**

See CAN command.

## 8.32 Canceling a Submit Program (CAN)

**Syntax:** CAN (CANCEL)

**Operands:** B/W

**Action:**

Cancel a submit program with the specified identifier during processing, or remove it from the queue. You must have already stored the identifier in a byte or word when you call the submit program. After you have canceled the program, the control immediately starts the next submit program from the queue. The following PLC modules cannot be canceled at just any location with CANCEL:

- PLC module for access to screen (908X)
- PLC module for reading NC files (909X)

For these modules, you must check with the RPLY command whether the CAN command may be executed.

**Example:**

This example also applies to the SUBM and RPLY commands.

Depending on input I10, submit the subroutine with the label LBL 300 to the NC for processing. In addition, check the processing status of the subroutine in the main program with the RPLY command, and cancel it with the CAN command, depending on input I11.

Function	STL
Load the content of input I10 into the logic accumulator	L I10
If logic accumulator = 0, jump to LBL 100.	JPF 100
Interrogate the status of the submit program and load it into the word accumulator.	RPLY B128
If the word accumulator is not equal to 0, i.e., the submit program has already been transferred to the NC for processing, set the logic accumulator to 1.	<> K+0
If logic accumulator = 1, jump to LBL 100.	JPT 100
Call submit program 300.	SUBM 300
Save the identifier of the submit program in byte 128.	= B128
Label	LBL 100
Load the state of input I11 into the logic accumulator	L I11
If logic accumulator = 0, jump to LBL 110 (skip the program cancellation).	JPF 110
Cancel the submit program.	CAN B128
Label	LBL 110
	⋮
End of main program	EM
Label: Beginning of the submit program	LBL 300
	⋮
End of the submit program	EM

Always insert submit programs, like any module, at the end of the main program. In this case, the content of the submit program could be a display in the PLC window that is realizable through permanently assigned PLC modules.



## 8.33 Cooperative Multitasking

You can run several processes in the PLC with cooperative multitasking. Unlike genuine multitasking, with cooperative multitasking information and tasks are exchanged only at places that you define. Cooperative multitasking permits up to 16 parallel PLC processes and the submit queue. In a program that you have started with SUBM, you can use commands for changing tasks and controlling events (Module 926x). You should additionally insert a task change between the individual jobs in the submit queue, so that the control can execute parallel processes by the end of a job at the latest. The cyclic PLC main program does not participate in cooperative multitasking, but interrupts a submit job and the parallel processes at whatever their current stage is.

### 8.33.1 Starting a parallel process (SPAWN)

**Syntax:** SPAWN <label>

**Operands:** D

**Action:**

In the specified double word, the control returns the identifier, see page 1733. The control returns -1 if no process could be started. You can call the spawn command only in a submit job or in another spawn process (maximum of eight parallel processes are permitted). If such a process ends with EM, the control removes it from the memory, and the memory space is again available.

### 8.33.2 Control of events

The parallel processes can make events available to one another. This saves processing time otherwise spent in the constant interrogating of operating states by the individual processes. A special feature of event control is the waiting period, during which the process can "sleep" for a programmed time. With this function you can repeat program sections in a slow time grid, for example for display or monitoring functions.

## Process monitor

In the PLC programming mode you can use the MONITOR and PROCESS MONITOR soft keys to open a status screen in which the control displays all parallel processes, including the process for the submit queue. In a time interval, which can be set with the "+" and "-" soft keys, the control displays:

- The name of the process (**TASKNAME**)
- The current status of the process (**STATE**)
  - Executable (**SCHED**)
  - Running (**RUN+**)
  - Waiting for event (**EVWAIT**)
  - Waiting for time period (**TMWAIT**)
  - AND-gating of the bits in the event mask (**AND**)
  - OR-gating of the bits in the event mask (**OR**)
- The event mask (**EVMASK**)
- The PLC module letting the process wait (**MOD**)
- How often the process has changed contexts in the last time interval (**SCHED**).
- How much CPU time the processor has used from the defined time interval (**CPU(ms)**). The control also shows the distribution of CPU time in a bar chart (**RATIO**).

### Module 9260 Receive events and wait for events

Call the module only in a submit job or spawn job. The module enables a spawn job or submit job to interrogate or wait for the occurrence of one or more events. At the same time, the module triggers a change in context.

If you transfer the value zero for the event mask, the control returns all set events without deleting them. Otherwise, in a call with a waiting period, the control returns all the requested events and deletes them. For a call without a waiting period, the control returns and deletes the events only if the condition is met.

If the events are OR-gated, the control returns and deletes only the set events. You can specify the events to be deleted by calling without a waiting period and with an OR gate.

Event bits 16 to 31 are reserved for the operating system:

- Bit 16: BREAK, cancels a function. Setting and reading is permitted. If you transmit this event, the control cancels access to interfaces and the network!
- Bit 17: Reserved, do not use
- Bit 18: Reserved, do not use
- Bit 19: QUIT, acknowledgment of a request. Use this bit only in the immediate context of a request.
- Bit 20 to bit 31: Reserved, do not use

Call:

```
PS    B/W/D/K  <Wait>
           0 = Do not wait
           -1 = Wait
PS    B/W/D/K  <AND/OR>
           0 = OR-gated, otherwise AND-gated
PS    B/W/D/K  <Event mask>
           0 = Available events
CM    9260
PS    B/W/D/K  <Events>
           Read events
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Event has been read
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	2	Incorrect transfer value for <Wait> parameter
	20	Module was not called in a spawn or submit job



### Module 9261 Send events

With this module you can send events to a spawn or submit job and then interrogate them with Module 9260. You can call the module in the cyclic program section, in submit jobs and in spawn processes. The control addresses the receiver through the identifier that the spawn command has returned. The submit queue is addressed through the identifier \$80000000 (not through the identifier returned by the SUBM command!). The control always assigns the events that you send to the submit queue to the job that is running at the time of arrival. If they are not read by this job, they remain for the next one. If you wish the receiver process to start immediately, after Module 9261 you must also call Module 9262 to enable a change of context. Event bits 16 to 31 are reserved for the operating system (see Module 9260).

Call:

```
PS    D/K    <Identifier>
        Identifier from the spawn command of the receiver
        K$80000000 = submit queue
PS    B/W/D/K <Events>
        Events to be triggered, bit encoded
CM    9261
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Event has been sent
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	30	Incorrect identifier





### Module 9262 Context change between spawn processes

You can call Module 9262 only in a submit job or spawn job. The module switches the context to another PLC process or submit queue if such a process exists and is not waiting for an event or for the expiration of a dwell time.

Call:  
CM 9262

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Context was changed
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	30	Module was not called in a spawn or submit job

### Module 9263 Interrupt a spawn process for a defined time

You can call Module 9263 only in a submit job or spawn job. The module interrupts the calling process for at least the specified time. If other processes or the submit queue are ready to run, the control changes the context to one of these processes. The waiting period is interpreted as an unsigned number, so that negative values result in very long waiting periods.

Call:  
PS B/W/D/K <Waiting period in ms>  
CM 9263

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Delay is active
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	30	Module was not called in a spawn or submit job

### Module 9264 Wait for a condition

Module 9264 enables a spawn process or submit job to wait for a specific condition. This module call replaces the procedure of the event list used by earlier HEIDENHAIN contouring controls.

You can call Module 9264 only in a submit job or spawn job.

The condition is a logical expression in accordance with the C language convention with the following syntax:

**<memory operand>[<comparison operator><value>]**

If at least one bit in the event mask is set, the process is continued immediately, and the event signalizes that the condition has been fulfilled. Module 9260 must wait for this. If the event mask equals zero, the process is paused until the condition is fulfilled. Only then is the module call ended.

The following relational operators may be used as conditions:

- == : Equal to
- <> : Not equal to
- < : Less than
- > : Greater than
- <= : Less than or equal to
- >= : Greater than or equal

If you do not specify a relational operator, the condition is fulfilled if the content of the memory operand is not equal to 0.

Constraints:

- If the value 0 is transferred for the event mask, the job waits for the condition to be fulfilled. There is always a change in context when another spawn process or the PLC queue is executable. If there are several other executable PLC processes, the CPU is allocated to the process that has been waiting for allocation the longest. If there is no other executable PLC process and the wait condition is not fulfilled, the NC software is allocated the CPU time that is not required.
- Module 9260 can be used to check if the condition has been fulfilled or to wait for the condition to be fulfilled if a value that is not equal to 0 is transferred for the event mask. Calling the Module 9264 does not cause a change in context in this case.



Call:

PS B/W/D/K/S<Condition>

e.g. "ML\_TestMemory[0] = 1"

Syntax corresponds to the NC syntax from **FN20: WAIT FOR:** (see the User's Manual).

Following conditions are permissible:

== : Equal to

<> : Not equal to

< : Less than

> : Greater than

<= : Less than or equal to

>= : Greater than or equal

PS B/W/D/K <Event bit mask>

0 : Process is paused until condition is fulfilled

Bit#1 to bit#15: Reserved, do not use

Bit#16: BREAK – causes cancellation of a function.

Can be set and read. Access to interfaces and networks is aborted by sending this event in the case of waiting states!

Bit#17: Reserved, do not use

Bit#18: Reserved, do not use

Bit#19: QUIT – acknowledgment of a request.

Quitting a request may only be used in direct context with a request. Therefore: Delete QUIT event, set request to another process, wait for QUIT event.

Bit#20..#31: Reserved, do not use

CM 9264

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Condition is waited for
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	2	Syntax error in the condition
	3	Address for string outside value range
	20	Module was not called in a spawn or submit job

## 8.34 Constants Field (KF)

You can use the constants-field data type to access one of several constants, defined in tabular form, depending on the value of the index register X. You address it with KF <Name>[X], where <Name> is a label indicating the beginning of the constants field. Constants fields must be introduced with the label KFIELD <Name>. This is followed by any quantity (other than zero) of constants and the end label ENDK. Constants fields can only be programmed where the program has previously been concluded with an EM or JP statement. The name of constants fields corresponds to the rules for naming labels.

### Addressing

Types of addresses:

- L KF <Name> [X], with  $X \geq 0$ :  
The control transfers the value of the constant defined by X in the constants field <Name>.
- L KF <Name> [X], with  $X = -1$ :  
The control transfers the length of the constants field <Name>.
- L KF <Name>:  
The control transfers the absolute address of the constants field <Name>. This is only worthwhile in conjunction with modules (e.g. Module 9200). You can also use this addressing in a constants field.

Example:

Function	STL
Access value field with $X = [0 \text{ to } 3]$ .	L KF VAL_FIELD [X]
Assign one of the constants to word W0.	= W0
End of main program	EM
Define the constants field. Constant to be loaded with $X = 0$	KFIELD VAL_FIELD K+10 K+1 K\$ABC
Constant to be loaded with $X = 3$ End of the constants field.	K-100000 ENDK

The control checks the access to constants fields in the same way as the write access for indexed operands. X can assume only positive values from 0 to <Length of constants field - 1>.

## 8.35 Program Structures

To design an easily understandable program, divide it into program sequences. Use labels (LBL) as well as conditional and unconditional jumps. If you use structured statements, the compiler creates the labels and jump commands. Remember that using these labels and jump commands reduces the number of available labels accordingly. You can nest structured statements in up to 16 levels. It is not possible to share levels.

Example:

<b>Correct program structure</b>	<b>Incorrect program structure</b>
<b>IFT</b>	<b>IFT</b>
⋮	⋮
<b>WHILEF</b>	<b>WHILEF</b>
⋮	⋮
<b>ENDW</b>	<b>ENDI</b>
⋮	⋮
<b>ENDI</b>	<b>ENDW</b>

The statements IFT, IFF, WHILET, WHILEF, ENDW, UNTILT and UNTILF require a valid gating result in the logic accumulator. They conclude the sequence of gating operations. The statements ELSE, ENDI and REPEAT require that all previous operations sequences have been concluded.

### 8.35.1 IF ... ELSE ... ENDI structure

The IF ... ELSE ... ENDI structure permits the alternative processing of two program branches depending on the value in the logic accumulator. The ELSE branch is not mandatory. The following commands are available:

- IFT (IF LOGIC ACCU TRUE):  
Following code only if logic accumulator = 1
- IFF (IF LOGIC ACCU FALSE):  
Following code only if logic accumulator = 0
- ELSE (ELSE):  
Following code only if IF is not fulfilled
- ENDI (END OF IF STRUCTURE):  
End of the IF structure

Function	STL
Load input I0 into the logic accumulator	L I0
Run the following code if logic accumulator = 1	IFT
Program code for I0 = 1	⋮
Run the following code if logic accumulator = 0; command can be omitted	ELSE
Program code for I0 = 0, can be omitted	⋮
End of the conditional processing	ENDI

### 8.35.2 REPEAT ... UNTIL structure

The REPEAT ... UNTIL structure repeats a program sequence until a condition is fulfilled. Under no circumstances can you wait with this structure in the cyclic PLC program for the occurrence of an external event! The following commands are available:

- REPEAT (REPEAT):  
Repeat the program sequence from here.
- UNTILT (UNTIL TRUE):  
Repeat the sequence until the logic accumulator = 1.
- UNTILF (UNTIL FALSE):  
Repeat the sequence until the logic accumulator = 0.

The control runs a REPEAT ... UNTIL loop at least once!

Function	STL
Assign the content of the logic accumulator to marker 100; conclusion of the previous commands	= M100
Repeat the following program code	REPEAT
Program code to be run	⋮
Load the index register	L X
Check the index register	>= K100
Repeat until X >= 100	UNTILT

### 8.35.3 WHILE ... ENDW structure

The WHILE ... ENDW structure repeats a program sequence if a condition is fulfilled. Under no circumstances can you wait with this structure in the cyclic PLC program for the occurrence of an external event! The following commands are available:

- WHILET (WHILE TRUE):  
Run the sequence if logic accumulator = 1.
- WHILEF (WHILE FALSE):  
Run the sequence if logic accumulator = 0.
- ENDW (END WHILE):  
End of the program sequence, return to the beginning

The control runs a WHILE ... ENDW loop only if at the beginning the WHILE condition is fulfilled. Before the ENDW statement you must reproduce the condition for execution. The control generates two internal labels for the WHILE ... ENDW structure. The condition can also be produced in a way different from before the WHILE statement!

Function	STL
	⋮
Load marker 100 into the logic accumulator; create condition for 1st WHILE scan.	L M100
Run the following code if logic accumulator = 1	WHILET
Program code for logic accumulator = 1	⋮
Produce the condition of repeated execution: Load marker 101 in the logic accumulator and gate the content of marker M102 with AND.	L M101 A M102
Jump back to the WHILE request	ENDW

## 8.36 CASE Branch

**Indexed module call (CASE)**    **Syntax:**    CASE (CASE OF)

**Operands:**    B/W

**Action:**

Selects a certain subroutine from a list of module calls (CM). These CM commands must follow the CASE statement immediately and are numbered internally in ascending order from 0 to a maximum of 127. The content of the operand (B, W) addresses the desired module. Subsequent entries in the jump table (CM) must have addresses at least four bytes higher than the previous entry.

**Example:**

See ENDC command.

**End of indexed module call (ENDC)**    **Syntax:**    ENDC (ENDCASE)

**Operands:**    None

**Action:**

Use the ENDC command in connection with the CASE command. It must come immediately after the list of CM commands.

**Example:**

Function	STL
Case command and operand; the internal address of the desired module must be saved in the operand	CASE B150
Call module if operand content = 0 Internal addressing from 0 to max. 127	CM 100
Call module if operand content = 1	CM 200
Call module if operand content = 2	CM 201
Call module if operand content = 3	CM 202
Call module if operand content = 4	CM 203
Call module if operand content = 5	CM 204
Call module if operand content = 6	CM 300
End of the CASE statement	ENDC





## 8.37 Linking Files

You can store the source code of the PLC program in several files. To manage these files, use the following commands:

- USES
- GLOBAL
- EXTERN

These statements must be located at the beginning of your PLC program—i.e., before the first PLC command. With the USES statement you link another file into the program. The GLOBAL statement supplies a label from its own file for an entry that can be used by all other files. The EXTERN statement provides a label that is defined in another file and is identified there with GLOBAL. You can then call this label from the active file. You can dramatically improve the transparency of your program by dividing your source code by function into individual groups and then save these groups in individual files. The number of labels is not limited. You can link up to 256 files to one program. The total size is only limited by the available memory. If the memory is exceeded the error message **System memory overflow** appears. With multiple files, the main program in the directory must have the "M" status flag. This can be done in RAM by using the PLC program function "COMPILE" once and choosing the main program in the file window.

## 8.38 USES Statement (USES)

**Syntax:** USES <file name>

**Operands:** None

**Action:**

You can use the USES statement in the main program to link other files. Files that are linked with USES can themselves also use the statement to link further files. It is also permissible to use the USES statement to link a single file to several other files. The code for this file is generated only once. The USES statement requires a file name as an argument. The USES statement only links a file; it does not run the file's program code. The USES statement cannot be compared with a CM statement. The linked files must therefore contain individual modules that you can then call with the CM statement.

**Example:**

```
USES PLCMOD1
USES EPRUPG
USES RAMPLC
```

Linking of files:

Function	STL
Main program	PLCMAIN.PLC
Link the file for spindle control.	USES SPINDLE.PLC
Link the file for tool change.	USES TCHANGE.PLC
Program code	⋮

Function	STL
File for spindle control	SPINDLE.PLC
Integrate file with general subroutines.	USES PLCUPG.PLC
Program code	⋮

Function	STL
File for tool change	TCHANGE.PLC
Integrate file with general subroutines.	USES PLCUPG.PLC
Program code	⋮

Function	STL
File with general subroutines	PLCUPG.PLC
Program code	⋮



## 8.39 GLOBAL Statement (GLOBAL)

**Syntax:** GLOBAL <Label, declaration beyond the file boundary>

**Operands:** None

**Action:**

There is no limit to the number of labels in each file linked with USES. To enable a module that was defined in a file to be called from another file, you must declare the module to be global. This is done by entering the GLOBAL statement at the beginning of the file. You can set labels globally only if they are defined with LBL (and not with KFIELD!) later on in the program.

The main program must not contain any GLOBAL definitions. A single label cannot be declared global by more than one module. However, a name that is declared global in file A can be used again locally in file B. The number of labels is not limited.

## 8.40 EXTERN Statement (EXTERN)

**Syntax:** EXTERN <Label, a module from another file can now be called with a CM command>

**Operands:** None

**Action:**

To enable a label in one file to access modules that other files have declared as GLOBAL, you must declare the label with EXTERN. You must write the EXTERN statement at the beginning of the file. In the program code you can then jump to this label with the commands CM, CMT and CMF.

The following functions are not permitted with external labels:

- JP, JPF, JPT
- Access to a constants field
- Linking a CM statement in a CASE branch

The name of the external label cannot be used again as a local label in the same file.

## 8.41 PLC Modules

A number of PLC modules are available for PLC functions that are very difficult or even impossible to perform with PLC commands alone. You will find descriptions of these modules under the corresponding functions. (See "Overview of Modules" on page 599.)

If the control processes a module incorrectly, it sets the marker **NN\_GenApiModuleError** (M4203). You can evaluate this marker for displaying an error message.

### 8.41.1 Markers, bytes, words, and double words

#### Module 9000/9001 Copy in the marker or word range

Modules 9000 (markers) and 9001 (byte/word/double) copy a block with a certain number of markers or bytes, beginning with the start address, to the specified target address. For Module 9001 the length should always be defined in bytes.

Constraints: The control copies sequentially, beginning with the first memory cell. Therefore the function is not ensured if the source block and the target block overlap and the source block begins at a lower address than the target block. In this case the control overwrites the overlapping part of the source block before the copying process.

Call:

```
PS   B/W/D/K <Number of the 1st marker in source block>
PS   B/W/D/K <Number of the 1st marker in target block>
PS   B/W/D/K <Length of block in markers>
CM   9000
PS   B/W/D/K <Number of the 1st word in source block>
PS   B/W/D/K <Number of the 1st word in target block>
PS   B/W/D/K <Length of block in markers>
CM   9001
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Markers, bytes, words, or double words were copied
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Operand address invalid
	2	Address too high or block too long
	4	Programmed source or target block too long



### Module 9010/9011/9012 Read in the word range

From the specified location in the word memory the control reads a byte, word or double word and returns it as an output quantity to the stack. Indexed reading is possible by specifying a variable as designation of the memory location.

Call:

```
PS   B/W/D/K <Address of the byte to be read>
CM   9010    ; READ BYTE
PL   B       <Target address for byte that was read>
```

```
PS   B/W/D/K <Address of the word to be read>
CM   9011    ; READ WORD
PL   B       <Target address for word that was read>
```

```
PS   B/W/D/K <Address of the double word to be read>
CM   9012    ; READ DOUBLE WORD
PL   B       <Target address for double word that was read>
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Byte was read
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	3	Invalid address was programmed
	5	Module 9011: Specified address is not a word address Module 9012: Specified address is not a double word address

#### Example of Module 9010

Initial state:

```
Byte B10 = 35 (address)
Byte B35 = 80 (byte to be read)
Byte B100 = ?
```

Function	STL	Accumulator content (dec)	Data stack (dec)
Save the address (B10) of the byte to be read from the word accumulator in the data stack	PS B10	35	35
Read byte B35 and save in the data stack	CM 9010		80
Save data stack in byte B100.	PL B100	80	80

### Module 9020/9021/9022 Write in the word range

The control writes the specified byte, word or double word to the defined location in the word memory. Indexed writing is possible by specifying a variable as designation of the memory location.

Call:

PS B/W/D/K <Address of the byte to be written>

PS B/W/D/K <Byte to be written>

CM 9020 ; WRITE BYTE TO ADDRESS

PS B/W/D/K <Address of the word to be written>

PS B/W/D/K <Word to be written>

CM 9021 ; WRITE WORD TO ADDRESS

PS B/W/D/K <Address of the double word to be written>

PS B/W/D/K <Double word to be written>

CM 9022 ; WRITE DOUBLE WORD TO ADDRESS

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Byte was written
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	3	Invalid address was programmed
	5	Module 9021: Specified address is not a word address Module 9022: Specified address is not a double word address

#### Example of Module 9020

Initial state:

Byte B10 = 35 (address)

Byte B100 = 120 (byte to be written)

Byte B35 = ?

Function	STL	Accumulator content (dec)	Data stack (dec)
Save the address (B10) of the byte to be written from the word accumulator in the data stack	PS B10	35	35
Save byte B100 from the word accumulator in the data stack	PS B100	120	120
Write data stack to byte B35	CM 9020	120	

## 8.41.2 Number conversion

### Module 9050 Conversion from binary → ASCII

Module 9050 converts a binary numerical value consisting of a mantissa and exponent to base 10 into an ASCII-coded decimal number and saves it as a string in the specified address. The exponent refers to the least significant place of the number. The control detects a negative number when the mantissa corresponds to a negative number in the notation as a two's complement. The control sets an algebraic sign only before negative numbers. The control does not convert trailing zeros after the decimal point or leading zeros before the decimal point. The control writes the string left-aligned in the string address that you specify.

Constraints:

The decimal character is defined by Machine Parameter MP7280 as a comma (MP7280 = 0) or a period (MP7280 = 1).

Call:

PS B/W/D/K <Mantissa of the number to be converted>

PS B/W/D/K <Exponent to base 10 of the value>

PS B/W/D/K <String address in which the control saves the ASCII-coded decimal number>

CM 9050

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModuleError (M4203)	0	Number was converted
	1	For error code see NN_GenApiModuleErrorCode (W1022)
NN_GenApiModuleErrorCode (W1022)	2	Invalid string address or invalid exponent

### Module 9051 Conversion from binary → ASCII

Module 9051 converts a binary numerical value into an ASCII-coded decimal number in the specified format and saves it as a string in the specified address. The number is interpreted as a two's complement. For algebraically unsigned notation, the control converts the absolute amount of the number without putting a sign before the string. For algebraically signed notation, the control sets an algebraic sign ("+" or "-") in front of the string in any event. For notation in inches, the number is divided by 25.4 before conversion. If the number has more decimal places than the total that you have specified for the number of places before and after the decimal point, then the control omits the most highly significant decimal places. In right-aligned notation leading zeros before the decimal point are replaced by blanks; in left-aligned notation they are suppressed. Trailing zeroes after the decimal point are always converted.

#### Constraints:

The decimal character is defined by Machine Parameter MP7280 as a comma (MP7280 = 0) or a period (MP7280 = 1).

#### Call:

PS B/W/D/K <Numerical value to be converted>  
PS B/W/D/K <Display modes, bit-encoded>

Bit #1/#0: Format

00: Sign and number left-aligned

1: Sign left-aligned, number right-aligned

10: Sign and number right-aligned

11: Not permitted

Bit #2: Display converted to INCH

Bit #3: Display with sign

PS B/W/D/K <Number of places after the decimal point>

PS B/W/D/K <Number of places before the decimal point>

PS B/W/D/K <String address in which the control saves the ASCII-coded decimal number>

CM 9051

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Number was converted
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	2	Invalid string address, invalid display mode or invalid number of places before or after the decimal point





### Module 9052 Conversion of decimal string → Decimal number with an exponent

Module 9052 converts an ASCII-coded decimal number (possibly with decimal places) into a signed number and an exponent to the base of 10. You must assign the ASCII-coded decimal number to one of the string memories. If the number has no algebraic sign, the control interprets it as a positive number and accepts both a point and a comma as decimal character. If the full extent of the mantissa cannot be represented in a double word, then the last places are omitted and the exponent is corrected accordingly. If possible, the control adjusts the exponent so that it corresponds to the ASCII notation.

Call:

PS B/W/D/K <String address in which the ASCII-coded decimal number is saved>

CM 9052

PL B/W/D <Numerical value>

PL B/W/D <Exponent to the base of 10 of the value>

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModuleError (M4203)	0	Number was converted
	1	For error code see NN_GenApiModuleErrorCode (W1022)
NN_GenApiModuleError (W1022)	2	Invalid string address or string contains none or too many characters

### Module 9053 Conversion from binary → ASCII/hexadecimal

Module 9053 converts blocks of binary values from the word-marker range into a string of ASCII-coded hexadecimal numbers. The control reads the specified number of bytes from the word address that you have specified and converts it to a hexadecimally coded ASCII string. Each byte produces two characters in the string memory.

Call:

PS B/W/D/K <Word address from which the binary values are saved>

PS B/W/D/K <String address in which the control saves the hexadecimal numbers>

PS B/W/D/K <Number of data bytes>

CM 9053

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModuleError (M4203)	0	Number was converted
	1	For error code see NN_GenApiModuleErrorCode (W1022)
NN_GenApiModuleErrorCode (W1022)	1	Too many data bytes
	2	Invalid string address
	4	Invalid word address

### Module 9054 Conversion from ASCII/hexadecimal → binary

Module 9054 converts strings of ASCII-coded hexadecimal values into a block of binary values in the word-marker range. The string in the specified string memory is interpreted as a sequence of ASCII-coded hexadecimal numbers and converted into a block of corresponding binary bytes. Two ASCII characters produce one binary byte. The control saves the binary block beginning at the specified address in the word-marker range.

Call:

PS B/W/D/K <String address in which the hexadecimal value is saved>

PS B/W/D/K <Word address from which the control saves the binary values>

CM 9054

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Number was converted
	1	For error code see NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	2	Invalid string address
	11	Invalid word address
		Odd number of characters in the string or a character that cannot be interpreted as hexadecimal

#### Example

Initial state:

SO = „63“

BO = 99

Function	STL	String accu. (characters), data stack [bits]
Push string address S0 onto the data stack	PS K+0	63
Push word address B0 onto the data stack	PS B0	99
Conversion of the two ASCII characters 6 and 3 to the binary number 99	CM 9054	01100011

# 9 Data Interfaces

## 9.1 Introduction

In addition to their Central Processing Unit (CPU), computer systems usually include various peripheral devices.

A CPU is, for example:

- PC
- Control

Peripheral devices include:

- Printers
- Scanners
- External storage devices, such as hard disks, floppy-disk drives or USB memory sticks.
- Other computer systems


A data interface makes it possible for the CPU and its peripheral devices to communicate.

The interfaces, which consist of physical links between the computer system and the peripherals, need a transmission line and appropriate software in order to transfer data between the individual units.

Standard interfaces include:

- Ethernet
- USB 1.1
- RS-232-C/V.24

The relationship between hardware and software, which fully defines an interface, is illustrated by the following diagram:



The hardware in the diagram covers all the physical components, such as

- Circuit design
- Pin Layout
- Electrical characteristics

The software is the operating software, which includes, for example, the drivers for the output modules.

## 9.2 The Ethernet Interface

You can connect the control with your plant's intranet or use a transposed cable to connect directly with a PC. The data transfer rate is dependent on the amount of traffic at the time on the net. For information on the pin layout, see Chapter 3, "Mounting and Electrical Installation."

### **X26: Ethernet interface RJ45 port (10BaseT)**

Maximum cable length:

Unshielded: 100 m

Shielded: 400 m

Network topology: Star configuration

This means a hub serves as a central node that establishes the connection to the other participants.

The control requires an NFS server (Network File System) or a Windows PC (SMB = Server Message Block) as the remote station. It must operate according to the TCP/IP protocol principle.

OSI 7-layer model		Control
7	Application layer	NFS, SMB
6	Presentation layer	
5	Communications layer	
4	Transport layer	TCP protocol
3	Network layer	IP protocol
2	Data link layer	Ethernet card
1	Physical layer	

Before networking, the TNC must be properly configured. Please discuss the required settings with your network supervisor.

## 9.3 HSCI interface

The individual control components communicate with each other via the HSCI connection (HEIDENHAIN Serial Controller Interface). At this time a connection via HSCI is only permitted for HEIDENHAIN components that are part of the machine tool's control system. In addition, the HSCI connecting cable may only be installed in a protected manner (e.g. within the electrical cabinet, cable ducts).

The following features characterize the HSCI connection:

- Based on standard 100BaseT Ethernet hardware
- Telegrams of the HSCI connection are not compatible with the Ethernet
- Line structure
- No collisions
- Data-transfer cycle (HSCI cycle): 3 ms
- Jitter less than 1 ns
- Only one master in the system (MC), all other devices are HSCI slaves
- Slave-to-slave communication possible
- HSCI master must initiate every data transfer
- Realization with FPGAs

Different addresses are assigned to the individual participants in the HSCI network. The addresses are assigned dynamically during booting of the MC. The HSCI addresses of the participants are formed from a bus address (8 bits) and a device type address (6 bits).

After the machine has undergone acceptance testing, the nominal configuration of the machine is saved on the control's hard disk. This nominal configuration contains the association between the device-type address and serial number of the device to the individual bus addresses. The momentary configuration is ascertained during startup of the system by requesting the serial numbers. The momentary configuration is compared with the nominal configuration. If there is a deviation, the machine operator is prompted to check the configuration.

The following applies to the assignment of the bus address:

- The bus address is the result of the device's position in the bus
- The master (MC) always has the bus address 0
- The bus addresses of the slaves result from their position in the bus:
  - First device after the master (MC): Bus address 1
  - Second device after the master (MC): Bus address 2
  - etc.
- The bus address 0xFF is used as multicast address

The following applies to the assignment of the device-type address:

<b>Device-type address:</b>	<b>Device type</b>
000000	MC
000001	Inputs/outputs of the MC
000010	CC
000011	Inputs/outputs of the CC (STO ports)
000100	PL 6xxx
000101	PL 6xxx interface for Profibus
000110	PL 6xxx S and MB xxx S from channel A
000111	PL 6xxx S and MB xxx S from channel B
001000	MB xxx
111111	Multicast to all device types
001011 ... 111110	Reserved



## 9.4 The USB Interface of the Control (USB 2.0)

The USB interface is a standard serial interface.  
(USB = Universal Serial Bus)

USB 1.1 provides a maximum data transfer rate of 12 Mbps.

Various USB block devices, such as keyboard, mouse, external hard disks, and USB memory sticks, can be connected to the control via the USB interface (X141, X142).



### Note

If USB components require more than 0.5 A, a separate power supply becomes necessary for these components. One possibility is the USB hub from HEIDENHAIN (368 735-01).

The USB interface features the "hot-plug capability." This means that you can connect USB devices to the USB interface and remove them, without having to shut down and then restart the control.

Transmission distance without hub: Up to 6 meters




### Note

For greater transmission distances, you must use a USB hub after every six meters in order to amplify the signal. You can use more than one hub for one transmission distance. USB cables with a length of up to 30 meters (with 5 integrated USB hubs) are available from HEIDENHAIN under ID 624 775-xx.

## Bed

The USB interface connects the USB peripheral devices with the USB host. The topology of a USB connection may consist of several levels arranged in a star configuration. Every level consists of a USB hub to which other USB devices or hubs are connected in a star configuration. A maximum of 127 USB devices can be connected to a USB host in this way.




### Functionality and signal designations

USB uses packet-based communication over two differential data lines. This reduces radiation and increases transmission reliability. USB provides significantly higher data transfer rates than other external interfaces (parallel / Centronics, serial / RS-232, RS-422):

- USB full speed of up to 12 Mbps
- USB low speed of up to 1.5 Mbps

Conventional interfaces, such as the RS-232, are more suitable for time-critical applications because they are not based on packets, which reduce the transfer rate (in case of packets with only a few bytes) or delay transmission (when collecting bytes for filling a packet).

Only four wires are required in a USB cable. Two for a power supply of 5 V (with max. 500 mA / 2.5 W) and two for data transmission:





## USB devices on the control

The USB interface of the control allows for convenient and fast exchange of data. You can connect USB block devices, such as memory sticks, hard disks, CD-ROM drives, to your control via the USB interface without having to reboot the system. The data media can be accessed immediately after connection.

The control supports the following USB block devices:

- Floppy disk drives with the FAT/VFAT file system
- Memory sticks with the FAT/VFAT file system
- Hard disks with the FAT/VFAT file system
- CD-ROM drives

The control does not support USB devices with other file systems (e.g. NTFS). If you try to connect such devices, the control will issue an error message.



### Note

It should basically be possible to connect all USB block devices with the above-mentioned file system to the control. If you nevertheless encounter problems, please contact HEIDENHAIN.

## USB devices tested by HEIDENHAIN

A variety of USB storage media from different manufacturers is available on the market. It may happen that a USB device is not identified correctly by the control. The USB devices listed in the table below were tested by HEIDENHAIN for proper functioning in conjunction with the control (numerous other USB devices are supported by the control, but you should test them for proper functioning on the control before using them):

USB device	Manufacturer	Model designation	VendorID	ProductID	Revision
Floppy disk drive	TEAC	TEAC FD-05PUW	0644	0000	0.00
Floppy disk drive	TEAC	TEAC FD-05PUB	0644	0000	0.00
CD-ROM drive	TEAC	USB CD-ROM 210 PU	0644	1000	1.33
CD-ROM drive	FREECOM	USB2-IDE Controller	07ab	fc02	11.10
Hard disk	UNKNOWN	USB to IDE Converter	05e3	0702	0.02
Memory stick	TrekStor	USB MiniStick	0c76	0007	1.00
Memory stick	QDI	UNKNOWN	0c76	0005	1.00
Memory stick	Transcend	TS512MJFLASH	058f	9380	1.00
Memory stick	Transcend	Flash Disk	0ea0	2168	2.00
Memory stick	Generic	Mass Storage Device	058f	9384	1.05

## 9.5 The Serial Interface of the Control

### 9.5.1 RS-232-C/V.24 interface


With RS-232-C/V.24, data transfer is executed asynchronously, with a start bit before each character and one or two stop bits after each character.

Transmission distance: up to 20 m

#### Hardware

The physical connection between two RS-232-C/V.24 interfaces is an asymmetrical line, i.e. the common ground connection between transmitter and receiver is used as a return wire.


Physical connections:



## Signal levels

The levels of the individual signal lines differ:

- Data lines: The data signals are defined as being logical zero (SPACE) over the range +3 V to +15 V and logical one (MARK) over the range -3 V to -15 V.
- Control and verification lines: These signals are defined as being ON (High) over the range +3 V to +15 V and as OFF (Low) over the range -3 V to -15 V.



### Note

For all signals: The voltage range from -3 V to +3 V cannot be evaluated.

## Signal designation

One must differentiate between the following types of lines and their signals:

### ■ Data lines:

- TxD Transmitted data
- RxD Received data

### ■ Control and signal lines:

- DCD (Data Carrier Detect):  
Received signal level. The receiver signals that the information it has received lies within the defined level. The DCD signal is not used by the control. The control delivers no signal from this pin.
- DTR (Data Terminal Ready):  
Control is ready / not ready for operation (e.g. the receiving buffer is full, the signal DTR indicates "LOW").
- DSR (Data Set Ready):  
Peripheral device ready / not ready for service.
- RTS (Request to Send):  
Switch transmission unit on. The control wishes to transmit data.
- CTS (Clear to Send):  
Readiness for transmission. The peripheral wishes to transmit data.

### ■ Ground conductors (lines for power supply):

- Chassis GND:  
Housing connection
- Signal GND:  
0 V lines for all signals

## Pin layout

Keep in mind that there might be a difference between the pin layout of the control and the adapter block.

## 9.5.2 RS-422/V.11 interface

The RS-422/V.11 serial interface is suitable for data transfer rates up to 10 Mbps.

The interface modules of the control can transfer data at up to 115 200 bps.

Transmission distance: over 1 kilometer


### Hardware

The interface works symmetrically, using two signal lines. At the receiver, the difference in voltage of the two lines is evaluated.

Advantage:

- Large transmission distances are possible
- High data transfer rates

Physical connections:



## Signal levels


The signals are both transmitted and received as differential voltage.

A positive differential voltage corresponds to logical zero (OFF).

A negative differential voltage corresponds to logical one (ON).

$$U_{dmin} = 2 \text{ V and } U_{dmax} = 5 \text{ V}$$

The control unit detects the differential voltages between  $U_{dmin} = 0.2$  and  $U_{dmax} = 6 \text{ V}$  as a logically defined level.



## Signal designation

The following signals are transmitted as differential signals:

Signals	Signal designation	
Data signals	TxD, $\overline{\text{TxD}}$	RxD, $\overline{\text{RxD}}$
Control and message signals	RTS	CTS
	DSR	DTR

The protective ground connects the transmitter and receiver housings.

GND is the differential voltage reference conductor.

These signals perform the same functions as those on the RS-232-C/V.24 interface.

## Pin layout

The control and the adapter block have the same pin layout.

## 9.6 Configuring the Serial Interface

### 9.6.1 Control characters

Overview of control characters specific to HEIDENHAIN

Character	Description	Description
SOH	Start of Header	Identifies the beginning of the data transfer header. The character string contains the program number and information about the type of program and the transfer mode.
STX	Start of Text	Identifies the beginning of a program block.
ETB	End of Text Block	Terminates a data transfer block. The character that follows (BCC) is used for data checking.
DC1	XON	Starts the transfer of data.
DC3	XOFF	Stops the transfer of data.
ETX	End of Text	Transmitted at the end of a program.
EOT	End of Transmission	Terminates the data transfer and establishes the idle state. This character is transmitted by the control at the end of a program input and to the external device in the event of an error.
ACK	Acknowledgment	Transmitted by the receiver when a data block has been transferred without error.
NAK	Negative Acknowledgment	Transmitted by the receiver when a data block has been transferred with an error. The transmitter must re-transmit the data block.

## 9.6.2 Configuration of interfaces

Settings in the configuration editor	MP number
System	
Network	
Serial	
CfgSerialPorts	
<b>activeRs232</b>	106601
<b>interfaceRs232</b>	106602
<b>interfaceRs422</b>	106604
interfacePlc	106605
<b>[0]: Keyname Interface PLC 0</b>	106605.0
<b>[1]: Keyname Interface PLC 1</b>	106605.1
<b>[2]: Keyname Interface PLC 2</b>	106605.2
<b>baudRateLsv2</b>	106606
CfgSerialInterface	
[Key names of the interface	
parameters]	
<b>baudRate</b>	106701
<b>protocol</b>	106702
<b>dataBits</b>	106703
<b>parity</b>	106704
<b>StopBits</b>	106705
<b>flowControl</b>	106706
<b>fileSystem</b>	106707
<b>bccAvoidCtrlChar</b>	106708
<b>rtsLow</b>	106709
<b>noEotAfterEtx</b>	106710

### Specifying and selecting interface parameters

You have the possibility of managing multiple parameter sets for the serial interface at the same time by using the configuration editor. The various key names in the CfgSerialInterface parameter object are used to distinguish between the various interface configurations. You assign the settings to the interface by entering the key name in the **MP\_interfaceRs232** or **MP\_interfaceRs422** parameter. This enables you to change quickly between different settings, for example if you frequently connect peripheral devices with different interface parameters. You configure the interface parameters in the **CfgSerialInterface** configuration object. Under each key name, the properties of a serial port are defined.

In addition, up to three different parameter sets are available via the PLC when using the serial interface. They are assigned by key names in the parameter **MP\_interfacePlc**. If no key name has been defined, the parameter set configured under **MP\_interfaceRs232** or **MP\_interfaceRs422** is automatically used by the PLC (Module 9100) for assignment of the interface.



### MP\_activeRs232

Cannot be used for the MANUALplus 620!  
Enable the RS-232 interface in the program manager  
Available from NCK software version: 597 110-03.

Format: Selection menu

Selection: **TRUE**

The RS-232 interface is enabled in the program manager and shown as a drive icon **(RS232:)**.

**FALSE**

The RS-232 interface cannot be accessed via the program manager.

Default: No entry, value optional

Access: LEVEL3

Reaction: NOTHING

### MP\_interfaceRs232

Key name of the data record for the RS-232 interface  
Available from NCK software version: 597 110-01.

Format: String

Input: Max. 18 characters

Define the default parameter set for the serial RS-232 interface here. The "Default" data record is selected by default. But you can use any desired designation. The specified data record must be contained in **CfgSerialInterface**. The data record is not effective if another record was activated by the PLC.

Default: No entry, value optional

Access: LEVEL2

Reaction: NOTHING

### MP\_interfaceRs422

Key name of the data record for the RS-422 interface  
Available from NCK software version: 597 110-01.

Format: String

Input: Max. 18 characters

Define the default parameter set for the serial RS-422 interface here. The "Default" data record is selected by default. But you can use any desired designation. The specified data record must be contained in **CfgSerialInterface**. The data record is not effective if another record was activated by the PLC.

Default: No entry, value optional

Access: LEVEL2

Reaction: NOTHING

### MP\_interfacePlc

Key names of the data records for interface access by the PLC  
Available from NCK software version: 597 110-01.

Format: Array [0...2]

Input: A string of max. 18 characters

Here you can enter a maximum of three different key names for interface accesses by the PLC. If no parameter set is specified, the control automatically uses the default parameter set defined in **CfgSerialInterface**.

Default: [0]: PLC

Access: LEVEL3

Reaction: NOTHING

## Defining the LSV2 baud rate

### MP\_baudRateLsv2

	Data transfer rate for LSV2 communication in baud Available from NCK software version: 597 110-01.
Format:	Selection menu
Selection:	Use a selection menu to define the transfer rate for the LSV2 communication. Minimum value is 110 baud, maximum value 115200 baud.
Default:	BAUD_57600
Access:	LEVEL2
Reaction:	NOTHING

## Creating parameter sets, configuring interface ports


Use the **CfgSerialInterface** configuration object to manage the individual parameter sets for the serial interface. Each parameter set is identified by a key name, and contains the properties of the respective connection. In the **CfgSerialPorts** machine parameter you define which of the parameter sets is activated. See "Specifying and selecting interface parameters" on page 1772. The interface settings to be defined are described below.

## Data transfer rate: Baud rate

The data transfer rate is given in baud (bits per second).  
Common transfer rates are:

110, 150, 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 baud

The time taken to transmit one bit ( $t_B$ ) can be calculated from the transfer rate:



$$t_B = \frac{1}{\text{transfer rate (bit/s)}}$$

For example, a transfer rate of 19 200 bps will have a bit duration of  $t_B = 52.083 \mu\text{s}$ .

$$t_B = \frac{1}{19200 \text{ (Bit/s)}} = 52.083 \mu\text{s}$$

The number of characters transmitted per second can be calculated from the transfer rate and the transmission format:

$$\text{characters transmitted per second} = \frac{\text{transfer rate (bit/s)}}{\text{number of bit per characters}}$$

Example:

With a transmission format of one start bit, 7 data bits, two stop bits and a data transfer rate of 300 bps, exactly 30 characters per second will be transmitted.

$$\text{characters per second} = \frac{300 \text{ (Bit/s)}}{1 + 7 + 2} = 30$$

### MP\_baudRate

Data transfer rate for LSV2 communication in baud  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: Use a selection menu to define the transfer rate for the data transmission. Minimum value is 110 baud, maximum value 115200 baud.

Default: BAUD\_9600

Access: LEVEL2

Reaction: NOTHING

## Communications protocol

The protocol of a serial connection means the controlling of the data flow by feeding reserved ASCII characters into the data stream. Define the communications protocol of the interface in **MP\_protocol**.

For an overview of all communications protocols available on the control, see page 1783.

### MP\_protocol

Communications protocol

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **STANDARD**

Standard data transfer. Data transferred line-by-line

#### **BLOCKWISE**

Packet-based data transfer, "ACK/NAK" protocol. Blockwise data transfer is controlled by the control characters ACK (Acknowledgment) and NAK (Negative Acknowledgment).

#### **RAW\_DATA**

Data transferred without protocol. Transfer of characters without control characters. Protocol intended for transfer of data of the PLC.

Default: STANDARD

Access: LEVEL2

Reaction: NOTHING



#### Note

Here, the BLOCKWISE setting designates a form of data transfer where data is transmitted in blocks. This is not to be confused with the blockwise data reception and simultaneous blockwise processing by older TNC contouring controls. Blockwise reception of an NC program and simultaneous machining of the program is not possible!

## Word length Data bits

Define whether a character is transmitted with 7 or 8 data bits.

### MP\_dataBits

Data bits in each transferred character  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **7 bits**  
7 bits are transferred for each character transferred  
**8 bits**  
8 data bits are transferred for each character transferred

Default: 8 bits

Access: LEVEL2

Reaction: NOTHING

## Transmission reliability: Parity bit

The parity bit helps the receiver to detect transmission errors.

The parity bit can take three different forms:

- No parity (NONE): There is no error detection
- Even parity (EVEN): The transmitter counts bits with a value of one. If the number is odd, the parity bit is set to one, otherwise it is cleared to zero. The sum of set data bits and the parity bit is therefore always even. Upon receiving a word, the receiver counts all of the set bits, including the parity bit. If the count is odd, there is a transmission error.
- Odd parity (ODD): The parity bit is chosen by the transmitter so that the total number of all the set bits is odd. An error will thus be detected if the receiver observes an even number of set bits in its evaluation.

Example: The letter "z" corresponds to the bit sequence: 1 1 1 1 0 1 0

Parity bit:

- With even parity = 1
- With odd parity = 0

### MP\_parity

Specifies the type of parity checking  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **NONE**  
No parity formation  
**EVEN**  
Even parity  
**ODD**  
Odd parity


Default: NONE

Access: LEVEL2

Reaction: NOTHING

**Synchronization:**  
**Stop bits**

The start bit and one or two stop bits enable the receiver to synchronize to every transmitted character during serial data transmission.



One start bit is sent before each character. In **MP\_stopBits**, you determine the number of stop bits sent at the end of a character:

**MP\_stopBits**

Number of stop bits

Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: 1 stop bit

1 stop bit is appended after each transferred character.

2 stop bits

Default: 1 stop bit

Access: LEVEL2

Reaction: NOTHING

**Data transfer check:**  
**Handshaking**

By handshaking, two devices control data transfer between them. A distinction is made between software handshaking and hardware handshaking.

You can choose either of the two procedures:

## Hardware handshaking

Data transfer is controlled by electrical signals. Information, such as Clear to Send (CTS), Request to Send (RTS), "Start transmission" and "Stop transmission" is passed on by the hardware.

Example:

When a computer is to transmit a character, it checks the CTS signal line to see whether it is active (ON). If it is, the character is transmitted.

Hardware handshaking requires


- the data lines TXD and RXD (transmitted and received data)
- the RTS control line (switching on transmitting unit)
- the CTS signal line (Clear to Send)
- a ground connection

The DTR and DSR signals indicate the operational status of the LE and peripheral device:


- DTR: Interrogated by peripheral; it is logical one if LE is ready for operation.
- DSR: Interrogated by LE.
  - LOW level means: external data input/output not ready.
  - HIGH level means: external data input/output ready.

- Data output from the control to EXT

When the receiving buffer is full, the external device resets the RTS signal. The control detects that the peripheral unit receiving buffer is full at its CTS input:



- Data input from EXT to the control  
When the receiving buffer is full, the control removes the RTS signal. This is detected by the peripheral device at its CTS input:



## Software handshaking

Control of data transfer is achieved by control characters transmitted via the data line.

In **MP\_flowControl**, you define whether the control stops transfer from an external device with control character <DC3>. Transfer is then resumed with character <DC1>. (XON/XOFF method)

If transfer is stopped with the control character <DC3>, up to three more characters can be stored; any further incoming characters are lost. Software handshaking is normally recommended when interfaces are connected to an external device.

### MP\_flowControl

Handshaking: Type of data-flow checking  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **NONE**  
No data-flow checking; handshaking not active  
**RTS\_CTS**  
Hardware handshaking; transfer is stopped with RTS active  
**XON\_XOFF**  
Software handshaking; transfer is stopped with DC3 (XOFF) active

Default: RTS\_CTS

Access: LEVEL2

Reaction: NOTHING

## Defining the file system

In **MP\_fileSystem**, define the file system for data transmission over the serial interface. This machine parameter is not mandatory. Remove the parameter from the configuration if you do not need a special file system.

Select one of two different file systems from the selection menu.

### MP\_fileSystem

Define the file system for file operation via the serial interface  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **EXT**  
Minimum file system for external devices. Corresponds to the EXT1 and EXT2 modes of earlier TNC controls. Use these settings if you are using printers, punches, or non-HEIDENHAIN data transfer software.  
**FE1**  
Use this setting for communication with the external HEIDENHAIN FE 401 B or FE 401 floppy disk unit as of software 230 626-03, or for communication with the "TNCserver" PC software from HEIDENHAIN.

Default: EXT

Access: LEVEL2

Reaction: NOTHING





## Block Check Character (BCC)

The BCC is a block check character. The BCC is added to a transfer block to simplify error detection. During the horizontal parity check and the cyclic block check, block check characters are calculated and added to every transferred data block. The appended BCC is compared with a second BCC that is calculated by the receiver. The comparison determines whether the transmission was executed without error.

Use **MP\_bccAvoidCtrlChar** to ensure that the BCC is not interpreted as a control character.

On the control, numbers less than \$20 are defined as control characters. If calculation of the BCC produces a number less than \$20, then a blank space is sent in addition immediately before <ETB>. The BCC will consequently always be greater than \$20 and cannot therefore be interpreted as a control character.



### Note

You can remove this parameter from your configuration if you do not use blockwise data transfer.

### MP\_bccAvoidCtrlChar

Block Check Character (BCC) is not a control character  
Available from NCK software version: 597 110-01.

Format: Selection menu

Selection: **TRUE**

Ensures that the check sum does not correspond to a control character

**FALSE**

Function not active

Default: FALSE

Access: LEVEL2

Reaction: NOTHING

## Status of the RTS line

When using RTS/CTS hardware handshaking, two control lines in the RS-232 cable are used to signalize readiness to send data to or receive data from the other side. If the control wants to send data to the peripheral device, and the device is ready to receive data, then the RTS line is set to HIGH. The peripheral device sets the CTS line to HIGH in order to signalize its readiness to receive data from the control.

In the idle state, the control normally provides a HIGH level on the RTS line. You can change the idle state of the RTS line from HIGH to LOW level by setting the optional **MP\_rtsLow** parameter.

### MP\_rtsLow

Idle state of the RTS line  
Available from NCK software version: 597 110-03.  
Format: Selection menu  
Selection: **TRUE**  
The idle state of the RTS line is logical LOW  
**FALSE**  
(default) The idle state of the RTS line is logical HIGH  
Default: No entry, value optional  
Access: LEVEL2  
Reaction: NOTHING

## Behavior after receipt of ETX

With the optional parameter **MP\_noEotAfterEtx** you define the behavior of the control after reception of the ETX control character. ETX signalizes the end of input for software handshaking. Normally the control automatically sends an EOT control character after reception of an ETX control character (EOT= End Of Transmission). Set the **MP\_noEotAfterEtx** parameter to the value TRUE in order to deactivate transmission of the EOT character.

### MP\_noEotAfterEtx

Defines the behavior after reception of an ETX control character  
Available from NCK software version: 597 110-03.  
Format: Selection menu  
Selection: **TRUE**  
No EOT control character is sent after reception of an ETX control character.  
**FALSE**  
(default) The control sends an EOT control character after reception of an ETX control character.  
Default: Value optional, no entry  
Access: LEVEL2  
Reaction: NOTHING



## 9.7 Data Transmission Protocols

### 9.7.1 Standard communications protocol

#### General information

To set the standard communications protocol:

- ▶ See "MP\_protocol" on page 1775.

When outputting a file, the <NUL> character is sent exactly 50 times at the start of file. When reading in, however, the control unit ignores this character, regardless of how often the peripheral sends the <NUL> character before the file.

The program blocks are not checked for correctness but are transmitted one after the other.

If you wish to signal an error to the control in the standard communications protocol, you must send the following sequence of instructions:  
<ESC><1><Error number>

If the receiver's data buffer is full, the transmission can be stopped and resumed in one of two ways:

- Software handshaking
  - Stop transfer by sending the character <DC3> (XOFF)
  - Continue by transmitting the character <DC1> (XON)
- Hardware handshaking
  - By suitable levels on the control and signal lines RTS and CTS of interfaces RS-232-C/V.24 or RS-422/V.11

Twelve characters before the receiving buffer is full, the control transmits the character <DC3> to the transmitter in order to terminate transmission.

Example: Protocol for conversational NC program

<NUL><NUL><NUL><NUL> 50 times

0 BEGIN PGM 1 MM<CR><LF> 1st program block

1 TOOL DEF 1 L+0 R+3<CR><LF> 2nd program block

26 END PGM 1 MM <CR><LF> End of program

... ..

<ETX><EOT> Close the data transmission menu

Example of software handshake

Control to peripheral device	Peripheral device to control
12 Z + 2 FMAX<CR><LF>	Receiving buffer full: <DC3> Receiving buffer ready again: <DC1>
13 Z -10 F100 M03<CR><LF>	...

## Output selected file

The serial interface uses software handshake.

The control outputs all of the program lines in sequence.

The peripheral device can:

- Stop transmission with <DC3>
- Resume transmission with <DC1>

Control to peripheral device	Peripheral device to control
<NUL> <NUL> <NUL>... 1st line of file <CR> <LF>... 5th line of file <CR> <LF>...	Transmission stop: <DC3> Resume transmission: <DC1>
6th line of file <CR> <LF>... Last line of file <CR> <LF>	...

## Load selected file

The serial interface uses software handshake.

To transfer a file from a peripheral device:

- Enter the file name in the control.

The control can:

- Stop transmission with <DC3>
- Resume transmission with <DC1>

Control to peripheral device	Peripheral device to control
100.H "START" <DC1>	<NUL><NUL> 1st line PGM100<CR><LF> ... Last line PGM 100 <CR><LF><ETX>
<EOT>	

If the file name in the first line and the name indicated in the control are not identical, the control downloads each block and searches for the correct file name. If the END PGM block has been downloaded, and the selected name has not been found, the control stops transfer without an error message:

- In this case, terminate transfer with the END key.

### 9.7.2 Communications protocol with block check character

This protocol is specific to HEIDENHAIN and operates with its own control characters and an additional data check feature when transmitting.

The protocol is active during blockwise data transfer in FE1 mode, see page 1780.

In FE1 mode, a command sequence is output at the beginning to request the contents directory from the peripheral device.

#### Header

When a file is transferred, the first block—called the header—consists of the following characters:

<SOH><K><Name><M><ETB><BCC><DC1>

Character	Meaning
<SOH>	Identifies the beginning of the header
<K>	File code
<Name>	File name
<M>	Data transfer mode (E = input, A = output)
<ETB>	Identifies the end of the header
<BCC>	Block Check Character
<DC1>	XON

#### Block Check Character (BCC)

In addition to checking the parity of the individual characters, the parity of the complete transferred block is also checked. The BCC always rounds the individual bits of the transferred characters in a data transfer block to even parity.

Example of BCC generation:

In this example, program 15, which has been written in HEIDENHAIN plain-language text (H), is input through the data interface (E).

Character	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
SOH	0	0	0	0	0	0	1
H	1	0	0	1	0	0	0
1	0	1	1	0	0	0	1
5	0	1	1	0	1	0	1
E	1	0	0	0	1	0	1
ETB	0	0	1	0	1	1	1
<b>BCC</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>	<b>1</b>

A parity bit is also generated for the BCC. With even parity, the parity bit in this example is assigned the value 1.

At the end of every block, the receiver checks whether it has been transferred correctly.

To do this, the receiver computes a BCC from the received block and compares it with the received BCC. If the received BCC and the computed BCC are identical, the receiver transmits the character <ACK> for positive acknowledgment. If the two BCCs are not identical, the data block was not transmitted correctly. The receiver transmits the character <NAK> for negative acknowledgment. The block must be re-transmitted. This process is repeated up to 15 times.

If the header is acknowledged with <ACK>, the first file block can be transmitted:

The beginning of a file block is identified by the control character <STX>. The remaining control characters in this block are identical with the control characters in the header. If this block is acknowledged by <ACK>, then the next program block is transmitted. If <NAK> is transmitted, the same block has to be re-transmitted, etc. Once the last program block has been acknowledged by <ACK>, the transmission is terminated by the characters <ETX> (end of text) and <EOT> (end of transmission).

## Handshaking

The character <DC1> (XON) follows the BCC. This character is required by many devices to explicitly request the transmission once again from the transmitter.

The <DC1> character is not required for reading in a file in the BCC format.

The transmitter waits and only resumes data transmission when the receiver has transmitted a positive (ACK) or negative (NAK) acknowledgment to indicate that the receiving buffer is ready.

To disable transmission of the character <DC1>:

- ▶ Set **MP\_flowControl** to NONE.

Example:

A file with the name PPP is to be transferred to a peripheral device (e.g. HEIDENHAIN FE 401 Floppy Disk Unit).

Control to peripheral device	Peripheral device to control
<SOH><L>PPP<A><ETB>BCC	ACK
<STX> "1st line"<ETB>BCC	<ACK>
...	...
<STX> "10th line"<ETB>BCC	<NAK>
<STX> "10th line"<ETB>BCC	<ACK>
<STX> "11th line"<ETB>BCC	<ACK>
...	...
<STX> "last line"<ETB>BCC	<ACK>
<ETX><EOT>	

### Report an error to the control

#### FE1 mode is set.

If an error occurs at a peripheral device, the following block must be sent to the control:

<SOH><Error text><ETB>BCC

Peripheral device to control	Control to peripheral device
<SOH> "Error"<ETB>BCC	<ACK><EOT>

The error message received will be displayed on the control. To continue

► Press the CE key.

### Request external directory

#### FE1 mode is set.

In FE1 mode the following Escape sequence is sent to request the external directory:

<DC3><ESC><DC1><0><SP><D><CR><LF>

The control expects the following input to this request:

xxxxxx<Code letters><Sectors><Name><P<sup>1</sup>><CR><LF>

<sup>1</sup>) P = Protected (optional)

The first four lines, each ending in <CR><LF>, are ignored. In subsequent lines ending with <CR><LF>, the program name and, after any number of blank characters, the number of sectors are stored.

If the character combination <FREE:> is detected, only a number—the number of free sectors—will be transferred.

The control requests the complete directory. The directory is saved and the files of the selected type are displayed.

The peripheral device ends transmission with <EXT>. The control responds with <EOT>.

### Output selected file

Control to peripheral device	Peripheral device to control
<SOH><K>Name<A><ETB>BCC	<SOH><K>Name<A><ETB>BCC
<STX> "1st line"<ETB>BCC	<ACK>
...	...
<STX> "last line"<ETB>BCC <DC1>	<ACK>
<ETX><EOT>	

### Output marked files

Marked files are output in the same protocol as for outputting the selected files. After each file, the control characters <EXT><EOT> are sent to the peripheral device.



## Load selected file

To download a file from an external storage device, the control transmits a header with the corresponding file name.

Control to peripheral device	Peripheral device to control
<SOH><K>Name<E><ETB>BCC <DC1>	<ACK> <STX>"1st line"<ETB>BCC<DC1>
<ACK>	...
...	<STX> "last line" <ETB>BCC <DC1>
<ACK>	<ETX>
<EOT>	

### 9.7.3 LSV2 transmission protocol

The LSV2 protocol is a data transfer protocol for the two-way transfer of commands and data.

The data is transferred in blocks—so-called telegrams—into which the data is split up.

The following functions are possible:

- Data transfer
- File management, such as deleting, copying and renaming files
- Changing, creating and deleting paths
- Remote operation of the control functions. The control screen appears on the computer monitor. All functions can be executed from the computer.
- Real DNC operation. Starting and stopping the machine from the PC
- Diagnosis of control error messages and keystrokes for service purposes. The last 1000 events are stored in the control.

HEIDENHAIN offers two LSV2 software packages. Please contact HEIDENHAIN for further information.





## 9.8 Saving and Loading Files

The table lists all the files that can be saved to external memory devices and loaded from them.

File	File extension
MANUALplus 620 cycle programs	.gmz
NC program, DIN/ISO	.nc, .ncs
Tool table	.htt
Datum table	.hzp
Machine parameters	.CFG
Compensation-value table	.COM
Compensation-value assignment	.CMA
PLC program	.PLC
PLC source code files	.SRC
Text file	
Pocket table	.TCH
Help files	
Point table	
PLC error table	.PET
Cutting-data table	
Freely definable tables	
Motor table	.MOT
Motor table (servo amplifiers)	.INV
Error file	.log
OEM cycles	
Oscilloscope recordings	.SCO

To write to or read from machine parameter files, compensation tables or PLC files, you must enter the correct code numbers. For data transmission with the **TNCremoNT** PC software from HEIDENHAIN the identifier of a file has no significance. The files are saved on the PC with the same extension as on the control.

## 9.9 Configuring the Control for TeleService 2.0

The TeleService 2.0 computer program offers numerous possibilities for remote maintenance and remote diagnosis of the MANUALplus 620. Along with transmission of the screen contents, all soft keys of the control can be operated remotely, for example.

A virtual screen keyboard (for MANUALplus 620 as of TeleService 2.1) can be displayed, making remote key entry possible. In addition, comprehensive diagnostic possibilities, such as outputting of control logs, are available.

The machine operator can initiate a SERVICE REQUEST via soft key, as well as establish an automatic connection between the control and TeleService. In the **Transfer** mode, press the **TeleService** soft key after configuring the machine parameters described below. Please contact HEIDENHAIN if you would like to use TeleService 2.0.

For TeleService 2.0, you must connect the control to the network. For information, please refer to the "Transfer" chapter in the User's Manual. Then you can access the control with TeleService via the host name or IP address.

The following machine parameters are available for configuration of the service request:

Settings in the configuration editor	MP number
System	
Network	
CfgServiceRequest	
<b>name</b>	114601
<b>host</b>	114602
<b>port</b>	114603
<b>content</b>	114604
<b>period</b>	114605
<b>timeout</b>	114606
<b>serverIp</b>	114607
<b>serverIpMask</b>	114608

### MP\_name

Logical name of the service host

Available from NCK software version: 597 110-03.

Format: String

Input: Max. 500 characters

The name identifies the remote service host and can be displayed on the user interface of the control.

Default: No value, parameter optional

Access: LEVEL2

Reaction: NOTHING



### **MP\_host**

Network address or host name of the remote service host  
Available from NCK software version: 597 110-03.

Format: String

Input: Max. 500 characters

Enter the network address as four decimal numbers separated by periods (IP address in dotted-decimal notation) or as a fully qualified host name, e.g.:

**192.168.10.51**

**\HOME\DATA\SERVICE**

Default: No value, parameter optional

Access: LEVEL2

Reaction: NOTHING

### **MP\_port**

Port number of the remote service host  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: Initial value: 19001

The control sends the service request report to the port entered here.

Default: No value, parameter optional

Access: LEVEL2

Reaction: NOTHING

### **MP\_content**

Contents of the message to the remote service host  
Available from NCK software version: 597 110-03.

Format: String

Input: Max. 500 characters

The contents serve to identify the machine, e.g. machine model and serial number.

Default: No value, parameter optional

Access: LEVEL2

Reaction: NOTHING

### **MP\_period**

Duration of repeated transmission of the message to the service host  
Available from NCK software version: 597 110-03.

Format: Numerical value

Input: 0 to 10 [s]

Transmission of the report is repeated during the specified period of time in seconds until the function is activated or the time entered in the **MP\_timeOut** parameter is exceeded.

Default: No value, parameter optional

Access: LEVEL2

Reaction: NOTHING

### **MP\_timeout**

Timeout in minutes for transmission of the message to the remote service host

Available from NCK software version: 597 110-03.

Format: Numerical value  
Input: 0 to 15 [min]  
Default: No value, parameter optional  
Access: LEVEL2  
Reaction: NOTHING

### **MP\_serverIp**

Network address or host name of the server

Available from NCK software version: 597 110-03.

Format: String  
Input: Max. 500 characters  
The data traffic of the specified server(s) is checked. The default value is the server given in the **MP\_host** parameter.  
Default: No value, parameter optional  
Access: LEVEL2  
Reaction: NOTHING

### **MP\_serverIpMask**

Subnet mask of the server network

Available from NCK software version: 597 110-03.

Format: String  
Input: Max. 500 characters  
Enter the subnet mask of the server as four decimal numbers separated by periods (IP address in dotted-decimal notation).  
Default: No value, parameter optional  
Access: LEVEL2  
Reaction: NOTHING



## 9.10 The Transfer Mode of Operation

The Transfer mode is used for data backup and data exchange with other IT systems. NC program files, parameter or tool files are transferred.

The data is transmitted through Ethernet-based networks or via the USB interface. The control supports the networks provided by WINDOWS. The control uses the "dual-window concept." This means you see the files of your own system in the left and the files of the other side in the right half of the screen.

- You send data from the control or receive data from the other side. This is always initiated by the control.
- Use **TNCremoNT** if you want to send files from a PC to the control or "collect" them from the control. **TNCremoNT** is available free of charge from HEIDENHAIN.

### The following transfer functions are available:

- **Programs** – Transmitting and receiving files
- **Back up parameters** – Creating, transmitting and receiving
- **Restore Parameters** – Reloading the parameter backup files
- **Backup tools** – Creating, transmitting and receiving
- **Restore Tools** – Reloading the tool backup files
- **Service** – Creating and transmitting service data
- **Data Backup** – Backing up **all** data in a project folder
- **Free external** – Freely selecting program files on a USB storage device
- **Miscellan. functions** – Importing the cycle programs and DIN programs of the MANUALplus 4110 and DIN PLUS programs of the CNC PILOT 4290



#### Note

For detailed information and descriptions of the Transfer mode of operation of MANUALplus 620, refer to the User's Manual for the control.

## 9.10.1 Selective parameter backup

Settings in the configuration editor	MP number
System	
Backup	
CfgBackup	
<b>groupList</b>	605501
CfgBackupGroup	605600
[Key name of the backup list]	
<b>backupFiles</b>	605601

For parameter backups that are started with the **Parameter Backup** soft key in the Transfer mode of operation, you can configure any file lists in CfgBackup, and save them under a unique key name on the control.

When starting the parameter backup, in a dialog box you can individually select all defined file lists via their key names. Parameter backups can now be carried out separately for machine parameters and PLC parameters, for example.

### Configuration of backup lists

In **MP\_groupList** under CfgBackup, define the desired key names for all of the backup lists you want to create.

In a second step, you have to enter these key names under CfgBackupGroup and assign configuration files to each backup list by means of **MP\_backupFiles**. To do so, enter in **MP\_backupFiles** the paths to the desired configuration files instead of the absolute paths by using the placeholders **%oemPath%** and **%usrPath%**.

The key names of the backup lists and the associated configuration file lists can be expanded as desired in the configuration editor with these machine parameters.

#### MP\_groupList

List with the key names of all backup lists  
Available from NCK software version: 597 110-05.

Format: Array [0...12]  
Input: Enter the key names of all backup lists.  
Default: No value, parameter optional  
Access: LEVEL1  
Reaction: NOTHING

#### MP\_backupFiles

List with the paths to the configuration files  
Available from NCK software version: 597 110-05.

Format: Array [0...40]  
Input: Enter the paths to the configuration files using the placeholders **%oemPath%** and **%usrPath%**.  
Default: No value, parameter optional  
Access: LEVEL1  
Reaction: NOTHING



## 9.11 Data Transfer by PLC

### 9.11.1 PLC modules

With the following PLC modules you can control the data interfaces from the PLC:

- Modules 9100 and 9101: Assign/release the data interfaces
- Module 9102: Interrogate the status of the interface
- Modules 9103 and 9104: Transmit and receive a string from the string memory. The transmit and receive buffers for the PLC are 128 characters long. Since every STRING ends with an END character, a STRING can only be up to 127 characters long.
- Modules 9105 and 9106: Transfer a block of binary values (bytes) from the word memory
- Module 9107: Read bytes from the receiving buffer without erasing the buffer
- Modules 9112 and 9113: Send or receive ASCII characters via the data interface

Strings and binary data are transmitted using ASCII characters. Example: Transfer of a block of binary data

Address	Value	ASCII character
.	.	.
B126	11111010	\$FA
.	10000001	\$81
.	.	
.	.	
.	.	

When transferring binary data starting from the address B126, the ASCII characters <F> <A> <8> <1> etc. are transmitted in sequence from the word memory through the interface. Each byte contains two ASCII characters. The transmitting and receiving buffers each hold 63 bytes.

### Module 9100 Assign data interface

Module 9100 assigns a serial interface to the PLC and configures the transfer parameters. They initialize the interface, thereby erasing any errors that may have occurred. The interface is then ready to receive.

Once assigned to the PLC, the interface is disabled for use by the input/output program of the user interface.

Input/output program of the user interface is locked. The assignment is canceled when the PLC program is recompiled.

Can only be called in a submit job or spawn job!

Call:

PS B/W/D/K <>Interface>  
0: RS232  
1: RS422

PS B/W/D/K <>Transfer parameters>  
0: Entry from interfacePlc[0] is used  
1: Entry from interfacePlc[1] is used  
2: Entry from interfacePlc[2] is used

CM 9100

### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Interface was configured for the PLC and assigned
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Incorrect interface or incorrect transfer parameter
	13	No connection
	14	Interface busy or input/output not ready
	20	Module was not called in a spawn job or submit job





### Module 9101 Release data interface

Module 9101 cancels the assignment of an interface to the PLC. The receive mode of the interface is canceled.

Can only be called in a submit job or spawn job!

Call:

```
PS    B/D/W/K  <>Interface>
        0: RS232
        1: RS422
```

```
CM    9101
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Interface enabled
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Incorrect interface
	14	Interface not assigned
	20	Module was not called in a spawn or submit job

### Module 9102 Status of data interface

Module 9102 reads the status information about an interface in bit-coded form.

The information "interface ready" is updated when the interface is assigned to the PLC or NC. If the interface is not assigned, the module reads the last valid status.

Call:

PS B/W/D/K <>Interface>  
0: RS232  
1: RS422

CM 9102

PL B/W/D <>Interface status>  
-1: Error code in NN\_GenApiModuleErrorCode (W1022)  
Bit 0: Interface is assigned  
Bit 1: Interface is assigned to the PLC  
Bit 2: Interface is ready  
Bit 3: Transmit buffer is empty  
Bit 4: Error during transmission  
Bit 5: Receive buffer is full  
Bit 6: Error in reception  
Bit 7: ETX was received (not ready to receive)  
Bit 8: Internal buffer from Module 9113 contains characters

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Status read
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Incorrect interface



### Module 9103 Transmit string through data interface

You must first assign the interface to the PLC and initialize it with Module 9100.

Module 9103 transmits a string from a string memory through one of the two interfaces. Links to the PLC error file and PLC dialog file are deleted.

Can only be called in a submit job or spawn job!

Call:

```
PS    B/W/D/K <>Interface>
      0: RS232
      1: RS422
```

```
PS    K/B/W/D <>Number of source string in the string buffer>
CM    9103
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	String sent
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Incorrect interface or incorrect string number
	12	No string end found
	13	Interface not ready
	14	Interface not assigned
	15	Transmit buffer not empty
	20	Module was not called in a spawn job or submit job

### Module 9104 Receive string through data interface

You must first assign the interface to the PLC and initialize it with Module 9100.

Module 9104 reads a string from the receive buffer of a serial interface in a string memory and resets the receive buffer.

Can only be called in a submit job or spawn job!

Call:

```
PS    B/W/D/K <>Interface>
      0: RS232
      1: RS422
```

```
PS    K/B/W/D <>Number of the string in the string buffer>
CM    9104
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	String was received
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Incorrect interface or incorrect string number
	12	String too long
	14	Interface not assigned
	16	Receiving buffer empty
	18	Transmission error or input/output not ready
	20	Module was not called in a spawn job or submit job



### Module 9105 Transmit binary data through data interface

You must first assign the interface to the PLC and initialize it with Module 9100.

Module 9105 transmits a block of binary values from the word memory of the PLC to one of the two interfaces. The transfer is in the form of ASCII-coded hexadecimal values. Every byte in the source block makes two ASCII characters at the interface.

Can only be called in a submit job or spawn job!

Call:

```
PS    B/W/D/K  <>Interface>
        0: RS232
        1: RS422
```

```
PS    K/B/W/D  <>Number of the first byte in the binary block>
```

```
PS    K/B/W/D  <>Length of the binary block (0 to 63)>
```

```
CM    9105
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Data was transmitted
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Incorrect interface or incorrect byte number or block too long
	4	Block outside value range
	13	Interface not ready or no connection
	14	Interface not assigned
	15	Transmit buffer not empty
	20	Module was not called in a spawn or submit job

### Module 9106 Receive binary data through data interface

You must first assign the interface to the PLC and initialize it with Module 9100.

Module 9106 reads a block of binary values from one of the two interfaces into the word memory of the PLC. The transfer is in the form of ASCII-coded hexadecimal values. Every two ASCII characters from the serial interface make one byte in the binary block.

The length of the read binary block is returned as the initial variable.

Can only be called in a submit job or spawn job!

Call:

PS B/W/D/K <>Interface>  
0: RS232  
1: RS422

PS K/B/W/D <>Number of the first byte in the binary block>

CM 9106

PL B/W/D <>Length of binary block in bytes>  
-1: Incorrect module call

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Data was received
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Incorrect interface or incorrect byte number or block too long
	4	Block outside value range
	11	Odd number of characters or illegal character
	12	String too long
	14	Interface not assigned
	16	Receiving buffer empty
	18	Transmission error or input/output not ready
	20	Module was not called in a spawn job or submit job



### Module 9107 Read from receiving buffer

You must first assign the interface to the PLC and initialize it with Module 9100.

Module 9107 reads two ASCII characters from the receive buffer to one of the two interfaces and codes them to a binary value.

You can specify an offset that corresponds to the position of the byte to be read in a binary block read by Module 9106. The contents of the receiving buffer are retained and can be read by Modules 9104 and 9106.

Can only be called in a submit job or spawn job!

Call:

```
PS    B/W/D/K  <>Interface>
        0: RS232
        1: RS422
```

```
PS    B/W/D/K  <>Offset of byte to be read in binary block>
```

```
CM    9107
```

```
PL    B/W/D    <>Binary value read>
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Receiving buffer was read
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Incorrect interface or incorrect byte number
	11	Illegal character
	12	String too long or offset too large
	14	Interface not assigned
	16	Receiving buffer empty
	18	Transmission error or input/output not ready
	20	Module was not called in a spawn job or submit job

### Module 9111 Receive a message via LSV2

Module 9111 reads a message (double word or string) that has been received from a host computer connected by LSV2 protocol.

The message must be transmitted from the host by the LSV2 command "M\_PC<msg.l>".

Call:

PS B/W/D/K <>Data type>  
0: Binary data double word  
1: String

PS B/W/D/K <>Target address>  
With binary: Number of the double word  
With string: Number of the string

CM 9111

PL B/W/D <>Error code>  
0: Message was read  
1: No connection to host  
2: No message of this type in receiving buffer  
3: Incorrect data type (not 0 or 1)  
4: Incorrect target address

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Message received
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	2	Incorrect data type
	4	No double word address, or incorrect string number
	11	String too long
	13	No connection
	15	Transmit buffer not empty
	16	Receiving buffer empty





### Module 9112 Transmit ASCII characters via data interface

You must first assign the interface to the PLC and initialize it with Module 9100. Module 9112 transmits a single ASCII character.

Can only be called in a submit job or spawn job!

Call:

```
PS    B/W/D/K <>Interface>
      0: RS232
      1: RS422
```

```
PS    W/D/K <>ASCII code [0 to 255]>
CM    9112
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Character was transmitted
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Incorrect interface
	13	Interface not ready or no connection
	14	Interface not assigned
	15	Transmit buffer not empty
	20	Module was not called in a spawn job or submit job

### Module 9113 Receive ASCII characters via data interface

You must first assign the interface to the PLC and initialize it with Module 9100.

Module 9113 reads a single ASCII character from the receiving buffer of a serial interface and resets the receiving buffer.

If there is more than one character in the receiving buffer, the first is returned and the others are stored in a special buffer.

You can interrogate the current state with Module 9102, bit 8.

As long as data remains in the buffer, no further characters are collected from the interface.



#### Note

Store the result in at least one word so that the values to 255 will be recognized.

Can only be called in a submit job or spawn job!

Call:

```
PS    B/W/D/K  <>Interface>
        0: RS232
        1: RS422
```

```
CM    9113
```

```
PL    W/D      <>ASCII character read
        [0 to 255 = ASCII characters; -1 = error>
```

#### Error recognition:

Marker	Value	Meaning
NN_GenApiModule Error (M4203)	0	Character was received
	1	Error code in NN_GenApiModuleErrorCode (W1022)
NN_GenApiModule ErrorCode (W1022)	1	Incorrect interface
	12	String too long
	13	Interface not ready or no connection
	14	Interface not assigned
	16	Receiving buffer empty
	18	Transmission error or input/output not ready
	20	Module was not called in a spawn job or submit job
37	Receiving queue is full	



## A

Acceleration.....	809
Acceleration feedforward control.....	866
Acceleration feedforward control for analog axes.....	904, 916
Access protection.....	350
Access rights to machine parameters.....	347
Access rights to NC files.....	1230
Actual-to-nominal value transfer.....	851
Adapters for encoder signals.....	109, 250
ADD STRING (+).....	1725
ADDITION (+).....	1690
Analog inputs.....	1368
Analog nominal value output.....	255
Analog outputs.....	1371
AND (A).....	1678
AND NOT (AN).....	1680
API DATA.....	1490
ApiAxis.....	1484
ApiChn.....	1484
ApiGen.....	1484
ApiOmg.....	1484
ApiSpin.....	1484
ASSIGN (=).....	1670
ASSIGN BYTE (B=).....	1671
ASSIGN NOT (=N).....	1673
ASSIGN TWO'S COMPLEMENT (=-).....	1673
ASSIGN WORD (W=).....	1672
Axes, clamping.....	849
Axes, configuring.....	624
Axes, enabling.....	126
Axis designations and coordinates.....	626
Axis information, reading.....	671
Axis-error compensation.....	705

## B

Backlash compensation.....	707
Band-rejection filter.....	858
Baud rate.....	1774
Bend radius.....	294
BIT CLEAR (BC).....	1711
BIT SET (BS).....	1710
BIT TEST (BT).....	1712
Block Check Character.....	1785
Brake test.....	985
Braking the drives.....	890
Buffer battery.....	241
Bus diagnostics screen content.....	1504

## C

C axis with separate drive .....	1436
C axis, removing .....	1434, 1439, 1446, 1447, 1452, 1453, 1455, 1456, 1464, 1466
Cable diameter .....	294
Cables, instructions for wiring .....	294
Cables, specifications .....	294
Call Module (CM) .....	1718
CALL MODULE IF FALSE (CMF) .....	1719
CALL MODULE IF TRUE (CMT) .....	1718
Call submit (SUBM) .....	1734
Canceling a submit program (CAN) .....	1735
Cascade control .....	808
CASE branch .....	1748
C-axis operation .....	1040
CC 61xx .....	1046
CC 61xx controller unit .....	1046
CMA-H 04-00-04 .....	255
CML 110, specifications .....	292
Code number .....	365
Code numbers .....	1230
Coded output of spindle speed .....	1572
Commissioning .....	1072
Commissioning of analog axes .....	1104
Commissioning of digital axes .....	1089
Commissioning the position controller .....	1091
Communications protocol .....	1775
Compensation of axis errors .....	705
Compensation of reversal peaks .....	906, 918
Compensation of thermal expansion .....	721
COMPILE .....	1497
Component overview .....	84
Components, overview of .....	163
Configuration of interfaces .....	1772
Configuration of the lathe .....	1428
Configuration of user parameters .....	366
Constants field .....	1744
Constants field (KF) .....	1744
Context-sensitive help system .....	1278
Control characters .....	1771
Control loop .....	808
Control loops, enabling .....	126
Control of events .....	1737
Control, adapting to the machine .....	613
Control, powering up .....	1313
Controller parameters for analog axes .....	902, 913
Conversational language .....	1225
Converter TTL to 1 Vpp .....	250
Cooling .....	157
Cooperative multitasking .....	1737
Counters .....	1525
Counting direction of the axes .....	1429
Current controller .....	885
Current controller cycle time .....	808
Cycle time .....	808

## D

Data backup.....	149
Data bits .....	1776
Data interfaces .....	265, 1759
Data transfer to the PLC.....	1404
DC-link voltage .....	1085
DECREMENT (DEC) .....	1695
Dimensions, adapter block for the data interface.....	306
Dimensions, adapter cable for TT 120/TS 220 .....	313
Dimensions, CC 6106.....	298
Dimensions, CC 6108, CC 6110 .....	299
Dimensions, CML 110.....	318
Dimensions, line-drop compensator.....	308
Dimensions, MB 620T.....	297
Dimensions, MC 6110T.....	296
Dimensions, PL 6001 .....	302
Dimensions, PL 6xxx.....	301
Dimensions, PSL 130 .....	303
Dimensions, SE 540 .....	315
Dimensions, SE 640 .....	314
Dimensions, touch-probe adapter cable.....	312
Dimensions, TS 220 .....	313
Dimensions, TS 440 .....	316
Dimensions, TS 640 .....	317
Dimensions, TT 130 .....	311
Dimensions, UEC 11x .....	300
Dimensions, USB hub .....	307, 318
Direction of spindle rotation .....	1430
Distance .....	809
DIVISION (/) .....	1693
Documentation.....	110
Drive controller, enabling.....	218, 874

## E

Electromagnetic compatibility .....	152
Emergency stop monitoring .....	989
Emergency stop testing .....	989
Enabling the drive controller.....	218
Encoder model .....	645
Encoder monitoring .....	665
Encoder signals .....	250
Encoders .....	242, 1059
END OF MODULE (EM) .....	1720
END OF MODULE IF FALSE (EMF) .....	1720
END OF MODULE IF TRUE (EMT).....	1720
EnDat.....	792, 795
EQUAL TO (==).....	1696
EQUAL TO STRING (==) .....	1727
Error list .....	1254
Error messages .....	1254
ESD precautions .....	153
Ethernet.....	1760
EXCLUSIVE OR (XO) .....	1686
EXCLUSIVE OR NOT (XON) .....	1688
Expert programs.....	1476
EXTERN statement .....	1751

## F

FAILTEST.....	989
Fast PLC input.....	1532
Feed rate limitation.....	845
Feed-rate enable.....	852
Field orientation.....	1058, 1084
Field-angle definition.....	1071
File management.....	1489
Filter before position control loop.....	811
Following error.....	841
Formula for analog axis feedback control.....	902, 914
Frequent flexing.....	294

## G

Gantry axes.....	765
Gear ranges.....	1430
Gear shifting.....	1567
GLOBAL statement.....	1751
GREATER THAN (>).....	1698
GREATER THAN OR EQUAL TO (<=).....	1700
GREATER THAN OR EQUAL TO STRING (>=).....	1728
GREATER THAN STRING (>).....	1727

## H

Handshaking.....	1777
Handwheel.....	287, 1333
Handwheel selection switch.....	100
Hard-disk organization.....	1534, 1536
Hardware handshaking.....	1778
Heat generation.....	157
HEIDENHAIN code numbers, changing.....	1231
Help system.....	1278
Hirth coupling.....	702
HR 130.....	289
HR 150.....	100, 1350
HR 150 handwheel.....	99
HR 410.....	98, 287, 1348
HR 420.....	287
HRA 110.....	100, 290, 1350
HSCI configuration.....	238



<b>I</b>	
I2t monitoring .....	965
Icons in the configuration editor .....	332
ID number of HR 150 .....	100
ID number of HR 410 .....	98
IF...ELSE...ENDI .....	1746
INCREMENT (INC).....	1695
INDEX register (X register) .....	1721
Installation elevation .....	158
Interface parameters, specifying and selecting.....	1772
IOconfig.....	238
<b>J</b>	
Jerk.....	809
JUMP (JP) .....	1716
JUMP IF FALSE (JPF).....	1718
JUMP IF TRUE (JPT) .....	1717
<b>K</b>	
Key assignments HR 410 handwheel .....	99
Keystroke simulation .....	1325
KeySynonym .....	377
Kinematics.....	727
Kinematics configuration .....	747
Kinematics, configuring .....	730
<b>L</b>	
LABEL (LBL) .....	1720
LESS THAN (<).....	1697
LESS THAN OR EQUAL TO (<=) .....	1699
LESS THAN OR EQUAL TO STRING (<=).....	1728
LESS THAN STRING (<) .....	1727
Linear axis error compensation .....	711
LOAD (L).....	1664
LOAD BYTE (LB) .....	1669
LOAD DOUBLE WORD (LD) .....	1670
LOAD NOT (LN).....	1666
LOAD STRING (L).....	1725
Logical axes, defining .....	614
Look-ahead .....	825
Look-ahead, configuring .....	1124
Low-pass filter .....	858
LSV2.....	1788
Lubrication pulse .....	690



## M

M function (M strobe) .....	1548
M functions .....	1549, 1561, 1575, 1583
Machine kinematics .....	727, 747
Machine kinematics for lathes .....	747
Machine parameter number .....	342
Machine Parameters mode of operation .....	329
Machine parameters, automated updating .....	140
Machine parameters, change list .....	338
Machine parameters, entering and changing .....	331
Machine parameters, general information .....	327
Machine-parameter access rights .....	347
Machining channels, configuring .....	617
Manual axes .....	643
Manual direction key .....	1430
Master-slave torque control .....	775, 1054
Modules for string processing .....	1730
Monitoring functions .....	946, 996
Monitoring the 5 V supply .....	185
Motor brake .....	983
Motor brake test .....	985
Motor table .....	1078
Motor table, configuring .....	1072
Mounting position .....	159, 160
Movement monitoring .....	953
Mozilla .....	1278
MP number .....	342
MP subfile .....	383
MULTIPLICATION (X) .....	1692

## N

NC macro .....	1555
NET123 .....	1230
Nominal position value filter .....	811
Nominal position value filter for manual traverse .....	901
Nominal position value filter, configuring .....	819, 1124
Nominal position value filters, selection criteria .....	811
Nominal position value filters, settings .....	820
Nonlinear axis error compensation .....	713
NOT EQUAL (<>) .....	1701
NOT EQUAL TO STRING (<>) .....	1729
Number conversion .....	1755



## O

OEM log .....	1266
OEM logo .....	1313
Operating times.....	1373
Options for the OEM.....	135
Options, enabling .....	126
Options, temporary enabling .....	133
OR (O) .....	1682
OR NOT (ON) .....	1684
Oriented spindle stop.....	1001
Oscilloscope .....	1145
Oscilloscope recording, saving/loading .....	1157
OVERWRITE STRING (OVWR).....	1726

## P

Parallel axes.....	762
Parameter backup (selective) .....	1794
Parameter sets, switching.....	398
Parity bit .....	1776
Partitions .....	1534, 1536
PET table .....	1268, 1269
Physical axes .....	631
PLB 6001.....	278
PLC axes .....	616
PLC basic program .....	1486
PLC commands .....	1661
PLC cycle time .....	1481, 1488
PLC error messages.....	1254, 1268
PLC functions.....	1488
PLC inputs.....	1361
PLC main menu.....	1487
PLC outputs.....	214, 1361
PLC partition.....	1534, 1536
PLC program format.....	1659
PLC program structure .....	1660
PLC soft keys .....	1307
Position control loop, opening .....	848
Position controller.....	839
Position controller cycle time .....	808
Position monitoring .....	948
Position-controlled spindle .....	1000
Positioning window .....	956
Power limit.....	894
Power module, configuring .....	1072
Power supply unit, monitoring .....	959
Probing feed rate, limiting .....	1383
Products, overview of .....	163
Profibus .....	237
Programmable axes, configuring.....	628
Programming station mode.....	1233
Protection, degrees of.....	152

## P

PSL 130 .....	189
PSL 135 .....	189
PSL13x low-voltage power supply unit .....	189
Pt 100 .....	235
PULL (PL) .....	1714
PULL LOGICACCU (PLL) .....	1715
PULL WORDACCU (PLW) .....	1716
PUSH (PS) .....	1713
PUSH LOGICACCU (PSL) .....	1714
PUSH WORDACCU (PSW) .....	1715

## R

Rapid traverse .....	845
Reactions if parameters are changed .....	348
Reactor .....	1080
Reference marks .....	789
Reference marks, traversing .....	621, 790, 794
Reference positions .....	1429
REMAINDER (MOD) .....	1694
REPEAT...UNTIL .....	1746
RESET (R) .....	1675
RESET NOT (RN) .....	1677
Returning to the contour .....	622
Reversal-spike compensation for analog axes .....	906, 918
RS-232-C/V.24 interface .....	1766
RS-422/V.11 interface .....	1769
Rules for entries .....	380

## S

S code .....	1572, 1573
S function (S strobe) .....	1560
Safety precautions .....	151
Screen logo .....	1313
SE 640 .....	107
Secondary axes .....	762
Serial interface .....	1766
Series reactor .....	1080
Service files, saving .....	1267
Service pack .....	143
SET (S) .....	1674
SET NOT (SN) .....	1676
SHIFT LEFT (<<) .....	1709
SHIFT RIGHT (>>) .....	1710
Shutting down the control .....	1317
Signal period .....	648
SIK .....	85, 126, 1230

SOFT KEY .....	1309
Soft keys .....	1307
Soft keys for bus diagnostics .....	1503
Soft keys in the Machine Parameters mode of operation .....	330
Software designation .....	125
Software exchange .....	137
Software handshaking .....	1780
Software options .....	122
Software releases .....	150
Specifications .....	111, 374
Speed controller cycle time .....	808
Speed controller, low-pass filter order .....	861
Speed-controlled spindle .....	1009
SPI analog module .....	255
Spindle acceleration .....	1011
Spindle data .....	1404
Spindle in position control loop .....	1000
Spindle in speed control .....	1009
Spindle of the kinematic model .....	1036, 1037
SQL language	
Command options .....	1627
Standstill monitoring .....	955
Status submit (RPLY) .....	1734
Stop bits .....	1777
Storage temperature .....	116
STORE STRING (=) .....	1725
Submit Programs .....	1733
SUBTRACTION (-) .....	1691
Switch positions .....	1351
Switching inputs .....	1365
Switching outputs .....	1365
Switching parameter sets .....	398
Swivel axes .....	748
Symbols used in this manual .....	79
SYS partition .....	1534, 1536
System time .....	1379
System times .....	1373

## T

Table.....	1493
Tabular view of the machine parameters .....	333
Tapping.....	1039
Temperature monitoring.....	962
Testing the motor brake.....	985
Timers .....	1522
TNC partition .....	1534, 1536
TNCbackup.....	149
TNCguide.....	1278
Tool carriers, working with two... ..	1403
Tool editor .....	1405
Tool measurement .....	1384
Topology and cables, HSCI.....	170
Torque limit .....	894
Touch probe .....	260
Trace.....	1495
Transfer .....	1793
Transfer mode.....	1793
Traverse direction.....	663
Traverse direction of the handwheels .....	1429
TRC, Torque Ripple Compensation .....	941
TS 220 .....	106
TS 440 .....	107
TS 444 .....	107
TS 640 .....	107
TS 740 .....	107
TT 130 .....	108

## U

UE 212B, specifications .....	206
UE 230B, specifications .....	206
Unipolar motor.....	1032
Update of NC software .....	137
Update rules .....	351
Updating while software is running.....	141, 145
USB hub .....	268
USB interface .....	268
User parameters.....	365
USES statement.....	1750
Utilization display.....	977
UV 102, specifications.....	192



## V

Velocity .....	809
Velocity feedforward control .....	843
Voltage protection module .....	924
Volts-per-hertz control mode .....	1042

## W

WATCH LIST .....	1491
Weakened field operation .....	924
Weakened-field operation, CC424 settings .....	862
WHILE...ENDW .....	1747

## X

X1 to X3 .....	290
X1 to X6 .....	243, 244
X101 .....	184
X121 .....	237
X127 .....	267
X141, X142 .....	171
X141, X142, X143, X144 .....	268
X15 to X20 .....	246, 247
X169 .....	186
X201 to X210 .....	243, 244
X26 .....	265
X27 .....	267
X31 .....	291
X34 .....	217
X35 to X38 .....	243, 244
X42/33 .....	218
X51 to X62 .....	254
X69 .....	186
X80 to X85 .....	246, 247
XML commands .....	374
XML format .....	366

# HEIDENHAIN

---

## DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

**83301 Traunreut, Germany**

☎ +49 8669 31-0

FAX +49 8669 5061

E-mail: [info@heidenhain.de](mailto:info@heidenhain.de)

---

**Technical support** FAX +49 8669 32-1000

**Measuring systems** ☎ +49 8669 31-3104

E-mail: [service.ms-support@heidenhain.de](mailto:service.ms-support@heidenhain.de)

**TNC support** ☎ +49 8669 31-3101

E-mail: [service.nc-support@heidenhain.de](mailto:service.nc-support@heidenhain.de)

**NC programming** ☎ +49 8669 31-3103

E-mail: [service.nc-pgm@heidenhain.de](mailto:service.nc-pgm@heidenhain.de)

**PLC programming** ☎ +49 8669 31-3102

E-mail: [service.plc@heidenhain.de](mailto:service.plc@heidenhain.de)

**Lathe controls** ☎ +49 8669 31-3105

E-mail: [service.lathe-support@heidenhain.de](mailto:service.lathe-support@heidenhain.de)

---

[www.heidenhain.de](http://www.heidenhain.de)